RESTRICTED
FOR OFFICIAL USE ONLY
DIST: 2, 4
FILE: BEHS

T. O. NO. 01-20EE-4
A.P. NO. 2099B

AIRPLANE PARTS CATALOG

ARMY MODEL
B-17E

BRITISH MODEL
FORTRESS IIA

NOTE: This Technical Order replaces T. O. No. 01-20EE-4 dated October 5, 1942.

NOTICE: This document contains information affecting the National Defense of the United States within the meaning of the Espionage Act, 50 U. S. C., 31 and 32, as amended. Its transmission or the revelation of its contents in any manner to an unauthorized person is prohibited by law.

J.S.S.Co., St.L., 9-17-43 18M

OCTOBER 1, 1943

AVIALOGS.COM

Published by authority of the Commanding General, Army Air Forces, and accepted by the Air Council of the United Kingdom.

THIS PUBLICATION MAY BE USED BY PERSONNEL RENDERING SERVICE TO THE UNITED STATES OR ITS ALLIES

Paragraph 5.*d.* of Army Regulation 380-5 relative to the handling of "restricted" printed matter is quoted below.

"*d.* Dissemination of restricted matter.—The information contained in restricted documents and the essential characteristics of restricted material may be given to *any person known to be in the service of the United States and to persons of undoubted loyalty and discretion who are cooperating in Government work*, but will not be communicated to the public or to the press except by authorized military public relations agencies."

This permits the issue of "restricted" publications to civilian contract and other accredited schools engaged in training personnel for Government work, to civilian concerns contracting for overhaul and repair of aircraft or aircraft accessories, and to similar commercial organizations.

LIST OF REVISED PAGES ISSUED

NOTE: A heavy black vertical line, to the left of the text on revised pages, indicates the extent of the revision. This line is omitted where more than 50 percent of the page is revised.

This issue contains no revisions.

ADDITIONAL COPIES of this publication may be secured on Requisition, AAF Form 102. as prescribed in AAF Regulations 15-102. Submit requisitions to: Commanding General, Air Service Command, Patterson Field, Fairfield, Ohio. Also, see T. O. No. 00-25-3 for details on distribution of Technical Orders. (Requests from Naval activities shall be submitted to: Chief of the Bureau of Aeronautics, Navy Department, Washington, D. C.)

AVIALOGS.COM

TABLE OF CONTENTS

Section		*Page*
I	Introduction	2
II	Group Assembly Parts List	3
	Index	4
	Final Assembly	7
	Wing Installation LH and RH	7
	Control Surface Installation	46
	Fuselage Assembly	53
	Tail Gear Installation	90
	Landing Gear and Brakes Installation	92
	Power Plant Installation	95
	Equipment Installation	127
	Armament Installation	155
	Flight Controls Installation	164
	Wing Flap Controls Installation	169
	Electrical Equipment Installation	169
	Radio Equipment Installation	184
	NOTE: For list of assemblies in above installations, refer to INDEX on page 4.	
III	Numerical Parts List	205
IV	Standard Parts List	257

AVIALOGS.COM

Section 1

INTRODUCTION

INTRODUCTION

1. This catalog lists and describes the parts for the Model B-17E Bombardment Airplane. The British designation for this model is Fortress IIA. The catalog is divided into four sections as shown in the Table of Contents.

2. In section II, the Group Assembly Parts List, the assemblies are broken down into subassemblies and their procurable component parts. Each assembly listed is followed immediately by its component parts properly indented to shown their relationship to the assembly. Installation parts follow immediately the part or last item of assemblies which they serve to attach and are in line with the assembly.

3. The Numerical Parts List, section III, lists all the part numbers shown in the Group Assembly Parts List in numerical sequence and gives the total quantity required per airplane and also the parts list numbers of the group assembly list where each part appears. However, standard parts are listed separately in section IV, the Standard Parts List.

4. The symbol (*) is used in section III and section IV before a part number when that part number appears in numerous parts lists.

AVIALOGS.COM

Section 2

GROUP ASSEMBLY PARTS LIST

AVIALOGS.COM

INDEX

(Parts List No. 1)

1 2 3 4 5	Dwg. No.	Part List Number
FINAL ASSEMBLY	1-18635	5-551
WING INSTALLATION L.H. and R.H.	84-1580	6-112
Wing Assembly—Inner	75-4771	9-94
Nacelle Installation—Inboard	75-4805	28-41
Firewall Assembly—Inboard nacelle	15-8536	36-39
Fairing Installation—Lower inboard nacelle	55-5929	40-41
Nacelle Installation—Outboard	75-4806	42-55
Firewall Assembly—Outboard nacelle	15-8535	50-53
Support Installation—Supercharger—outboard nacelle	65-5965	54-55
Spar Assembly—Wing inner front	78-581	56-66
Spar Assembly—Wing inner rear	78-582	67-71
Spar Installation—Wing gas tank support	74-1500	72-73
Nose Installation—Wing—station 1-3	64-1831	74-76
Nose Installation—Wing—station 7-11	55-7483	77-79
Nose Installation—Wing—station 15-19	15-7476	80-81
Panel Installation—Wing—station 1-6 lower	85-4808	82-85
Panel Installation—Wing—station 1-19 upper	85-5005	86-87
Door Installation—Fuel tank—station 7-11	75-4799	88-89
Support Installation—Flap	64-1490	90-91
Control Installation—Flap	55-5442	92-94
Wing Assembly—Outer	75-4772	95-112
Wing Tip Assembly	75-3590	104-105
Spar Assembly—Front outer	64-1424	106-107
Spar Assembly—Rear outer	64-1425	108-110
Panel Installation—Station 19-½-33 lower	65-4774	111-112
CONTROL SURFACE INSTALLATION	15-7324	113-135
Rudder Assembly	15-7024	117-119
Elevator Assembly	15-7026	120-123
Fin Assembly	15-7023	124-126
Stabilizer Assembly	15-7025	127-129
Flap Assembly—Wing	75-5127	130-131
Aileron Assembly—Fabric covered	58-784	132-135
FUSELAGE ASSEMBLY	15-7377	136-242
Fuselage Assembly—Forward section	15-7330	140-213
Bulkhead Assembly—Station 3	15-9298	167-168
Bulkhead Assembly—Station 4	75-3424	169-173
Bulkhead Assembly—Station 5	85-3425	174-177
Floor Installation—Pilot	75-3513	178-184
Floor Installation—Radio and gunner	75-3577	185-189
Enclosure Installation—Pilots cockpit	55-8765	190-194

(Parts List No. 2)

Door Assembly—Bomb	75-4122	195-197
Strut Installation—Body compartment	75-3445	198-199
Fairing Installation—Top turret	55-6612	200-201
Stiffener Installation—Station 2A-2E circumference	65-5795	202-204
Stiffener Installation—Station 3A-3J	15-7313	205-208
Stiffener Installation—Station 4A-4J circumference	15-7314	209-210

AVIALOGS.COM

INDEX

1 2 3 4 5	Dwg. No.	Part List Number
Stiffener Installation—Station 5A-5H circumference	75-7315	211-213
Fuselage Assembly—Rear section	15-7331	214-236
Inclosure Assembly—Rear gun	15-7360	237-242
TAIL GEAR INSTALLATION	55-7470	243-246
LANDING GEAR and BRAKES INSTALLATION	65-4801	247-253
Control Installation—Landing gear hand retracting	55-5593	252-253
POWER PLANT INSTALLATION	55-7350	254-347
Engine Installation	55-7359	273-278
Fuel System Installation	1-18638	279-295
Tank Installation—Wing fuel	15-7029	280-287
Tank Installation—Auxiliary fuel	15-9462	288-290
Tubing Installation—Fuel	55-7348	291-295
Oil System Installation	65-6242	296-301
Tank Installation—Inboard oil	15-8522	300
Tank Installation—Outboard oil	15-8541	301
Controls Installation—Engine	1-18363	302-326
Controls Installation—Throttle	15-7035	303-317
Stand Installation—Engine control	15-9275	305-317
Control Installation—Mixture	15-7036	318-319
Control Installation—Supercharger	15-7037	320-322
Control Installation—Intercooler temperature	15-7038	323-326
Stand Installation—Carburetor air	55-6070	325-326
Supercharger Installation	65-5680	327-337
Duct Installation—Air inboard	55-5910	330-333
Duct Installation—Air outboard	65-5911	334-337
Cowling Installation—Inboard engines	15-7664	338-341
Cowling Installation—Outboard engine	15-7667	342-343
Oil System Installation—Supercharger lubrication	55-6088	344-345
Tubing Installation—Supercharger regulator	75-6164	346-347
(Parts List No. 3)		
EQUIPMENT INSTALLATION	15-7311	348-422
Board Installation—Pilot and co-pilot instrument	55-7380	373-375
Seat Installation—Pilot and co-pilot	47-1501	376-377
Seat Installation—Bombers	7-1502	378-379
Heating and Ventilating Installation	15-7386	380-389
Controls Installation—Fire extinguisher system	65-5715	390
Fire Extinguisher Installation—Engine	65-5679	391-392
Tubing Installation—System installation	65-5594	393-396
De-icer Installation—Wing and tail	15-7600	397-401
Hydraulic System Installation	75-5821	402-409
Units Installation—Hydraulic system	55-6055	408-409
Anti-icer Installation—Propeller	65-5660	410-411
Life Raft Installation—Auto ejector	64-1698	412
Tubing Installation—Oxygen	15-7365	413-417
Lining Installation—Soundproofing	6-9319	418-422
ARMAMENT INSTALLATION	15-6806	423-448
Control Installation—Bomb racks and doors	15-9255	432-441
Control Installation—Bomb doors	65-4139	436-440
Screw Assembly—Bomb door cont	65-4127	439-440

AVIALOGS.COM

INDEX

1 2 3 4 5	Dwg. No.	Part List Number
Bracket Installation—Main and inboard bomb cont.	75-4083	441
Racks Installation—Bomb	15-7329	442-446
Hoist Installation—Internal bomb	15-7335	447-448
FLIGHT CONTROLS INSTALLATION	1-18364	449-462
Controls Installation—Aileron	15-7030	450-451
Controls Installation—Rudder	15-9254	452-455
Rudder Pedals Installation	65-3508	454-455
Controls Installation—Elevator	15-9253	456-458
Column Installation—Aileron and elevator control	85-3540	457-458
Control Installation—Tail wheel and surface lock	15-7033	459-460
Control Installation—Aileron, rudder and elevator trim tab	15-7034	461-462

(Parts List No. 4)

WING FLAP CONTROLS INSTALLATION	47-1331	463
ELECTRICAL EQUIPMENT INSTALLATION	15-7332	464-501
RADIO EQUIPMENT INSTALLATION	55-7589	502-515
RADIO EQUIPMENT INSTALLATION	15-7931	516-530
RADIO EQUIPMENT INSTALLATION	15-7789	531-551

AVIALOGS.COM

FINAL ASSEMBLY

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 5)	
1-18635	Final Assembly	1
84-1580	Wing Installation—LH (PL 6-112)	1
84-1580-1	Wing Installation—RH (PL 6-112)	1
15-7324	Control Surface Installation (PL 113-135)	1
15-7377	Fuselage Assembly (PL 136-242)	1
55-7470	Tail Gear Installation (PL 243-246)	1
65-4801	Landing Gear and Brakes Installation (PL 247-253)	1
55-7350	Power Plant Installation (PL 254-347)	1
15-7311	Equipment Installation (PL 348-422)	1
15-6806	Armament Installation (PL 423-448)	1
1-18364	Controls Installation—Flight (PL 449-462)	1
47-1331	Control Installation—Wing flap (PL 463)	1
15-7332	Equipment Installation—Electrical (PL 464-501)	1
55-7589	Equipment Installation—Radio (AC41-2393 to 41-2542) (PL 502-515)	1
15-7931	Equipment Installation—Radio (AC41-2543 to 41-2669) (PL 516-530)	1
15-7789	Equipment Installation—Radio (AC41-9011 to 41-9245) (PL 531-545)	1
65-5925	Marking Installation (PL 546-551)	

Wing Installation

	(Parts List No. 6)	
84-1580	Wing Installation LH	1
84-1580-1	Wing Installation RH	1
75-4771-826	Wing Assembly—Inner LH (PL 9-94)	1
75-4771-827	Wing Assembly—Inner RH (PL 9-94)	1
55-4766	Diagram—Wing	
64-1080	Connection Installation—Inner wing LH	1
64-1080-1	Connection Installation—Inner wing RH	1
41-9507	Link—Hoisting	2
386-10A-30	Pin—Taper	4
51-176	Spacer—Wing connection	2
975-14	Washer	4
AN320-14	Nut	4
AN380-4-5	Cotter	4
386-8-24	Pin—Taper	4
386-8-31	Pin—Taper	2
386-9-31	Pin—Taper	4
386-9-32	Pin—Taper	6
386-10-29	Pin—Taper	4
975-9	Washer	6
975-12	Washer	10
975-14	Washer	4
51-176	Spacer—Wing connection	6
AN320-9	Nut	6
AN320-12	Nut	10
AN320-14	Nut	4
AN380-4-4	Cotter	6
AN380-4-5	Cotter	14
75-4772	Wing Assembly—Outer LH (PL 95-112)	1
75-4772-1	Wing Assembly—Outer RH (PL 95-112)	1
55-4766	Diagram—Wing	
55-4764	Connection Installation—Outer wing LH	1
55-4764-1	Connection Installation—Outer wing RH	1
3-8760	Strut Assembly—Front spar	2
41-7609-5-31	Bushing—AN taper pin replacement (for spare parts only)	1
41-7609-5-27	Bushing—AN taper pin replacement (for spare parts only)	1
386-5-24A	Pin—Taper	2
386-5-27A	Pin—Taper	2
51-176-3	Spacer—Wing connection	2
51-176-4	Spacer—Wing connection	2
975-6	Washer	4
364-720	Nut	16
3-8761	Strut Assembly—Rear spar	2
41-7609-5-31	Bushing—AN taper pin replacement (for spare parts only)	1
41-7609-5-27	Bushing—AN taper pin replacement (for spare parts only)	1

Wing Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
386-5-24A	Pin—Taper	2
386-5-27A	Pin—Taper	2
51-176-1	Spacer—Wing connection	2
51-176-2	Spacer—Wing connection	2
975-6	Washer	4
364-624	Nut	8
	(Parts List No. 7)	
364-14A	Pin	16
AN975-7	Washer	16
64-1031	Cover Installation—Wing gap LH	1
64-1031-1	Cover Installation—Wing gap RH	1
64-1031-6	Cover Assembly—Wing gap—upper rear LH	1
64-1031-7	Cover Assembly—Wing gap—upper rear RH	1
64-1031-472	Cover Assembly—Wing gap—upper rear LH	1
64-1031-473	Cover Assembly—Wing gap—upper rear RH	1
64-1031-474	Cover Assembly—Wing gap—upper rear LH	1
64-1031-475	Cover Assembly—Wing gap—upper rear RH	1
1-22946-1	Washer—.019 steel (corrosion resisting)	68
64-1031-32	Door—Hoisting ring access wing gap cover LH	1
64-1031-33	Door—Hoisting ring access wing gap cover RH	1
1-22946-1	Washer—.019 steel (corrosion resisting)	14
64-1031-400	Cover Assembly—Wing gap—leading edge LH	1
64-1031-401	Cover Assembly—Wing gap—leading edge RH	1
64-1031-458	Cover Assembly—Wing gap—leading edge LH	1
64-1031-459	Cover Assembly—Wing gap—leading edge RH	1
64-1031-460	Cover Assembly—Wing gap—leading edge LH	1
64-1031-461	Cover Assembly—Wing gap—leading edge RH	1
64-1031-462	Cover Assembly—Wing gap—leading edge LH	1
64-1031-463	Cover Assembly—Wing gap—leading edge RH	1
1-22946-1	Washer—.019 steel (corrosion resisting)	76
64-1031-408	Cover Assembly—Wing gap—lower front LH	1
64-1031-409	Cover Assembly—Wing gap—lower front RH	1
64-1031-464	Cover Assembly—Wing gap—lower front LH	1
64-1031-465	Cover Assembly—Wing gap—lower front RH	1
1-22946-1	Washer—.019 steel (corrosion resisting)	24
64-1031-410	Cover Assembly—Wing gap—lower center LH	1
64-1031-411	Cover Assembly—Wing gap—lower center RH	1
64-1031-468	Cover Assembly—Wing gap—lower center LH	1
64-1031-469	Cover Assembly—Wing gap—lower center RH	1
1-22946-1	Washer—.019 steel (corrosion resisting)	66
64-1031-418	Door Assembly—Wing access—wing gap cover LH	1
64-1031-419	Door Assembly—Wing access—wing gap cover RH	1
64-1031-470	Door Assembly—Wing gap cover—access LH	1
64-1031-471	Door Assembly—Wing gap cover—access RH	1
64-1031-431	Door—Wing gap cover—access LH	1
64-1031-432	Door—Wing gap cover—access RH	1
1-22946-1	Washer—.019 steel (corrosion resisting)	22
64-1031-500	Cover Assembly—Wing gap—lower rear LH	1
64-1031-501	Cover Assembly—Wing gap—lower rear RH	1
64-1031-502	Cover Assembly—Wing gap—lower rear LH	1
64-1031-503	Cover Assembly—Wing gap—lower rear RH	1
1-22946-1	Washer—.019 steel (corrosion resisting)	54
	(Parts List No. 8)	
64-1031-425	Cover Assembly—Wing gap—upper center LH	1
64-1031-426	Cover Assembly—Wing gap—upper center RH	1
64-1031-466	Cover Assembly—Wing gap—upper center LH	1
64-1031-467	Cover Assembly—Wing gap—upper center RH	1

AVIALOGS.COM

FINAL ASSEMBLY

Wing Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-22946-1	Washer	80
41-5881	Brace Assembly—Wing comp. strut support	2
41-5881-1	Brace Assembly—Wing comp. strut support	2
BAC1615-19	Spacer—5/32 rivet	12
AN4-10	Bolt	8
AN960-416	Washer	8
AN310-4	Nut	8
AN380-2-2	Cotter	8
84-1580-8	Cover—Wing gap—rear LH	1
84-1580-9	Cover—Wing gap—rear RH	1
84-1580-10	Cover—Wing gap—lower LH	1
84-1580-11	Cover—Wing gap—lower RH	1
84-1580-14	Cover—Wing gap—upper LH	1
84-1580-15	Cover—Wing gap—upper RH	1
84-1580-16	Cover—Wing gap—lower LH	1
84-1580-17	Cover—Wing gap—lower RH	1

Wing Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
84-1580-700	Cover—Wing gap—upper LH	1
84-1580-701	Cover—Wing gap—lower RH	1
84-1580-702	Cover—Wing gap—nose LH	1
84-1580-703	Cover—Wing gap—nose RH	1
21-3147-1	Washer—.019 steel (corrosion resisting)	84
BAC1901	Washer—Flat head screw	120
526-1032-7	Screw	84
AN510-10-9	Screw	120
365-1032	Nut	2
AN5-11A	Bolt	48
AN6-12A	Bolt	48
AN960-516	Washer	48
AN960-616	Washer	48
365-524	Nut	48
365-624	Nut	48

WING INSTALLATION

Wing Assembly—Inner

(Parts List No. 9)

75-4771-826	Wing Assembly—Inner LH	1
75-4771-827	Wing Assembly—Inner RH	1
75-4805	Nacelle Installation—Inboard LH (PL 28-41)	1
75-4805-1	Nacelle Installation—Inboard RH (PL 28-41)	1
75-4806	Nacelle Installation—Outboard LH (PL 42-55)	1
75-4806-1	Nacelle Installation—Outboard RH (PL 42-55)	1
78-581	Spar Assembly—Wing inner front LH (PL 56-66)	1
78-581-1	Spar Assembly—Wing inner front RH (PL 56-66)	1
78-582	Spar Assembly—Wing spar—rear—LH (PL 67-71)	1
78-582-1	Spar Assembly—Wing spar—rear—RH (PL 67-71)	1
74-1500	Spar Installation—Wing gas tank support LH (PL 72-73)	1
74-1500-1	Spar Installation—Wing gas tank support RH (PL 72-73)	1
64-1831	Nose Installation—Wing station 1-3 LH (PL 74-76)	1
64-1831-1	Nose Installation—Wing station 1-3 RH (PL 74-76)	1
55-7483	Nose Installation—Wing station 7-11 LH (PL 77-79)	1
55-7483-1	Nose Installation—Wing station 7-11 RH (PL 77-79)	1
15-7476	Nose Installation—Wing station 15-19 LH (PL 80-81)	1
15-7476-1	Nose Installation—Wing station 15-19 RH (PL 80-81)	1
85-4808	Panel Installation—Wing station 1-6 lower LH (PL 82-85)	1
85-4808-1	Panel Installation—Wing station 1-6 lower RH (PL 82-85)	1
85-5005	Panel Installation—Wing station 1-19 upper LH (PL 86-87)	1
85-5005-1	Panel Installation—Wing station 1-19 upper RH (PL 86-87)	1
75-4799	Door Installation—Fuel tank—station 7-11 lower LH (PL 88-89)	1
75-4799-1	Door Installation—Fuel tank—station 7-11 lower RH (PL 88-89)	1
64-1490	Support Installation—Flap LH (PL 90-91)	1
64-1490-1	Support Installation—Flap RH (PL 90-91)	1
55-5442	Control Installation—Flap LH (PL 92-94)	1
55-5442-1	Control Installation—Flap RH (PL 92-94)	1

Wing Assembly—Inner

65-4818-33	Panel Installation—Wing—station 11-19 lower LH	1
65-4818-34	Panel Installation—Wing—station 11-19 lower RH	1
65-4818-400	Skin Assembly—Panel—station 11-19 lower LH	1
65-4818-401	Skin Assembly—Panel—station 11-19 lower RH	1
3-12040-2	Plate—Corrugated splice	22
3-12041-2	Plate—Corrugated splice	18
3-12041-7	Plate—Corrugated splice	6
1-20561	Shim—Corrugated	6
1-20564	Shim—Corrugated	2
14-2046	Rib Installation—Wing—station No. 1 comp. LH	1
14-2046-1	Rib Installation—Wing—station No. 1 comp. RH	1

(Parts List No. 10)

14-2046-42	Rib Assembly—Wing—station No. 1 comp. LH	1
14-2046-43	Rib Assembly—Wing—station No. 1 comp. RH	1
43-8784	Joint Assembly—Wing rib station 1	1
BAC114-36DD	Bolt—Bearing	2
BAC1604-112	Spacer—¼ bolt	2
6-11568	Joint Assembly—Wing rib—station 1 LH	1
6-11568-1	Joint Assembly—Wing rib—station 1 RH	1
3-8785	Joint Assembly—Wing rib station 1 LH	1
3-8785-1	Joint Assembly—Wing rib station 1 RH	1
41-1433	Channel—Cradle support LH	1
41-1433-3	Channel—Cradle support RH	1
3-8786	Joint Assembly—Wing rib station 1 LH	1
3-8786-1	Joint Assembly—Wing rib station 1 RH	1
41-3125-2	Link—Fuel tank brace	2
41-3125-3	Link—Fuel tank brace	2
BAC114-40S	Bolt—Bearing	4
21-6862-32-17	Washer—.125 aluminum alloy	4
BAC1604-112	Spacer—¼ bolt	4
41-1433-1	Channel—Cradle support LH	1
41-1433-4	Channel—Cradle support RH	1
3-8787	Joint Assembly—Wing rib station 1 LH	1
3-8787-1	Joint Assembly—Wing rib station 1 RH	1
41-1433-2	Channel—Gas tank support LH	1
41-1433-5	Channel—Gas tank support RH	1
43-8788	Joint Assembly—Wing rib station 1	2
43-8789	Joint Assembly—Wing rib station 1	2
BAC1604-112	Spacer—¼ bolt	2
3-9782	Joint Assembly—Wing rib station 1 LH	1

AVIALOGS.COM

WING INSTALLATION

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-9782-1	Joint Assembly—Wing rib—station 1 RH	1
41-9870	Tee—Support	2
BAC113-10S	Bolt—Bearing	2
6-11568	Joint Assembly—Wing rib—station 1 LH	1
6-11568-1	Joint Assembly—Wing rib—station 1 RH	1
1-24223	Angle—⅜ x ¾ x .081	2
1-24223-1	Angle—⅜ x ¾ x .081	2
41-9870	Tee—Support	4
41-6511-400	Gusset—Air seal ring	4
41-6511-401	Angle—Air seal ring LH	1
41-6511-402	Angle—Air seal ring LH	1
41-6511-403	Angle—Air seal ring RH	1
41-6511-404	Angle—Air seal ring RH	1
51-497	Lug—Strut brace	2
BAC113S10A	Bolt—Bearing	4
BAC113-42A	Bolt—Bearing	4
BAC113-10S	Bolt—Bearing	4
BAC1603-112	Spacer—No. 10 bolt	4
	(Parts List No. 11)	
43-9153	Joint Assembly—Wing rib—station 1	2
46-6520	Joint Assembly— Wing rib—station 1 LH	1
46-6520-1	Joint Assembly—Wing rib—station 1 RH	1
41-3125	Link—Fuel tank brace	2
41-3125-1	Link—Fuel tank brace	2
BAC1604-112	Spacer—¼ bolt	4
21-6862-32-17	Washer—.125 aluminum alloy	4
1-16763	Zee—Duct support	1L
51-497	Lug—Strut brace	2
BAC53-S25.5A	Bolt—Close tolerance	4
BAC53-S6A	Bolt—Close tolerance	4
BAC1603-112	Spacer—No. 10 bolt	4
6-8328	Bracket Installation—Intercooler temperature control LH	1
6-8328-1	Bracket Installation—Intercooler temperature control RH	1
6-8328-2	Bracket Assembly—Intercooler temperature control LH	1
6-8328-3	Bracket Assembly—Intercooler temperature control RH	1
BAC1614-28	Spacer—⅛ rivet	2
BAC1614-36	Spacer—⅛ rivet	4
BAC1603-8	Spacer—No. 10 bolt	4
BAC113-S10A	Bolt—10-32 bearing	2
14-2046-26	Angle—Station No. 1 comp. wing rib	1L
14-2046-27	Angle—Station No. 1 comp. wing rib	1L
BAC113A37S	Bolt—Bearing	1L
14-2046-28	Angle—Station No. 1 comp. wing rib	2L
14-2046-29	Angle—Station No. 1 comp. wing rib	1L
14-2046-2	Chord Assembly—Upper station No. 1 comp. wing rib	1
14-2046-3	Chord Assembly—Upper station No. 1 comp. wing rib	1
14-2046-8	Chord Assembly—Lower station No. 1 comp. wing rib	1
14-2046-9	Chord Assembly—Lower station No. 1 comp. wing rib	1
41-9465	Ring—Hoisting—wing	4
51-223	Spring—Hoisting—wing	4
41-9417	Hinge—Hoisting—ring—wing	2
41-9417-1	Hinge—Hoisting—ring—wing	2
41-9870	Tee—Support	2
BAC115-DD9A	Bolt—Bearing	18
BAC115-DD10A	Bolt—Bearing	30
BAC115-DD11A	Bolt—Bearing	30
BAC115-DD12A	Bolt—Bearing	10
BAC115-DD37A	Bolt—Bearing	22
BAC115-DD41A	Bolt—Bearing	4
BAC115-DD42A	Bolt—Bearing	4
BAC1604-112	Spacer—¼ bolt	8
BAC1605-97	Spacer—¼ bolt	2
BAC1605-106	Spacer—¼ bolt	4

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 12)	
BAC1605-111	Spacer—¼ bolt	4
BAC538-7	Clamp—Loop type cushioned	2
1-13892-56-12	Clamp—Tabulated square	2
14-2046-34	Angle—Wiring support	1
14-2046-35	Angle—Wiring support	1
NAS54A-23DD	Bolt—Close tolerance	20
48-597-10	Rib Installation—Wing—station 2 LH	1
48-597-11	Rib Installation—Wing—station 2 RH	1
48-597-2	Rib Assembly—Wing—station LH	1
48-597-3	Rib Assembly—Wing—station RH	1
51-106	Bracket—Wing rib	2
51-106-1	Bracket—Wing rib	2
51-107-1	Gusset—Wing rib	8
51-134-10-14	Spacer—Micarta	8
41-3390	Gusset—Wing rib	4
41-3390-1	Gusset—Wing rib	4
1-18050	Spacer—Wing and tail rib	4
58-598	Rib Installation—Wing—station 3 LH	1
58-598-1	Rib Installation—Wing—station 3 RH	1
58-598-500	Rib Assembly—Wing—station 3 LH	1
58-598-501	Rib Assembly—Wing—station 3 RH	1
58-598-505	Chord Assembly—Upper LH	1
58-598-506	Chord Assembly—Upper RH	1
41-3390	Gusset—Wing rib	4
41-3390-1	Gusset—Wing rib	4
58-598-507	Chord Assembly—Lower front LH	1
58-598-508	Chord Assembly—Lower front RH	1
51-105	Bracket—Wing rib LH	1
51-105-1	Bracket—Wing rib RH	1
51-107	Gusset—Wing rib	4
51-134-10-16	Spacer—Micarta	4
58-598-509	Chord Assembly—Lower rear LH	1
58-598-510	Chord Assembly—Lower rear RH	1
51-105-1	Bracket—Wing rib LH	1
51-105	Bracket—Wing rib RH	1
51-107	Gusset—Wing rib	4
51-134-10-16	Spacer—Micarta	4
1-18050-0	Spacer—Wing and tail rib	4
14-2044	Rib Installation—Wing station 4 LH	1
14-2044-1	Rib Installation—Wing station 4 RH	1
14-2044-25	Rib Assembly—Wing station 4 LH	1
14-2044-26	Rib Assembly—Wing station 4 RH	1
14-2044-14	Chord Assembly—Upper wing station 4	1
14-2044-15	Chord Assembly—Upper wing station 4	1
3-9182	Joint Assembly—Wing rib station 4 LH	1
3-9182-1	Joint Assembly—Wing rib station 4 RH	1
3-9277-1	Channel Cradle Support LH	1
3-9277-4	Channel Cradle Support RH	1
	(Parts List No. 12A)	
3-9183	Joint Assembly—Wing rib station 4 LH	1
3-9183-1	Joint Assembly—Wing rib station 4 RH	1
3-9277-2	Channel—Cradle support LH	1
3-9277-5	Channel—Cradle support RH	1
3-9184	Joint Assembly—Wing rib station 4	2
3-9185	Joint Assembly—Wing rib station 4	2
3-9186	Joint Assembly—Wing rib station 4	2
6-5918	Joint Assembly—Wing rib station 4	2
BAC1604-172	Spacer—¼ bolt	8
	(Parts List No. 13)	
53-9181	Joint Assembly—Wing rib station 4 LH	1
53-9181-1	Joint Assembly—Wing rib station 4 RH	1
53-9181-502	Angle—Wing rib station 4 RH	2
NAS54DD34A	Bolt—Close tolerance	2
BAC1604-172	Spacer—¼ bolt	2
3-9277	Channel Cradle Support LH	1
3-9277-3	Channel Cradle Support RH	1
68-590	Joint Assembly—Wing rib station 4 LH	1
68-590-1	Joint Assembly—Wing rib station 4 RH	1
BAC54S36A	Bolt—Close tolerance	4
BAC54DD36A	Bolt—Close tolerance	8

AVIALOGS.COM

WING INSTALLATION

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC57DD35A	Bolt—Close tolerance	4
BAC57DD37.5A	Bolt—Close tolerance	12
BAC1604-152	Spacer—¼ bolt	4
BAC1604-172	Spacer—¼ bolt	36
1-20022-1	Angle—Tube support	8
6-8009	Bracket Installation—Supercharger control LH	1
6-8009-1	Bracket Installation—Supercharger control RH	1
6-8009-2	Bracket Assembly—Supercharger control LH	1
6-8009-3	Bracket Assembly—Supercharger control RH	1
6-8009-4	Plate Assembly—Supercharger control bracket	1
6-8009-5	Plate Assembly—Supercharger control bracket	1
6-8009-6	Plate Assembly—Supercharger control bracket	1
6-8009-7	Plate Assembly—Supercharger control bracket	1
BAC1603-101	Spacer—No. 10 bolt	4
BAC1604-8	Spacer—¼ bolt	2
BAC1604-12	Spacer—¼ bolt	2
BAC1604-18	Spacer—¼ bolt	2
6-8329	Bracket Installation—Intercooler oil temperature control LH	1
6-8329-1	Bracket Installation—Intercooler oil temperature control RH	1
6-8329-2	Bracket Assembly—Intercooler oil temperature control LH	1
6-8329-3	Bracket Assembly—Intercooler oil temperature control RH	1
BAC1603-80	Spacer—No. 10 bolt	2
BAC1603-84	Spacer—No. 10 bolt	6
41-445-0-4	Spacer—No. 10 bolt	6
6-8329-9	Angle—Intercooler temperature control bracket LH	1
6-8329-10	Angle—Intercooler temperature control bracket RH	1
6-8329-11	Angle—Intercooler temperature control bracket LH	1
6-8329-12	Angle—Intercooler temperature control bracket RH	1
BAC1603-8	Spacer—No. 10 bolt	2
BAC1603-28	Spacer—No. 10 bolt	2
BAC1603-37	Spacer—No. 10 bolt	2
BAC1603-57	Spacer—No. 10 bolt	2
3-12985	Strap Installation—Inboard fuel tank station 4 LH	1
3-12985-1	Strap Installation—Inboard fuel tank station 4 RH	1
3-12985-3	Strap Assembly—Inboard fuel tank station 4	2
3-12985-2	Strap—Inboard fuel tank station 4	2
41-2787	Fitting—Strap—tank installation	8
3-12213	Angle Installation—Cooling air duct station 4	1
3-12213-1	Angle Installation—Cooling air duct station 4	1
	(Parts List No. 14)	
3-12213-2	Angle Assembly—Cooling air duct station 4 LH	1
3-12213-3	Angle Assembly—Cooling air duct station 4 RH	1
1-20207	Plate—Tube support	2
54-2044-400	Tube—Wing rib station 4	2
54-2044-401	Tube—Wing rib station 4	2
54-2044-402	Tube—Wing rib station 4	2
54-2044-403	Tube—Wing rib station 4	2
54-2044-404	Tube—Wing rib station 4	2
54-2044-405	Tube—Wing rib station 4	2
54-2044-406	Tube—Wing rib station 4	2

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
54-2044-407	Tube—Wing rib station 4	2
54-2044-408	Tube—Wing rib station 4	2
54-2044-409	Tube—Wing rib station 4	2
BAC1603-18	Spacer—No. 10 bolt	2
BAC115-11DD	Bolt—Bearing	52
BAC115-12DD	Bolt—Bearing	24
BAC115-13DD	Bolt—Bearing	16
BAC115-14DD	Bolt—Bearing	16
BAC115-54DD	Bolt—Bearing	24
BAC116-56DD	Bolt—Bearing	26
14-2044-18	Filler—Wing rib station 4	4
14-2044-23	Filler—Wing rib station 4	4
BAC1604-172	Spacer—¼ bolt	10
BAC113-49S	Bolt—10-32 bearing	4
51-471-1	Clip—Supercharger brace	2
64-1512	Rib Installation—Wing—station 5 LH	1
64-1512-1	Rib Installation—Wing—station 5 RH	1
64-1512-8	Rib Assembly—Wing—station 5 LH	1
64-1512-9	Rib Assembly—Wing—station 5 RH	1
21-5887-6	Gusset—Tail ribs	12
21-5887-3	Gusset—Tail ribs	4
21-5887-4	Gusset—Tail ribs	4
21-6730-28-7	Spacer—5/16 micarta	2
64-1512-530	Spacer—Wing rib station 5	2
1-18050	Spacer—Wing and tail rib	2
64-1512-402	Rib Assembly—Wing center section LH	1
64-1512-403	Rib Assembly—Wing center section RH	1
41-7583	Gusset—Wing rib LH	2
41-7583-1	Gusset—Wing rib RH	2
41-7583-2	Gusset—Wing rib LH	2
41-7583-3	Gusset—Wing rib RH	2
41-8378-1	Gusset—Wing rib	4
41-8379-1	Gusset—Wing rib	4
41-871-50-22	Spacer—7/16 micarta	2
41-871-50-13	Spacer—7/16 micarta	2
64-1512-530	Spacer—Wing rib station 5	2
41-871-51-13	Spacer—7/16 micarta	2
41-468-28-8	Clamp—Square loop type	2
BAC1603-50	Spacer—No. 10 bolt	2
3-13785	Support Installation—Supercharger control LH	1
3-13785-3	Support Installation—Supercharger control RH	1
41-7574-30-9	Clamp Assembly—Tabulated square	4
	(Parts List No. 15)	
41-468-30-9	Clamp—Square loop type	4
51-84	Bracket—Station 5 rib	2
51-85	Bracket—Station 5 rib	2
41-871-50-13	Spacer—7/16 micarta	4
41-871-49-13	Spacer—7/16 micarta	2
59-2410	Rib Installation—Wing station 6 LH	1
59-2410-1	Rib Installation—Wing station 6 RH	1
59-2410-515	Rib Assembly—Wing station 6 LH	1
59-2410-516	Rib Assembly—Wing station 6 RH	1
59-2410-509	Chord Assembly—Rib—upper LH	1
59-2410-510	Chord Assembly—Rib—upper RH	1
43-9270	Joint Assembly—Wing—rib station 6	2
43-9271-5	Joint Assembly—Wing rib station 6 LH	1
43-9271-6	Joint Assembly—Wing rib station 6 RH	1
3-11890-1	Channel—Wing tank spar	2
NAS54-DD30.5	Bolt—Close tolerance	4
BAC1604-116	Spacer—¼ bolt	2
BAC1604-130	Spacer—¼ bolt	2
3-9272	Joint Assembly—Wing rib—station 6	2
3-9273	Joint Assembly—Wing rib—station 6	1
43-9274	Joint Assembly—Wing rib—station 6 LH	1
43-9274-1	Joint Assembly—Wing rib—station 6 RH	1
3-11890	Channel—Wing tank spar	2
BAC54-DD30.5	Bolt—Close tolerance	4
BAC1604-127	Spacer—¼ bolt	4
43-9284	Joint Assembly—Wing rib—station 6	2

AVIALOGS.COM

WING INSTALLATION

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1604-140	Spacer—¼ bolt	2
68-589	Joint Assembly—Wing rib station 6 LH	1
68-589-1	Joint Assembly—Wing rib station 6 RH	1
NAS54DD31.5	Bolt—Close tolerance	6
NAS54S31.5	Bolt—Close tolerance	4
BAC1604-128	Spacer—¼ bolt	4
BAC1604-140	Spacer—¼ bolt	42
1-20022-1	Angle—Tube support	2
BAC1603-140	Spacer—No. 10 bolt	2
BAC1603-16	Spacer—No. 10 bolt	2
51-471-1	Clip—Supercharger brace	2
NAS53-25.5A	Bolt—10-32 bearing	4
NAS55A-5.5DD	Bolt—Bearing	28
NAS55A-6DD	Bolt—Bearing	32
NAS55A-6.5DD	Bolt—Bearing	16
NAS55A-7DD	Bolt—Bearing	16
NAS55A-27DD	Bolt—Bearing	16
NAS55A-30DD	Bolt—Bearing	24

(Parts List No. 16)

BAC1604-140	Spacer—¼ bolt	14
55-4817	Cradle Installation—Inboard fuel tank LH	1
55-4817-1	Cradle Installation—Inboard fuel tank RH	1
55-4817-400	Cradle Assembly—Inboard fuel tank LH	1
55-4817-401	Cradle Assembly—Inboard fuel tank RH	1
41-3845-1	Angle—Cradle attachment	8
1-16050-39-6	Cushion—Tank support	2
55-4817-402	Cradle Assembly—Inboard fuel tank LH	1
55-4817-403	Cradle Assembly—Inboard fuel tank RH	1
41-3845-1	Angle—Cradle attachment	8
1-16050-39-6	Cushion—Tank support	2
55-4817-404	Cradle Assembly—Inboard fuel tank LH	1
55-4817-405	Cradle Assembly—Inboard fuel tank RH	1
41-3845-1	Angle—Cradle attachment	8
1-16050-39-6	Cushion—Tank support	2
68-715	Cradle Installation—Fuel tanks—station 7 LH	1
68-715-1	Cradle Installation—Fuel tanks—station 7 RH	1
68-715-600	Cradle Assembly—Fuel tanks—station 7 LH	1
68-715-601	Cradle Assembly—Fuel tanks—station 7 RH	1
41-1458-1-0	Spacer—⅛ countersunk rivet	2
BAC1614-64	Spacer—⅛ rivet	2
68-715-614	Cradle Assembly—Fuel tank—station 7 LH	1
68-715-615	Cradle Assembly—Fuel tank—station 7 RH	1
BAC1614-64	Spacer—⅛ rivet	6
1-16050-31-5	Cushion—Tank support	2
1-16050-55-0	Cushion—Tank support	2
68-716	Cradle Installation—Fuel tank center section—station 8 LH	1
68-716-1	Cradle Installation—Fuel tank center section—station 8 RH	1
68-716-600	Cradle Assembly—Fuel tank center section—station 8 LH	1
68-716-601	Cradle Assembly—Fuel tank center section—station 8 RH	1
BAC1614-64	Spacer—⅛ rivet	2
41-1458-1-0	Spacer—⅛ countersunk rivet	2
68-716-614	Cradle Assembly—Fuel tank center section—station 8 LH	1
68-716-615	Cradle Assembly—Fuel tank center section—station 8 RH	1
BAC1614-64	Spacer—⅛ rivet	2
1-16050-52-6	Cushion—Tank support	2
1-16050-31-5	Cushion—Tank support	2
78-717	Cradle Installation—Fuel tank station 9 LH	1
78-717-1	Cradle Installation—Fuel tank station 9 RH	1

(Parts List No. 17)

78-717-700	Cradle Assembly—Fuel tank station 9 LH	1
78-717-701	Cradle Assembly—Fuel tank station 9 RH	1
BAC1614-64	Spacer—⅛ rivet	2
41-1458-1-0	Spacer—⅛ countersunk rivet	2

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
78-717-714	Cradle Assembly—Fuel tank station 9 LH	1
78-717-715	Cradle Assembly—Fuel tank station 9 RH	1
BAC1614-64	Spacer—⅛ rivet	8
1-16050-31-5	Cushion—Tank support	2
1-16050-50-6	Cushion—Tank support	2
68-718	Cradle Installation—Fuel tank—station 10 LH	1
68-718-1	Cradle Installation—Fuel tank—station 10 RH	1
68-718-600	Cradle Assembly—Fuel tanks station 10 LH	1
68-718-601	Cradle Assembly—Fuel tanks station 10 RH	1
BAC1614-64	Spacer—⅛ rivet	2
41-1458-1-0	Spacer—⅛ countersunk rivet	2
68-718-614	Cradle Assembly—Fuel tank station 10 LH	1
68-718-615	Cradle Assembly—Fuel tank station 10 RH	1
BAC1614-64	Spacer—⅛ rivet	8
1-16050-31-5	Cushion—Tank support	2
1-16050-48-4	Cushion—Tank support	2
68-719	Cradle Installation—Fuel tanks station 11 LH	1
68-719-1	Cradle Installation—Fuel tanks station 11 RH	1
68-719-600	Cradle Assembly—Fuel tanks station 11 LH	1
68-719-601	Cradle Assembly—Fuel tanks station 11 RH	1
BAC1614-64	Spacer—⅛ rivet	2
41-1458-1-0	Spacer—⅛ countersunk rivet	2
68-719-614	Cradle Assembly—Fuel tank station 11 LH	1
68-719-615	Cradle Assembly—Fuel tank station 11 RH	1
BAC1614-64	Spacer—⅛ rivet	8
1-16050-31-5	Cushion—Tank support	2
1-16050-45-4	Cushion—Tank support	2
64-1505	Rib Installation—Wing station 12 LH	1
64-1505-1	Rib Installation—Wing station 12 RH	1
64-1505-20	Rib Installation—Wing tail section station 12 LH	1
64-1505-21	Rib Installation—Wing tail section station 12 RH	1

(Parts List No. 18)

64-1505-10	Rib Assembly—Wing tail section station 12 LH	1
64-1505-11	Rib Assembly—Wing tail section station 12 RH	1
21-6136-1	Gusset—Wing ribs	4
21-5887-1	Gusset—Tail ribs	12
21-5887-6	Gusset—Tail ribs	12
1-18050	Spacer—Wing and tail rib	2
59-2411	Rib Installation—Wing—station 13 LH	1
59-2411-1	Rib Installation—Wing—station 13 RH	1
59-2411-412	Rib Assembly—Wing—station 13 LH	3
59-2411-413	Rib Assembly—Wing—station 13 RH	3
3-9368	Joint Assembly—Wing rib station 13	2
43-9369	Joint Assembly—Wing rib station 13 LH	1
43-9369-1	Joint Assembly—Wing rib station 13 RH	1
3-11891	Channel—Wing spar tank	2
NAS54-DD24.5	Bolt—Close tolerance	4
BAC1604-104	Spacer—¼ bolt	4
43-9370	Joint Assembly—Wing rib station 13 LH	1
43-9370-1	Joint Assembly—Wing rib station 13 RH	1
3-11891-1	Channel—Wing spar tank	2
NAS54-DD24.5	Bolt—Close tolerance	4
BAC1604-104	Spacer—¼ bolt	2
BAC1604-106	Spacer—¼ bolt	2
3-9371	Joint Assembly—Wing rib—station 13	2
3-9372	Joint Assembly—Wing rib—station 13	2
BAC114A38DD	Bolt—¼—28 bearing	28
64-1504	Rib Installation—Wing—center section—station 14 LH	1
64-1504-1	Rib Installation—Wing—center section—station 14 RH	1
64-1504-2	Rib Assembly—Wing—center section—station 14 LH	1
64-1504-3	Rib Assembly—Wing—center section—station 14 RH	1
21-5511	Gusset—Wing rib	4
21-5511-1	Gusset—Wing rib	4
21-5512-1	Gusset—Wing rib	4
41-871-59-12	Spacer—1/16 micarta	4
64-1504-23	Rib Installation—Wing—tail section station 14 LH	1

AVIALOGS.COM

WING INSTALLATION

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
64-1504-24	Rib Installation—Wing—tail section station 14 RH	1
64-1504-8	Rib Assembly Wing—Tail section station 14 LH	1
64-1504-9	Rib Assembly Wing—Tail section station 14 RH	1
BAC1615-35	Spacer—5/32 rivet	8
BAC1615-42	Spacer—5/32 rivet	6
21-5534	Gusset—Wing rib	12
41-1606-37-11	Spacer—3/8 micarta	2
1-18050-14	Spacer—Wing and tail rib	2
48-1217	Rib Installation—Station 14½ LH	1
48-1217-1	Rib Installation—Station 14½ RH	1
48-1217-2	Rib Assembly—Station 14½ LH	1
48-1217-3	Rib Assembly—Station 14½ RH	1
	(Parts List No. 19)	
51-282	Gusset—Wing rib	2
51-282-1	Gusset—Wing rib	2
1-17458	Gusset—Wing rib	2
1-17458-1	Gusset—Wing rib	2
21-6730-28-10	Spacer—5/16 micarta	4
84-1123-407	Rib Installation—Wing—center section station 15 LH	1
84-1123-408	Rib Installation—Wing—center section station 15 RH	1
84-1123-700	Rib Assembly Wing—center section station 15 LH	1
84-1123-701	Rib Assembly Wing—center section station 15 RH	1
1-18389	Gusset—Wing rib	4
1-18389-1	Gusset—Wing rib	4
1-18394	Gusset—Wing rib	2
1-18394-1	Gusset—Wing rib	2
1-18395	Gusset—Wing rib	2
1-18395-1	Gusset—Wing rib	2
21-9392-1	Gusset—Wing rib	8
1-18050-0	Spacer—Wing and tail rib	4
84-1123-419	Rib Installation—Wing—tail section station 15 LH	1
84-1123-420	Rib Installation—Wing—tail section station 15 RH	1
84-1123-421	Rib Assembly—Tail section station 15 LH	1
84-1123-422	Rib Assembly—Tail section station 15 RH	1
1-19653-1	Gusset—Wing rib	4
1-19654	Gusset—Wing rib	4
21-5887-1	Gusset—Tail rib	16
1-18050	Spacer—Wing tail rib	2
1-18050	Spacer—Wing and tail rib	2
48-1202	Rib Installation—Station 15½ LH	1
48-1202-1	Rib Installation—Station 15½ RH	1
48-1202-2	Rib Assembly—Station 15½ LH	1
48-1202-3	Rib Assembly—Station 15½ RH	1
51-282	Gusset—Wing rib	4
51-282-1	Gusset	4
1-18050-2	Spacer—Wing and tail rib	4
84-1124-407	Rib Installation—Wing—center section station 16 LH	1
84-1124-408	Rib Installation—Wing—center section station 16 RH	
84-1124-700	Rib Assembly—Wing—center section station 16 LH	1
84-1124-701	Rib Assembly—Wing—center section station 16 RH	1
1-18260	Gusset—Wing rib	2
1-18260-1	Gusset—Wing rib	2
1-18389	Gusset—Wing rib	4
1-18389-1	Gusset—Wing rib	4
1-18395	Gusset—Wing rib	2
1-18395-1	Gusset—Wing rib	2
21-9392-1	Gusset—Wing rib	8
1-18050-0	Spacer—Wing and tail rib	4

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
84-1124-419	Rib Installation—Wing—tail section—station 16 LH	1
84-1124-420	Rib Installation—Wing—tail section—station 16 RH	1
84-1124-421	Rib Assembly—Wing—tail section—station 16 LH	1
	(Parts List No. 20)	
84-1124-422	Rib Assembly—Wing—tail section—station 16 RH	1
1-19653	Gusset—Wing rib	4
1-19653-1	Gusset—Wing rib	4
21-5887-1	Tail ribs	16
1-18050	Spacer—Wing and tail rib	2
1-18050-0	Spacer—Wing and tail rib	2
94-1125-407	Rib Installation—Wing—center section—station 17 LH	1
94-1125-408	Rib Installation—Wing—center section—station 17 RH	1
94-1125-806	Rib Assembly—Wing—center section—station 17 LH	1
94-1125-807	Rib Assembly—Wing—center section—station 17 RH	1
21-9392-1	Gusset—Wing rib	20
1-18050-0	Spacer—Wing and tail rib	4
94-1125-419	Rib Installation—Wing tail section—station 17 LH	1
94-1125-420	Rib Installation—Wing tail section—station 17 RH	1
94-1125-421	Rib Assembly—Wing—tail section—station 17 LH	1
94-1125-422	Rib Assembly—Wing—tail section—station 17 RH	1
21-5887-1	Gusset—Tail rib	12
21-6730-28-7	Spacer—5/16 micarta	2
1-18050-0	Spacer—Wing and tail rib	2
94-1126-500	Rib Installation—Wing—station 18 LH	1
94-1126-501	Rib Installation—Wing—station 18 RH	1
94-1126-806	Rib Assembly—Wing—center section—station 18 LH	1
94-1126-807	Rib Assembly—Wing—center section—station 18 RH	1
21-9392-1	Gusset—Wing rib	20
1-18050-0	Spacer—Wing and tail rib	4
94-1126-421	Rib Assembly—Wing—tail section—station 18 LH	1
94-1126-422	Rib Assembly—Wing—tail section—station 18 RH	1
21-5534	Gusset—Wing rib	12
BAC1615-35	Spacer—5/32 rivet	8
BAC1615-42	Spacer—5/32 rivet	6
41-1606-37-11	Spacer—3/8 micarta	2
1-18050-14	Spacer—Wing and tail rib	2
9-3139	Bracket Installation—Aileron control station 18 LH	1
9-3139-1	Angle Assembly—Aileron control station 18 bracket	1
BAC1603-35	Spacer—No. 10 bolt	1
9-3139-4	Zee Assembly—Aileron control station 18 bracket	1
41-5633-40-20	Fair-lead—3/16 cable	2
BAC1604-79	Spacer—¼ bolt	1
48-1203	Rib Installation—Station 18½ LH	1
48-1203-1	Rib Installation—Station 18½ RH	1
48-1203-2	Rib Assembly—Station 18½ LH	1
48-1203-3	Rib Assembly—Station 18½ RH	1
51-282	Gusset—Wing rib	4
51-282-1	Gusset—Wing rib	4
1-18050-2	Spacer—Wing and tail rib	4

AVIALOGS.COM

WING INSTALLATION

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 21)	
84-1127-500	Rib Installation—Wing center section—station 19 comp. LH	1
84-1127-501	Rib Installation—Wing center section—station 19 comp. RH	1
84-1127-409	Rib Assembly—Center section—station 19 comp. LH	1
84-1127-410	Rib Assembly—Center section—station 19 comp. RH	1
21-5511	Gusset—Wing rib	4
21-5511-1	Gusset—Wing rib	4
21-5512-1	Gusset—Wing rib	4
41-871-47-15	Spacer—7/16 micarta	4
84-1127-421	Rib Assembly—Tail section station 19 comp. LH	1
84-1127-422	Rib Assembly—Tail section station 19 comp. RH	1
21-5887-2	Gusset—Tail rib	12
21-6730-28-7	Spacer—5/16 micarta	2
1-18050-0	Spacer—Wing and tail rib	2
54-1487-409	Rib Installation—Wing—tail section—station 1	1
54-1487-410	Rib Installation—Wing—tail section—station 1	1
54-1487-411	Rib Assembly—Tail section—station 1 LH	1
54-1487-412	Rib Assembly—Tail section—station 1 RH	1
21-5887-6	Gusset—Tail ribs	8
21-5887-4	Gusset—Tail ribs	8
21-7452-3-0	Spacer—1/2 x 5/8 micarta	2
51-494	Gusset—Tail rib	4
21-6730-28-7	Spacer—5/16 micarta	2
1-18050-16	Spacer—Wing and tail rib	2
64-1135-515	Rib Installation—Wing—tail section—station 2 LH	1
64-1135-516	Rib Installation—Wing—tail section—station 2 RH	1
64-1135-517	Rib Assembly—Wing—tail section—station 2 LH	1
64-1135-518	Rib Assembly—Wing—tail section—station 2 RH	1
21-5534	Gusset—Wing rib	16
21-5534-1	Gusset—Wing rib	4
41-1606-37-11	Spacer—3/8 micarta	2
BAC1615-35	Spacer—5/32 rivet	10
BAC1615-42	Spacer—5/32 rivet	2
1-18050-14	Spacer—Wing and tail rib	2
74-1144-400	Rib Installation—Wing—tail section—station 3 LH	1
74-1144-401	Rib Installation—Wing—tail section—station 3 RH	1
74-1144-402	Rib Assembly—Tail section—station 3 LH	1
74-1144-412	Rib Assembly—Tail section—station 3 RH	1
21-5887-1	Gusset—Tail rib	2R
21-5887-4	Gusset—Tail rib	4
21-5887-6	Gusset—Tail rib	4R
21-5887-6	Gusset—Tail rib	2L
21-6136	Gusset—Tail rib	4
1-18050-0	Spacer—Wing and tail rib	2R
41-7371	Gusset—Tail rib	2R
41-7372-1	Gusset—Tail rib	2R
41-4977	Gusset—Tail rib	3L
41-4977-1	Gusset—Tail rib	3L
1-18050-0	Spacer—Wing and tail rib	2
	(Parts List No. 22)	
64-1494	Rib Installation—Wing—tail section—station 4 LH	1
64-1494-1	Rib Installation—Wing—tail section—station 4 RH	1
64-1494-2	Rib Assembly—Wing—tail section—station 4 LH	1
64-1494-12	Rib Assembly—Wing—tail section—station 4 RH	1

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-5887-1	Gusset—Tail rib	2R
21-5887-4	Gusset—Tail rib	4
21-5887-6	Gusset—Tail rib	4R
21-5887-6	Gusset—Tail rib	2L
21-6334	Gusset—Station 4 comp.	4
21-6730-28-7	Spacer—5/16 micarta	2
41-7371	Gusset—Tail rib	2R
41-7372-1	Gusset—Tail rib	2R
41-4977	Gusset—Tail rib	3L
41-4977-1	Gusset—Tail rib	3L
1-18050	Spacer—Wing and tail rib	2
1-18050	Spacer—Wing and tail rib	2
54-1503	Rib Installation—Wing—tail section—station 6 LH	1
54-1503-1	Rib Installation—Wing—tail section—station 6 RH	1
54-1503-2	Rib Assembly—Wing—Tail section—station 6 LH	1
54-1503-3	Rib Assembly—Wing—Tail section—station 6 RH	1
21-5534	Gusset—Wing rib	12
21-5534-1	Gusset—Wing rib	4
21-6177-1	Gusset—Wing comp. rib—station 6	4
BAC1615-35	Spacer—5/32 rivet	10
BAC1615-42	Spacer—5/32 rivet	2
41-1606-37-11	Spacer—3/8 micarta	2
1-18050-14	Spacer—Wing and tail rib	2
58-777-400	Rib Installation—Wing—tail section—station 7 LH	1
58-777-401	Rib Installation—Wing—tail section—station 7 RH	1
58-777-402	Rib Assembly—Wing—Tail section—station 7 LH	1
58-777-403	Rib Assembly—Wing—Tail section—station 7 RH	1
21-5887-1	Gusset—Tail rib	8
21-5887-6	Gusset—Tail rib	12
21-6021	Gusset—Wing rib	4
1-19654-1	Gusset—Wing rib	4
1-18050	Spacer—Wing and tail rib	2
68-775-400	Rib Installation—Wing—tail section—station 8 LH	1
68-775-401	Rib Installation—Wing—tail section—station 8 RH	1
68-775-402	Rib Assembly—Wing—tail section—station 8 LH	1
68-775-403	Rib Assembly—Wing—tail section—station 8 RH	1
21-5887-1	Gusset—Tail rib	8
21-5887-6	Gusset—Tail rib	12
21-6021	Gusset—Wing rib	4
1-19654-1	Gusset—Wing rib	4
1-18050	Spacer—Wing and tail rib	2
21-6730-28-7	Spacer—5/16 micarta	2
68-780-400	Rib Installation—Wing—tail section—station 9 LH	1
68-780-401	Rib Installation—Wing—tail section—station 9 RH	1
68-780-402	Rib Assembly—Wing—tail section—station 9 LH	1
	(Parts List No. 23)	
68-780-403	Rib Assembly—Wing—tail section—station 9 RH	1
21-5887-6	Gusset—Tail rib	8
21-6146-1	Gusset—Wing	4
1-18050	Spacer—Wing and tail rib	2
21-6730-28-7	Spacer—5/16 micarta	2
58-778-400	Rib Installation—Wing—tail section—station 10 LH	1
58-778-401	Rib Installation—Wing—tail section—station 10 RH	1

AVIALOGS.COM

WING INSTALLATION

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
58-778-402	Rib Assembly—Wing—tail section—station 10 LH	1
58-778-403	Rib Assembly—Wing—tail section—station 10 RH	1
21-5534	Gusset—Wing rib	8
21-5534-1	Gusset—Wing rib	4
BAC1615-35	Spacer—5/32 rivet	10
BAC1615-42	Spacer—5/32 rivet	6
1-18050-14	Spacer—Wing and tail rib	2
1-18050-14	Spacer—Wing and tail rib	2
58-779-400	Rib Installation—Wing—tail section—station 11 LH	1
58-779-401	Rib Installation—Wing—tail section—station 11 RH	1
58-779-402	Rib Assembly—Wing—tail section—station 11 LH	1
58-779-403	Rib Assembly—Wing—tail section—station 11 RH	1
21-5887-1	Gusset—Tail rib	8
21-5887-6	Gusset—Tail rib	12
21-6021	Gusset—Wing rib	2L
21-6021-1	Gusset	2R
1-19654-1	Gusset	4
21-6730-28-7	Spacer—5/16 micarta	2
1-18050	Spacer—Wing and tail rib	2
48-592	Rib Installation—Wing—tail section—station 13 LH	1
48-592-1	Rib Installation—Wing—tail section—station 13 RH	1
48-592-2	Rib Assembly—Wing—tail section—station 13 LH	1
48-592-3	Rib Assembly—Wing—tail section—station 13 RH	1
21-5887-6	Gusset—Tail rib	12
1-18050	Spacer—Wing and tail rib	2
14-2045	Door Installation—Inspection—station 1-2 LH	1
14-2045-1	Door Installation—Inspection—station 1-2 RH	1
1-18355	Plate—Reinforcement	6
41-8211	Spring—Dzus fastener	6
6-9290	Door Assembly—Inspection	2
6-9290-1	Door—Inspection	2
6-9290-7	Hinge—Inspection Door	2
41-8209-40	Button—Dzus type AFA	6
41-8210	Grommet—Dzus type 375F	6
14-1337	Door Installation—Station 4-5—wing LH	1
14-1337-1	Door Installation—Station 4-5—wing RH	1
14-1337-4	Door Assembly—Station 4-5—wing LH	2
14-1337-8	Door Assembly—Spotweld—station 4-5 wing	2
BAC1326-65-45	Button—Dzus flathead type FA6	24
BAC1328-6-250	Grommet—Dzus fastener	24
14-1337-9	Frame Assembly—Station 4-5 wing door LH	1

(Parts List No. 24)

14-1337-10	Frame Assembly—Station 4-5 wing door RH	1
21-6038	Spring—Dzus fastener	24
14-2049	Door Installation—Inspection—station 9-10 LH	1
14-2049-1	Door Installation—Inspection—station 9-10 RH	1
1-18355	Plate—Reinforcing	6
41-8211	Spring—Dzus fastener	6
3-13794-8	Flange Assembly—Tank vents LH	1
3-13794-9	Flange Assembly—Tank vents RH	1
3-13908	Flange—Tank vents	2
6-9290-5	Door Assembly—Inspection	2
6-9290-1	Door—Inspection	2
41-8209-40	Button—Dzus type AFA	6
41-8210	Grommet—Dzus type 375F	6
14-2059	Door Installation—Inspection—station 13-14 LH	1
14-2059-1	Door Installation—Inspection—station 13-14 RH	1
1-18355	Plate—Reinforcing	6
41-8211	Spring—Dzus fastener	6
6-9290-6	Door Assembly—Inspection	2

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-9290-1	Door Assembly—Inspection	2
41-8209-40	Fastener—Dzus type AFA	6
41-8210	Grommet—Dzus type 375F	6
14-2058	Door Installation—Inspection—station 17-18 LH	1
14-2058-1	Door Installation—Inspection—station 17-18 RH	1
1-18355	Plate—Reinforcing	6
41-8211	Spring—Dzus fastener	6
6-9290	Door Assembly—Inspection	2
6-9290-1	Door—Inspection	2
6-9290-7	Hinge—Inspection door	2
41-8209-40	Button—Dzus type AFA	6
41-8210	Grommet—Dzus type 375F	6
21-6630	Door Assembly—Inspection	10
21-6630-1	Door—Inspection	10
21-6630-2	Hinge—Continuous	10
9-3024-19	Bracket Installation—Supercharger pulley LH	1
9-3024-20	Bracket Installation—Supercharger pulley RH	1
9-3024-2	Bracket Assembly—Supercharger pulley LH	1
9-3024-3	Bracket Assembly—Supercharger pulley RH	1
BAC1603-96	Spacer—No. 10 bolt	6
BAC1604-24	Spacer—¼ bolt	2
BAC1604-41	Spacer—¼ bolt	2
BAC1604-61	Spacer—¼ bolt	2
15-6143	Bracket Installation—Supercharger control LH	1
15-6143-1	Bracket Installation—Supercharger control RH	1
15-6143-2	Angle Assembly—Supercharger control LH	1
15-6143-3	Angle Assembly—Supercharger control RH	1
BAC114-61S	Bolt—Bearing	4
21-7221-1-28	Spacer—Tabulated	4
1-20022	Angle—Tube support	2
15-6143-8	Plate—Supercharger contact bracket LH	1

(Parts List No. 25)

15-6143-9	Plate—Supercharger contact bracket RH	1
15-6143-12	Bracket Assembly—Supercharger contact LH	1
15-6143-13	Bracket Assembly—Supercharger contact RH	1
41-445-0-28	Spacer—No. 10 bolt	4
BAC1603-171	Spacer—No. 10 bolt	4
BAC1604-10	Spacer—¼ bolt	2
BAC1603-45	Spacer—No. 10 bolt	2
15-6143-10	Fairlead—Micarta	2
15-6143-11	Fairlead—Micarta	2
BAC1603-100	Spacer—No. 10 bolt	4
BAC1604-14	Spacer—¼ bolt	2
BAC1604-46	Spacer—¼ bolt	2
BAC1604-66	Spacer—¼ bolt	2
BAC1604-98	Spacer—¼ bolt	2
3-13681	Bracket Installation—Station 6 wiring LH	1
3-13681-1	Bracket Installation—Station 6 wiring RH	1
3-13681-2	Angle—Wire support LH	1
3-13681-3	Angle—Wire support RH	1
3-13682	Bracket Installation—Wiring LH	1
3-13682-1	Bracket Installation—Wiring RH	1
3-13682-2	Angle—Wire support	2
BAC1603-19	Spacer—No. 10 bolt	2
3-13683	Bracket Installation—Wiring LH	1
3-13683-1	Bracket Installation—Wiring RH	1
3-13683-2	Bracket Angle—Wire support	2
BAC1603-15	Spacer—No. 10 bolt	2
3-13684	Bracket Installation—Wiring	1 R
3-13684-1	Angle—Wire support	1
3-13684-2	Angle—Wire support	1
14-2346	Deflector Installation—Wing vent LH	1
14-2346-1	Deflector Installation—Wing vent RH	1
1-18285	Deflector—Wing vent	4
1-18285-1	Deflector—Wing vent	4
3-11385-1	Deflector—Wing vent	12
41-9166	Plate—Wing vent	4
41-9166-1	Plate—Wing vent	2
41-9166-2	Plate—Wing vent	2

AVIALOGS.COM

WING INSTALLATION

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-9166-3	Plate—Wing vent	2
41-9166-4	Plate—Wing vent	6
41-8380	Angle—Support	32
15-6623	Cradle Installation—Supchg. oil tank LH	1
15-6623-1	Cradle Installation—Supchg. oil tank RH	1
15-6623-14	Cradle Assembly—Supchg. oil tank	2
15-6623-7	Bulkhead Assembly—Supchg. oil tank	2
15-6623-6	Bulkhead Assembly—Supchg. oil tank	4
BAC343-2-123	Bushing—Staked	8
BAC1603-53	Spacer—No. 10 bolt	8
21-8469-48-50	Spacer—No. 10 bolt	6
	(Parts List No. 26)	
43-11667	Strap Assembly—Supchg. oil tank	8
43-11667-402	Cushion—Supchg. oil tank	8
6-7797-7	Scoop Installation—Flap motor vent	1L
6-7797-1	Outlet Assembly—Weld—flap motor vent scoop	1
6-7797-4	Intake Assembly—Weld—flap motor vent scoop	1
41-7632	Scoop—Ventilator	1
6-10787	Support Installation—Exterior bomb beam—rear spar LH	1
6-10787-1	Support Installation—Exterior bomb beam—rear spar RH	1
1-23509	Plate—Support	8
6-10788	Support Installation—Exterior bomb beam—front spar LH	1
6-10788-1	Support Installation—Exterior bomb beam—front spar RH	1
1-23509-1	Plate—Beam support	8
54-1636	Support Installation—Flap motor LH only	1
54-1636-402	Support Assembly—Flap motor support	1
6-6686	Channel Assembly—Flap motor support	1
BAC1603-32	Spacer—No. 10 bolt	12
55-5962	Fairing Installation—Outboard nacelle—upper LH	1
55-5962-1	Fairing Installation—Outboard nacelle—upper RH	1
55-5962-427	Fairing Assembly—Outboard nacelle—upper LH	1
55-5962-428	Fairing Assembly—Outboard nacelle—upper RH	1
1-16283-4	Angle—Stiffener tie	8L
1-16283-4	Angle—Stiffener tie	7R
1-16283-5	Angle—Stiffener tie	7L
1-16283-5	Angle—Stiffener tie	8R
41-8941	Angle—Stringer tie LH	1
41-8941-1	Angle—Stringer tie RH	1
41-8947	Angle Assembly—Support	2
41-8947-2	Angle Assembly—Support	2
21-1803-1	Gusset—Reinforcement	6
1-20235	Gusset—Reinforcement	4
41-3834	Washer—Special	58
21-3147-2	Washer—.019 steel (corrosive resistant)	52
15-6333	Fairing Installation—Inboard nacelle—upper LH	1

Wing Assembly—Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-6333-1	Fairing Installation—Inboard nacelle—upper RH	1
15-6333-31	Fairing Assembly—Inboard nacelle upper LH	1
15-6333-32	Fairing Assembly—Inboard nacelle upper RH	1
1-16283-12	Angle—Stiffener tie	12L
1-16283-13	Angle—Stiffener tie	8R
21-1803-1	Gusset—Reinforcing	8
21-3147-2	Washer—.019 steel (corrosive resistant)	72
41-3834	Washer—Special	82
1-20026	Angle Installation—Hose support	1
1-20026-1	Angle Installation—Hose support	1
1-20026-2	Angle—Hose support	2
3-9364-1	Gusset—Wing	8
	(Parts List No. 27)	
3-9364-2	Gusset—Wing	8
21-3147-1	Washer—.019 steel (corrosive resistant)	20
41-1801-1	Splice—Stiffener	10
75-4771-715	Name Plate—Inner wing LH	1
75-4771-765	Name Plate—Inner wing RH	1
41-3741	Angle—Support	2
41-3741-1	Angle—Support	2
41-6642	Gusset—Wing	8
41-6642-1	Gusset—Wing	4
41-9604	Splice—Spar cap	1L
41-9604-1	Splice—Spar cap	1R
21-9430-1	Strip—Flap wing cut-out—reinforcing	10
51-606	Spacer—Trailing edge	16
51-606-1	Spacer—Trailing edge	18
51-606-3	Spacer—Trailing edge	2
51-606-4	Spacer—Trailing edge	4
51-606-6	Spacer—Trailing edge	8
51-606-7	Spacer—Trailing edge	4
51-606-8	Spacer—Trailing edge	4
51-606-9	Spacer—Trailing edge	16
51-610-3	Angle—Spar cap splice	2
51-610-4	Angle—Spar cap splice	2
1-16764	Splice—Stiffener	12
21-7022-1	Splice—Stiffener	16
1-18757	Fitting—Tube end	1L
526-1032-7	Screw	20
366F1032	Nut	128
BAC1249-110S	Plate—Fiber nut	2
41-7609-5-28	Bushing—AN taper pin replacement	4
41-7609-6-15	Bushing—AN taper pin replacement For spare	16
41-7609-8-27	Bushing—AN taper pin replacement parts only	4
41-7609-8-35	Bushing—AN taper pin replacement used when	2
41-7609-9-35	Bushing—AN taper pin replacement replacing	4
41-7609-9-36	Bushing—AN taper pin replacement wing	6
41-7609-10-33	Bushing—AN taper pin replacement	4
41-7609-10A-34	Bushing—AN taper pin replacement	4

WING ASSEMBLY—INNER

Nacelle Installation—Inboard

	(Parts List No. 28)	
75-4805	Nacelle Installation—Inboard LH	1
75-4805-1	Nacelle Installation—Inboard RH	1
6-8652	CL Diagram	
75-4805-769	Nacelle Assembly—Inboard LH	1
75-4805-770	Nacele Assembly—Inboard RH	1
15-8536	Firewall Assembly—Inboard nacelle LH (PL 36-39)	1
15-8536-1	Firewall Assembly—Inboard nacelle RH (PL 36-39)	1
55-5929	Fairing Installation—Lower inboard nacelle LH (PL 40-41)	1

Nacelle Installation—Inboard

55-5929-1	Fairing Installation—Lower inboard nacelle RH (PL 40-41)	1
75-4805-105	Cover—Inboard nacelle	1L
75-4805-551	Cover—Inboard nacelle	1R
75-4805-633	Cover—Inboard nacelle	1L
75-4805-634	Cover—Inboard nacelle	1R
75-4805-468	Longeron Assembly—Inboard nacelle LH	1
75-4805-469	Longeron Assembly—Inboard nacelle RH	1
48-1076	Channel Installation—Long reinforcement LH	1
48-1076-1	Channel Installation—Long reinforcement RH	1
BAC1603-95	Spacer—No. 10 bolt	2

AVIALOGS.COM

WING ASSEMBLY—INNER

Nacelle Installation—Inboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
75-4805-600	Longeron Assembly—Inboard nacelle	1
75-4805-601	Longeron Assembly—Inboard nacelle	1
BAC1603-91	Spacer—No. 10 bolt	2
14-1755-17	Bulkhead Installation—Inboard nacelle station 2D LH	1
14-1755-18	Bulkhead Installation—Inboard nacelle station 2D RH	1
14-1755-13	Bulkhead Assembly—Inboard nacelle station 2D	1
14-1755-14	Bulkhead Assembly—Inboard nacelle station 2D	1
21-264-2	Plate—Attachment	2
41-8802-56-28	Fairlead—⅛ cable	12
1-17103-6	Angle—Stiff tie	2
1-17103-7	Angle—Stiff tie	2
46-6158	Bearing Assembly—Drag strut support LH	1
46-6158-1	Bearing Assembly—Drag strut support RH	1
46-6158-400	Cap—Bearing	2
41-4614-29-18	Bolt—½-20 drilled head	4
41-9792-1	Bushing—Strut support	2
41-9792-2	Bushing—Strut support	2
BAC114A34S	Bolt—Bearing	2
BAC114A37S	Bolt—Bearing	12
BAC115A39S	Bolt—Bearing	2
BAC115A40S	Bolt—Bearing	10
BAC1604-60	Spacer—¼ bolt	8
46-6530	Support Installation—Nacelle platform LH	2
46-6530-1	Support Installation—Nacelle platform RH	2
51-573-0-18	Spacer—$^{5}/_{16}$ OD-.028	2
51-574-1-16	Tee—Support	4
6-6533	Support Installation—Nacelle platform LH	2
6-6533-1	Support Installation—Nacelle platform RH	2
41-5595	Hook—Nacelle platform	4
	(Parts List No. 29)	
6-6956	Support Installation—Nacelle platform LH	1
6-6956-1	Support Installation—Nacelle platform RH	1
41-5451	Angle—Platform support	2
41-5451-1	Angle—Platform support	2
41-5983	Plate—Locking	2
46-6957	Support Installation—Nacelle platform LH	1
46-6957-1	Support Installation—Nacelle platform RH	1
41-5451	Angle—Platform support	4
41-5451-1	Angle—Platform support	4
41-5983	Plate—Locking	2
6-8001	Support Installation—Inboard nacelle plumbing LH	1
6-8001-1	Support Installation—Inboard nacelle plumbing RH	1
3-12302	Bracket Installation—Safety valve nacelle No. 2	1L
41-5878-4	Angle—Stiff tie	1
3-12303	Bracket Installation—Safety valve nacelle No. 3	1R
41-5878-4	Angle—Stiff tie	1
6-8472	Bracket Installation—Safety and relief valve	1L
41-5878-4	Angle—Stiff tie	2
6-8472-1	Support Assembly—Safety and relief valve	1
46-8660	Bracket Installation—Glycol filter	1L
46-8660-7	Saddle Assembly—Glycol filter	1
46-8660-8	Saddle—Glycol filter	1
46-8660-9	Pad—Glycol filter	1
6-10470	Support Installation—Oil drain cock LH	1
6-10470-1	Support Installation—Oil drain cock RH	1
6-10470-11	Support Assembly—Oil drain cock	2
6-10470-10	Support—Oil drain cock	2
6-10470-4	Plate—Oil drain cock	2
9-3730	Support Installation—Generator relay	1L
9-3374	Support Installation—Generator relay	1R
21-2367-7	Clip—Stiff tie	2
21-2367-6	Clip—Stiff tie	1
15-7639	Support Assembly—Inboard cowling LH	1
15-7639-1	Support Assembly—Inboard cowling RH	1
3-9582	Spring Installation—Dzus	36

Nacelle Installation—Inboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-2086-1	Guide—Cowl fastener	36
41-3637	Spring—Dzus fastener	36
41-5039	Plate—Splice	8
9-3265	Bracket Installation—Glycol tank	1L
9-3265-1	Bracket Assembly—Glycol tank	2R
9-3265-5	Strap Assembly—Glycol tank	4L
9-3266	Door Installation—Glycol tank filler	1L
	(Parts List No. 30)	
41-8211	Spring—Dzus fastener	2
9-3266-1	Door Assembly—Glycol tank filler	1
41-8209-40	Button—Dzus type AFA	2
41-8210	Grommet—Dzus type 375F	2
9-3266-40	Hinge—Continuous	1
9-3266-2	Door—Glycol tank filler	1
9-3266-11	Pan Assembly—Glycol tank filler	1
9-3266-9	Diaphram—Glycol tank filler	1
9-3266-10	Ring—Glycol tank filler	2
6-8049	Stop Installation—Landing gear LH	1
6-8049-1	Stop Installation—Landing gear RH	1
6-8049-10	Stop Assembly—Landing gear	2
6-8049-11	Spring—Landing gear stop	2
1-24985	Plate—Serrated	2
6-8049-12	Spring—Landing gear stop	2
41-9252	Shield Installation—Inboard nacelle LH	1
49-2539	Shield Installation—Inboard nacelle LH	1
49-2539-1	Shield Installation—Inboard nacelle RH	1
54-1759	Patch Installation—Inboard nacelle LH	1
54-1759-1	Patch Installation—Inboard nacelle RH	1
41-8802-56-28	Fairlead—⅛ cable	16
65-5299	Beam Installation—Landing gear—inboard nacelle LH	1
65-5299-1	Beam Installation—Landing gear—inboard nacelle RH	1
9-2958-1	Support Installation—Landing gear retracting screw LH	1
9-2958	Support Installation—Landing gear retracting screw RH	1
9-2958-3	Support Assembly—Landing gear retracting screw LH	1
9-2958-2	Support Assembly—Landing gear retracting screw RH	1
9-2958-6	Support—Landing gear retracting screw RH	1
9-2958-7	Support—Landing gear retracting screw LH	1
9-2958-8	Cap—Landing gear retracting screw RH	1
9-2958-9	Cap—Landing gear retracting screw LH	1
BAC206-11S	Bolt—⅜—24 drilled head	4
9-2958-5	Support Assembly—Inboard landing gear retracting screw LH	1
9-2958-4	Support Assembly—Inboard landing gear retracting screw RH	1
9-2958-10	Support—Landing gear retracting screw RH	1
9-2958-11	Support—Landing gear retracting screw LH	1
9-2958-12	Cap—Landing gear retracting screw RH	1
9-2958-13	Cap—Landing gear retracting screw LH	1
BAC206-10S	Bolt—⅜—24 drilled head	2
BAC206-11S	Bolt—⅜—24 drilled head	2
NAS54-S5.5A	Bolt—Close tolerance	16
NAS54-S7A	Bolt—Close tolerance	8
NAS54-S10A	Bolt—Close tolerance	8
NAS55-S10A	Bolt—Close tolerance	2
NAS55-S11A	Bolt—Close tolerance	14
3-12081	Bracket Assembly—Landing gear motor support LH	1
3-12081-1	Bracket Assembly—Landing gear motor support RH	1
51-83	Strap Assembly—Landing gear motor support	2
51-83-1	Strap—Landing gear motor support	2

AVIALOGS.COM

WING ASSEMBLY—INNER

Nacelle Installation—Inboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 31)	
51-83-2	Pad—Landing gear motor support	2
21-6092-18-1	Bolt—Special No. 10—32	2
65-5836	Beam Assembly—Inboard nacelle LH	1
65-5836-1	Beam Assembly—Inboard nacelle RH	1
3-11854	Bracket—Oil separator	2
1-17103-6	Angle—Stiffener tie	8
1-17103-7	Angle—Stiffener tie	4
NAS53S5	Bolt—Close tolerance	4
49-2876	Door Installation—Inboard oil tank filler LH	1
49-2876-1	Door Installation—Inboard oil tank filler RH	1
49-2876-400	Door Assembly—Inboard oil tank filler	2
49-2876-401	Door—Inboard oil tank filler	2
41-8209-40	Button—Dzus type AFA	2
41-8210	Grommet—Dzus type 375F	2
41-8211	Spring—Dzus fastener	2
15-6045	Shroud Installation—Inboard nacelle bulkhead (front spar) LH	1
15-6045-1	Shroud Installation—Inboard nacelle bulkhead (front spar) RH	1
15-6045-28	Shroud Assembly—Inboard nacelle bulkhead (front spar) LH	1
15-6045-29	Shroud Assembly—Inboard nacelle bulkhead (front spar) RH	1
15-6045-2	Shroud Assembly—Weld inboard nacelle (front spar) LH	1
15-6045-3	Shroud Assembly—Weld inboard nacelle (front spar) RH	1
15-6045-20	Angle Assembly—Weld inboard nacelle (front spar) LH	1
15-6045-21	Angle Assembly—Weld inboard nacelle (front spar) RH	1
65-5915	Cradle Installation—Oil tank—inboard nacelle LH	1
65-5915-1	Cradle Installation—Oil tank—inboard nacelle RH	1
	Dash number parts, shown on 65-5915 drawing are represented by dash numbers of 65-5915 and 55-5915	
65-5915-500	Cradle Assembly—Oil tank inboard nacelle forward	1
65-5915-501	Cradle Assembly—Oil tank inboard nacelle forward	1
41-8467	Channel—Stiffener attachment	1
41-8467-1	Channel—Stiffener attachment	1
41-7855	Angle—Stiffener attachment LH	2
41-7855-1	Angle—Stiffener attachment RH	2
3-14997	Support Assembly—Oil tank cradle LH	1
3-14997-1	Support Assembly—Oil tank cradle RH	1
BAC344-2-238	Bushing—Staked	1
1-20368	Angle—Oil tank cradle	1R
1-20368-1	Angle—Oil tank cradle	1L
41-9834	Angle—Longeron tie	1L
41-9834-1	Angle—Longeron tie	1R
41-9835	Angle—Circumference tie LH	1
41-9835-1	Angle—Circumference tie RH	1
BAC113S34A	Bolt—Bearing	2
BAC113S33A	Bolt—Bearing	2
BAC113S36A	Bolt—Bearing	2
BAC1603-91	Spacer—No. 10 bolt	4
	(Parts List No. 32)	
BAC1609-96	Spacer—No. 10 bolt	2
1-16056-28-6	Cushion—Tank support	2
1-16056-4-3	Cushion—Tank support	2
65-5915-502	Cradle Assembly—Oil tank—inboard nacelle station 2D LH	1
65-5915-503	Cradle Assembly—Oil tank—inboard nacelle station 2D RH	1
41-7855	Angle—Stiffener attachment LH	2
41-7855-1	Angle—Stiffener attachment RH	2

Nacelle Installation—Inboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-8467	Channel—Stiffener attachment LH	1
41-8467-1	Channel—Stiffener attachment RH	1
3-14997	Support Assembly—Oil tank cradle LH	1
3-14997-1	Support Assembly—Oil tank cradle RH	1
BAC344-2-238	Bushing—Staked	1
41-7855	Angle—Stiffener attachment LH	1
41-7855-1	Angle—Stiffener attachment RH	1
1-20374	Plate—Oil tank cradle	2
BAC113S32A	Bolt—Bearing	4
BAC1603-91	Spacer—No. 10 bolt	4
1-16056-28-6	Cushion—Tank support	2
1-16056-4-3	Cushion—Tank support	2
65-5915-504	Cradle Assembly—Oil tank—inboard nacelle LH	1
65-5915-505	Cradle Assembly—Oil tank—inboard nacelle RH	1
41-7855	Angle—Stiffener attachment LH	2
41-7855-1	Angle—Stiffener attachment RH	2
41-8464	Angle—Support	1
41-8464-1	Angle—Support	1
41-8467	Channel—Stiffener attachment LH	1
41-8467-1	Channel—Stiffener attachment RH	1
3-14997	Support Assembly—Oil tank cradle LH	1
3-14997-1	Support Assembly—Oil tank cradle RH	1
BAC344-2-238	Bushing—Staked	1
1-20374	Plate—Oil tank cradle	2
41-7855	Angle—Stiffener attachment LH	1
41-7855-1	Angle—Stiffener attachment RH	1
BAC113S32A	Bolt—Bearing	4
BAC1603-91	Spacer—No. 10 bolt	4
1-16056-28-6	Cushion—Tank support	2
1-16056-4-3	Cushion—Tank support	2
65-6044	Bracket Installation—Engine controls LH	1
65-6044-1	Bracket Installation—Engine controls RH	1
65-6044-514	Bracket Assembly—Engine controls LH	1
65-6044-515	Bracekt Assembly—Engine controls RH	1
41-1645-55	Angle—Tabulated	4
3-12210	Arm Assembly—Engine controls	4
3-12210-1	Arm—Engine controls	4
BAC450-4	Bearing—Ball control	4
BAC283-10St	Bushing—No. 10 press	8
BAC343-4-220	Bushing—5/16 staked	4
BAC1604-23	Spacer—¼ bolt	2
BAC1604-56	Spacer—¼ bolt	2
BAC1604-59	Spacer—¼ bolt	2
	(Parts List No. 33)	
BAC1604-78	Spacer—¼ bolt	2
15-6063-64	Shroud Installation—Exhaust—inboard nacelle LH	1
15-6063-65	Shroud Installation—Exhaust—inboard nacelle RH	1
15-6063-4	Shroud Assembly—Exhaust—inboard nacelle LH	1
15-6063-5	Shroud Assembly—Exhaust—inboard nacelle RH	1
BAC1095-1032	Nut—Self-locking—high temperature	26
BAC1253-410	Nut Plate—High temperature	4
BAC1253-10	Nut Plate—High temperature	24
15-6063-41	Shroud Assembly — Weld — exhaust — inboard nacelle LH	1
15-6063-42	Shroud Assembly — Weld — exhaust — inboard nacelle RH	1
15-6063-30	Shroud Assembly—Detachable—exhaust—inboard nacelle LH	1
15-6063-31	Shroud Assembly—Detachable—exhaust—inboard nacelle RH	1
BAC1253-10	Nut Plate—High temperature	10
15-6063-66	Angle Assembly—Exhaust inboard nacelle shroud LH	1
15-6063-67	Angle Assembly—Exhaust inboard nacelle shroud RH	1

AVIALOGS.COM

WING ASSEMBLY—INNER

Nacelle Installation—Inboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1095-1032	Nut—Self-locking—high temperature	16
15-6063-55	Bulkhead Assembly—Station 3A inboard nacelle exhaust shroud LH	1
15-6063-56	Bulkhead Assembly—Station 3A inboard nacelle exhaust shroud RH	1
15-6063-20	Angle—Inboard nacelle shroud	2
BAC1253-10	Nut—Plate—high temperature	8
65-6019	Shroud Installation—Station 2D—front spar LH	1
65-6019-1	Shroud Installation—Station 2D—front spar RH	1
65-6019-518	Shroud Assembly—Station 2D front spar LH	1
65-6019-519	Shroud Assembly—Station 2D front spar RH	1
65-6019-516	Shroud Assembly—Station 2D front spar LH	1
65-6019-517	Shroud Assembly—Station 2D front spar RH	1
65-6019-510	Shroud Assembly—Weld station 2D front spar LH	1
65-6019-511	Shroud Assembly—Weld station 2D front spar RH	1
65-6019-515	Cover Assembly—Station 2D front spar shroud LH	1
65-6019-514	Cover Assembly—Station 2D front spar shroud RH	1
65-6019-513	Cover Assembly—Station 2D front spar shroud LH	1
65-6019-512	Cover Assembly—Station 2D front spar shroud RH	1
65-6019-401	Cover—Station 2D front spar shroud LH	1
65-6019-402	Cover—Station 2D front spar shroud RH	1
BAC1095-1032	Nut—Self-locking—high temperature	12
BAC1094-1032	Nut—Self-locking—high temperature	68
55-6081	Patch Installation—Inboard nacelle LH	1
55-6081-1	Patch Installation—Inboard nacelle RH	1
75-6002	Shroud Installation—Inboard nacelle—station 2-2D LH	1
75-6002-1	Shroud Installation—Inboard nacelle—station 2-2D RH	1
75-6002-604	Shroud Assembly—Inboard nacelle LH	1
75-6002-605	Shroud Assembly—Inboard nacelle RH	1
6-8474	Bracket Installation—Safety valve	1R
6-8474-1	Support Assembly—Safety valve	1L
41-5878-4	Angle—Stiffener tie	2
46-7795	Support—Exhaust stack	8
	(Parts List No. 34)	
65-6002-500	Shroud—Inboard nacelle exhaust LH	1
65-6002-501	Shroud—Inboard nacelle exhaust RH	1
3-9582	Spring Installation—Dzus fastener	4
41-2086-1	Guide—Cowl fastener	4
41-3637	Spring—Dzus fastener	4
65-6002-407	Support—Inboard nacelle shroud station 2-2D	8
43-9588	Bearing Assembly—Drag strut support LH	1
43-9588-1	Bearing Assembly—Drag strut support RH	1
43-9588-2	Block—Bearing LH	1
43-9588-3	Block—Bearing RH	1
43-9588-400	Cap—Bearing (forging 41-9644)	2
21-8645-20-10	Bolt—3/8—24 drilled head	4
41-3826-1	Bushing—Strut support	2

Nacelle Installation—Inboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-3826-2	Bushing—Strut support	2
41-3702	Gusset—Longeron tie LH	1
41-3702-1	Gusset—Longeron tie RH	1
BAC115-37S	Bolt—Bearing	2
BAC115-38S	Bolt—Bearing	2
47-1305	Longeron—Upper nacelle	4
7-1363	Beam—Inboard nacelle reinforcement LH	1
7-1363-1	Beam—Inboard nacelle reinforcement RH	1
7-1363-2	Beam—Inboard nacelle reinforcement LH	1
7-1363-3	Beam—Inboard nacelle reinforcement RH	1
41-3703	Terminal—Nacelle longeron	2
41-3625	Gusset—Longeron tie LH	1
41-3625-1	Gusset—Longeron tie RH	1
41-3623	Gusset—Longeron tie LH	1
41-3623-1	Gusset—Longeron tie RH	1
BAC114A37S	Bolt—Bearing	8
3-11743	Terminal—Inboard long attachment LH	1
3-11743-1	Terminal—Inboard long attachment RH	1
3-11743-2	Terminal—Inboard long attachment LH	1
3-11743-3	Terminal—Inboard long attachment RH	1
3-11759	Terminal—Outboard long attachment LH	1
3-11759-1	Terminal—Outboard long attachment RH	1
3-11759-2	Terminal—Outboard long attachment LH	1
3-11759-3	Terminal—Outboard long attachment RH	1
BAC1605-60	Spacer—5/16 bolt	20
41-9542-1	Plate—Engine mount support	2
41-9542-2	Plate—Engine mount support	2
41-3840	Terminal—Nacelle longeron	4
41-3831	Filler—Bolt spacer	4
BAC114-36S	Bolt—Bearing	8
41-5135	Angle—Stiffener tie LH	1
41-5135-1	Angle—Stiffener tie RH	1
41-3828	Angle—Longeron tie	4
41-3828-1	Angle—Longeron tie	4
41-3827	Angle—Longeron tie LH	3
41-3827-1	Angle—Longeron tie RH	3
41-9824	Angle—Longeron tie LH	1
41-9824-1	Angle—Longeron tie RH	1
BAC1603-96	Spacer—No. 10 bolt	8
	(Parts List No. 35)	
41-3842	Gusset—Circumference tie LH	5
41-3842-1	Gusset—Circumference tie RH	5
41-3841	Gusset—Circumference tie LH	4
41-3841-1	Gusset—Circumference tie RH	4
41-9541	Plate—Engine mount support	2
41-9541-1	Plate—Engine mount support	2
41-3831	Filler—Bolt—spacer	2
1-17103-6	Angle—Stiffener tie	24L
1-17103-6	Angle—Stiffener tie	29R
1-17103-7	Angle—Stiffener tie	29L
1-17103-7	Angle—Stiffener tie	24R
1-17103-5	Angle—Stiffener tie	2L
1-17103-4	Angle—Stiffener tie	2R
41-8713	Angle—Stringer tie LH	1
41-8713-1	Angle—Stringer tie RH	1
41-8713-2	Angle—Stringer tie LH	1
41-8713-3	Angle—Stringer tie RH	1
BAC1605-36	Spacer—5/16 bolt	6
41-9007-1	Angle—Tube support	2R

NACELLE INSTALLATION—INBOARD

Firewall Assembly—Inboard Nacelle

(Parts List No. 36)

15-8536	Firewall Assembly—Inboard nacelle LH	1
15-8536-1	Firewall Assembly—Inboard nacelle RH	1
15-8536-9	Firewall Sub-assembly—Inboard nacelle LH	1

Firewall Assembly—Inboard Nacelle

15-8536-8	Firewall Sub-assembly—Inboard nacelle RH	1
1-21437	Support Installation—Hose end	1L
46-8941	Support Installation—Inboard autosyn panel	4
1-20735-1001	Absorber—Vibration rubber shock mount	8
6-8941-15	Channel—Inboard autosyn panel support	4

AVIALOGS.COM

NACELLE INSTALLATION—INBOARD

Firewall Assembly—Inboard Nacelle

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-6342	Door Installation—Inboard firewall	2
15-6342-6	Door Assembly—Inboard firewall	2
41-3866-30	Button—Dzus type A	22
41-3862	Grommet—Dzus type 375	22
15-6342-1	Door Assembly—Inboard firewall	2
6-8333-1	Cover—Inboard firewall door	2
15-6342-12	Door—Inboard firewall	2
64-1430	Joint Installation—Inboard firewall	2
64-1430-1	Joint Installation—Inboard firewall	2
64-1551	Joint Installation—Inboard firewall LH	1
64-1551-1	Joint Installation—Inboard firewall RH	1
NAS53-S5.5	Bolt—Close tolerance	4
74-1552	Joint Installation—Inboard firewall LH	1
74-1552-1	Joint Installation—Inboard firewall RH	1
NAS53-56	Bolt—Close tolerance	2
NAS53-56.5	Bolt—Close tolerance	2
BAC1604-112	Spacer—¼ bolt	2
1-19057	Angle—Throttle control	2
41-3863	Spring—Dzus fastener	22
75-6344	Sheet Assembly—Inboard firewall LH	1
75-6344-1	Sheet Assembly—Inboard firewall RH	1
75-6344-600	Sheet Assembly—Inboard firewall LH	1
75-6344-601	Sheet Assembly—Inboard firewall RH	1
51-220	Flange—Engine control stand	2
41-6351	Flange—Riveted block	6
41-8589	Flange—⅜ P.T. block	2L
41-8589	Flange—⅜ P.T. block	1R
41-4146-1	Flange—Riveted block	4
51-86	Flange—¾ P.T. x ½ P.T. block	2L
51-948	Flange—¼ F.P.T. riveting	2
41-4376	Fitting—Block flange	4L
41-4376	Fitting—Block flange	5R
1-20558	Flange—1 P.T. block	2
1-17457	Brace—Start control bracket	1L
1-21074	Coupling Assembly—Block hose flange	2

(Parts List No. 37)

51-473	Fairlead Installation—Starter control	1R
51-473-1	Tee—Starter control fairlead	1
51-671	Fairlead—Starter control	2
51-472	Fairlead Installation—Starter control	1L
51-472-1	Tee—Starter control fairlead	1
51-671-1	Fairlead—Starter control	2
BAC113S7	Bolt—No. 10—32 bearing	3L
BAC113S7	Bolt—No. 10—32 bearing	4R
BAC1249-2416S	Plate—Fiber nut	1R
49-2936	Support Installation—Propeller feather pump LH	1
49-2936-1	Support Installation—Propeller feather pump RH	1
49-2936-400	Bracket Assembly—Propeller feather pump LH	1
49-2936-401	Bracket Assembly—Propeller feather pump RH	1
1-20568	Angle—Reinforcement	4
55-6330	Bracket Installation—No. 2 nacelle firewall	1
55-6330-1	Bracket Assembly—No. 2 nacelle firewall	1
51-397	Plate—Pulley bracket	1
51-397-1	Plate—Pulley bracket	1
BAC1614-68	Spacer—⅛ rivet	4
55-6330-400	Bracket Assembly—No. 2 nacelle firewall	1
BAC1603-46	Spacer—No. 10 bolt	1
BAC1603-84	Spacer—No. 10 bolt	3
6-8265	Bracket—Engine controls	1
3-12090-2	Crank Assembly—Control	2
3-12088-48-48	Crank—Serrated control	2
BAC450-4	Bearing—Ball control	2
41-1066-64-17	Washer—.031 corrosive resistant steel	2
41-8802-70-27	Fairlead—⅛ cable	4
51-395-6	Guide—Control rod fairlead	1
41-665-2	Guide—Control rod fairlead	1
BAC1603-26	Spacer—No. 10 bolt	1
BAC1603-38	Spacer—No. 10 bolt	1
BAC1603-7	Spacer—No. 10 bolt	1

Firewall Assembly—Inboard Nacelle

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1603-57	Spacer—No. 10 bolt	1
BAC1603-8	Spacer—No. 10 bolt	2
BAC1603-41	Spacer—No. 10 bolt	2
55-6331	Bracket Installation—No. 3 nacelle firewall	1R
55-6331-1	Bracket Assembly—No. 3 nacelle firewall	1
51-397	Plate—Pulley control	1
51-397-1	Plate—Pulley control	1
BAC1614-68	Spacer—⅛ rivet	4
6-8265-1	Bracket—Engine controls	1
3-12090-2	Crank Assembly—Control	2
3-12088-48-48	Crank—Serrated control	2
BAC450-4	Bearing—Ball control	2
41-1066-64-17	Washer—.031 steel (corrosive resistant)	2
41-8802-70-27	Fairlead—⅛ cable	4
41-665-2	Guide—Control rod fairlead	1
51-395-6	Guide—Control rod fairlead	1

(Parts List No. 38)

55-6331-400	Angle—No. 3 nacelle firewall	1
BAC1603-45	Spacer—No. 10 bolt	2
6-8314-18	Bracket Installation—Throttle and mixture nacelle No. 2	1
6-8314-1	Bracket Assembly—Throttle and mixture nacelle No. 2	1
1-16511	Plate—Crank support	2
3-8202-100	Crank Assembly—Control	1
BAC450-4	Bearing—Ball control	1
51-761-1	Lever—Control	1
51-761-6	Lever—Control	1
3-13504-13	Crank Assembly—Control	1
1-18353-1	Arm Lever—Throttle control	1
3-15187	Crank—Control	1
BAC450-4	Bearing—Ball control	1
BAC1604-75	Spacer—¼ bolt	1
BAC1604-76	Spacer—¼ bolt	1
BAC1604-151	Spacer—¼ bolt	1
6-8315	Bracket Installation—Throttle and mixture	1
6-8315-1	Bracket Assembly—Throttle and mixture	1
1-16511	Plate—Crank support	1
1-16511-1	Plate—Crank support	1
41-445-0-16	Spacer—No. 10 bolt	2
3-8202-100	Crank Assembly—Control	1
BAC450-4	Bearing—Ball control	1
51-761-1	Lever—Control	1
51-761-6	Lever—Control	1
3-12090 1	Crank Assembly—Control	1
3-12089-40-40	Crank—Control	1
BAC450-4	Bearing—Ball control	1
BAC1604-151	Spacer—¼ bolt	1
BAC1604-76	Spacer—¼ bolt	1
BAC1604-75	Spacer—¼ bolt	1
6-8311	Bracket Installation—Throttle and mixture controls	1
6-8311-1	Bracket Installation—Throttle and mixture controls	1
3-12057	Bracket—Control	2
3-12090-1	Crank Assembly—Control	2
3-12089-40-40	Crank—Control	2
BAC450-4	Bearing—Ball control	2
41-1066-64-17	Washer—.031 (corrosive resistant steel)	2
3-12057-1	Bracket—Control	2
3-12090-1	Crank Assembly—Control	1
3-12090-13	Crank Assembly—Control	1
3-12089-40-40	Crank—Control	2
BAC450-4	Bearing—Ball control	2
BAC1604-8	Spacer—¼ bolt	2
41-1066-64-17	Washer—.031 (corrosive resistant steel)	2
6-10697	Support Installation—Inboard fuel strainer LH	1
6-10697-1	Support Installation—Inboard fuel strainer RH	1
6-10697-2	Support Assembly—Inboard fuel strainer LH	1
1-18767-1	Bracket—Inboard fuel strainer LH	1

AVIALOGS.COM

NACELLE INSTALLATION—INBOARD

Firewall Assembly—Inboard Nacelle

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 39)	
6-10697-3	Support Assembly—Inboard fuel strainer LH	1
6-10697-10	Support Assembly—Inboard fuel strainer RH	1
6-10697-11	Support Assembly—Inboard fuel strainer RH	1
3-13664	Bracket—Inboard fuel strainer	3
6-9491	Bracket Installation—Propeller pitch control	1R
6-9491-7	Bracket Assembly—Propeller pitch control	1
BAC1603-74	Spacer—No. 10 bolt	2
BAC1603-78	Spacer—No. 10 bolt	2
6-9491-11	Filler—Propeller pitch control bracket	1
BAC1604-6	Spacer—¼ bolt	1

Firewall Assembly—Inboard Nacelle

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1604-40	Spacer—¼ bolt	1
BAC1604-42	Spacer—¼ bolt	1
6-10138	Support Assembly—Forward autosyn panel	2
6-10138-1	Bracket—Autosyn panel	1
1-20735-1001	Absorber—Rubber shock mount	1
1-21351	Stop—Autosyn panel	2
6-11300	Support Assembly—Autosyn	1R
6-11300-1	Bracket—Autosyn support	1
1-22970-1	Mount—Rubber shock	4
37B6535	Tube Assembly—Fire extinguisher (Government furnished)	2

NACELLE ASSEMBLY

Fairing Installation—Lower Inboard Nacelle

	(Parts List No. 40)	
55-5929	Fairing Installation—Lower inboard nacelle LH	1
55-5929-1	Fairing Installation—Lower inboard nacelle RH	1
15-5930	Diagram—Lower inboard nacelle fairing	1
55-5929-543	Channel Assembly—Center lower inboard nacelle fairing RH	1
55-5929-542	Channel Assembly—Center lower inboard nacelle fairing LH	1
55-5929-432	Plate Assembly—Lower inboard nacelle fairing LH	1
55-5929-433	Plate Assembly—Lower inboard nacelle fairing RH	1
55-5929-84	Cowling Assembly—Rear lower inboard nacelle fairing LH	1
55-5929-85	Cowling Assembly—Rear lower inboard nacelle fairing RH	1
55-5929-417	Cowling Assembly—Outboard center lower inboard nacelle fairing LH	1
55-5929-418	Cowling Assembly—Outboard center lower inboard nacelle fairing RH	1
55-5929-415	Cowling Assembly—Inboard center lower inboard nacelle fairing LH	1
55-5929-416	Cowling Assembly—Inboard center lower inboard nacelle fairing RH	1
55-5929-461	Scoop Assembly—Lower inboard nacelle fairing LH	1
55-5929-462	Scoop Assembly—Lower inboard nacelle fairing RH	1
55-5929-451	Scoop Assembly—Lower inboard nacelle fairing RH	1
55-5929-452	Scoop Assembly—Lower inboard nacelle fairing	1
55-5929-473	Scoop Assembly—Lower inboard nacelle fairing LH	1
55-5929-474	Scoop Assembly—Lower inboard nacelle fairing RH	1
55-5929-463	Scoop Assembly—Lower inboard nacelle fairing RH	1
55-5929-464	Scoop Assembly—Lower inboard nacelle fairing LH	1
55-5929-447	Sheet Assembly—Lower inboard nacelle fairing LH	1
55-5929-448	Angle Assembly—Lower inboard nacelle fairing LH	1
55-5929-449	Sheet Assembly—Lower inboard nacelle fairing RH	1
55-5929-450	Angle Assembly—Lower inboard nacelle fairing RH	1

Fairing Installation—Lower Inboard Nacelle

BAC1253-410	Nut Plate—High temperature	2
55-5929-443	Sheet Assembly—Lower inboard nacelle fairing LH	1
55-5929-444	Angle Assembly—Lower inboard nacelle fairing LH	1
55-5929-445	Sheet Assembly—Lower inboard nacelle fairing RH	1
55-5929-446	Angle Assembly—Lower inboard nacelle fairing RH	1
BAC1253-410	Nut Plate—High temperature	2
55-5929-400	Cover—Lower inboard nacelle fairing	1
55-5929-401	Cover—Lower inboard nacelle fairing	1
55-5929-406	Cover—Lower inboard nacelle fairing	2
55-5929-482	Reinforcement Assembly—Lower inboard nacelle fairing	2
BAC1253-110	Nut Plate—High temperature	12
55-5929-512	Clip Assembly—Lower inboard nacelle fairing LH.	1
55-5929-513	Clip Assembly—Lower inboard nacelle fairing RH.	1
55-5929-514	Clip Assembly—Lower inboard nacelle fairing LH.	1
55-5929-515	Clip Assembly—Lower inboard nacelle fairing RH.	1
41-5135	Angle—Stiffener tie LH	1
41-5135-1	Angle—Stiffener tie RH	1
15-6534	Duct Installation—Supercharger cooling nacelle No. 2 LH	1
15-6534-1	Duct Installation—Supercharger cooling nacelle No. 3 RH	1
15-6534-2	Duct Assembly—Supercharger cooling nacelle No. 2 LH	1
15-6534-3	Duct Assembly—Supercharger cooling nacelle No. 3 RH	1
6-8527	Duct Assembly—Supercharger cooling LH	1
	(Parts List No. 41)	
6-8527-13	Duct Assembly—Supercharger cooling RH	1
6-8527-1	Duct Assembly—Supercharger cooling	2
6-8527-2	Duct Assembly—Supercharger cooling LH	1
6-8527-12	Duct Assembly—Supercharger cooling RH	1
BAC1095-1032	Nut—Self-locking high temperature	4
15-6535	Duct Installation—Supercharger cooling nacelle No. 2 LH	1
15-6535-1	Duct Installation—Supercharger cooling nacelle No. 3 RH	1
15-6535-2	Duct Assembly—Supercharger cooling nacelle No. 2 LH	1
15-6535-3	Duct Assembly—Supercharger cooling nacelle No. 3 RH	1

AVIALOGS.COM

NACELLE ASSEMBLY

Fairing Installation—Lower Inboard Nacelle

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-6535-14	Duct Assembly—Supercharger cooling nacelle No. 2 LH	1
15-6535-15	Duct Assembly—Supercharger cooling nacelle No. 3 RH	1
6-8532-1	Duct Assembly—Supercharger cooling RH	1
6-8532-17	Duct Assembly—Supercharger cooling	1
6-8532-18	Duct Assembly—Supercharger cooling	1
6-8532	Duct Assembly—Supercharger cooling LH	1
6-8532-2	Duct Assembly—Supercharger cooling	1
6-8532-3	Duct Assembly—Supercharger cooling	1
BAC1095-1032	Nut—Self-locking high temperature	4
65-5034-500	Bulkhead Assembly—Lower fairing—inboard nacelle upper LH	1
65-5034-501	Bulkhead Assembly—Lower fairing—inboard nacelle upper RH	1
65-5034-513	Web Assembly—Spotweld lower fairing inboard nacelle block LH	1
65-5034-514	Web Assembly—Spotweld lower fairing inboard nacelle block RH	1
65-5034-502	Bulkhead Assembly—Lower fairing—inboard nacelle LH	1
65-5034-503	Bulkhead Assembly—Lower fairing—inboard nacelle RH	1

Fairing Installation—Lower Inboard Nacelle

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-5034-509	Bulkhead Assembly—Spotweld lower fairing inboard nacelle block LH	1
65-5034-510	Bulkhead Assembly—Spotweld lower fairing inboard nacelle block RH	1
41-7473	Washer—Special	22
9-3195	Extension Installation—Scoop supercharger cooler LH	1
9-3195-1	Extension Installation—Scoop supercharger cooler RH	1
9-3195-2	Extension Assembly—Scoop LH	1
9-3195-3	Extension Assembly—Scoop RH	1
6-8526	Extension Installation—Scoop supercharger cooler LH	1
6-8526-1	Extension Installation—Scoop supercharger cooler RH	1
6-8526-2	Extension Assembly—Scoop LH	1
6-8526-3	Extension Assembly—Scoop RH	1
21-3147-1	Washer—.019 steel (corrosive resistant)	30
BAC1253-110	Nut Plate—High temperature	275
BAC1253-410	Nut Plate—High temperature	20
BAC1253-10	Nut Plate—High temperature	46
BAC1253-210	Nut Plate—High temperature	4
BAC1095-1032	Nut—Self-locking high temperature	20

WING ASSEMBLY—INNER

Nacelle Installation—Outboard

(Parts List No. 42)

75-4806	Nacelle Installation—Outboard LH	1
75-4806-1	Nacelle Installation—Outboard RH	1
46-5541	CL Diagonal—Outboard nacelle	
75-4806-746	Nacelle Assembly—Outboard LH	1
75-4806-747	Nacelle Assembly—Outboard RH	1
15-8535	Firewall Assembly—Outboard nacelle LH (PL 50-53)	1
15-8535-1	Firewall Assembly—Outboard nacelle RH (PL 50-53)	1
65-5965	Support Installation—Supercharger—outboard nacelle LH (PL 54-55)	1
65-5965-1	Support Installation—Supercharger—outboard nacelle RH (PL 54-55)	1
75-5985	Bulkhead Installation—Station 2C—outboard nacelle LH	1
75-5985-1	Bulkhead Installation—Station 2C—outboard nacelle RH	1
	Dash number parts, shown on 75-5985 drawing are represented by dash numbers of 55-5985, 65-5985 and 75-5985.	
75-5985-600	Bulkhead Assembly—Station 2C—outboard nacelle LH	1
75-5985-601	Bulkhead Assembly—Station 2C—outboard nacelle RH	1
1-20376	Plate—Oil tank cradle	2
41-8478	Angle—Oil tank cradle	1L
41-8478-1	Angle—Oil tank cradle	1R
BAC1249-110S	Plate—Fiber nut	2
1-17103	Angle—Stiffener tie	2L
1-17103	Angle—Stiffener tie	5R
1-17103-1	Angle—Stiffener tie	5L
1-17103-1	Angle—Stiffener tie	2R
41-8424	Angle—Long attachment	2L
41-8424-1	Angle—Long attachment	2R

Nacelle Installation—Outboard

41-8324	Angle—Stiffener attachment	1L
41-8324-1	Angle—Stiffener attachment	1R
41-8324-2	Angle—Stiffener attachment	1L
41-8324-3	Angle—Stiffener attachment	1R
41-8324-4	Angle—Stiffener attachment	1L
41-8324-5	Angle—Stiffener attachment	1R
41-8423	Angle—Stiffener attachment	1R
41-8423-1	Angle—Stiffener attachment	1L
1-16056-33-0	Cushion—Tank support	2
1-20374	Plate—Oil tank cradle	2
15-5926	Reinforcing Installation—Nacelle—outboard LH	1
15-5926-1	Reinforcing Installation—Nacelle—outboard RH	1
9-2901	Door Installation—Outboard oil tank filler LH	1
9-2901-1	Door Installation—Outboard oil tank filler RH	1
9-2901-5	Door Assembly—Outboard oil tank filler	2
9-2901-7	Door—Outboard oil tank filler	2
31-8209-40	Button—Dzus type AFA	2
41-8210	Grommet—Dzus type 375F	2
41-8211	Spring—Dzus fastener	2
15-5665	Door Installation—Outboard nacelle access LH	1
15-5665-1	Door Installation—Outboard nacelle access RH	1

(Parts List No. 43)

15-5665-2	Door Assembly—Outboard nacelle access	2
15-5665-3	Door Assembly—Outboard nacelle access	2
41-8210	Grommet—Dzus type 375F	20
41-8209-40	Button—Dzus type AFA	20
41-8380	Angle—Support	4
41-8211	Spring—Dzus fastener	20
366F1032	Nut—Plate	10
41-8264	Angle—Stiffener tie	2
41-8264-1	Angle—Stiffener tie	2
41-8266	Angle—Stiffener tie LH	1
41-8266-1	Angle—Stiffener tie RH	1
75-5025	Door Installation—Outboard nacelle LH	1

AVIALOGS.COM

WING ASSEMBLY—INNER

Nacelle Installation—Outboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
75-5025-26	Door Installation—Outboard nacelle RH	1
	Dash number parts, shown on 75-5025 drawing are represented by dash numbers of 75-5025 and 65-5025	
75-5025-600	Door Assembly—Outboard nacelle	2
75-5025-601	Door Assembly—Outboard nacelle	2
21-6082-46	Button—Dzus type AFA	24
21-6083	Grommet—Dzus type 375F	24
65-5025-425	Channel Assembly—Outboard nacelle LH	1
65-5025-426	Channel Assembly—Outboard nacelle RH	1
21-6038	Spring—Dzus fastener	24
15-7994	Door Installation—Outboard nacelle accessory LH	1
15-7994-1	Door Installation—Outboard nacelle accessory RH	1
15-7994-2	Door Assembly—Outboard nacelle accessory	2
15-7994-3	Door—Outboard nacelle accessory	2
15-7994-6	Hinge—Outboard nacelle accessory door	2
BAC1326-5-40	Button—Dzus flat head	4
BAC1328-5-175	Grommet—Dzus fastener	4
9-3044-2	Door Assembly—Outboard nacelle accessory	2
9-3044-3	Door—Outboard nacelle accessory	2
41-8209-40	Button—Dzus type AFA	4
41-8210	Grommet—Dzus type 375F	4
BAC1327-5-300	Spring—Dzus fastener	4
54-1766	Door Installation—Outboard nacelle accessory LH	1
54-1766-1	Door Installation—Outboard nacelle accessory RH	1
54-1766-2	Door Assembly—Outboard nacelle accessory	2
54-1766-3	Door—Outboard nacelle accessory	2
41-8210	Grommet—Dzus fastener	4
41-8209-40	Button—Dzus fastener	4
54-1766-4	Door Assembly—Outboard nacelle accessory	2
54-1766-5	Door—Outboard nacelle accessory	2
41-8210	Grommet—Dzus fastener	4
41-8209-40	Button—Dzus fastener	4
41-8211	Spring—Dzus fastener	8
55-6162	Support Installation—Supercharger oil tank LH	1
	(Parts List No. 44)	
55-6162-1	Support Installation—Supercharger oil tank RH	1
55-6162-400	Support Assembly—Supercharger oil tank LH	1
55-6162-401	Support Assembly—Supercharger oil tank RH	1
43-11667	Strap Assembly—Supercharger oil tank	8
55-6162-402	Cushion—Supercharger oil tank	4
55-6162-17	Channel—Supercharger oil tank LH	1
55-6162-18	Channel—Supercharger oil tank RH	1
21-2367-6	Clip—Stiffener tie LH	1
21-2367-7	Clip—Stiffener tie RH	1
1-17103-9	Angle—Stiffener tie LH	1
1-17103-8	Angle—Stiffener tie RH	1
46-6959	Support Installation—Nacelle platform outboard side outboard nacelle LH	1
46-6959-1	Support Installation—Nacelle platform outboard side outboard nacelle RH	1
41-5983	Plate—Locking	2
65-5982	Cradle Installation—Outboard nacelle LH	1
65-5982-1	Cradle Installation—Outboard nacelle RH	1
	Dash number parts, shown on 65-5982 drawing are represented by dash numbers of 65-5982 and 55-5982	
65-5982-500	Cradle Assembly—Outboard nacelle LH	1
65-5982-501	Cradle Assembly—Outboard nacelle RH	1
65-5982-502	Cradle Assembly—Outboard nacelle LH	1

Nacelle Installation—Outboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-5982-503	Cradle Assembly—Outboard nacelle RH	1
55-5982-416	Angle Assembly—Outboard nacelle	4
41-8301	Channel—Stiffener attachment LH	1
41-8301-1	Channel—Stiffener attachment RH	1
41-8301-2	Channel—Stiffener attachment LH	1
41-8301-3	Channel—Stiffener attachment RH	1
41-8301-4	Channel—Stiffener attachment LH	1
41-8301-5	Channel—Stiffener attachment RH	1
1-16056-5-3	Cushion—Tank support	2
1-16056-28-0	Cushion—Tank support	2
3-14998	Support Assembly—Oil tank cradle LH	1
3-14998-1	Support Assembly—Oil tank cradle RH	1
BAC344-2-148	Bushing—Staked	2
1-17103-8	Angle—Stiffener tie LH	1
1-17103-9	Angle—Stiffener tie RH	1
NAS53-S23A	Bolt—Close tolerance	4
NAS53-S22A	Bolt—Close tolerance	4
NAS53-S6A	Bolt—Close tolerance	4
BAC1603-96	Spacer—No. 10 bolt	8
65-5983	Cradle Installation—Station 2D—outboard nacelle	1L
65-5983-1	Cradle Installation—Station 2D—outboard nacelle	1R
65-5983-500	Cradle Assembly—Station 2D	1L
65-5983-501	Cradle Assembly—Station 2D	1R
41-8279	Angle—Stiffener tie	1L
41-8279-1	Angle—Stiffener tie	1R
	(Parts List No. 45)	
41-8279-2	Angle—Stiffener tie	1L
41-8279-3	Angle—Stiffener tie	1R
41-8279-4	Angle—Stiffener tie	1L
41-8279-5	Angle—Stiffener tie	1R
BAC344-2-249	Bushing—¼ staked	2
1-16056-33-0	Cushion—Tank support	2
1-20374-1	Plate—Oil tank	2
41-8388	Angle—Support	1L
41-8388-1	Angle—Support	1R
BAC113S11A	Bolt—10—32 bearing	2
47-1305-1	Longeron—Nacelle	4
6-6533-2	Support Installation—Nacelle platform LH	1
6-6533-3	Support Installation—Nacelle platform RH	1
6-6533-4	Support Installation—Nacelle platform LH	1
6-6533-5	Support Installation—Nacelle platform RH	1
41-5595	Hook—Nacelle platform	4
65-5977-421	Shroud Installation—Outboard nacelle (exhaust) LH	1
65-5977-422	Shroud Installation—Outboard nacelle (exhaust) RH	1
	Dash number parts, shown on 65-5977 drawing are represented by dash numbers of 65-5977 and 55-5977	
65-5977-507	Shroud Assembly—Weld outboard nacelle (exhaust) LH	1
65-5977-508	Shroud Assembly—Weld outboard nacelle (exhaust) RH	1
54-1821	Spill Installation—Outboard air LH	1
54-1821-1	Spill Installation—Outboard air RH	1
14-1821-2	Spill Assembly—Air outboard LH—weld	1
14-1821-3	Spill Assembly—Air outboard RH—weld	1
14-1821-8	Angle—Base	1
14-1821-9	Angle—Base	1
BAC1245-10	Nut—Anchor	2
BAC1253-10	Nut Plate—High temperature	10
BAC1253-10	Nut Plate—High temperature	8

AVIALOGS.COM

WING ASSEMBLY—INNER

Nacelle Installation—Outboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-9582	Spring Installation—Dzus fastener	4
41-3637	Spring—Dzus fastener	4
41-2086-1	Guide—Cowl fastener	4
41-5135-4	Angle—Stiffener tie LH	2
41-5135-5	Angle—Stiffener tie RH	2
41-5878-6	Angle—Stiffener tie	2
BAC1253-410	Nut Plate—High temperature	2
46-8050	Step Installation—Outboard nacelle LH	1
46-8050-1	Step Installation—Outboard nacelle RH	1
51-1191	Brace—Shroud flange	2
51-1191-1	Brace—Shroud flange	2
9-2927	Support Installation—Oil cooler LH	1
9-2927-1	Support Installation—Oil cooler RH	1
15-6012-28	Support Installation—Outboard intercooler LH	1
15-6012-29	Support Installation—Outboard intercooler RH	1
15-6012-30	Beam Assembly—Outboard intercooler LH	1
15-6012-31	Beam Assembly—Outboard intercooler RH	1
41-2574-12	Angle—Reinforcing—outboard intercooler RH support	1
	(Parts List No. 46)	
41-2574-13	Angle—Reinforcing—outboard intercooler support LH	1
41-9508	Ring—Washer retainer	4
15-6012-6	Beam Assembly—Outboard intercooler LH	1
15-6012-7	Beam Assembly—Outboard intercooler RH	1
41-2574-12	Angle—Reinforcing outboard intercooler support LH	1
41-2574-13	Angle—Reinforcing outboard intercooler support RH	1
41-9508	Ring—Washer retainer	4
3-13528	Clip Installation—Spring support	1R
1-18207	Clip—Spring support	1
15-6012-18	Arch Assembly—Outbcard intercooler LH	1
15-6012-19	Arch Assembly—Outboard intercooler RH	1
9-3127	Bracket Installation—Intercooler temperature control No. 1 nacelle	1
3-12090-4	Crank Assembly—Control	1
3-12088-36-48	Crank—Control	1
BAC450-4	Bearing—Ball control	1
BAC1604-20	Spacer—¼ bolt	1
BAC1604-85	Spacer—¼ bolt	1
9-3127-1	Bracket Assembly—Intercooler temperature control	1
1-18107	Angle—Spring support	1
41-5135	Angle—Stiffener tie	1
41-5135-1	Angle—Stiffener tie	1
41-5135-4	Angle—Stiffener tie	1
41-5135-5	Angle—Stiffener tie	1
49-3129	Bracket Installation—Intercooler temperature control	1
3-12090-4	Crank Assembly—Control	1
3-12088-36-48	Crank—Serrated control	1
BAC450-4	Bearing—Ball control	1
BAC1604-8	Spacer—¼ bolt	1
BAC1604-32	Spacer—¼ bolt	1
49-3129-1	Bracket Assembly—Intercooler temperature control	1
41-5135-4	Angle—Stiffener tie LH	1
41-5135-1	Angle—Stiffener tie RH	1
9-3126	Lever Installation—Intercooler temperature control LH	1
9-3126-1	Lever Installation—Intercooler temperature control RH	1
3-12170	Lever Assembly—Control	2

Nacelle Installation—Outboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-11968-19	Lever Assembly—Control	2
BAC450-4	Bearing—Ball control	2
BAC1603-51	Spacer—No. 10 bolt	2
1-18207-1	Clip—Spring support	
BAC1604-7	Spacer—¼ bolt	2
BAC1604-29	Spacer—¼ bolt	2
BAC1603-73	Spacer—No. 10 bolt	8
9-3194	Cowling Installation—External outboard supercharger LH	1
9-3194-1	Cowling Installation—External outboard supercharger RH	1
9-3194-2	Cowl Assembly—External inboard supercharger LH	1
9-3194-3	Cowl Assembly—External inboard supercharger RH	1
9-3194-14	Cowl Assembly—External inboard supercharger LH	1
	(Parts List No. 47)	
9-3194-15	Cowl Assembly—External inboard supercharger RH	1
366F1032	Nut Plate—Self-locking (steel)	38
15-7638	Support Assembly—Outboard cowl LH	1
15-7638-11	Support Assembly—Outboard cowl RH	1
3-9582	Spring Installation—Dzus fastener	36
41-2086-1	Guide—Dzus fastener	36
41-3637	Spring—Dzus fastener	36
41-5039	Plate—Splice	8
7-1360	Cover Installation—Air outlet LH	1
7-1360-1	Cover Installation—Air outlet RH	1
7-1360-2	Cover—Air outlet LH	1
7-1360-3	Cover—Air outlet RH	1
9-4907	Support Installation—Oil drain cock LH	1
9-4907-1	Support Installation—Oil drain cock RH	1
9-4907-8	Support Assembly—Oil drain cock LH	1
9-4907-9	Support Assembly—Oil drain cock RH	1
6-6958	Support Installation—Nacelle platform LH	1
6-6958-1	Support Installation—Nacelle platform RH	1
41-5982	Angle—Platform support	2
41-5982-1	Angle—Platform support	2
41-5983	Plate—Lock	2
46-6530	Support Installation—Nacelle platform LH	1
46-6530-1	Support Installation—Nacelle platform RH	1
51-574-1-16	Tee—Support	4
51-573-0-18	Spacer—5/16 OD—.028	2
41-9542	Plate—Engine mount support—lower	4
41-9542-1	Plate—Engine mount support—upper	4
41-3831	Filler—Bolt spacer	8
41-3840	Terminal—Nacelle long	8
AN3-22A	Bolt	8
AN10-46	Bolt	4
BAC114S36	Bolt—¼—28 bearing	16
AN960-10	Washer	8
AN960-416	Washer	16
365-1032	Nut	8
AN310-4	Nut—Castle	16
AN380-2-2	Cotter	16
41-8300	Angle—Stiffener tie	6
AN3-21	Bolt	4
AN3-22	Bolt	4
BAC1603-96	Spacer—No. 10 bolt	8
AN960-10	Washer	4
AN310-3	Nut	8
AN380-2-2	Cotter	8
41-3827	Angle—Longeron tie	4L

AVIALOGS.COM

WING ASSEMBLY—INNER

Nacelle Installation—Outboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-3827	Angle—Longeron tie	3R
41-3827-1	Angle—Longeron tie	3L
41-3827-1	Angle—Longeron tie	4R
	(Parts List No. 48)	
AN3-22	Bolt	16
BAC1603-96	Spacer—No. 10 bolt	16
AN960-10	Washer	32
AN310-3	Nut	16
AN380-2-2	Cotter	16
AN10-27	Bolt	4
41-3828	Angle—Longeron tie	4
41-3828-1	Angle—Longeron tie	4
41-9546	Angle—Stiffener tie	2
41-8622	Angle—Support	6
1-17103-8	Angle—Stiffener tie	10L
1-17103-8	Angle—Stiffener tie	19R
1-17103-9	Angle—Stiffener tie	19L
1-17103-9	Angle—Stiffener tie	10R
1-17103-2	Angle—Stiffener tie	4L
1-17103-2	Angle—Stiffener tie	3R
1-17103-3	Angle—Stiffener tie	3L
1-17103-3	Angle—Stiffener tie	4R
41-8947-4	Angle Assembly—Support	2R
65-6007	Fairing Installation—Lower outboard nacelle LH	1
65-6007-1	Fairing Installation—Lower outboard nacelle RH	1
65-6007-445	Fairing Assembly—Lower outboard nacelle LH	1
65-6007-446	Fairing Assembly—Lower outboard nacelle RH	1
65-6007-490	Fairing Assembly—Lower outboard nacelle	1
65-6007-491	Fairing Assembly—Lower outboard nacelle	1
6-8056	Door Installation—Accessory—waste gate control supercharger LH	1
6-8056-1	Door Installation—Accessory—waste gate control supercharger RH	1
6-8056-8	Door Installation—Accessory—waste gate control supercharger RH	1
6-8056-9	Door Installation—Accessory—waste gate control supercharger LH	1
6-8056-4	Door—Accessory—waste gate control supercharger LH	2
6-8056-10	Door—Accessory—waste gate control supercharger RH	2
BAC1249-110S	Plate—Fiber nut	8
41-2574-14	Angle—Stiffener tie	18

Nacelle Installation—Outboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-2574-15	Angle—Stiffener tie	18
41-2574-16	Angle—Stiffener tie	2
41-2574-17	Angle—Stiffener tie	2
41-3316-28	Angle—Stiffener tie LH	2
41-3316-29	Angle—Stiffener tie RH	2
41-3316-30	Angle—Stiffener tie RH	2
41-3316-31	Angle—Stiffener tie LH	2
41-3834	Washer—Special	76
21-3147-2	Washer—.019 steel (corrosive resistant)	76
55-6191	Bracket Installation—Engine controls LH	1
	(Parts List No. 49)	
55-6191-1	Bracket Installation—Engine controls RH	1
3-12210-2	Arm Assembly—Engine controls LH	2
3-12210-4	Arm Assembly—Engine controls RH	2
3-12210-3	Arm—Engine controls LH	2
3-12210-5	Arm—Engine controls RH	2
BAC450-4	Bearing—Ball control	4
BAC283-10ST	Bushing—No. 10 pressure	8
BAC343-4-220	Bushing—5/16 staked	4
55-6191-402	Bracket Assembly—Engine controls LH	1
55-6191-403	Bracket Assembly—Engine controls RH	1
55-6191-406	Bracket Assembly—Engine controls LH	1
55-6191-407	Bracket Assembly—Engine controls RH	1
55-6191-410	Bracket Assembly—Engine controls LH	1
55-6191-411	Bracket Assembly—Engine controls RH	1
BAC1604-23	Spacer—¼ bolt	1R
BAC1604-26	Spacer—¼ bolt	1L
BAC1604-38	Spacer—¼ bolt	1R
BAC1604-40	Spacer—¼ bolt	1L
BAC1604-49	Spacer—¼ bolt	1L
BAC1604-56	Spacer—¼ bolt	1R
BAC1604-68	Spacer—¼ bolt	1L
BAC1604-66	Spacer—¼ bolt	1R
51-571	Plate—Filler	4
51-572	Channel—Platform support	2
51-572-1	Channel—Platform support	2
51-573-0-18	Spacer—5/16 OD—.028	2
51-574-1-16	Tee—Support	4
9-3054	Shield Installation—Oil tank LH	1
9-3054-1	Shield Installation—Oil tank RH	1
9-3054-2	Shield—Oil tank LH	1
9-3054-3	Shield—Oil tank RH	1
3-15145	Bracket Installation—Tube support LH	1
3-15145-1	Bracket Installation—Tube support RH	1
3-15145-4	Bracket Assembly—Tube support LH	1
3-15145-5	Bracket Assembly—Tube support RH	1

NACELLE INSTALLATION—OUTBOARD

Firewall Assembly—Outboard Nacelle

	(Parts List No. 50)	
15-8535	Firewall Assembly—Outboard nacelle LH	1
15-8535-1	Firewall Assembly—Outboard nacelle RH	1
15-8535-14	Firewall Assembly—Outboard nacelle LH	1
15-8535-13	Firewall Assembly—Outboard nacelle RH	1
1-20524	Flange—¾ P.T. block LH	1
1-20558	Flange—1 P.T. block	2
3-12096	Angle Installation—Intercooler beam support LH	1
3-12096-1	Angle Installation—Intercooler beam support RH	1
46-8975	Support Assembly—Outboard autosyn panel	2
46-8975-1	Support Assembly—Outboard autosyn panel	2
1-20735-1001	Absorber—Rubber shock mounting	8
15-6334	Door Installation—Outboard firewall	2

Firewall Assembly—Outboard Nacelle

15-6334-14	Door Assembly—Upper—outboard firewall	2
15-6334-16	Door Assembly—Upper outboard firewall	2
6-8331-1	Cover—Firewall door	2
41-3862	Grommet—Dzus type 375	8
41-3863	Spring—Dzus fastener	4
41-3866-40	Button—Dzus type A	8
15-6334-19	Door Assembly—Lower—outboard firewall	2
15-6334-22	Door Assembly—Lower—outboard firewall	2
41-3862	Grommet—Dzus type 375	16
41-3866-30	Button—Dzus type A	4
41-3866-40	Button—Dzus type A	12
41-8380	Angle—Support	2
41-3863	Spring—Dzus fastener	20
41-4376	Fitting—Block flange	8
41-5135	Angle—Stiffener tie LH	2
41-5135	Angle—Stiffener tie RH	1

AVIALOGS.COM

NACELLE INSTALLATION—OUTBOARD

Firewall Assembly—Outboard Nacelle

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-5135-1	Angle—Stiffener tie LH	1L
41-5135-1	Angle—Stiffener tie RH	2R
41-6351	Flange—Riveted block	4L
41-6351	Flange—Riveted block	3R
41-7967	Bracket—Outboard firewall	2
41-7967-1	Bracket—Outboard firewall	2
51-220	Flange—Riveted block	2
51-948	Flange—¼ FPT riveting	2
74-1826	Sheet Assembly—Outboard firewall	1L
74-1826-1	Sheet Assembly—Outboard firewall	1R
BAC1615-26	Spacer—5/32 rivet	8
BAC1253-110	Nut Plate—High temperature	4
BAC1604-112	Spacer—¼ bolt	16
41-8947-4	Angle Assembly—Support	2
1-18809	Clip—Throttle control LH	1
6-10138	Support Assembly—Forward autosyn panel	4
6-10138-1	Bracket—Forward autosyn panel	4
1-20735-1001	Absorber—Rubber shock mount	4
1-21351	Stop—Autosyn panel	8
	(Parts List No. 51)	
3-12226	Bracket Assembly—Starter control (No. 4 nacelle) RH	1
3-12226-1	Channel—Starter control bracket (nacelle No. 4)	1
3-12226-2	Plate—Starter control bracket (nacelle No. 4)	1
BAC1614-20	Spacer—⅛ rivet	2
3-12306	Bracket Assembly—Starter control (nacelle No. 1) LH	1
3-12306-1	Channel—Starter control bracket (nacelle No. 1)	1
3-12306-2	Angle—Starter control bracket (nacelle No. 1)	1
3-12306-3	Plate—Starter control bracket (nacelle No. 1)	1
BAC1614-20	Spacer—⅛ rivet	2
3-12311	Bracket Assembly—Starter control (nacelle No. 4) RH	1
3-12311-1	Channel—Starter control bracket (nacelle No. 4)	1
3-12311-2	Plate—Starter control bracket (nacelle No. 4)	1
BAC1614-20	Spacer—⅛ rivet	2
9-3087	Bracket Installation—Throttle and mix (No. 4 nacelle) RH	1
9-3087-1	Angle—Support	1
3-12003-1	Bracket—Engine control	1
3-12003-4	Bracket—Engine control	1
3-12090	Crank Assembly—Control	2
3-12089-48-48	Crank—Control	2
BAC450-4	Bearing—Ball control	2
41-1066-64-17	Washer—.031 corrosive resistant steel	2
BAC1604-8	Spacer—¼ bolt	1
9-3093	Bracket Installation—Throttle and mixture	2
9-3093-37	Support Assembly—Throttle and mixture bracket	2
1-16511-2	Plate—Crank support	4
3-8202-100	Crank Assembly—Control	2
51-761-1	Lever—Control	2
51-761-6	Lever—Control	2
BAC450-4	Bearing—Ball control	2
3-13530	Crank Assembly—Control	2
3-13530-1	Spacer—Control crank	2
1-18353-1	Arm—Lever—throttle control	2
41-207-26	Crank—Control	2
41-207-16	Crank—Control	2
BAC450-4	Bearing—Ball control	2
41-445-0-12	Spacer—No. 10 bolt	4
41-445-0-16	Spacer—No. 10 bolt	4
BAC1604-143	Spacer—¼ rivet	1
9-3653	Support Installation—Outboard fuel strainer LH	1
9-3653-1	Support Installation—Outboard fuel strainer RH	1
9-3653-2	Bracket Assembly—Outboard fuel strainer LH	1
9-3653-3	Bracket Assembly—Outboard fuel strainer RH	1
1-18767	Bracket—Fuel strainer	1L
1-18767-1	Bracket—Fuel strainer	1R
9-3653-6	Bracket Assembly—Outboard fuel strainer support LH	1

Firewall Assembly—Outboard Nacelle

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
9-3653-7	Bracket Assembly—Outboard fuel strainer support RH	1
3-13664	Bracket—Fuel strainer	2
9-3653-10	Spacer—Strainer—outboard fuel support	1R
	(Parts List No. 52)	
14-2344	Bracket Installation—Propeller pitch control LH	1
14-2344-16	Bracket Assembly—Propeller pitch control	1
BAC1614-59	Spacer—⅛ rivet	2
14-2344-17	Bracket Assembly—Propeller pitch control	1
14-2344-14	Plate—Propeller pitch control bracket	2
BAC1614-53	Spacer—⅛ rivet	2
BAC1604-8	Spacer—¼ rivet	1
BAC1604-14	Spacer—¼ rivet	1
BAC1604-24	Spacer—¼ rivet	1
15-7688	Bracket Installation—Engine control RH	1
15-7688-7	Bracket Assembly—Engine control	1
15-7688-4	Bracket Assembly—Engine control	1
51-487	Plate—Control bracket	1
51-488	Plate—Control bracket	1
15-7688-5	Channel Assembly—Engine control	1
1-19031	Plate—Control bracket	1
51-487	Plate—Control bracket	1
51-488	Plate—Control bracket	1
15-7688-6	Bracket Assembly—Engine control	1
1-19031	Plate—Control bracket	1
BAC1614-53	Spacer—⅛ rivet	2
BAC1614-74	Spacer—⅛ rivet	2
BAC1614-78	Spacer—⅛ rivet	2
1-19001-21	Fairlead Assembly—1 hole	1
1-19001-22	Fairlead—Micarta	2
1-19001-23	Fairlead Assembly—1 hole	1
1-19001-24	Fairlead—Micarta	2
3-12071-1	Bracket—Engine control	1
3-12090-2	Crank Assembly—Control	2
3-12088-48-48	Crank—Serrated control	2
BAC450-4	Bearing—Ball control	2
41-665-2	Guide—Control rod fairlead	2
41-1066-64-17	Washer—.031 steel corrosive resistant	2
41-8607	Washer—No. 10 square	2
51-563-1	Filler—Special	1
51-566	Bracket Assembly—Intercooler temperature control	1
51-566-1	Channel—Intercooler temperature control bracket	1
BAC1614-43	Spacer—⅛ rivet	2
BAC1603-10	Spacer—No. 10 bolt	1
BAC1603-13	Spacer—No. 10 bolt	1
BAC1603-14	Spacer—No. 10 bolt	1
BAC1603-21	Spacer—No. 10 bolt	1
BAC1603-27	Spacer—No. 10 bolt	2
BAC1603-32	Spacer—No. 10 bolt	2
46-7590	Support Installation—Propeller feather pump LH	1
46-7590-1	Support Installation—Propeller feather pump RH	1
46-7590-400	Bracket Assembly—Propeller feather pump LH	1
46-7590-401	Bracket Assembly—Propeller feather pump RH	1
1-20568	Angle—Reinforcing	4
46-7590-410	Filler—Propeller feather pump bracket	2
	(Parts List No. 53)	
49-3088	Bracket Installation—Throttle and mixture LH	1
3-8202-99	Crank Assembly—Control	1
41-207-16	Crank—Lever control	2
BAC450-4	Bearing—Ball control	1
3-12003-2	Bracket—Engine controls	1
3-12004	Bracket—Engine controls	1
3-12090-1	Crank Assembly—Control	1
3-12089-40-40	Crank—Control	1
BAC450-4	Bearing—Ball control	1
41-1066-64-17	Washer—.031 corrosive resistant steel	2
55-6336	Bracket Installation—Engine controls LH	1

AVIALOGS.COM

NACELLE INSTALLATION—OUTBOARD

Firewall Assembly—Outboard Nacelle

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
55-6336-400	Bracket Assembly—Engine controls	1
BAC1603-79	Spacer—No. 10 bolt	4
3-12071	Bracket—Engine controls	1
3-12090-2	Crank Assembly—Controls	2
3-12088-48-48	Crank—Serrated controls	2
BAC450-4	Bearing—Ball control	2
41-445-0-9	Spacer—No. 10 bolt	1
41-665-2	Guide—Control rod fairlead	2
41-1066-64-17	Washer—.031 corrosive resistant steel	2
41-8607	Washer—No. 10 square	1
51-563	Filler—Special	1
51-565	Bracket Assembly — Intercooler temperature control	1
BAC1614-43	Spacer—⅛ rivet	2
51-615-56-28	Fairlead—⅛ cable	4
BAC1603-8	Spacer—No. 10 bolt	1
BAC1603-16	Spacer—No. 10 bolt	1
BAC1604-19	Spacer—¼ bolt	1
BAC1604-29	Spacer—¼ bolt	1
BAC1604-44	Spacer—¼ bolt	1
37-B6535	Tube Assembly—Fire extinguisher (furnished by government)	2

Support Installation—Supchg.—Outboard Nacelle

(Parts List No. 54)

65-5965	Support Installation—Supercharger—outboard nacelle LH	1
65-5965-1	Support Installation—Supercharger—outboard nacelle RH	1
65-5965-403	Cover Assembly—Supercharger—outboard nacelle support LH	1
65-5965-404	Cover Assembly—Supercharger—outboard nacelle support RH	1
BAC1249-210S	Plate—Fiber nut	4
65-5972-501	Beam Assembly—Support—outboard supercharger LH	1
65-5972-502	Beam Assembly—Support—outboard supercharger RH	1
65-5972-424	Cover—Outboard supercharger support beam	2
65-5972-503	Beam Assembly—Outboard supercharger support LH	1
65-5972-504	Beam Assembly—Outboard supercharger support RH	1
65-5972-510	Beam Assembly—Support—outboard supercharger LH	1
65-5972-511	Beam Assembly—Support—outboard supercharger RH	1
65-5972-421	Cover—Outboard supercharger support beam	2
65-5972-512	Beam Assembly—Outboard supercharger support LH	1
65-5972-513	Beam Assembly—Outboard supercharger support RH	1
55-6017	Cowling Installation—Inner—outboard supercharger LH	1
55-6017-1	Cowling Installation—Inner—outboard supercharger RH	1
55-6017-410	Door Assembly—Inner—outboard supercharger cowling	1
55-6017-411	Door Assembly—Inner—outboard supercharger cowling	1
55-6017-422	Plate Assembly—Cover inner outboard supercharger	1R
55-6017-421	Seal—Inner outboard supercharger cowling	1
55-6017-401	Seal—Asbestos—inner outboard supercharger cowling LH	1
55-6017-423	Seal—Asbestos—inner outboard supercharger cowling RH	1
55-6017-416	Door—Inner—outboard supercharger cowling LH	1

Support Installation—Supchg.—Outboard Nacelle

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
55-6017-417	Door—Inner—outboard supercharger cowling RH	1
BAC1249-210S	Plate—Fiber nut	2
55-6017-2	Wall Assembly—Inner outboard supercharger cowling LH	1
55-6017-3	Wall Assembly—Inner outboard supercharger cowling RH	1
55-6017-15	Wall Assembly—Inner outboard supercharger cowling LH	1
55-6017-16	Wall Assembly—Inner outboard supercharger cowling RH	1
55-6017-451	Door Assembly—Inner—outboard supercharger cowling LH	1
55-6017-422	Cover Plate Assembly—Inner outboard supercharger cowling	1
55-6017-421	Seal—Inner outboard supercharger cowling.	1
55-6017-452	Door—Inner outboard supercharger cowling.	1
BAC1249-210S	Nut Plate	1
55-6017-453	Door Assembly—Inner—outboard supercharger cowling RH	1
55-6017-454	Door—Inner outboard supercharger cowling.	1
BAC1249-210S	Plate—Fiber nut	1
BAC1095-1032	Nut—Self locking high temperature	52
65-5965-401	Cover—Front—supercharger—outboard nacelle support	2
41-6351	Flange—Riveted block	2
41-8759	Flange—Riveted block	2
41-8343	Angle—Inboard longeron tie	1L
41-8343-1	Angle—Inboard longeron tie	1R
41-8360	Angle—Inboard longeron tie	1L
41-8360-1	Angle—Inboard longeron tie	1R
41-8219	Angle—Inboard longeron tie	1L
41-8219-1	Angle—Inboard longeron tie	1R
41-7853	Angle—Inboard longeron tie	1L
41-7853-1	Angle—Inboard longeron tie	1R
3-10309	Brace—Supercharger support LH	2
3-10309-1	Brace—Supercharger support RH	2
41-7647-2	Angle—Longeron attachment RH	2

(Parts List No. 55)

41-7647-3	Angle—Longeron attachment LH	2
3-10309-2	Brace—Supercharger support	1R
3-10309-3	Brace—Supercharger support	1L
41-7647	Angle—Longeron attachment	1L
41-7647-1	Angle—Longeron attachment (outboard)	1R
41-7647-4	Angle—Longeron attachment (inboard)	1L
41-7647-5	Angle—Longeron attachment (inboard)	1R
41-3034	Angle—Tubing support	2
41-8364-2	Angle—Longeron tie	2
41-8364-3	Angle—Longeron tie	2
BAC1249-210S	Plate—Fiber nut	4
BAC1603-80	Spacer—No. 10 bolt	2
BAC1603-92	Spacer—No. 10 bolt	16
BAC1603-96	Spacer—No. 10 bolt	6
65-5965-428	Beam Assembly—Horizontal outboard nacelle supercharger support LH	1
65-5965-429	Beam Assembly—Horizontal outboard nacelle supercharger support RH	1
65-5965-430	Beam Assembly—Inboard nacelle supercharger support LH	1
65-5965-431	Beam Assembly—Inboard nacelle supercharger support RH	1
NAS53-S23A	Bolt—Close tolerance	8
NAS53-S23	Bolt—Close tolerance	8
NAS53-S22.5	Bolt—Close tolerance	8

AVIALOGS.COM

WING ASSEMBLY—INNER

Spar Assembly—Front Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 56)	
78-581	Spar Assembly—Wing—front—inner LH (48-713 CL diagonal)	1
78-581-1	Spar Assembly—Wing—front—inner RH	1
78-581-738	Chord Assembly—Lower inner spar LH	1
78-581-739	Chord Assembly—Lower inner spar RH	1
78-581-740	Chord Assembly—Upper inner spar LH	1
78-581-741	Chord Assembly—Upper inner spar RH	1
68-593-600	Cap Installation—Inboard front spar upper LH	1
68-593-601	Cap Installation—Inboard front spar upper RH	1
68-593-517	Cap Installation—Inboard front spar lower LH	1
68-593-518	Cap Installation—Inboard front spar lower RH	1
75-4781	Joint Assembly—Wing spar front station 1-2-3U LH	1
75-4781-1	Joint Assembly—Wing spar front station 1-2-3U RH	1
	Dash number parts, shown on 75-4781 drawing are represented by dash numbers of 65-4781.	
65-4781-516	Channel—Wing spar joint front station 1-2-3U LH	1
65-4781-517	Channel—Wing spar joint front station 1-2-3U RH	1
BAC1604-78	Spacer—¼ bolt	4
65-4781-13	Clip Assembly—Wing spar joint station 1-2-3U LH	1
65-4781-14	Clip Assembly—Wing spar joint station 1-2-3U RH	1
43-8782	Channel—Wing spar front station 1-U LH	1
43-8782-1	Channel—Wing spar front station 1-U RH	1
21-9132-1	Filler—Spar channel	2
65-4781-504	Filler—Wing spar joint front station 1-2-3U	2
65-4781-502	Angle—Wing spar joint front station 1-2-3U LH	1
65-4781-503	Angle—Wing spar joint front station 1-2-3U RH	1
65-4781-500	Angle—Wing spar joint front station 1-2-3U	2
65-4781-501	Angle—Wing spar joint front station 1-2-3U	1
65-4781-521	Angle—Wing spar joint front station 1-2-3U	1
66-5531	Terminal—Front spar upper LH	1
66-5531-1	Terminal—Front spar upper RH	1
41-9674	Clip—Wing rib	2L
41-9674-1	Clip—Wing rib	2R
1-17354	Clip—Wing rib	2
1-17354-1	Clip—Wing rib	2
41-9671-2	Clip—Wing rib	2
65-4781-510	Filler—Wing spar joint front station 1-2-3U	2
NAS54-S33.5A	Bolt—Close tolerance	12
NAS54-S34A	Bolt—Close tolerance	12
NAS54-S22.5A	Bolt—Close tolerance	2
NAS54-S35A	Bolt—Close tolerance	6
NAS54-DD35A	Bolt—Close tolerance	2
NAS54-DD33.5A	Bolt—Close tolerance	4
NAS54-DD34A	Bolt—Close tolerance	10
NAS55-S36.5A	Bolt—Close tolerance	14
NAS55-S37A	Bolt—Close tolerance	2
NAS56-S36A	Bolt—Close tolerance	2
NAS62-S44.5	Bolt—Close tolerance	2
BAC1604-161	Spacer—¼ bolt	12
	(Parts List No. 57)	
BAC1604-172	Spacer—¼ bolt	18
65-4782-510	Joint Assembly—Wing spar front station 1-2-3L LH	1
65-4782-511	Joint Assembly—Wing spar front station 1-2-3L RH	1

Spar Assembly—Front Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-4782-6	Channel Assembly—Wing spar joint front station 1-2-3L LH	1
65-4782-7	Channel Assembly—Wing spar joint front station 1-2-3L RH	1
41-2541	Filler—Wing spar front station 1-L LH	1
41-2541-1	Filler—Wing spar front station 1-L RH	1
41-1426	Filler—Spar channel	2
NAS54S36.5A	Bolt—Close tolerance	4
BAC1604-161	Spacer—¼ bolt	4
65-4781-516	Channel—Wing spar joint front station 1-2-3L LH	1
65-4781-517	Channel—Wing spar joint front station 1-2-3L RH	1
NAS60S43	Bolt—Close tolerance	2
BAC1604-78	Spacer—¼ bolt	4
NAS54S34A	Bolt—Close tolerance	10
41-9671	Clip—Wing rib LH	1
41-9671-1	Clip—Wing rib RH	1
65-4782-505	Filler—Wing spar joint front station 1-2-3L	2
NAS54S22.5A	Bolt—Close tolerance	2
NAS56S36A	Bolt—Close tolerance	2
BAC1604-161	Spacer—¼ bolt	2
46-5891	Connection Assembly—Wing shear LH	1
46-5891-1	Connection Assembly—Wing shear RH	1
56-5532	Terminal—Front spar lower LH	1
56-5532-1	Terminal—Front spar lower RH	1
41-9672	Clip—Wing rib	2L
41-9672-1	Clip—Wing rib	2R
1-17468	Clip—Wing rib	2L
1-17468-1	Clip—Wing rib	2R
NAS54DD33.5A	Bolt—Close tolerance	4
NAS54DD35A	Bolt—Close tolerance	6
NAS54S35A	Bolt—Close tolerance	6
BAC1604-161	Spacer—¼ bolt	16
BAC1604-172	Spacer—¼ bolt	6
59-2409	Joint Assembly—Wing spar front station 4U LH	1
59-2409-1	Joint Assembly—Wing spar front station 4U RH	1
41-9915	Angle—Wing nacelle bulkhead LH	1
41-9915-1	Angle—Wing nacelle bulkhead RH	1
3-9387-4	Channel—Wing spar front LH	1
3-9387-5	Channel—Wing spar front RH	1
NAS54-S37A	Bolt—Close tolerance	4
NAS56-S37-5A	Bolt—Close tolerance	4
NAS56-S40.5A	Bolt—Close tolerance	2
BAC1604-146	Spacer—¼ bolt	4
BAC1604-172	Spacer—¼ bolt	2
59-2408	Joint Assembly—Wing spar front station 4L LH	1
59-2408-1	Joint Assembly—Wing spar front station 4L RH	1
3-12728	Angle—Wing spar LH	1
3-12728-1	Angle—Wing spar RH	1
3-12728-2	Angle—Wing spar LH	1
	(Parts List No. 58)	
3-12728-3	Angle—Wing spar RH	1
41-3422	Gusset—Front	2
NAS54-S34.5A	Bolt—Close tolerance	8
53-9356	Joint Assembly—Wing spar front station 5U LH	1
53-9356-1	Joint Assembly—Wing spar front station 5U RH	1
3-11752	Clip—Wing rib	1R
3-11752-1	Clip—Wing rib	1L
NAS54DD33.5A	Bolt—Close tolerance	2
59-2407	Joint Assembly—Wing spar front station 5L LH	1
59-2407-1	Joint Assembly—Wing spar front station 5L RH	1
3-11752	Clip—Wing rib	1L

AVIALOGS.COM

WING ASSEMBLY—INNER

Spar Assembly—Front Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-11752-1	Clip—Wing rib	1R
NAS54-DD34.5A	Bolt—Close tolerance	2
BAC1604-172	Spacer—¼ bolt	8
59-2406	Joint Assembly—Wing spar front station 6U LH	1
59-2406-1	Joint Assembly—Wing spar front station 6U RH	1
3-9387-2	Channel—Wing spar front LH	1
3-9387-3	Channel—Wing spar front RH	1
41-3150	Spacer—Micarta	2
41-9915-2	Angle—Wing nacelle bulkhead RH	1
41-9915-3	Angle—Wing nacelle bulkhead LH	1
NAS54S37A	Bolt—Close tolerance	4
NAS57S40A	Bolt—Close tolerance	2
NAS57S37.5A	Bolt—Close tolerance	2
BAC1604-172	Spacer—¼ bolt	14
49-2405	Joint Assembly—Wing spar front station 6L LH	1
49-2405-1	Joint Assembly—Wing spar front station 6L RH	1
1-16756	Gusset—Wing spar front	2
3-11768	Angle—Wing spar LH	1
3-11768-1	Angle—Wing spar RH	1
3-11768-2	Angle—Wing spar LH	1
3-11768-3	Angle—Wing spar RH	1
56-5880	Joint Assembly—Wing spar front station 7L LH	1
56-5880-1	Joint Assembly—Wing spar front station 7L RH	1
1-17587	Clip—Nose rib	2
41-9681	Clip—T section	2
BAC1604-172	Spacer—¼ bolt	6
66-5881	Joint Assembly—Wing spar front station 7U LH	1
66-5881-1	Joint Assembly—Wing spar front station 7U RH	1
1-17587	Clip—Nose rib	2
21-6349	Channel—Cradle support LH	1
21-6349-1	Channel—Cradle support RH	1
BAC1604-172	Spacer—¼ bolt	6
66-5879	Joint Assembly—Wing spar front station 8U LH	1
66-5879-1	Joint Assembly—Wing spar front station 8U RH	1
1-17587	Clip—Nose rib	2
	(Parts List No. 59)	
21-6349-2	Channel—Cradle support rear LH	1
21-6349-3	Channel—Cradle support rear RH	1
66-5878	Joint Assembly—Wing spar front station 8L LH	1
66-5878-1	Joint Assembly—Wing spar front station 8L RH	1
1-17587-1	Clip—Nose rib	2
41-9681-2	Clip—T section	1
41-9681-3	Clip—T section	1
41-9821	Fitting Assembly—Jack cone	2
NAS54A-33.5	Bolt—Close tolerance	8
NAS54A-35	Bolt—Close tolerance	8
NAS55A-33.5	Bolt—Close tolerance	4
BAC1604-172	Spacer—¼ bolt	2
66-5877	Joint Assembly—Wing spar front station 9U LH	1
66-5877-1	Joint Assembly—Wing spar front station 9U RH	1
1-17587	Clip—Nose rib	2
21-6349-4	Channel—Cradle support rear LH	1
21-6349-5	Channel—Cradle support rear RH	1
56-5876	Joint Assembly—Wing spar front station 9L LH	1
56-5876-1	Joint Assembly—Wing spar front station 9L RH	1
41-9681	Clip—T section	2
1-17587	Clip—Nose rib	2
66-5875	Joint Assembly—Wing spar front station 10U LH	1
66-5875-1	Joint Assembly—Wing spar front station 10U RH	1
66-5873-600	Gusset—Wing spar station 11U	2
1-17587	Clip—Nose rib	2
21-6349-6	Channel—Cradle support rear LH	1
21-6349-7	Channel—Cradle support rear RH	1

Spar Assembly—Front Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
56-5874	Joint Assembly—Wing spar front station 10L LH	1
56-5874-1	Joint Assembly—Wing spar front station 10L RH	1
1-17587	Clip—Nose rib	2
41-9681	Clip—T section	2
66-5873	Joint Assembly—Wing spar front station 11U LH	1
66-5873-1	Joint Assembly—Wing spar front station 11U RH	1
1-17587	Clip—Nose rib	2
21-6349-10	Channel—Cradle support—rear LH	1
21-6349-11	Channel—Cradle support—rear RH	1
56-5872	Joint Assembly—Wing spar front station 11L LH	1
56-5872-1	Joint Assembly—Wing spar front station 11L RH	1
1-17587	Clip—Nose rib	2
41-9681	Clip—T section	2
46-5871	Joint Assembly—Wing spar front station 12U LH	1
46-5871-1	Joint Assembly—Wing spar front station 12U RH	1
3-9286	Channel—Wing spar front station 12 rear LH	1
3-9286-1	Channel—Wing spar front station 12 rear RH	1
41-3003-56-40	Filler—.125 channel	2
	(Parts List No. 60)	
NAS54-S37.5A	Bolt—Close tolerance	2
BAC1604-161	Spacer—¼ bolt	2
BAC1604-172	Spacer—¼ bolt	2
46-5870-402	Joint Assembly—Wing spar front station 12L LH	1
46-5870-403	Joint Assembly—Wing spar front station 12L RH	1
3-9286	Channel—Wing spar front station 12 rear RH	1
3-9286-1	Channel—Wing spar front station 12 rear LH	1
41-3003-56-40	Filler—.125 channel	4
NAS54-DD34A	Bolt—Close tolerance	2
NAS54-S36.5A	Bolt—Close tolerance	2
BAC1604-161	Spacer—¼ bolt	2
56-5868	Joint Assembly—Wing spar front station 13L LH	1
56-5868-1	Joint Assembly—Wing spar front station 13L RH	1
3-11752-6	Channel—Wing spar front station 13 LH	1
3-11752-7	Channel—Wing spar front station 13 RH	1
NAS54-DD35A	Bolt—Close tolerance	2
NAS54-S35A	Bolt—Close tolerance	4
NAS54-S35.5A	Bolt—Close tolerance	4
BAC1604-172	Spacer—¼ bolt	2
43-9355	Joint Assembly—Wing spar front station 13U LH	1
43-9355-1	Joint Assembly—Wing spar front station 13U RH	1
3-11762-4	Channel—Wing spar front LH	1
3-11762-5	Channel—Wing spar front RH	1
NAS54-S35A	Bolt—Close tolerance	10
56-5866	Joint Assembly—Wing spar front station 14L LH	1
56-5866-1	Joint Assembly—Wing spar front station 14L RH	1
NAS54-DD34A	Bolt—Close tolerance	2
46-5867	Joint Assembly—Wing spar front station 14U LH	1
46-5867-1	Joint Assembly—Wing spar front station 14U RH	1
66-5865	Joint Assembly—Wing spar station 15U LH	1
66-5865-1	Joint Assembly—Wing spar station 15U RH	1
1-17587	Clip—Nose rib	2
41-9674-3	Clip—Nose rib LH	1
41-9674-4	Clip—Nose rib RH	1
66-5864	Joint Assembly—Wing spar front station 15L LH	1
66-5864-1	Joint Assembly—Wing spar front station 15L RH	1
1-17587	Clip—Nose rib	2
41-9676-3	Clip—Nose rib LH	1
41-9676-4	Clip—Nose rib RH	1
66-5863	Joint Assembly—Wing spar front station 16U LH	1
66-5863-1	Joint Assembly—Wing spar front station 16U RH	1
1-17587	Clip—Nose rib	2
41-9674-3	Clip—Nose rib LH	1
41-9674-4	Clip—Nose rib RH	1

AVIALOGS.COM

WING ASSEMBLY—INNER

Spar Assembly—Front Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 61)	
66-5862	Joint Assembly—Wing spar front station 16L LH	1
66-5862-1	Joint Assembly—Wing spar front station 16L RH	1
1-17587	Clip—Nose rib	2
41-9676-3	Clip—Nose rib LH	1
41-9676-4	Clip—Nose rib RH	1
66-5861	Joint Assembly—Wing spar front station 17U LH	1
66-5861-1	Joint Assembly—Wing spar front station 17U RH	1
1-17587	Clip—Nose rib	2
41-6974-3	Clip—Nose rib LH	1
41-6974-4	Clip—Nose rib RH	1
66-5860	Joint Assembly—Wing spar front station 17L LH	1
66-5860-1	Joint Assembly—Wing spar front station 17L RH	1
41-9676-3	Clip—Nose rib LH	1
41-9676-4	Clip—Nose rib RH	1
1-17587	Clip—Nose rib	2
74-1433	Joint Assembly—Wing spar front station 18-19 LH	1
74-1433-1	Joint Assembly—Wing spar front station 18-19 RH	1
3-11720-1	Terminal—Front and rear station 19	4
NAS54-S34	Bolt—Close tolerance	8
NAS55-DD32.5A	Bolt—Close tolerance	12
NAS54-S32.5	Bolt—Close tolerance	8
21-7031	Ring—Wing hoisting	2
61-7032	Lug—Wing hoisting	2
41-9697	Filler—Spar	2
NAS55-DD33.5	Bolt—Close tolerance	8
1-18272-1	Clip—Nose rib	2
1-18272-2	Clip—Nose rib	2
74-1433-2	Gusset Assembly—Wing spar joint station 18-19 LH	2
74-1433-3	Gusset Assembly—Wing spar joint station 18-19 RH	2
1-27180	Plate—Reinforcing front spar strut	4
3-11751	Clip—Wing rib	1L
3-11751-1	Clip—Wing rib	1R
3-11752-4	Clip—Wing rib	1L
3-11752-5	Clip—Wing rib	1R
1-17587	Clip—Nose rib	4
41-9674	Clip—Wing rib	2L
41-9674-1	Clip—Wing rib	2R
41-9676	Clip—Wing rib	1L
41-9676-1	Clip—Wing rib	1R
51-281-1	Clip—Wing rib	1L
51-281-2	Clip—Wing rib	1R
NAS54-DD33A	Bolt—Close tolerance	4
NAS54-S32.5A	Bolt—Close tolerance	8
15-8537	Bulkhead Assembly—Inboard nacelle LH	1
15-8537-1	Bulkhead Assembly—Inboard nacelle RH	1

Dash number parts, shown on 15-8537 drawing are represented by dash numbers of 74-1429 and 15-8537.

	(Parts List No. 62)	
6-7738	Joint Installation—Inboard nacelle block station 6 lower LH	1
6-7738-1	Joint Installation—Inboard nacelle block station 6 lower RH	1
65-6043	Bracket Installation—Engine controls LH	1
65-6043-1	Bracket Installation—Engine controls RH	1
65-6043-2	Bracket Assembly—Engine controls LH	1
65-6043-3	Bracket Assembly—Engine controls RH	1
6-7892	Bracket Installation—Propeller pitch control LH	1
6-7892-1	Bracket Installation—Propeller pitch control RH	1
6-7892-2	Bracket Assembly—Propeller pitch control LH	1
6-7892-3	Bracket Assembly—Propeller pitch control RH	1
BAC1614-46	Spacer—⅛ rivet	6
6-7898	Bracket Installation—Mixture control LH	1

Spar Assembly—Front Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-7898-1	Bracket Installation—Mixture control RH	1
6-7898-2	Bracket Assembly—Mixture control LH	1
6-7898-3	Bracket Assembly—Mixture control RH	1
BAC1614-64	Spacer—⅛ rivet	6
BAC1603-11	Spacer—No. 10 bolt	2
BAC1603-34	Spacer—No. 10 bolt	2
BAC1603-41	Spacer—No. 10 bolt	2
6-7901	Bracket Installation—Throttle control LH	1
6-7901-1	Bracket Installation—Throttle control RH	1
6-7901-2	Bracket Assembly—Throttle control LH	1
6-7901-3	Bracket Assembly—Throttle control RH	1
BAC1603-50	Spacer—No. 10 bolt	2
BAC1614-50	Spacer—⅛ rivet	4
BAC1604-6	Spacer—¼ bolt	4
BAC1604-13	Spacer—¼ bolt	4
41-8802-56-28	Fair-lead—⅛ cable	24
41-6969-44-48	Filler—.125 angle	4
BAC1249-210S	Plate—Fiber nut	8
NAS53-S34	Bolt—Close tolerance	2
NAS53-S33.5	Bolt—Close tolerance	2
41-445-0-10	Spacer—No. 10 bolt	2
41-445-0-14	Spacer—No. 10 bolt	2
NAS53-S32	Bolt—Close tolerance	2
BAC1603-5	Spacer—No. 10 bolt	2
BAC1603-11	Spacer—No. 10 bolt	2
BAC1603-16	Spacer—No. 10 bolt	2
BAC1603-22	Spacer—No. 10 bolt	2
15-8537-5	Sheet Assembly—Bulkhead inboard nacelle LH	1
15-8537-6	Sheet Assembly—Bulkhead inboard nacelle RH	1
74-1429-41	Plate—Splice inboard nacelle bulkhead	2
15-8537-12	Sheet Assembly—Bulkhead inboard nacelle	1L
41-6351	Flange—Riveted bulkhead	2
21-3894-140-6	Washer—Retaining	2
41-8380	Angle—Support	2
41-1645-57	Angle—Tabulated	2
	(Parts List No. 63)	
1-18275-5	Support Installation—Tubing LH	1
1-18275-6	Support Installation—Tubing RH	1
64-1607	Bulkhead Assembly—Outboard nacelle LH	1
64-1607-1	Bulkhead Assembly—Outboard nacelle RH	1
46-8013	Bracket Installation—Supercharger control LH	1
46-8013-400	Bracket—Supercharger control RH	1
1-20199	Spring—Compression	1
3-12090-8	Crank Assembly—Control	1
3-12188	Crank—Control	1
BAC450-4	Bearing—Ball control	1
BAC1604-8	Spacer—¼ bolt	1
1-20201	Washer—Cup	2
1-20200	Pin Assembly—Threaded	1
1-20200-1	Pin—Threaded	1
51-888-2	Angle—Spring support	1
46-8014	Bracket Installation—Supercharger control RH	1
46-8014-400	Bracket—Supercharger control LH	1
1-20200	Pin Assembly—Threaded	1
1-20201	Washer—Cup	2
1-20199	Spring—Compression	1
3-12090-9	Crank Assembly—Control	1
3-12188-1	Crank—Control	1
BAC450-4	Bearing—Ball control	1
BAC1604-8	Spacer—¼ bolt	1
51-888-3	Angle—Spring support	1
6-8375	Bracket Installation—Supercharger control LH	1
3-12212	Bracket—Supercharger control LH	1
3-8202-90	Crank Assembly—Control	1
51-761	Lever—Control	1
51-761-4	Lever—Control	1
BAC450-4	Bearing—Ball control	1
41-1066-64-17	Washer—.031 corrosion resisting steel	1
6-8376	Bracket Installation—Supercharger control RH	1
3-12212-1	Bracket—Supercharger control	1
3-8202-91	Crank Assembly—Control	1

AVIALOGS.COM

WING ASSEMBLY—INNER

Spar Assembly—Front Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
51-761	Lever—Control	1
51-761-4	Lever—Control	1
BAC450-4	Bearing—Ball control	1
41-1066-64-17	Washer—.031 corrosion resisting steel	1
15-6155	Bracket Installation—Supercharger control LH	1
15-6155-1	Bracket Installation—Supercharger control RH	1
15-6155-24	Bracket Assembly—Supercharger control LH	1
15-6155-25	Bracket Assembly—Supercharger control RH	1
15-6155-2	Bracket Assembly—Supercharger control LH	1
15-6155-3	Bracket Assembly—Supercharger control RH	1
	(Parts List No. 64)	
BAC1614-48	Spacer—⅛ rivet	4
15-6155-14	Bracket Assembly—Supercharger control LH	1
15-6155-15	Bracket Assembly—Supercharger control RH	1
BAC1614-48	Spacer—⅛ rivet	4
15-6155-37	Bracket Assembly—Supercharger control LH	1
15-6155-38	Bracket Assembly—Supercharger control RH	1
41-6969-40-40	Filler—.125 angle	8
41-445-0-18	Spacer—No. 10 bolt	2
41-445-0-22	Spacer—No. 10 bolt	2
21-7221-1-16	Spacer—Tabulated	2
BAC53-7S	Bolt—Close tolerance	2
BAC1604-13	Spacer—¼ bolt	4
49-3045	Bracket Installation—Supercharger control LH	1
49-3045-1	Bracket Installation—Supercharger control RH	1
49-3045-2	Bracket Assembly—Supercharger control LH	1
49-3045-3	Bracket Assembly—Supercharger control RH	1
49-3045-400	Filler—Supercharger control	2
21-7221-1-16	Spacer—Tabulated	2
9-3045-9	Bracket Assembly—Supercharger control LH	1
9-3045-10	Bracket Assembly—Supercharger control RH	1
BAC113A55S	Bolt—No. 10-32 bearing	4
BAC114A57S	Bolt—⅛-28 bearing	2
21-7221-16	Spacer—Tabulated	2
41-445-0-22	Spacer—No. 10 bolt	2
3-13905-5	Crank Assembly—Supercharger control	1
3-13905-3	Crank Assembly—Supercharger control	1
3-13905-2	Arm—Supercharger control crank	2
3-13905-1	Hub Assembly—Supercharger control crank	2
1-19827-275	Hub—Tab control	2
BAC1604-140	Spacer—¼ bolt	2
1-19834	Lever—Tab control	2
BAC1604-58	Spacer—¼ bolt	2
BAC1604-64	Spacer—¼ bolt	2
55-6087	Bracket Installation—Engine controls outboard LH	1
55-6087-1	Bracket Installation—Engine controls outboard RH	1
6-7935	Bracket Assembly—Propeller pitch control LH	1
6-7935-1	Bracket Assembly—Propeller pitch control RH	1
6-7935-2	Plate Assembly—Upper propeller pitch control bracket LH	1
6-7935-3	Plate Assembly—Upper propeller pitch control bracket RH	1
6-7935-16	Plate Assembly—Lower propeller pitch control bracket LH	1
6-7935-17	Plate Assembly—Lower propeller pitch control bracket RH	1
BAC1603-83	Spacer—No. 10 bolt	8
55-6087-3	Filler—Outboard engine control bracket	2
BAC1603-26	Spacer—No. 10 bolt	2

Spar Assembly—Front Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 65)	
BAC1603-38	Spacer—No. 10 bolt	2
BAC1603-60	Spacer—No. 10 bolt	2
6-7938	Bracket Assembly—Carburetor air control LH	1
6-7938-1	Bracket Assembly—Carburetor air control RH	1
6-7938-2	Plate Assembly—Upper carburetor air control bracket LH	1
6-7938-3	Plate Assembly—Upper carburetor air control bracket RH	1
41-8951	Angle—Control bracket LH	1
41-8951-1	Angle—Control bracket RH	1
6-7938-6	Plate Assembly—Lower carburetor air control bracket LH	1
6-7938-7	Plate Assembly—Lower carburetor air control bracket RH	1
41-8952	Angle—Control bracket LH	1
41-8952-1	Angle—Control bracket RH	1
BAC1603-86	Spacer—No. 10 bolt	8
NAS54-S35.5A	Bolt—Bearing	2
BAC1603-12	Spacer—No. 10 bolt	2
BAC1603-14	Spacer—No. 10 bolt	2
BAC1603-55	Spacer—No. 10 bolt	2
BAC1603-63	Spacer—No. 10 bolt	2
BAC1604-12	Spacer—¼ bolt	2
21-8539-36	Washer—¼ square	2
6-7939	Bracket Assembly—Throttle control LH	1
6-7939-1	Bracket Assembly—Throttle control RH	1
BAC1614-44	Spacer—⅛ rivet	8
BAC1604-9	Spacer—¼ bolt	4
6-7980	Bracket Assembly—Mixture control LH	1
BAC1614-62	Spacer—⅛ rivet	4
6-7981	Bracket Assembly—Mixture control RH	1
BAC1614-62	Spacer—⅛ rivet	4
BAC1603-39	Spacer—No. 10 bolt	4
41-9174	Angle—Stiff tie LH	1
41-9174-1	Angle—Stiff tie RH	1
41-9174-2	Angle—Stiff tie RH	1
41-9174-3	Angle—Stiff tie LH	1
64-1607-416	Angle—Outboard nacelle block LH	1
64-1607-417	Angle—Outboard nacelle block RH	1
BAC113-8S	Bolt—Bearing	4
15-6343	Bracket Installation—Intercooler temperature control LH	1
15-6343-1	Bracket Installation—Intercooler temperature control RH	1
15-6343-2	Bracket Assembly—Intercooler temperature control LH	1
	(Parts List No. 66)	
15-6343-3	Bracket Assembly—Intercooler temperature control RH	1
51-931	Guard—Micarta	2
BAC1614-24	Spacer—⅛ rivet	4
BAC1614-28	Spacer—⅛ rivet	4
BAC1603-72	Spacer—⅛ rivet	4
15-6343-12	Plate Assembly—Intercooler temperature control LH	1
15-6343-13	Plate Assembly—Intercooler temperature control RH	1
1-19001-103	Fairlead Assembly—Intercooler temperature control	2
1-19001-104	Fairlead—Half intercooler temperature control	4
3-12085	Crank Assembly—Intercooler temperature control LH	1
3-12085-1	Crank Assembly—Intercooler temperature control RH	1
3-12083	Lever Assembly—Control	2
41-9053-2	Shaft—Engine control	2
51-762-4	Lever—Serrated control	2
21-2364-108-57	Washer—.064 aluminum alloy	2
3-12085-2	Spacer—Intercooler temperature control crank	2

AVIALOGS.COM

WING ASSEMBLY—INNER

Spar Assembly—Front Inner

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC450-4	Bearing—Ball control	4
BAC1604-170	Spacer—¼ bolt	2
BAC1604-75	Spacer—¼ bolt	2
BAC1604-53	Spacer—¼ bolt	2
BAC1603-24	Spacer—No. 10 bolt	2
BAC1603-29	Spacer—No. 10 bolt	2
BAC1603-49	Spacer—No. 10 bolt	2
15-6343-17	Plate Assembly—intercooler temperature control bracket LH	1
15-6343-18	Plate Assembly—Intercooler temperature control bracket RH	1
41-9674	Clip—Wing rib	2L
41-9674-1	Clip—Wing rib	2R
1-17460	Clip—Wing rib	1L
1-17460-1	Clip—Wing rib	1R
51-281-1	Clip—Wing rib	1L
51-281-2	Clip—Wing rib	1R

Spar Assembly—Wing Inner—Rear

(Parts List No. 67)

78-582	Spar Assembly—Wing spar—rear LH	1
78-582-1	Spar Assembly—Wing spar—rear RH	1
58-713	CL Diagram—Wing spars	
78-582-738	Chord Assembly—Rear wing inner LH	1
78-582-739	Chord Assembly—Rear wing inner RH	1
78-582-740	Chord Assembly—Rear wing inner LH	1
78-582-741	Chord Assembly—Rear wing inner RH	1
48-594-420	Cap Installation—Inboard rear spar LH	1
48-594-421	Cap Installation—Inboard rear spar RH	1
48-594-422	Cap Installation—Inboard rear spar LH	1
48-594-423	Cap Installation—Inboard rear spar RH	1
6-11945	Joint Assembly—Wing rear spar LH	1
6-11945-1	Joint Assembly—Wing rear spar RH	1
41-9674-2	Clip—Front	2
41-9680	Clip—Rear	2
6-11946	Joint Assembly—Wing rear spar LH	1
6-11946-1	Joint Assembly—Wing rear spar RH	1
3-11751-3	Clip—Front	2
41-9680	Clip—Rear	2
BAC54-DD34A	Bolt	2
6-11947	Joint Assembly—Wing rear spar LH	1
6-11947-1	Joint Assembly—Wing rear spar RH	1
3-11752-3	Clip—Front	2
41-9680-1	Clip—Rear	2
BAC54-DD34A	Bolt	1R
75-4783	Joint Assembly—Wing spar rear—station 1-2 U LH	1
75-4783-1	Joint Assembly—Wing spar rear—station 1-2 U RH	1
65-4783-6	Channel Assembly LH—Wing spar joint station 1-2 U rear	1
65-4783-7	Channel Assembly RH—Wing spar joint station 1-2 U rear	1
81-2540	Channel—Wing spar rear	2
21-6169-18	Filler—Spar channel	2
BAC117A63S	Bolt—Bearing	2
BAC116A62S	Bolt—Bearing	2
BAC1606-161	Spacer—⅜ bolt	2
66-5529	Terminal—Rear spar upper LH	1
66-5529-1	Terminal—Rear spar upper RH	1
41-9682-1	Clip—Wing rib	2
BAC116A64S	Bolt—Bearing	2
BAC117A65S	Bolt—Bearing	2
BAC1606-161	Spacer—⅜ bolt	2
BAC114A56S	Bolt—Bearing	6
41-9674-2	Clip—Wing rib	2
1-17368	Clip—Wing rib	2
BAC114A53S	Bolt—Bearing	4
65-4784-508	Channel—Wing spar joint station 1-2 U rear	2
BAC114A35S	Bolt—Bearing	4

Spar Assembly—Wing Inner—Rear

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1604-80	Spacer—¼ bolt	4
BAC114A53DD	Bolt—Bearing	4
BAC1604-161	Spacer—¼ bolt	6
BAC1604-172	Spacer—¼ bolt	4

(Parts List No. 68)

65-4784-502	Filler—Inside—wing spar joint—rear 1 and 2U	4
NAS56S37A	Bolt—Close tolerance	2
NAS55S37.5A	Bolt—Close tolerance	2
NAS54S33A	Bolt—Close tolerance	8
46-5882	Connection Assembly—Wing shear	2
NAS54S34.5A	Bolt—Close tolerance	6
NAS56S40.5A	Bolt—Close tolerance	2
NAS54DD33.5A	Bolt—Close tolerance	2
BAC1604-161	Spacer—¼ bolt	8
BAC1604-80	Spacer—¼ bolt	4
41-9680-1	Filler—Rear—wing rib clip	2
1-17369	Clip—Wing rib	2
1-17468-2	Clip—Wing rib	2
NAS54DD34.5A	Bolt—Close tolerance	2
NAS55-S33A	Bolt—Close tolerance	4
65-4784-503	Filler—Wing spar joint—rear station 1-2-3L	2
BAC1604-172	Spacer—¼ bolt	4
46-5888	Joint Assembly—Wing spar rear—station 4U LH	1
46-5888-1	Joint Assembly—Wing spar rear—station 4U RH	1
41-2830-1	Channel—Wing spar—rear 6L	2
41-9680	Clip—Wing rib	2
NAS54S36A	Bolt—Close tolerance	8
BAC1604-172	Spacer—¼ bolt	2
56-5887	Joint Assembly—Wing spar rear—station 4L LH	1
56-5887-1	Joint Assembly—Wing spar rear—station 4L RH	1
41-3383	Gusset—Wing spar rear	2
41-9680-2	Clip—Wing rib	2
3-12728-4	Angle—Wing spar	2
3-12728-5	Angle—Wing spar	2
BAC54S33.5A	Bolt—Close tolerance	8

(Parts List No. 69)

56-5883	Joint Assembly—Wing spar rear—station 6L LH	1
56-5883-1	Joint Assembly—Wing spar rear—station 6L RH	1
41-2830	Channel—Wing spar rear 6L	2
41-9678-2	Clip—Wing rib	2
41-9681	Clip—T section	2
NAS54DD34A	Bolt—Close tolerance	2
NAS54S36A	Bolt—Close tolerance	8
NAS54S37A	Bolt—Close tolerance	4
BAC1604-172	Spacer—¼ bolt	2
54-1481-2	Joint Assembly—Wing spar rear—station 7-17 LH	1
54-1481-3	Joint Assembly—Wing spar rear—station 7-17 RH	1
3-6691	Gusset—Rear spar	20
3-6691-2	Gusset—Rear spar	24
3-6692-2	Gusset—Rear spar	4
3-8768	Gusset—Wing spar rear	4
3-8768-1	Gusset—Wing spar rear	4
3-8768-2	Gusset—Wing spar rear	4
3-11997-1	Gusset—Wing spar rear	8
21-6018-1	Gusset—Rear spar	16
64-1434-506	Gusset—Upper—wing spar joint—rear station 18 and 19	4
3-11756	Clip—Wing rib	2
3-11756-1	Clip—Wing rib	2
41-9674-2	Clip—Wing rib	10
41-9676-2	Clip—Wing rib	6
41-9677	Clip—Wing rib	4
41-9678-2	Clip—Wing rib	4
41-9680	Clip—Wing rib	18
41-9680-1	Clip—Wing rib	18
41-9681	Clip—T section	12

AVIALOGS.COM

WING ASSEMBLY—INNER

Spar Assembly—Wing Inner—Rear

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
51-281	Clip—Wing rib	4
21-6126	Channel—Cradle support	2
21-6126-1	Channel—Cradle support	2
21-6126-2	Channel—Cradle support	2
21-6126-3	Channel—Cradle support	2
21-6126-4	Channel—Cradle support	2
41-2823	Channel—Wing spar rear	4
41-3055	Spacer—Micarta	2
41-4448	Bracket Assembly—Fair-lead support LH	1
41-4449	Fair-lead Assembly—Aileron tab control	1L
41-4445	Bracket—Fair-lead support	1R
NAS54DD33A	Bolt—Close tolerance	6
NAS54DD34A	Bolt—Close tolerance	2
NAS54DD34.5A	Bolt—Close tolerance	6
NAS54S35A	Bolt—Close tolerance	20
NAS54-S34.5A	Bolt—Close tolerance	4
21-8539-38	Washer—¼ square	4
	(Parts List No. 70)	
64-1434	Joint Assembly—Wing spar rear—station 18 and 19 LH	1
64-1434-1	Joint Assembly—Wing spar rear—station 18 and 19 RH	1
64-1434-500	Gusset Assembly—Wing spar rear—station 18 and 19 LH	2
64-1434-501	Gusset Assembly—Wing spar rear—station 18 and 19 RH	2
3-8748-4	Plate—Reinforcement	4
3-11720	Terminal—Front and rear—station 19	4
3-11751-2	Clip—Wing rib	2
3-11752-2	Clip—Wing rib	2
41-9674-2	Clip—Wing rib	4
41-9676-2	Clip—Wing rib	2
41-9677	Clip—Wing rib	2
41-9678-1	Clip—Wing rib	2
41-9678-3	Clip—Wing rib	2
41-9679	Clip—Wing rib	2
41-9679-1	Clip—Wing rib	2
51-281	Clip—Wing rib	2
NAS53A-33	Bolt—Close tolerance	8
NAS54-33DD	Bolt—Close tolerance	6
NAS54A-32.5	Bolt—Close tolerance	8
NAS54A-34	Bolt—Close tolerance	8
NAS55A-32.5DD	Bolt—Close tolerance	20
9-2722	Support Installation—Flap motor	1
9-2722-1	Support Assembly—Flap motor	1
6-6918	Support Installation—Flap control LH	1
6-6918-1	Support Installation—Flap control RH	1
6-6918-2	Support Assembly—Flap control LH	1
6-6918-11	Support Assembly—Flap control RH	1
BAC1604-161	Spacer—No. ¼ bolt	4
NAS54-DD35A	Bolt	4
9-2696	Support Installation—Flap control station 5-6 LH	1
9-2696-1	Support Installation—Flap control station 5-6 RH	1
9-2696-2	Support Installation—Flap control station 9-10 LH	1
9-2696-3	Support Installation—Flap control station 9-10 RH	1
9-2696-4	Support Installation—Flap control station 13-14 LH	1
9-2696-5	Support Installation—Flap control station 13-14 RH	1
9-2696-7	Support Assembly—Flap control station 5-6 LH	1
9-2696-10	Support Assembly—Flap control station 9-10 LH	1
9-2696-13	Support Assembly—Flap control station 13-14 LH	1
9-2696-25	Support Assembly—Flap control station 5-6 RH	1
9-2696-26	Support Assembly—Flap control station 9-10 RH	1
9-2696-27	Support Assembly—Flap control station 13-14 RH	1
6-7128	Plate—Flap control station 5-6 LH	2

Spar Assembly—Wing Inner—Rear

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-7128-1	Plate—Flap control station 5-6 RH	2
6-7128-2	Plate—Flap control station 9-10 LH	2
6-7128-3	Plate—Flap control station 9-10 RH	2
6-7128-4	Plate—Flap control station 13-14 LH	2
6-7128-5	Plate—Flap control station 13-14 RH	2
49-2698	Support Installation—Flap control LH	1
49-2698-1	Support Installation—Flap control RH	1
49-2698-400	Support Assembly—Flap control LH	1
	(Parts List No. 71)	
49-2698-401	Support Assembly—Flap control RH	1
NAS54-532.5A	Bolt—Close tolerance	2
9-3039	Support Installation—Fair-lead	1L
9-3039-1	Support Assembly—Fair-lead	1
51-1088	Bracket—Fair-lead support	1R
41-4441	Bracket Assembly—Fair-lead support	1R
51-1161	Bracket Assembly—Fairlead support	2
41-4445	Bracket—Fair-lead support	2
BAC1246-10S	Plate—Fiber nut	4
41-4445	Bracket—Fair-lead support	1R
41-4447	Bracket—Fair-lead support	1L

Spar Installation—Wing Gas Tank Support

(Parts List No. 72)

74-1500	Spar Installation—Fuel tank support LH	1
74-1500-1	Spar Installation—Fuel tank support RH	1
74-1500-600	Spar Assembly—Fuel tank support LH	1
74-1500-601	Spar Assembly—Fuel tank support RH	1
41-3041	Gusset—Fuel tank support spar	4
41-3043	Gusset—Fuel tank support spar	4
41-3044	Gusset—Fuel tank support spar	4
41-3045	Gusset—Fuel tank support spar	2L
41-3045-1	Gusset—Fuel tank support spar	2R
41-3046	Gusset—Fuel tank support spar	2L
41-3046-1	Gusset—Fuel tank support spar	2R
41-3047	Gusset—Fuel tank support spar	2L
41-3047-1	Gusset—Fuel tank support spar	2R
41-3048	Gusset—Fuel tank support spar	2L
41-3048-1	Gusset—Fuel tank support spar	2R
41-3049	Gusset—Fuel tank support spar	2L
41-3049-1	Gusset—Fuel tank support spar	2R
41-3050	Gusset—Fuel tank support spar	2L
41-3050-1	Gusset—Fuel tank support spar	2R
41-3039	Gusset—Fuel tank support spar	4
41-3040	Gusset—Fuel tank support spar	8
21-5782-6	Gusset—Gas tank support spar	8
21-5782-7	Gusset—Gas tank support spar	4
21-5782-8	Gusset—Gas tank support spar	4
21-5782-9	Gusset—Gas tank support spar	4
41-3140	Channel—Cradle support	2L
41-3140-1	Channel—Cradle support	2R
NAS53-S20	Bolt—Close tolerance	2
41-3003-69-44	Filler—.125 channel	4
BAC1603-68	Spacer—No. 10 bolt	2
41-3140-2	Channel—Cradle support	2L
41-3140-3	Channel—Cradle support	2
NAS53-S20	Bolt—Close tolerance	2
41-3003-69-44	Filler—.125 channel	4
BAC1603-68	Spacer—No. 10 bolt	2
41-3140-4	Channel—Cradle support	2L
41-3140-5	Channel—Cradle support	2R
NAS53-17.5S	Bolt—Close tolerance	2
41-3003-69-44	Filler—.125 channel	4
BAC1603-68	Spacer—No. 10 bolt	2
41-3140-6	Channel—Cradle support	2
41-3140-7	Channel—Cradle support	2
NAS53-S20	Bolt—Close tolerance	2
41-3003-69-44	Filler—.125 channel	4
BAC1603-68	Spacer—No. 10 bolt	2

AVIALOGS.COM

WING ASSEMBLY—INNER

Spar Installation—Wing Gas Tank Support

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-3140-8	Channel—Cradle support	2L
41-3140-9	Channel—Cradle support	2
NAS53-S20	Bolt—Close tolerance	2
	(Parts List No. 73)	
41-3003-69-44	Filler—.125 channel	4
BAC1603-68	Spacer—No. 10 bolt	2
41-2823-1	Channel—Wing spar station 12 U and L	2L
41-2823-2	Channel—Wing spar station 12 U and L	2R
NAS53-S20	Bolt—Close tolerance	4
41-3003-56-48	Filler—.125 channel	8
BAC1603-68	Spacer—No. 10 bolt	2
BAC1603-69	Spacer—No. 10 bolt	2
41-2823-3	Channel—Wing spar—station 12 U and L	2L
41-2823-4	Channel—Wing spar—station 12 U and L	2R
NAS53-S20	Bolt—Close tolerance	4
41-3003-56-48	Filler—.125 channel	8
BAC1603-68	Spacer—No. 10 bolt	2
BAC1603-69	Spacer—No. 10 bolt	2
1-18133-2-0	Link—Fuel tank strap	2
1-18132-3-4	Link—Fuel tank strap	2
NAS54-S20	Bolt—Close tolerance	1
BAC1604-68	Spacer—¼ bolt	1
1-18133-2-2	Link—Fuel tank strap	2
1-18132-3-4	Link—Fuel tank strap	2
NAS54-S30	Bolt—Close tolerance	1
BAC1604-68	Spacer—¼ bolt	1
1-18133-2-0	Link—Fuel tank strap	2
1-18132-3-6	Link—Fuel tank strap	2
NAS54-S20	Bolt—Close tolerance	1
BAC1604-68	Spacer—¼ bolt	1
1-18133-2-0	Link—Fuel tank strap	2
1-18132-3-4	Link—Fuel tank strap	2
NAS54-S20	Bolt—Close tolerance	1
BAC1604-68	Spacer—¼ bolt	1
81-8072	Angle—Tank spar connection	1L
81-8072-1	Angle—Tank spar connection	1R
81-8071	Angle—Tank spar connection	1L
81-8071-1	Angle—Tank spar connection	1R
3-11891-2	Channel—Wing tank spar	2
BAC54-S22	Bolt—Close tolerance	4
BAC1604-68	Spacer—¼ bolt	4
74-1500-515	Filler—Fuel tank support spar	4
74-1500-516	Shim—Fuel tank support spar	2
NAS54-DD17	Bolt—Close tolerance	16

Nose Installation—Wing Inner—Station 1-3

(Parts List No. 74)

64-1831	Nose Installation—Station 1-3 wing LH	1
64-1831-1	Nose Installation—Station 1-3 wing RH	1
64-1831-418	Nose Assembly—Station 1-3 wing LH	1
64-1831-419	Nose Assembly—Station 1-3 wing RH	1
59-2314	Rib Installation—Station 1 nose LH	1
59-2314-1	Rib Installation—Station 1 nose RH	1
59-2314-500	Rib Assembly—Station 1 nose LH	1
59-2314-501	Rib Assembly—Station 1 nose RH	1
21-5742-6	Gusset—Nose rib	4
21-5742-7	Gusset—Nose rib	2L
21-5742-8	Gusset—Nose rib	2R
3-12409-3	Shield Assembly—Walkway cut-out	2
BAC1603-24	Spacer No. 10 bolt	2
49-2314-406	Diagonal—Rib station 1 nose	2
49-2314-407	Diagonal—Rib station 1 nose	2
41-871-28-11	Spacer—7/16 micarta	4
49-2314-6	Shim—Rib station 1 nose	8
1-18050-15	Spacer—Wing and tail rib	2
69-1734	Rib Installation—Station 2 nose LH	1
69-1734-1	Rib Installation—Station 2 nose RH	1
69-1734-600	Rib Assembly—Station 2 nose LH	1
69-1734-601	Rib Assembly—Station 2 nose RH	1

Nose Installation—Wing Inner—Station 1-3

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-5742-6	Gusset—Nose rib	4
21-5742-7	Gusset—Nose rib	2L
21-5742-8	Gusset—Nose rib	2R
3-12409	Shield Assembly—Walkway cut-out	2
BAC1603-24	Spacer—No. 10 bolt	2
59-1734-506	Angle—Rib station 2 nose	2
59-1734-507	Diagonal—Rib station 2 nose	2
59-1734-508	Diagonal—Rib station 2 nose	2
41-871-28-11	Spacer—7/16 micarta	4
1-18050-2	Spacer—Wing and tail rib	2
69-1735	Rib Installation—Station 3 nose LH	1
69-1735-1	Rib installation—Station 3 nose RH	1
69-1735-600	Rib Assembly—Station 3 nose LH	1
69-1735-601	Rib Assembly—Station 3 nose RH	1
21-5742-6	Gusset—Nose rib	4
21-5742-7	Gusset—Nose rib	2
21-5742-8	Gusset—Nose rib	2
41-871-28-11	Spacer—7/16 micarta	4
1-18050-2	Spacer—Wing and tail rib	2
55—6539-1	Door Installation—Battery access LH	1
55-6539-400	Door Assembly—Battery access	1
21-6083	Grommet—Dzus type 502	20
21-6082-56	Button—Dzus type FA	20
55-6539-401	Cover Assembly—Battery access door—LH	1
	(Parts List No. 75)	
55-6539-404	Support Assembly—Battery access door	1
21-6038	Spring—Dzus fastener	20
65-6539	Door Installation—Battery access RH	1
65-6539-500	Support Assembly—Battery access door LH	1
21-6038	Spring—Dzus fastener	41
65-6539-3	Door Assembly—Inboard battery access	1
21-6082-56	Button—Dzus type FA	20
21-6083	Grommet—Dzus type 502	20
65-6539-15	Door Assembly—Spotweld battery access	1
65-6539-502	Door Assembly—Outboard battery access	1
21-6082-56	Button—Dzus type FA	22
21-6083	Grommet—Dzus type 502	22
65-6539-503	Door Assembly—Spotweld battery access	1
15-6804	Support Installation—Battery LH	1
15-6804-31	Pan Assembly—Battery support RH	1
41-8208-1	Angle—Tie down	2
15-6804-11	Pad—Rubber battery support	1
15-6804-4	Angle Vertical—Battery support	1
15-6804-6	Angle Vertical—Battery support	1
15-6804-21	Leg Assembly—Battery support	1
1-17469-3	Gusset—Battery support	1
15-6804-30	Leg Assembly—Battery support	1
1-17469	Gusset—Battery support	1
15-6804-17	Pad—Rubber battery support	1
21-2589-27	Clip—Tab loop type	1
BAC1603-28	Spacer—No. 10 bolt	8
15-6994	Support Installation—Battery RH	1
15-6994-30	Pan Assembly—Battery support	1
41-8208-1	Angle—Tie down	2
15-6994-1	Leg Assembly—Battery support	1
1-17469-2	Gusset—Battery support	1
15-6994-20	Pan Assembly—Battery support	1
41-8208-1	Angle—Tie down	2
15-6994-5	Leg Assembly—Battery support	1
1-17469-5	Gusset—Battery support	1
15-6994-31	Leg Assembly—Battery support	1
1-17469-1	Gusset—Battery support	1
15-6994-9	Angle—Vertical battery support	1
51-134-22-7	Spacer—Micarta	1
BAC1603-28	Spacer—No. 10 bolt	12
43-11344-400	Outlet Installation—Battery ventilator LH	1
43-11344-2	Outlet Installation—Battery ventilator RH	1
43-11344-3	Outlet Assembly—Weld battery ventilator	2
64-1680	Intake Installation—Carburetor and intercooler inboard LH	1

AVIALOGS.COM

WING ASSEMBLY—INNER

Nose Installation—Wing Inner—Station 1-3

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
64-1680-1	Intake Installation—Carburetor and intercooler inboard RH	1
64-1680-500	Intake Assembly—Carburetor and intercooler inboard LH	1
	(Parts List No. 76)	
64-1680-503	Intake Assembly—Carburetor and intercooler inboard RH	1
3-12925-4	Inlet Installation—Battery ventilator	1R
3-12925-1	Intake Assembly—Battery ventilator inlet	1R
64-1680-511	Intake Assembly—Carburetor and intercooler LH	1
64-1680-507	Intake Assembly—Carburetor and intercooler RH	1
64-1680-512	Intake Assembly—Weld carburetor and intercooler LH	1
64-1680-508	Intake Assembly—Weld carburetor and intercooler RH	1
3-12925	Intake Installation—Battery ventilator	2
3-12925-1	Intake Assembly—Battery ventilator	2
1-24627	Flange Assembly—Air intake	2
BAC1901	Washer—Flat head screw	44L
BAC1901	Washer—Flat head screw	42R
59-3034	Fair-lead Installation—Station 2 nose LH	1
59-3034-1	Fair-lead Installation—Station 2 nose RH	1
59-3034-500	Angle—Station 2 nose fair-lead LH	1
59-3034-501	Angle—Station 2 nose fair-lead RH	1
59-3034-502	Angle—Station 2 nose fair-lead RH	1
BAC1603-28	Spacer—No. 10 bolt	2
BAC1603-20	Spacer—No. 10 bolt	2
BAC1603-8	Spacer—No. 10 bolt	4
41-8802-56-22	Fair-lead—1/8 cable	4
41-8802-56-28	Fair-lead—1/8 cable	12
59-3035	Fair-lead Installation—Station 3 nose LH	1
59-3035-1	Fair-lead Installation—Station 3 nose RH	1
59-3035-400	Panel Assembly—Station No. 3 nose fair-lead LH	1
59-3035-401	Panel Assembly—Station No. 3 nose fair-lead RH	1
41-445-0-40	Spacer—No. 10 bolt	4
41-8802-56-28	Fair-lead—1/8 cable	60
NAS53-S37A	Bolt—No. 10-32 bearing	2
59-3035-500	Angle—Station 2 nose fair-lead LH	1
59-3035-501	Angle—Station 2 nose fair-lead RH	1
59-3035-10	Angle—Station 2 nose fair-lead LH	1
59-3035-11	Angle—Station 2 nose fair-lead RH	1
41-8802-56-28	Fair-lead—1/8 cable	4
BAC1603-28	Spacer—No. 10 bolt	4
BAC1603-8	Spacer—No. 10 bolt	2
BAC1603-20	Spacer—No. 10 bolt	4
1-16274	Angle—Duct support LH	4
1-16274-1	Angle—Duct support RH	4
41-1645-68	Angle—Tabulated	8

Nose Installation—Wing Inner—Station 7-11

	(Parts List No. 77)	
55-7483	Nose Installation—Wing station 7-11 LH	1
55-7483-1	Nose Installation—Wing station 7-11 RH	1
	Dash number parts, shown on 55-7483 drawing are represented by dash numbers of 15-7483 and 55-7483.	
55-7483-400	Nose Assembly—Wing station 7-11 LH	1
55-7483-401	Nose Assembly—Wing station 7-11 RH	1
55-7483-56	Door—Removable—wing station 7-11 Nose LH	1
55-7483-57	Door—Removable—wing station 7-11 nose RH	1
15-7483-85	Door Assembly—Wing station 7-11 nose	2
15-7483-87	Door—Wing station 7-11 nose	2
41-8209-35	Fastener—Dzus	1
41-8210	Grommet—Dzus type GF	1
41-8211	Spring—Dzus	1

Nose Installation—Wing Inner—Station 7-11

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18543-84L	Angle—Stiffener tie LH	6
1-18543-84R	Angle—Stiffener tie RH	6
1-18543-96L	Angle—Stiffener tie LH	4
1-18543-96R	Angle—Stiffener tie RH	4
9-3438	Rib—Nose station 10 LH	1
9-3438-1	Rib—Nose station 10 RH	1
9-3435	Nose Rib Assembly—Wing station 7 LH	1
9-3435-1	Rib—Nose station 7	1
9-3436	Nose Rib—Wing station 8	1
9-3436-1	Nose Rib—Wing station 8	1
9-3437	Nose Rib—Wing station 9	1
9-3437-1	Nose Rib—Wing station 9	1
9-3439-2	Nose Rib Assembly—Wing station 11 LH	1
9-3439-3	Nose Rib Assembly—Wing station 11 RH	1
15-7973	Bracket Installation—Fuel shut-off valve LH	1
15-7973-1	Bracket Installation—Fuel shut-off valve RH	1
15-7973-2	Bracket Assembly—Fuel shut-off valve LH	1
15-7973-3	Bracket Assembly—Fuel shut-off valve RH	1
1-21075	Bracket—Fuel shut-off valve LH	1
1-21075-1	Bracket—Fuel shut-off valve RH	1
3-14675	Support—Fuel shut-off valve bracket LH	1
3-14675-1	Support—Fuel shut-off valve bracket RH	1
3-14674	Support—Fuel shut-off valve bracket LH	1
3-14674-1	Support—Fuel shut-off valve bracket RH	1
15-7596	Door Installation—Wing access LH	1
15-7596-1	Door Installation—Wing access RH	1
15-7596-2	Door Assembly—Wing access LH	1
15-7596-3	Door Assembly—Wing access RH	1
15-7596-4	Door Assembly—Spotweld—wing access LH	1
15-7596-5	Door Assembly—Spotweld—wing access RH	1
21-6082-46	Button—Dzus type FA	8
21-6083	Grommet—Dzus type 502	8
21-6038	Spring—Dzus fastener	8
	(Parts List No. 77A)	
15-7648	Support Installation—Oil temperature regulator station 7-8 LH	1
15-7648-1	Support Installation—Oil temperature regulator station 7-8 RH	1
15-7648-2	Support Assembly—Oil temperature regulator station 7-8 LH	1
15-7648-3	Support Assembly—Oil temperature regulator station 7-8 RH	1
	(Parts List No. 78)	
9-3695	Cradle Assembly—Oil temperature regulator (rear)	2
9-3695-4	Cradle Assembly—Oil temperature regulator	2
1-19703	Channel—Oil cooler beam	4
BAC343-4-156	Bushing—Staked	8
15-7648-16	Support Assembly—Oil temperature regulator LH	1
15-7648-17	Support Assembly—Oil temperature regulator RH	1
9-3696	Cradle Assembly—Oil temperature regulator LH	1
9-3696-1	Cradle Assembly—Oil temperature regulator RH	1
9-3696-6	Cradle Assembly—Oil temperature regulator LH	1
9-3696-7	Cradle Assembly—Oil temperature regulator RH	1
1-19703	Channel—Oil cooler beam	4
BAC343-4-145	Bushing—Staked	8
41-7050	Cover—De-icer connecting	2
41-7051	Frame—De-icer connecting	2
BAC1246-10S	Plate—Fiber nut	16
BAC1246-210S	Plate—Fiber nut	32
BAC1330-101	Rivnut—No. 6-32—115° countersunk head	140
BAC1901	Washer—Flat head screw	120
15-7483-90	Door—Removable wing station 7-11—nose	1L

AVIALOGS.COM

WING ASSEMBLY—INNER

Nose Installation—Wing Inner—Station 7-11

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7643	Support Installation—Oil temperature regulator LH	1
15-7643-1	Support Installation—Oil temperature regulator RH	1
15-7643-2	Cradle Assembly—Oil temperature regulator LH	1
15-7643-3	Cradle Assembly—Oil temperature regulator RH	1
9-3695	Cradle Assembly—Oil temperature regulator (rear)	2
1-19703	Channel—Oil cooler beam	4
BAC343-4-156	Bushing—Staked	8
15-7643-16	Cradle Assembly—Oil temperature regulator support LH	1
15-7643-17	Cradle Assembly—Oil temperature regulator support RH	1
9-3698	Cradle Assembly—Oil temperature regulator (front) LH	1
9-3698-1	Cradle Assembly—Oil temperature regulator (front) RH	1
9-3698-6	Cradle Assembly—Oil temperature regulator (front)	1
9-3698-7	Cradle Assembly—Oil temperature regulator (front)	1
1-19703	Channel—Oil cooler beam	4
BAC343-4145	Bushing—Staked	8
15-7945	Door—Accessory oil temperature regulator	1R
55-6156	Fair-lead Installation—Station 9—nose LH	1
55-6156-1	Fair-lead Installation—Station 9—nose RH	1
55-6156-407	Panel Assembly—Station 9—Nose fair-lead LH	1
55-6156-408	Panel Assembly—Station 9—Nose fair-lead	1
1-19001-133	Fair-lead—⅛ cable	40
1-23447	Spring—Lock	40
49-3439	Nose Assembly—Rib—station 11 LH	1
49-3439-1	Nose Assembly—Rib—station 11 RH	1
15-7483-106	Door Assembly—Wing station 7-11—nose	2
55-7483-410	Door Assembly—Drain spot weld	1
55-7483-84	Door—Drain accessory	1
55-7483-87	Patch—Door—drain accessory	1
55-7483-111	Hinge—Continuous	1
	(Parts List No. 78A)	
15-7483-111	Hinge continuous	1
41-8210	Grommet—Dzus type 375F	2
41-8209-40	Button—Dzus type AFA	2
41-8211	Spring—Dzus fastener	2
	(Parts List No. 79)	
37B-3822-1	Screw	8
BAC1330-102	Rivnut—No. 6-32—115° countersunk head	8

Nose Installation—Wing Inner—Station 15-19

	(Parts List No. 80)	
15-7476	Nose Installation—Wing station 15-19 LH	1
15-7476-1	Nose Installation—Wing station 15-19 RH	1
15-7476-2	Nose Assembly—Wing station 15-19 LH	1
15-7476-3	Nose Assembly—Wing station 15-19 RH	1
15-7476-28	Door—Wing station 15-19 LH	1
15-7476-29	Door—Wing station 15-19 RH	1
15-7476-68	Hinge—Continuous	2
15-7476-44	Door—Wing station 15-19 nose LH	1
15-7476-45	Door—Wing station 15-19 nose RH	1
BAC1901	Washer—Flat head screw	10
7-1510	Rib Assembly—Nose station 15 LH	1
7-1510-1	Rib Assembly—Nose station 15 RH	1
7-1511	Rib Nose—Station 16 LH	1
7-1511-1	Rib Nose—Station 16 RH	1
7-1512	Rib Nose—Station 17 LH	1
7-1512-1	Rib Nose—Station 17 RH	1
7-1513	Rib Nose—Station 18	2
7-1514	Rib Nose—Station 19	2

Nose Installation—Wing Inner—Station 15-19

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
9-3645	Panel Assembly—Lamp support LH	1
9-3645-1	Panel Assembly—Lamp support RH	1
9-3645-5	Panel—Lamp support LH	1
9-3645-6	Panel—Lamp support RH	1
3-10764-1	Bracket—Passing lamp LH	1
41-4541	Spring Assembly—Clinch nut	8
41-4541-1	Spring—Clinch nut	8
BAC1097-10-63	Nut—Elastic clinch	8
41-4542	Clamp—Passing lamp	1L
3-13622	Gasket—Access door LH	1
3-13622-1	Gasket—Access door RH	1
41-6546	Angle—Stiffener tie LH	1
41-6546-1	Angle—Stiffener tie RH	1
41-6546-2	Angle—Stiffener tie RH	1
41-6546-3	Angle—Stiffener tie LH	1
1-18543-84L	Angle—Stiffener tie LH	4
1-18543-84R	Angle—Stiffener tie RH	4
1-18543-96R	Angle—Stiffener tie RH	1L
1-18543-96L	Angle—Stiffener tie LH	1R
1-18665	Angle—Landing lamp LH	1
1-18665-1	Angle—Landing lamp RH	1
54-1618	Intake Installation—Carburetor and intercooler LH	1
54-1618-1	Intake Installation—Carburetor and intercooler RH	1
54-1618-410	Intake Assembly—Carburetor and intercooler LH	1
54-1618-411	Intake Assembly—Carburetor and intercooler RH	1
54-1618-418	Intake Assembly—Carburetor and intercooler LH	1
54-1618-419	Intake Assembly—Carburetor and intercooler RH	1
BAC1907-11S	Washer—Flat head screw	152
15-7607	Lamp Installation—Landing and passing LH	1
15-7607-1	Lamp Installation—Landing and passing RH	1
15-7607-11	Lamp—Landing and passing (government furnished)	1
	(Parts List No. 81)	
15-7607-12	Lamp—Landing and passing (Government furnished)	2
6-7186	Bracket—Landing lamp	2
6-7366	Ring Assembly—Landing lamp	2
6-7366-1	Ring—Landing lamp	2
6-7366-2	Block—Landing lamp	12
6-7369	Plate—Landing lamp	2
9-3648	Lens—Landing light LH	1
9-3648-1	Lens—Landing light RH	1
21-9588-9	Washer—Ball seat	8
41-1399-26	Screw Assembly—No. 10-32 wing	4
41-1399-1	Plate—No. 10—32 wing screw	4
41-1399-48	Screw Assembly—No. 10—32 wing	4
41-1399-1	Plate—No. 10—32 wing screw	4
51-61-15-6	Washer—Paw tape	72
51-75	Washer—Special	4
36D3467	Lamp Assembly—Running type B3 (Government furnished)	2
37D4865	Lamp Assembly—Running type B3 (Government furnished)	1
BAC1901	Washer—Flat head screw	18

Panel Installation—Wing—Station 1-6 Lower

	(Parts List No. 82)	
85-4808	Panel Installation—Wing station 1-6 lower LH	1
85-4808-1	Panel Installation—Wing station 1-6 lower RH	1
	Dash number parts, shown on 85-4808 drawing are represented by dash numbers of 75-4808 and 85-4808	
75-4808-600	Door Assembly—Jig wing panel station 1-6 lower LH	1

AVIALOGS.COM

WING ASSEMBLY—INNER

Panel Installation—Wing—Station 1-6 Lower

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
75-4808-601	Door Assembly—Jig wing panel station 1-6 lower RH	1
64-2054	Cover Installation—Booster pump accessory LH	1
64-2054-1	Cover Installation—Booster pump accessory RH	1
64-2054-406	Cover Assembly—Booster pump accessory	2
41-3862	Grommet—Dzus type 375	8
41-3866-35	Button—Dzus type A	4
41-3866-40	Button—Dzus type A	4
14-2055-1	Cover—Booster pump accessory	2
41-3863	Spring—Dzus fastener	8
41-5495-38	Washer—No. 10 square	16
BAC1603-50	Spacer—No. 10 bolt	16
54-1691	Mount Installation—Inboard supercharger LH	1
54-1691-1	Mount Installation—Inboard supercharger RH	1
55-5839	Patch Installation—Wing supercharger support LH	1
55-5839-1	Patch Installation—Wing supercharger support RH	1
BAC1603-44	Spacer—No. 10 bolt	4
55-5918	Brace Installation—Rear inboard supercharger LH	1
55-5918-1	Brace Installation—Rear inboard supercharger RH	1
51-471	Clip—Supercharger brace	4
41-871-27-13	Spacer—7/16 micarta	8
NAS53S4.5A	Bolt—Close tolerance	8
BAC1253-110	Nut Plate—High temperature	36
BAC1095-10-32	Nut—Self-locking high temperature	32
55-6142	Bracket Installation—Supercharger controls LH	1
55-6142-1	Bearing Assembly—Supercharger control bracket	1
41-9284	Housing Assembly—Bearing	1
41-9284-1	Housing—Bearing	1
21-9734-64	Spacer—No. 10-32 nut plate	4
41-7473	Washer—Special	1
BAC1603-52	Spacer—No. 10 bolt	1
55-6142-2	Shaft Assembly—Supercharger control bracket	1
41-4023-8-22	Shaft—Control lever	1
1-17588-4	Lever—Engine control	1
1-17588-5	Lever—Engine control	1
55-6142-5	Bracket Assembly—Supercharger control	1
21-8469-50-50	Spacer—No. 10 bolt	3
55-6142-405	Bracket Assembly—Supercharger control	1
41-9284	Housing Assembly—Bearing	1
41-9284-1	Housing—Bearing	1
BAC114S58A	Bolt—Bearing	3

(Parts List No. 83)

9-3038	Bracket Assembly—Supercharger regulator control	1
9-3038-1	Support Assembly—Supercharger regulator bracket	1
9-3038-9	Support Assembly—Supercharger regulator bracket	1
21-8469-48-50	Spacer—No. 10 bolt	4
6-8010	Crank Assembly—Supercharger control	1
6-8010-1	Crank Assembly—Supercharger control	1
6-8010-2	Crank—Supercharger control	1
BAC283-10ST	Bushing—No. 10 press	2
41-5282-8	Lever—Control	1
BAC450-4	Bearing—Ball control	1
BAC1608-41	Spacer—½ bolt	1
BAC1604-20	Spacer—¼ bolt	1
BAC1604-23	Spacer—¼ bolt	1
1-20200	Pin Assembly—Threaded	1
1-20200-1	Pin—Threaded	1
1-20199	Spring—Compression	1
1-20201	Washer—Cup	2
55-6154	Bracket Installation—Supercharger control RH	1
55-6154-2	Bearing Assembly—Supercharger control	1
41-9284	Housing Assembly—Bearing	1
41-9284-1	Housing—Bearing	1

Panel Installation—Wing—Station 1-6 Lower

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-9734-64	Spacer—No. 10-32 nut plate	2
41-7473	Washer—Special	2
55-6154-3	Shaft Assembly—Supercharger control bracket	1
41-4023-8-10	Shaft—Control lever	1
1-17588-4	Crank—Engine control lever	1
1-17588-5	Crank—Engine control lever	1
BAC1608-41	Spacer—½ bolt	1
55-6154-6	Bracket Assembly—Supercharger control	1
21-8469-50-50	Spacer—No. 10 screw	4
55-6154-403	Bracket Assembly—Supercharger control	1
41-9284	Housing Assembly—Bearing	1
41-9284-1	Housing—Bearing	1
BAC114S58A	Bolt—¼-28 bearing	3
3-11620	Crank Assembly—Supercharger control	1
3-11620-1	Crank Assembly—Supercharger control	1
3-11620-2	Crank—Supercharger control	1
BAC283-10ST	Bushing—No. 10 press	2
BAC450-4	Bearing—Ball control	1
BAC1604-16	Spacer—¼ bolt	1
BAC1604-26	Spacer—¼ bolt	1
9-3038	Bracket Assembly—Supercharger regulator support	1
9-3038-1	Support Assembly—Supercharger regulator bracket LH	1
9-3038-9	Support Assembly—Supercharger regulator bracket RH	1
9-3038-8	Plate—Supercharger regulator support bracket	1
21-8469-48-50	Spacer—No. 10 bolt	4

(Parts List No. 84)

1-20200	Pin Assembly—Threaded	1
1-20199	Spring—Compression	1
1-20201	Washer—Cup	2
3-14239	Bracket Installation—Fuel shut-off valve	1
3-14239-1	Bracket Installation—Fuel shut-off valve	1
3-14651	Bracket Assembly—Fuel shut-off valve	2
3-14651-1	Bracket Assembly—Fuel shut-off valve	2
15-6249	Support Installation—Landing gear LH	1
15-6249-1	Support Installation—Landing gear RH	1
15-6249-2	Support Assembly—Landing gear LH	1
15-6249-3	Support Assembly—Landing gear RH	1
41-805	Tube—Landing gear support	2
41-2789	Trunnion—Landing gear	2
9-3048-2	Fitting—Landing gear attachment LH	1
9-3048-3	Fitting—Landing gear attachment RH	1
7-1345	Fitting—Landing gear support LH	1
7-1345-1	Fitting—Landing gear support RH	1
41-9404-1	Bolt—Special	4
1-17461	Bolt—Clevis 1"	4
21-9588-11	Washer—Ball seat	12
6-8129-2	Fitting—Landing gear attachment LH	1
6-8129-3	Fitting—Landing gear attachment RH	1
41-3387-18-10	Bolt—7/17-20 drilled head	
41-3387-17-9	Bolt—7/17-20 drilled head	14
41-3387-16-8	Bolt—7/17-20 drilled head	
41-3387-20-12	Bolt—7/17-20 drilled head	
41-3387-19-11	Bolt—7/17-20 drilled head	14
41-3387-18-10	Bolt—7/17-20 drilled head	
21-8645-18-10	Bolt—⅜-24 drilled head	
21-8645-17-9	Bolt—⅜-24 drilled head	12
21-8645-16-8	Bolt—⅜-24 drilled head	
21-8645-20-12	Bolt—⅜-24 drilled head	
21-8645-19-11	Bolt—⅜-24 drilled head	12
21-8645-18-10	Bolt—⅜-24 drilled head (Bolts to be used depending on variation of shim used in Assembly. Total number required in Assembly.)	
21-9588-4	Washer—Ball seat	2
21-9588-8	Washer—Ball seat	8
46-6513-400	Angle—Landing gear attachment station 6 LH	1
46-6513-401	Angle—Landing gear attachment station 6 RH	1
46-6513-402	Angle—Landing gear attachment station 6 LH	1

AVIALOGS.COM

WING ASSEMBLY—INNER

Panel Installation—Wing—Station 1-6 Lower

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 85)	
46-6513-403	Angle—Landing gear attachment station 6 RH	1
BAC1607-95	Spacer—7/17 bolt	8
BAC1606-95	Spacer—⅜ bolt	22
46-6512-400	Angle—Landing gear attachment station 4 LH	1
46-6512-401	Angle—Landing gear attachment station 4 RH	1
46-6512-402	Angle—Landing gear attachment station 4 LH	1
46-6512-403	Angle—Landing gear attachment station 4 RH	1
BAC1606-105	Spacer—⅜ bolt	22
BAC1607-105	Spacer—7/16 bolt	8
BAC113-39S	Bolt—Bearing	6
BAC113-41S	Bolt—Bearing	6
BAC1603-123	Spacer—No. 10 bolt	12
21-9735-64	Spacer—½-28 nut plate	16
41-1156-1	Dowel—Fuel tank doors	4
41-1156-2	Dowel—Fuel tank doors	2
41-6492-2	Shim—Wing panel	1R
41-6492-3	Shim—Wing panel	1L
41-6492-5	Shim—Wing panel	2
3-11154	Gusset—Tank spar connection	2
51-610	Angle—Spar cap splice LH	1
51-610-2	Angle—Spar cap splice RH	1
21-3147-2	Washer—.019 steel (corrosive resistant)	450
1-20022	Angle—Tube support	2
BAC1255-45-101	Nut—Gang channel standard steel	16
BAC1257-412-122	Nut—Gang channel counterboard steel	2
BAC1257-412-123	Nut—Gang channel counterboard steel	2
BAC1257-424-105	Nut—Gang channel counterboard steel	4

Panel Installation—Wing—Station 1-19 Upper

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 86)	
85-5005	Panel Installation—Wing—station 1-19 upper LH	1
85-5005-1	Panel Installation—Wing—station 1-19 upper RH	1
85-5005-700	Skin Assembly—Wing—station 1-19 upper panel LH	1
85-5005-701	Skin Assembly—Wing—station 1-19 upper panel RH	1
7-1506	Patch Installation—Tank gage LH	1
7-1506-1	Patch Installation—Tank gage RH	1
3-13569	Cover Assembly—Main tank gage LH	1
3-13569-1	Cover—Main tank gage	1
1-16064	Bushing—Antenna connection	1
7-1506-6	Patch Assembly—Engine tank gage	2
1-20562	Shim—Tapered corrugation	2
1-18641	Cover—Tank gage RH	1
14-2069	Patch Installation—Engine 1 and 4—tank filler	1L
14-2069-1	Patch Installation—Engine 1 and 4—tank filler	1R
9-3642-2	Door Installation—Tank filler	1
9-3642-3	Door Installation—Tank filler	1
9-3642-12	Door Assembly—Tank filler	2
9-3642-13	Door—Tank filler	2
41-8209-35	Button—Dzus type AFA	2
41-8210	Grommet—Dzus type 375F	2
9-3642-16	Chain—Tank filler door	2
41-8211	Spring—Dzus fastener	2
BAC1246-10S	Plate—Fiber nut	8
15-7591	Patch Installation—Feeder tank filler	1L
15-7591-1	Patch Installation—Feeder tank filler	1R
9-3642	Door Installation—Tank filler	1
9-3642-1	Door Installation—Tank filler	1
9-3642-12	Door Assembly—Tank filler	2
9-3642-13	Door—Tank filler	2
41-8209-35	Button—Dzus type AFA	2
41-8210	Grommet—Dzus type 375F	2
9-3642-16	Chain—Tank filler door	2
41-8211	Spring—Dzus fastener	2
BAC1246-10S	Plate—Fiber nut	8
1-20562	Shim—Tapered corrugation	2
1-20562-1	Shim—Tapered corrugation	2
1-18641-1	Cover—Tank gage	2

Panel Installation—Wing—Station 1-19 Upper

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7591-12	Patch Assembly—Feeder tank filler	2
15-7591-13	Patch Assembly—Feeder tank filler	2
15-7592	Patch Installation—Engine 2 and 3 tank filler	1L
15-7592-1	Patch Installation—Engine 2 and 3 tank filler	1L
15-7592-10	Patch Assembly—Engine No. 2 and 3 tank filler	2
9-3642-4	Door Installation—Tank filler	1
9-3642-5	Door Installation—Tank filler	1
9-3642-12	Door Assembly—Tank filler	2
9-3642-13	Door—Tank filler	2
41-8209-35	Button—Dzus type AFA	2
41-8210	Grommet—Dzus type 375F	2
9-3642-16	Chain—Tank filler door	2
41-8211	Spring—Dzus fastener	2
	(Parts List No. 87)	
BAC1246-10S	Plate—Fiber nut	4
1-18641-1	Cover—Tank gage	2
1-20561-1	Shim—Corrugated	6
41-6492	Shim—Wing panel	1L
41-6492-1	Shim—Wing panel	1R
41-6492-4	Shim—Wing panel	2
41-7473	Washer—Special	24
3-12040-11	Plate—Corrugated splice	2
3-12040-5	Plate—Corrugated splice	24
3-12041-5	Plate—Corrugated splice	20
3-12041-11	Plate—Spar splice	6
51-610	Angle—Spar cap splice LH	2

Door Installation—Fuel Tank—Station 7-11

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 88)	
75-4799	Door Installation—Fuel tank—station 7-11 LH	1
75-4799-1	Door Installation—Fuel tank—station 7-11 RH	1
75-4799-600	Door Assembly—Fuel tank station 7-11 LH	1
75-4799-601	Door Assembly—Fuel tank station 7-11 RH	1
47-1309	Door Installation—Drain cock accessory LH	1
47-1309-1	Door Installation—Drain cock accessory RH	1
6-9220	Door Assembly—Drain cock accessory	2
6-9220-1	Cover—Drain cock accessory door	2
41-8209-35	Fastener—Dzus type AFA	4
BAC1328-5-175	Grommet—Dzus type 375F	4
1-18355	Plate—Reinforcing	4
41-8211	Spring—Dzus fastener	4
1-20373	Plate—Serrated	4
75-4799-618	Beam Assembly—Fuel tank station 7-11 door	10
1-18232	Channel—Tank door	10
1-18247	Channel—Tank door	10
1-21065	Block—Serrated	4
75-4799-602	Door Assembly—Fuel tank station 7-11 LH	1
75-4799-603	Door Assembly—Fuel tank station 7-11 RH	1
75-4799-635	Beam Assembly—Fuel tank station 8 LH	1
75-4799-636	Beam Assembly—Fuel tank station 8 RH	1
1-21993	Block—Serrated	2
1-20373	Plate—Serrated	2
75-4799-637	Beam Assembly—Fuel tank station 10 LH	1
75-4799-638	Beam Assembly—Fuel tank station 10 RH	1
1-21993	Block—Serrated	2
1-20373	Plate—Serrated	2
1-18248-1	Channel—Tank door	8
1-18249	Channel—Tank door	1L
1-18249-1	Channel—Tank door	1R
1-18249-2	Channel—Tank door	4L
1-18249-3	Channel—Tank door	4R
1-18248	Channel—Tank door	2
15-7784	Cover Installation—Pump and drain accessory LH	1
15-7784-1	Cover Installation—Pump and drain accessory RH	1
15-7784-2	Cover Assembly—Pump and drain accessory LH	2

AVIALOGS.COM

WING ASSEMBLY—INNER

Door Installation—Fuel Tank—Station 7-11

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
14-2354	Cover—Booster pump accessory	2
41-3862	Grommet—Dzus type 375F	6
41-3866-40	Fastener—Dzus type "A" button	6
41-3866-35	Fastener—Dzus type "A" button	6
1-18355	Plate—Reinforcement	4
41-3863	Spring—Dzus fastener	6
41-8211	Spring—Dzus fastener	4
6-9220	Door Assembly—Drain cock accessory	2
6-9220-1	Cover—Drain cock accessory door	2
41-8209-35	Button—Dzus type AFA	4
41-8210	Grommet—Dzus type 375F	4

Door Installation—Fuel Tank—Station 7-11

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 89)	
3-11738	Cone Installation—Jacking LH	1
3-11738-1	Cone Installation—Jacking RH	1
41-9656	Cone—Jacking LH	2
41-9576	Collar—Jack cone	2
41-1156	Dowel—Fuel tank doors	16
41-5106	Tee—Tank door	24
21-3147-2	Washer—.019 corrosive resistant steel	462
21-9735-188	Spacer—¼-28 nut plate	2
75-4799-650	Pad—Adelite—fuel tank door station 7-11	10
75-4799-651	Pad—Adelite—fuel tank door station 7-11	10
75-4799-652	Washer—Plate—fuel tank door station 7-11	8

WING INSTALLATION—INNER

Support Installation—Flap

	(Parts List No. 90)	
64-1490	Support Installation—Flap LH	1
64-1490-1	Support Installation—Flap RH	1
61-6672	Flange—Tube support—station 2, 6, 10, 12, LH	5
61-6672-1	Flange—Tube support—station 2, 6, 10, 12, RH	5
61-6674	Flange—Tube support—station 13 LH	5
61-6674-1	Flange—Tube support—station 13 RH	5
3-12077	Flange—Flap tube support—station 1	2
3-12077-4	Flange—Flap tube support—station 2	2
3-12077	Flange—Flap tube support—station 5	2
3-12077-5	Flange—Flap tube support—station 6	2
3-12077-2	Flange—Flap tube support—station 9	2
3-12077-6	Flange—Flap tube support—station 10	2
3-12077-3	Flange—Flap tube support—station 13	2
3-12077-7	Flange—Flap tube support—station 14	2
3-12078	Flange Assembly—Flap tube support—station 17.	2
3-12078-1	Flange Assembly—Flap tube support—station 18.	2
BAC54-DD11A	Bolt—Close tolerance	58
BAC54-DD12.5A	Bolt—Close tolerance	62
BAC54-DD11.5A	Bolt—Close tolerance	4
BAC54-S10.5A	Bolt—Close tolerance	8
BAC54-S12.5A	Bolt—Close tolerance	8
BAC1604-34	Spacer—¼ bolt	25R
BAC1604-27	Spacer—¼ bolt	66
BAC1604-36	Spacer—¼ bolt	10R
BAC1604-36	Spacer—¼ bolt	55L
61-6866	Bracket Assembly—Flap support	14
41-3018-253-6	Bushing—¼ staked	28
61-6866-400	Fitting—Flap support	28
BAC54DD24	Bolt—Close tolerance	28
61-6866-3	Bracket Assembly—Flap support	8
41-4222-253-3	Bushing—5/16 staked	16
61-6866-401	Fitting—Flap support	8
1-17357	Bracket Assembly—Flap support RH	1
1-17357-1	Bracket Assembly—Flap support LH	1
1-17357-2	Bracket—Flap support LH	1
1-17357-3	Bracket—Flap support RH	1
41-3018-253-6	Bushing—¼ staked	4

Support Installation—Flap

64-1490-400	Washer—Flap support	16
64-1490-401	Washer—Flap support	4
6-9279	Swing Assembly—Flap support LH	1
6-9279-1	Swing Assembly—Flap support LH	1
6-9279-2	Swing Assembly—Flap support RH	2
6-9279-3	Swing—Flap support LH	1
6-9279-4	Swing—Flap support LH	1
6-9279-5	Swing—Flap support RH	2
6-9279-6	Bearing—Flap support (Fafnir-D4)	8
21-4843-50	Jumper Assembly—No. 8¼ terminal bonding	4
21-4843-50A	Braid—Copper No. 8¼ terminal bonding jumper	4
	(Parts List No. 91)	
BAC820-8	Terminal—Lock	4
BAC820-14	Terminal—Lock	4
21-4843-80	Jumper Assembly—No. 8¼ terminal bonding	4
21-4843-80A	Braid—Copper No. 8¼	4
BAC820-8	Terminal—Lock	4
BAC820-14	Terminal—Lock	4
21-6854-2	Arm Assembly—Flap support	6
41-3555	Terminal Assembly—Flap control	6
41-3555-1	Terminal—Flap support	6
41-3555-2	Bearing—Flap support terminal (Fafnir-D4)	12
21-6708-2	Terminal Assembly—Control rod	6
21-6708-3	Terminal—Control rod	6
51-981	Rod Assembly—Adjustable flap	8
41-3572	Terminal Assembly—Control rod	16
41-3572-1	Terminal—Control rod	16
51-982	Plug—Threaded adjustable flap	8
51-983	Tube—Adjustable flap threaded	8
51-981-2	Rod Assembly—Adjustable flap	2
21-6708-2	Terminal Assembly—Control rod	2
21-6708-3	Terminal—Control rod	2
41-3572	Terminal Assembly—Control rod	2
41-3572-1	Terminal—Control rod	2
51-982	Plug—Threaded—adjustable flap	2
51-983	Tube—Adjustable flap threaded	2

WING ASSEMBLY—INNER

Control Installation—Wing Flap

	(Parts List No. 92)	
55-5442	Control Installation—Wing flap LH	1
55-5442-1	Control Installation—Wing flap RH	1
49-2631	Motor Assembly—Unit flap controls	1L
46-6603	Housing—Flap controls	1
41-4483	Cap Assembly—Flap control	2
41-4483-1	Cap—Flap control	2
41-1434-1	Gear—Flap control	1
41-1435	Gear—Flap control	1

Control Installation—Wing Flap

41-1436-2	Gear—Flap control	1
BAC1002-8	Key—5/32 square	2
BAC1851-16	Universal Joint—(Apex 2700 13-16)	2
41-2801	Plate—Flap control	2
1-19034	Spacer—Flap control	1
49-2631-2	Sleeve—Unit flap control motor	2
41-1439	Shim—Laminated	2
41-4602-1	Washer—Flap control	2
41-4601	Nut—Flap control	2

AVIALOGS.COM

WING ASSEMBLY—INNER

Control Installation—Wing Flap

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-6905	Shaft Assembly—Flap motor	1
41-6905-1	Tube—Flap motor shaft	2
3-8752-1	Screw—Flap motor stop	1
3-11733	Nut—Flap motor stop	1
41-4498	Stop—Flap motor	1
51-569	Stop—Flap motor	1
51-568	Coupling—Flap motor	1
41-4600	Stop Assembly—Flap motor	1
41-4600-1	Stop—Flap motor	1
41-4600-2	Pin—Flap motor stop	1
41-5613	Spring—Torsion	1
49-2976	Tube Assembly—Flap motor unit	1
49-2976-400	Tube—Flap motor unit	1
49-2976-402	Track—Flap motor unit tube	2
41-8487	Washer—Special	4
41-5205	Flange—Flap control	1
41-4937	Flange—Flap control unit	1
41-5876	Cover Assembly—Flap control	2
41-5876-1	Cover—Flap control	1
41-5876-2	Spring—Flap control cover	1
21-8038-12	Screw—No. 10-32 flat head	8
41-4220-1	Coupling—Shaft	2
6-8325	Shield Assembly—Flap limit switch	1
6-8325-1	Box Assembly—Flap limit switch shield	1
BAC1247-80	Angle—Nut plate	6
6-8325-5	Channel Assembly—Flap limit switch shield	1
21-6092-12-0	Bolt—Special No. 10-32	1
51-490	Trip—Limit switch	1
51-493	Spring—Return	1
39A3756	Switch Assembly—Type B-15	2
6-8325-7	Spacer—Flap limit shield	1
6-8325-12	Spacer—Flap limit shield	1
BAC1603-38	Spacer—No. 10 bolt	2
	(Parts List No. 93)	
6-8325-10	Cover—Flap limit switch shield	1
36A4486-832	Screw—Round head necked	6
51-211	Striker—Limit switch	2
51-482	Nut—Limit switch	1
49-2631-4	Shim—Limit switch	1
7-1365	Control Assembly—Wing flap LH	1
7-1365-1	Control Assembly—Wing flap RH	1
7-1365-2	Control Assembly—Wing flap LH	1
7-1365-3	Control Assembly—Wing flap RH	1
7-1365-4	Control Assembly—Wing flap LH	1
7-1365-5	Control Assembly—Wing flap RH	1
7-1365-6	Control Assembly—Wing flap LH	1
7-1365-7	Control Assembly—Wing flap RH	1
7-1365-8	Control Assembly—Wing flap LH	1
7-1365-9	Control Assembly—Wing flap RH	1
43-8754	Bracket Assembly—Flap control	10
43-8754-1	Bracket—Base flap control	10
43-8754-2	Bracket—Top flap control	20

Control Installation—Wing Flap

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
43-8756	Housing—Wing flap control	10
41-4483	Cap Assembly—Flap control	20
41-4483-1	Cap—Flap control	20
41-1436	Shaft—Flap control	10
41-1434	Gear—Flap control	10
41-1435	Gear—Flap control	10
BAC1002-8	Key—5/32 square	10
41-2801	Plate—Flap control	10
41-4601	Nut—Flap control	20
41-4602-1	Washer—Flap control	20
7-1365-10	Sleeve—Wing flap control	20
3-12087	Rod Assembly—Flap control (used in -0 and -1)	2
3-12087-2	Rod Assembly—Flap control (used in -2 and -3)	2
3-12087-4	Rod Assembly—Flap control (used in -4 and -5)	2
3-12087-6	Rod Assembly—Flap control (used in -6 and -7)	2
3-12087-8	Rod Assembly—Flap control (used in -8 and -9)	2
3-12087-1	Tube—Flap control rod (used in -0 only)	2
3-21087-3	Tube—Flap control rod (used in -2 only)	2
3-12087-5	Tube—Flap control rod (used in -4 only)	2
3-12087-7	Tube—Flap control rod (used in -6 only)	2
3-12087-9	Tube—Flap control rod (used in -8 only)	2
3-15123	Nut—Flap control	10
41-4633	Terminal—Flap control rod	10
41-1437	Screw—Flap control	10
41-4638	Sleeve Assembly—Flap control	10
41-4484	Flange—Flap control	10
1-19034	Spacer—Flap controls	10
41-4220-1	Coupling—Shaft (used in -0 and -1 only)	2
41-4220-1	Coupling—Shaft (used in -2 to -9 inclusive only)	16
41-1439	Shim—Laminated	20
BAC560-36	Clamp Assembly—1/2 wide round rube	10
BAC560-36A	Clamp Assembly—1/2 wide round tube	10
BAC1550-17	Sleeve—5/16—.058	10
	(Parts List No. 94)	
3-15122	Screw—Flap control	10
BAC1851-16	Universal Joint—(Used in -0 and -1 only)	20
41-1395-21	Bolt—1/4-28 clevis	10
41-5918	Boot Installation—Universal grease	11L
41-5918	Boot Installation—Universal grease	9R
41-5918-1	Boot—Universal grease	20
41-5918-2	Card—Universal grease boot	40
41-5035-21-15	Tube Assembly—Flap torque	1L
41-5035-24-8	Tube Assembly—Flap torque	1L
41-5035-50-31	Tube Assembly—Flap torque	1R
41-5035-51-1	Tube Assembly—Flap torque	1L
41-5035-53-13	Tube Assembly—Flap torque	1L
41-5035-53-17	Tube Assembly—Flap torque	1R
41-5035-55-25	Tube Assembly—Flap torque	1R
41-5035-61-16	Tube Assembly—Flap torque	1L
41-5035-61-19	Tube Assembly—Flap torque	1
41-4220	Coupling—Shaft	9
41-4220	Coupling—Shaft	5L
41-4220	Coupling—Shaft	4R

WING INSTALLATION

Wing Assembly—Outer

	(Parts List No. 95)	
75-4772	Wing Assembly—Outer LH	1
75-4772-1	Wing Assembly—Outer RH	1
75-3590-620	Tip Assembly—Wing LH (PL 104-105)	1
75-3590-621	Tip Assembly—Wing RH (PL 104-105)	1
BAC115-34S	Bolt—Bearing	8
AN310-5	Nut	8
AN380-2-2	Cotter	8
64-1424	Spar Assembly—Front outer LH (PL 106-107)	1
64-1424-1	Spar Assembly—Front outer RH (PL 106-107)	1

Wing Assembly—Outer

64-1425	Spar Assembly—Wing outer rear LH (PL 108-110)	1
64-1425-1	Spar Assembly—Wing outer rear RH (PL 108-110)	1
65-4774	Panel Installation—Station 19½-33 lower LH (PL 111-112)	1
65-4774-1	Panel Installation—Station 19½-33 lower RH (PL 111-112)	1
58-784	Aileron Assembly LH Fabric Covered LH	1
58-784-1	Aileron Assembly RH Fabric Covered RH	1
	See Control Surface Installation 15-7324 for Aileron (PL 113).	

AVIALOGS.COM

WING INSTALLATION

Wing Assembly—Outer

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7030	Cable Installation—Aileron control	1
	See Flight Controls Installation 1-18364 (PL 449)...	
65-4786	Panel Installation—Station 19½-33 upper LH....	1
65-4786-1	Panel Installation—Station 19½-33 upper RH...	1
65-4786-500	Panel Assembly—Station 19½-33 upper.....	1
65-4786-501	Panel Assembly—Station 19½-33 upper.....	1
65-4786-33	Skin Assembly—Panel.....	1
65-4786-34	Skin Assembly—Panel.....	1
15-7475	Nose Installation—Station 19A-33 LH.....	1
15-7475-1	Nose Installation—Station 19A-33 RH.....	1
15-7475-2	Nose Assembly—Station 19A-33 LH.....	1
15-7475-11	Nose Assembly—Station 19A-33 RH.....	1
9-3445	Rib—Nose—station 19A.....	2
9-3446	Rib—Nose—station 20.....	2
9-3447	Rib—Nose—station 21.....	2

Wing Assembly—Outer

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
9-3448	Rib—Nose—station 22.....	2
9-3449	Rib—Nose—station 23.....	2
9-3450	Rib—Nose—station 24.....	2
9-3451	Rib—Nose—station 25.....	2
9-3452	Rib—Nose—station 26.....	2
9-3453	Rib—Nose—station 27.....	2
9-3454	Rib—Nose—station 28.....	2
9-3455	Rib—Nose—station 29.....	2
9-3456	Rib—Nose—station 30.....	2
9-3457	Rib—Nose—station 31.....	2
9-3458	Rib—Nose—station 32.....	2
9-3459	Rib—Nose—station 33.....	2
41-7052-2	Frame—De-icer connection.....	2
41-7052-3	Frame—De-icer connection.....	2
41-7101	Cover—De-icer connection.....	2

WING ASSEMBLY—OUTER

Nose Installation—Station 19A-33

(Parts List No. 96)

41-7101-1	Cover—De-icer connection.....	2
1-18112	Terminal—Nose rib.....	60
1-18400-96	Clip—Stiffener angle.....	16
41-7295	Screw—Rivnut plug.....	24
21-5743	Pin—Nose rib.....	60
21-6429	Shim—Pin retaining.....	60
BAC1901	Washer—Flat head screw.....	652
BAC1330-101	Rivnut—6-32 rivnut 115° countersunk head....	570
BAC1330-102	Rivnut—6-32 rivnut 115° countersunk head....	34
55-6341	Control Installation—Aileron LH.....	1
55-6341-1	Control Installation—Aileron RH.....	1
55-6341-400	Control Assembly—Aileron LH.....	1
55-6341-401	Control Assembly—Aileron RH.....	1
8-1262-2	Quadrant Assembly—Aileron control LH....	1
8-1262-3	Quadrant Assembly—Aileron control RH....	1
8-1262-4	Quadrant—Aileron control LH.....	1
8-1262-5	Quadrant—Aileron control RH.....	1
51-791	Spacer—Bearing.....	2
BAC1602-20	Spacer—No. 8 machine screw.....	2
6-8365	Support—Aileron control.....	1
6-8365-1	Support—Aileron control.....	1
BAC1784-95-4L	Cable Assembly—3/16-7 x 19 control.....	2
BAC1784-95-4A	Cable—3/16-7 x 19 control.....	2

Nose Installation—Station 19A-33

BAC1826-6	Swaged Terminal—Class B.....	2
BAC1827-26L	Swaged Terminal—Class D.....	2
BAC1801-89-2L	Cable Assembly—3/16-7 x 19 control.....	2
BAC1801-89-2A	Cable—3/16-7 x 19 control.....	2
BAC1825-6	Swaged Terminal—Class C.....	2
BAC1827-26L	Swaged Terminal—Class D.....	2
21-2363-32-13	Washer—.063 steel.....	2
NAS53-S34.5A	Bolt—Close tolerance.....	2
BAC1603-133	Spacer—No. 10 bolt.....	2
BAC1603-136	Spacer—No. 10 bolt.....	2
BAC1603-137	Spacer—No. 10 bolt.....	2
65-3584	Control Installation—Aileron tab.....	1
65-3584-501	Tube Assembly—Aileron tab control.....	1
BAC1849-10	Universal—Joint.....	1
94-1128-407	Chord and Diagonal Installation—Station 20 LH.	1
94-1128-408	Chord and Diagonal Installation—Station 20 RH.	1
94-1128-802	Chord and Diagonal Assembly Station 20 LH..	1
94-1128-803	Chord and Diagonal Assembly Station 20 RH..	1
21-9392	Gusset—Wing rib.....	8
21-9392-1	Gusset—Wing rib.....	12
1-18050-0	Spacer—Wing and tail rib.....	4
94-1129-400	Chord and Diagonal Installation—Station 21 LH.	1
94-1129-401	Chord and Diagonal Installation—Station 21 RH.	1
94-1129-802	Chord and Diagonal Assembly Station 21 LH..	1
94-1129-803	Chord and Diagonal Assembly Station 21 RH..	1

WING INSTALLATION

Wing Assembly—Outer

(Parts List No. 97)

21-9392	Gusset—Wing rib.....	8
21-9392-1	Gusset—Wing rib.....	12
1-18050-0	Spacer—Wing and tail rib.....	4
88-761-400	Chord and Diagonal Installation—Upper station 22 LH.....	1
88-761-401	Chord and Diagonal Installation—Upper station 22 RH.....	1
88-761-802	Chord and Diagonal Assembly—Station 22 LH.	1
88-761-803	Chord and Diagonal Assembly—Station 22 RH.	1
21-5738	Gusset Assembly—Wing rib.....	4
21-5738-1	Gusset Assembly—Wing rib.....	4
21-9392-1	Gusset—Wing rib.....	12
1-18050	Spacer—Wing and tail rib.....	4
88-762-400	Chord and Diagonal Installation—Upper station 23 LH.....	1
88-762-401	Chord and Diagonal Installation—Upper station 23 RH.....	1

Wing Assembly—Outer

88-762-802	Chord and Diagonal Assembly—Upper station 23 LH.....	1
88-762-803	Chord and Diagonal Assembly—Upper station 23 RH.....	1
21-5738	Gusset Assembly—Wing rib.....	4
21-5738-1	Gusset Assembly—Wing rib.....	4
21-9392-1	Gusset—Wing rib.....	12
1-18050-0	Spacer—Wing and tail rib.....	4
84-1130-407	Chord and Diagonal Installation—Station 24 compartment LH.....	1
84-1130-408	Chord and Diagonal Installation—Station 24 compartment RH.....	1
84-1130-700	Chord and Diagonal Assembly—Station 24 compartment LH.....	1
84-1130-701	Chord and Diagonal Assembly—Station 24 compartment RH.....	1
21-5511-2	Gusset—Wing rib.....	4
21-5511-3	Gusset—Wing rib.....	4
1-18279	Assembly—Wing rib.....	4
BAC1249-110S	Plate—Fiber nut.....	8

AVIALOGS.COM

WING INSTALLATION

Wing Assembly—Outer

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18050-9	Spacer—Wing and tail rib	4
68-763-407	Chord and Diagonal Installation—Upper station 25 LH	1
68-763-408	Chord and Diagonal Installation—Upper station 25 RH	1
68-763-409	Chord and Diagonal Assembly—Station 25 LH	1
68-763-410	Chord and Diagonal Assembly—Station 25 RH	1
21-5738	Gusset Assembly—Wing rib	2
21-5738-1	Gusset Assembly—Wing rib	2
21-5739-2	Gusset—Wing rib	4L
21-5739-3	Gusset—Wing rib	4R
1-18050-1	Spacer—Wing and tail rib	4
1-18050-17	Spacer—Wing and tail rib	2
68-764-408	Chord and Diagonal Installation—Upper station 26 LH	1
68-764-409	Chord and Diagonal Installation—Upper station 26 RH	1
68-764-410	Chord and Diagonal Assembly—Upper station 26 LH	1
68-764-411	Chord and Diagonal Assembly—Upper station 26 RH	1
21-5738	Gusset Assembly—Wing rib	2
21-5738-1	Gusset Assembly—Wing rib	2
21-5739-2	Gusset—Wing rib	4
21-5739-3	Gusset—Wing rib	4
1-18050-1	Spacer—Wing and tail rib	4

(Parts List No. 98)

68-765-405	Chord and Diagonal Installation—Upper station 27 LH	1
68-765-406	Chord and Diagonal Installation—Upper station 27 RH	1
68-765-407	Chord and Diagonal Assembly—Upper station 27 LH	1
68-765-408	Chord and Diagonal Assembly—Upper station 27 RH	1
21-5738-1	Gusset Assembly—Wing rib	2
21-5738	Gusset Assembly—Wing rib	2
21-5739-2	Gusset—Wing rib	4
21-5739-3	Gusset—Wing rib	4
1-18050-1	Spacer—Wing and tail rib	4
68-766-405	Chord and Diagonal Installation—Upper station 28 LH	1
68-766-406	Chord and Diagonal Installation—Upper station 28 RH	1
68-766-407	Chord and Diagonal Assembly—Upper station 28 LH	1
68-766-408	Chord and Diagonal Assembly—Upper station 28 RH	1
21-5738	Gusset Assembly—Wing rib	2
21-5738-1	Gusset Assembly—Wing rib	2
21-5739-2	Gusset—Wing rib	4
21-5739-3	Gusset—Wing rib	4
1-18050-1	Spacer—Wing and tail rib	4
68-767-405	Chord and Diagonal Installation—Upper station 29 LH	1
68-767-406	Chord and Diagonal Installation—Upper station 29 RH	1
68-767-401	Chord and Diagonal Assembly—Upper station 20 LH	1
68-767-402	Chord and Diagonal Assembly—Upper station 20 RH	1
21-5536	Gusset Assembly—Inboard wing rib	2
21-5536-1	Gusset Assembly—Inboard wing rib	2
21-5531-2	Gusset—Wing rib LH	4
21-5531-3	Gusset—Wing rib RH	4
BAC1615-56	Spacer—5/32 rivet	6
1-18050-9	Spacer—Wing and tail rib	4
68-768-405	Chord and Diagonal Installation—Upper station 30 LH	1
68-768-406	Chord and Diagonal Installation—Upper station 30 RH	1

Wing Assembly—Outer

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
68-768-407	Chord and Diagonal Assembly—Upper station 30 LH	1
68-768-408	Chord and Diagonal Assembly—Upper station 30 RH	1
21-5738	Gusset Assembly—Wing rib	2
21-5738-1	Gusset Assembly—Wing rib	2
21-5739-2	Gusset—Wing rib	4
21-5739-3	Gusset—Wing rib	4
1-18050-1	Spacer—Wing and tail rib	4
68-769-404	Chord and Diagonal Installation—Upper station 31 LH	1
68-769-405	Chord and Diagonal Installation—Upper station 31 RH	1
68-769-406	Chord and Diagonal Assembly—Upper station 31 LH	1
68-769-407	Chord and Diagonal Assembly—Upper station 31 RH	1
21-5738	Gusset Assembly—Wing rib	2
21-5738-1	Gusset Assembly—Wing rib	2
21-5739-2	Gusset—Wing rib	4
21-5739-3	Gusset—Wing rib	4
1-18050-1	Spacer—Wing and tail rib	4
68-770-404	Chord and Diagonal Installation—Upper station 32 LH	1
68-770-405	Chord and Diagonal Installation—Upper station 32 RH	1

(Parts List No. 99)

68-770-406	Chord and Diagonal Assembly—Upper station 32 LH	1
68-770-407	Chord and Diagonal Assembly—Upper station 32 RH	1
21-5739-2	Gusset—Wing rib	4
21-5739-3	Gusset—Wing rib	4
21-9392	Gusset—Wing rib	4
1-18050-1	Spacer—Wing and tail rib	4
68-771-404	Chord and Diagonal Installation—Upper station 33 LH	1
68-771-405	Chord and Diagonal Installation—Upper station 33 RH	1
68-771-406	Chord and Diagonal Assembly—Upper station 33 LH	1
68-771-407	Chord and Diagonal Assembly—Upper station 33 RH	1
21-5531	Gusset—Wing rib	4
21-5531-1	Gusset—Wing rib	4
21-5537	Gusset—Wing rib	4
BAC1615-56	Spacer—5/32 rivet	6
1-18050-9	Spacer—Wing and tail rib	4
8-596	Rib Installation—Station 19A tail LH	1
8-596-1	Rib Installation—Station 19A tail RH	1
8-596-2	Rib Assembly—Tail station 19A LH	1
8-596-3	Rib Assembly—Tail station 19A RH	1
21-5741-4	Gusset—Tail rib	4
21-5887-2	Gusset—Tail rib	16
1-18050-0	Spacer—Wing and tail rib	2
94-1128-419	Rib Installation—Station 20 tail LH	1
94-1128-420	Rib Installation—Station 20 tail RH	1
94-1128-421	Rib Assembly—Station 20 tail RH	1
94-1128-422	Rib Assembly—Station 20 tail LH	1
21-5534	Gusset—Wing rib	8
21-5534-1	Gusset—Wing rib	8
21-5833	Bracket—Aileron hinge	1
21-5833-1	Bracket—Aileron hinge	1

AVIALOGS.COM

WING INSTALLATION

Wing Assembly—Outer

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-5834	Bracket—Aileron hinge	1
21-5834-1	Bracket—Aileron hinge	1
21-6003	Gusset—Wing rib	4
41-871-35-15	Spacer—7/16 micarta	2
21-6849	Fair-lead—Aileron tab control LH	1
41-9894	Bracket—Fair-lead—support LH	1
41-1606-37-10	Spacer—3/8 micarta	2
9-3135	Bracket Installation—Aileron control station 20 LH	1
9-3135-1	Angle—Aileron control bracket—station 20	1
BAC1603-37	Spacer—No. 10 bolt	1
9-3135-2	Zee—Aileron control bracket—station 20	1
41-5633-40-20	Fair-lead—3/16 cable	2
41-5533-0-44	Spacer—No. 10 bolt	1
BAC1604-45	Spacer—1/4 bolt	1
8-1204	Rib Installation—Station 20½ LH	1
8-1204-1	Rib Installation—Station 20½ RH	1
8-1204-2	Rib Assembly—Station 20½ LH	1
8-1204-3	Rib Assembly—Station 20½ RH	1
	(Parts List No. 100)	
51-282	Gusset—Wing rib	4
51-282-1	Gusset—Wing rib	4
1-18050-8	Spacer—Wing and tail rib	4
94-1129-20	Rib Installation—Tail station 21 LH	1
94-1129-21	Rib Installation—Tail station 21 RH	1
94-1129-22	Rib Assembly—Tail station 21	1
94-1129-23	Rib Assembly—Tail station 21	1
21-5887-2	Gusset—Tail ribs	16
21-5741-4	Gusset—Tail ribs	4
21-6726-21-7	Spacer—9/32 micarta	2
88-761-20	Rib Installation—Tail station 22 LH	1
88-761-21	Rib Installation—Tail station 22 RH	1
88-761-22	Rib Assembly—Tail station 22 LH	1
88-761-23	Rib Assembly—Tail station 22 RH	1
21-5741-2	Gusset—Tail rib	4
21-5887	Gusset—Tail rib	4
21-5887-5	Gusset—Tail rib	12
21-6726-21-7	Spacer—9/32 micarta	2
88-762-20	Rib Installation—Station 23 tail LH	1
88-762-21	Rib Installation—Station 23 tail RH	1
88-762-22	Rib Assembly—Tail station 23 LH	1
88-762-23	Rib Assembly—Tail station 23 RH	1
21-5741-2	Gusset—Tail rib	4
21-5887	Gusset—Tail rib	4
21-5887-5	Gusset—Tail rib	12
21-6726-21-7	Spacer—9/32 micarta	2
84-1130-19	Rib Installation—Tail station 24 LH	1
84-1130-20	Rib Installation—Tail station 24 RH	1
84-1130-21	Rib Assembly—Tail station 24 LH	1
84-1130-22	Rib Assembly—Tail station 24 RH	1
21-5741-2	Gusset—Tail rib	4
21-5887	Gusset—Tail rib	4
21-5887-2	Gusset—Tail rib	12
21-6726-21-7	Spacer—9/32 micarta	2
9-3136	Bracket Installation—Aileron control station 24 LH	1
9-3136-1	Bracket Installation—Aileron control station 24 RH	1
9-3136-2	Bracket Assembly—Aileron control station 24 LH	1
9-3136-3	Bracket Assembly—Aileron control station 24 RH	1

Wing Assembly—Outer

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1614-40	Spacer—1/8 rivet	2
BAC1603-21	Spacer—No. 10 bolt	8
41-445-0-12	Spacer—No. 10 bolt	8
41-5533-0-20	Spacer—No. 10 bolt	2
41-5633-40-20	Fair-lead—3/16 cable	2
BAC1603-56	Spacer—No. 10 bolt	1
BAC1604-21	Spacer—No. 10 bolt	1
68-763-419	Rib Installation—Tail station 25 LH	1
68-763-420	Rib Installation—Tail station 25 RH	1
	(Parts List No. 101)	
68-763-421	Rib Assembly—Tail station 25 RH	1
68-763-422	Rib Assembly—Tail station 25 LH	1
21-5534	Gusset—Wing rib	4
21-5534-1	Gusset—Wing rib	12
41-871-35-15	Spacer—7/16 micarta	2
61-5837	Bracket—Aileron hinge	1
61-5837-1	Bracket—Aileron hinge	1
21-5841-1	Gusset—Wing rib	4
41-1606-37-10	Spacer—3/8 micarta	2
68-764-20	Rib Installation—Tail station 26 LH	1
68-764-21	Rib Installation—Tail station 26 RH	1
68-764-22	Rib Assembly—Tail station 26 LH	1
68-764-23	Rib Assembly—Tail station 26 RH	1
21-5741-2	Gusset—Tail rib	4
21-5887	Gusset—Tail rib	4
21-5887-5	Gusset—Tail rib	12
21-6726-21-7	Spacer—9/32 micarta	2
68-765-17	Rib Installation—Tail station 27 LH	1
68-765-18	Rib Installation—Tail station 27 RH	1
68-765-19	Rib Assembly—Tail station 27 LH	1
68-765-20	Rib Assembly—Tail station 27 RH	1
21-5741-1	Gusset—Tail rib	4
68-766-17	Rib Installation—Tail station 28 LH	1
68-766-18	Rib Installation—Tail station 28 RH	1
68-766-19	Rib Assembly—Tail station 28 LH	1
68-776-20	Rib Assembly—Tail station 28 RH	1
21-5741-1	Gusset—Tail rib	4
68-767-16	Rib Installation—Tail station 29 LH	1
68-767-17	Rib Installation—Tail station 29 RH	1
68-767-18	Rib Assembly—Tail station 29 LH	1
68-767-19	Rib Assembly—Tail station 29 RH	1
21-5534	Gusset—Wing rib	4
21-5534-1	Gusset—Wing rib	12
21-5835	Bracket—Aileron hinge	1L
21-5835-1	Bracket—Aileron hinge	1R
21-5836	Bracket—Aileron hinge	1L
21-5836-1	Bracket—Aileron hinge	1R
51-930-1	Gusset—Wing rib	4
41-871-35-15	Spacer—7/16 micarta	2
41-1606-37-10	Spacer—3/8 micarta	2
68-768-17	Rib Installation—Tail station 30 LH	1
68-768-18	Rib Installation—Tail station 30 RH	1
68-768-19	Rib Assembly—Tail station 30 LH	1
68-768-20	Rib Assembly—Tail station 30 RH	1
21-5741-1	Gusset—Tail rib	4
68-769-16	Rib Installation—Tail station 31 LH	1
68-769-17	Rib Installation—Tail station 31 RH	1
	(Parts List No. 102)	
68-769-18	Rib Assembly—Tail station 31 LH	1
68-769-19	Rib Assembly—Tail station 31 RH	1
21-5741-1	Gusset—Tail rib	4

AVIALOGS.COM

WING INSTALLATION

Wing Assembly—Outer

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
68-770-16	Rib Installation—Tail station 32 LH	1
68-770-17	Rib Installation—Tail station 32 RH	1
68-770-18	Rib Assembly—Tail station 32 LH	1
68-770-19	Rib Assembly—Tail station 32 RH	1
21-5741-1	Gusset—Tail rib	4
68-771-16	Rib Installation—Tail station 33 LH	1
68-771-17	Rib Installation—Tail station 33 RH	1
68-771-18	Rib Assembly—Tail station 33 LH	1
68-771-19	Rib Assembly—Tail station 33 RH	1
21-5534-1	Gusset—Tail rib	8
21-5739-1	Gusset—Tail rib	4
21-5835	Bracket—Aileron hinge	1L
21-5835-1	Bracket—Aileron hinge	1R
21-5836	Bracket—Aileron hinge	1L
21-5836-1	Bracket—Aileron hinge	1R
21-5938	Gusset—Wing rib	4
51-930	Gusset—Wing rib	4
41-871-37-15	Spacer—1/16 micarta	2
41-1606-37-10	Spacer—3/8 micarta	2
14-2053	Door Installation—Inspection station 24-25 LH	1
14-2053-1	Door Installation—Inspection station 24-25 RH	1
6-9219	Door Assembly—Inspection	2
41-8209-40	Button—Dzus type AFA	6
41-8210	Grommet—Dzus type 375F	6
1-18355	Plate—Reinforcing	6
41-8211	Spring—Dzus fastener	6
9-3599	Door Installation—Inspection station 19A-20 LH	1
9-3599-1	Door Installation—Inspection station 19A-20 RH	1
6-8946	Door Assembly—Inspection	2
6-8946-1	Door—Inspection	2
41-8209-40	Button—Dzus type AFA	2
41-8210	Grommet—Dzus type 375F	2
1-18355	Plate—Reinforcing	2
41-8211	Spring—Dzus fastener	2
6-6242-7	Door Installation—Outer wing hoisting LH	1
6-6242-8	Door Installation—Outer wing hoisting RH	1
6-6242-2	Door—Wing hoisting	2
6-6242-3	Frame Assembly—Outer wing hoisting LH	1
6-6242-4	Frame Assembly—Outer wing hoisting RH	1
21-3147-1	Washer—.019 steel (corrosive resistant)	12
75-4772-609	Bracket Assembly—Outer wing	1

Wing Assembly—Outer

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
75-4772-610	Bracket Assembly—Outer wing	1
48-1061	Wire Installation—Outer wing LH	1
48-1061-1	Wire Installation—Outer wing RH	1
	(Parts List No. 103)	
48-1061-400	Wire—Outer wing	2
BAC821-118-10	Terminal—Electrical solderless	4
BAC538-2	Clamp—Loop type cushioned	28
BAC822-18	Sleeve Insulation—Electrical terminal	4
BAC1602-16	Spacer—No. 8 machine screw	28
75-4772-604	Cover Assembly—Gap nose	1L
75-4772-605	Cover Assembly—Gap nose	1R
75-4772-601	Cover—Gap nose	1L
75-4772-602	Cover—Gap nose	1R
BAC1330-101	Rivnut—6-32—115° countersunk head	2
BAC1901	Washer—Flat head screw	32
AN510-10-8	Screw—Flat head	32
75-4772-13	Cover—Gap lower	2
75-4772-14	Cover—Gap upper	2
21-3147-1	Washer—.019 steel (corrosive resistant)	220
525-10-7	Screw—Washer head	220
75-4772-4	Cover—Gap lower	1
75-4772-5	Cover—Gap lower	1
75-4772-17	Cover—Gap upper	1
75-4772-18	Cover—Gap upper	1
21-3147-1	Washer—.019 steel (corrosive resistant)	48
525-10-7	Screw	48
21-1537-4	Bracket Assembly—Door support	8
21-6526-3	Plate—Station 20 aileron hinge	1R
21-6527	Plate—Station 20 aileron hinge	1L
21-3147-1	Washer—.019 steel (corrosive resistant)	26
41-1801	Splice—Stiffener	4
366F1032	Plate nut	70
526-1032-7	Screw	26
21-7022	Splice—Stiffener	10
41-7609-6-18	Bushing—AN taper pin replacement (for spare parts only)	16
41-7609-5-24	Bushing—AN taper pin replacement (for spare parts only)	4

WING ASSEMBLY—OUTER

Wing Tip Assembly

(Parts List No. 104)

75-3590-620	Tip Assembly—Wing LH	1
75-3590-621	Tip Assembly—Wing RH	1
48-790	Spar Assembly—Wing tip front LH	1
48-790-1	Spar Assembly—Wing tip front RH	1
48-790-418	Spar Assembly—Wing tip front	1L
48-790-419	Spar Assembly—Wing tip front	1R
21-6716	Terminal Assembly—Wing tip spar	2L
21-6716-1	Terminal Assembly—Wing tip spar	2R
61-6590	Bracket Assembly—Conduit box	2L
61-6590-1	Bracket Assembly—Conduit box	2R
48-789	Spar Assembly—Wing tip rear	2L
48-789-419	Spar Assembly—Wing tip rear	2
21-6715	Terminal Assembly—Wing tip spar LH	2
21-6715-1	Terminal Assembly—Wing tip spar RH	2
48-791	Rib Installation—Wing tip station 34 LH	1
48-791-1	Rib Installation—Wing tip station 34 RH	1
48-791-406	Rib Assembly—Tail station 34	1L
48-791-407	Rib Assembly—Tail station 34	1R
21-6584-3	Gusset—Tail rib station 34	4
48-791-402	Rib Assembly—Center station 34	1L
48-791-403	Rib Assembly—Center station 34	1R
21-6584-2	Gusset—Tail station 34 rib	8

Wing Tip Assembly

48-791-400	Rib Assembly—Nose wing tip station 34	2
21-6584-3	Gusset—Tail rib station 34	4
48-792	Rib Installation—Wing tip station 35 LH	1
48-792-1	Rib Installation—Wing tip station 35 RH	1
48-792-400	Rib Assembly—Wing tip station 35	2
21-6747-2	Gusset—Rib	2
21-6747-3	Gusset—Rib	2
48-792-402	Rib Assembly—Center station 35	1L
48-792-403	Rib Assembly—Center station 35	1R
21-6747	Gusset—Rib	4
21-6747-1	Gusset—Rib	4
48-792-406	Rib Assembly—Tail—wing tip station 35	1L
48-792-407	Rib Assembly—Tail—wing tip station 35	1R
21-6747-2	Gusset—Rib	2
21-6747-3	Gusset—Rib	2
48-793	Rib Installation—Wing tip station 36 LH	1
48-793-1	Rib Installation—Wing tip station 36 RH	1
48-793-400	Rib Assembly—Nose—wing tip station 36	2
21-6747-2	Gusset—Rib	2
21-6747-3	Gusset—Rib	2
48-793-402	Rib Assembly—Center—wing tip station 36	1L
48-793-403	Rib Assembly—Center—wing tip station 36	1R
21-6747	Gusset—Rib	4
21-6747-1	Gusset—Rib	4

AVIALOGS.COM

WING ASSEMBLY—OUTER

Wing Tip Assembly

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
48-793-406	Rib Assembly—Tail—wing tip station 36	1L
48-793-407	Rib Assembly—Tail station 36	1R
21-6747-2	Gusset—Rib	2
	(Parts List No. 105)	
21-6747-3	Gusset—Rib	2
48-794	Rib Installation—Wing tip station 37 LH	1
48-794-1	Rib Installation—Wing tip station 37 RH	1
48-794-409	Rib Assembly—Wing tip station 37	2
48-794-401	Rib Assembly—Wing tip station 37	1L
48-794-402	Rib Assembly—Wing tip station 37	1R
21-6747	Gusset—Rib	2
21-6747-1	Gusset—Rib	2
48-794-406	Rib Assembly—Wing tip station 37	1R
48-794-405	Rib Assembly—Wing tip station 37	1L
49-1777-409	Light Installation—Wing running LH	1
49-1777-410	Light Installation—Wing running RH	1
49-1777-413	Plate Assembly—Lower wing running light	1L
49-1777-414	Plate Assembly—Lower wing running light	1R
51-604	Packing—Type A-8 lamp	2
49-1777-411	Plate Assembly—Upper wing running light	1L
49-1777-412	Plate Assembly—Upper wing running light	1R
51-604	Packing—Type A-8 lamp	2
49-1777-417	Lamp 6CP 12-16V type G-6 single contact (government furnished)	4
37B-4962-1	Lamp Assembly—Upper left red (government furnished)	1
37B-4962-2	Lamp Assembly—Upper right green (government furnished)	1
37B-4962-3	Lamp Assembly—Lower left red (government furnished)	1
37B-4962-4	Lamp Assembly—Lower right green (government furnished)	1
75-3590-15	Door Assembly—Wing tip LH	1
75-3590-16	Door Assembly—Wing tip RH	1
75-3590-20	Door—Wing tip	1L
75-3590-424	Door—Wing tip	1R
41-1831-3	Washer—.016 aluminum	16
525-10-7	Screw	16
3-13452	Panel Installation—Wing tip	1
3-13452-1	Panel Installation—Wing tip	1
41-5123	Panel Assembly—Connector	2
41-5123-1	Panel—Connector	2
BAC1330-102	Rivnut—6-32—115° countersunk head	96
75-3590-622	Wire—Wing tip	2
BAC539-2	Clamp—Lug type cushioned	6
BAC821-18-10	Terminal—Electrical solderless	2
BAC821-18-6	Terminal—Electrical solderless	2
75-3590-623	Wire—Wing tip	2
BAC821-20-6	Terminal—Electrical solderless	4

Spar Assembly—Front Outer

(Parts List No. 106)

64-1424	Spar Assembly—Front outboard wing LH	1
64-1424-1	Spar Assembly—Front outboard wing RH	1
21-6107	Plate Assembly—Front side wing tip hinge LH	2
21-6107-1	Plate Assembly—Front side wing tip hinge RH	2
21-6107-4	Plate—Wing tip hinge (front side)	2L
21-6107-5	Plate—Wing tip hinge (front side)	2R
BAC345-4-257	Bushing—Staked	4
21-6108	Plate Assembly—Wing tip hinge rear side LH	2
21-6108-1	Plate Assembly—Wing tip hinge rear side RH	2
21-6108-4	Plate—Wing tip hinge rear side	2L
21-6108-5	Plate—Wing tip hinge rear side	2R
BAC345-4-257	Bushing—Staked	4
3-6658	Gusset—Front spar station 29 upper	2
3-6658-1	Gusset—Front spar station 29 upper	2
3-6659	Gusset—Front spar station 30	2

Spar Assembly—Front Outer

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-6659-1	Gusset—Front spar station 30	2
3-6660	Gusset—Front spar station 31	2
3-6660-1	Gusset—Front spar station 31	2
3-6661	Gusset—Front spar station 32	2
3-6661-1	Gusset—Front spar station 32	2
3-8744-1	Gusset—Front spar	8
3-8744-2	Gusset—Front spar	8
3-8746-1	Gusset—Front spar	4
3-8746-2	Gusset—Front spar	4
3-6755	Gusset—Wing spar	2
3-6521-1	Gusset—Wing spar	8
3-6521-2	Gusset—Wing spar	8
3-6555-2	Gusset—Wing spar	4
3-6523-1	Gusset—Wing spar	8
21-5748	Gusset—Wing spar	4
7-1361	Gusset Assembly—Wing spar front station 20 and 21	1
7-1361-1	Gusset Assembly—Wing spar front station 20 and 21	1
7-1361-3	Gusset Assembly—Wing spar front station 20 and 21	1
7-1361-4	Gusset Assembly—Wing spar front station 20 and 21	1
1-27180	Plate—Reinforcing front spar strut	4
3-11997	Gusset—Wing spar station 21	8
3-12005	Gusset—Wing spar front station 20	4
64-1424-527	Chord Assembly—Upper front outboard wing spar	1L
64-1424-528	Chord Assembly—Upper front outboard wing spar	1R
1-21007	Tube Assembly—Spar chord splice upper	2
64-1424-529	Chord Assembly—Lower front outboard wing spar LH	1
64-1424-530	Chord Assembly—Lower front outboard wing spar RH	1
1-21008	Tube Assembly—Spar chord splice	2
46-4022	Channel Installation—Mooring	2
21-926-1	Shim—Staking channel	2
21-5566	Clip—Wing rib	52
21-5566-1	Clip—Wing rib	8
3-11746	Clip—Wing rib LH	1
	(Parts List No. 107)	
3-11746-1	Clip—Wing rib RH	1
3-11745	Clip—Wing rib	1
3-11745-1	Clip—Wing rib	1
41-9665	Clip—Wing rib	7
41-9665-1	Clip—Wing rib	7
41-9666	Clip—Wing rib	7
41-9666-1	Clip—Wing rib	7
43-6493-400	Clip—⅞ TT section LH	2
43-6493-401	Clip—⅞ TT section RH	2
43-6494-400	Clip—⅞ TT section LH	2
43-6494-401	Clip—⅞ TT section RH	2
51-281-1	Clip—Wing rib LH	1
51-281-2	Clip—Wing rib RH	1
41-9663	Clip—Wing rib LH	4
41-9663-1	Clip—Wing rib RH	4
41-9664	Clip—Wing rib LH	5
41-9664-1	Clip—Wing rib RH	5
3-11721	Terminal—Front and rear station 19 (outer)	4
41-9461	Ring—Hoisting outer wing	2
BAC114S11A	Bolt—Bearing	16
BAC114S12A	Bolt—Bearing	32
BAC114S44A	Bolt—Bearing	8
BAC114DD44A	Bolt—Bearing	12
BAC114S45A	Bolt—Bearing	8
BAC116-DD45A	Bolt—Bearing	10
BAC116-DD46A	Bolt—Bearing	10
BAC1604-140	Spacer—¼ bolt	12
BAC1605-123	Spacer—5/16 bolt	2

AVIALOGS.COM

WING ASSEMBLY—OUTER

Spar Assembly—Rear Outer

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 108)	
64-1425	Spar Assembly—Wing outer rear LH	1
64-1425-1	Spar Assembly—Wing outer rear RH	1
41-9461	Ring Hoisting—Outer wing	2
7-1531	Drum Installation—Aileron tab control	1L
7-1531-5	Drum Assembly—Aileron tab control	1
1-18494	Drum—Tab control	1
1-18580	Shaft Assembly—Drum support	1
BAC1805-61-7	Cable Assembly—3/32-7 x 7 control	2
BAC1805-61-7A	Cable—3/32-7 x 7 control	2
BAC1826-3	Swaged Terminal—Class "B"	2
BAC1828-34	Terminal—Dead end cable	2
51-247	Retainer Assembly—Ball bearing	1
51-247-1	Retainer—Ball bearing	2
21-6094	Plate Assembly—Wing tip hinge rear LH	4
21-6094-1	Plate Assembly—Wing tip hinge rear RH	4
BAC345-4-257	Bushing—Staked	8
BAC114S12A	Bolt—Bearing	32
6-8249	Gusset Assembly—Wing spar rear station 20 LH	1
6-8249-1	Gusset Assembly—Wing spar rear station 20 LH	1
6-8249-2	Gusset Assembly—Wing spar rear station 20 RH	1
6-8249-3	Gusset Assembly—Wing spar rear station 20 RH	1
3-8748-4	Plate—Reinforcing	4
3-12012	Gusset—Wing spar station 20	4
3-6523-1	Gusset—Wing spar station 26U only	4
3-6520-1	Gusset—Wing spar station 21L and 21U only	8
3-6520-2	Gusset—Wing spar station 24L and 25U rear	8
3-11747	Gusset—Rear spar station 25L and 26U	8
3-11747-1	Gusset—Rear spar station 26L	4
3-11749	Gusset—Rear spar station	8
3-11749-1	Gusset—Rear spar station	8
21-5748	Gusset—Wing spar station 29L	4
3-6589	Gusset—Wing spar station 27	2
3-6589-1	Gusset—Wing spar station 27	2
3-6588	Gusset—Wing spar station 28	2
3-6588-1	Gusset—Wing spar station 28	2
3-6587	Gusset—Wing spar station 29U	2
3-6587-1	Gusset—Wing spar station 29U	2
3-6586	Gusset—Wing spar station 30	2
3-6586-1	Gusset—Wing spar station 30	2
3-6585	Gusset—Wing spar station 31	2
3-6585-1	Gusset—Wing spar station 31	2
3-6513	Gusset—Wing spar station 32	2
3-6513-1	Gusset—Wing spar station 32	2
3-6705	Gusset—Wing spar station 33	2
41-9667	Clip—Wing rib station 19A	2
41-9667-1	Clip—Wing rib station 19A	2
41-9663-2	Clip—Wing rib lower front station 20	8
41-9664-2	Clip—Wing rib upper front station 20	10
41-9669	Clip—Wing rib lower rear station 20	2
41-9670	Clip—Wing rib upper rear station 20	2
51-281	Clip—Wing rib station 20-21	2
	(Parts List No. 109)	
41-9668	Clip—Wing rib lower rear station 21	10
41-9668-1	Clip—Wing rib upper rear station 21	10
43-6493-402	Clip—Front lower station 24 and 29 7/8 TT section	2
43-6494-402	Clip—Front lower station 24 and 29 7/8 TT section	2
41-9665-3	Clip—Wing rib lower station 25	2
41-9666-3	Clip—Wing rib lower station 25	2
41-9669-1	Clip—Wing rib lower station 25 and 29	4
41-9670-1	Clip—Wing rib upper station 25 and 29	4
41-9665-2	Clip—Wing rib lower front station 26	12
41-9666-2	Clip—Wing rib upper front station 26	12
3-11745-2	Clip—Wing rib lower front station 33	2
3-11746-2	Clip—Wing rib upper front station 33	2
41-9669-2	Clip—Wing rib lower rear station 33	2
41-9670-2	Clip—Wing rib upper rear station 33	2
43-6493-403	Clip—7/8 TT section	2
43-6494-403	Clip—7/8 TT section	2
21-5913	Clip—Rear T section	20

Spar Assembly—Rear Outer

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
54-1425-423	Filler—Wing outboard rear spar	8
21-7758-2-12	Spacer—No. 10 bolt special	4
21-7758-2-13	Spacer—No. 10 bolt special	4
21-7758-2-10	Spacer—No. 10 bolt special	8
41-3002-24-104	Filler—.091 channel	4
BAC1604-108	Spacer—1/4 bolt	4
BAC1604-140	Spacer—1/4 bolt	18
NAS56A27.5DD	Bolt—Close tolerance	12
NAS54A27.5	Bolt—Close tolerance	4
NAS54A26.5	Bolt—Close tolerance	2
NAS54A27	Bolt—Close tolerance	6
NAS54A27.5DD	Bolt—Close tolerance	8L
NAS54A27.5DD	Bolt—Close tolerance	7R
NAS54A27DD	Bolt—Close tolerance	2L
NAS54A27DD	Bolt—Close tolerance	3R
NAS53A30	Bolt—Close tolerance	4
NAS54A26.5DD	Bolt—Close tolerance	4
NAS56A30DD	Bolt—Close tolerance	12
NAS53A27.5	Bolt—Close tolerance	4
NAS53A27	Bolt—Close tolerance	8
9-3137	Bracket Installation—Aileron control station 20-21	1
9-3137-1	Bracket Installation—Aileron control station 20-21	1
9-3137-2	Bracket Assembly—Aileron control station 20-21	1L
9-3137-3	Bracket Assembly—Aileron control station 20-21	1R
51-1097	Bracket Assembly—Fair-lead	1L
BAC1614-32	Spacer—1/8 rivet	2
41-5633-40-20	Fair-lead—3/16 cable	2L
64-1425-425	Chord Assembly—Wing outer rear spar upper LH	1
64-1425-426	Chord Assembly—Wing outer rear spar upper RH	1
1-21007	Tube Assembly—Spar chord splice upper	1
64-1425-427	Chord Assembly—Wing outer rear spar lower LH	1
64-1425-428	Chord Assembly—Wing outer rear spar lower RH	1
1-21008	Tube Assembly—Spar chord splice	2
3-11721-1	Terminal—Front and rear station 19A	4
	(Parts List No. 110)	
51-1087	Bracket—Pulley support	1L
51-951	Bracket Assembly—Fair-lead support	1R

Panel Installation—Station 19½-33 Lower LH & RH

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 111)	
65-4774	Panel Installation—Station 19½-33 lower LH	1
65-4774-1	Panel Installation—Station 19½-33 lower RH	1
65-4774-500	Panel Assembly—Station 19½-33 lower LH	1
65-4774-501	Panel Assembly—Station 19½-33 lower RH	1
94-1128-13	Chord Installation—Lower station 20 LH	1
94-1128-14	Chord Installation—Lower station 20 RH	1
94-1128-800	Chord Assembly—Lower station 20 LH	1
94-1128-801	Chord Assembly—Lower station 20 RH	1
1-18050-8	Spacer—Wing and tail rib	4
1-18050-8	Spacer—Wing and tail rib	4
94-1129-408	Chord Installation—Lower station 21 LH	1
94-1129-409	Chord Installation—Lower station 21 RH	1
94-1129-800	Chord Assembly—Lower station 21 LH	1
94-1129-801	Chord Assembly—Lower station 21 RH	1
1-18050-8	Spacer—Wing and tail rib	4
1-18050-8	Spacer—Wing and tail rib	4
88-761-408	Chord Installation—Lower station 22 LH	1
88-761-409	Chord Installation—Lower station 22 RH	1
1-18050-8	Spacer—Wing and tail rib	4
88-762-408	Chord Installation—Lower station 23 LH	1
88-762-409	Chord Installation—Lower station 23 RH	1
1-18050-8	Spacer—Wing and tail rib	4
84-1130-13	Chord Installation—Lower station 24 compartment LH	1
84-1130-14	Chord Installation—Lower station 24 compartment RH	1
21-5933	Spacer—Micarta	4
68-763-413	Chord Installation—Lower station 25 LH	1
68-763-414	Chord Installation—Lower station 25 RH	1

AVIALOGS.COM

WING ASSEMBLY—OUTER

Panel Installation—Station 19½-33 Lower LH & RH

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
68-763-415	Chord Assembly—Lower station 25 LH	1
68-763-416	Chord Assembly—Lower station 25 RH	1
1-18050-5	Spacer—Wing and tail rib	2
1-18050-17	Spacer—Wing and tail rib	2
68-764-14	Chord Installation—Lower station 26 LH	1
68-764-15	Chord Installation—Lower station 26 RH	1
1-18050-5	Spacer—Wing and tail rib	4
68-765-11	Chord Installation—Lower station 27 LH	1
68-765-12	Chord Installation—Lower station 27 RH	1
1-18050-5	Spacer—Wing and tail rib	4
68-766-11	Chord Installation—Lower station 28 LH	1
68-766-12	Chord Installation—Lower station 28 RH	1
1-18050-5	Spacer—Wing and tail rib	4
68-767-10	Chord Installation—Lower station 29 LH	1
68-767-11	Chord Installation—Lower station 29 RH	1
21-5933	Spacer—Micarta	4
	(Parts List No. 112)	
68-768-11	Chord Installation—Lower station 30 LH	1
68-768-12	Chord Installation—Lower station 30 RH	1

Panel Installation—Station 19½-33 Lower LH & RH

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18050-5	Spacer—Wing and tail rib	4
68-769-10	Chord Installation—Lower station 31 LH	1
68-769-11	Chord Installation—Lower station 31 RH	1
1-18050-5	Spacer—Wing and tail rib	4
68-770-10	Chord Installation—Lower station 32 LH	1
68-770-11	Chord Installation—Lower station 32 RH	1
68-770-12	Chord Assembly—Lower station 32 LH	1
68-770-13	Chord Assembly—Lower station 32 RH	1
41-871-21-11	Spacer—7/16 micarta	2
1-18050-5	Spacer—Wing and tail rib	4
68-771-10	Chord Installation—Lower station 33 LH	1
68-771-11	Chord Installation—Lower station 33 RH	1
68-771-12	Chord Assembly—Lower station 33 RH	1
68-771-13	Chord Assembly—Lower station 33 LH	1
1-18050-11	Spacer—Wing and tail rib	2
1-18050-10	Spacer—Wing and tail rib	4
21-2521-8	Screw—No. 10-32 special	52
NAS54-DD13.5A	Bolt—¼-28 close tolerance	4
NAS54-DD10.5A	Bolt—¼-28 close tolerance	16
NAS54-DD7.5A	Bolt—¼-28 close tolerance	4

FINAL ASSEMBLY

Control Surface Installation

(Parts List No. 113)

15-7324	Control Surface Installation	1
15-7024	Rudder Assembly	1
15-7026	Elevator Assembly LH	1
15-7026-1	Elevator Assembly RH	1
15-7023	Fin Assembly	1
15-7025	Stabilizer Assembly LH	1
15-7025-1	Stabilizer Assembly RH	1
75-5127	Flap Assembly—Wing LH	1
75-5127-1	Flap Assembly—Wing RH	1
58-784	Aileron Assembly—Fabric covered LH	1
58-784-1	Aileron Assembly—Fabric covered RH	1
15-7478	Tube Installation—Rudder torque lower	1
15-7478-1	Tube Assembly—Rudder torque lower	1
9-3590	Quadrant Assembly—Rudder lock and stop	1
9-3590-1	Quadrant—Rudder lock and stop	1
1-18651	Socket—Elevator rudder lock	1
NAS53-S11.5A	Bolt—Close tolerance	2
6-9208	Collar—Torque tube connector	1
6-9221	Fitting—Rudder mast support	1
6-9222	Fitting—Rudder hinge	1
15-7478-2	Tube—Rudder torque	1
NAS-55A-13	Bolt—Close tolerance	2
7-1515	Mast—Rudder control	1
BAC801-70	Jumper Assembly—Double terminal bonding	1
BAC801-70A	Braid—Double terminal bonding jumper	1
BAC820-6	Terminal—Electrical lock	2
AN3-6A	Bolt	8
365-1032	Nut	8
AN960-10	Washer	8
6-9458	Boot Installation—Rudder torque tube	1
6-9458-1	Boot Assembly—Rudder torque tube	1
6-9458-2	Strip—Reinforcing rudder torque tube	1
6-9458-4	Boot—Rudder torque tube	1
1-18934	Clamp—Torque tube boot	1
21-4841-50	Jumper Assembly—No. 8-8 terminal bonding	1
21-4841-50A	Braid—Copper No. 8-8 terminal bonding	1
BAC820-8	Terminal—Electrical lock	2
365-832	Nut	2
AN515-8-8	Screw	1
AN515-8-10	Screw	1
41-2424-32-17	Washer—.016 steel	2
AN4-11	Bolt	2
AN4-16	Bolt	1

Control Surface Installation

(Parts List No. 114)

AN310-4	Nut	3
AN380-2-2	Cotter	3
AN960-416	Washer	3
15-7617	Tube Installation—Elevator torque	1
15-7617-1	Tube Assembly—Elevator torque	1
15-7617-2	Tube—Elevator torque	1
6-9208	Collar—Torque tube connection	2
6-9321	Hinge Assembly—Elevator	2
6-9321-1	Hinge—Elevator	2
9-3613	Quadrant Assembly—Elevator lock and stop	1
9-3613-1	Quadrant—Elevator lock and stop	1
1-18651	Socket—Elevator rudder lock	1
NAS53-S11.5A	Bolt—Close tolerance	2
9-3664	Mast—Elevator control	4
1-18811-7-328	Filler—Extended	2
BAC1605-58	Spacer—No. 6 machine screw	2
21-4841-70	Jumper Assembly—No. 8-8 terminal bonding	1
21-4841-70A	Braid—Copper No. 8-8 terminal bonding jumper	1
BAC820-8	Terminal—Electrical lock	2
AN3-6A	Bolt	16
365-1032	Nut	16
AN960-10	Washer	16
21-4841-50	Jumper Assembly—No. 8-8 terminal bonding	2
21-4841-50A	Braid—Copper No. 8-8 terminal bonding jumper	2
BAC820-8	Terminal—Electrical lock	4
365-832	Nut	4
AN515-8-8	Screw	4
41-2424-32-17	Washer—.016 steel	4
AN4-13	Bolt	4
AN4-16	Bolt	2
AN310-4	Nut	6
AN380-2-2	Cotter	6
AN960-416	Washer	6
15-7630	Fairing Installation—Fin and fuselage station 8-10	1
15-7630-5	Fairing Assembly—Fin and fuselage station 8-10	1
BAC1330-1	Rivnut—6/32 115° countersunk head	4
15-7631	Fairing Installation—Fin station 10-11	1
15-7631-1	Fairing Assembly—Fin station 10-11	1
15-7631-2	Fairing Assembly—Fin station 10-11	1
3-13718	Fairing Assembly—Fin station 10-11	1
3-13720	Fairing Assembly—Fin station 10-11	1
364-524	Nut	4

AVIALOGS.COM

FINAL ASSEMBLY

Control Surface Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
364-624	Nut	4
386-4-92	Pin—Taper	4
386-5-17A	Pin—Taper	4
	(Parts List No. 115)	
975-5	Washer	4
975-6	Washer	4
15-7632	Cover Installation—Stabilizer gap LH	1
15-7632-1	Cover Installation—Stabilizer gap RH	1
15-7632-6	Cover Assembly—Stabilizer gap LH	1
15-7632-7	Cover Assembly—Stabilizer gap RH	1
BAC1252-10S	Plate—Fiber nut	4
6-9455	Boot Installation—Elevator torque tube LH	1
6-9455-1	Boot Installation—Elevator torque tube RH	1
6-9455-4	Boot Assembly—Elevator torque tube LH	1
6-9455-5	Boot Assembly—Elevator torque tube RH	1
6-9455-6	Boot—Elevator torque tube	2
1-18934	Clamp—Torque tube boot	2
364-624	Nut	16
386-5-23A	Pin—Taper	16
975-6	Washer	16
21-3894-48-17	Washer—Retaining	30
AN960-416	Washer	10
AN960-516	Washer	10
AN5-15	Bolt	10
AN4-24	Bolt	10
AN310-4	Nut	10
AN310-5	Nut	10
AN380-2-2	Cotter	20
21-4838-60	Jumper Assembly—No. 6-8 terminal bonding	4
21-4838-60A	Braid—Copper No. 8-8 terminal bonding	1
BAC820-6	Terminal—Electrical lock	4
BAC820-8	Terminal—Electrical lock	4

Control Surface Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
37B3822-6B	Rivnut	4
365-832	Nut	4
AN515-6-8	Screw	4
AN515-8-8	Screw	4
3-12098-3	Rod Assembly—Aileron control	2
3-12098-4	Tube—Aileron control rod	1
51-764	Terminal Assembly—Aileron control rod	2
51-764-1	Terminal—Aileron control rod	2
41-9543-1	Terminal Assembly—Aileron control rod	2
41-9543-2	Terminal—Aileron control rod	2
61-9034	Rod End—Aileron control rod	2
AN25-23	Bolt	2
AN25-25	Bolt	2
AN320-5	Nut	4
AN380-2-2	Cotter	4
6-8992-6	Weight Assembly—Aileron counterbalance	1R
6-8992-7	Weight Assembly—Aileron counterbalance	1L
6-8992-2	Tube Assembly—Aileron counterbalance	2
3-12966-4	Weight—Aileron counterbalance	1L
3-12966-3	Weight—Aileron counterbalance	1R
	(Parts List No. 116)	
NAS54A21S	Bolt—Close tolerance	4
365-428	Nut	4
AN960-416	Washer	4
AN4-12	Bolt	6
AN4-16	Bolt	2
AN310-4	Nut	8
AN380-2-2	Cotter	8
AN960-416	Washer	18

CONTROL SURFACE INSTALLATION

Rudder Assembly

	(Parts List No. 117)	
15-7024	Rudder Assembly (15-7021 CL diagonal) fin and rudder	1
8-1277	Spar Installation—Rudder rear	1
8-1277-1	Spar Assembly—Rudder rear	1
1-18656	Channel—Rear spar rudder	1
1-18657	Angle—Rudder	2
1-18657-1	Angle—Rudder	1
1-18657-2	Angle—Rudder	1
BAC1252-10S	Plate—Fiber nut	24
15-7479	Spar Assembly—Rudder	1
15-7479-29	Hinge Assembly—Rudder spar	1
1-18607	Channel—Rudder hinge	1
BAC113A11S	Bolt—No. 10-32 bearing	2
1-18607-1	Channel—Rudder hinge	1
NAS53-S6A	Bolt—Bearing	4
1-18813	Clip—Stiffener attachment	2
1-18813-1	Clip—Stiffener attachment	2
3-13654	Gusset—Rudder hinge	4
15-7370	Rib Installation—Rudder nose—upper	1
15-7371	Rib Installation—Rudder nose—lower	1
15-7371-1	Rib Assembly—Rudder nose—lower	1
15-7371-5	Rib Assembly—Rudder nose—lower	1
15-7477	Rib Installation—Rudder hinge—nose	1
15-7477-1	Rib Assembly—Rudder hinge—nose	1
15-7477-5	Rib Assembly—Rudder hinge—nose	1
15-7477-7	Rib Assembly—Rudder hinge—nose	1
15-7477-9	Rib Assembly—Rudder hinge—nose	1
15-7477-3	Cover—Rudder hinge—nose	4
15-7481	Rib Installation—Rudder tail—lower	1
1-18724	Spacer—Empennage T.E.	1
15-7482	Rib Installation—Rudder tail—upper	1

Rudder Assembly

1-18724	Spacer—Empennage T.E.	5
6-9405	Rib Assembly—Rudder brace	1
6-9406	Rib—Rudder top	1
6-9479	Rib—Pan rudder LH	1
6-9479-1	Rib—Pan rudder RH	1
14-2043	Tab Assembly—Rudder trim	1
3-13562	Rib—Rudder tab	1
3-13604	Rib—Rudder tab	1
3-13707	Rib—Rudder tab	2
3-13708	Rib—Rudder tab	2
3-13708-1	Rib—Rudder tab	2
3-13697	Spar—Rudder tab	1
3-13746	Gusset—Rudder trim tab	1
1-18464	Mast Assembly—Rudder	1
1-18464-1	Mast—Rudder trim tab	1
1-18848	Angle—Rudder tab mast	1
	(Parts List No. 118)	
1-18864	Angle—Rudder tab mast	1
1-18657-3	Angle—Rudder tab mast	1
1-18657-4	Angle—Rudder tab mast	1
21-9078-2	Spacer—3/32 beveled rivet	8
21-9078-6	Spacer—3/32 beveled rivet	6
14-2043-2	Hinge—Continuous	1
15-7523	Control Installation—Rudder trim tab	1
3-13730	Nut Assembly—Rudder trim tab	1
3-13730-1	Felt—Rudder trim tab	1
3-13730-2	Rod—Rudder trim tab	1
1-18446	Terminal—Trim tab rod	1
1-18537	Nut—Trim tab	1
1-18589	Filler—Trim tab nut	1
41-1395-16	Bolt—Clevis	1

AVIALOGS.COM

CONTROL SURFACE INSTALLATION

Rudder Assembly

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18494	Drum—Tab control	1
3-13729	Screw Assembly—Rudder trim tab	1
1-18517	Screw—Trim tab	1
1-18527	Shaft—Rudder tab control	1
21-9751-16	Boot Installation—Grease	1
21-9751-16A	Boot—Grease	1
21-9751-2	Chord—Grease boot	2
BAC1851-16	Joint—Universal	1
6-9408-2	Housing Assembly—Tab control	1
6-9408-3	Housing—Tab control	1
1-18367	Guard—Rudder tab control cable	2
BAC1807-295-1R	Cable Assembly—3/32-7 x 7 control	2
BAC1827-23R	Swaged Terminal—Class "D"	2
BAC1828-34	Terminal—Dead end cable	2
15-7024-11	Door—Rudder	1
6-9320	Door Installation—Rudder hinge	1
6-9320-1	Door Installation—Rudder hinge	1
1-18908	Door—Rudder hinge	4
6-9403	Door Installation—Rudder—lower	1
1-18908	Door—Rudder hinge	1
8-1525	Fairing Installation—Control tab rod	1
41-1831-3	Washer—.016 aluminum	7
8-1525-3	Support Assembly—Rudder tab control rod	1
3-13436	Angle—Fairing support	1
15-7042	Tube Installation—Rudder torque	1
15-7042-1	Tube Assembly—Rudder torque	1
1-18191	Collar—Torque tube support	1
6-9208	Collar—Torque tube connection	1
1-18191	Collar—Torque tube support	1
1-18192	Collar—Torque tube support	1

(Parts List No. 119)

8-1524	Channel Assembly—Rudder	1
6-9452	Weight—Rudder balance	1
6-9452-1	Weight—Rudder balance	1
6-9452-4	Weight—Rudder balance	1
1-17267	Clip—Fabric attachment	160
1-18370	Plate—Name	1
1-18824	Block—Rudder hinge	1
1-18857	Angle—Rib support	1
1-18858	Angle—Rib support	1
1-18870	Filler—Trailing edge	1
1-18870-1	Filler—Trailing edge	1
6-9477	Channel—Rudder nose	1

Elevator Assembly

(Parts List No. 120)

15-7026	Elevator Assembly—LH	1
15-7026-1	Elevator Assembly—RH	1
1-17267	Clip—Fabric attachment	650
1-18370	Plate—Name	2
1-18721	Spacer—Micarta	2
1-18721-1	Spacer—Micarta	2
3-13570-4	Brace Assembly—Fabric shrink	2
3-13570-3	Pan—Fabric shrink brace	2
6-9449	Weight—Elevator balance LH	1
6-9449-1	Weight—Elevator balance RH	1
6-9449-3	Weight—Elevator balance	2
8-1278	Door Installation—Elevator accessory LH	1
8-1278-1	Door Installation—Elevator accessory RH	1
8-1278-2	Frame Assembly—Elevator accessory door	2
8-1278-3	Frame—Elevator accessory door	2
BAC1252-10S	Plate—Fiber nut	16
8-1278-4	Cover—Elevator accessory door	2
8-1520	Spar Installation—Elevator (rear) LH	1
8-1520-1	Spar Installation—Elevator (rear) RH	1
8-1520-2	Spar Assembly—Elevator rear LH	1
8-1520-3	Spar Assembly—Elevator rear RH	1
1-18595	Reinforcement—Elevator rear spar	2
8-1520-4	Spar—Elevator rear rib LH	1

Elevator Assembly

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
8-1520-5	Spar—Elevator rear rib RH	1
1-18596	Angle—Elevator rib tie	8
1-18596-1	Angle—Elevator rib tie	2
1-18596-2	Angle—Elevator rib tie	4
BAC1252-10S	Plate—Fiber nut	58
8-1521	Tube Installation—Elevator torque	2
8-1521-1	Tube Installation—Elevator torque	2
8-1521-2	Tube Assembly—Elevator torque	4
8-1521-3	Tube—Elevator torque	4
6-9208	Collar—Torque tube connector	4
8-1521-4	Tie—Shear torque tube connector	4
1-18191-4	Collar—Torque tube support	8
1-18192-1	Collar—Torque tube support	4
9-3666	Pan—Elevator stiffener LH	1
9-3666-1	Pan—Elevator stiffener RH	1
14-2073	Tab Assembly—Elevator trim LH	1
14-2073-1	Tab Assembly—Elevator trim RH	1
14-2073-2	Spar—Elevator trim LH	1
14-2073-3	Spar—Elevator trim RH	1
14-2073-9	Hinge—Elevator trim LH	1
14-2073-10	Hinge—Elevator trim RH	1
1-18096	Fitting—Elevator trim tab	2
3-13440	Gusset—Elevator trim tab	2
3-13513	Mast Assembly—Elevator tab control LH	1
3-13513-1	Mast Assembly—Elevator tab control RH	1

(Parts List No. 121)

3-13513-2	Mast—Elevator tab control LH	1
3-13513-3	Mast—Elevator tab control RH	1
3-13658	Rib—Elevator trim tab	4
3-13770	Rib—Elevator trim tab connector panel	6
3-13770-2	Rib—Elevator trim tab connector panel	10
21-9078-2	Spacer—3/32 beveled rivet	20
14-2340	Door Installation—Elevator accessory LH	1
6-9462	Cover—Accessory door	1
7-1538-1	Patch Assembly—Accessory door	1
14-2341	Door Installation—Elevator accessory RH	1
3-13773	Cover—Accessory door	1
7-1538-2	Patch Assembly—Accessory door	1
15-7043	Rib Installation—Elevator nose (outboard) LH	1
15-7043-1	Rib Installation—Elevator nose (outboard) RH	1
15-7045	Rib Installation—Elevator nose inboard LH	1
15-7045-1	Rib Installation—Elevator nose inboard RH	1
15-7045-2	Rib Assembly—Elevator nose inboard	2
15-7045-6	Rib Assembly—Elevator nose inboard	2
15-7046	Rib Installation—Elevator nose (center) LH	1
15-7046-1	Rib Installation—Elevator nose (center) RH	1
15-7580	Control Installation—Elevator trim tab LH	1
15-7580-1	Control Installation—Elevator trim tab RH	1
1-18289	Guard—Elevator tab control cable	2
1-18494	Drum—Tab control	2
1-18528	Guard—Elevator tab control cable	2
6-9408-2	Housing Assembly—Tab control	2
6-9408-3	Housing—Tab control	2
6-9442-1	Control Assembly—Elevator trim tab LH	1
6-9442-2	Control Assembly—Elevator trim tab RH	1
1-18494	Drum—Tab control	2
3-13516	Screw Assembly—Elevator trim tab	2
1-18517	Screw—Trim tab	2
1-18518	Shaft—Elevator trim tab	2
21-9751-16	Boot Installation—Universal grease	2
21-9751-16A	Boot—Universal grease	2
21-9751-2	Chord—Universal grease	4
BAC1851-16	Joint—Universal	1
3-13572	Nut Assembly—Elevator trim tab	2
3-13572-1	Rod—Elevator trim tab	2
3-13572-2	Felt—Elevator trim tab	2
1-18446	Terminal—Trim tab rod	2
1-18589	Filler—Trim tab nut	2
1-18537	Nut—Trim tab	2
BAC1807-197-6R	Cable Assembly—3/32—7 x 7 control	1L
BAC1807-197-6A	Cable—3/32—7 x 7 control	1

AVIALOGS.COM

CONTROL SURFACE INSTALLATION

Elevator Assembly

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1827-23R	Swaged Terminal—Class D	1
BAC1828-34	Swaged Terminal—Dead end cable	1
BAC1807-267-3R	Cable Assembly—3/32—7 x 7 control	1R
	(Parts List No. 122)	
BAC1807-267-3A	Cable—3/32—7 x 7 control	1
BAC1827-23R	Swaged Terminal—Class D	1
BAC1828-34	Swaged Terminal—Dead end cable	1
51-446-0-8	Tube—7/8—.058	2
51-446-0-60	Tube—7/8—.058	2
BAC1807-68-0L	Cable Assembly—3/32—7 x 7 control	1L
BAC1807-68-0A	Cable—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class D	1
BAC1828-34	Swaged Terminal—Dead end cable	1
BAC1807-131-1R	Cable Assembly—3/32—7 x 7 control	1R
BAC1807-131-1A	Cable—3/32—7 x 7 control	1
BAC1827-23A	Swaged Terminal—Class D	1
BAC1828-34	Swaged Terminal—Dead end cable	1
15-7581	Spar Assembly—Elevator front LH	1
15-7581-1	Spar Assembly—Elevator front RH	1
1-18813	Clip—Stiffener attachment	4
1-18813-1	Clip—Stiffener attachment	4
1-18816	Plate—Elevator spar splice	2
15-7594	Pan Assembly—Elevator stiffener LH	1
15-7594-1	Pan Assembly—Elevator stiffener RH	1
15-7594-2	Pan—Elevator stiffener	1
15-7594-3	Pan—Elevator stiffener	1
BAC1252-10S	Plate—Fiber nut	10
15-7613	Rib Installation—Elevator tail (inboard) LH	1
15-7613-1	Rib Installation—Elevator tail (inboard) RH	1
15-7614	Rib Installation—Elevator tail—center LH	1
15-7614-1	Rib Installation—Elevator tail—center RH	1
1-18724	Spacer—Empennage T.E.	12
15-7615	Rib Installation—Elevator tail outboard LH	1
15-7615-1	Rib Installation—Elevator tail outboard RH	1
1-18230	Fitting Assembly—Elevator hinge	2
1-18230-1	Plate—Elevator hinge fitting	2
1-18550	Fitting—Elevator hinge	2
1-18724	Spacer—Empennage T.E.	14
1-18921	Channel—Elevator rib tie	4
1-18922	Channel—Rib reinforcing	2
15-7026-7	Door—Hinge accessory	2
15-7636	Hinge Installation—Elevator station 94 LH	1
15-7636-1	Hinge Installation—Elevator station 94 RH	1
1-18754	Angle—Elevator hinge support	4
1-18754-1	Angle—Elevator hinge support	4
3-13692	Gusset—Elevator hinge support	4
6-9375	Support Assembly—Elevator hinge bearing	2
1-18568	Angle—Elevator hinge support	4
1-18568-1	Angle—Elevator hinge support	4
	(Parts List No. 123)	
1-18752	Spacer—Elevator hinge bearing	4
1-18753	Cover—Elevator hinge support	2
3-13691	Support—Elevator hinge bearing	4
6-9377	Base—Elevator hinge door	2
6-9401	Door—Elevator hinge accessory	2
BAC1252-10S	Plate—Fiber nut	12
15-7637	Hinge Installation—Elevator station 168 LH	1
15-7637-1	Hinge Installation—Elevator station 168 RH	1
1-18754-2	Angle—Elevator hinge support	4
1-18754-3	Angle—Elevator hinge support	4
3-13692	Gusset—Elevator hinge support	4
6-9376	Support Assembly—Elevator hinge bearing	2
1-18568	Angle—Elevator hinge support	4
1-18568-1	Angle—Elevator hinge support	4
1-18752	Spacer—Elevator hinge bearing	4
1-18753-1	Cover—Elevator hinge support	2
3-13690	Support—Elevator hinge bearing	4
6-9377	Base—Elevator hinge door	2
6-9401	Door—Elevator hinge accessory	2
21-2023-1	Grommet—Drainage	44

Fin Assembly

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 124)	
15-7023	Fin Assembly	1
15-7023-1	Frame Assembly—Rear fin	1
1-18838	Tee—Rib tie	1
1-18838-1	Tee—Rib tie	1
1-18839	Tee—Rib tie	1
1-18839-1	Tee—Rib tie	1
3-13724	Rib Assembly—Fin stations 2 and 4	1
6-9409	Rib Installation—Fin station 5 hinge	1
6-9410	Rib Installation—Station 8 hinge	1
8-1270	Spar Assembly—Fin rear	1
8-1270-4	Chord—Lower rear spar	1
8-1270-5	Chord—Lower rear spar	1
8-1270-6	Chord—Forward spar	1
8-1270-7	Chord—Forward spar	1
8-1270-8	Chord—Upper spar	1
8-1270-9	Chord—Upper spar	1
3-13608	Reinforcement—Fin spar	2
14-2052	Terminal Installation—Fin rear spar	1
8-1267	Terminal—Fin rear spar LH	1
8-1267-1	Terminal—Fin rear spar RH	1
NAS53-S55A	Bolt—Bearing	4
8-1523-7	Rib Installation—Fin station 10A aft	1
15-7339-5	Rib Installation—Fin station 3 aft	1
15-7340-5	Rib Installation—Fin station 4 aft	1
15-7342-5	Rib Installation—Fin station 6 aft	1
15-7343-5	Rib Installation—Fin station 7 aft	1
15-7345-7	Rib Installation—Aft	1
15-7388	Hinge Assembly—Rudder stations 5 and 8	1
15-7388-2	Hinge Assembly—Rudder stations 5 and 8	1
15-7388-1	Fitting—Rudder stations 5 and 8 (used in -0 only)	1
15-7388-3	Fitting—Rudder stations 5 and 8 (used in -1 only)	1
15-7023-2	Nose Assembly—Fin	1
1-18447	Eye Bolt—Command antenna	1
1-18636	Grommet—Antenna support	1
1-18904	Angle—Stiffener tie LH	1
1-18904-1	Angle—Stiffener tie RH	1
8-1523-1	Rib Installation—Fin station 10A forward	1
8-1523-2	Rib Assembly—Fin station 10A forward	1
15-7338-1	Rib Installation—Fin station 2 forward	1
	(Parts List No. 125)	
15-7338-2	Rib Assembly—Fin station 2 forward	1
1-18350	Angle—Rib tie fin	1
1-18350-1	Angle—Rib tie fin	1
1-18350	Angle—Rib tie fin	1
1-18350-1	Angle—Rib tie fin	1
NAS54-S12A	Bolt—Close tolerance	2
15-7339-1	Rib Installation—Fin station 3 forward	1
15-7340-1	Rib Installation—Fin station 4 forward	1
15-7341-1	Rib Installation—Fin station 5 forward	1
15-7342-1	Rib Installation—Fin station 6 forward	1
15-7343-1	Rib Installation—Fin station 7 forward	1
15-7344-1	Rib Installation—Fin station 8 forward	1
15-7345-1	Rib Installation—Fin station 9A	1
15-7345-2	Rib Assembly—Fin station 9A forward	1
8-1269	Spar Assembly—Fin front	1
1-18723	Angle Assembly—Antenna rod support	1
1-18684	Spacer—Micarta	1
3-13652	Tip Assembly—Fin front spar	1
3-13652-1	Tip—Fin front spar	1
14-2051	Terminal Installation—Fin front spar	1
8-1266	Terminal—Fin front spar	1L
8-1266-1	Terminal—Fin front spar	1R
BAC54-57A	Bolt—Close tolerance	4
15-7517	Block Assembly—Fin stations 8 and 5	1
15-7517-2	Tip—Fin station 8-5 block	1
41-8737-90L-135	Angle—Stiffener tie	1L
41-8737-90R-135	Angle—Stiffener tie	1R

AVIALOGS.COM

CONTROL SURFACE INSTALLATION

Fin Assembly

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-8737-90L-145	Angle—Stiffener tie	1L
41-8737-90R-145	Angle—Stiffener tie	1R
BAC1246-10S	Plate—Fiber nut	2
BAC1330-102	Rivnut—5/32-115° countersunk head	62
BAC1252-10S	Plate—Fiber nut	28
15-7023-31	Tip Assembly—Fin	1
8-1522	Rib Installation—Fin station 11A	1
8-1522-1	Rib Assembly—Fin station 11A	1
3-13705	Hinge Assembly—Fin station 11A	1
3-13705-1	Housing—Fin station 11A hinge	1
1-18892	Angle—Rib tie	1
14-2057-1	Bulkhead—Fin	1
14-2057-2	Bulkhead—Fin	1

(Parts List No. 126)

14-2057-3	Bulkhead—Fin	1
41-6063-78-32-2	Angle—3/16 x 3/4 aluminum alloy	2
BAC1330-102	Rivnut—5/32	22
3-13736	Rib Assembly—Fin trailing edge	1
41-6063-83-32-2	Angle—3/16 x 3/4 aluminum alloy	2
BAC1246-10S	Plate—Fiber nut	2
1-18370	Plate—Name	1
6-9203	Support Installation—Fin lamp	1
6-9203-1	Plate—Fin lamp support	2
21-8377-24	Washer—No. 10 square	2
41-1058-XL6	Rivnut—No. 6—32	33
41-1058-XM6	Rivnut—No. 6—32	133
41-1058-XT6	Rivnut—No. 6—32	30
8-1523-5	Rib Installation—Fin station 10A center	1
15-7338-7	Rib Installation—Fin station 2 center	1
15-7338-8	Rib Assembly—Fin station 2 center	1
15-7339-3	Rib Installation—Fin station 2 center	1
15-7340-3	Rib Installation—Fin station 4 center	1
15-7341-3	Rib Installation—Fin station 5 center	1
15-7341-4	Rib Assembly—Fin station 5 center	1
15-7342-3	Rib Installation—Fin station 6 center	1
15-7343-3	Rib Installation—Fin station 7 center	1
15-7344-3	Rib Installation—Fin station 8 center	1
15-7344-4	Rib Assembly—Fin station 8 center	1
15-7345-5	Rib Installation—Center	1
BAC538-2	Clamp—Loop type cushioned	6
BAC1246-10S	Plate—Fiber nut	4
BAC1330-102	Rivnut—5/32 115° countersunk head	6
BAC1446	Screw—Headless plug	196
15-7023-54	Wire—Cambric covered	1

Stabilizer Assembly

(Parts List No. 127)

15-7025	Stabilizer Assembly LH	1
15-7025-1	Stabilizer Assembly RH	1
15-7025-2	Tip Assembly—Stabilizer LH	2
1-18871	Splice Bow—Stabilizer tip	2
6-9206	Lamp Support Installation—Formation LH	1
6-9206-1	Lamp Support Installation—Formation RH	1
6-9206-2	Plate—Formation lamp support	2
8-1298-1	Rib Installation—Station 229.3	2
8-1298-3	Rib Assembly—Tail station 229.3	2
1-18209	Fitting—Elevator hinge	2
41-5135-3	Angle—Stiffener tie RH	4
41-5135-2	Angle—Stiffener tie LH	4
41-5878-3	Angle—Stiffener tie	4
15-7367-6	Tip—Stabilizer rear spar	2
15-7619-1	Rib Installation—Stabilizer tip (aft)	2
15-7619-4	Rib Assembly—Stabilizer tip (aft)	2
15-7619-2	Rib Installation—Stabilizer tip—center	2
15-7619-5	Rib Assembly—Stabilizer tip—center	2
15-7619-3	Rib Installation—Stabilizer tip—forward	2
15-7619-6	Rib Assembly—Stabilizer tip—forward	2
BAC1252-10S	Plate—Fiber nut	16
BAC1330-102	Rivnut—5/32-115° countersunk head	42

Stabilizer Assembly

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7025-4	Tail Assembly—Stabilizer LH	2
1-18872	Tee—Elevator hinge attachment	2
1-18872-1	Tee—Elevator hinge attachment	2
1-18873	Tee—Elevator hinge attachment	2
1-18873-1	Tee—Elevator hinge attachment	2
6-9379	Rib Installation—Tail—station 96	2
6-9460	Rib Installation—Tail—stabilizer—station 171	2
8-1261-1	Rib Installation—Stabilizer—station 149	2
8-1263-1	Rib Installation—Tail	2
8-1284-1	Rib Installation—Tail station A46	2
8-1297-1	Rib Installation—Station 208—tail	2
15-7367	Spar Assembly—Stabilizer—rear	2
8-1264	Terminal—Stabilizer—rear spar	2
8-1264-1	Terminal—Stabilizer—rear spar	2
BAC113A17S	Bolt—Bearing	4
BAC114A18S	Bolt—Bearing	8

(Parts List No. 128)

15-7385	Hinge Assembly—Elevator station 168 and 92	2
15-7385-1	Hinge—Elevator station 168 and 92	2
15-7385-2	Hinge Assembly—Elevator station 168 and 92	2
15-7385-3	Hinge—Elevator station 168 and 92	2
15-7525-1	Rib Installation—Stabilizer station 30 tail	2
15-7537-1	Rib Installation—Stabilizer station 78 tail	2
15-7539-1	Rib Installation—Stabilizer station 62 tail	2
15-7571-1	Rib Installation—Stabilizer station 112 tail	2
15-7578-1	Rib Installation—Stabilizer station 130 tail	2
15-7025-6	Leading Edge Assembly—Stabilizer	2
1-17575	Channel—Stabilizer spar splice	2
1-17575-1	Channel—Stabilizer spar splice	2
6-9368	Rib Installation—Stabilizer station 139.5	2
6-9369	Rib Installation—Stabilizer station 158.5	2
6-9370	Rib Installation—Stabilizer station 178	2
6-9371	Rib Installation—Stabilizer station 198	2
6-9372	Rib Installation—Stabilizer station 218.65	2
6-9413	Cover Installation—Stabilizer de-icer	2
6-9413-1	Cover—Stabilizer de-icer	2
1-18571	Guard—De-icer	2
BAC1330-101	Rivnut—6-32-115° countersunk head	24
BAC1446	Screw—Headless plug	12
8-1261-3	Rib Installation—Stabilizer station 149 nose	2
8-1283-3	Rib Installation—Stabilizer station 168 nose	2
8-1284-3	Rib Installation—Stabilizer station A46 nose	2
8-1263-3	Rib Installation—Stabilizer station 188 nose	2
8-1286-3	Rib Installation—Stabilizer—nose center	2
8-1297-3	Rib Installation—Stabilizer station 208 nose	2
9-3651	Rib Installation—Stabilizer station 103	2
9-3652	Rib Installation—Stabilizer station 121	2
14-2074	Rib Installation—Stabilizer station 38	2
14-2075	Rib Installation—Stabilizer station 54	2
14-2076	Rib Installation—Stabilizer station 70	2
14-2077	Rib Installation—Stabilizer station 86	2
15-7376	Spar Assembly—Front stabilizer	2
8-1268-3	Terminal—Stabilizer front spar	2
8-1268-4	Terminal—Stabilizer front spar	2
BAC113A15S	Bolt—Bearing	4
BAC114A17S	Bolt—Bearing	8
BAC113A19S	Bolt—Bearing	4
15-7525-3	Rib Installation—Station 30 nose	2
1-18880	Angle—Rib attachment station 30	2
1-18880-1	Angle—Rib attachment station 30	2
NAS53A13.5	Bolt—Close tolerance	4

(Parts List No. 129)

15-7537-3	Rib Installation—Nose	2
15-7539-3	Rib Installation—Station 62 nose	2
15-7571-3	Rib Installation—Station 112 nose	2
15-7578-3	Rib Installation—Nose	2
BAC1330-102	Rivnut—3-32-115° countersunk head	380
1-18370	Plate—Name	2
1-18645	Splice—Channel stiffener	20

AVIALOGS.COM

CONTROL SURFACE INSTALLATION

Stabilizer Assembly

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18918	Angle—Stiffener tie	2
1-18918-1	Angle—Stiffener tie	2
6-9202	Lamp Support Installation—Formation stabilizer inboard LH	2
6-9202-2	Plate—Formation stabilizer inboard lamp support	2
8-1261-2	Rib Installation—Station 149	2
8-1263-2	Rib Installation—Station 188 center	2
8-1283-2	Rib Installation—Station 168 center	2
8-1284-2	Rib Installation—Station A46	2
8-1286-2	Rib Installation—Center	2
8-1297-2	Rib Installation—Station 208 center	2
8-1298-2	Rib Installation—Nose—station 229-3	2
8-1298-4	Rib Assembly—Nose—station 229.3	2
41-5135-2	Angle—Stiffener tie	2
15-7525-18	Rib Installation—Center LH	1
15-7525-19	Rib Installation—Center RH	1
15-7537-2	Rib Installation—Station 78—center	2
15-7539-2	Rib Installation—Station 62—center	2
15-7571-2	Rib Installation—Station 112—center	2
15-7578-2	Rib Installation—Station 130—center	2
21-8377-24	Washer—No. 10 square	6
41-1058XM6	Rivnut—No. 6-32	768
41-7295	Screw—Rivnut plug	768
BAC537-2	Clamp—Lug type cushioned	4
BAC538-2	Clamp—Loop type cushioned	48
BAC1252-10S	Plate—Fiber nut	4
15-7025-12	Wire—Cambric—outboard	4
15-7025-35	Wire—Cambric—inboard	4
15-7025-118	Cover—Lamp support	4
41-7609-5-29	Bushing	32
BAC1097-10-105S	Nut—Elastic clinch	8

Wing Flap Assembly

(Parts List No. 130)

75-5127	Flap Assembly—Wing LH	1
75-5127-1	Flap Assembly—Wing RH	1
7-1364	Rib—Wing flap LH	2
7-1364-1	Rib—Wing flap RH	2
8-1205	Rib—Wing flap LH	2
8-1205	Rib—Wing flap RH	1
8-1205-1	Rib—Wing flap LH	1
8-1205-1	Rib—Wing flap RH	2
8-1205-2	Rib—Wing flap LH	4
8-1205-3	Rib—Wing flap RH	4
8-1205-4	Rib—Wing flap LH	4
8-1205-5	Rib—Wing flap RH	4
8-1205-6	Rib—Wing flap LH	4
8-1205-7	Rib—Wing flap RH	4
8-1205-8	Rib—Wing flap LH	8
8-1205-9	Rib—Wing flap RH	8
8-1205-10	Rib—Wing flap LH	6
8-1205-11	Rib—Wing flap RH	6
8-1205-12	Rib—Wing flap LH	5
8-1205-14	Rib—Wing flap LH	1
8-1205-13	Rib—Wing flap RH	5
8-1205-15	Rib—Wing flap RH	1
21-5991-1	Flange—Rib support	24
21-5994	Flange—Rib support	116
21-5994-1	Flange—Rib support	26
21-5994-2	Flange—Rib support	2
41-5024	Angle—Wing flap stiffener LH	33
41-5024-1	Angle—Wing flap stiffener RH	33
41-5024-2	Angle—Wing flap stiffener LH	2
41-5024-3	Angle—Wing flap stiffener RH	2
41-5024-4	Angle—Wing flap stiffener LH	33
41-5024-5	Angle—Wing flap stiffener RH	33
41-5024-6	Angle—Wing flap stiffener RH	2
41-5024-7	Angle—Wing flap stiffener LH	2
41-6109	Hinge Assembly—Wing flap LH	2
41-6109-1	Hinge Assembly—Wing flap RH	2

Wing Flap Assembly

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-6109-2	Hinge Assembly—Wing flap LH	2
41-6109-3	Hinge Assembly—Wing flap RH	2
41-6109-4	Hinge Assembly—Wing flap LH	2
41-6109-5	Hinge Assembly—Wing flap RH	2
41-6109-6	Hinge Assembly—Wing flap LH	2
41-6109-7	Hinge Assembly—Wing flap RH	2
41-6109-8	Hinge Assembly—Wing flap LH	2
41-6109-9	Hinge Assembly—Wing flap RH	2
41-6109-10	Hinge—Wing flap (used in -0, -2, -4, -6 and -8 only)	10
41-6109-11	Hinge—Wing flap (used in -1, -3, -5, -7 and -9 only)	10
21-5947	Bushing—Flap hinge	20
43-6668-400	Rib—Flap nose	36L
43-6668-401	Rib—Flap nose	36R
43-6668-404	Rib—Flap nose	1L
43-6668-405	Rib—Flap nose	1R
51-776	Angle—Wing flap stiffener LH	33

(Parts List No. 131)

51-776-1	Angle—Wing flap stiffener RH	33
51-776-2	Angle—Wing flap stiffener RH	3
51-776-3	Angle—Wing flap stiffener LH	3
51-776-4	Angle—Wing flap stiffener LH	1
51-776-5	Angle—Wing flap stiffener RH	1
51-776-6	Angle—Wing flap stiffener LH	33
51-776-7	Angle—Wing flap stiffener RH	33
51-776-8	Angle—Wing flap stiffener RH	3
51-776-9	Angle—Wing flap stiffener LH	3
51-776-10	Angle—Wing flap stiffener LH	1
51-776-11	Angle—Wing flap stiffener RH	1
53-6667	Rib Assembly—Flap hinge LH	2
53-6667-1	Rib Assembly—Flap hinge RH	2
53-6667-2	Rib Assembly—Flap hinge LH	2
53-6667-3	Rib Assembly—Flap hinge RH	2
53-6667-4	Rib Assembly—Flap hinge LH	2
53-6667-5	Rib Assembly—Flap hinge RH	2
53-6667-6	Rib Assembly—Flap hinge LH	2
53-6667-7	Rib Assembly—Flap hinge RH	2
53-6667-8	Rib Assembly—Flap hinge LH	2
53-6667-9	Rib Assembly—Flap hinge	2
53-6667-500	Rib—Flap hinge (used in -0, -2, -4, -6, and -8 only)	10
53-6667-501	Rib—Flap hinge (used in -1, -3, -5, -7, and -9 only)	10
21-6264-9	Bushing—Flap hinge	20
1-20569	Tie—Flap rib	46
1-20569-1	Tie—Flap rib	46
1-20569-2	Tie—Flap rib	24
1-20569-3	Tie—Flap rib	24
81-3822-400	Tie Bottom—Flap rib	10
81-3822-401	Tie Top—Flap rib	10
81-4094	Tie—Flap rib	4
81-4094-1	Tie—Flap rib	4

Aileron Assembly—Fabric Covered

(Parts List No. 132)

58-784	Aileron Assembly—Fabric covered LH	1
58-784-1	Aileron Assembly—Fabric covered RH	1
1-16316	Clip—Aileron	21L
1-16316	Clip—Aileron	28R
3-6481	Hinge Assembly—Aileron	2
3-6481-2	Hinge Assembly—Aileron	2
3-6481-4	Hinge Assembly—Aileron	2
3-6481-1	Hinge—Aileron (used in -0 only)	2
3-6481-3	Hinge—Aileron (used in -2 only)	2
3-6481-5	Hinge—Aileron (used in -4 only)	2
3-11866	Mast Assembly—Aileron LH	1
3-11866-1	Mast Assembly—Aileron RH	1
3-11866-2	Hinge—Aileron mast LH	1
3-11866-3	Hinge—Aileron mast RH	1
3-12101	Rib Assembly—Aileron	2

AVIALOGS.COM

CONTROL SURFACE INSTALLATION

Aileron Assembly—Fabric Covered

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-12109	Rib Assembly—Aileron nose LH	1
3-12109-1	Rib Assembly—Aileron nose RH	1
3-12109-3	Rib—Aileron nose LH	1
3-12109-4	Rib—Aileron nose RH	1
3-12176	Rib—Aileron nose	2
3-12176-1	Rib—Aileron nose	2
3-12176-2	Rib—Aileron nose	2
3-12176-3	Rib—Aileron nose	2
3-12176-4	Rib—Aileron nose	2
3-12176-5	Rib—Aileron nose	2
3-12176-6	Rib—Aileron nose	2
3-12176-7	Rib—Aileron nose	2
3-12176-8	Rib—Aileron nose	2
3-12176-9	Rib—Ailron nose	2
3-12176-10	Rib—Aileron nose	2
3-12176-11	Rib—Aileron nose	2
3-12176-12	Rib—Aileron nose	2
3-12176-13	Rib—Aileron nose	2
3-12176-14	Rib—Aileron nose	2
3-12176-15	Rib—Aileron nose	2
3-12176-16	Rib—Aileron nose	2
3-12176-17	Rib—Aileron nose	2
3-12176-18	Rib—Aileron nose	2
3-12176-19	Rib—Aileron nose	2
3-12176-20	Rib—Aileron nose	2
3-12176-21	Rib—Aileron nose	2
3-12176-22	Rib—Aileron nose	2
3-12176-23	Rib—Aileron nose	2
3-12177	Rib—Aileron	2
3-12178	Rib Assembly—Aileron hinge	2
3-12179	Rib Assembly—Aileron	1R
3-12179-1	Rib Assembly—Aileron	1R
3-12179-2	Rib Assembly—Aileron	2
3-12179-3	Rib Assembly—Aileron	2
3-12179-4	Rib Assembly—Aileron	2
	(Parts List No. 133)	
3-12179-5	Rib Assembly—Aileron	2
3-12180	Rib—Aileron	1L
3-12180-1	Rib—Aileron	1L
3-12180-2	Rib—Aileron	1L
3-12182	Rib Assembly—Aileron	2
3-12183	Rib Assembly—Aileron	2
3-12184	Rib Assembly—Aileron	1L
3-12184-1	Rib Assembly—Aileron	1L
3-12185	Rib—Aileron	1L
3-12185-1	Rib Assembly—Aileron	1L
3-12186	Rib—Aileron nose	1R
3-12186-1	Rib—Aileron nose	2
3-12186-2	Rib—Aileron nose	1R
3-12186-3	Rib—Aileron nose	1L
3-12186-4	Rib—Aileron nose	2L
3-12186-5	Rib—Aileron nose	2R
3-12186-6	Rib—Aileron nose	2L
3-12186-7	Rib—Aileron nose	2R
7-1536	Control Assembly—Aileron trim tab	1L
7-1536-1	Tube—Aileron trim tab control	1
7-1536-2	Sleeve—Aileron trim tab control	1
7-1536-3	Filler—Aileron trim tab control	1
7-1536-4	Bearing—Aileron trim tab control	1
7-1536-5	Spacer—Aileron trim tab control	1
1-18129	Screw—Aileron trim tab	1
1-18703	Sleeve Assembly—Grease retainer	1
1-18703-1	Sleeve—Grease retainer	1
1-18703-2	Packing—Grease retainer	1
1-18898	Nut Assembly—Aileron trim tab	1
1-18898-1	Nut—Aileron trim tab	1
41-4639-4	Terminal—Control rod	1
1-18935	Plug—Aileron trim tab	1
6-9440	Flange—Screw support	1
21-2366-58-44	Washer—.091 aluminum alloy	2
21-7312-5	Washer—Bearing retainer	2

Aileron Assembly—Fabric Covered

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-7312-6	Washer—Bearing retainer	2
NAS53-S105A	Bolt—Close tolerance	1
BAC1849-10	Universal Joint	2
3-12187	Rib—Aileron nose LH	1
6-8263-1	Rib—Aileron nose RH	1
6-8263-2	Rib—Aileron LH	1
6-8263-3	Rib—Aileron RH	1
6-8263-4	Rib—Aileron LH	1
6-8263-5	Rib—Aileron RH	1
6-8379	Rib—Aileron	2
7-1367	Rib—Aileron end LH	1
7-1367-1	Rib—Aileron end RH	1
7-1368	Rib—Aileron LH	1
7-1368-1	Rib—Aileron RH	1
7-1368-2	Rib—Aileron LH	1
7-1368-3	Rib—Aileron RH	1
	(Parts List No. 134)	
7-1368-4	Rib—Aileron	2
7-1369	Rib—Aileron	1R
7-1369-1	Rib—Aileron	1R
7-1369-2	Rib—Aileron	1R
7-1369-3	Rib—Aileron	1R
7-1369-4	Rib—Aileron	1R
7-1369-5	Rib—Aileron	1L
7-1369-6	Rib—Aileron	1R
7-1369-7	Rib—Aileron	2
7-1369-8	Rib—Aileron	2
7-1369-9	Rib—Aileron	2
7-1369-11	Rib—Aileron	2
7-1369-12	Rib—Aileron	2
7-1369-13	Rib—Aileron	2
7-1369-14	Rib—Aileron	2
7-1369-15	Rib—Aileron	2
7-1369-16	Rib—Aileron	2
7-1369-17	Rib—Aileron	2
7-1369-18	Rib—Aileron	2
7-1369-19	Rib—Aileron	2
7-1369-20	Rib—Aileron	2
7-1369-21	Rib—Aileron	2
7-1369-22	Rib—Aileron	2
7-1369-23	Rib—Aileron	2
7-1369-24	Rib—Aileron	2
8-787-6	Tab Assembly—Aileron trim LH	1
8-787-1	Spar—Aileron trim tab	1
21-6031	Rib—Aileron tab	1
21-6031-1	Rib—Aileron tab	1
21-6031-2	Rib—Aileron tab	1
21-6031-3	Rib—Aileron tab	1
21-6031-4	Rib—Aileron tab	1
21-6609	Bracket Assembly—Aileron tab hinge	1
21-6609-6	Bracket Assembly—Aileron tab hinge	1
21-6847	Rib Assembly—Aileron tab	1
21-6847-1	Rib Assembly—Aileron tab	1
21-6847-2	Rib Assembly—Aileron tab	1
21-9078-1	Spacer—3/32 beveled rivet	8
51-468	Mast Assembly—Aileron tab	1
AN200K3-1	Mast—Aileron tab	1
8-1041	Spar Assembly—Aileron tab support	1L
8-1041-10	Fairing Assembly—Lower aileron tab support spar	1
8-1041-13	Fairing Assembly—Lower aileron tab support spar	1
8-1041-16	Fairing Assembly—Aileron tab support spar	1
8-1041-19	Fairing Assembly—Aileron tab support spar	1
8-1041-22	Fairing Assembly—Aileron tab support spar	1
8-1041-25	Fairing Assembly—Aileron tab support spar	1
8-1041-28	Fairing Assembly—Aileron tab support spar	1
8-1041-31	Fairing Assembly—Aileron tab support spar	1
3-6581-7	Bracket Assembly—Tab hinge	1
3-6581-13	Bracket Assembly—Tab hinge	1
1-19830	Plate—Tab hinge bracket	2

AVIALOGS.COM

CONTROL SURFACE INSTALLATION

Aileron Assembly—Fabric Covered

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 135)	
21-6872	Angle—Tab control support	2
21-6861-2	Filler—Aileron	2
21-2023-1	Grommet — Drainage	27L
21-2023-1	Grommet — Drainage	30R
21-6030	Clip—Aileron	2L
21-6030-1	Clip—Aileron	3R
21-6030-2	Clip—Aileron	4
21-6035-1	Clip—Aileron	2
21-6387	Clip—Aileron mast	2
21-6387-1	Clip—Aileron mast	2L
21-6387-1	Clip—Aileron mast	1R
21-6387-2	Clip—Aileron mast	4
21-6447-4	Spacer—Micarta	2
21-6447-5	Spacer—Micarta	4
21-6448	Clip—Aileron hinge LH	1
21-6448-1	Clip—Aileron hinge RH	1
21-6448-2	Clip—Aileron hinge LH	1
21-6448-3	Clip—Aileron hinge RH	1
21-6448-4	Clip—Aileron hinge LH	1
21-6448-5	Clip—Aileron hinge RH	1
21-6449	Clip—Aileron mast	2
21-6861	Filler—Aileron	12

Aileron Assembly—Fabric Covered

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-6861-1	Filler—Aileron	4
21-6861-4	Filler—Aileron	4
48-785	Spar Assembly—Aileron	1L
48-785-1	Spar Assembly—Aileron	1R
48-785-2	Spar Assembly—Inner	1L
48-785-3	Spar Assembly—Inner	1R
48-785-10	Insert—Inner—splice half—aileron spar LH	1
48-785-11	Insert—Inner—splice half—aileron spar RH	1
48-785-400	Insert—Inner—splice half—aileron spar	2
48-785-4	Spar Assembly—Outer—splice half—aileron spar	2
48-785-6	Insert—Outer—splice half—aileron spar	2
48-785-7	Insert—Outer—splice half—aileron spar	2
48-785-401	Insert—Splice half—aileron spar	2
48-785-402	Insert—Splice half—aileron spar	2
41-1394-14	Bolt—10-32 clevis	1L
41-1394-15	Bolt—10-32 clevis	1L
51-783	Angle—Aileron brace	2
51-783-1	Angle—Aileron brace	2
51-793	Angle—Aileron reinforcement	4
51-794	Channel—Aileron reinforcement	2
51-794-1	Channel—Aileron reinforcement	2
41-3627-1	Fair-lead—Aileron spar	1L
41-3627-2	Fair-lead—Aileron spar	1L
1-18370	Plate—Name	2

FINAL ASSEMBLY

Fuselage Assembly

	(Parts List No. 136)	
15-7377	Fuselage Assembly	1
15-7330	Fuselage Assembly—Forward section (PL 140-213)	1
15-7331	Fuselage Assembly—Rear section (PL 214-236)	1
15-7360	Enclosure Assembly—Rear gun (PL 237-242)	1
65-5589	Nose Installation—Fuselage	1
65-5589-500	Nose Installation—Fuselage	1
65-5589-3	Panel—Plexiglass fuselage nose	1
65-5589-7	Panel—Plexiglass fuselage nose	1
65-5589-8	Panel—Plexiglass fuselage nose	1
65-5589-9	Panel—Plexiglass fuselage nose	1
65-5589-11	Panel—Plexiglass fuselage nose	1
65-5589-12	Panel—Plexiglass fuselage nose	1
65-5589-16	Panel—Plexiglass fuselage nose	1
65-5589-17	Panel—Plexiglass fuselage nose	1
65-5589-18	Panel—Plexiglass fuselage nose	1
65-5589-19	Panel—Plexiglass fuselage nose	1
65-5589-445	Panel—Plexiglass fuselage nose	1
65-5589-501	Panel—Plexiglass fuselage nose	1
65-5589-502	Panel—Plexiglass fuselage nose	1
65-5589-503	Panel—Plexiglass fuselage nose	1
51-713	Cable Assembly—Door stop	1
51-713-1	Cable Assembly—Door stop	1
51-560	Gasket—Rubber	1
51-259	Keeper—Latch	1
65-5589-401	Door Assembly—Fuselage nose	1
65-5589-88	Door—Fuselage nose	1
51-258	Latch—Door	1
BAC1603-8	Spacer—No. 10 bolt	1
51-61-14-6	Washer—Paw tape	79
65-5589-508	Frame Assembly—Fuselage nose	1
1-19079	Plate—Cover lock	1
15-7937	Window Assembly—Bomb sight	1
1-20188	Window—Bomb sight auxiliary	1
3-10407	Window—Bomb sight auxiliary	1
41-4888-14-4	Washer—1/16 rubber	3
15-7937-7	Spacer—Bomb sight window	1
15-7937-8	Spacer—Bomb sight window	1
3-13930	Tube Assembly—Dehydrator	1
3-13930-1	Tube—Dehydrator	1

Fuselage Assembly

3-13930-2	Screen—Dehydrator tube	2
1-20231	Nipple Assembly—Dehydrator	1
1-20232	Cap—Dehydrator	1
BAC538-4	Clamp—Loop type cushioned	3
BAC538-8	Clamp—Loop type cushioned	2
	(Parts List No. 137)	
55-5684	Support Installation—Bomb sight	1
55-5684-407	Support Assembly—Bomb sight	1
41-202-7	Washer—No. 10 bevel	1
55-5684-411	Angle Assembly—Bomb sight support	1
3-11741	Clamp Assembly—Bomb sight	1
41-9833	Handle—Bomb sight clamp	1
41-9758	Clamp—Bomb sight support	1
BAC115A40S	Bolt—5/16-24 bearing	1
3-11741-1	Clamp Assembly—Bomb sight	1
41-9833	Handle—Bomb sight clamp	1
41-9758-1	Clamp—Bomb sight support	1
BAC115A40S	Bolt—5/16-24 bearing	1
3-11741-2	Spacer—Bomb sight clamp	1
1-24581	Clip Assembly—Hose support	3
1-18413-1	Clip—Spring	3
75-3684-678	Fairing Installation—Rear wing fillet LH	1
75-3684-1	Fairing Installation—Rear wing fillet RH	1
75-3684-704	Fillet Assembly—Rear wing fairing LH	1
75-3684-633	Fillet Assembly—Rear wing fairing RH	1
1-18775	Fitting—Tube end	1R
1-18538-3	Bracket—Rear wing fillet	1
BAC114A9DD	Bolt—1/4-28 bearing	50
BAC114A11S	Bolt—1/4-28 bearing	4
BAC115A14S	Bolt—5/16-24 bearing	8
BAC116A44DD	Bolt—3/8-24	16
1-18594	Angle—Rear wing fillet	1
1-18594-1	Angle—Rear wing fillet	1
1-20206	Blister—Rear wing fillet	2
1-18680-2	Angle—Rear wing fillet	7L
1-21989	Angle—Rear wing fillet	6L
1-21989-1	Angle—Rear wing fillet	6R

AVIALOGS.COM

FINAL ASSEMBLY

Fuselage Assembly

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-21989	Angle—Rear wing fillet	1R
1-21989-1	Angle—Rear wing fillet	1L
1-18674-4	Angle—Rear wing fillet LH	1
1-18674-5	Angle—Rear wing fillet RH	1
1-18538-2	Bracket—Rear wing fillet	1R
1-21363	Spacer—Rear wing fillet	4
53-12016	Fitting—Compression strut	1
53-12016-1	Fitting—Compression strut	1
BAC114A11DD	Bolt—¼-28 bearing	10
BAC114A12DD	Bolt—¼-28 bearing	10
1-18670	Angle—Rear wing fillet	1
1-18670-1	Angle—Rear wing fillet	1
1-18681	Angle—Rear wing fillet	2
1-18681-1	Angle—Rear wing fillet	2
75-3684-674	Strut Assembly—Rear wing fillet fairing LH	1
75-3684-675	Strut Assembly—Rear wing fillet fairing RH	1
	(Parts List No. 138)	
21-6469-1	Terminal—Compression strut tie	4
BAC116A41S	Bolt—⅜-24 bearing	10
1-21363-1	Spacer—Compression strut	4
95-3684-800	Tube—Rear wing fillet fairing	1
95-3684-801	Tube—Rear wing fillet fairing	1
95-3684-802	Tube—Rear wing fillet fairing	1
95-3684-803	Tube—Rear wing fillet fairing	1
75-3684-681	Bolt—Rear wing fillet fairing	4
1-21989	Angle—Rear wing fillet fairing	1
1-21989-1	Angle—Rear wing fillet fairing	6
75-3684-640	Bulkhead Assembly—Rear wing fillet fairing	1
75-3784-641	Bulkhead Assembly—Rear wing fillet fairing	1
75-3684-642	Bulkhead Assembly—Rear wing fillet fairing	1
75-3684-643	Bulkhead Assembly—Rear wing fillet fairing	1
65-3684-711	Tip Assembly—Rear wing fillet fairing	1
55-7679	Step Installation—Side gunner's station 6-6C	1
55-7679-417	Floor Assembly—Side gunner's station 6-6C step	1
55-7679-434	Floor—Side gunner's station 6-6C step	1

Fuselage Assembly

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-4858	Washer—No. 10 flathead screw	27
55-7679-446	Bracket Installation—Side gunner's station 6-6A step	1
55-7679-448	Bracket Installation—Side gunner's station 6-6B step	1
55-7679-406	Bracket Installation—Side gunner's station 6-6C step	1
55-7679-445	Floor Assembly—Side gunner's station 6-6C step	1
55-7679-443	Floor—Side gunner's station 6-6C step	1
55-7679-444	Matting—Side gunner's station 6-6C step (Goodrich)	1
41-4858	Washer—No. 10 flathead screw	36
41-4858	Washer—No. 10 flathead screw	27
7-1517	Bracket Installation—Control cables	1
7-1517-1	Bracket Installation—Control cables	1
3-13454	Bracket—Pulley	1
3-13454-1	Bracket—Pulley	1
BAC1604-8	Spacer—¼ bolt	2
BAC1604-83	Spacer—¼ bolt	2
BAC1603-34	Spacer—No. 10 bolt	2
BAC1603-142	Spacer—No. 10 bolt	2
BAC1603-23	Spacer—No. 10 bolt	1L
BAC1603-8	Spacer—No. 10 bolt	1
BAC1603-104	Spacer—No. 10 bolt	1
BAC1603-134	Spacer—No. 10 bolt	1R
BAC1605-24	Spacer—5/16 bolt	2
BAC1605-7A	Bolt	62
BAC1605-10A	Bolt	8
BAC1605-11A	Bolt	46
AN525-10-6	Screw	23
AN960-516	Washer	42
365-524	Nut	114
	(Parts List No. 139)	
365-1032	Nut	23

FUSELAGE ASSEMBLY

Fuselage Assembly—Forward Section

	(Parts List No. 140)	
15-7330	Fuselage Assembly—Forward section	1
15-9298	Bulkhead Assembly—Station 3 (PL 167-168)	1
75-3424	Bulkhead Assembly—Station 4 (PL 169-173)	1
85-3425	Bulkhead Assembly—Station 5 (PL 174-177)	1
75-3513	Floor Installation—Pilots (PL 178-184)	1
75-3577	Floor Installation—Radio and gunner's (PL 185-189)	1
55-8765	Enclosure Installation—Pilots (PL 190-194)	1
75-4122	Door Assembly—Bomb LH (PL 195-197)	1
75-4122-1	Door Assembly—Bomb RH (PL 195-197)	1
75-3445	Strut Installation—Body comp. (PL 198-199)	1
75-3445-1	Strut Installation—Body comp. (PL 198-199)	1
55-6612	Fairing Installation—Top turret (PL 200-201)	1
65-5795	Stiffener Installation—Station 2A-2E circumference (PL 202-204)	1
15-7313	Stiffener Installation—Station 3A-3J (PL 205-208)	1
15-7314	Stiffener Installation—Station 4A-4JA (PL 209-210)	1
75-7315	Stiffener Installation—Station 5A-5H (PL 211-213)	1
65-5663	Bulkhead Assembly—Station 1	1
41-6602-12	Angle—Bulkhead support	11
41-6602-13	Angle—Bulkhead support	10
1-16031	Tab Assembly—Lining support	33
65-5584	Bulkhead Assembly—Station 2	1
65-5584-21	Spacer—Micarta station 2 bulkhead	2
65-5584-22	Spacer—Micarta station 2 bulkhead	2
21-5473-4	Angle—Bulkhead support LH	1
21-5473-5	Angle—Bulkhead support RH	1

Fuselage Assembly—Forward Section

1-18409	Angle—Longeron tie bulkhead 2	2
1-18409-1	Angle—Longeron tie bulkhead 2	2
1-21389	Angle—Stiffener tie	4
1-21389-1	Angle—Stiffener tie	3
41-3316-6	Angle—Stiffener tie LH	12
41-3316-7	Angle—Stiffener tie RH	11
41-5544	Hook—Lining support	22
41-7591	Angle Assembly—Navigation floor	1
65-5584-500	Angle Assembly—Station 2 bulkhead	1
65-5584-529	Angle Assembly	8
37B3822-6B	Rib Nut—Threaded	2
15-7015	Bulkhead Assembly—Station 6 forward	1
15-7015-42	Plate Assembly—Forward bulkhead station 6 LH.	1
15-7015-43	Plate Assembly—Forward bulkhead station 6 RH.	1
	(Parts List No. 141)	
15-7015-44	Angle Assembly—Forward bulkhead station 6	4
15-7015-64	Angle Assembly—Block station 6 forward	1
1-26457	Decalcomania	1
14-2064	Support Installation—Sounding	1
41-4323-2	Tab—Lining support	41
41-5544	Hook—Lining support	2
15-7372-2	Door Installation—Bulkhead 4-5-6	1
15-7372-6	Door Assembly—Bulkhead 4-5-6	1
15-7372-28	Door Assembly—Bulkhead 4-5-6	1
1-18266-1	Hinge—Half bulkhead door	3
1-18266-3	Pin—Loose bulkhead door	3
48-1071	Support Installation—Hand crank and extension:	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-20555	Keeper Installation—Door	1
21-5581-1	Gusset—Channel tie	2
21-5582	Gusset—Channel tie	13
1-18890	Angle—Tube support	1
21-5582-1	Gusset—Channel tie	3
BAC1238-2	Spacer—Nut plate	8
3-14920	Channel—Antenna tuning	1
1-17560	Gusset—Channel tie	2
1-17560-1	Gusset—Channel tie	2
1-17561	Gusset—Channel tie	1
1-17561-1	Gusset—Channel tie	1
1-17562	Gusset—Channel tie	1
1-17562-1	Gusset—Channel tie	1
BAC1249-516S	Plate—Fiber nut	2
1-25577	Angle—Wire support	1
15-7352	Walk Installation—Station 3 to 3G	1
15-7352-1	Floor Assembly—Station 3 to 3G walk	1
41-4858	Washer—No. 10 flathead screw	31
46-8373	Bracket Installation—Bomb door release	1
46-8373-402	Bracket Assembly—Bomb door release	1
BAC1603-16	Spacer—No. 10 bolt	6
BAC1603-51	Spacer—No. 10 bolt	6
46-7095	Bracket Installation—Bomb door release	1
46-7095-1	Bracket Assembly—Bomb door release	1
BAC1614-20	Spacer—No. 10 bolt	4
64-1693	Floor Installation—Extra station 3 to 3B	1
64-1693-605	Floor Assembly—Extra station 3 to 3B	1
64-1693-403	Matting—Extra station 3 to 3B floor	1
65-5796	Stiffener Installation—Station 1B circumference	1
65-5796-404	Segment Assembly—Station 1B circumference stiffener	1
1-16283-6	Angle—Stiffener tie	5
1-16283-7	Angle—Stiffener tie	4
21-9221	Spacer—Nut plate	2
41-8097	Hook—String support	8
	(Parts List No 141A)	
65-5796-408	Segment Assembly—Station 1B circumference stiffener	1
1-16283-6	Angle—Stiffener tie	2
1-16283-7	Angle—Stiffener tie	3
21-9221	Spacer—Nut plate	1
41-8097	Hook—String support	2
BAC1247-10S	Angle—Nut plate	1
37B3822-6B	Rivnut—Threaded	1
65-5796-500	Segment Assembly—Station 1B circumference stiffener	1
1-16283-6	Angle—Stiffener tie	3
	(Parts List No. 142)	
1-16283-7	Angle—Stiffener tie	3
21-9221	Spacer—Nut plate	2
41-8097	Hook—String support	7
BAC1247-10S	Angle—Nut plate	3
37B3822-6B	Rivnut—Threaded	3
65-5796-502	Segment Assembly—Station 1B circumference stiffener	1
1-16283-6	Angle—Stiffener tie	2
1-16283-7	Angle—Stiffener tie	1
41-7084	Angle—Stiffener tie	3
41-7084-1	Angle—Stiffener tie	3
41-7504	Angle—Stiffener tie	1
41-7504-1	Angle—Stiffener tie	1
BAC1246-10S	Plate—Fiber nut	1
1-17243-3	Angle—Stiffener attaching	4
41-7084-1	Angle—Stiffener attaching	3
41-6063-90-40-1	Angle—$\frac{5}{16}$ x $\frac{3}{4}$ aluminum alloy	4
65-5797	Stiffener Installation—Station 1A circumference	1
65-5797-400	Segment Assembly—Station 1A circumference stiffener	1
1-16283-7	Angle—Stiffener tie	3
1-17243-3	Angle—Stiffener attach	1
41-8097	Hook—String support	2

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-5797-401	Segment Assembly—Station 1A circumference stiffener	1
1-16283-6	Angle—Stiffener tie	3
1-17243-3	Angle—Stiffener attaching	1
41-8097	Hook—String support	2
65-5797-404	Segment Assembly—Station 1A circumference stiffener	1
1-16283-7	Angle—Stiffener tie	1
1-17243-3	Angle—Stiffener attaching	1
65-5797-405	Segment Assembly—Station 1A circumference stiffener	1
1-16283-6	Angle—Stiffener tie	1
1-17243-3	Angle—Stiffener attaching	1
65-5797-500	Segment Assembly—Station 1A circumference stiffener	1
1-21044	Angle—Stiffener tie	1
41-6829-4	Angle—Stiffener tie	1
41-6830	Angle—Stiffener tie	1
41-6602-9	Angle—Block support	2
41-6829	Angle—Stiffener tie	1
41-6829-1	Angle—Stiffener tie	1
41-6829-2	Angle—Stiffener tie	1
41-6829-3	Angle—Stiffener tie	1
41-6602-17	Angle—Block support	1
BAC1246-10S	Angle—Nut plate	3
65-5797-408	Segment Assembly—Station 1A circumference stiffener	1
1-16283-6	Angle—Stiffener tie	2
1-16283-7	Angle—Stiffener tie	1
41-8597	Tab—Lining support	2
	(Parts List No. 143)	
65-5797-409	Segment Assembly—Station 1A circumference stiffener	1
1-16283-6	Angle—Stiffener tie	1
1-16283-7	Angle—Stiffener tie	2
41-8097	Hook—String support	2
BAC1247-10S	Angle—Nut plate	1
37B3822-6B	Rivnut—Threaded	1
65-5797-412	Segment Assembly—Station 1A circumference stiffener	1
1-16283-6	Angle—Stiffener tie	2
1-16283-7	Angle—Stiffener tie	2
21-9221	Spacer—Nut plate	6
BAC1247-10S	Angle—Nut plate	2
37B3822-6B	Rivnut—Threaded	1
41-6063-90-40-1	Angle—$\frac{5}{16}$ x $\frac{3}{4}$ aluminum alloy	4
59-2932	Stiffener Installation—Stowage support	1
59-2932-400	Support Assembly—Stowage stiffener	1
59-2932-402	Support Assembly—Stowage stiffener	1
59-2932-500	Support Assembly—Stowage stiffener	1
21-9221	Spacer—Nut plate	6
1-16283-2	Angle—Stiffener tie	3
1-16283-3	Angle—Stiffener tie	5
1-16283-22	Angle—Stiffener tie	1
41-3002-30-64	Filler—.091 channel	5
15-7013	Stiffener Installation—Station 1-6 longt.	1
3-13587	Splice Installation—Longt. block 4 and 5	12
1-18500	Splice Installation—Longt. stiffener	8
1-20238	Splice Installation—Longt. stiffener	2
1-20242	Angle—Longt. stiffener splice	2
1-20520	Splice Installation—Longt. stiffener	3
1-19822	Channel—Stiffener tie	1
1-19822-1	Channel—Stiffener tie	1
1-19818	Channel—Stiffener tie	1
1-19818-1	Channel—Stiffener tie	5
1-19821	Gusset—Stiffener tie	4
1-19820	Gusset—Stiffener tie	8
1-19820-1	Gusset—Stiffener tie	2
1-19820-2	Gusset—Stiffener tie	3
1-18768	Plate—Stiffener tie LH	1
1-18768-1	Plate—Stiffener tie RH	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18846	Plate—Stiffener tie	4
1-18846-1	Plate—Stiffener tie	4
1-18847	Plate—Stiffener tie	1
1-18847-1	Plate—Stiffener tie	1
41-9042-2	Plate—Stiffener tie	1
41-9042-3	Plate—Stiffener tie	1
1-18903	Plate—Longt. tie	2
1-20242	Angle—Longt.	17
1-18449	Angle—Stiffener tie	5
1-18850	Angle—Longt. att.	2
	(Parts List No. 144)	
1-18850-1	Angle—Longt. att.	2
1-18851	Angle—Longt. att.	4
1-18851-1	Angle—Longt. att.	4
1-18942	Angle—Longt. att.	2
1-18942-1	Angle—Longt. att.	2
21-2367-8	Clip—Stiffener	1
21-2367-9	Clip—Stiffener	1
41-1645-52	Angle—Tabulated	2
41-8924	Angle—Stiffener tie	1
41-8924-1	Angle—Stiffener tie	1
41-5135	Angle—Stiffener tie	15
41-5135-1	Angle—Stiffener tie	15
1-18277	Tee—Stiffener tie	13
BAC1247-110S	Angle—Nut plate	25
48-726	Fairing Installation—Center wing fillet lower	1
55-3685	Fairing Installation—Front wing fillet LH	1
55-3685-1	Fairing Installation—Front wing fillet RH	1
21-2367	Clip—Stiffener	2
21-2367-1	Clip—Stiffener	2
6-9582	Support Installation—Transmitter LH	1
6-9582-1	Support Installation—Transmitter RH	1
6-9582-2	Support Assembly—Weld LH	1
6-9582-3	Support Assembly—Weld RH	1
3-12211	Window Installation—Station 5C LH	1
3-12211-1	Window Installation—Station 5C RH	1
3-12211-4	Strip—Sealing station 5C window (Everseal Products Co.)	2
3-12211-5	Window—Station 5C	2
3-12211-7	Frame Assembly—Station 5C window LH	1
3-12211-8	Frame Assembly—Station 5C window RH	1
41-5135-6	Angle—Stiffener tie	2
41-5135-7	Angle—Stiffener tie	2
37B3822-6B	Rivnut	16
65-5667-2	Gusset	4
41-6063-90-40-1	Angle—9/16 x 3/4 aluminum alloy	2
51-61-14-6	Washer—Paw tape	42
65-5667	Window Installation—Station 1-3	1
65-5667-503	Frame Assembly—Station 1-3 window	1
65-5667-504	Frame Assembly—Station 1-3 window	1
65-5667-505	Frame Assembly—Station 1-3 window LH	1
65-5667-506	Frame Assembly—Station 1-3 window RH	1
65-5667-507	Frame Assembly—Station 1-3 window LH	1
65-5667-508	Frame Assembly—Station 1-3 window RH	1
65-5667-509	Frame Assembly—Station 1-3 window LH	1
65-6667-510	Frame Assembly—Station 1-3 window RH	1
65-5667-3	Retainer—Station 1-3 window LH	1
65-5667-4	Strip—Sealing station 1-3 window (Everseal Products Co.)	5
65-5667-8	Retainer—Station 1-3 window RH	1
65-5667-9	Strip—Sealing station 1-3 window (Everseal Products Co.)	5
65-5667-11	Retainer—Station 1-3 window LH	1
65-5667-13	Window—Station 1-3 LH	1
65-5667-14	Window—Station 1-3 LH	1
65-5667-16	Window—Station 1-3	1
65-5667-17	Window—Station 1-3 LH	1

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 145)	
65-5667-22	Window—Station 1-3 RH	1
65-5667-23	Retainer—Station 1-3 window RH	1
65-5667-25	Retainer—Station 1-3 window RH	1
65-5667-26	Window—Station 1-3 RH	1
65-5667-28	Retainer—Station 1-3 window RH	1
65-5667-29	Window—Station 1-3 RH	1
65-5667-403	Retainer—Station 1-3 window RH	1
65-5667-405	Retainer—Station 1-3 window LH	1
65-5667-500	Window—Station 1-3 RH	1
65-5667-501	Window—Station 1-3	1
65-5667-502	Window—Station 1-3 LH	1
41-5135	Angle—Stiffener tie LH	8
41-5135-1	Angle—Stiffener tie RH	8
65-5667-511	Frame Assembly—Station 1-3 window	1
65-5667-512	Frame Assembly—Station 1-3 window	1
41-5135	Angle—Stiffener tie	2
41-5135-1	Angle—Stiffener tie	1
41-6063-90-40-1	Angle—9/16 x 3/4 aluminum alloy	8
51-61-14-6	Washer—Paw tape	210
65-3468	Door Installation—Forward entrance	1
65-3468-414	Channel Assembly—Forward entrance door	1
65-3468-400	Door Assembly—Forward entrance	1
3-11880	Latch Installation—Door	1
51M16-1	Latch Assembly—Door ND reference No. 5290 (Rite Hardware Co. 502 Douillard St., Los Angeles)	1
51-17	Knob Assembly—Door No. R25-1D (Rite Hdwe. Co.)	1
21-9670	Channel—Latch support	1
1-17640	Lever—Latch support	1
41-5135	Angle—Stiffener tie	2
41-5135-1	Angle—Stiffener tie	1
3-6475-2	Hinge Assembly—Cabin door RH	1
3-6475-3	Hinge Assembly—Cabin door LH	1
3-6475-6	Hinge—Cabin door	1
3-6475-7	Hinge—Cabin door	1
BAC344-4-439	Bushing—1/4 staked	2
21-2367	Clip—Stiffener	1
65-3468-41	Strip—Weather forward entrance door	1
3-11880-1	Keeper Installation—Door	1
41-9992	Hinge Assembly—Forward entrance door	1
41-9992-1	Hinge Assembly—Forward entrance door	1
21-1022-8-S	Bushing—1/4 diameter knurled	4
1-20521	Fair-lead Installation—Door release	1
1-19001-49	Fair-lead—Door release	2
1-18557-2	Handle Assembly—Door release	1
1-18557-7	Cable—Door release handle	1
1-18557-8	Cable—Door release handle	1
1-18557-9	Handle—Door release	1
1-18556	Terminal—Swaged special	2
	(Parts List No. 146)	
3-16132-8	Decalcomania—Miscellaneous	1
BAC1828-23	Terminal—Dead end cable	2
41-4452-1	Spring—Door pin	2
21-3232	Clip—Spring	2
65-5780	Floor Installation—Bombers forward gun	1
65-5780-516	Track Assembly—Outer bombers forward gun floor RH	1
65-5780-517	Track Assembly—Outer bombers forward gun floor LH	1
BAC1246-10S	Plate—Fiber nut	4
65-5780-51A	Matting—Bombers forward gun floor (Goodrich)	1
1-18750	Angle—Support	2
65-5780-518	Track Assembly—Inner bombers forward gun floor	1
BAC1249-110S	Plate—Fiber nut	7
41-7282	Angle—Support LH	1
41-7282-1	Angle—Support RH	1
43-10811	Stop—Bombers seat	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1614-24	Spacer—⅛ rivet	2
41-7280	Angle—Support LH	1
41-7280-1	Angle—Support RH	1
41-3119	Gusset—Stiffener attaching	2
41-4323-1	Tab—Lining support	8
51-998	Socket Installation—support	1
51-997	Socket—Support	1
41-7084	Angle—Stiffener tie	1
41-7084-1	Angle—Stiffener tie	1
BAC1614-32	Spacer—⅛ rivet	4
BAC1249-2416D	Plate—Fiber nut	1
65-5780-521	Channel Assembly—Bombers forward gun floor	1
65-5780-522	Channel Assembly—Bombers forward gun floor	1
65-5780-523	Channel Assembly—Bombers forward gun floor	1
65-5780-524	Channel Assembly—Bombers forward gun floor	1
65-5780-525	Channel Assembly—Bombers forward gun floor	1
65-5780-526	Floor Assembly—Bombers forward gun floor	1
65-5780-513	Matting—Bombers forward gun floor	1
65-5780-527	Floor Assembly—Bombers forward gun floor	1
65-5780-515	Matting—Bombers forward gun floor	1
41-4323-1	Tab—Lining support	5
BAC1603-80	Spacer—No. 10 bolt	1
75-5781	Floor Installation—Navigators	1
	Dash number parts, shown on 75-5781 drawing are represented by dash numbers of 75-5781 and 65-5781.	
75-5781-600	Sheet Assembly—Navigators floor	1
3-14223	Web Assembly—Armor support	1
1-20546	Clip—Angle	1
65-5781-507	Sheet Assembly—Navigators floor	1
3-14224	Web—Armor support	1
BAC1246-10	Plate—Fiber nut	1
	(Parts List No. 147)	
65-5781-504	Sheet Assembly—Navigators floor	1
6-9486	Bracket Installation—Driftmeter valve	1
65-5781-526	Sheet Assembly—Navigators floor	1
41-8594-16-12	Angle—Reinforcement	1
74-1689	Bracket Installation—Bomb control	1
	Dash number parts, shown on 74-1689 drawing are represented by dash numbers of 74-1689 and 64-1689.	
74-1689-607	Bracket Assembly—Bomb control	1
41-7589-2	Crank Assembly—Bomb control	1
41-7589-1	Arm—Bomb control crank	1
BAC450-4	Bearing—Ball control	1
51-761-1	Lever—Control	1
BAC1604-8	Spacer—¼ bolt	1
BAC1604-46	Spacer—¼ bolt	1
59-2861	Crank Installation—Bomb control	1
3-13900	Crank Assembly—Bomb control	1
3-13900-1	Hub Assembly—Control crank	1
1-19827-259	Hub—Tab control	1
BAC1604-130	Spacer—¼ bolt	1
1-19828-2	Lever—Tab fork	2
BAC1603-55	Spacer—No. 10 bolt	2
BAC1604-35	Spacer—¼ bolt	2
1-20348	Loop—Footman	1
BAC1245-10	Anchor Nut—High temperature	4
BAC1328-5-312	Grommet—Dzus fastener	2
BAC1324-5-35	Button—Dzus oval head	2
65-5781-523	Sheet Assembly—Navigators floor	1
BAC958-4-8	Hinge—Continuous	1
75-3444	Truss Installation—Catwalk	1
75-3444-423	Matting—Catwalk truss (Goodrich)	1
75-3444-602	Strip—Weather catwalk truss	1
75-3444-612	Walk Assembly—Catwalk truss	1
41-88	Angle—Limit switch	1
3-6532-1	Gusset—Catwalk truss	2
6-10115	Support Assembly—Catwalk	1
6-10115-1	Support Assembly—Catwalk	1
6-10115-2	Support Assembly—Catwalk	1

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-10115-3	Support Assembly—Catwalk	1
41-9799	Bracket Assembly—Catwalk truss LH	2
41-9799-1	Bracket Assembly—Catwalk truss RH	2
3-12471	Bracket Installation—Hydraulic units filter	1
3-12471-1	Bracket Assembly—Hydraulic units filter	1
3-6531-1	Gusset—Catwalk truss	2
	(Parts List No. 148)	
3-6533-1	Gusset—Catwalk truss	2
3-6534	Gusset—Catwalk truss	2
3-6535	Gusset—Catwalk truss	2
3-6565	Gusset—Catwalk truss	2
21-5591	Gusset—Catwalk truss	2
21-5593	Gusset—Catwalk truss	2
21-5594	Gusset—Catwalk truss	2
3-6512	Plate Assembly—Bomb rail support	4
3-6512-1	Plate—Bomb rail support	4
BAC348-4-225	Bushing—Staked	8
3-12009	Bracket Installation—Regulator valve	1
3-12009-1	Bracket Assembly—Spotweld regulator valve	1
6-4829	Brace Assembly—Catwalk truss	1
41-87	Angle—Limit switch	1
73-3444-615	Bracket Assembly—Catwalk truss	1
3-11087	Bracket—Limit switch	1
1-17586	Channel—Catwalk truss	1
BAC1604-140	Spacer—¼ bolt	2
BAC114A-44S	Bolt—Bearing	4
BAC114A-10DD	Bolt—Bearing	4
BAC114A-42DD	Bolt—Bearing	4
BAC114A-44DD	Bolt—Bearing	18
BAC114A-45DD	Bolt—Bearing	5
BAC114A-46DD	Bolt—Bearing	26
BAC114A-47DD	Bolt—Bearing	6
BAC115A-48DD	Bolt—Bearing	39
BAC115A-49DD	Bolt—Bearing	3
BAC115A-50DD	Bolt—Bearing	3
BAC116A-47DD	Bolt—Bearing	42
BAC113A-19S	Bolt—Bearing	16
BAC114A-48DD	Bolt—Bearing	6
6-8337	Door Installation—Drift signals	1
6-8337-1	Door Assembly—Drift signals	1
41-7708	Latch—Flare door	1
BAC364-9S	Spacer—Bearing bushing	1
6-8337-2	Door—Draft signals	1
6-8337-10	Hinge—Draft signals door	1
6-8337-9	Gasket—Draft signals door	1
41-7707	Plate—Latch	1
15-7471	Door Installation—Control access	1
15-7471-1	Door Assembly—Control access	2
15-7471-2	Gasket—Control access door	1
15-7471-3	Door—Rear control access	2
15-7471-4	Door Assembly—Control access	1
15-7471-5	Gasket—Control access door	1
15-7471-6	Door—Front control access	1
	(Parts List No. 148A)	
15-7471-7	Door Assembly—Control access	1
15-7471-8	Door—Control access	1
15-7471-5	Gasket—Control access	1
BAC1246-10S	Plate—Fiber nut	2
BAC1252-10S	Plate—Fiber nut	30
15-7012	Skin Installation—Body station 1-6 fuselage	1
65-5671-500	Frame Installation—Bomber panel switch	1
65-5671-511	Frame Assembly—Bomber panel switch	1
65-5671-21	Door Assembly—Bomber panel switch frame	1
65-5671-22	Door—Bomber panel switch frame	1
65-5671-601	Hinge—Door	1
41-9638-30	Button—Dzus wing type	1
41-3862	Grommet—Dzus type 375	1
65-5671-412	Lid Assembly—Bomber panel switch frame	1
65-5671-28	Felt—Bomber panel switch frame	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-5671-29	Spacer—Bomber panel switch frame	3
65-5671-411	Lid—Bomber panel switch frame	1
65-5671-602	Hinge—Lid	3
41-6472	Stop—Door LH	1
41-6472-1	Stop—Door RH	1
65-5671-603	Plate Assembly—Bomber panel frame	1
6-8942	Mounting Installation—Bomb load indicator	1
1-17585	Support Assembly—Panel	1
BAC1097-10-105	Nut—Elastic clinch	1
BAC1247-10	Angle—Nut plate	3
	(Parts List No. 149)	
3-12920	Bracket Installation—Switch support	1
3-12920-1	Bracket Assembly—Switch support	1
41-6473	Spring—Flat door	2
21-7395-104-56	Washer—1/8 fiber	1
BAC1246-110S	Plate—Fiber nut	3
51-541	Fair-lead Installation—Bombers panel	1
51-541-1	Fair-lead—Bombers panel	2
41-3863	Spring—Dzus fastener	14
41-7957-8-24	Angle—Support	1
41-7957-8-80	Angle—Support	1
15-9257	Support Installation—Flight control	1
	Dash number parts, shown on 15-9257 drawing are represented by dash numbers of 55-5693.	
55-5693-1	Bracket Assembly—Flight control support	1
55-5693-4	Bracket Assembly—Flight control support	1
55-5693-7	Bracket Assembly—Flight control support	1
55-5693-10	Bracket Assembly—Flight control support	1
55-5693-13	Bracket Assembly—Flight control support	1
55-5693-16	Bracket Assembly—Flight control support	1
BAC1249-110S	Plate—Fiber nut	2
55-5693-21	Bracket Assembly—Flight control support	1
BAC1249-110S	Plate—Fiber nut	3
55-5693-28	Bracket Assembly—Flight control support	1
55-5693-32	Bracket Assembly—Flight control support	1
15-9451	Bracket Assembly—Control cables	1
15-9541-1	Bracket Assembly—Control cables	1
BAC1603-39	Spacer—No. 10 bolt	1
BAC1603-14-39	Spacer—No. 10 bolt	1
15-5692-23	Spacer—Control cables bracket	1
BAC204-S12	Bolt—1/4-28 drilled head	1
BAC1603-39	Spacer—No. 10 bolt	3
BAC1603-58	Spacer—No. 10 bolt	5
1-23569	Gyro Assembly—Modified A.F.C.E. (Honeywell Regulator Co., Minneapolis) (Government furnished)	1
1-23591	Converter Assembly—Rotary (Honeywell Regulator Co.) (Government furnished)	1
1-23568	Amplifier Assembly—Modified A.F.C.E. (Honeywell Regulator Co.) (Government furnished)	1
1-23584	Motor—Aileron servo (Honeywell Regulator Co.) (Government furnished)	1
1-22989-3	Block—Lam. phenolic	4
1-22989-1	Block—Lam. phenolic	6
1-22989-2	Block—Lam. phenolic	2
BAC1603-64	Spacer—No. 10 bolt	1
15-9257-1	Table Installation—Flight controls	1
15-9256-1	Table Assembly—Flight controls	1
51-622-44-46	Block—Micarta	4
51-622-55-62	Block—Micarta	1
51-622-59-22	Block—Micarta	8
	(Parts List No. 150)	
51-622-64-52	Block—Micarta	6
1-19812	Block—Micarta	1
1-22989-1	Block—Micarta	8
1-22989-2	Block—Micarta	1
1-22989-3	Block—Micarta	4
1-22989-4	Block—Micarta	5

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1603-59	Spacer—No. 10 bolt	6
15-9257-2	Table Installation—Flight controls	1
15-9256-2	Table Assembly—Flight controls	1
1-19709-92-81	Block—Micarta	1
1-19709-100-81	Block—Micarta	1
1-22994-1	Block	1
1-22994-2	Block	1
BAC1603-59	Spacer—No. 10 bolt	4
BAC1603-59	Spacer—No. 10 bolt	1
BAC1603-64	Spacer—No. 10 bolt	2
65-3469	Supplemental Installation—Bomb rack	1
65-3469-421	Plate Assembly—Bomb rack support	1
65-3469-422	Plate Assembly—Bomb rack support	1
21-6246	Name—Plate	2
21-6246-1	Name—Plate	2
21-5958-2	Plate—Bomb rack no tab	4
21-5958-5	Plate—Bomb rack no tab	2
21-6246	Name—Plate	1
21-6246-1	Name—Plate	2
21-6246-2	Name—Plate	2
1-18055	Name—Plate	2
21-6492	Angle—Channel attaching	24
21-6498	Angle—Bomb rail support LH	4
21-6498-1	Angle—Bomb rail support RH	4
21-6498-2	Angle—Bomb rail support LH	4
21-6498-3	Angle—Bomb rail support RH	4
21-9401	Gusset—Bomb rail support	8
21-9402	Angle—Bomb rail support	12
21-9403	Angle—Bomb rail reinforcement LH	1
21-9403-1	Angle—Bomb rail reinforcement RH	1
21-9405	Channel—Bomb rail support	4
1-18054	Name—Plate	2
41-4188	Universal—Bomb hoist pulley bracket	6
41-4188-1	Universal—Bomb hoist pulley bracket	4
41-4188-2	Universal—Bomb hoist pulley bracket	2
41-4190	Spring—Universal hold-down	6
41-4196	Spring—Universal hold-down	2
41-5317	Angle—Bomb rail reinforcement LH	1
41-5317-1	Angle—Bomb rail reinforcement RH	1
41-6913	Angle Assembly—No. 8/32 M.T.G	1
41-9755	Socket—Universal pulley bracket	4
41-9755-1	Socket—Universal pulley bracket	2
46-9766	Angle—Bomb rail support LH	2
46-9766-1	Angle—Bomb rail support RH	2
41-9797	Bracket Assembly—Bomb hoist "2" pulley	6
	(Parts List No. 151)	
41-9797-1	Bracket—Bomb hoist "2" pulley	2
41-9798	Bracket Assembly—Bomb hoist "2" pulley	4
41-9798-1	Bracket Assembly—Bomb hoist "2" pulley	2
41-9798-2	Bracket—Bomb hoist "2" pulley	2
41-9798-3	Bracket—Bomb hoist "2" pulley	2
51-172	Socket—Bomb hoist pulley bracket	2
51-174	Socket—Bomb hoist pulley bracket	2
21-9404	Gusset—Inboard rail support	8
1-16283	Angle—Stiffener tie	3
1-16283-1	Angle—Stiffener tie	3
1-17364	Channel—Stiffener attaching	2
1-17364-1	Channel—Stiffener attaching	2
1-17364-2	Channel—Stiffener attaching	10
1-17364-3	Channel—Stiffener attaching	10
1-17364-4	Channel—Stiffener attaching	2
1-17364-5	Channel—Stiffener attaching	2
1-17364-6	Channel—Stiffener attaching	2
1-17364-7	Channel—Stiffener attaching	2
1-17365	Angle—Stiffener attaching	8
1-17365-1	Angle—Stiffener attaching	8
1-17565-2	Angle—Stiffener attaching	4
1-17565-3	Angle—Stiffener attaching	4
BAC1604-84	Spacer—1/4 bolt	6
BAC1604-88	Spacer—1/4 bolt	16
1-18449	Angle—Stiffener tie	14

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1246-10S	Plate—Fiber nut	1
1-25507	Support Installation—Hose	1
1-25507-1	Angle Assembly—Hose support	1
BAC1097-6-1055	Nut	2
9-3665	Support Installation—Driftmeter	1
1-16283-20	Angle—Stiffener tie	1
1-16283-21	Angle—Stiffener tie	1
41-3002-28-56	Filler—.091 channel	1
3-10949	Support Installation—Table leg	1
3-10949-3	Channel Assembly—Table	1
41-7581	Angle Assembly—Support	1
3-11375	Support Installation—Data card box	1
3-11375-1	Support Assembly—Data card box support	1
21-9221	Spacer—Nut plate	2
41-5878-4	Angle—Stiffener tie	2
6-8421	Support Installation—Antenna switch	1
6-8421-1	Support Assembly—Antenna switch support	1
BAC1247-10	Angle—Nut plate	2
21-9905	Clip—Stiffener tie	1
21-9905-1	Clip—Stiffener tie	1
6-8424	Support Installation—Extension lamp radio compartment	1
6-8424-1	Support Assembly—Extension lamp radio compartment	1
21-9905	Clip—Stiffener tie	1
21-9905-1	Clip—Stiffener tie	1
21-9221	Spacer—Nut plate	3

(Parts List No. 152)

6-8439	Support Installation—Bomber's map case	1
6-8439-1	Channel Assembly—Bomber's map case	2
6-9361	Support Installation—Oxygen regulator bracket	1
6-9361-1	Support Assembly—Oxygen regulator bracket	1
6-9366	Support Installation—Bomber's lamp	1
3-12978	Support Assembly—Bomber's lamp	1
BAC1252-210S	Plate—Fiber nut	4
BAC1246-10S	Plate—Fiber nut	1
6-9378	Support Installation—Cockpit lamp	1
1-17242-1	Angle—Stiffener attaching	1
7-1336	Support Installation—Navigator's lamp	1
21-9221	Spacer—Nut plate	4
8-819	Support Installation—Emergency bomb control	1
8-819-14	Support Assembly—Station 3B	1
8-819-15	Support Assembly—Station 3E	1
9-3090	Support Installation—Radio compartment seat station 5F	1
41-6063-90-40-1	Angle—9/16 x 3/4 aluminum alloy	2
41-314	Support—Radio operator's seat	1
1-16283	Angle—Stiffener tie	1
1-16283-1	Angle—Stiffener tie	1
9-3091	Support Installation—Radio compartment seat station 5C	1
9-3091-7	Stiffener Assembly—Radio compartment seat station 5C	1
6-8247	Support—Radio compartment seat	1
41-314	Support—Radio compartment seat	1
9-3092	Support Installation—Radio operator's seat	1
9-3092-6	Stiffener Assembly—Radio operator's seat	1
9-3092-8	Support Assembly—Radio operator's seat	1
6-8247-1	Support—Radio compartment seat	1
41-314	Support—Radio operator's seat	1
3-12309	Support Installation—Oxygen regulator station 5C	1
3-12309-1	Support Assembly—Oxygen regulator station 5C	1
BAC1246-10S	Plate—Fiber nut	2
3-12309-4	Support Installation—Oxygen regulator station 5A	1
3-12309-1	Support Assembly—Oxygen regulator	1
BAC1246-10S	Plate—Fiber nut	2
3-13650	Support Installation—Liaison outside insulator	1
41-8270-7	Cup Assembly—Antenna insulator	1
6-7379-2	Support Installation—Dome light	1
1-16283	Angle—Stiffener tie	2
21-9221	Spacer—Nut plate	4

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-7529	Support Installation—Compass lamp	1
21-2367	Clip—Stiffener LH	2
21-2367-1	Clip—Stiffener RH	2

(Parts List No. 153)

21-9221	Spacer—Nut plate	4
BAC1613-6	Spacer—3/32 rivet	4
6-7757	Support Installation—Radio lamp	1
6-7757-1	Support Installation—Radio lamp	1
6-7757-5	Zee Assembly—Radio lamp support	4
21-9221	Spacer—Nut plate	8
6-7757-6	Angle Assembly—Radio lamp support	4
6-7890	Support Installation—Junction box LH	1
6-7890-1	Support Installation—Junction box RH	1
21-2367	Clip—Stiffener	2
6-7918	Support Installation—Spar lamp panel	1
6-7918-5	Support Assembly—Spar lamp panel	1
21-2367-2	Clip—Stiffener	1
21-2367-3	Clip—Stiffener	1
21-9221	Spacer—Nut plate	2
6-7918-6	Angle Assembly—Spare lamp panel	2
43-9803	Support Installation—Vibration absorber LH	1
21-2367-6	Clip—Stiffener LH	1
43-9803-1	Support Installation—Vibration absorber RH	1
21-2367-7	Clip—Stiffener RH	1
46-4254-5	Support Installation—Auxiliary control panel	1
1-16283-8	Angle—Stiffener tie	1
21-7224	Angle—Panel support	1
21-7225	Angle—Panel support	1
41-6303	Channel Assembly—Auxiliary panel support	1
47-1141	Support Installation—Bomb bay lamp LH	1
47-1141-1	Support Installation—Bomb bay lamp RH	1
47-1141-402	Support Assembly—Bomb bay lamp LH	1
47-1141-403	Support Assembly—Bomb bay lamp RH	1
55-7598	Support Installation—Radio	1
15-7930-1	Pan—Radio loop support	1
21-2367	Clip—Stiffener	1
41-6063-90-40-1	Angle—9/16 x 3/4 aluminum alloy	1
49-3189	Support Installation—Interphone station 5D	1
9-3189-1	Angle Assembly—Interphone station 5D support	1
9-3189-5	Angle Assembly—Interphone station 5D support	1
21-9221	Spacer—Nut plate	5
55-6518	Support Installation—Interphone station 5D	1
15-6518-1	Angle Assembly—Interphone station 5D support	1
15-6518-3	Angle Assembly—Interphone station 5D support	1
15-6518-5	Angle Assembly—Interphone station 5D support	1
15-6518-10	Angle Assembly—Interphone station 5D support	1

(Parts List No. 153A)

15-6518-12	Angle Assembly—Interphone station 5D support	1
15-6518-13	Angle Assembly—Interphone station 5D support	1

(Parts List No. 154)

15-6518-16	Angle Assembly—Interphone station 5D support	1
21-9221	Spacer—Nut plate	4
41-5451-2	Angle—Platform support	3
41-5451-3	Angle—Platform support	3
6-10696	Support Installation—Fuel tubing	2
6-10696-1	Support Installation—Fuel tubing	2
41-9007-1	Angle—Tube support	4

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
9-3192-7	Support Installation—Bomber clipboard	1
9-3192-3	Channel Assembly—Bomber clipboard support	1
9-3192-6	Channel Assembly—Bomber clipboard support	1
3-13670-5	Angle Installation—Navigator's case	1
3-13670-4	Angle Assembly—Navigator's case	1
9-3655	Support Installation—Fuel transfer select valve LH	1
9-3655-9	Plate—Fuel transfer select valve support	1
9-3655-1	Support Installation—Fuel transfer select valve RH	1
9-3655-10	Plate—Fuel transfer select valve support	1
9-3655-2	Bracket Assembly—Fuel transfer select valve LH	1
9-3655-3	Bracket Assembly—Fuel transfer select valve RH	1
9-3655-12	Bracket Assembly—Fuel transfer select valve	1
9-3655-13	Bracket Assembly—Fuel transfer select valve	1
BAC1246-10S	Plate—Fiber nut (used 12-13)	6
14-2353	Support Installation—Radio compass antenna	1
14-2353-1	Bracket Assembly—Radio compass antenna	1
14-2353-6	Bracket—Radio compass antenna support	1
8-1526	Support Installation—Vacuum and heat controls	1
8-1526-12	Channel Assembly	1
41-2476	Housing Assembly—Bearing	2
41-2476-3	Housing	2
8-1526-13	Channel Assembly	1
8-1526-7	Clip	1
8-1526-8	Clip	1
41-2476	Housing Assembly—Bearing	2
41-2476-3	Housing	2
BAC1603-64	Spacer—No. 10 bolt	1
BAC1603-64	Spacer—No. 10 bolt	1
BAC1603-256	Spacer	2
BAC1604-20	Spacer	1
BAC1604-205	Spacer	1
6-9691	Support Installation—Antenna control unit	1
6-9691-1	Support Assembly—Antenna control unit	1
6-4283-1	Support Installation—Bomb rack junction box LH	1
6-4283-4	Support Installation—Bomb rack junction box RH	1
3-11572-3	Support Installation—Emergency bomb release	1
BAC1247-108S	Angle—Nut plate	1
	(Parts List No. 155)	
3-13943	Support Installation—Lead-in insulation	1
1-18980	Cup Assembly—Antenna insulation	1
3-13945	Support Installation—Lead-in insulation	1
6-9510	Support Installation—Generator wing break shield	1
6-9510-1	Support Installation—Generator wing break shield	1
1-21400	Angle Assembly—Support	6
14-2070	Support Installation—Pitot mast	1
14-2070-1	Support Assembly—Pitot mast	2
49-2900	Support Installation—Interphone station 1	1
	Dash number parts, shown on 59-2900 drawing are represented by dash numbers of 49-2900.	
49-2900-5	Support Assembly—Interphone station 1	1
21-9221	Spacer—Nut plate	2
49-2900-400	Angle Assembly—Interphone station 1 support	1
49-2900-402	Angle Assembly—Interphone station 1 support	1
49-2900-405	Angle Assembly—Interphone station 1 support	1
49-2900-406	Angle Assembly—Interphone station 1 support	1
21-2367-3	Clip—Stiffener	3
41-3701	Angle—Stiffener tie	1
41-4407-1	Angle—Stiffener tie	2
41-4764	Angle—Reinforcing	2
55-5292	Support Installation—Ammunition box nose	1
1-17591	Angle Assembly—Support	2
41-5533-0-56	Spacer—No. 10 bolt	2
41-5533-1-2	Spacer—No. 10 bolt	2
41-5533-1-6	Spacer—No. 10 bolt	4
41-5889-6	Angle Assembly—Support	1

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-5889-8	Angle Assembly—Support	1
41-5889-10	Angle Assembly—Support	2
BAC1468-10-22S	Screw—82° countersunk recessed flathead	2
BAC1468-10-256	Screw—82° countersunk recessed flathead	4
55-6522	Support Installation—Bomb release	1
55-6522-1	Support Assembly—Bomb release support	1
3-13906	Crank Assembly—Control	1
3-13906-1	Hub Assembly—Control crank	1
1-19827-294	Hub—Tab control	1
BAC1604-152	Spacer—No. ¼ bolt	1
1-19828	Lever—Tab fork	1
1-19828-3	Lever—Tab fork	1
3-12223	Channel Assembly—Handle support	1
41-7800-2	Support Assembly—Switch shield	1
BAC1249-210S	Plate—Fiber nut	1
BAC1604-119	Spacer—No. ¼ bolt	1
BAC1604-38	Spacer—No. ¼ bolt	1
BAC204-61S	Bolt—¼-28 drilled head	1
15-7984	Support Installation—Generator voltage regulator	1
	(Parts List No. 156)	
1-22631	Flange Assembly—Air intake	2
41-7632	Scoop—Ventilation	2
3-11572-1	Support Installation—Emergency bomb release	1
BAC1247-108S	Angle—Nut plate	1
55-5685	Bracket Installation—Control cables LH	1
55-5685-1	Bracket Installation—Control cables RH	1
55-5685-2	Panel Assembly—Control cables bracket LH	1
55-5685-3	Panel Assembly—Control cables bracket RH	1
55-5685-22	Panel Assembly—Control cables bracket LH	1
55-5685-23	Panel Assembly—Control cables bracket RH	1
55-5685-74	Bracket Assembly—Control cables bracket LH	1
55-5685-75	Bracket Assembly—Control cables bracket RH	1
55-5685-417	Bracket Assembly—Control cables bracket LH	1
55-5685-418	Bracket Assembly—Control cables bracket RH	1
55-5685-422	Bracket Assembly—Control cables LH	1
55-5685-423	Bracket Assembly—Control cables RH	1
6-6535	Bracket Installation—Supercharger control	1L
6-6535-6	Bracket Assembly—Supercharger control	1
BAC1603-46	Spacer—No. 10 bolt	2
BAC1604-10	Spacer—¼ bolt	1
6-7847	Bracket Installation—Propeller pitch pulley	1L
6-7847-1	Bracket Assembly—Propeller pitch pulley	1
41-3054-17	Spacer—Angle filler	2
41-8579-4	Fair-lead—Engine control	1
41-8579-5	Fair-lead—Engine control	1
BAC1614-50	Spacer—⅛ rivet	6
BAC1603-28	Spacer—No. 10 bolt	4
6-7852	Bracket Installation—Propeller pitch pulley	1R
6-7852-1	Bracket Assembly—Propeller pitch pulley	1
41-8579-6	Fair-lead—Engine control	1
41-8579-7	Fair-lead—Engine control	1
BAC1614-50	Spacer—⅛ rivet	6
BAC1603-28	Spacer—No. 10 bolt	4
6-7848	Bracket Installation—Mixture pulley	1L
6-7848-1	Bracket Assembly—Mixture pulley	1
41-3054-17	Filler—Angle	2
51-716-138-15	Strip—Rubbing ⅛ fiber	1
BAC1603-48	Spacer—No. 10 bolt	1
BAC1614-48	Spacer—⅛ rivet	3
BAC1603-24	Spacer—No. 10 bolt	2
6-7849	Bracket Installation—Mixture pulley	1L
6-7849-1	Bracket Assembly—Mixture pulley	1
41-3054-17	Filler—Angle	2
BAC1614-48	Spacer—⅛ rivet	3
BAC1603-24	Spacer—No. 10 bolt	2
BAC1603-48	Spacer—No. 10 bolt	1
	(Parts List No. 157)	
9-2946	Bracket Installation—Supercharger control	1L
9-2946-1	Bracket Assembly—Supercharger control	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1614-64	Spacer—⅛ rivet	1
BAC1614-68	Spacer—⅛ rivet	5
BAC1604-18	Spacer—¼ bolt	2
BAC1604-28	Spacer—¼ bolt	2
BAC1604-32	Spacer—¼ bolt	1
6-7850	Bracket Installation—Supercharger pulley	1R
6-7850-1	Bracket Assembly—Supercharger pulley	1
BAC1603-72	Spacer—No. 10 bolt	1
BAC1614-72	Spacer—⅛ rivet	3
6-7850-2	Bracket—Supercharger pulley	1
6-7850-3	Bracket—Supercharger pulley	1
BAC1604-36	Spacer—¼ bolt	2
6-7851	Bracket Installation—Supercharger pulley	1R
6-7851-1	Bracket Assembly—Supercharger pulley	1
BAC1614-40	Spacer—⅛ rivet	6
41-8508-32-6	Fair-lead—Control cable	1
41-8508-32-8	Fair-lead—Control cable	1
6-7851-2	Bracket—Supercharger pulley	1
6-7851-3	Bracket—Supercharger pulley	1
3-13432	Terminal—Compartment structure LH	1
3-13432-1	Terminal—Compartment structure RH	1
15-6047	Bracket Installation—Control cables	1L
15-6047-14	Bracket Assembly—Control cables	1
15-6047-10	Bracket Assembly—Control cables	1
15-6047-11	Bracket Assembly—Control cables	1
15-6047-12	Bracket Assembly—Control cables	1
BAC1602-45	Spacer—No. 8 machine screw	1
BAC1603-45	Spacer—No. 10 bolt	1
9-2948-1	Bracket Installation—Mixture pulley	1R
9-2948-2	Bracket Assembly—Mixture pulley	1
41-3054-17	Filler—Angle	2
BAC1603-52	Spacer—No. 10 bolt	1
BAC1614-52	Spacer—⅛ rivet	2
BAC1603-28	Spacer—No. 10 bolt	1
9-2948-12	Bracket Installation—Mixture pulley	1R
9-2948-7	Bracket Assembly—Mixture pulley	1
41-3054-17	Filler—Angle	2
BAC1614-52	Spacer—⅛ rivet	2
1-19001-111	Fair-lead Assembly—1 hole	1
1-19001-112	Fair-lead—Half	1
1-19001-113	Fair-lead—Half	1
BAC1603-28	Spacer—No. 10 bolt	1
BAC1603-52	Spacer—No. 10 bolt	1
	(Parts List No. 158)	
49-2947	Bracket Installation—Throttle pulley LH	1
49-2947-1	Bracket Installation—Throttle pulley RH	1
49-2947-2	Bracket Assembly—Throttle pulley LH	1
49-2947-3	Bracket Assembly—Throttle pulley RH	1
41-3054-18	Filler—Angle	4
BAC1603-76	Spacer—No. 10 bolt	4
41-8579-2	Fair-lead—Control cable LH	2
41-8579-3	Fair-lead—Control cable RH	2
BAC1604-8	Spacer—¼ bolt	4
BAC1604-36	Spacer—¼ bolt	4
BAC1604-40	Spacer—¼ bolt	4
49-2952	Bracket Installation—Mixture pulley	1R
49-2952-402	Bracket Assembly—Mixture pulley	1
BAC1614-60	Spacer—⅛ rivet	2
BAC1614-62	Spacer—⅛ rivet	1
BAC1614-68	Spacer—⅛ rivet	4
BAC1604-6	Spacer—¼ bolt	1
BAC1604-23	Spacer—¼ bolt	1
BAC1604-33	Spacer—¼ bolt	1
15-6053	Bracket Installation—Control cables	1
15-6053-14	Bracket Assembly—Control cables	1
15-6053-10	Bracket Assembly—Control cables	1
15-6053-11	Bracket Assembly—Control cables	1
15-6053-12	Bracket Assembly—Control cables	1
15-6053-26	Fair-lead—Control cables	1
BAC1603-45	Spacer—No. 10 bolt	1
21-2364-32-8	Spacer—.064 aluminum alloy	2
21-2364-48-13	Washer—.064 aluminum alloy	2

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC324-167-CS	Bushing—Bearing	8
BAC1603-50	Spacer—No. 10 bolt	4
BAC324-4-89CS	Bushing—9/32 OD bearing	16
6162-10Z	Nut Plate—Tinnerman	6
6264-10Z	Nut Plate—Tinnerman	6
65-5000	Bracket Installation—Engine control LH	1
65-5000-1	Bracket Installation—Engine control RH	1
65-5000-400	Support Assembly—Engine control LH	1
65-5000-401	Support Assembly—Engine control RH	1
BAC1249-110S	Nut Plate—Elastic	1R
65-6000-425	Bracket Assembly—Engine control LH	1
65-6000-426	Bracket Assembly—Engine control RH	1
65-6000-431	Bracket Assembly—Engine control LH	1
65-6000-432	Bracket Assembly—Engine control RH	1
15-5991	Bracket Installation—Supercharger control LH	1
15-5991-1	Bracket Installation—Supercharger control RH	1
15-5991-2	Bracket Assembly—Supercharger control LH	1
15-5991-3	Bracket Assembly—Supercharger control RH	1
15-5991-4	Plate Assembly—Top supercharger control bracket LH	1
15-5991-5	Plate Assembly—Top supercharger control bracket RH	1
	(Parts List No. 158A)	
15-5991-6	Plate Assembly—Bottom supercharger control bracket LH	1
15-5991-7	Plate Assembly—Bottom supercharger control bracket RH	1
BAC1603-136	Spacer—No. 10 bolt	16
BAC1604-12	Spacer—¼ bolt	2
BAC1604-36	Spacer—¼ bolt	2
BAC1604-69	Spacer—¼ bolt	2
BAC1604-93	Spacer—¼ bolt	2
BAC1603-96	Spacer—No. 10 bolt	1
BAC1604-101	Spacer—¼ bolt	4
15-5992	Bracket Installation—Carburetor air control	1L
	(Parts List No. 159)	
15-5992-2	Bracket Assembly—Carburetor air control	1
15-5992-4	Plate Assembly—Top carburetor air control bracket	1
15-5992-6	Plate Assembly—Bottom carburetor air control bracket	1
BAC1603-88	Spacer—No. 10 bolt	12
BAC1603-8	Spacer—No. 10 bolt	1
BAC1603-17	Spacer—No. 10 bolt	1
BAC1603-21	Spacer—No. 10 bolt	1
BAC1603-48	Spacer—No. 10 bolt	1
BAC1603-52	Spacer—No. 10 bolt	1
BAC1603-61	Spacer—No. 10 bolt	1
BAC1603-65	Spacer—No. 10 bolt	1
15-6097	Bracket Installation—Carburetor air control	1R
15-6097-1	Bracket Assembly—Carburetor air control	1
15-6097-2	Plate Assembly—Carburetor air control bracket	1
15-6097-3	Plate Assembly—Carburetor air control bracket	1
BAC1603-83	Spacer—No. 10 bolt	9
3-16001-3	Fair-lead Assembly—1 hole	1
3-16001-4	Fair-lead	1
21-2366-28-13	Washer—.091 aluminum alloy	1
BAC1603-24	Spacer—No. 10 bolt	2
BAC1603-44	Spacer—No. 10 bolt	2
BAC1603-62	Spacer—No. 10 bolt	1
BAC1603-64	Spacer—No. 10 bolt	1
15-5993	Bracket Installation—Propeller pitch control LH	1
15-5993-2	Bracket Assembly—Propeller pitch control LH	1
15-5993-4	Plate Assembly—Top propeller pitch control bracket	1
15-5993-6	Plate Assembly—Bottom propeller pitch control bracket	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-8501	Block—Rubbing	1
BAC1603-68	Spacer—No. 10 bolt	1
BAC1614-67	Spacer—⅛ rivet	1
BAC1614-68	Spacer—⅛ rivet	7
BAC1603-24	Spacer—No. 10 bolt	1
BAC1603-25	Spacer—No. 10 bolt	1
BAC1603-45	Spacer—No. 10 bolt	3
15-5993-1	Bracket Installation—Propeller pitch control RH	1
15-5993-3	Bracket Assembly—Propeller pitch control RH	1
15-5993-5	Plate Assembly—Top propeller pitch control bracket	1
15-5993-7	Plate Assembly—Bottom propeller pitch control bracket	1
41-8501	Block—Rubbing	1
BAC1603-68	Spacer—No. 10 bolt	1
BAC1614-67	Spacer—⅛ rivet	1
BAC1614-68	Spacer—⅛ rivet	7
BAC1603-24	Spacer—No. 10 bolt	1
BAC1603-25	Spacer—No. 10 bolt	1
BAC1603-45	Spacer—No. 10 bolt	3
15-5994	Bracket Installation—Throttle control LH	1
15-5994-1	Bracket Installation—Throttle control RH	1
15-5994-2	Bracket Assembly—Throttle control LH	1
	(Parts List No. 160)	
15-5994-3	Bracket Assembly—Throttle control RH	1
15-5994-4	Plate Assembly—Top throttle control bracket LH	1
15-5994-5	Plate Assembly—Top throttle control bracket RH	1
15-5994-6	Plate Assembly—Bottom throttle control bracket LH	1
15-5994-7	Plate Assembly—Bottom throttle control bracket RH	1
BAC1603-72	Spacer—No. 10 bolt	4
BAC1614-72	Spacer—⅛ rivet	12
41-1066-32-16	Washer—.031 corrosive resistant steel	2
BAC1604-35	Spacer—¼ bolt	2
BAC1604-37	Spacer—¼ bolt	6
15-5995	Bracket Installation—Mixture control LH	1
15-5995-1	Bracket Installation—Mixture control RH	1
15-5995-2	Bracket Assembly—Mixture control LH	1
15-5995-3	Bracket Assembly—Mixture control RH	1
15-5995-4	Plate Assembly—Top mixture control bracket LH	1
15-5995-5	Plate Assembly—Top mixture control bracket RH	1
15-5995-6	Plate Assembly—Bottom mixture control bracket LH	1
15-5995-7	Plate Assembly—Bottom mixture control bracket RH	1
41-8501	Block—Rubbing (used on 6 and 7)	2
BAC1603-88	Spacer—No. 10 bolt	14
41-8501	Block—Rubbing	2
BAC1603-24	Spacer—No. 10 bolt	4
BAC1603-45	Spacer—No. 10 bolt	4
BAC1603-59	Spacer—No. 10 bolt	2
BAC1603-63	Spacer—No. 10 bolt	2
BAC1603-65	Spacer—No. 10 bolt	2
41-1818	Angle—Transmitter support	8
1-16283-18	Angle—Stiffener tie	4
1-16283-19	Angle—Stiffener tie	4
51-101	Bracket—Engine control	10
51-101-1	Bracket—Engine control RH	1
51-101-2	Bracket—Engine control LH	1
51-101-3	Bracket—Engine control	4
BAC1603-164	Spacer—No. 10 bolt	14
65-5695	Bracket Installation—Control cables LH	1
65-5695-1	Bracket Installation—Control cables RH	1
65-5695-23	Bracket Assembly—Control cables	2

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1614-32	Spacer—⅛ rivet	4
65-5695-27	Bracket Assembly—Control cables	2
BAC1603-32	Spacer—No. 10 bolt	2
BAC1614-32	Spacer—⅛ rivet	4
65-5695-50	Bracket Assembly—Control cables LH	1
65-5695-51	Bracket Assembly—Control cables RH	1
65-5695-56	Bracket Assembly—Control cables LH	1
65-5695-57	Bracket Assembly—Control cables RH	1
65-5695-518	Bracket Assembly—Control cables LH	1
65-5695-519	Bracket Assembly—Control cables RH	1
21-9379-1	Fair-lead—Rudder cable	4
	(Parts List No. 161)	
41-8345-3	Fair-lead—Control cable	2
41-8345-4	Fair-lead—Control cable	2
1-19001-115	Fair-lead Assembly	1
1-19001-114	Fair-lead—Half	1
1-19001-116	Fair-lead—Half	1
1-19001-45	Fair-lead Assembly	1
1-19001-46	Fair-lead Assembly	1
1-19001-47	Fair-lead Assembly	1
15-7373	Bracket Installation—Oxygen cylinder	1
15-7373-1	Support Assembly—Forward oxygen cylinder bracket	1
1-18114-10-5	Strap Assembly—Clamp	2
1-17559	Hook—Strap end	2
1-18782	Loop—Strap hinge	2
1-17573-7-199	Spacer—Clamp	2
1-18759	Angle—Hinge	2
15-7373-2	Support Assembly—Rear oxygen cylinder bracket	1
1-18114-10-5	Strap Assembly—Clamp	2
1-17559	Hook—Strap end	2
1-18782	Loop—Strap hinge	2
1-17573-7-199	Spacer—Clamp	2
1-18759	Angle—Hinge	2
3-11754-1	Bracket Instrument—Interphone	1
3-11754-4	Bracket Assembly—Interphone	1
41-9622-K75	Rivnut	2
3-11758	Bracket Instrument—Interphone	1
3-11758-3	Bracket Instrument—Interphone	1
3-11758-1	Bracket Assembly—Interphone	2
41-2741-6B	Rivnut—No. 6-32 special	8
6-7091	Bracket Instrument—Emergency bomb release	1
6-7091-4	Bracket Assembly—Emergency bomb release	1
41-9163	Post—$^{3}/_{32}$ flexible cable casing	1
BAC1614-28	Spacer—⅛ rivet	1
21-3894-28-13	Washer—Retaining	1
41-9163	Post—$^{3}/_{32}$ flexible cable casing	1
	(Parts List No. 162)	
BAC1603-7	Spacer—No. 10 bolt	1
BAC1604-8	Spacer—¼ bolt	1
6-7092	Bracket Installation—Emergency bomb release	1
6-7092-12	Bracket Assembly—Emergency bomb release	1
21-6116-32	Angle—½ x ½ aluminum alloy	1
41-5135-1	Angle—Stiffener tie	1
41-9163	Post—$^{3}/_{32}$ flexible cable casing	1
BAC1614-19	Spacer—⅛ rivet	1
6-8567	Bracket Installation—Gun holder	1
6-8567-1	Bracket Assembly—Gun holder	1
1-16465	Spring—Nose gun stowage	1
1-16466	Support—Folding bracket spring	1
3-12473	Bracket—Gun stowage folding	1
6-8567-7	Pad—Gun holder bracket (rubber No. 35)	1
21-3894-48-25	Washer—Retaining	2
BAC1603-6	Spacer—No. 10 bolt	2
8-1062	Bracket Installation—Anti-icer fluid pump	1
8-1062-4	Bracket Assembly—Anti-icer fluid pump	1
14-1767	Bracket Installation—Emergency bomb control	1
14-1767-3	Bracket Assembly—Emergency bomb control	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1614-28	Spacer—⅛ rivet	1
14-1767-7	Bracket Assembly—Emergency bomb control	1
41-9163	Post—3/32 flexible cable casing	1
BAC1614-64	Spacer—⅛ rivet	2
14-1767-8	Plate—Emergency bomb control bracket	1
14-1767-9	Plate—Emergency bomb control bracket	1
14-1767-24	Spacer—Emergency bomb control bracket	1
21-7837	Washer—Square	1
41-9163	Post—3/32 flexible cable casing	5
BAC1603-12	Spacer—No. 10 bolt	2
BAC1603-28	Spacer—No. 10 bolt	2
BAC1603-32	Spacer—No. 10 bolt	2
BAC1603-40	Spacer—No. 10 bolt	1
15-5686-28	Bracket Installation—Control cables RH	1
15-5686-26	Bracket Assembly—Control cables RH	1
BAC1603-43	Spacer—⅛ rivet	1
21-9379-1	Fair-lead—Rudder cable	2
BAC1603-31	Spacer—No. 10 bolt	2
15-7577	Bracket Installation—Oxygen cylinder	1
1-18348	Angle—Tie	2
15-7577-1	Bracket Assembly—Oxygen cylinder	2
1-18114-10-5	Strap Assembly—Clamp	4
1-17559	Hook—Strap end	4
1-18782	Loop—Strap hinge	4
1-17573-7-199	Spacer—Clamp	4
1-18759	Angle—Hinge	4
15-7577-2	Bracket—Oxygen cylinder	2
15-7577-3	Bracket	2
	(Parts List No. 163)	
46-7372	Bracket Installation—Elevator bus LH	1
46-7372-1	Bracket Installation—Elevator bus RH	1
3-10939	Bracket Assembly—Elevator bus LH	1
3-10939-1	Bracket Assembly—Elevator bus RH	1
BAC1614-40	Spacer—⅛ rivet	4
41-3003-40-144	Filler—.125 channel	2
BAC1603-50	Spacer—No. 10 bolt	4
46-7696	Bracket Installation—Ammeter box support	1
46-7696-1	Bracket Assembly—Ammeter box support	1
46-7696-2	Bracket—Ammeter box support	1
46-7696-400	Stiffener Assembly — Ammeter box support bracket	1
1-16283-3	Angle—Stiffener tie	1
41-6063-90-40-1	Angle—9/32 x ¾ aluminum alloy	1
15-6244	Bracket Installation—Hydraulic hand pump	1
3-11887	Bracket—Hydraulic hand pump	1
3-11887-1	Bracket—Hydraulic hand pump	1
21-6685-9	Filler—Angle	3
21-8378-39	Washer—No. 10 square	1
9-3585	Bracket Installation—Accumulator	1
9-3585-1	Unit Assembly—Accumulator bracket	1
7-1640	Bracket Installation—Pilot's bomb release	1
7-1640-3	Bracket Assembly—Pilot's bomb release	1
7-1640-1	Bracket—Pilot's bomb release	1
7-1640-2	Bracket—Pilot's bomb release	1
41-9163	Post—3/32 flexible cable casing	2
BAC1603-72	Spacer—No. 10 bolt	3
BAC1603-9	Spacer—No. 10 bolt	1
BAC1603-43	Spacer—No. 10 bolt	1
15-5686	Bracket Installation—Control cables LH	1
15-5686-25	Bracket Assembly—Control cables LH	1
15-5686-2	Bracket—Control cables	1
15-5686-3	Bracket—Control cables	1
BAC1603-43	Spacer—No. 10 bolt	3
49-2999	Bracket Installation—Mixture pulley	1
6-9584-1	Bracket Assembly—Mixture pulley	1
BAC1614-40	Spacer—⅛ rivet	2
6-9585-1	Bracket Assembly—Mixture pulley	1
BAC1246-10S	Plate—Fiber nut	2
BAC1249-2416S	Plate—Fiber nut	1
BAC1614-40	Spacer—⅛ rivet	2
BAC204-11S	Bolt—Drilled head	1

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 164)	
9-3692	Cover Installation—Aileron control cables LH	1
9-3692-1	Cover Installation—Aileron control cables RH	1
9-3692-2	Air Seal—Aileron control cables cover (Booth felt No. 35 red)	2
9-3690	Cover Assembly—Aileron control cables	1
9-3690-1	Cover Assembly—Aileron control cables	1
1-18821	Bracket Assembly—Aileron cables cover	2
BAC1249-210S	Plate—Fiber nut	3
1-18938	Filler—Aileron cables cover	2
1-18973	Filler—Aileron cables cover	2
BAC1603-14	Spacer—No. 10 bolt	8
65-5931	Cover Installation—Station 3	1
65-5931-1	Cover Assembly—Station 3	1
41-8925-50	Angle—Lining support	1
65-5931-20	Cover Assembly—Station 3	1
41-8925-50	Angle—Lining support	1
65-5931-500	Cover Assembly—Station 3	1
65-5931-501	Support Assembly—Upper cover	1
41-5544	Hook—Lining support	6
65-5931-504	Support Assembly—Lower cover	1
41-5544	Hook—Lining support	5
65-5931-507	Cover Assembly—Station 3	1
65-5931-508	Cover Assembly—Station 3	1
3-13470	Cover—Bulkhead 3	1
65-5931-400	Stud—Machine screw (Black United-Carr Fastener Corp. No. 561)	8
3-11571-1	Post Installation—Emergency bomb release	1
41-9756	Angle—Control support	1
41-9163	Post—3/32 flexible cable casing	1
3-13610	Fair-lead Installation—Driftmeter	1
3-13610-4	Plate Assembly—Retainer	1
BAC1246-10D	Plate—Fiber nut	1
3-14226	Gasket—Driftmeter fair-lead	1
3-13002	Fair-lead Installation—Controls LH	1
3-13002-1	Fair-lead Installation—Controls RH	1
1-19000-5	Fair-lead Assembly—Miscellaneous	2
3-12035	Fair-lead Installation—Fire extinguisher	1
3-12035-3	Fair-lead Assembly—Fire extinguisher	1
3-12035-1	Fair-lead—Hall fire extinguisher	1
3-12035-2	Fair-lead—Hall fire extinguisher	1
	(Parts List No. 165)	
21-4841-60	Jumper Assembly—No. 8-8 terminal bonding	4
BAC820-8	Terminal—Electrical lock	8
64-1694	Patch Installation—Reinforcement station 4 LH	1
64-1694-1	Patch Installation—Reinforcement station 4 RH	1
51-335-48-20	Strip—3/16 fiber	4
BAC1246-10S	Plate—Fiber nut	6R
3-13948	Catch Installation—Door bulkhead 4	1
3-13947-2	Channel Assembly—Door stop	1
21-6744	Fastener—Inspection door	1
1-18689	Angle Installation—Valve support	1
15-7943	Box Installation—Exterior power receptacle	1
15-7943-1	Box Assembly—Exterior power receptacle	1
15-7943-14	Box Assembly—Exterior power receptacle	1
BAC1247-8	Angle—Nut plate	2
15-7943-15	Patch Assembly—Exterior power receptacle box	1
21-6744	Fastener—Inspection door	2
41-353-15-7	Pin—Door catch	2
15-7943-6	Door—Exterior power receptacle box	1
15-7943-13	Hinge—Exterior power receptacle box	1
15-7943-9	Gasket—Exterior power receptacle box (Rubbercraft No. 99)	1
15-7943-16	Cover Assembly—Exterior power receptacle	1
BAC1461	Screw—No. 8-32 non-losable	2
1-17103-6	Angle—Stiffener tie	1
1-17103-7	Angle—Stiffener tie	1
55-3652-405	Step Installation—Station 4 and 5	1
55-3652-1	Step Assembly—Station 4 and 5	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Forward Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-10756-1	Brace—Station 4 step	1
41-1720	Plate—Name bomb door	1
51-626	Plate—Name bomb door warning	1
55-3652-7	Step Assembly—Station 4 and 5	1
55-3652-12	Matting—Station 4 and 5 step (Rubber Goodrich)	1
55-3652-23	Matting—Station 4 and 5 step (Duck)	1
BAC1603-24	Spacer—No. 10 bolt	2
NAS54-DD26.5A	Bolt—Close tolerance	4
NAS54-DD26A	Bolt—Close tolerance	4
46-7921-402	Patch Installation—Plumbing	1
46-7921-403	Patch Installation—Plumbing	1
BAC1247-10S	Angle—Nut plate	1
51-72	Angle—Tube support	2
1-22639	Angle Installation—Tube support	3
1-18890	Angle—Tube support	7
AN4-11A	Bolt	12
365-428	Nut	12
365-832	Nut	8
366F1032	Nut Plate	38
366DF1032	Nut Plate	6

(Parts List No. 166)

AN515-8-10	Screw	8
366F1032	Nut Plate	6
3-13795	Plate—Air ventilator	1

Bulkhead Assembly—Station 3

(Parts List No. 167)

15-9298	Bulkhead Assembly—Station 3	1
15-5683-14	Bracket Installation—Aileron servo	1
15-5683-1	Bracket Assembly—Aileron servo	1
BAC1614-40	Spacer—⅛ rivet	2
15-5683-15	Bracket Assembly—Aileron servo	1
BAC1614-40	Spacer—⅛ rivet	2
BAC1614-50	Spacer—⅛ rivet	1
BAC1614-56	Spacer—⅛ rivet	1
15-6067-11	Support Installation—Control bracket	1
41-8709	Gusset—Control bracket	6
BAC1249-110S	Plate—Fiber nut	1
15-7634	Support Installation—Soundproofing	1
1-18780	Hook—Lining support	22
41-5544	Hook—Lining support	23
41-8925-120	Angle—Lining support	2
37B3822-6B	Rivnut—Threaded	21
37B3822-6C	Rivnut—Threaded	25
37B3822-6K	Rivnut—Threaded	5
37B3822-6X	Rivnut—Threaded	2
6-6426	Bracket Installation—Brake control	4
6-6426-1	Bracket Assembly—Brake control	4
BAC1614-37	Spacer—⅛ rivet	16
BAC1614-46	Spacer—⅛ rivet	32
6-7376	Support Installation—Dome lamp	1
3-10761	Bracket Assembly—Bomb control	1
3-10757	Gusset—Channel tie	1
3-10762	Bracket Assembly—Bomb control	1
3-6562	Angle—Floor beam support	1
21-2367-2	Clip—Stiffener	2
21-2367-3	Clip—Stiffener	1
21-5582	Gusset—Channel tie	14
21-5474	Angle—Bulkhead support	3
21-5474-1	Angle—Bulkhead support	5
41-8031-2	Bracket Assembly—Pilot's air duct	2
21-5615-1	Bracket—Pedal support	6
21-5515	Angle—Stiffener tie	2
21-5581	Gusset—Channel tie	4
21-9148	Bracket—Longeron tie	3
21-9142-2	Gusset—Channel tie	4
21-9142-3	Gusset—Channel tie	2

Bulkhead Assembly—Station 3

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-5941	Bracket—Pedal support brace	1
21-5941-1	Bracket—Pedal support brace	1
41-5741-1	Bracket—Pedal support brace	2
41-5741-2	Bracket—Pedal support brace	4
41-8639	Patch—Air duct	1
41-8868	Spring—Catch	4
41-8380	Angle—Support	1

(Parts List No. 168)

41-5135-1	Angle—Stiffener tie	1
BAC1249-110S	Plate—Fiber nut	6
BAC1246-10S	Plate—Fiber nut	2
BAC1603-16	Spacer—No. 10 bolt	1
BAC1603-57	Spacer—No. 10 bolt	2
21-5617	Angle—Floor tie LH	2
21-5617-1	Angle—Floor tie RH	2
21-5617-2	Angle—Floor tie	2
21-5617-3	Angle—Floor tie	2
75-3423-753	Bracket Assembly—No. 3 bulkhead	4
21-9141	Bracket Assembly—Rudder pedal support	4
75-3423-754	Bracket Assembly—No. 3 bulkhead	1
75-3423-755	Bracket Assembly—No. 3 bulkhead	1
21-5942	Gusset—Pedal support brace	4
21-9141	Bracket Assembly—Rudder pedal support	2
6-10684	Bracket Installation—Oxygen valve support	1
46-4051	Support Installation—Rudder bus cable	1
46-4051-400	Bracket Assembly—Rudder bus cable support LH	1
BAC-346-4-188	Bushing—⅜ staked	1
46-4051-401	Bracket Assembly—Rudder bus cable support	1
BAC-346-4-188	Bushing—⅜ staked	1
14-1823	Bracket Installation—Fire extinguishing control	1
14-1823-1	Bracket Assembly—Fire extinguishing control	1
BAC1614-26	Spacer—⅛ rivet	4
BAC1614-32	Spacer—⅛ rivet	2
BAC1603-72	Spacer—No. 10 bolt	2
14-1823-6	Support Assembly—Fire extinguishing control bracket	1
14-1823-9	Filler—Fire extinguishing control bracket	1
14-1823-10	Filler—Fire extinguishing control bracket	1
BAC1603-16	Spacer	2
BAC1603-56	Spacer—No. 10 bolt	1
BAC1603-8	Spacer—No. 10 bolt	1
BAC1603-48	Spacer—No. 10 bolt	1
41-7024	Spacer—No. 10-32 nut plate	2
1-16283	Angle—Stiffener tie	5
1-16283-1	Angle—Stiffener tie	5
41-1645-63	Angle—Tabulated	2
1-18927	Angle—Splice	1
1-18927-1	Angle—Splice	1
1-18890	Angle—Tube support	1
41-1818	Angle—Transformer support	2
1-19700	Angle Assembly—Air control	2
1-19698	Spring—Air control	2
1-18397	Clip—Stiffener attachment	9
41-8925-28	Angle—Lining support	1

Bulkhead Assembly—Station 4

(Parts List No. 169)

75-3424	Bulkhead Assembly—Station 4	1
15-7372	Door Installation—Station 4 bulkhead	1
15-7372-4	Door Assembly—Station 4 bulkhead	1
51-16	Latch Assembly (N.D.) (Rite Hardware Co.)	1
1-18266-2	Hinge—Half—bulkhead door	3
51-15	Lever—Door latch	2
51-144-1	Spindle—Latch	1
BAC1448-8-8	Screw—Oval head recessed sheet metal	37
BAC1448-10-14	Screw—Oval head recessed sheet metal	12
BAC1449-8-8	Screw—Flathead	2

AVIALOGS.COM

FUSELAGE ASSEMBLY

Bulkhead Assembly—Station 4

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18266-1	Hinge—Half—bulkhead door	3
1-18266-3	Pin—Loose bulkhead door	3
75-3441	Terminal Installation—Front stub spar LH	1
75-3441-1	Terminal Installation—Front stub spar RH	1
57-992	Bracket Installation—Outboard bomb control LH	1
57-992-500	Bracket Installation—Outboard bomb control RH	1
3-12090-6	Crank Assembly—Control	2
3-12088-36-42	Crank—Serrated control	3
BAC450-4	Bearing—Ball control	3
3-7366	Bracket Assembly—Outboard bomb control	1L
3-7366-1	Bracket Assembly—Outboard bomb control	1L
21-9064	Bracket Assembly—Outboard bomb control	1R
21-9064-1	Bracket Assembly—Outboard bomb control	1R
BAC1604-31	Spacer—¼ bolt	2
BAC1604-34	Spacer—¼ bolt	2
6-3851	Terminal—Upper forward station 4 LH	1
6-3851-1	Terminal—Upper forward station 4 RH	1
46-3851-400	Terminal—Upper forward station 4 RH	1
46-3851-401	Terminal—Upper forward station 4 LH	1
46-3852	Terminal—Lower forward station 4	2
56-3852-500	Terminal—Lower forward station 4 LH	1
56-3852-501	Terminal—Lower forward station 4 RH	1
6-3850-6	Fitting Assembly—Shear terminal LH	2
6-3850-7	Fitting Assembly—Shear terminal RH	2
21-5604-3	Washer—Bevel	4
21-6542	Bracket—Box support	4
51-7	Cone—Jacking	2
3-11779	Bracket Installation—Bomb control LH	1
3-11779-1	Bracket Installation—Bomb control RH	1
3-15113	Filler—Truss joint	1
3-15113-1	Filler—Truss joint	1
3-15114	Filler—Truss joint	1
3-15114-1	Filler—Truss joint	1
BAC1614-20	Spacer—⅛ rivet	6
41-9163	Post—Flexible cable casing	2
NAS53-S32A	Bolt—Close tolerance	4
NAS53-32.5A	Bolt—Close tolerance	8
NAS57-S37A	Bolt—Close tolerance	2
NAS57-S44A	Bolt—Close tolerance	12
	(Parts List No. 169A)	
NAS57-S45.5A	Bolt—Close tolerance	10
NAS56-S45.5A	Bolt—Close tolerance	12
NAS56-S40.5A	Bolt—Close tolerance	4
NAS57-S45A	Bolt—Close tolerance	2
NAS57-S42.5A	Bolt—Close tolerance	12
NAS56-DD35.5A	Bolt—Close tolerance	16
NAS56-S44A	Bolt—Close tolerance	6
NAS57-S35.5A	Bolt—Close tolerance	20
	(Parts List No. 170)	
BAC1606-136	Spacer—⅜ bolt	2
BAC1606-148	Spacer—⅜ bolt	2
51-93	Filler—Spar tube	2
51-94	Channel—Compartment strut tie LH	1
51-94-1	Channel—Compartment strut tie RH	1
51-95	Channel—Compartment strut tie LH	1
51-95-1	Channel—Compartment strut tie RH	1
55-4100	Support Installation—Bomb door control LH	1
55-4100-1	Support Installation—Bomb door control RH	1
55-4100-425	Channel Assembly—Bomb door control support LH	1
55-4100-426	Channel Assembly—Bomb door control support RH	1
55-4100-427	Channel Assembly—Bomb door control LH	1
55-4100-428	Channel Assembly—Bomb door control RH	1
3-7838	Support Assembly—Bomb door control LH	1
3-7838-1	Support Assembly—Bomb door control RH	1
3-7838-8	Cup—Bomb door control support Timken bearing No. 07196	2

Bulkhead Assembly—Station 4

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-7838-9	Cup—Bomb door control support Timken bearing No. A-4138	2
51-409	Angle—Tube support LH	1
51-409-1	Angle—Tube support RH	1
14-2062	Support Installation—Soundproofing	1
1-18468-196	Angle—Support	1
41-4323-2	Tab—Lining support	35
37B-3822-6D	Rivnut—Threaded	2
37B-3822-6K	Rivnut—Threaded	13
59-1712	Support Installation—Control pulley LH	1
59-1712-1	Support Installation—Control pulley RH	1
6-4116-7	Bracket Installation—Aileron cable RH	1
21-6893	Bracket Assembly—Aileron cable RH	1
BAC1614-31	Spacer—⅛ rivet	1
6-4115	Bracket Installation—Aileron cable LH	1
3-7000	Bracket Assembly—Aileron cable	1
BAC1614-94	Spacer—⅛ rivet	1
6-4854	Bracket Installation—Control cables	1
6-4854-8	Bracket Assembly—Control cables	1
BAC1613-78	Spacer—$\frac{3}{32}$ rivet	2
6-4854-9	Side Assembly—Control cables bracket LH	1
6-4854-10	Side Assembly—Control cables bracket RH	1
	(Parts List No. 171)	
8-1271	Bracket Installation—Pulleys	1
8-1271-3	Bracket Assembly—Pulleys	2
8-1271-5	Bracket—Pulleys	1
BAC1603-47	Spacer—No. 10 bolt	2
BAC1603-66	Spacer—No. 10 bolt	2
8-1271-1	Spacer—Pulleys bracket	8
8-1271-4	Spacer—Pulleys bracket	2
3-13447	Bracket Assembly—Pulleys	2
BAC1603-31	Spacer—No. 10 bolt	12
3-13447-1	Bracket—Pulleys	1
3-13447-2	Bracket—Pulleys	1
BAC1603-23	Spacer—No. 10 bolt	1
BAC1603-41	Spacer—No. 10 bolt	1
BAC1603-159	Spacer—No. 10 bolt	8
BAC1604-159	Spacer—¼ bolt	6
BAC1603-41	Spacer—No. 10 bolt	1
41-9865	Fair-lead Installation—Flexible casing	1
3-6567	Angle—Longeron tie rear LH	1
3-6567-1	Angle—Longeron tie rear RH	1
3-6567-2	Angle—Longeron tie front RH	1
3-6567-3	Angle—Longeron tie front LH	1
3-7820	Angle—Station 4 bulkhead	1
3-7820-1	Angle—Station 4 bulkhead	1
21-9454	Angle—Catwalk support	1
21-9454-1	Angle—Catwalk support	1
6-3857	Gusset—Lower station 4	1
21-6022	Gusset—Bulkhead No. 4	4
21-5624	Gusset—Bulkhead 4 and 5	4
21-5625	Gusset—Bulkhead 4 and 5	2
6-3857-1	Gusset—Lower station 4	1
21-9892	Gusset—Bulkhead 4	2
21-6041	Clip—Bulkhead No. 4	1
21-6041-1	Clip—Bulkhead No. 4	1
21-6042	Clip—Bulkhead station 4	1
21-6042-1	Clip—Bulkhead station 4	1
21-5626	Clip—Bulkhead 4 and 5	1
21-5626-2	Clip—Bulkhead 4 and 5	2
21-5626-3	Clip—Bulkhead 4 and 5	1
21-5627	Clip—Bulkhead 4 and 5	2
21-5627-2	Clip—Bulkhead 4 and 5	1
21-5633	Clip—Bulkhead 4 and 5	1
21-9520	Clip—Bulkhead 4	2
21-9091	Channel—Bomb control support	1
21-9092	Channel—Bomb control support	1
21-5664-1	Channel—Upper longeron	2
21-7484	Lug—Guard rail	2

AVIALOGS.COM

FUSELAGE ASSEMBLY

Bulkhead Assembly—Station 4

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-9093	Angle—Bomb control support	1
3-6552	Gusset—Upper station 4 and 5	2
41-3034	Angle—Tubing support	2
	(Parts List No. 172)	
BAC115A54S	Bolt—Bearing	4
BAC115A60S	Bolt—Bearing	8
BAC1604-162	Spacer—¼ bolt	1
BAC1604-172	Spacer—¼ bolt	1
1-16464	Angle—Step support	1
1-16464-1	Angle—Step support	2
41-9466	Keeper Installation—Door	1
41-9466-2	Keeper—Door	1
41-9756	Angle—Control support	2
3-11865	Fitting—Support station 4	1
6-8344	Support Installation—Bomb door check LH	1
6-8344-1	Support Installation—Bomb door check RH	1
41-3003-97-48S	Filler—.125 channel	2
41-3005-97-48S	Filler—.188 channel	2
6-8344-2	Channel Assembly—Bomb door check support	1
6-8344-3	Channel Assembly—Bomb door check support	1
7-1518	Bracket Installation—Control cables LH	1
7-1518-11	Bracket Assembly—Control cables	1
7-1518-12	Bracket Assembly—Control cables	1
7-1518-13	Bracket Assembly—Control cables	1
BAC1603-107	Spacer—No. 10 bolt	1
BAC1603-58	Spacer—No. 10 bolt	1
BAC1603-46	Spacer—No. 10 bolt	2
41-4912-7	Angle Installation—Emergency bomb release	1
41-7190	Spring—Cover clamp	1
1-18361	Plate Assembly—Armor attachment	3
1-18356	Plate Assembly—Armor attachment	7
1-18128	Clip—Bulkheads 4 and 5 LH	1
1-18128-1	Clip—Bulkheads 4 and 5 RH	1
1-18236	Clip—Bulkheads 4 and 5 LH	2
1-18236-1	Clip—Bulkheads 4 and 5 RH	2
1-18237	Clip—Bulkhead 4	10
1-18194	Gusset—Bulkheads 4 and 5	4
1-18198	Gusset—Bulkheads 4 and 5	4
1-18234	Gusset—Bulkheads 4 and 5	4
1-18360	Spacer—Armor attachment	3
1-18357	Spacer—Armor attachment	7
1-18431	Angle—Armor attachment	1
1-18890	Angle—Tube support	1
1-19003-5	Fair-lead Assembly—3 holes	1
9-3657	Support Installation—Fire extinguisher bracket	1
3-11864	Fitting—Lower station 4	1
3-13907-2	Bracket—Armor plate	1
3-11865	Fitting—Lower station 4	1
BAC114ADD50	Bolt—Bearing	6
BAC114ADD53	Bolt—Bearing	2
BAC115A51DD	Bolt—Bearing	8
	(Parts List No. 173)	
BAC115ADD54	Bolt—Bearing	8
BAC116ADD55	Bolt—Bearing	21
BAC116A61DD	Bolt—Bearing	14

Bulkhead Assembly—Station 5

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 174)	
85-3425	Bulkhead Assembly—Station 5	1
	Dash number parts, shown on 85-3425 drawing are represented by dash numbers of 75-3425 and 85-3425.	
85-3425-604	Channel Assembly—Station 5 LH	1
85-3425-605	Channel Assembly—Station 5 RH	1
75-3440	Terminal Installation—Rear stub spar LH	1
75-3440-1	Terminal Installation—Rear stub spar RH	1
75-3440-413	Fitting Assembly—Rear stub spar terminal LH	1

Bulkhead Assembly—Station 5

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
75-3440-414	Fitting Assembly—Rear stub spar terminal RH	1
75-3440-506	Filler Assembly—Rear stub spar terminal	1
NAS56-S41.5A	Bolt—Close tolerance	4
BAC1606-144	Spacer—⅜ bolt	2
21-5604-4	Washer—Bevel	4
6-3854	Terminal—Upper station 5 RH	1
6-3854-1	Terminal—Upper station 5 LH	1
NAS56-S13A	Bolt—Close tolerance	2
NAS56-DD35A	Bolt—Close tolerance	8
NAS57-S36.5A	Bolt—Close tolerance	6
21-5604-1	Nut—Bevel washer	4
BAC1606-144	Spacer—⅜ bolt	4
NAS56-DD36.5A	Bolt—Close tolerance	6
41-6310	Patch Installation—Aileron control bracket LH	1
41-6310-1	Patch Installation—Aileron control bracket RH	1
6-6509-2	Bracket Installation—Ailron control cable LH	1
6-6509-3	Bracket Assembly—Aileron control	1
46-6507	Bracket Assembly—Aileron pulley	1
46-6508	Bracket Assembly—Aileron tab pulley	1
1-19001-199	Fair-lead Assembly—1 hole	1
1-19001-198	Fair-lead—Half	1
1-19001-200	Fair-lead—Half	1
1-19001-205	Fair-lead Assembly—1 hole	1
1-19001-204	Fair-lead—Half	1
1-19001-206	Fair-lead—Half	1
1-19001-207	Fair-lead Assembly—1 hole	2
1-19001-208	Fair-lead—1 half	4
BAC1603-80	Spacer—No. 10 bolt	2
6-6509-1	Spacer—Aileron control cable bracket	1
41-5131	Spacer—Aileron tab bracket	1
BAC1603-42	Spacer—No. 10 bolt	1
BAC1604-57	Spacer—¼ bolt	2
6-7032-1	Bracket Installation—Aileron control cable RH	1
6-7032-3	Fair-lead Assembly—Aileron control cable	1
1-19001-201	Fair-lead	1
1-19001-205	Fair-lead	1
1-19001-207	Fair-lead	2
46-6507-1	Bracket Assembly—Aileron pulley	1
46-6508-401	Angle—Aileron tab pulley	1
	(Parts List No. 174A)	
BAC1604-57	Spacer—¼ bolt	2
1-18678	Angle—Rear wing fillet attaching	2
51-336	Angle—Tube support	1
NAS54-S33.5A	Bolt—Close tolerance	4
NAS54-S33A	Bolt—Close tolerance	2
56-3855-500	Terminal—Station 5 lower rear	1
	(Parts List No. 175)	
56-3855-501	Terminal—Station 5 lower rear	1
46-3854-400	Terminal—Station 5 lower rear	1
46-3854-401	Terminal—Station 5 lower rear	1
NAS56-S44A	Bolt—Close tolerance	6
NAS56-S11A	Bolt—Close tolerance	2
46-3855-400	Terminal—Station 5 lower rear	1
46-3855-401	Terminal—Station 5 lower rear	1
6-3856-6	Fitting Assembly—Shear terminal	2
6-3856-7	Fitting Assembly—Shear terminal	2
3-15111	Filler—Truss joint	2
3-15111-1	Filler—Truss joint	2
3-15112	Filler—Truss joint	2
3-15112-1	Filler—Truss joint	2
NAS57-S35A	Bolt—Close tolerance	10
NAS56-S43A	Bolt—Close tolerance	6
NAS56-S41A	Bolt—Close tolerance	4
NAS56-S40.5A	Bolt—Close tolerance	2
NAS56-DD40.5A	Bolt—Close tolerance	6
NAS56-DD43A	Bolt—Close tolerance	2
NAS56-S50.5A	Bolt—Close tolerance	8
NAS56-S46.5A	Bolt—Close tolerance	12
NAS56-S41.5A	Bolt—Close tolerance	6

AVIALOGS.COM

FUSELAGE ASSEMBLY

Bulkhead Assembly—Station 5

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
NAS57-S41.5A	Bolt—Close tolerance	10
NAS57-S43.5A	Bolt—Close tolerance	2
NAS57-S42.5A	Bolt—Close tolerance	2
1-16461	Plate—Terminal reinforcing	4
15-7372-1	Door Installation—Bulkhead 5	1
15-7372-5	Door Assembly—Bulkhead 5	1
15-7372-18	Door Assembly—Wood Bulkhead 5	1
51-16	Latch Assembly—Door no drawing (Rite Hdwe. Co.)	1
51-144-1	Spindle—Latch	1
51-15	Lever—Door latch	2
BAC1449-8-8	Screw—Flathead recessed sheet metal	2
BAC1448-8-8	Screw—Flathead recessed sheet metal	42
BAC1448-10-14	Screw—Oval head recessed sheet metal	12
1-18266-2	Hinge—Half bulkhead door	3
1-18266-1	Hinge—Half bulkhead door	3
1-18266-3	Pin—Loose bulkhead door hinge	3
41-353-15-8	Pin—Door catch	1
41-9466	Keeper Instrument—Door	1
41-9466-2	Keeper—Door	1
49-2002	Support Installation—Bomb door control LH	1
49-2002-1	Support Installation—Bomb door control RH	1
49-2002-410	Clip—Bomb door control support	4
49-2002-411	Channel Assembly—Bomb door control LH	1
49-2002-412	Channel Assembly—Bomb door control RH	1
49-2002-413	Channel Assembly—Bomb door control LH	1
49-2002-414	Channel Assembly—Bomb door control RH	1
49-2002-401	Clip—Bomb door control support	4
3-7838-3	Support Assembly—Bomb door control LH	1
3-7838-4	Support Assembly—Bomb door control RH	1
	(Parts List No. 176)	
3-7838-8	Cup—Bomb door control support (Timken Brg. No. 07196)	2
3-7838-9	Cup—Bomb door control support (Timken Brg. No. A-4138)	2
6-8344	Support Installation—Bomb door check LH	1
6-8344-1	Support Installation—Bomb door check RH	1
41-3003-97-48S	Filler—.125 channel	2
41-3005-97-48S	Filler—.188 channel	2
6-8344-2	Channel Assembly—Bomb door check support	1
6-8344-3	Channel Assembly—Bomb door check support	1
14-2063	Support Installation—Soundproofing bulkhead 5	1
1-18377	Zee—Angle support	12
37B3822-6B	Rivnut	8
37B3822-6E	Rivnut	2
41-2741-6B	Rivnut—No. 6-32 special	3
41-8925-13	Angle—Lining support	1
41-8925-17	Angle—Lining support	1
41-8925-19	Angle—Lining support	1
41-8925-23	Angle—Lining support	1
41-8925-36	Angle—Lining support	2
41-8925-49	Angle—Lining support	3
41-8925-69	Angle—Lining support	1
41-8925-83	Angle—Lining support	1
41-8925-98	Angle—Lining support	1
41-8925-111	Angle—Lining support	1
41-8925-462	Angle—Lining support	1
3-10815	Bracket Assembly—Housing flap control	1
6-8136-4	Shield Installation—Switch	1
41-9981	Shield Assembly—Junction	1
BAC1247-8D	Angle—Nut plate	2
41-9981-2	Cover—Junction shield	1
3-16467	Bracket Installation	1
1-18890	Angle—Tube support	2
3-7817	Angle—Bulkhead station 5 LH	1
3-7817-1	Angle—Bulkhead station 5 RH	1
1-17240	Channel—Bomb hoist support	1
21-5508	Channel—Radio table support	1
21-5664-1	Channel—Upper longeron	2
1-18128	Clip—Bulkhead 4 and 5 LH	1
1-18128-1	Clip—Bulkhead 4 and 5 RH	1

Bulkhead Assembly—Station 4

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18200	Clip—Bulkhead 5	2
1-18236	Clip—Bulkhead 4 and 5	2
1-18236-1	Clip—Bulkhead 4 and 5	2
1-18237	Clip—Bulkhead 4 and 5	8
1-18194	Gusset—Bulkhead 4 and 5	4
1-18195	Gusset—Bulkhead 4 and 5	4
1-18235	Gusset—Bulkhead 5	4
3-6552	Gusset—Upper station 4	2
6-3842-1	Gusset—Lower station 5	2
	(Parts List No. 177)	
21-5624	Gusset—Bulkhead 4 and 5	20
21-5624-2	Gusset—Bulkhead 4 and 5	2
21-5656-1	Gusset—Bulkhead 5	4
21-7484	Lug—Guard rail	1
21-7512	Lug—Guard rail	1
41-63	Lug—Bomb hoist	2
41-63-1	Lug—Bomb hoist	2
3-11857	Fitting—Upper station 5	1
3-11867	Fitting—Lower station 5	1
21-5626	Clip—Bulkhead 4 and 5	3
1-18198	Gusset—Bulkhead 4 and 5	4
6-10123	Fair-lead Installation—Bulkhead 5	1
1-19000-7	Fair-lead Assembly—8 holes	1
1-19000-8	Fair-lead—8 holes	1
1-19000-9	Fair-lead—8 holes	1
1-19006-1	Fair-lead Assembly—Miscellaneous	1
1-19006-2	Fair-lead—Miscellaneous	1
1-19006-3	Fair-lead—Miscellaneous	1
NAS55A33.5	Bolt—Close tolerance	4
NAS54A32.5DD	Bolt—Close tolerance	6
NAS55A33.5	Bolt—Close tolerance	4
NAS54A33.5DD	Bolt—Close tolerance	4
NAS55A33.5DD	Bolt—Close tolerance	6
NAS55A36.5	Bolt—Close tolerance	8
NAS56A34.5DD	Bolt—Close tolerance	16
NAS56A40DD	Bolt—Close tolerance	10
NAS53A-33DD	Bolt—Close tolerance	4
BAC1603-37	Spacer—No. 10 bolt	2
BAC1603-172	Spacer—No. 10 bolt	4
BAC1247-10S	Angle—Nut plate	2
BAC1246-10D	Plate—Fiber nut	2
BAC115A-51DD	Bolt—5/16-24 bearing	4
NAS56A37.5DD	Bolt—Close tolerance	6

Floor Installation—Pilots

	(Parts List No. 178)	
75-3513	Floor Installation—Pilot's	1
75-3513-600	Floor Assembly—Pilot's	1
75-3513-601	Sidewall Assembly—Pilot's floor LH	1
75-3513-607	Channel Assembly—Pilot's floor	1
75-3513-626	Channel Assembly—Pilot's floor	1
75-3513-628	Angle Assembly—Pilot's floor	1
1-18605	Angle Assembly—Forward radio junction support	1
75-3513-602	Sidewall Assembly—Pilot's floor RH	1
75-3513-607	Channel Assembly—Pilot's floor	2
75-3513-620	Channel Assembly—Pilot's floor	2
75-3513-622	Channel Assembly—Pilot's floor	1
75-3513-626	Channel Assembly—Pilot's floor	1
75-3513-629	Angle Assembly—Pilot's floor	1
1-18890	Angle—Tube support	2
1-18890-1	Angle—Tube support	1
75-3513-639	Channel Assembly—Pilot's floor	1
75-3513-642	Zee Assembly—Pilot's floor	1
75-3513-648	Sheet Assembly—Pilot's floor	1
3-10755	Pan Installation—Lock control lever LH	1
3-10755-1	Pan Installation—Lock control lever RH	1
7-1523	Beam Installation—Pilot's floor	1
7-1523-1	Beam Assembly—Pilot's floor	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Floor Installation—Pilots

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
8-1281	Beam Installation—Pilot's floor	1
8-1281-13	Beam Assembly—Pilot's floor	1
8-1274	Beam Assembly—Pilot's floor inboard LH	1
8-1274-1	Beam Assembly—Pilot's floor inboard RH	1
8-1275	Beam Assembly—Pilot's floor outboard LH	1
8-1275-1	Beam Assembly—Pilot's floor outboard RH	1
6-9358	Bracket—De-icer valve	1L
8-1275-12	Clip—Pilot's floor outboard beam	1
48-1073	Beam Assembly—Pilot's floor	1
48-1073-412	Channel Assembly—Pilot's floor beam	1
48-1073-413	Channel Assembly—Pilot's floor beam	1
55-6083	Bracket Installation—Carburetor air control	1
55-6083-405	Bracket Assembly—Middle carburetor air control	1
55-6083-406	Bracket Assembly—Inboard carburetor air control	1
1-19001-29	Fair-lead Assembly—1 hole	1
1-19001-28	Fair-lead—1 hole	1
1-19001-30	Fair-lead—1 hole	1
BAC1603-77	Spacer—No. 10 bolt	2
BAC1603-86	Spacer—No. 10 bolt	1
BAC1603-163	Spacer—No. 10 bolt	2
BAC1604-6	Spacer—¼ bolt	1
BAC1604-28	Spacer—¼ bolt	1
BAC1604-34	Spacer—¼ bolt	1
BAC1604-39	Spacer—¼ bolt	1
BAC1604-51	Spacer—¼ bolt	1
	(Parts List No. 179)	
9-3032	Bracket Installation—Carburetor air control	1
9-3032-1	Bracket Assembly—Carburetor air control	1
BAC1603-84	Spacer—No. 10 bolt	2
9-3032-2	Bracket—Carburetor air control	1
9-3032-4	Bracket—Carburetor air control	1
9-2765-12	Bracket Installation—Control cables	1
21-9379-1	Fair-lead—Rudder cables	2
BAC1614-8	Spacer—⅛ rivet	3
9-2764-10	Bracket Installation—Control cables	1
9-2764-1	Bracket Assembly—Control cables	1
21-9379-1	Fair-lead—Rudder cable	2
BAC1614-8	Spacer—⅛ rivet	3
6-4856	Bracket Assembly—Rudder tab	1
9-2763	Bracket Installation—Control cables	1
9-2763-1	Bracket Assembly—Control cables	1
41-8541-39-44	Fair-lead—¼ thick fiber tab	2
BAC1603-32	Spacer—No. 10 bolt	2
BAC1614-8	Spacer—Bearing	3
9-2762	Bracket Installation—Control cables	1
9-2762-1	Bracket Assembly—Control cables	1
BAC1247-10S	Angle—Nut plate	1
41-8541-30-44	Fair-lead—¼ thick fiber tab	2
BAC1603-32	Spacer—No. 10 bolt	2
BAC1604-8	Spacer—¼ bolt	3
9-2984	Bracket Installation—Carburetor air control	1
9-2984-1	Bracket Assembly—Carburetor air control	1
BAC1603-68	Spacer—No. 10 bolt	2
41-3003-68-48	Filler—.125 channel	6
BAC1603-24	Spacer—No. 10 bolt	1
BAC1603-25	Spacer—No. 10 bolt	1
BAC1603-45	Spacer—No. 10 bolt	2
BAC1603-68	Spacer—No. 10 bolt	1
7-1533	Bracket Installation—Vacuum control	1
7-1533-1	Bracket Assembly—Vacuum control	1
BAC1603-88	Spacer—No. 10 bolt	2
41-8802-56-23	Fair-lead—Half—⅛ cable	2
BAC1603-42	Spacer—No. 10 bolt	1
49-2015	Bracket Installation—Control cables LH	1
49-2015-1	Bracket Installation—Control cables RH	1
BAC1614-30	Spacer—⅛ rivet	1L
BAC1614-42	Spacer—⅛ rivet	2R
15-7527	Fair-lead Installation—Engine cable	1
41-8802-56-22	Fair-lead—Half—⅛ cable	10

Floor Installation—Pilots

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-8802-56-24	Fair-lead—Half—⅛ cable	2
41-8802-56-25	Fair-lead—Half—⅛ cable	2
	(Parts List No. 180)	
41-8802-56-28	Fair-lead—Half—⅛ cable	50
BAC1603-8	Spacer—No. 10 bolt	2
15-6014-26	Cover Installation—Control cables	1
15-6014-1	Cover—Control cables	1
15-6014-2	Cover—Control cables	1
15-6014-3	Angle Assembly—Control cables cover	1
BAC1246-10S	Plate—Fiber nut	1
15-6014-6	Angle Assembly—Control cables cover	1
15-6014-8	Angle Assembly—Control cables cover	1
BAC1246-10S	Plate—Fiber nut	2
15-6014-9	Angle Assembly—Control cables cover	1
BAC1249-110S	Plate—Fiber nut	2
15-6014-19	Angle Assembly—Control cables cover	1
15-6014-22	Angle Assembly—Control cables cover	1
BAC1249-110S	Plate—Fiber nut	1
9-2771	Collar Installation—Control column boot LH	1
9-2771-1	Collar Installation—Control column boot RH	1
9-2771-10	Collar Assembly—Control column boot LH	1
9-2271-11	Collar Assembly—Control column boot RH	1
3-11582-7	Fair-lead Installation—Carburetor air control	1
3-11582-9	Fair-lead Assembly—Carburetor air control	1
3-11582-4	Fair-lead—Carburetor air control	1
3-11582-5	Fair-lead—Carburetor air control	1
3-11582-6	Fair-lead—Carburetor air control	1
3-13553	Plate—Pilot's floor	1
1-19837	Plate Assembly—Top turret support	2
1-18432	Fitting—Pilot's seat	2
1-18432-1	Fitting—Pilot's seat	2
41-9763	Angle—Stiffener tie	3
41-9763-1	Angle—Stiffener tie	1
BAC1249-110S	Plate—Fiber nut	8
41-8582	Angle—Beam support	1
41-8582-1	Angle—Beam support	1
75-3513-649	Floor Assembly—Pilot's	1
6-7791-21	Bracket Installation—Supercharger and mixture control LH	1
6-7791-22	Bracket Installation—Supercharger and mixture control RH	1
3-11133-22	Pulley Assembly—Engine controls	1L
3-11133-11	Pulley Assembly—Engine controls	1
3-11133-25	Pulley—Engine control	1
21-2364-71-48	Washer—.064 aluminum alloy	1
BAC1807-92-0L	Cable Assembly—3/32—7 x 7 control	1
	(Parts List No. 181)	
BAC1807-112-0L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	2
BAC1828-34	Terminal—Dead end cable	2
3-12038-3	Pulley Assembly—Engine control	1R
3-12038-1	Pulley Assembly—Engine control	1
3-12038-4	Pulley—Engine control	1
21-2364-71-48	Washer—.064 aluminum alloy	1
BAC1807-112-3L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-117-7L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	2
BAC1828-34	Terminal—Dead end cable	2
21-9594	Bracket Installation—Floor stiffener LH	1
21-9594-1	Bracket Installation—Floor stiffener RH	1
8-1292	Beam Assembly—Pilot's floor—inboard LH	1
8-1292-1	Beam Assembly—Pilot's floor—inboard RH	1
1-20203	Channel—Floor beam	1L
1-20203-1	Channel—Floor beam	1R
1-20204	Channel—Floor beam	1L
1-20204-1	Channel—Floor beam	1R
41-9763	Angle—Stiffener tie	6
BAC1615-21	Spacer—5/32 rivet	2
8-1294	Beam Assembly—Pilot's floor—outboard RH	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Floor Installation—Pilots

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
8-1294-1	Beam Assembly—Pilot's floor—outboard LH	11
1-20203	Channel—Floor beam	1R
1-20203-1	Channel—Floor beam	1L
1-20204	Channel—Floor beam	1R
1-20204-1	Channel—Floor beam	1L
41-9763	Angle—Stiffener tie	4
BAC1615-21	Spacer—5/32 rivet	2
3-10750	Support Installation—Lock lever LH	1
3-10750-1	Support Installation—Lock lever RH	1
3-10750-11	Bracket Assembly—Lock lever support	1L
3-10750-14	Bracket Assembly—Lock lever support	1L
41-7083	Quadrant—Lock lever	2
3-10750-10	Bracket Assembly—Lock lever support	1R
3-10750-15	Bracket Assembly—Lock lever support	1R
41-7083-1	Quadrant—Lock lever	2
75-3513-504	Door Assembly—Pilot's	1
75-3513-65	Felt—Pilot's floor (booth No. 61)	3
75-3513-132	Ring—Key—pilot's floor (Seattle Hardware Co.)	1
75-3513-531	Mat—Rubber—pilot's floor (Goodrich)	1
75-3513-532	Mat—Rubber—pilot's floor (Goodrich)	1
75-3513-619	Felt—Pilot's floor (booth No. 61)	1
75-3513-633	Felt—Pilot's floor (booth No. 61)	2
21-9434-1	Plunger—Door latch	1
21-9438-5	Gusset—Floor corner	4
21-9689	Spring—Compression	1
	(Parts List No. 182)	
51-236	Knob—Door latch	2
51-285	Guide—Door latch	2
51-286	Stop—Door latch	1
75-3513-655	Tee Assembly—Pilot's floor	1
75-3513-657	Tee Assembly—Pilot's floor	1
55-5832	Bracket Installation—Aileron tab and de-icer control	1
41-7816-1	Fair-lead—De-icer valve rod	1
41-7957-10-34	Angle—Support	1
41-7957-10-75	Angle—Support	1
6264-10Z	Speednut—Special (Tinnerman Prod. Inc., 2048 N. W. Fulton Road, Cleveland, Ohio)	1
9-5204-8	Decalcomania	1
9-5204-12	Decalcomania	1
BAC1246-10S	Plate—Fiber nut	2
BAC1249-210S	Plate—Fiber nut	2
49-3037	Bracket Installation—Carburetor air control	1
49-3037-400	Bracket Assembly—Carburetor air control	1
BAC1246-10S	Plate—Fiber nut	1
BAC1614-28	Spacer—1/8 rivet	2
9-3615	Bracket Installation—Control pulley LH	1
9-3615-1	Bracket Installation—Control pulley RH	1
9-3615-2	Bracket Assembly—Control pulley LH	1
9-3615-3	Bracket Assembly—Control pulley RH	1
BAC1603-46	Spacer—No. 10 bolt	3L
21-2362-49-14	Washer—.050 aluminum alloy	16
BAC1603-65	Spacer—No. 10 bolt	4
BAC1603-27	Spacer—No. 10 bolt	2R
6-7855	Bracket Installation—Aileron tab control	1
6-7855-1	Bracket Assembly—Aileron tab control	1
BAC1614-46	Spacer—1/8 rivet	1
15-6013	Bracket Installation—Elevator tab control	1
15-6013-1	Support Assembly—Elevator tab control	1
15-5013-2	Bracket Assembly—Elevator tab control	1
21-6730-28-18	Spacer—5/16 micarta	1
BAC1614-28	Spacer—1/8 rivet	3
15-6013-3	Bracket Assembly—Elevator tab control LH	1
15-6013-4	Bracket Assembly—Elevator tab control RH	1
BAC1603-28	Spacer—No. 10 bolt	1
BAC1603-34	Spacer—Elevator tab control bracket	1
46-7880	Guard Installation—Supercharger and mixture control LH	1
46-7880-1	Guard Installation—Supercharger and mixture control RH	1

Floor Installation—Pilots

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
46-7880-400	Guide Assembly—Supercharger and mixture control	1
46-7880-401	Guide Assembly—Supercharger and mixture control	1
46-7880-402	Base Assembly—Supercharger and mixture control guard	1
46-7880-403	Base Assembly—Supercharger and mixture control guard	1
	(Parts List No. 183)	
65-5787	Sidewall Installation—Cockpit LH	1
65-5787-500	Sidewall Assembly—Cockpit	1
65-5787-503	Channel Assembly—Cockpit sidewall	1
BAC1246-10S	Plate—Fiber nut	1
65-5787-505	Channel Assembly—Cockpit Sidewall	1
BAC1246-10S	Plate—Fiber nut	1
65-5787-507	Channel Assembly—Cockpit sidewall	1
65-5787-508	Channel Assembly—Cockpit sidewall	1
51-384	Channel Assembly—Cockpit sidewall	1
51-385	Channel Assembly—Cockpit sidewall	6
46-7631-406	Pan Assembly—Jack box recess	1
1815-M-1	Nut—Speed (Tinnerman Prods., Inc., 2048 N. W. Fulton Road, Cleveland, Ohio)	7
65-5787-524	Angle Assembly—Cockpit sidewall	1
65-5787-525	Angle Assembly—Cockpit sidewall	1
BAC1246-6D	Plate—Fiber nut	1
65-5787-526	Angle Assembly—Cockpit sidewall	1
65-5787-527	Angle Assembly—Cockpit sidewall	1
65-5787-528	Angle Assembly—Cockpit sidewall	1
65-5787-529	Angle Assembly—Cockpit sidewall	1
65-5787-533	Channel Assembly—Cockpit sidewall	1
BAC1246-10S	Plate—Fiber nut	1
65-5787-535	Channel Assembly—Cockpit sidewall	1
BAC1246-10S	Plate—Fiber nut	1
37B3822-6B	Rivnut	2
37B3822-6E	Rivnut	2
41-4764	Angle—Reinforcing	5
BAC1246-10S	Nut Plate—One lug	2
1-18544	Angle—Sidewall Installation	4
41-8089	Clip—String support	26
41-8925-477	Angle—Lining support	1
BAC1246-10S	Plate—Fiber nut	2
BAC1246-6D	Plate—Fiber nut	2
75-5788	Sidewall Installation—Cockpit RH	1
75-5788-600	Sidewall Assembly—Cockpit	1
75-5788-503	Angle Assembly—Cockpit sidewall	1
75-5788-504	Channel Assembly—Cockpit sidewall	2
BAC1246-10S	Plate—Fiber nut	2
75-5788-515	Angle Assembly—Cockpit sidewall	1
75-5788-525	Angle Assembly—Cockpit sidewall	1
75-5788-602	Channel Assembly—Cockpit sidewall	1
75-5788-605	Channel Assembly—Cockpit sidewall	1
75-5788-606	Channel Assembly—Cockpit sidewall	1
75-5788-609	Channel Assembly—Cockpit sidewall	1
	(Parts List No. 183A)	
9-2928	Bracket Installation—Engine primer	1
9-2928-9	Bracket Assembly—Engine primer	1
1-25553	Decalcomania—Fluorescent	1
9-5042	Bracket—Engine primer	1
BAC1249-210S	Plate—Fiber nut	1
51-384	Channel Assembly—Cockpit sidewall	1
51-385	Channel Assembly—Cockpit sidewall	2
46-7631-405	Pan Assembly—Jack box recess	1
1815-M-1	Nut—Speed (Tinnerman Prods., Inc., 2048 N. W. Fulton Road, Cleveland, Ohio)	7
41-4764	Angle—Reinforcing	3
41-8925-118	Angle—Lining support	1
41-8925-160	Angle—Lining support	1
41-1818	Angle—Trans. support	1
1-18544	Angle—Sidewall Installation	2
41-8089	Clip—String support	22

AVIALOGS.COM

FUSELAGE ASSEMBLY

Floor Installation—Pilots

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 184)	
41-8925-19	Angle—Lining support	1
41-8925-47	Angle—Lining support	1
41-8925-510	Angle—Lining support	1
6-9296	Floor Assembly—Pilot's center	1
6-9296-1	Panel Floor—Pilot's center	1
BAC1906-2	Washer—F.H. screw wood	10
BAC1449-6-6	Screw—F.H. recessed sheet metal	2
8-1290	Floor—Pilot's outboard	1
8-1290-1	Floor—Pilot's outboard	1
8-1290-2	Floor—Pilot's outboard	1
8-1290-3	Floor—Pilot's outboard	1
1-18823	Angle—Pilot's floor LH	1
1-18823-1	Angle—Pilot's floor RH	1
1-25577	Angle	2
41-8925-223	Angle—Lining support	2
3-7854	Fitting—Pilot's seat—outboard	4
6-10763	Support Installation—Spare whip antenna	1
6-10763-2	Plate Assembly—Spare whip antenna support	1
3-15136	Bracket Assembly—Spare whip antenna	1
3-15136-1	Bracket—Spare whip antenna	1
3-14971	Bracket Installation—Idler pulley	1
3-14971-3	Bracket Assembly—Idler pulley	1
BAC1603-65	Spacer—No. 10 bolt	1
3-14971-4	Bracket Assembly—Idler pulley	1
BAC1603-88	Spacer—No. 10 bolt	1
21-2362-49-14	Washer—.050 aluminum alloy	10

Floor Installation—Radio and Gunners

	(Parts List No. 185)	
75-3577	Floor Installation—Radio and gunners	1
75-3577-618	Door Assembly—Radio and gunners	1
BAC1449-8-14	Screw—Flathead recessed	6
43-11261-400	Support Installation—Intervolometer	1
43-11261-403	Bracket Assembly—Intervolometer support	1
BAC1616-5	Spacer—3/16 rivet	1
41-8273	Spring—Torsion	1
41-9812	Brace Assembly—Camera door	1
41-9477	Hook—Camera door brace	1
3-13740-1	Latch Installation—Camera hatch	1
3-13740-3	Latch Assembly—Camera hatch	1
1-18578	Spindle Assembly—Camera hatch latch	1
1-18578-1	Pin—Camera hatch latch spindle	1
1-18578-2	Pin—Camera hatch latch spindle	1
1-18388	Cap—Camera hatch latch	1
1-18448	Spindle—Camera hatch latch	1
1-18849	Handle Assembly—Camera hatch latch	1
1-18462	Plate Assembly—Camera hatch latch	1
1125	Latch—Door (Daton Mfg. Co., Dayton, Ohio)	1
BAC1447-8-14	Screw—Roundhead recessed sheet metal	4
75-3577-602	Panel—Radio and gunner's floor	1
75-3577-603	Bracket—Radio and gunner's floor	1
75-3577-634	Matting—Radio and gunner's floor rubber (Goodrich)	1
75-3577-661	Hinge—Radio and gunner's floor	3
48444	Nut—Radio and gunner's floor	9
BAC1449-8-16	Screw—Flathead recessed	16
BAC1907-3D	Washer—82° countersunk	16
BAC1907-9D	Washer—82° countersunk	8
75-3577-622	Channel Assembly—Radio and gunner's floor	1
75-3577-623	Channel Assembly—Radio and gunner's floor	1
75-3577-620	Panel Assembly—Aft radio and gunner's floor	1
41-4858	Washer—No. 10 flathead screw	8
75-3577-604	Panel—Radio and gunner's floor	1
75-3577-629	Matting—Radio and gunner's floor rubber (Goodrich)	1
75-3577-647	Felt—Radio and gunner's floor (booth No. 61)	1
75-3577-648	Felt—Radio and gunner's floor (booth No. 61)	1

Floor Installation—Radio and Gunners

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
75-3577-633	Panel Assembly—Forward radio and gunner's floor	1
75-3577-600	Panel—Radio and gunner's floor	1
75-3577-632	Matting—Radio and gunner's floor rubber (Goodyear)	1
75-3577-637	Felt—Radio and gunner's floor (booth No. 61)	1
75-3577-650	Felt—Radio and gunner's floor (booth No. 61)	1
75-3577-651	Felt—Radio and gunner's floor (booth No. 61)	1
75-3577-653	Panel Assembly—Radio and gunner's floor	1
41-4858	Washer—No. 10 flathead screw	42
6-9702	Support Installation—Modulator	1
6-9702-1	Plate Assembly—Modulator support	2
BAC1447-6-4	Screw—Roundhead recessed	10
	(Parts List No. 186)	
75-3577-605	Nut—Radio and gunner's floor (United Carr Fastener No. 48444)	8
75-3577-609	Plate—Radio and gunner's floor	2
75-3577-616	Panel—Radio and gunner's floor	1
75-3577-619	Matting—Radio and gunner's floor (Goodrich)	1
75-3577-645	Felt—Radio and gunner's floor (booth No. 61)	1
75-3577-654	Panel Assembly—Radio and gunner's floor	1
41-4858	Washer—No. 10 flathead screw	53
75-3577-601	Panel—Radio and gunner's floor	1
75-3577-607	Matting—Radio and gunner's floor rubber (Goodrich)	1
75-3577-605	Nut—Radio and gunner's floor (United Carr Fastener No. 48444)	4
75-3577-609	Plate—Radio and gunner's floor	1
75-3577-645	Felt—Radio and gunner's floor (booth No. 61)	1
75-3577-646	Felt—Radio and gunner's floor (booth No. 61)	1
75-3686	Door Installation—Camera and finder	1
3-7022	Bracket Assembly—Camera support LH	1
3-7022-1	Bracket Assembly—Camera support RH	1
21-7020	Trigger—Camera mount lock	2
21-7021	Spring—Camera mount lock	2
3-9095	Bracket Assembly—Photographer's belt	1
41-164	Washer—Bolt attachment	2
3-9799-9	Lever Assembly—Camera door control	1
3-9799-10	Lever Assembly—Camera door control	1
41-8596	Lever Assembly—Lock	1
41-7909	Tube—Lock lever	1
41-7916	Plug—Lock lever	2
41-2399	Spring—Compression	1
41-8427	Plug—Lock lever	1
41-7808-3	Knob Assembly—Lock lever	1
41-9779	Bearing—Torque tube	4
21-7007-5	Crank Assembly—Camera door control	1
21-7007-6	Crank Assembly—Camera door control	1
3-6738-5	Bolt Assembly—Self-locking	4
3-6738-6	Bolt Assembly—Self-locking	4
3-6738-3	Spring—Self-locking belt	2
3-6738-7	Bolt—Self-locking belt (used -5)	1
3-6738-8	Bolt—Self-locking belt (used -6)	1
3-6738-17	Ring—Self-locking belt (Pacific Marine Supply)	2
1-16283	Angle—Stiffener tie	6
1-16283-1	Angle—Stiffener tie	7
21-7008-5	Link—Camera door control	2
21-7013	Bracket—Camera support LH	1
21-7013-1	Bracket—Camera support RH	1
21-7030-1	Link—Camera door control	1
3-7012	Support—Camera pit floor	1
3-7012-1	Support—Camera pit floor	1
	(Parts List No. 187)	
3-7012-2	Support—Camera pit floor	1
15-7588-1	Cradle Installation—Oxygen cylinder	1
15-7586-2	Cradle Installation—Oxygen cylinder	1
15-7586-3	Cradle Assembly—Oxygen cylinder	4
1-18759	Angle—Hinge	8
1-17673-7-199	Spacer—Clamp	8

AVIALOGS.COM

FUSELAGE ASSEMBLY

Floor Installation—Radio and Gunners

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18114-9-8	Strap Assembly—Clamp	8
1-17559	Hook—Strap end	16
1-18782	Loop—Strap hinge	16
41-5456	Sector—Camera door control	1
41-5580	Spacer—Camera door control	2
41-306	Angle—Stiffener tie LH	12
41-306-1	Angle—Stiffener tie RH	14
21-6578-0-5	Angle—½ x ⅝ x .040	10
21-9221	Spacer—Nut plate	14
41-6063-90-40	Angle—9/16 x ¾ aluminum alloy	2
41-6063-90-40-1	Angle—9/16 x ¾ aluminum alloy	2
073410	Ring Installation—Vertical view finder	1
BAC1603-71	Spacer—No. 10 bolt	1
BAC1603-9	Spacer—No. 10 bolt	2
75-3686-522	Door Assembly—Camera finder LH	1
75-3686-523	Door Assembly—Camera finder RH	1
75-3686-525	Door—Camera finder	2
75-3686-544	Felt—Camera finder door (booth No. 9)	1L
75-3686-643	Hinge—Camera finder door	2
1-20383	Plate—Latch	2R
21-7010-1	Terminal—Camera door control RH	2
75-3686-17	Door Assembly—View finder	1
75-3686-646	Door—Camera finder	1
75-3686-634	Hinge—Camera finder door	1
21-7009-1	Terminal—Sight door control	1
75-3686-500	Floor Assembly—Camera and finder door	1
75-3686-501	Floor—Camera finder door	1
41-9778	Name Plate—Camera door	1
65-3686-405	Seat Assembly—Camera finder door	1
21-5474-5	Angle—Bulkhead support	8
75-3686-602	Beam Assembly—Camera and finder LH	1
75-3686-603	Beam Assembly—Camera and finder RH	1
21-6327	Angle—Floor beam	8
21-7001	Angle—Floor beam	8
41-3002-59-80	Filler—.091 channel (used on -602 only)	2
75-3686-609	Floor Assembly—Camera finder	1
75-3686-537	Floor—Camera finder door	1
1-17351	Angle—Stiffener tie	3
1-17351-1	Angle—Stiffener tie	3
1-17351-2	Angle—Stiffener tie	8
1-17351-3	Angle—Stiffener tie	8
1-17507	Stud—Camera door control	2
1-18415	Tube Assembly—Torque	2
1-18414-19-11	Stud—No. ¼-28 thread	2
	(Parts List No. 188)	
41-1818	Angle—Trans. support	8
51-226-32	Spacer—Tube	2
51-226-24	Spacer—Tube	1
1-20382	Latch—Camera door	1
1-20382-1	Latch—Camera door	1
75-3686-400	Washer—Camera and finder door	1
75-3686-441	Felt—Camera and finder door	1
75-3686-442	Felt—Camera and finder door	1
75-3686-545	Felt—Camera and finder door	2
75-3686-546	Felt—Camera and finder door	2
46-4128	Bracket Installation—Aileron bus cable	1
21-5474-5	Angle—Bulkhead support	3
46-4128-402	Bracket Assembly—Aileron bus cable	1
BAC1603-32	Spacer—No. 10 bolt	2
BAC1603-62	Spacer—No. 10 bolt	1
6-9345	Cover Installation—Aileron control cables LH	1
6-9345-1	Cover Installation—Aileron control cables RH	1
6-9345-2	Cover—Aileron control cables LH	1
6-9345-3	Cover—Aileron control cables RH	1
41-1066-40-13	Washer—.031 corrosive resistant steel	36
3-13740-2	Keeper Installation—Camera hatch	1
1-18881	Channel—Latch keeper	1
41-5997	Spring Assembly—Camera door brace	1
41-5997-1	Spring—Camera door brace	1
41-5997-2	Spacer—Camera door brace spring	1
3-11852	Bearing Installation—Crank flap control	1

Floor Installation—Radio and Gunners

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-11852-5	Bearing Assembly—Crank flap control	1
3-11852-7	Housing—Crank flap control bearing	1
3-11852-3	Bushing—Crank flap control bearing (Olite A-1323)	1
3-11852-4	Spacer—Crank flap control bearing	1
3-11852-6	Spacer—Crank flap control bearing	1
21-6328	Gusset—Floor beam	2
1-18637	Angle—Floor beam	2
1-18637-1	Angle—Floor beam	2
1-18890	Angle—Floor beam	2
61-5771	Fitting—Radio table	1
21-6326-1	Angle—Floor beam RH	1
41-5888	Angle—Floor beam outboard	1
41-5996-1	Spacer—Camera door brace	1
41-6158	Angle—Floor beam inboard LH	1
41-6159	Angle—Floor beam inboard RH	1
41-1645-67	Angle—Tabulated	16
41-4858	Washer—No. 10 F.H. screw	100
BAC1603-18	Spacer—No. 10 bolt	2
6-8143	Cradle Installation—Anti-icing tank stations 5B and 5D	1
6-8143-7	Cradle Assembly—Anti-icing tank stations 5B and 5D	2
3-11991	Strap Assembly—Propeller anti-icing tank	4
3-11991-3	Cushion—Propeller anti-icing tank strap	4
1-16134-19-5	Cushion—Tank support	2
	(Parts List No. 189)	
75-3577-652	Felt—Radio and gunner's floor (booth No. 61)	1

Enclosure Installation—Pilot's Cockpit

(Parts List No. 190)

55-8765	Enclosure Installation—Pilot's cockpit	1
55-8765-400	Enclosure Assembly—Pilot's cockpit. Dash number parts, shown on 55-8765 drawing are represented by dash number of 75-3471	1
75-3471-679	Frame Assembly—Front	1
75-3471-680	Frame Assembly—Front outside—pilot's cockpit enclosure	1
75-3471-681	Frame Assembly—Front inside—pilot's cockpit enclosure	1
75-3471-682	Frame Assembly—Front inside—pilot's cockpit enclosure	1
41-514	Gusset—Cockpit enclosure	1
75-3471-657	Bulkhead Assembly—Rear—pilot's cockpit enclosure	1
75-3471-687	Frame Assembly—Side spot weld—pilot's cockpit enclosure	1
75-3471-689	Frame Assembly—Side—outside—pilot's cockpit enclosure	1
75-3471-693	Frame Assembly—Side—inside—pilot's cockpit enclosure	1
37B3822-6B	Rivnut	2
75-3471-686	Frame Assembly—Side—spot weld—pilot's cockpit enclosure	1
75-3471-688	Frame Assembly—Side—outside—pilot's cockpit enclosure	1
75-3471-692	Frame Assembly—Side—inside—pilot's cockpit enclosure	1
37B3822-6B	Rivnut	2
75-3471-696	Frame Assembly—Top spot weld—pilot's cockpit enclosure	1
75-3471-698	Frame Assembly—Top outside—pilot's cockpit enclosure	1
75-3471-702	Frame Assembly—Top inside—pilot's cockpit enclosure	1
75-3471-703	Frame Assembly—Top inside—pilot's cockpit enclosure	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Enclosure Installation—Pilot's Cockpit

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
75-3471-733	Plate Assembly—Splice—pilot's cockpit enclosure	1
75-3471-781	Panel Assembly—Turret wheel—pilot's cockpit enclosure	1
75-3471-746	Hose—Rubber—pilot's cockpit enclosure	2
75-3471-819	Cover—Pilot's cockpit enclosure	1
75-5783	Fairing Installation—Station 4-5 life raft	1
75-5783-670	Fairing Assembly—Life raft—station 4-5	1
	Dash number parts, shown on 75-5783 drawing are represented by dash numbers of 65-5783 and 75-5783.	
75-5783-668	Bulkhead Assembly—Station 4-5 life raft fairing LH	1
75-5783-669	Bulkhead Assembly—Station 4-5 life raft fairing RH	1
1-21357	Clip—Reinforcement	6
1-18796	Cover Assembly—Accessory holes	4
1-18801	Spring—Accessory holes	12
75-5783-671	Former Assembly—Station 4-5 life raft fairing	1
1-16283	Angle—Stiffener tie	2
1-16283-1	Angle—Stiffener tie	3
75-5783-672	Channel Assembly—Door latch—life raft fairing LH	1
43-10760-9	Latch Assembly—Raft door LH	1
43-10760-400	Latch Assembly—Raft door LH	1
	(Parts List No. 191)	
43-10760-7	Bolt—Raft door latch	2
51-293	Guide—Raft door latch (rear)	1
41-8184	Fitting Assembly—Latch LH	1
41-8184-5	Plate Assembly—Latch fitting LH	1
070618	Snap	1
41-8202	Spring—Compression	1
51-291	Guide—Raft door latch (forward)	1
51-295	Guide—Raft door latch (center)	1
21-6578-1	Angle—Reinforcing ½ x ⅝ x .040	1
75-5783-673	Channel Assembly—Door latch—life raft fairing RH	1
43-10760-10	Latch Assembly—Raft door RH	1
43-10760-401	Latch Assembly—Raft door RH	1
43-10760-7	Bolt—Raft door latch	2
51-293	Guide—Raft door latch (rear)	1
41-8184-1	Fitting Assembly—Latch RH	1
41-8184-6	Plate Assembly—Latch fitting RH	1
070618	Snap	1
41-8202	Spring—Compression	1
51-291	Guide—Raft door latch (forward)	1
51-295	Guide—Raft door latch (center)	1
21-6578-1	Angle—Reinforcing ½ x ⅝ x .040	1
75-5783-691	Panel Assembly—Station 4-5 life raft fairing LH	1
1-18796	Cover Assembly—Accessory holes	3
1-18801	Spring—Accessory holes	9
75-5783-692	Panel Assembly—Station 4-5 life raft fairing RH	1
1-18796	Cover Assembly—Accessory holes	3
1-18801	Spring—Accessory holes	9
75-5783-710	Bulkhead Assembly—Station 4-5 life raft fairing (forward) RH	1
75-5783-711	Bulkhead Assembly—Station 4-5 life raft fairing (forward) LH	1
75-5783-712	Bulkhead Assembly—Station 4-5 life raft fairing (center) RH	1
75-5783-713	Bulkhead Assembly—Station 4-5 life raft fairing (center) LH	1
75-5783-714	Bulkhead Assembly—Station 4-5 life raft fairing (rear) RH	1
75-5783-715	Bulkhead Assembly—Station 4-5 life raft fairing (rear) LH	1
65-5783-405	Door Assembly—Station 4-5 life raft fairing LH	1

Enclosure Installation—Pilot's Cockpit

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-5783-654	Door Assembly—Raft compartment LH	1
51-297-4	Latch—Raft compartment door LH	1
51-297-6	Latch—Raft compartment door LH	2
65-5783-406	Door Assembly—Station 4-5 life raft fairing RH	1
	(Parts List No. 192)	
65-5783-655	Door Assembly—Raft compartment RH	1
51-297-7	Latch—Raft compartment door RH	2
51-297-5	Latch—Raft compartment door RH	1
65-5783-425	Former Assembly—Station 4-5 life raft fairing LH	1
1-16283	Angle—Stiffener tie	2
1-16283-1	Angle—Stiffener tie	3
65-5783-607	Former Assembly—Station 4-5 life raft fairing	1
1-16283	Angle—Stiffener tie	2
1-16283-1	Angle—Stiffener tie	3
41-7024	Spacer—No. 10-32 nut plate	1
75-5783-721	Former Assembly—Life raft station 4-5	1
1-16283-1	Angle—Stiffener tie	1
75-5783-722	Former Assembly—Life raft station 4-5	1
1-16283	Angle—Stiffener tie	1
75-5783-723	Former Assembly—Life raft station 4-5	1
1-16283	Angle—Stiffener tie	1
1-16283-1	Angle—Stiffener tie	2
65-5783-622	Bulkhead Assembly—Station 4-5 life raft fairing	1
65-5783-624	Bulkhead Assembly—Station 4-5 life raft fairing	1
21-2367-4	Clip—Stiffener LH	1
21-2367-5	Clip—Stiffener RH	1
14-1695	Door Installation—Inspection LH	1
14-1695-1	Door Installation—Inspection RH	1
14-1695-2	Frame Assembly—Installation door LH	1
14-1695-6	Frame Assembly—Installation door RH	1
3-9582	Fastener Installation—Dzus	8
41-3637	Spring—Dzus fastener	8
41-2086-1	Guide—Cowl fastener	8
14-1695-4	Door Assembly—Inspection LH	1
14-1695-5	Door Assembly—Inspection RH	1
14-1695-8	Door—Inspection	2
14-1695-36	Gasket—Inspection door	1R
14-1695-37	Gasket	1L
14-1695-38	Gasket	1L
14-1695-39	Gasket	1L
14-1695-40	Gasket	1L
3-9582-1	Button Installation—Dzus	8
41-3853	Plate—Cowl fastener	8
41-3888-50	Fastener—Dzus type F	8
54-1696	Support Installation—Inspection door LH	1
54-1696-1	Support Installation—Inspection door RH	1
43-11181	Bracket Assembly—Pulley LH	1L
49-2914	Bracket Installation—Pulley RH	1
49-2914-400	Bracket Assembly—Pulley	1
	(Parts List No. 193)	
1-18907	Clip—Stiffener tie	3
1-18907-1	Clip—Stiffener tie	2
21-2367-4	Clip—RH	1
21-2367-5	Clip—LH	1
41-6616	Clamp—¼ conduit	2
1-18500	Splice Installation—Longitudinal stiffener	2
1-18854	Angle—Stiffener tie	3
1-18854-1	Angle—Stiffener tie	2
1-18854-2	Angle—Stiffener tie	2
1-18854-3	Angle—Stiffener tie	1
BAC1246-10S	Plate—Fiber nut	2
64-1697	Window Installation—Cockpit enclosure LH	1
64-1697-1	Window Installation—Cockpit enclosure RH	1
64-1697-511	Retainer Assembly—Cockpit enclosure LH	1
64-1697-512	Retainer Assembly—Cockpit enclosure RH	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Enclosure Installation—Pilot's Cockpit

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-13932-20	Latch Installation—Cockpit sliding window LH	1
3-13932-21	Latch Installation—Cockpit sliding window RH	1
21-5618-3	Washer—Serrated adjusting	2
3-13932-18	Latch Assembly—Cockpit sliding window LH	1
3-13932-19	Latch Assembly—Cockpit sliding window RH	1
3-13932-7	Knob—Mold (Paragon No. 114—black—Paragon Molded Plastics, Inc., Seattle, Wash.)	2
3-13932-8	Plate—Serrated	
3-13932-15	Tube—Cement per BAC 5010 use U.S. rubber No. 5066 cement	2
BAC1603-28	Spacer—No. 10 bolt	2
15-8761	Window Assembly—Sliding LH	1
15-8761-1	Window Assembly—Sliding RH	1
15-8761-2	Window Assembly—Sliding LH (Pittsburg Plate Glass Co.)	1
15-8761-3	Window Assembly—Sliding RH (Pittsburg Plate Glass Co.)	1
7-1654	Channel Assembly—Sliding window LH	1
7-1654-1	Channel Assembly—Sliding window RH	1
1-22104-0-32	Spacer—⅛ countersunk rivet	16
1-26474	Plate—Sliding window	2
1-26475	Plate—Sliding window	2
1-22684	Fingerpull—Sliding window	2
6-10669	Channel—Sliding window	2
64-1697-502	Plug—Cockpit enclosure (rubbercraft No. 153)	4
1-18769	Drain Assembly—Cockpit enclosure	2
1-18770	Louver—Cockpit enclosure drain	2
43-18605	Support Assembly—Upper gunners interphone	1
BAC1249-208S	Plate—Fiber nut dural	1
6-9323	Support Installation—Pilot's dome lamp	1
	(Parts List No. 193A)	
6-9323-1	Plate Assembly—Pilot's dome lamp support	1
6-9323-4	Angle Assembly—Pilot's dome lamp support	1
9-3709	Support Installation—Radio control	1
9-3709-1	Support Assembly—Radio control	1
BAC1249-206D	Plate—Fiber nut dural	4
9-3709-4	Support Assembly—Radio control	1
BAC1247-8D	Angle—Nut plate	4
	(Parts List No. 194)	
43-9771	Support Installation—Compass board	1
1-18727-1	Angle—Lining support	4
3-13930	Tube Assembly—Dehydrator	2
3-13930-1	Tube—Dehydrator	2
3-13930-2	Screen—Dehydrator	4
1-20231	Nipple Assembly—Dehydrator	1
1-20231-1	Cap—Dehydrator nipple	1
1-20231-2	Rivnut—Dehydrator nipple (Goodrich type 6-240)	1
9-4606	Drain Installation—Upper turret	1
9-4606-4	Tube Assembly—Weld—upper turret drain	1
9-4606-3	Hose—Rubber—upper turret drain	2
9-4606-17	Tube—Upper turret drain	1
9-4606-8	Hose—Rubber—upper turret drain	1
9-4606-18	Hose—Rubber—upper turret drain	1
9-4606-14	Plug—Rubber—upper turret drain	2
1-18770	Louver—Cockpit enclosure drain	3
BAC535-16	Clamp—Hose	8
BAC538-10	Clamp—Loop type—cushioned	2
15-8757	Windshield Assembly—Cockpit enclosure LH (Pittsburg Plate Glass Co.)	1
15-8757-1	Windshield Assembly—Cockpit enclosure RH (Pittsburg Plate Glass Co.)	1
BAC1246-10S	Plate—Fiber nut	8
41-9006-1	Angle Assembly—Tube support	10
1-18413-1	Clip—Spring	8

Enclosure Installation—Pilot's Cockpit

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-20354	Vent—Dehydrator	4
15-8765-3	Tube—Rubber—side gun	2
15-8765-4	Tube—Rubber—side gun	2
41-1645-52	Angle—Tabulated	1
41-4888-14-7	Washer—1/16 rubber	16
1-24907-4	Studs—No. 10-132	10
1-24623	Loop—Cover	2
37B3822-6E	Rivnut	35
37B3822-6K	Rivnut	4
BAC1322-2B	Fastener—Flat steel head type	24
BAC1601-40	Spacer—No. 6 machine screw	4
BAC1246-10D	Plate—Fiber nut	2
21-6240-1	Panel—Side	2
21-5345	Gusset—Stiffener tie	8
41-5544	Hook—Lining support	50
37B3822-6B	Rivnut	35
21-3147-1	Washer—.019 steel (corrosive resistant)	166
6-8434	Support Installation—Pilot's extension lamp	1
6-8434-1	Support Assembly—Pilot's extension lamp	1
21-5515	Angle—Stiffener tie	2
41-8925-51	Angle—Lining support	2
37B3822-6B	Rivnut—Open end with key	5
41-1779	Gusset Installation—Board cowl	2

Door Assembly—Bomb

(Parts List No. 195)

75-4122	Door Assembly—Bomb LH	1
75-4122-1	Door Assembly—Bomb RH	1
75-4122-642	Rib Assembly—Bomb door LH	1
75-4122-643	Rib Assembly—Bomb door RH	1
75-4122-647	Rib Assembly—Bomb door LH	1
75-4122-648	Rib Assembly—Bomb door RH	1
21-9905	Clip—Stiffener tie (used in -648 only)	2
21-9905-1	Clip—Stiffener tie (used in -647 only)	2
75-4122-654	Rib Assembly—Bomb door LH	1
75-4122-655	Rib Assembly—Bomb door RH	1
75-4122-657	Rib Assembly—Bomb door LH	1
75-4122-658	Rib Assembly—Bomb door RH	1
3-7941	Hinge Assembly—Bomb door LH	1
3-7941	Hinge Assembly—Bomb door RH	2
3-7941-6	Hinge Assembly—Bomb door LH	1
3-7941-2	Hinge—Bomb door (used in -0 only)	3
3-7941-5	Hinge—Bomb door (used in -6 only)	1
3-7941-7	Plate—Bomb door (used in -6 only)	1
3-7941-8	Plate—Bomb door (used in -6 only)	1
3-7942	Hinge Assembly—Bomb door	2
3-7942-1	Hinge Assembly—Bomb door RH	1
3-7942-2	Hinge Assembly—Bomb door	2
3-7942-10	Hinge Assembly—Bomb door LH	1
3-7942-3	Hinge—Bomb door (used in -0 only)	2
3-7942-4	Hinge—Bomb door (used in -1 only)	1
3-7942-5	Hinge—Bomb door (used in -2 only)	2
3-7942-11	Hinge—Bomb door (used in -10 only)	1
1-18066	Pin—Switch throw (used in -10 only)	1
3-7943	Hinge Assembly—Bomb door	2
3-7943-1	Hinge—Bomb door	2
3-7986-1	Filler—Bomb door LH	1
3-7986-2	Filler—Bomb door RH	1
3-7986-3	Filler—Bomb door LH	1
3-7986-4	Filler—Bomb door RH	1
3-7987-1	Filler—Bomb door LH	1
3-7987-2	Filler—Bomb door RH	1
3-7987-3	Filler—Bomb door LH	1
3-7987-4	Filler—Bomb door RH	1
3-10396	Bracket Installation—Bomb door control LH	1
3-10396-1	Bracket Installation—Bomb door control RH	1
41-1766	Bracket Assembly—Bomb door control	2
BAC1614-80	Spacer—⅛ rivet	4
BAC1603-21	Spacer—No. 10 bolt	4
3-11770	Fitting Assembly—Bomb door—front LH	1
3-11770-1	Fitting Assembly—Bomb door—front RH	1
3-11770-2	Fitting—Bomb door LH	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Door Assembly—Door

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-11770-3	Fitting—Bomb door RH	1
BAC327-35S	Bushing—Bearing	2
	(Parts List No. 196)	
3-11771	Fitting Assembly—Bomb door rear LH	1
3-11771-1	Fitting Assembly—Bomb door rear RH	1
3-11771-2	Fitting—Bomb door rear LH	1
3-11771-3	Fitting—Bomb door rear RH	1
BAC327-35S	Bushing—7/16 outside dimension bearing	2
21-2367-8	Clip—Stiffener tie	1
21-2367-9	Clip—Stiffener tie	1
21-5604-5	Washer—Bevel	8
21-5604-6	Washer—Bevel	8
21-5604-7	Washer—Bevel	8
21-5604-8	Washer—Bevel	8
21-9905	Clip—Stiffener tie	6
21-9905-1	Clip—Stiffener tie	6
21-9905-2	Clip—Stiffener tie	8L
21-9905-2	Clip—Stiffener tie	7R
21-9905-3	Clip—Stiffener tie	7L
21-9905-3	Clip—Stiffener tie	8R
21-9905-4	Clip—Stiffener tie	3L
21-9905-4	Clip—Stiffener tie	4R
21-9905-5	Clip—Stiffener tie	4L
21-9905-5	Clip—Stiffener tie	3R
41-1725-1	Shim—Bomb door mast	8
41-1725-2	Shim—Bomb door mast	8
41-1725-3	Shim—Bomb door mast	16
41-9998	Terminal—Bomb door check	4
58-817	Beam Assembly—Bomb door LH	1
58-817-1	Beam Assembly—Bomb door RH	1
49-2710	Controls Installation—Bomb door LH	1
49-2710-1	Controls Installation—Bomb door RH	1
49-2710-4	Cover Assembly—Bomb door controls	2
49-2710-5	Cover—Bomb door controls	2
49-2710-400	Cover—Bomb door controls	2
49-2710-401	Cover—Bomb door controls	2
3-10307	Bracket Installation—Bomb door controls LH	1
3-10307-1	Bracket Installation—Bomb door controls RH	1
BAC1603-20	Spacer—No. 10 bolt	4
46-7580	Bracket Installation—Bomb door control RH	1
46-7580-1	Bracket Installation—Bomb door control LH	1
46-7580-20	Bracket Assembly—Bomb door control RH	1
46-7580-21	Bracket Assembly—Bomb door control LH	1
51-780-2	Brace—Bomb door control bracket RH	1
51-780-3	Brace—Bomb door control bracket LH	1
51-790	Guard—Control pulley	2
BAC1614-20	Spacer—1/8 rivet	2
51-779	Angle—Bomb door control bracket	2
6-8361	Bracket Installation—Bomb door controls LH	1
6-8361-1	Bracket Installation—Bomb door controls RH	1
6-8361-2	Bracket Assembly—Bomb door controls	2
BAC1614-48	Spacer—1/8 rivet	2
6-8361-4	Guard—Bomb door control bracket	2
	(Parts List No. 197)	
46-8111	Bracket Installation—Bomb door controls (forward) LH	1
46-8111-1	Bracket Installation—Bomb door controls (forward) RH	1
46-8111-2	Bracket Assembly—Bomb door controls (forward) LH	1
46-8111-3	Bracket Assembly—Bomb door controls (forward) RH	1
51-780	Brace—Bomb door control bracket LH	1
51-780-1	Brace—Bomb door control bracket RH	1
51-790	Guard—Control pulley	2
BAC1614-19	Spacer—1/8 rivet	4
51-779	Angle—Bomb door control bracket	2
51-337	Fair-lead Assembly—Bomb door control	2
51-337-1	Block—Bomb door control fair-lead	2
51-337-2	Block—Bomb door control fair-lead	1
41-6615-4	Fair-lead—Bomb door control fair-lead	16

Door Assembly—Door

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-6615-5	Fair-lead—Bomb door control fair-lead	16
1-16650-43-0	Cable Assembly—3/32 x 7 x 7 control	2
1-16650-98-1	Cable Assembly—3/32 x 7 x 7 control	2
1-16650-43-0A	Cable—3/32 x 7 x 7 control (used in -43-0 only)	2
1-16650-98-1A	Cable—3/32 x 7 x 7 control (used in -43-0 only)	2
BAC1827-3L	Swaged Terminal—Class "D"	4
51-300	Filler—Bomb door LH	1
51-300-1	Filler—Bomb door RH	1
51-381	Filler—Bomb door LH	1
51-381-1	Filler—Bomb door RH	1
51-382	Filler—Bomb door LH	1
51-382-1	Filler—Bomb door RH	1
51-383	Filler—Bomb door LH	1
51-383-1	Filler—Bomb door RH	1
1-18303	Gusset—Stiffener	6
1-18086	Gusset—Stiffener	8
1-18085	Gusset—Stiffener	12
1-26858	Decalcomania (used on -0, -1)	24

Strut Installation—Body Compression

(Parts List No. 198)

75-3445	Strut Installation—Body compression LH	1
75-3445-1	Strut Installation—Body compression RH	1
3-6539	Gusset—Compression strut inboard	2
3-6540	Gusset—Compression strut outboard	2
3-6541	Gusset—Compression strut inboard	2
3-6542	Gusset—Compression strut outboard	2
3-6544	Gusset—Compression strut inboard	2
3-6544-1	Gusset—Compression strut outboard	2
3-6543	Gusset—Compression strut	4
21-5608-1	Gusset—Compression strut	4
3-6538	Gusset—Compression strut	4
3-11774	Brace Assembly—Bomb rail LH	1
3-11774-1	Brace Assembly—Bomb rail RH	1
14-1827	Step Installation—Landing gear retractor LH	1
14-1827-1	Step Installation—Landing gear retractor RH	1
14-1827-20	Cover—Landing gear retractor step	1
14-1827-21	Cover—Landing gear retractor step	1
14-1827-34	Matting—Landing gear retractor step LH	1
14-1827-46	Matting—Landing gear retractor step RH	1
14-1827-2	Step Assembly—Landing gear retractor LH	1
14-1827-3	Step Assembly—Landing gear retractor RH	1
14-1827-6	Bracket Assembly—Landing gear retractor step LH	1
14-1827-7	Bracket Assembly—Landing gear retractor step RH	1
14-1827-14	Angle Assembly—Landing gear retractor step	2
14-1827-16	Bracket Assembly—Landing gear retractor step	1
14-1827-17	Bracket Assembly—Landing gear retractor step	1
14-1827-35	Bracket Assembly—Landing gear retractor step	1
14-1827-36	Bracket Assembly—Landing gear retractor step	1
14-1827-22	Angle Assembly—Landing gear retractor step LH	1
14-1827-23	Angle Assembly—Landing gear retractor step RH	1
14-1827-26	Bracket Assembly—Landing gear retractor step LH	1
14-1827-27	Bracket Assembly—Landing gear retractor step RH	1
14-1827-30	Angle Assembly—Landing gear retractor step LH	1
14-1827-42	Angle Assembly—Landing gear retractor step RH	1
21-1063	Angle—Stiffener	8
51-497	Lug—Strut brace	4

AVIALOGS.COM

FUSELAGE ASSEMBLY

Strut Installation—Body Compression

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC114A-46S	Bolt—Bearing	8
BAC114A-47S	Bolt—Bearing	8
21-5601-2	Hinge—Bomb door	12
21-5601-3	Hinge—Bomb door	12
BAC114A-43S	Bolt—Bearing	16
41-8369	Channel—Duct support	1L
41-8369-1	Channel—Duct support	1L
41-8369-2	Channel—Duct support	1L
41-8369-3	Channel—Duct support	1L
21-5609	Plate Assembly—Bomb rail support	8
21-5609-1	Plate—Bomb rail support	8
BAC346-4-194	Bushing—Staked	8
3-11464	Bracket Assembly—Shield support LH	1
3-11464-1	Bracket Assembly—Shield support RH	1
56-5608	Step Installation—Bomb leader LH	1
56-5608-500	Step Installation—Bomb leader RH	1
56-5608-501	Matting—Bomb leader	2
	(Parts List No. 199)	
55-5785	Support Installation—Lux cylinders	1R
55-5785-404	Door Assembly—Lux cylinders support	1
55-5785-405	Door—CO^2 cylinders support	1
55-5785-406	Support Assembly—Lux cylinders	1
6-8134	Bracket Assembly—CO^2 cylinders	1
41-9916	Strap Assembly—CO^2 cylinders	2
BAC1613-64	Spacer—3/32 rivet	3
55-4301	Support Installation—De-icer distributor valve	1R
55-4301-405	Door—De-icer distributor valve support	1
55-4301-400	Bracket Assembly—De-icer distributor valve	1
3-7060-5	Bracket Installation—Aileron pulley	1L
3-7060-6	Bracket Installation—Aileron pulley	1R
3-7060-8	Bracket Assembly—Aileron pulley	2
41-7183	Support Assembly—Fire extinguisher	1R
3-11722	Cover Installation—Fire extinguisher	1R
3-11774-11	Brace Assembly—Bomb rail	1L
21-9073	Angle—Stiffener support	8L
21-9073-1	Angle—Stiffener support	8R
21-9073-2	Angle—Stiffener support	5L
21-9073-3	Angle—Stiffener support	5R
21-9073-4	Angle—Stiffener support	1L
21-9073-5	Angle—Stiffener support	1R
21-9073-6	Angle—Stiffener support	1L
21-9073-7	Angle—Stiffener support	1R
21-9073-8	Angle—Stiffener support	1L
21-9073-9	Angle—Stiffener support	1R
3-11774-12	Brace Assembly—Bomb rail	1R
1-20316	Angle—Stiffener support	1
1-20316-1	Angle—Stiffener support	1
BAC114A41DD	Bolt—Bearing	2
BAC114A43DD	Bolt—Bearing	40
BAC114A44DD	Bolt—Bearing	42
BAC114A45DD	Bolt—Bearing	32
BAC114A46DD	Bolt—Bearing	4
BAC116A47DD	Bolt—Bearing	24
BAC116A48DD	Bolt—Bearing	26
BAC1603-45	Spacer—No. 10 bolt	4R
NAS56A-30DD	Bolt—Close tolerance	24
NAS54A-26	Bolt—Close tolerance	16
NAS54A26DD	Bolt—Close tolerance	40
NAS54A25.5DD	Bolt—Close tolerance	2
NAS54A26.5DD	Bolt—Close tolerance	26
NAS54A27.5DD	Bolt—Close tolerance	44
NAS54A27DD	Bolt—Close tolerance	16

Fairing Installation—Top Turret

(Parts List No. 200)

55-6612	Fairing Installation—Top turret	1
55-6612-499	Beam Assembly—Top turret LH	1
55-6612-500	Beam Assembly—Top turret RH	1
55-6612-69	Rail Assembly—Top turret LH	1
1-16372	Plate	2

Fairing Installation—Top Turret

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1603-32	Spacer—No. 10 bolt	1
55-6612-465	Rail Assembly—Top turret RH	1
1-16372	Plate	2
1-20076	Stop—Gun mount	2
BAC1246-10	Nut plate—Fiber	4
15-6620-61	Window Installation—Top gun fairing	1
15-6620-62	Window Assembly—Top gun fairing	1
15-6620-2	Frame Assembly—Top gun fairing	1
15-6620-3	Window—Plexiglas top gun fairing window	1
15-6620-4	Retainer—Left side top gun fairing window	1
15-6620-5	Retainer—Right side top gun fairing window	1
15-6620-6	Retainer—Forward top gun fairing window	1
15-6620-7	Retainer—Aft top gun fairing window	1
15-6620-8	Retainer—Forward top gun fairing window	1
15-6620-9	Retainer—Aft top gun fairing window	1
15-6620-10	Packing—Top gun fairing window	2
15-6620-11	Packing—Top gun fairing window	1
15-6620-12	Angle—Forward top gun fairing window	1
15-6620-13	Angle—Aft top gun fairing window	1
15-6620-27	Seal—Rubber top gun fairing window	1
15-6620-32	Packing—Top gun fairing window	2
15-6620-55	Filler—Micarta gun fairing window, top	4
15-6620-66	Tube—Top gun fairing window	1
15-6620-67	Tube—Top gun fairing window	1
3-13774	Handle—Top window	2
3-13774-1	Handle—Top window	2
3-12580	Handle Assembly—Top window	2
3-12580-1	Handle Assembly—Top window	2
3-12580-2	Handle—Top window	2
3-12580-4	Bushing—Top window handle	2
3-12580-5	Collar—Top window handle	2
41-4429-2	Plate—Reinforcing	4
3-13774-4	Handle Assembly	2
3-13774-5	Handle Assembly	2
BAC1605-8	Spacer—5/16 bolt	4
BAC1605-56	Spacer—5/16 bolt	4
51-61-14-6	Washer—Paw tape	64
1-16288-2	Plate—Camera cover latch	4
1-20209	Catch Assembly—Bulkhead 6 door	1
21-6744	Fastener—Inspection door	1
15-6621	Spoiler Installation—Upper gun emplacement	1
15-6621-1	Spoiler Assembly—Upper gun emplacement	1
	(Parts List No. 200A)	
1-16414	Angle—Spoiler	1
1-16414-1	Angle—Spoiler	1
1-16415	Angle—Spoiler	1
1-16415-1	Angle—Spoiler	1
	(Parts List No. 201)	
1-16416	Channel—Spoiler	2
1-16417	Angle—Spoiler	1
1-16417-1	Angle—Spoiler	1
15-6621-8	Angle Assembly—Upper gun emplacement	2
1-16418	Track—Spoiler	1
1-16418-1	Track—Spoiler	1
1-16419	Plate—Striker spoiler	1
1-18833	Angle—Support	4
1-16379	Spring—Spoiler	1
1-16380	Handle Assembly—Spoiler upper gun	1
1-16381	Link Assembly—Spoiler	1
BAC1613-15	Spacer—3/32 Rivet	2
BAC1603-14	Spacer—No. 10 bolt	1
1-16378	Hinge Assembly—Spoiler	1
1-16378-1	Hinge Assembly—Spoiler	1
1-16378-2	Hinge—Spoiler	2
BAC345-4-194	Bushing—Staked	2
BAC1603-19	Spacer—No. 10 Bolt	4
BAC364-17S	Bushing—5/32 outer diameter bearing	2
1-19053-1	Guide—Window	1
1-16283	Angle—Stiffener tie	2

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fairing Installation—Top Turret

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-16283-1	Angle—Stiffener tie	2
1-16411	Angle—Stiffener tie	1
1-16411-1	Angle—Stiffener tie	1
1-18854	Clip—Stiffener tie	3
1-18854-1	Clip—Stiffener tie	3
5-9337	Support Installation—Life raft	1
6-9337-1	Support Assembly—Life raft control	1
3-16142-9	Decalcomania	1
6-8569	Channel—Spoiler support	1
51-61-14-6	Washer—Paw tape	22
BAC1447-4-4	Screw—Round head recessed sheet metal	24
1-18277	Tee—Stiffener tie	2
1-18709	Tee—Stiffener tie	1
1-18710	Tee—Stiffener tie	2
1-18711	Angle—Stiffener tie	8
1-18711-1	Angle—Stiffener tie	8
1-18712	Gusset—Stiffener tie	16
41-7814	Tab—Lining support	38
41-8097	Hook—String support	12
41-8557	Tab—Lining support	4
1-20371	Angle—Stiffener tie	1
1-20371-1	Angle—Stiffener tie	1
55-6612-90	Retainer—Top gun emplacement fairing	1
55-6612-91	Retainer—Top gun emplacement fairing	1
55-6612-122	Panel—Plexiglass top gun emplacement fairing	1
37B3822-6K	Rivnut—Threaded	11

Stiffener Installation—Station 2A-2E Circumference

(Parts List No. 202)

65-5795	Stiffener Installation—Station 2A-2E circumference	1
65-5795-504	Segment Assembly—Station 2A-2E circumference stiffener	1
41-8097	Hook—String support	2
1-16283-2	Angle—Stiffener tie	1
1-16283-3	Angle—Stiffener tie	1
65-5795-510	Segment Assembly—Station 2A circumference stiffener	1
41-8097	Hook—String support	1
21-9221	Spacer—Nut plate	1
65-5795-514	Segment Assembly—Station 2B circumference stiffener	1
41-8097	Hook—String support	10
21-9221	Spacer—Nut plate	6
65-5795-520	Segment Assembly—Station 2C circumference stiffener	1
41-8097	Hook—String support	3
65-5795-521	Segment Assembly—Station 2C circumference stiffener	1
41-8097	Hook—String support	3
65-5795-524	Segment Assembly—Station 2C circumference stiffener	1
65-5795-607	Segment Assembly—Station 2A circumference stiffener	1
41-3003-25-64	Filler—.125 channel	1
41-3003-25-70	Filler—.125 channel	1
41-7591	Angle Assembly—Navigator's floor	2
41-7591-1	Angle Assembly—Navigator's floor	3
41-6830	Angle—Stiffener tie	1
1-16283-4	Angle—Stiffener tie	1
65-5795-608	Segment Assembly—Station 2B circumference stiffener	1
41-7591	Angle Assembly—Navigator's floor	6
41-8097	Hook—String support	1
1-16283-4	Angle—Stiffener tie	1
41-6830	Angle—Stiffener tie	1
65-5795-571	Segment Assembly—Station 2D circumference stiffener	1
41-7590-2	Angle Assembly—Navigator's floor	1
41-7591	Angle Assembly—Navigator's floor	3
1-16283-4	Angle—Stiffener tie	1
41-6063-81-40-2	Angle—$\frac{9}{16}$ x $\frac{3}{4}$ aluminum alloy	1

Stiffener Installation—Station 2A-2E Circumference

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-6830	Angle—Stiffener tie	1
41-8097	Hook—String support	1
65-5795-573	Segment Assembly—Station 2E circumference stiffener	1
41-7590-3	Angle Assembly—Navigator's floor	1
1-17237-8	Channel—Stiffener attaching	1
41-6063-90-70-1	Angle—$\frac{9}{16}$ x $\frac{3}{4}$ aluminum alloy	1
BAC1249-110S	Plate—Fiber nut	2
1-16283-4	Angle—Stiffener tie	1
1-16283-5	Angle—Stiffener tie	1
BAC1327-4-200	Spring—Dzus fastener	2
BAC1327-5-200	Spring—Dzus fastener	2

(Parts List No. 203)

65-5795-575	Segment Assembly—Station 2A circumference stiffener	1
65-5795-576	Segment Assembly—Station 2A circumference stiffener	1
65-5795-577	Segment Assembly—Station 2A circumference stiffener	1
41-8097	Hook—String support	1
BAC1247-10S	Angle—Nut plate	1
65-5795-578	Segment Assembly—Station 2C circumference stiffener	1
BAC1247-10S	Angle—Nut plate	1
65-5795-569	Segment Assembly—Station 2C circumference stiffener	1
41-7591	Angle Assembly—Navigator's floor	4
41-8097	Hook—String support	1
BAC1249-141-6	Plate—Fiber nut	2
1-16283-4	Angle—Stiffener tie	1
41-6830	Angle—Stiffener tie	1
65-5795-579	Segment Assembly—Station 2C circumference stiffener	1
BAC1249-110S	Plate—Fiber nut	2
21-9221	Spacer—Nut plate	5
41-7510	Angle Assembly—Support	1
BAC1249-210S	Plate—Fiber nut	2
65-5795-581	Segment Assembly—Station 2D circumference stiffener	1
41-8097	Hook—String support	4
21-9221	Spacer—Nut plate	1
BAC1247-10S	Angle—Nut plate	1
37B3822-6B	Rivnut—Threaded	2
65-5795-582	Segment Assembly—Station 2C circumference stiffener	1
41-8097	Hook—String support	1
21-9221	Spacer—Nut plate	1
BAC1247-10S	Plate—Nut plate	1
65-5795-583	Segment Assembly—Station 2B circumference stiffener	1
41-8097	Hook—String support	6
21-9221	Spacer—Nut plate	2
BAC1247-10S	Angle—Nut plate	1
37B3822-6K	Rivnut—Threaded	1
65-5795-584	Segment Assembly—Station 2A circumference stiffener	1
41-8097	Hook—String support	2
21-9221	Spacer—Nut plate	1
BAC1247-10S	Angle—Nut plate	1
65-5795-590	Segment Assembly—Station 2A circumference stiffener	1
65-5795-592	Segment Assembly—Station 2A-2E circumference stiffener	1
41-8097	Hook—String support	8
21-9221	Spacer—Nut plate	2
BAC1247-8	Angle—Nut plate	2
BAC1247-10S	Angle—Nut plate	1
65-5795-594	Segment Assembly—Station 2C circumference stiffener	1
41-8097	Hook—String support	4

AVIALOGS.COM

FUSELAGE ASSEMBLY

Stiffener Installation—Station 2A-2E Circumference

(Parts List No. 204)

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1247-8	Angle—Nut plate	2
65-5795-596	Segment Assembly—Station 2D circumference stiffener	1
21-9221	Spacer—Nut plate	1
41-8097	Hook—String support	6
BAC1247-8	Angle—Nut plate	2
37B3822-6B	Rivnut—Threaded	1
65-5795-598	Segment Assembly—Station 2A-2E circumference stiffener	1
21-9221	Spacer—Nut plate	2

Stiffener Installation—Station 2A-2E Circumference

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-3003-25-70	Filler—.125 channel	1
1-17639	Splice Installation—Circumference stiffener	10
1-17242	Angle—Stiffener attaching	4
1-17242-1	Angle—Stiffener attaching	4
21-9221	Spacer—Nut plate	10
41-6063-90-40-1	Angle—Stiffener tie	12
1-16283	Angle—Stiffener tie	2
1-16283-1	Angle—Stiffener tie	2
1-16283-2	Angle—Stiffener tie	2
1-16283-3	Angle—Stiffener tie	2
1-20545	Clip—Angle	1
1-20544	Clip—Angle	1

FUSELAGE ASSEMBLY—FORWARD SECTION

Stiffener Installation—Station 3A-3J

(Parts List No. 205)

15-7313	Stiffener Installation—Station 3A-3J	1
15-7313-20	Segment Assembly—Station 3E stiffener	1
1-16283-1	Angle—Stiffener tie	1
1-17242	Angle—Stiffener tie	1
41-6063-90-40-1	Angle—Stiffener tie	1
41-8125-2	Angle—Stiffener tie	1
41-8125-3	Angle—Stiffener tie	1
15-7313-21	Segment Assembly—Station 3E stiffener	1
1-16283	Angle—Stiffener tie	1
1-17242-1	Angle—Stiffener tie	1
41-6063-90-40-1	Angle—Stiffener tie	1
41-8125-2	Angle—Stiffener tie	1
41-8125-3	Angle—Stiffener tie	1
15-7313-44	Segment Assembly—Station 3A—stiffener	1
1-16283-1	Angle—Stiffener tie	2
1-17237-4	Channel—Stiffener attaching	1
BAC1247-110S	Angle—Nut plate	2
15-7313-45	Segment Assembly—Station 3B—stiffener	1
1-16283-1	Angle—Stiffener tie	1
1-17237-4	Channel—Stiffener attaching	1
BAC1247-110S	Angle—Nut plate	2
15-7313-46	Segment Assembly—Station 3C—stiffener	1
1-16283-1	Angle—Stiffener tie	2
1-17237	Channel—Stiffener attaching	1
BAC1247-110S	Angle—Nut plate	1
15-7313-47	Segment Assembly—Station 3D—stiffener	1
1-16283	Angle—Stiffener tie	2
1-17237	Channel—Stiffener attaching	1
1-17237-3	Channel—Stiffener attaching	1
41-9057	Support Installation—Emergency bomb release	1
41-6913	Angle Assembly—8-32 M T G	1
BAC1247-110S	Angle—Nut plate	2
15-7313-49	Segment Assembly—Station 3E—stiffener	1
1-16283-1	Angle—Stiffener tie	2
1-17237	Channel—Stiffener attaching	1
1-17237-3	Channel—Stiffener attaching	1
BAC1247-110S	Angle—Nut plate	2
15-7313-51	Segment Assembly—Station 3F—stiffener	1
1-16283	Angle—Stiffener tie	3
1-16283-1	Angle—Stiffener tie	2
1-17237	Channel—Stiffener attaching	1
1-17237-3	Channel—Stiffener attaching	1
3-13782	Patch Installation—Valve support	1
BAC1247-110S	Angle—Nut plate	2

(Parts List No. 206)

15-7313-69	Segment Assembly—Station 3G—stiffener	1
1-16283	Angle—Stiffener tie	3
1-17237	Channel—Stiffener attaching	1
1-17237-3	Channel—Stiffener attaching	1

Stiffener Installation—Station 3A-3J

1-16283-1	Angle—Stiffener tie	2
BAC1247-110S	Angle—Nut plate	2
15-7313-70	Segment Assembly—Station 3H—stiffener	1
1-16283	Angle—Stiffener tie	4
1-17237	Channel—Stiffener attaching	1
1-17237-3	Channel—Stiffener attaching	1
BAC1247-110S	Angle—Nut plate	2
15-7313-85	Segment Assembly—Station 3A—stiffener	1
1-16283	Angle—Stiffener tie	2
1-17237-5	Channel—Stiffener attaching	1
1-17237-6	Channel—Stiffener attaching	1
15-7313-86	Segment Assembly—Station 3A—stiffener	1
1-16283-1	Angle—Stiffener tie	1
1-17237-5	Channel—Stiffener attaching	1
15-7313-87	Segment Assembly—Station 3A—stiffener	1
1-16283	Angle—Stiffener tie	1
1-17237-4	Channel—Stiffener attaching	1
15-7313-88	Segment Assembly—Station 3B—stiffener	1
1-17237-7	Channel—Stiffener attaching	1
15-7313-89	Segment Assembly—Station 3B—stiffener	1
1-16283	Angle—Stiffener tie	2
1-17237-5	Channel—Stiffener attaching	1
1-17237-6	Channel—Stiffener attaching	1
BAC1247-110S	Angle—Nut plate	3
15-7313-90	Segment Assembly—Station 3B—stiffener	1
1-16283-1	Angle—Stiffener tie	1
1-17237-5	Channel—Stiffener attaching	1
15-7313-91	Segment Assembly—Station 3B—stiffener	1
1-16283	Angle—Stiffener tie	1
1-17237-4	Channel—Stiffener attaching	1
15-7313-92	Segment Assembly—Station 3C—stiffener	1
1-17237-3	Channel—Stiffener attaching	1
15-7313-93	Segment Assembly—Station 3C—stiffener	1
1-17237-1	Channel—Stiffener attaching	1
1-17237-2	Channel—Stiffener attaching	1
1-16283	Angle—Stiffener tie	2
BAC1247-110S	Angle—Nut plate	1

(Parts List No. 207)

15-7313-94	Segment Assembly—Station 3C—stiffener	1
1-16283-1	Angle—Stiffener tie	1
1-17237-1	Channel—Stiffener attaching	1
15-7313-95	Segment Assembly—Station 3C—stiffener	1
1-16283	Angle—Stiffener tie	1
1-17237	Channel—Stiffener attaching	1
15-7313-96	Segment Assembly—Station 3D stiffener	1
1-16283-1	Angle—Stiffener tie	1
1-17237-1	Channel—Stiffener attaching	1
15-7313-97	Segment Assembly—Station 3D—stiffener	1
1-16283	Angle—Stiffener tie	1
1-17237	Channel—Stiffener attaching	1
15-7313-98	Segment Assembly—Station 3D—stiffener	1

AVIALOGS.COM

FUSELAGE ASSEMBLY—FORWARD SECTION

Stiffener Installation—Station 3A-3J

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-16283-1	Angle—Stiffener tie	3
1-17237-1	Channel—Stiffener attaching	1
1-17237-2	Channel—Stiffener attaching	1
15-7313-99	Segment Assembly—Station 3E—stiffener	1
1-16283	Angle—Stiffener tie	2
1-17237-1	Channel—Stiffener attaching	1
1-17237-2	Channel—Stiffener attaching	1
15-7313-100	Segment Assembly—Station 3F	1
1-16283	Angle—Stiffener tie	2
1-17237-1	Channel—Stiffener attaching	1
1-17237-2	Channel—Stiffener attaching	1
3-11576	Support Installation	1
41-9163	Post—3/16 flexible cable casing	1
15-7313-101	Segment Assembly—Stations 3F, G, H, I, J—stiffener	5
1-16283-1	Angle—Stiffener tie	5
1-17237-1	Channel—Stiffener attaching	5
15-7313-102	Segment Assembly—Stations 3F, G, H, I, J—stiffener	5
1-16283	Angle—Stiffener tie	5
1-17237	Channel—Stiffener attaching	5
BAC1247-10S	Angle—Nut plate	1
15-7313-103	Segment Assembly—Station 3G—stiffener	1
1-16283	Angle—Stiffener tie	2
1-16283-1	Angle—Stiffener tie	3
1-17237-1	Channel—Stiffener attaching	1
1-17237-2	Channel—Stiffener attaching	1
BAC1247-110S	Angle—Nut plate	1
15-7313-104	Segment Assembly—Station 3H—stiffener	1
1-16283-1	Angle—Stiffener tie	4
1-17237-1	Channel—Stiffener attaching	1
1-17237-2	Channel—Stiffener attaching	1

(Parts List No. 208)

15-7313-105	Segment Assembly—Station 3I—stiffener	1
1-17237	Channel—Stiffener tie	1
BAC1247-110S	Angle—Nut plate	1
15-7313-106	Segment Assembly—Station 3I—stiffener	1
1-17237-1	Channel—Stiffener tie	1
15-7313-107	Segment Assembly—Station 3I—stiffener	1
1-16283	Angle—Stiffener tie	4
1-17237-3	Channel—Stiffener attaching	1
15-7313-108	Segment Assembly—Station 3I—stiffener	1
1-16283-1	Angle—Stiffener tie	4
1-17237-2	Channel—Stiffener attaching	1
15-7313-109	Segment Assembly—Station 3J—stiffener	1
1-17237	Channel—Stiffener tie	1
15-7313-110	Segment Assembly—Station 3J—stiffener	1
1-17237-1	Channel—Stiffener tie	1
15-7313-111	Segment Assembly—Station 3J—stiffener	1
1-16283	Angle—Stiffener tie	4
1-18762	Angle—Stiffener tie	1
15-7313-112	Segment Assembly—Station 3J—stiffener	1
1-16283-1	Angle—Stiffener tie	4
1-18762-1	Angle—Stiffener tie	1
15-7313-113	Segment Assembly—Station 3A—stiffener	1
1-17237-7	Channel—Stiffener tie	1

Stiffener Installation—Station 4A-4JA Circumference

(Parts List No. 209)

15-7314	Stiffener Installation—Station 4A-4JA circumference	1
15-7314-39	Segment Assembly—Station 4A-4JA stiffener circumference	1
21-9221	Spacer—Nut plate	1
15-7314-40	Segment Assembly—Station 4B stiffener circumference	1
21-9221	Spacer—Nut plate	3
15-7314-41	Segment Assembly—Station 4B stiffener circumference	1
21-9221	Spacer—Nut plate	2

Stiffener Installation—Station 4A-4JA Circumference

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7314-42	Segment Assembly—Station 4B stiffener circumference	1
21-9221	Spacer—Nut plate	2
15-7314-43	Segment Assembly—Station 4C stiffener circumference	1
21-9221	Spacer—Nut plate	1
BAC1247-10S	Angle—Nut plate	1
15-7314-44	Segment Assembly—Station 4C stiffener circumference	1
21-9221	Spacer—Nut plate	1
15-7314-45	Segment Assembly—Station 4C stiffener circumference	1
21-9221	Spacer—Nut plate	4
BAC1247-10S	Angle—Nut plate	1
15-7314-46	Segment Assembly—Station 4D B stiffener circumference	1
21-9221	Spacer—Nut plate	3
15-7314-47	Segment Assembly—Station 4D C stiffener circumference	1
21-9221	Spacer—Nut plate	3
15-7314-48	Segment Assembly—Station 4F stiffener circumference	1
21-9221	Spacer—Nut plate	1
BAC1247-10S	Angle—Nut plate	1
15-7314-49	Segment Assembly—Station 4C A stiffener circumference	1
21-9221	Spacer—Nut plate	1
15-7314-50	Segment Assembly—Station 4I stiffener circumference	1
21-9221	Spacer—Nut plate	1
15-7314-51	Segment Assembly—Station 4J A stiffener circumference	1
21-9221	Spacer—Nut plate	1
BAC1247-10S	Angle—Nut plate	2
15-7314-52	Segment Assembly—Station 4A-4JA stiffener circumference	1
BAC1247-110S	Angle—Nut plate	1
15-7314-53	Segment Assembly—Station 4A-4JA stiffener circumference	1
BAC1247-110S	Angle—Nut plate	1
15-7314-54	Segment Assembly—Station 4A-4JA stiffener circumference	1
BAC1247-10S	Angle—Nut plate	1
15-7314-55	Segment Assembly—Station 4A-4JA stiffener circumference	1

(Parts List No. 210)

BAC1247-110S	Angle—Nut plate	1
15-7314-56	Segment Assembly—Station 4A-4JA stiffener circumference	1
BAC1247-110S	Angle—Nut plate	1
15-7314-57	Segment Assembly—Station 4A-4JA stiffener circumference	1
BAC1247-110S	Angle—Nut plate	1
15-7314-58	Segment Assembly—Station 4A-4JA stiffener circumference	1
BAC1247-110S	Angle—Nut plate	1
15-7314-59	Segment Assembly—Station 4A-4JA stiffener circumference	1
BAC1247-110S	Angle—Nut plate	1
15-7314-60	Segment Assembly—Station 4A-4JA stiffener circumference	1
BAC1247-110S	Angle—Nut plate	1
15-7314-61	Segment Assembly—Station 4G	1
BAC1247-10S	Angle—Nut plate	2
15-7314-62	Segment Assembly—Station 4G	1
BAC1247-10S	Angle—Nut plate	1
1-17237	Channel—Stiffener attaching	8
1-17237-1	Channel—Stiffener attaching	8
1-17237-2	Channel—Stiffener attaching	16
1-17237-3	Channel—Stiffener attaching	18

AVIALOGS.COM

FUSELAGE ASSEMBLY—FORWARD SECTION

Stiffener Installation—Station 4A-4JA Circumference

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-6063-90-40	Angle—$\frac{9}{16}$ x $\frac{3}{4}$ aluminum alloy	12
41-6063-1	Angle—$\frac{9}{16}$ x $\frac{3}{4}$ aluminum alloy	8
1-17242-4	Angle—Stiffener attaching	8
1-17242-5	Angle—Stiffener attaching	8

Stiffener Installation—Station 5A-5H Circumference

(Parts List No. 211)

75-7315	Stiffener Installation—Station 5A-5H circumference	1
75-7315-600	Segment Assembly—Station 5A-5H circumference stiffener	1
1-17237-2	Channel—Stiffener attaching	1
41-8097	Hook—String support	9
BAC1247-10S	Angle—Nut plate	4
75-7315-601	Segment Assembly—Station 5A-5H circumference stiffener	1
1-17237-2	Channel—Stiffener attaching	1
1-17632-3	Support Installation—Insulator	1
1-17632-4	Support Installation—Insulator	1
1-17632-5	Support Installation—Insulator	1
41-8604	Angle Assembly—Insulator support	3
41-5746-1	Stud—Plate	21
21-9221	Spacer—Nut plate	1
BAC1247-10S	Angle—Nut plate	1
75-7315-602	Segment Assembly—Station 5A-5H circumference stiffener	1
1-17237-2	Channel—Stiffener attaching	1
21-9221	Spacer—Nut plate	1
BAC1247-10S	Angle—Nut plate	2
75-7315-603	Segment Assembly—Station 5A-5H circumference stiffener	1
1-17237-3	Channel—Stiffener attaching	1
BAC1247-10S	Angle—Nut plate	1
75-7315-604	Segment Assembly—Station 5A-5H circumference stiffener	1
1-17237-3	Channel—Stiffener attaching	1
21-9221	Spacer—Nut plate	2
BAC1247-10S	Angle—Nut plate	1
75-7315-605	Segment Assembly—Station 5A-5H circumference stiffener	1
1-17237-3	Channel—Stiffener attaching	1
BAC1247-10S	Angle—Nut plate	1
55-7315-1	Segment Assembly—Station 5A-5H circumference stiffener	1
1-17237-2	Channel—Stiffener attaching	1
21-9221	Spacer—Nut plate	4
15-8097	Hook—String support	6
55-7315-2	Segment Assembly—Station 5A-5H circumference stiffener	1
1-17242-4	Angle—Stiffener attaching	1
1-22930-1	Angle—Stiffener tie	1
41-8097	Hook—String support	6
BAC1247-10S	Angle—Nut plate	2
55-7315-23	Segment Assembly—Station 5A-5H circumference stiffener	1
21-9221	Spacer—Nut plate	1
1-16283-1	Angle—Stiffener tie	2
1-17237-3	Channel—Stiffener attaching	1
55-7315-27	Segment Assembly—Station 5A-5H circumference stiffener	1
21-9221	Spacer—Nut plate	1
1-16283-1	Angle—Stiffener tie	2
1-17237-3	Channel—Stiffener tie	1

(Parts List No. 212)

55-7315-52	Segment Assembly—Station 5A-5H circumference stiffener	2
1-16283-1	Angle—Stiffener tie	4
1-17242-4	Angle—Stiffener attaching	2
1-22930-1	Angle—Stiffener tie	2

Stiffener Installation—Station 5A-5H Circumference

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
55-7315-53	Segment Assembly—Station 5A-5H circumference stiffener	2
1-16283	Angle—Stiffener tie	4
1-17242-5	Angle—Stiffener attaching	2
1-22930-1	Angle—Stiffener tie	2
55-7315-54	Segment Assembly—Station 5A-5H circumference stiffener	1
1-16283-1	Angle—Stiffener tie	2
1-17242-4	Angle—Stiffener attaching	1
1-22930-1	Angle—Stiffener tie	1
55-7315-55	Segment Assembly—Station 5A-5H circumference stiffener	1
1-16283	Angle—Stiffener tie	2
1-17242-5	Angle—Stiffener attaching	1
1-22930	Angle—Stiffener tie	1
55-7315-56	Segment Assembly—Station 5A-5H circumference stiffener	1
1-16283-1	Angle—Stiffener tie	2
1-17237-3	Channel—Stiffener attaching	1
55-7315-57	Segment Assembly—Station 5A-5H circumference stiffener	1
1-16283	Angle—Stiffener tie	2
1-17237-2	Channel—Stiffener attaching	1
55-7315-58	Segment Assembly—Station 5A-5H circumference stiffener	1
1-16283	Angle—Stiffener tie	2
1-17237-2	Channel—Stiffener attaching	1
55-7315-59	Segment Assembly—Station 5A-5H circumference attachment	1
1-16283-1	Angle—Stiffener tie	2
1-17237-3	Channel—Stiffener attaching	1
55-7315-60	Segment Assembly—Station 5A-5H circumference attachment	1
1-16283	Angle—Stiffener tie	2
1-17237-2	Channel—Stiffener attaching	1
55-7315-61	Segment Assembly—Station 5A-5H circumference stiffener	1
1-16283-1	Angle—Stiffener tie	2
1-17237-3	Channel—Stiffener attaching	1
55-7315-62	Segment Assembly—Station 5A-5H circumference stiffener	1
1-16283	Angle—Stiffener tie	2
1-17237-2	Channel—Stiffener attaching	1
55-7315-502	Segment Assembly—Station 5A-5H circumference stiffener	1
21-9221	Spacer—Nut plate	5
41-8097	Hook—String support	8
1-17242-5	Angle—Stiffener attaching	1
1-22930-1	Angle—Stiffener tie	1

(Parts List No. 213)

BAC1247-10S	Angle—Nut plate	3
55-7315-404	Segment Assembly—Station 5A-5H circumference stiffener	1
41-8097	Hook—String support	9
1-17242-4	Angle—Stiffener attaching	1
1-22930-1	Angle—Stiffener tie	1
BAC1247-10S	Angle—Nut plate	3
55-7315-406	Segment Assembly—Stations 5A-5H circumference stiffener	1
1-17237-2	Channel—Stiffener attaching	1
21-9221	Spacer—Nut plate	5
1-24975	Angle Assembly—Clinch nut	2
BAC1097-10-85S	Nut—Clinch	2
41-8604	Angle Assembly—Insulation support	1
41-5746-1	Stud—Plate	1
1-17632	Support Installation—Insulator	1
41-8604	Angle Assembly—Insulation support	1
41-5746-1	Stud—Plate	7
BAC1247-10S	Angle—Nut plate	1
55-7315-407	Segment Assembly—Station 5A-5H circumference stiffener	1

AVIALOGS.COM

FUSELAGE ASSEMBLY—FORWARD SECTION

Stiffener Installation—Station 5A-5H Circumference

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
55-7315-409	Segment Assembly—Station 5A-5H circumference stiffener	1
55-7315-413	Segment Assembly—Station 5A-5H circumference stiffener	1
1-17632-1	Support Installation—Insulator	1
41-8604	Angle Assembly—Insulation support	1
41-5746-1	Stud—Plate	7
1-17237-2	Channel—Stiffener attaching	1
41-8097	Hook—String support	8
21-9221	Spacer—Nut plate	1
BAC1247-10S	Angle—Nut plate	7
55-7315-415	Segment Assembly—Station 5A-5H circumference stiffener	1
1-17237-3	Channel—Stiffener attaching	1
41-8097	Hook—String support	8
BAC1247-10S	Angle—Nut plate	1
55-7315-422	Segment Assembly—Station 5A-5H circumference stiffener	1

Stiffener Installation—Station 5A-5H Circumference

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-17237-3	Channel—Stiffener attaching	1
41-8097	Hook—String support	9
BAC1247-10S	Angle—Nut plate	1
55-7315-427	Segment Assembly—Station 5A-5H circumference stiffener	1
1-17237-3	Channel—Stiffener attaching	1
1-23552	Support Installation—Insulator	1
41-8604	Angle Assembly—Insulation support	1
41-5746-1	Stud—Plate	7
21-9221	Spacer—Nut plate	2
BAC1247-10S	Angle—Nut plate	3
55-7315-428	Segment Assembly—Station 5A-5H circumference stiffener	1
1-17237-2	Channel—Stiffener attaching	1
	(Parts List No. 213A)	
21-9221	Spacer—Nut plate	2
BAC1247-10S	Angle—Nut plate	2
BAC1247-10S	Angle—Nut plate	10

FUSELAGE ASSEMBLY

Fuselage Assembly—Rear Section

(Parts List No. 214)

15-7331	Fuselage Assembly—Rear section	1
15-7016	Bulkhead Assembly—Station 6 rear	1
15-7017	Bulkhead Assembly—Station 7	1
9-3662	Stiffener Assembly—Bulkhead 7 circumference	1
1-18761	Angle—Floor support	1
1-18771	Angle—Stiffener tie	1
6-9469	Angle—Reinforcement	1
BAC1247-10S	Angle—Nut plate	1
7-1507	Bracket Installation—Tail wheel lock	1
7-1507-1	Bracket Assembly—Tail wheel lock	1
BAC1614-28	Spacer—⅛ rivet	2
41-2536-1-16	Plate—⅝ wide—24ST	1
43-11993	Lever Assembly—Tail wheel lock	1
43-11993-1	Lever—Tail wheel lock	1
1-16964	Bushing—Tail wheel lock	1
BAC285-32S	Bushing—5/16 press	1
BAC450-4	Bearing—Ball control	1
BAC1603-28	Spacer—No. 10 bolt	1
BAC1604-75	Spacer—¼ bolt	1
BAC203-23S	Bolt—10-32 drilled head	1
6-9215	Bracket Installation—Bulkhead 7 RH	1
6-9215-1	Bracket Assembly—Bulkhead 7 LH	1
BAC1614-28	Spacer—⅛ rivet	4
1-19000-3	Fair-lead Assembly—Miscellaneous	1
1-19000-4	Fair-lead—Miscellaneous	2
3-13430	Fair-lead Installation—Bulkhead 7 LH	1
1-19000-1	Fair-lead Assembly—Miscellaneous	1
1-19000-2	Fair-lead—Miscellaneous	2
1-18490	Angle Assembly—Floor attaching	1
1-18490-1	Angle Assembly—Floor attaching	1
1-18771	Angle—Stiffener tie	1
1-17557-2	Angle—Tab stiffener tie	1
1-17557-3	Angle—Tab stiffener tie	1
1-17557-4	Angle—Tab stiffener tie	1
1-17557-5	Angle—Tab stiffener tie	1
1-17557-6	Angle—Tab stiffener tie	1
1-17557-7	Angle—Tab stiffener tie	1
1-18467	Plate—Splice	1
1-18467-1	Plate—Splice	1
1-18493	Support—Bulkhead 7 channel	1
1-18493-1	Support—Bulkhead 7 channel	1
3-12974	Fitting—Tail gear lower	2
3-13563	Channel—Reinforcement	1
3-13580	Angle—Reinforcement	1
3-13580-1	Angle—Reinforcement	1

Fuselage Assembly—Rear Section

3-13612	Gusset—Bulkhead 7	1
3-13693	Angle—Reinforcement	1
6-9287	Support—Jacking cone	1
	(Parts List No. 215)	
6-9288	Support—Jacking cone	1
6-9305	Angle—Reinforcing	1
6-9305-1	Angle—Reinforcing	1
9-3582	Fitting—Tail gear upper	1
BAC1247-10	Angle—Nut plate	1
BAC1246-10S	Plate—Fiber nut	2
NAS55-S17.5A	Bolt—Close tolerance	2
NAS55-S14A	Bolt—Close tolerance	2
NAS55-S7A	Bolt—Close tolerance	16
NAS56-S14.5A	Bolt—Close tolerance	12
15-7017-15	Floor Assembly—Station 7 bulkhead	1
9-3423	Support Installation—Toilet	1
9-3423-2	Support Assembly—Toilet	1
41-7504	Angle Stiffener Tie	1
15-7018	Bulkhead Assembly—Station 8	1
15-7018-1	Web Assembly—Front station 8 bulkhead	1
1-18270	Gusset—Bulkhead 8 splice	2
1-18271	Gusset—Bulkhead 8 splice	1
1-18271-1	Gusset—Bulkhead 8 splice	1
1-18251-1	Angle Assembly—Floor support	1
1-21055	Angle—Floor support	1
1-21055-1	Angle—Floor support	1
BAC1246-10S	Plate—Fiber nut	2
15-7018-9	Web Assembly—Top aft station 8 bulkhead	1
3-13576	Terminal—Dorsal fin bulkhead 8	2
6-9204-2	Fitting—Bulkhead station 9	4
3-13492	Gusset—Bulkhead station 8	1
6-9231	Gusset—Bulkhead station 8 LH	1
6-9231-1	Gusset—Bulkhead station 8 RH	1
3-13493	Channel—Bulkhead station 8	1
3-13493-1	Channel—Bulkhead station 8	1
3-13494	Channel—Bulkhead station 8	1
3-13494-1	Channel—Bulkhead station 8	1
6-9298	Support Installation—Hangar stowage	1
1-18906	Fitting Assembly—Hangar stowage	2
BAC1603-172	Spacer—No. 10 bolt	4
15-9297	Bracket Installation—Controls. Dash number parts, shown on 15-9297 drawing are represented by dash numbers of 15-7602.	1
15-9297-2	Bracket Assembly—Controls	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-9297-3	Bracket Assembly—Controls	1
15-7602-1	Bracket Assembly—Controls	1
BAC1614-48	Spacer—⅛ rivet	1
15-7602-3	Bracket Assembly—Controls	1
BAC1614-43	Spacer—⅛ rivet	1
15-7602-4	Bracket Assembly—Controls	1
	(Parts List No. 216)	
BAC1614-43	Spacer—⅛ rivet	1
1-18456	Fair-lead Assembly—Control cable	1
1-18456-1	Fair-lead—Half control cable	2
1-18459	Fair-lead Assembly—Controls	2
1-18459-1	Fairlead—Half	2
6-11307	Bracket Assembly—Rudder servo LH	1
6-11307-2	Bracket—Rudder servo	1
6-11307-4	Bracket—Rudder servo	1
1-19001-73	Fair-lead Assembly—1 hole	1
1-19001-72	Fair-lead—Half	4
BAC1604-7	Spacer—¼ bolt	2
BAC1614-45	Spacer—⅛ rivet	1
6-11307-1	Bracket Assembly—Rudder servo RH	1
6-11307-3	Bracket—Rudder servo	1
6-11307-5	Bracket—Rudder servo	1
1-19001-73	Fair-lead Assembly—1 hole	1
1-19001-72	Fair-lead—Half	4
BAC1604-7	Spacer—¼ bolt	1
BAC1614-45	Spacer—⅛ rivet	1
6-9204-2	Terminal—Bulkhead station 9 fitting	2
6-10122-4	Terminal—Bulkhead station 8 and 9	2
3-15110	Filler—Bulkhead tube	1
3-15110-1	Filler—Bulkhead tube	1
BAC1603-172	Spacer—No. 10 bolt	1
BAC1603-175	Spacer—No. 10 bolt	2
BAC1604-6	Spacer—¼ bolt	4
BAC1604-8	Spacer—¼ bolt	4
BAC116A51DD	Bolt—Bearing	12
BAC116A54DD	Bolt—Bearing	12
BAC1246-10S	Plate—Fiber nut	2
15-7019	Bulkhead Assembly—Station 9	1
15-7019-22	Plate Assembly—Station 9 bulkhead	1
15-7019-24	Weatherseal—Station 9 bulkhead (Bridgeport Fabric Co. weatherseal No. X504B-25)	1
15-7603	Bracket Installation—Control bulkhead 9	1
15-7603-1	Bracket Assembly—Control bulkhead 9	1
BAC1614-43	Spacer—⅛ rivet	2
15-7603-5	Bracket Assembly—Control bulkhead 9	2
BAC1614-40	Spacer—⅛ rivet	4
15-7603-13	Bracket Assembly—Control bulkhead 9	1
15-7603-14	Bracket Pulley—Control bulkhead 9	1
BAC1614-32	Spacer—⅛ rivet	2
15-7603-16	Bracket Assembly—Control bulkhead 9	2
15-7603-17	Bracket Pulley—Control bulkhead 9	1
BAC1614-48	Spacer—⅛ rivet	2
BAC1614-58	Spacer—⅛ rivet	2
15-7603-6	Bracket Assembly—Control bulkhead 9	1
3-13584	Crank Assembly—Surface lock	1
BAC450-4	Bearing—Ball control	1
BAC1603-56	Spacer—No. 10 bolt	1
BAC1604-8	Spacer—¼ bolt	2
	(Parts List No. 217)	
1-18458	Fair-lead Assembly	2
1-18458-1	Fair-lead—Half	2
1-18459	Fair-lead Assembly	2
1-18459-1	Fair-lead—Half	2
BAC1603-6	Spacer—No. 10 bolt	4
BAC1603-10	Spacer—No. 10 bolt	4
BAC1604-8	Spacer—¼ bolt	4
BAC1604-6	Spacer—¼ bolt	4
NAS53-S34.5A	Bolt—Close tolerance	2
6-9299	Support Installation—Hangar stowage	1

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18906	Fitting Assembly—Hangar stowage	1
3-13744	Post Assembly—Bulkhead door	1
1-18814-2	Hinge—Half	2
3-13745-1	Post—Bulkhead door	1
3-13745	Post—Bulkhead door	1
3-13618	Channel Assembly—Elevator stop	1
3-13618-1	Channel Assembly—Elevator stop	1
1-18545	Bushing—Control surface lock	1
1-18546-3-70	Bushing—Control	1
6-9472	Bracket Assembly—Control surface lock	1
1-18512-1	Stop—Control crank	1
3-13617	Channel—Control surface lock	1
BAC1603-141	Spacer—No. 10 bolt	2
3-15115	Filler—Bulkhead tube	as req.
3-15115-1	Filler—Bulkhead tube	as req.
3-15115-2	Filler—Bulkhead tube	as req.
3-15110	Filler—Bulkhead tube	1
3-15110-1	Filler—Bulkhead tube	1
6-9204	Fitting—Bulkhead station 9	2
6-10122	Fitting—Bulkhead station 8 and 9 terminal	2
6-10122-5	Fitting—Bulkhead station 8 and 9 terminal	2
6-9230	Gusset—Bulkhead 9	1
6-9230-1	Gusset—Bulkhead 9	1
6-9230-2	Gusset—Bulkhead 9	1
6-9230-3	Gusset—Bulkhead 9	1
3-13466	Angle—Bulkhead 9	1
3-13466-1	Angle—Bulkhead 9	1
1-18717	Angle—Bulkhead web tie	4
1-18890	Angle—Tube support	1
1-18779	Angle—Bulkhead door	1
1-18779-1	Angle—Bulkhead door	1
1-18783	Angle—Bulkhead door	1
3-13743	Web—Bulkhead door	2
1-18586	Gusset—Bulkhead door	1
1-18586-1	Gusset—Bulkhead door	1
1-18652	Washer—Control surface lock	1
1-18682-10-199	Washer—Bolt	2
1-18704-32-11	Washer—.102 aluminum alloy	2
1-18704-32-13	Washer—.102 aluminum alloy	3
BAC116A54DD	Bolt—Bearing	12
BAC116A53DD	Bolt—Bearing	8
	(Parts List No. 218)	
BAC116A55S	Bolt—Bearing	12
BAC116A51DD	Bolt—Bearing	4
BAC113A52S	Bolt—Bearing	1
BAC113A54S	Bolt—Bearing	2
BAC113A55S	Bolt—Bearing	2
21-6758	Nut—1¼-18 lock	1
15-7020	Bulkhead Assembly—Station 10	1
8-1273	Terminal—Fin rear spar bulkhead	2
3-13607	Channel—Bulkhead station 10 rudder stop	1
1-18290	Channel—Bulkhead station 10 rudder stop	1
3-13509-1	Channel—Bulkhead station 10 rudder stop	1
3-13511	Channel—Bulkhead station 10 rudder hinge	1
3-13566	Fair-lead Installation—Control LH	1
3-13566-1	Fair-lead Installation—Control RH	1
3-13512	Tee—Bulkhead station 10	2
1-18288-1	Angle—Bulkhead station 10 elevator hinge	1
1-18261	Angle—Bulkhead station 10 stiffener attaching	8
1-18288	Angle—Bulkhead station 10 elevator hinge	1
1-18293	Angle—Bulkhead station 10 rudder hinge	1
1-18306	Angle—Bulkhead station 10 channel attaching LH	1
1-18306-1	Angle—Bulkhead station 10 channel attaching RH	1
3-13510	Angle—Bulkhead station 10 reinforcing LH	1
3-13510-1	Angle—Bulkhead station 10 reinforcing RH	1
1-18890	Angle—Tube support	1
1-18084	Gusset—Bulkhead station 10	1
1-18084-1	Gusset—Bulkhead station 10	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18362	Clip—Bulkhead station 10 LH	1
1-18362-1	Clip—Bulkhead station 10 RH	1
15-7011	Bulkhead Assembly—Station 11	1
6-9300	Beam Installation—Bulkhead station 11	1
6-9300-6	Beam Assembly—Bulkhead station 11	1
15-7027	Fin Installation—Dorsal	1
15-7027-1	Fin Assembly—Dorsal	1
15-7027-13	Door—Dorsal fin	1
6-8951	Support Installation—Formation lamp	3
6-8951-1	Patch Assembly—Formation lamp support	3
6-9461	Cover—Installation—Fin de-icer	1
1-18571	Guard—De-icer	1
BAC1446	Screw—Headless plug	6
BAC1330-101	Rivnut—115° countersunk head	12
15-7317	Rib Assembly—Station 8—1.42	1
15-7318	Rib Assembly—Dorsal fin station 7B	1
1-20334	Angle—Oxygen tube support	1
15-7319	Rib Assembly—Dorsal fin station 7A	1
1-19036	Angle—Circumference stiffener splice	1
3-13581	Rib—Former	14
3-13581-1	Rib Assembly—Dorsal fin former	1
	(Parts List No. 218A)	
3-13581	Rib—Dorsal fin	1
1-21066	Angle Assembly	1
3-13582	Rib—Dorsal fin former	1
	(Parts List No. 219)	
6-9315	Former—Dorsal fin	1
6-9316	Rib—Former dorsal fin	1
6-9317	Rib—Former dorsal fin	1
6-9318	Rib—Former dorsal fin	1
9-3420-1	Rib Assembly—Dorsal fin station 6H	1
1-21066	Angle Assembly	1
9-3422-1	Rib Assembly—Dorsal fin station 6F	1
1-21066	Angle Assembly	1
9-3427	Rib—Former	1
15-7320-1	Rib Assembly—Dorsal fin station 7 and 4, 3	1
1-21066	Angle Assembly	1
15-7321-1	Rib Assembly—Dorsal fin station 6K	1
1-21066	Angle Assembly	1
15-7322-1	Rib Assembly—Dorsal fin station 6J	1
1-20335	Angle—De-icer tube support	1
1-21066	Angle Assembly	1
15-7323-3	Rib Assembly—Dorsal fin station 6I	1
1-21066	Angle Assembly	1
15-7375	Rib Assembly—Dorsal fin station 7-11	1
1-21066	Angle Assembly	1
1-20334	Angle—Oxygen tube support	1
1-20335	Angle—De-icer tube support	1
6-8961-3	Rib Assembly—Dorsal fin station 6E	1
1-21066	Angle Assembly	1
9-3421-3	Rib Assembly—Dorsal fin station 6G	1
1-21066	Angle Assembly	1
3-13581-1	Rib—Former	15
3-13439-1	Rib—Dorsal fin station 6C	1
6-8962-3	Rib—Dorsal fin station 6D	1
BAC1246-10S	Plate—Fiber Nut	8
BAC1330-101	Rivnut—115° countersunk head	68
BAC1330-105	Rivnut—115° countersunk head	16
9-3722	Support Installation—Recognition lamp (upper)	1
55-7316	Stiffener Installation—Station 6A-9A circumference Dash number parts, shown on 55-7316 drawing are represented by dash numbers of 15-7316.	1
15-7316-17	Segment Assembly—Top stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	2
1-17557-1	Angle—Tabulated stiffener tie	2

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7316-22	Segment Assembly—Top stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	2
1-17557-1	Angle—Tabulated stiffener tie	2
15-7316-29	Segment Assembly—Top stiffener station 6A-9A circumference	1
	(Parts List No. 220)	
1-17557	Angle—Tabulated stiffener tie	2
1-17557-1	Angle—Tabulated stiffener tie	2
15-7316-62	Segment Assembly—Stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	4
1-17557-1	Angle—Tabulated stiffener tie	1
BAC1247-10S	Angle—Nut plate	2
15-7316-63	Segment Assembly—Stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	1
1-17557-1	Angle—Tabulated stiffener tie	4
15-7316-70	Segment Assembly—Stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	3
1-17557-1	Angle—Tabulated stiffener tie	1
BAC1247-10S	Angle—Nut plate	1
15-7316-71	Segment Assembly—Stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	1
1-17557-1	Angle—Tabulated stiffener tie	3
15-7316-74	Segment Assembly—Stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	8
1-17557-1	Angle—Tabulated stiffener tie	3
BAC1247-10S	Angle—Nut plate	1
15-7316-75	Segment Assembly—Stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	1
1-17557-1	Angle—Tabulated stiffener tie	5
15-7316-85	Segment Assembly—Stiffener station 6A-9A circumference	1
55-7316-400	Segment Assembly—Stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	4
1-17557-1	Angle—Tabulated stiffener tie	3
55-7316-402	Segment Assembly—Stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	4
1-17557-1	Angle—Tabulated stiffener tie	3
55-7316-404	Segment Assembly—Stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	4
1-17557-1	Angle—Tabulated stiffener tie	3
55-7316-406	Segment Assembly—Stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	3
1-17557-1	Angle—Tabulated stiffener tie	1
BAC1246-10S	Plate—Fiber nut	1
55-7316-408	Segment Assembly—Stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	1
1-17557-1	Angle—Tabulated stiffener tie	3
55-7316-410	Segment Assembly—Stiffener station 6A-9A circumference	1
1-17557	Angle—Tabulated stiffener tie	3
1-17557-1	Angle—Tabulated stiffener tie	3
55-7316-414	Segment Assembly—Stiffener station 6A-9A circumference	1
55-7316-415	Segment Assembly—Stiffener station 6A-9A circumference	1
55-7316-416	Segment Assembly—Stiffener station 6A-9A circumference LH	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
55-7316-417	Segment Assembly—Stiffener station 6A-9A circumference LH	1
55-7316-418	Segment Assembly—Stiffener station 6A-9A circumference top	1
1-17571	Splice Installation—Circumference stiffener	14
1-17589	Splice Installation—Circumference stiffener	2
1-20202	Splice Installation—Circumference stiffener	1
1-20565	Splice Installation—Circumference stiffener	1
3-12991	Splice Installation—Circumference stiffener	2
	(Parts List No. 221)	
6-9701	Splice Installation—Circumference stiffener	3
6-9701-1	Splice Installation—Circumference stiffener	3
1-20391	Splice Installation—Circumference stiffener	1
1-19036	Angle—Circumference stiffener splice	2
1-19664	Angle—Longeron tie	4
1-19664-1	Angle—Longeron tie	4
55-7014	Stiffener installation—Station 6-11 longeron	1
1-19832	Channel—Stiffener tie	7
1-19832-1	Channel—Stiffener tie	7
1-18277-2	Tee—Stiffener tie	2
1-18277-3	Tee—Stiffener tie	1
1-18278	Tee—Stiffener tie	11
1-18322-4	Angle—Stiffener tie	1
1-18322-5	Angle—Stiffener tie	1
1-18322-6	Angle—Stiffener tie	1
1-18322-7	Angle—Stiffener tie	1
1-18503	Splice Installation—Longitudinal stiffener	18
1-23535	Splice Installation—Longitudinal stiffener	13
1-18504	Splice Installation—Longitudinal stiffener	1
BAC1247-108S	Angle—Nut plate	40
14-2061	Stiffener Installation—Station 7B	1
14-2061-1	Stiffener Assembly—Station 7B	1
1-19030	Angle—Stiffener tie	1
1-19030-1	Angle—Stiffener tie	1
3-13711	Angle—Stiffener tie	1
3-13711-1	Angle—Stiffener tie	1
BAC1247-110S	Angle—Nut plate	2
9-3669	Stiffener Installation—Station 7—4.3	1
9-3669-1	Channel Assembly—Station 7 and 4, 3	1
1-17557-8	Angle—Tabulated Stiffener tie	1
1-17557-9	Angle—Tabulated stiffener tie	1
1-17557-10	Angle—Tabulated stiffener tie	1
1-17557-11	Angle—Tabulated stiffener tie	1
1-17557-12	Angle—Tabulated stiffener tie	1
1-17557-13	Angle—Tabulated stiffener tie	1
BAC1247-10S	Angle—Nut plate	1
1-18771	Angle—Stiffener tie	2
9-3763	Stiffener Installation—Station 8 and 6.24 circumference	1
9-3763-1	Segment Assembly—Stiffener station 8 and 6.24 circumference	1
1-17557-20	Angle—Tabulated stiffener tie	2
BAC1246-10	Plate—Fiber nut	2
9-3670	Stiffener Installation—Circumference station 7A	1
9-3670-1	Stiffener Assembly—Circumference station 7A	1
1-18987	Angle—Stiffener tie	1
1-18987-1	Angle—Stiffener tie	1
1-18988	Angle—Stiffener tie	1
1-18988-1	Angle—Stiffener tie	1
BAC1247-10S	Angle—Nut plate	3
15-7513	Frame Installation—Main entrance door	1
15-7513-1	Frame Assembly—Main entrance door	1
3-13603	Angle Installation—Door Frame	1
1-18520	Angle—Stiffener tie	1
	(Parts List No. 222)	
3-13603-1	Angle Installation—Door frame	2
1-18520-1	Angle—Stiffener tie	2
3-13603-2	Angle Installation—Door frame	1
1-18520-2	Angle—Stiffener tie	1

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-13603-3	Angle Installation—Door frame	2
1-18520-3	Angle—Stiffener tie	2
3-13603-4	Angle Installation—Door frame	3
1-18522	Angle—Stiffener tie	3
3-13603-5	Angle Installation—Door frame	1
1-18522-1	Angle—Stiffener tie	1
3-13603-6	Angle Installation—Door frame	2
1-18522-2	Angle—Stiffener tie	2
3-13603-7	Angle Installation—Door frame	2
1-18522-3	Angle—Stiffener tie	2
1-18557-10	Handle Assembly—Door release	1
1-18557-9	Handle—Tube door release	1
1-21946	Terminal—Swaged special	2
3-16132-8	Decalcomania—Miscellaneous	1
BAC1828-23	Terminal—Dead end cable	2
3-13628	Support Assembly—Door release	1
1-18600-2	Angle—Door frame	1
3-13727	Channel—Support	1
21-3232	Clip—Spring	2
BAC1603-32	Spacer—No. 10 bolt	2
BAC1603-44	Spacer—No. 10 bolt	2
46-9419-403	Support Installation—Door hinge LH	1
46-9419-402	Support Installation—Door hinge RH	1
46-9419-401	Support Assembly—Door hinge LH	1
46-9419-400	Support Assembly—Door hinge RH	1
1-21943	Spring—Door pin	2
3-13616	Support—Door hinge LH	1
3-13616-1	Support—Door hinge RH	1
1-18842	Hinge Assembly—Main door	1
1-18842-1	Hinge Assembly—Main door	1
1-18842-2	Hinge—Main door LH	1
1-18842-3	Hinge—Main door RH	1
BAC366-8S	Bushing—Bearing	4
1-18686	Angle—Corner clip	2
1-18843	Angle—Support tie	1
1-18843-1	Angle—Support tie	1
1-18856	Gusset—Hinge support	2
1-18889-2	Cover—Water tite	1
1-18889-3	Cover—Water tite	1
BAC1604-29	Spacer—¼ bolt	2
1-18875	Cap Assembly—Door catch	1
1-18875-1	Cap—Door catch	1
41-7171-12-32	Washer—1/16 neoprene	2
1-18599	Gusset—Door frame	2
1-18600	Angle—Door frame	2
	(Parts List No. 223)	
1-18600-1	Angle—Door frame	2
1-18863-1	Plate—Striker	1
1-18884	Plate—Door frame	1
15-7513-33	Seal Assemblies—Main Entrance Door	1
15-7513-34	Seal—Main entrance door (Kirkhill Rubber Co.)	2
15-7513-35	Seal—Main entrance door (Kirkhill Rubber Co.)	2
1-20565	Splice Installation—Circumference stiffener	2
1-23535	Splice Installation—Longitudinal	2
1-17557	Angle—Tabulated stiffener tie	4
1-17557-1	Angle—Tabulated stiffener tie	2
1-18601	Angle—Tabulated stiffener tie	1
1-19056-1	Angle—Stiffener tie	1
3-13656	Support Installation—Dome light switch	1
1-20360	Angle—Stiffener tie	1
1-20361	Angle—Stiffener tie	1
BAC1247-110S	Nut plate	3
15-7514	Frame Installation—Emergency exit	1
15-7514-1	Frame Assembly—Emergency exit	1
15-7514-21	Channel Assembly—Emergency exit lower	1
15-7514-22	Channel Assembly—Emergency exit upper	1
3-13666	Channel—Hinge support lower	1
3-13666-1	Channel—Hinge support upper	1
BAC344-4-96	Bushing—Staked	2

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18553	Gusset—Door frame	2
1-18554	Angle—Door frame	4
1-18555-3	Gusset—Door frame	1
1-18593-2	Spring—Door pin	1
1-18593-3	Spring—Door pin	1
1-18555-2	Gusset—Door frame	1
1-18553-1	Gusset—Door frame	2
15-7514-34	Seal Assembly—Emergency exit frame	1
15-7514-16	Seal—Side emergency exit frame (Kirkhill Neoprene Stock No. 117, Kirkhill Rubber Co., Los Angeles)	2
15-7514-32	Seal—Corner reinforcing emergency exit frame (Kirkhill Neoprene Stock No. 117)	4
15-7514-35	Seal—Top and bottom—emergency exit frame (Kirkhill Neoprene Stock No. 117)	2
1-18557-1	Handle Assembly—Door release	1
1-18557-9	Handle—Door release	1
1-18556	Terminal—Swaged special	2
3-16132-8	Decalcomania—Miscellaneous	1
BAC1828-23	Terminal—Dead end cable	2
3-13665	Support Installation—Release handle	1
3-13665-1	Bracket Assembly—Release handle support	1
21-3232	Clip—Spring	2
21-6909-0-40	Spacer—No. 10 bolt—fiber	1
BAC1603-32	Spacer—No. 10 bolt	2
1-20202	Splice Installation—Circumference stiffener	1
1-18663	Angle—Door frame	3
1-17557	Angle—Tabulated stiffener tie	3
	(Parts List No. 224)	
1-18559	Angle—Stiffener attaching	1
1-18559-1	Angle—Stiffener attaching	1
1-18552	Angle—Stiffener attaching	2
1-18552-1	Angle—Stiffener attaching	1
1-18277-3	Tee—Stiffener tie	1
1-23535	Splice Installation—Longitudinal stiffener	3
15-7511	Walk Installation—Station 8-11	1
15-7606	Door Installation—Main entrance	1
15-7606-20	Door Assembly—Main entrance	1
15-7606-30	Seal—Main entrance door	2
15-7606-1	Frame Assembly—Main entrance door	1
1-18686-1	Angle—Corner clip	2
1-18686-4	Angle—Corner clip	10
1-18686-2	Angle—Corner clip	2
1-18555-2	Gusset—Door frame	2
1-18725	Gusset—Door frame	1
1-18725-1	Gusset—Door frame	2
1-18726	Gusset—Door frame	1
1-18570	Angle Assembly—Latch attaching	1
1-22603	Angle Assembly—Latch attaching	1
1-18822	Hinge Assembly—Door	2
1-18630	Hinge—Door	2
BAC344-4-363	Bushing—Staked	2
3-16120	Plate Assembly—Escutcheon	1
1-18862	Escutcheon	1
1-20244-1	Knob Assembly—Door	1
3-13737-4	Strap Assembly—Door	1
3-13737-2	Snap Swivel—Door Stop (North and Judd Manufacturing Co., No. 029—nickel plated)	1
3-13737-3	Strip—Door strap	1
51-16-1	Latch Assembly—Door ND (Rite Hardware Co., No. 5290, 502 Douillard St., Los Angeles, California)	1
51-17-2	Knob Assembly—Door (Rite Hardware Co., R25-1D)	1
51-15	Lever—Door latch	1
1-18683	Fitting—Door hinge	1
1-18683-1	Fitting—Door hinge	1
3-13721	Window—Main entrance door	1
3-13722	Retainer—Window	1
1-18521	Spacer—Window	1

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC113S-15A	Bolt—Bearing	4
1-18686-4	Angle—Corner clip	1
1-22602	Angle—Corner clip	1
15-8520	Step Installation—Main door	1
15-8520-1	Step Assembly—Main door	1
15-8520-10	Hinge	1
15-8520-4	Pad—Main door step	1
15-7595	Door Installation—Emergency exit	1
15-7595-1	Door Assembly—Emergency exit	1
15-7595-14	Door Assembly—Emergency exit door spot-weld	1
	(Parts List No. 225)	
15-7595-13	Door Assembly—Frame emergency exit D.	1
1-18553	Gusset—Door frame	2
1-18555-1	Gusset—Door frame	4
1-18686-3	Angle—Corner clip	4
1-18786	Gusset—Exit door	4
1-18686	Angle—Corner Clip	4
3-13714	Latch Installation—Emergency exit door	1
3-13714-360	Handle—Emergency exit door latch (Rite Hardware Co., Los Angeles, California)	1
53-1C	Latch Assembly—Exit door (BAC Spec. 1-18788) (Rite Hardware Co., Los Angeles, California)	1
25-1F	Knob Assembly—Door (Rite Hardware Co., Los Angeles, California)	1
1-18789	Plate—Door latch	1
1-18661-3	Hinge Assembly—Emergency exit door	1
1-18661-4	Hinge Assembly—Emergency exit door	1
1-18661-5	Hinge—Emergency exit door	2
BAC344-4-190	Bushing—Staked	2
BAC1246-10S	Plate—Fiber nut	2
3-13714-1	Plate Striker Installation—Emergency exit door	1
1-18863-1	Plate—Striker	1
15-7652	Fairing Installation—Elevating to body	1
15-7652-1	Fairing Installation—Elevating to body	1
15-7652-2	Fairing Assembly—Elevating to body	1
15-7652-3	Fairing Assembly—Elevating to body	1
3-13735	Rib Assembly—Elevating fairing	1
3-13735-1	Rib Assembly—Elevating fairing	1
BAC1246-110S	Plate—Fiber nut	4
6-9443	Rib—Elevating fairing	2
15-7652-15	Fairing Assembly—Lower elevating to body LH	2
15-7652-16	Fairing Assembly—Lower elevating to body RH	2
BAC1246-110S	Plate—Fiber nut	6
15-7312	Wheel Well Installation	1
15-7312-1	Wheel Well Assembly	1
15-7312-13	Cover Assembly—Wheel well	1
15-7312-12	Cover Assembly—Wheel well	1
BAC1246-10S	Plate—Fiber nut	4
15-7312-26	Matting—Rubber Wheel Well (Goodrich)	1
15-7312-27	Boot Assembly—Wheel well	1
15-7312-21	Cord—Wheel well	1
15-7312-28	Boot—Wheel well	1
1-21980	Clamp Assembly—Tail wheel boot	1
15-7312-50	Angle Assembly—Wheel	1
15-7312-32	Floor Assembly—Wheel well	1
15-7312-33	Floor Assembly—Wheel well	1
15-8767	Floor Installation—Station 6-6B	1L
15-8767-1	Floor Assembly—Station 6-6B	1
	(Parts List No. 226)	
15-8767-6	Wood Assembly—Station 6-6B floor	1
15-8767-11	Floor—Station 6-6B	1
15-8767-12	Side—Station 6-6B floor	1
15-8767-13	Block—Station 6-6B floor	1
15-8767-9	Zee Assembly—Station 6-6B floor	1
15-8767-10	Zee Assembly—Station 6-6B floor	1
15-8767-7	Zee Nut—Station 6-6B floor	4

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-7604	Floor Installation—Side gunners station 6-7	1
3-13752	Bracket Assembly—Floor station 6G LH	1
3-13752-1	Bracket Assembly—Floor station 6G RH	1
3-13758	Bracket Assembly—Floor station 6I LH	1
3-13758-1	Bracket Assembly—Floor station 6I RH	1
3-13759	Bracket Assembly—Floor station 6H LH	1
3-13759-1	Bracket Assembly—Floor station 6H RH	1
3-13762	Bracket Assembly—Floor station 6J	1
3-13669	Bracket Assembly—Floor station 6K	1
46-9414	Floor Assembly—Station 6C-6E	1
46-9414-400	Floor—Station 6C-6E	1
46-9414-401	Matting—Rubber station 6C-6E floor (Goodrich)	1
6-9414-5	Angle—Station 6C-6E floor	1
41-4858	Washer—No. 10 FH screw	19
6-9414-1	Floor Assembly—Station 6C-6E	1
41-4858	Washer—No. 10 FH screw	16
6-9414-2	Floor—Station 6C-6E	1
6-9414-6	Matting—Station 6C-6E floor	1
46-9415	Floor Assembly—Station 6E-6G	1
46-9415-1	Floor Assembly—Station 6E-6G	1
41-4858	Washer—No. 10 FH screw	32
6-9415-2	Floor—Station 6E-6G	2
6-9415-3	Matting—Rubber station 6E-6G floor (Goodrich) LH	1
6-9415-6	Matting—Rubber station 6E-6G floor (Goodrich) RH	1
6-9416	Floor Assembly—Station 6G-6I LH	1
6-9416-1	Floor Assembly—Station 6G-6I RH	1
41-4858	Washer—No. 10 FH screw	32
6-9416-2	Floor—Station 6G-6I	2
6-9416-3	Matting—Rubber station 6G-6I floor (Goodrich) LH	1
6-9416-7	Matting—Rubber station 6G-6I floor (Goodrich) RH	1
6-9417	Floor Assembly—Station 6I-6K	1
41-4858	Washer—No. 10 FH screw	17
6-9417-1	Floor—Station 6I-6K	1
6-9417-5	Matting—Rubber station 6I-6K floor (Goodrich)	1
1-22707-30	Strap Assembly—Buckle ¾" wide, no drawing	1
3-14966	Bracket Assembly—Floor station 6F LH	1
	(Parts List No. 227)	
3-14966-1	Bracket Assembly—Floor station 6F RH	1
3-15104	Bracket Assembly—Antenna fair-lead	1
3-15153	Bracket Assembly—Floor station 6D	1
3-13609	Bracket Assembly—Floor station 6E LH	1
3-13609-1	Bracket Assembly—Floor station 6E RH	1
3-13747-1	Bracket Assembly—Floor station 6D RH	1
1-20389	Bracket—Antenna fair-lead	1
41-4858	Washer—No. 10 FH screw	56
BAC1456-10-10	Screw—Flathead	56
55-7604-401	Matting—Rubber (Goodrich)	1
55-7604-402	Floor Assembly—Side gunner station 6-7	1
1-19077-4	Floor—Side gunner	1
65-7604-501	Floor Assembly—Side gunner station 6-7	1
9-4914	Floor—Side gunner station 6-7	1
15-7480	Door Installation—Bulkhead station 9	1
15-7480-1	Filler—Bulkhead station 9 door	2
15-7480-2	Strip—Bulkhead station 9 door (Bridgeport Fabric Co. weatherstrip seal No. X504B-25)	2
15-7347	Door Assembly—Bulkhead station 9	1
1-18814-1	Hinge—Half	2
1-19045	Plate—Bulkhead 9 door latch	1
1-19046	Plate—Bulkhead 9 door latch	1
1-19047	Plate—Bulkhead 9 door latch	1
1-19048	Spacer—Micarta	1
1-19049	Latch—Bulkhead door station 9	1
21-8962-48-13	Washer—.050 resistant steel	1
15-7347-1	Door—Bulkhead station 9	1
15-7347-2	Weatherstrip—Bulkhead station 9	1

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7347-3	Knob—Oak bulkhead station 9 (Seattle Hardware Co., No. F21½ catalog page 566)	2
15-7347-4	Teenut—Bulkhead station 9 No. 48444 (United-Carr Fastener Corp.)	7
15-7347-5	Filler—Bulkhead station 9	2
BAC1447-4-6	Screw—Round-head recessed sheet metal	12
BAC1447-6-6	Screw—Round-head recessed sheet metal	11
BAC1603-13	Spacer—No. 10 bolt	1
BAC1449-8-14	Screw—Flathead recessed sheet metal	16
3-13565	Web—Bulkhead station 9	1
1-18814-3	Pin—Half hinge	2
9-3660	Mast Installation—Marker antenna	1
9-3660-1	Mast Assembly—Marker antenna	1
9-3660-2	Tube—Marker antenna mast	1
9-3660-3	Clip—Antenna support	1
1-18713	Cap—Antenna mast	1
BAC1603-34	Spacer—No. 10 bolt	2
	(Parts List No. 228)	
6-10137	Mast Installation—Marker antenna	1
6-10137-1	Mast Assembly—Marker antenna	1
6-10137-2	Tube—Marker anetnna mast	1
6-10137-3	Clip—Marker antenna mast	1
6-10137-5	Filler—Marker antenna mast	1
1-18713-1	Cap—Marker antenna mast	1
1-21401	Filler—Marker antenna mast	1
15-7374	Panel Installation—Side gun window LH	1
15-7374-1	Panel Installation—Side gun window RH	1
15-7374-2	Panel Assembly—Side gun window LH	1
15-7374-3	Panel Assembly—Side gun window RH	1
1-18671	Clip—Side window LH	1
1-18671-1	Clip—Side window RH	1
1-18693	Clip—Side window	2
1-18693-1	Clip—Side window	2
1-18694	Clip—Side window LH	4
1-18694-1	Clip—Side window RH	4
1-18701	Clip—Side window LH	1
1-18701-1	Clip—Side window RH	1
1-18702	Clip—Side window LH	1
1-18702-1	Clip—Side window RH	1
1-18380-8-250	Washer—Side window	16
1-19066-1	Stop—Front side gun window	4
1-19066	Stop—Rear side gun window	4
1-19080	Filler—Side window	4
6-9265	Hook Assembly—Side gun window LH	1
6-9265-1	Hook Assembly—Side gun window RH	1
6-9265-2	Hook Assembly—Side gun window RH	1
6-9265-3	Hook Assembly—Side gun window LH	1
1-18379-3	Hook—Side window	4
1-18393	Plate Assembly—Side window	4
BAC346-8-196	Bushing—Staked	4
1-18385	Bracket Assembly—Side window (used on -0 and -1 only)	2
1-18401	Bracket Assembly—Side window (used on -2 and -3 only)	2
1-18457-1	Washer—Side window	8
1-18560	Spring—Side window (used on -0 and -2 only)	2
1-18560-1	Spring—Side window (used on -1 and -3 only)	2
15-7044	Spoiler Installation—Side window LH	1
15-7044-1	Spoiler Installation—Side window RH	1
15-7044-2	Spoiler Assembly—Side window LH	1
15-7044-3	Spoiler Assembly—Side window RH	1
15-7044-8	Frame Assembly—Side window	1
15-7044-9	Frame Assembly—Side window	1
1-18499	Latch—Spoiler	2
1-18499-1	Latch—Spoiler	2
1-18972	Plate—Spoiler latch	4
3-13592	Bracket—Spoiler drain (used on -8)	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 229)	
3-13592-1	Bracket—Spoiler drain (used on -9)	1
3-13592-2	Bracket—Spoiler drain (used on -9)	1
3-13592-3	Bracket—Spoiler drain (used on -8)	1
15-7044-10	Door Assembly—Side window spoiler LH	1
15-7044-11	Door Assembly—Side window spoiler RH	1
15-7044-12	Hinge—Side window spoiler door	2
1-18946-4	Hinge—Spoiler	2
1-18497	Bracket—Spoiler channel	2
1-18511	Spring—Spoiler hinge	4
3-13589	Angle—Spoiler	1
3-13589-1	Angle—Spoiler	1
3-13590	Angle—Spoiler	1
3-13590-1	Angle—Spoiler	1
3-13591	Angle—Spoiler	1
3-13591-1	Angle—Spoiler	1
1-18498	Lever Assembly—Spoiler	2
1-18946-1	Hinge—Half spoiler	2
1-18510	Spring—Spoiler hinge	2
1-18946-2	Hinge—Spoiler	2
15-7661	Beam Installation—Side gun LH	1
15-7661-1	Beam Installation—Side gun RH	1
15-7661-2	Beam Assembly—Side gun LH	1
15-7661-3	Beam Assembly—Side gun RH	1
1-18587-2	Clip—Side gun beam LH	1
1-18587-3	Clip—Side gun beam RH	1
1-18883-4	Clip—Side gun beam	1
1-18883-5	Clip—Side gun beam	1
1-18883-6	Clip—Side gun beam	1
1-18883-7	Clip—Side gun beam	1
1-18929-2	Clip—Side gun beam	1
1-18929-3	Clip—Side gun beam	1
1-18385	Bracket Assembly—Side window	2
1-18401	Bracket Assembly—Side window	2
15-7573	Window Assembly—Side gun	1
15-7573-1	Window Assembly—Side gun	1
15-7573-2	Panel Assembly—Side gun window LH	1
15-7573-3	Panel Assembly—Side gun window RH	1
1-18369	Plate—Side window	16
15-7573-8	Window—Plexiglas side gun,	1
15-7573-9	Window—Plexiglas side gun,	1
15-7573-10	Retainer—Side gun window	1
15-7573-11	Retainer—Side gun window	1
15-7573-12	Strip—Side gun window (Kirkhill Rubber Co., Los Angeles, California)	2
15-7573-13	Strip—Side gun window (Everseal Prod. Co.)	2
15-7573-14	Tube—Side gun window	2
15-7573-15	Filler—Side gun window	2
49-3685	Handle Assembly—Side gun window	2
	(Parts List No. 230)	
1-18913-5	Link Assembly—Side window	4
1-18913-6	Link Assembly—Side window	4
1-24614	Angle—Link Stop	8
1-24613-2	Link—Side gun window	8
BAC326-17S	Bushing—Bearing	16
1-24613-1	Link—Side gun window	8
1-24613-4	Link—Side gun window	8
9-3685-2	Slider—Side gun window handle	8
9-3685-3	Slider—Side gun window handle	2
9-3685-4	Slider—Side gun window handle	2
9-3685-5	Slider—Side gun window handle	2
9-3685-6	Slider—Side gun window handle	2
49-3685-400	Tube—Side gun window handle	2
1-17557-1	Angle—Tab stiffener tie (used on -2)	4
1-17557	Angle—Tab stiffener tie (used on -3)	4
1-18692	Angle—Tab stiffener tie	1
1-18692-1	Angle—Tab stiffener tie	1
1-22681	Plate Installation—Sliding window	1
1-22681-1	Plate Installation—Sliding window	1
1-22689	Plate—Sliding window	2

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC326-17S	Bushing—Bearing	12
BAC326-64S	Bushing—Bearing	4
1-18503	Splice Installation—Longitudinal stiffener	10
1-17571	Splice Installation—Circumference stiffener	8
1-18900	Splice Installation—Longitudinal stiffener	2
1-21977	Splice—Circumference stiffener	2
1-18581	Clip—Side window (used on -1)	1
1-18581-1	Clip—Side window (used on -2)	2
1-18581-2	Clip—Side window (used on -1)	1
1-18696-2	Clip—Side window	1L
1-18696-3	Clip—Side window	1R
1-18698	Clip—Side window	1L
1-18698-1	Clip—Side window	1R
1-18930	Clip—Side window	2
6-9580	Boot Installation—Dorsal fin	1
6-9580-1	Boot Assembly—Dorsal fin	1
6-9580-2	Boot—Dorsal fin	1
1-19696	Frame—Dorsal fin boot	1
1-19695	Clip—Dorsal fin boot	13
15-7633	Beam Installation—Elevator hinge support LH	1
15-7633-1	Beam Installation—Elevator hinge support RH	1
6-9340	Bracket Installation—Elevator tab LH	1
6-9340-1	Bracket Installation—Elevator tab RH	1
6-9340-2	Bracket Assembly—Elevator tab LH	1
6-9340-3	Bracket Assembly—Elevator tab RH	1
6-9340-9	Bracket—Elevator tab	1
6-9340-10	Bracket—Elevator tab	1
BAC1614-27	Spacer—⅛ rivet	2
BAC1614-34	Spacer—⅛ rivet	2
	(Parts List No. 231)	
BAC1603-8	Spacer—No. 10 bolt	4
15-7633-13	Beam Assembly—Elevator hinge support	1
15-7633-14	Beam Assembly—Elevator hinge support	1
3-13704	Channel Assembly—Elevator hinge support	2
3-13704-1	Channel—Elevator hinge support	2
NAS53-S16A	Bolt—Close tolerance	8
BAC1603-51	Spacer—No. 10 bolt	8
1-18682-10-199	Washer—Bolt	2
NAS53-S32.5A	Bolt—Close tolerance	2
BAC1603-51	Spacer—No. 10 bolt	4
BAC1603-72	Spacer—No. 10 bolt	2
15-7541	Beam Installation—Rudder trim tab	1
15-7541-18	Bracket Assembly—Rudder trim tab	1
BAC1603-28	Spacer—No. 10 bolt	2
BAC1614-22	Spacer—⅛ rivet	2
BAC1614-24	Spacer—⅛ rivet	2
BAC1614-28	Spacer—⅛ rivet	2
BAC1603-12	Spacer—No. 10 bolt	2
15-7665	Support Installation—Bottom turret	1
9-3589	Beam Assembly—Bottom turret support	1
BAC1249-616S	Plate—Fiber nut	6
1-19855	Channel—Stiffener tie	2
1-19855-1	Channel—Stiffener tie	2
3-13763	Channel—Tab stiffener tie	2
3-13763-1	Channel—Tab stiffener tie	2
3-13763-2	Channel—Tab stiffener tie	1
3-13763-3	Channel—Tab stiffener tie	1
3-13763-4	Channel—Tab stiffener tie	1
3-13763-5	Channel—Tab stiffener tie	1
15-7665-14	Channel Assembly—Bottom turret support	1
15-7665-16	Channel Assembly—Bottom turret support	1
BAC1247-10S	Angle—Nut plate	2
9-4609	Support—Installation—Antenna reel	1
9-4609-1	Support Assembly—Antenna reel	1
6-10739	Plate Assembly—Antenna reel	1
BAC1246-10	Plate—Fiber nut	2
6-10740	Support—Antenna reel	1
1-16283-19	Angle—Antenna reel support	3
35A2277	Insulator—Type IN-82 (government furnished)	1
15-7780	Support Installation—Lower turret bottom	1
15-7780-1	Support Assembly—Lower turret bottom	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-20180-2	Bracket—Turret support	1
1-20180-3	Bracket—Turret support	1
1-20181	Bracket—Turret support	1
1-20181-1	Bracket—Turret support	1
1-20182	Bracket—Turret support	1
1-20182-1	Bracket—Turret support	1
1-20183	Bracket—Turret support	1
	(Parts List No. 232)	
1-20183-1	Bracket—Turret support	1
1-20184	Bracket—Turret support	1
1-20184-1	Bracket—Turret support	1
1-17557-16	Angle—Tabulated stiffener tie	1
1-17557-17	Angle—Tabulated stiffener tie	1
1-17557-18	Angle—Tabulated stiffener tie	1
1-17557-19	Angle—Tabulated stiffener tie	1
1-17557-20	Angle—Tabulated stiffener tie	1
1-17557-21	Angle—Tabulated stiffener tie	1
1-20035	Angle—Turret support	1
1-20035-1	Angle—Turret support	1
1-20041	Angle—Stiffener tie	2
1-20041-1	Angle—Stiffener tie	2
1-20042	Angle—Stiffener tie	1
1-20042-1	Angle—Stiffener tie	1
1-21481	Angle—Stiffener tie	1
1-21481-1	Angle—Stiffener tie	1
1-20047	Angle—Turret support	1
1-20047-1	Angle—Turret support	1
1-20048	Angle—Turret support	1
1-20048-1	Angle—Turret support	1
3-13935	Reinforcement—Turret support	1
3-13935-1	Reinforcement—Turret support	1
3-13936	Reinforcement—Turret support	1
3-13936-1	Reinforcement—Turret support	1
41-1645-75	Angle—Tabulated	2
1-20042-3	Angle—Stiffener tie	1
1-20042-2	Angle—Stiffener tie	1
1-20043-3	Angle—Stiffener tie	1
1-20043-2	Angle—Stiffener tie	1
15-7780	Gasket—Lower turret bottom support	2
15-7780-80	Tee Assembly—Lower turret bottom	1
15-7780-81	Tee Assembly—Lower turret bottom	1
1-18278	Tee—Stiffener tie	7
1-20186	Angle—Turret support	4
1-20186-1	Angle—Turret support	2
6-9703	Support Assembly—Floor station 6C	1
6-9703-1	Support Assembly—Floor station 6C	1
BAC1304-51	Plug—Fastener socket	18
49-3592	Support Installation—Interphone	1
	Dash numbers parts, shown on 49-3592 drawing are represented by dash numbers of 9-3592.	
9-3592-4	Support Assembly—Interphone	1
41-158	Retainer—Interphone jack	1
41-159	Stop—Interphone jack	1
3-16126-7	Decalcomania—Miscellaneous	1
15-9252	Support Installation—Servo motors	1
15-9252-1	Channel Assembly—Servo motors support	1
15-9252-2	Support Assembly—Servo motors	1
NAS53-531-5A	Bolt—Close tolerance	6
	(Parts List No. 233)	
6-9476	Support Installation—Station 6 fuse shield	1
9-3588	Support Installation—Nacelle platform	1
9-3588-1	Channel Assembly—Platform support	1
1-17103-1	Angle—Stiffener tie	1
1-18901-1	Plate—Platform stowage	1
9-3588-4	Strap and Buckle Assembly—Nacelle platform support (Western Auto Supply No. C-492)	1
1-18328	Stop—Platform	1
1-18329	Stop—Strap	1
1-18833	Angle—Support	1

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-6602-20-1	Bolt—¼-28 special	1
41-7170-17-48	Washer—$^{3}/_{32}$ neoprene	1
9-3588-3	Plate—Nacelle platform support	1
9-3607	Support Installation—Platform stowage	1
9-3607-1	Channel Assembly—Platform stowage support	1
1-17103-1	Angle—Stiffener tie	1
1-18901	Plate—Platform stowage	1
9-3607-4	Strap and Buckle Assembly—Platform stowage support (Western Auto Supply No. C-492)	1
1-18328	Stop—Platform	1
1-18329	Stop—Strap	1
1-18833	Angle—Support	1
21-6602-20-1	Bolt—¼-28 special	1
41-7170-17-48	Washer—$^{3}/_{32}$ neoprene	1
9-3607-3	Plate—Platform stowage	1
3-13653	Support Installation—Oxygen regulator	1
49-3719	Support Installation—Oxygen hose	1
49-3719-400	Channel Assembly—Oxygen hose support	1
1-23308	Support Assembly—Insulator	1
41-5746-2	Stud—Plate	1
21-6744	Fastener—Inspection door	4
41-5746-2	Stud—Plate	3
9-3719-7	Strap Assembly—Oxygen hose support	1
49-3719-403	Strap Assembly—Oxygen hose support	1
9-3719-5	Strap—Oxygen hose support	1
9-3719-3	Segment—Circumference oxygen hose support	1
1-17557	Angle—Tab stiffener tie	1
1-17557-1	Angle—Tab stiffener tie	2
3-13695	Support Installation—Marker antenna lead-in	1
1-18755	Support—Antenna lead-in	1
6-8949	Support Installation—Dome lamp	1
6-8949-1	Pan Assembly—Dome lamp	1
6-8953	Support Installation—Dome lamp	1
7-1529	Bracket Installation—Marker beacon	1
7-1529-1	Bracket Assembly—Marker beacon	1
	(Parts List No. 234)	
8-1527	Bracket Installation—Side gunners belt	1
8-1527-1	Bracket Installation—Side gunners belt	1
8-1527-2	Bracket Assembly—Side gunners belt	1
8-1527-7	Bracket Assembly—Side gunners belt	1
8-1537	Bracket Installation—Oxygen regulator LH	1
3-16136	Bracket—Oxygen regulator	1
8-1537-1	Bracket Installation—Oxygen regulator RH	1
3-16136-1	Bracket—Oxygen regulator RH	1
15-7670	Bracket Installation—Side gun	1
15-7670-1	Bracket Installation—Side gun	1
1-18900	Splice Installation—Longitudinal stiffener	2
1-20005	Clip—Side gun support	2
1-20011	Clip—Side gun support	3
1-20011-1	Clip—Side gun support	3
1-17557	Angle—Tabulated stiffener tie	2
1-17557-1	Angle—Tabulated stiffener tie	2
1-20012-2	Clip—Side gun support	1
1-20012-3	Clip—Side gun support	1
9-4610	Support Installation—Side gun	1
9-4610-1	Support Installation—Side gun	1
6-10738	Support Installation—Side gun mount base	1
6-10738-1	Support Installation—Side gun mount base	1
15-7670-6	Bracket Assembly—Side gun support	1
15-7670-7	Bracket Assembly—Side gun support	1
3-13920	Bracket Assembly—Side gun support	1
3-13920-1	Bracket Assembly—Side gun support	1
1-20013	Gusset—Side gun support	2
1-20003	Gusset—Side gun support	2
3-13922	Bracket—Side gun support	1
3-13922-1	Bracket—Side gun support	1
3-13921	Bracket—Side gun support	1
3-13921-1	Bracket—Side gun support	1
15-7621	Bracket Installation—Tail gear motor	1
15-7621-1	Bracket Assembly—Tail gear motor	1

AVIALOGS.COM

FUSELAGE ASSEMBLY

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7621-7	Bracket Assembly—Tail gear motor	1
15-7621-2	Plate Assembly—Tail gear motor bracket	1
15-7621-4	Plate Assembly—Tail gear motor bracket	1
15-7621-6	Cover—Tail gear motor bracket	1
3-13699	Support—Limit switch LH (used on -7)	1
3-13699-1	Support—Limit switch RH (used on -7)	1
15-9267	Bracket Installation—Elevator servo	1
15-9267-8	Bracket Assembly—Elevator servo	1
BAC1603-34	Spacer—No. 10 bolt	1
BAC1614-34	Spacer—1/8 rivet	3
15-9267-9	Bracket Assembly—Elevator servo	1
BAC1603-34	Spacer—No. 10 bolt	1
BAC1614-34	Spacer—1/8 rivet	3
	(Parts List No. 235)	
1-19001-147	Fair-lead—1 hole	2
BAC1603-34	Spacer—No. 10 bolt	2
6-9489	Bracket Installation—Tail gear hand retracting	1
6-9489-1	Bracket Assembly—Tail gear hand retracting	1
15-7641	Stowage Installation—Nacelle ladder	1
15-7641-1	Bracket Assembly—Lower nacelle ladder	2
3-13728	Bracket—Nacelle ladder	2
BAC1247-10S	Angle—Nut plate	1
15-7641-5	Plate—Nacelle ladder stowage	1
C-492	Strap and Buckle Assembly—Nacelle ladder stowage (Western Auto Supply, No. C-492, Los Angeles, California)	1
C-492-2	Bracket Assembly—Upper nacelle ladder stowage	1
C-492	Strap Assembly and Buckle—Upper nacelle ladder stowage (Western Auto Supply, No. C-492, Los Angeles, California)	1
C-492-5	Plate—Upper nacelle ladder stowage bracket	1
C-492-4	Pad—Upper nacelle ladder stowage bracket (Kirkhill Rubber, No. 608)	3
6-8947	Strap Installation—Brace stowage	1
6-8947-1	Support Assembly—Brace stowage strap	1
6-8947-4	Leather Pad—Brace stowage strap	1
6-9453	Collar Installation—Weather boot	1
6-9453-6	Collar Assembly—Weather boot	1
6-9453-1	Spotweld Assembly—Weather boot collar	1
6-9407	Flange Installation—Elevator torque tube cut out	1
6-9407-1	Flange Installation—Elevator torque tube cut out	1
3-13731-3	Angle Assembly—Elevator boot support	1
3-13731-4	Angle Assembly—Elevator boot support	1
1-19001-31	Fair-lead Assembly—1 hole	2
1-18920	Angle—Cut out flange	2
1-18920-1	Angle—Cut out flange	2
BAC1249-110S	Plate—Fiber nut	4
6-9312	Plate Installation—Shear tie bulkhead 9	1
6-9301	Channel Installation—Tail gear support	1
6-9301-3	Channel Assembly—Tail gear support	1
1-18781	Support—Limit switch	2
6-9404	Channel Assembly—Tail gear support	2
41-5135-4	Angle—Stiffener tie LH	1
41-5135-5	Angle—Stiffener tie RH	1

Fuselage Assembly—Rear Section

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-13573	Plate Installation—Shear tie bulkhead 10	1
3-13552	Cone Installation—Jacking	1
3-13541	Cone—Jacking	1
6-9211	Fair-lead Installation—Station 6H RH	
1-19000-3	Fair-lead Assembly—1 hole	1
1-19000-4	Fair-lead—Miscellaneous	2
	(Parts List No. 236)	
3-13004	Fair-lead Installation—Station 6H	1
1-19000-1	Fair-lead Assembly—Miscellaneous	1
1-19000-2	Fair-lead—Miscellaneous	2
3-13005	Fair-lead Installation—Station 6D LH	1
1-19000-1	Fair-lead Assembly—Miscellaneous	1
1-19000-2	Fair-lead—Miscellaneous	2
3-13007	Fair-lead Installation—Station 6D RH	1
1-19000-3	Fair-lead Assembly—Miscellaneous	1
1-19000-4	Fair-lead—Miscellaneous	2
3-13710	Fair-lead Installation—Rudder control	1
1-18458	Fair-lead Assembly—Rudder control	2
1-18458-1	Fair-lead—Half	2
15-7536	Hinge Installation—Rudder	1
15-7536-1	Beam Assembly—Rudder hinge	1
3-13575	Bearing Assembly—Rudder hinge	1
3-13625	Support Assembly—Rudder lock plunger	1
3-13625-1	Support Assembly—Welded rudder lock plunger	1
3-13549	Support—Rudder lock plunger	1
1-18546-2-34	Bushing—Control	1
1-18563	Block—Rudder stop	2
3-13568	Channel—Rudder lock support	1
3-13568-1	Channel—Rudder lock support	1
3-13574	Reinforcing—Rudder lock support	1
3-13574-1	Reinforcing—Rudder lock support	1
NAS53-S27.5A	Bolt—Close tolerance	2
6-9304	Gusset—Rudder lock	1
1-18090	Bumper Installation—Toilet seat	1
1-18090-1	Bumper Assembly—Toilet seat	1
1-18090-3	Bumper—Toilet seat (Atlantic India Rubber Works, No. 18)	1
15-8788	Reinforcing Installation—Side burning	1
6-13161	Angle	1
6-13161-1	Angle	1
1-22639	Angle Installation—Tube support	4L
1-18890	Angle—Tube support	4
6-10734	Patch Installation—Antenna fair-lead	1
6-10734-1	Patch Assembly—Antenna fair-lead	1
6-10734-3	Gasket—Rubber antenna fair-lead patch	1
BAC1327-4-2	Spring—Dzus fastener	3
1-18774	Bracket Installation—Toilet paper holder	1
55-7612	Skin Installation—Station 6-11 fuselage	1
6-9302	Patch Installation—Skin reinforcing	1
BAC1252-10S	Plate—Fiber nut	56
BAC1245-110S	Anchor Nut—High tempered	8
366F1032	Nut plate	8

FUSELAGE ASSEMBLY—REAR SECTION

Enclosure Assembly—Rear Gun

	(Parts List No. 237)	
15-7360	Enclosure Assembly—Rear gun	1
15-7489	Ring Assembly—Bulkhead attaching—station 11	1
1-18561	Plate—Splice	1
3-13522	Bulkhead Assembly—Station 11A head fairing	1
3-13788	Angle Assembly—Support—rear floor	1
6-9264	Support Assembly—Ammunition box station 11 LH	1

Enclosure Assembly—Rear Gun

6-9264-1	Support Assembly—Ammunition box station 11 RH	1
1-18890	Angle—Tube support	1L
15-7520	Cover Installation—Tail gun	1
15-7520-15	Cover Assembly—Tail gun	1
15-7520-13	Frame Assembly—Tail gun cover	1
15-7520-14	Cover Assembly—Tail gun	1
1-18295	Collar—Tail gun cover	4
1-20531	Sector—Cover ring	3

AVIALOGS.COM

FUSELAGE ASSEMBLY—REAR SECTION

Enclosure Assembly—Rear Gun

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-20532	Sector—Cover ring	3
1-21352	Sector—Cover ring	2
1-21353	Window—Camera tail gun	1
1-21354	Trim—Window camera	4
1-20531-1	Section—Cover ring	1
1-20532-1	Section—Cover ring	1
C-493	Strap—Web tail gun cover (Western Auto Supply Co., Los Angeles, California)	1
1-18233	Plug—Tail gun cover	2
21-3147-1	Washer—.019 steel (corrosive resistant)	31
1-24206	Rub Black—Tail gun	1
15-7360-1	Shell Assembly—Rear gun enclosure—upper	1
1-17551	Window—Gunner's bullet-proof glass	1
1-18408	Angle—Protect—glass frame	1
1-18408-1	Angle—Protect—glass frame	1
1-18278	Tee—Stiffener tie	2
1-18525	Channel Assembly—Protect glass mounting	1
1-18524	Channel—Protect glass mounting	1
1-18526	Angle—Protect glass mounting	1
1-18705	Strip—Window rubber retainer	1
1-18705-1	Strip—Window rubber retainer	1
1-18777	Gasket—Access cover	1
1-18785	Stiffener—Station 11G	1
1-18815	Gasket—Rubber	1
1-18876	Strip—Window rubber retainer	1
1-18876-1	Strip—Window rubber retainer	1
1-18877	Strip—Window rubber retainer	1
1-18877-1	Strip—Window rubber retainer	1
1-18878	Strip—Window rubber retainer	2
1-18879	Strip—Window rubber retainer	1
1-19059	Strip—Window rubber retainer	1
1-19059-1	Strip—Window rubber retainer	1
1-19072	Stop—Tail gun	1
1-19078	Angle—Gun ring support	1
1-19078-1	Angle—Gun ring support	1
1-18299-51-33	Spacer—Armor plate	8
3-13525	Bracket—Gun ring support—upper	1
	(Parts List No. 238)	
3-13525-1	Bracket—Gun ring support—upper	1
3-13534	Plate—Armor—rear gunner	1
3-13583	Fillet—Rear glass enclosure	1
3-13599	Yoke Assembly—Rear gun enclosure	1
6-9266	Channel Assembly—Rear gun enclosure	1
6-9266-1	Channel Assembly—Rear gun enclosure	1
15-7488	Yoke Assembly—Rear gun enclosure	1
1-18496	Angle—Armor plate support	1
1-18496-1	Angle—Armor plate support	1
1-18765	Gusset—Yoke splice	1
1-18765-1	Gusset—Yoke splice	1
1-18766	Angle—Yoke splice	1
1-18766-1	Angle—Yoke splice	1
1-18882-1	Angle—Bulkhead attaching	2
3-13600	Gasket—Rubber	1
3-13657	Gasket—Window rubber retainer	1
3-13659	Gasket—Window rubber retainer	1
3-13659-1	Gasket—Window rubber retainer	1
6-8979	Retainer—Protective glass	1
6-9200	Bracket Installation—Oxygen regulator LH	1
6-10746	Bracket Installation—Rear gunner dome light	1
3-15134	Bracket Assembly—Rear gunner dome light	1
6-9200-3	Bracket Installation—Oxygen regulator	1R
6-9262	Channel Assembly—Glass support	1
6-9262-1	Channel Assembly—Glass support	1
6-9263	Bulkhead—Upper station 11G	1
6-9268-2	Fairing—Window frame	1
6-9268-3	Fairing—Window frame	1
6-9270	Support Assembly—Gun bearing bracket	1
BAC1249-210S	Plate—Fiber nut	4
6-9326	Cover—Rear gun control access	1
6-9332	Panel—Pickup window	1
46-9339	Frame Assembly—Window rubber retainer	1

Enclosure Assembly—Rear Gun

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-9465	Bulkhead—Upper station 11C	1
6-9465-1	Bulkhead—Upper station 11C	1
6-9499-2	Bulkhead Assembly—Station 11A—upper	1
6-9499-3	Bulkhead Assembly—Station 11A—upper	1
1-18882	Angle—Bulkhead attaching	2
6-9468	Strip—Window rubber retainer	1
9-3442	Shell—Head fairing	1
15-7516	Sight Installation—Rear gun	1
15-7516-1	Mount Assembly—Rear gun sight	1
15-7516-4	Pulley Assembly—Rear gun sight	1
1-19083	Pulley Assembly—Rear gun sight	1
1-18269	Pulley—Rear gun sight	1
BAC326-44CS	Bushing—Bearing	1
	(Parts List No. 239)	
1-18300-1	Clip—Attaching	2
BAC1804-5-3L	Cable Assembly—1/16-7 x 7 control	2
BAC1827-2L	Swaged Terminal—Class "D"	2
BAC1828-23	Terminal—Dead end cable	2
1-18280	Support Assembly—Gun sight	1
6-9234-2	Support—Gun sight	1
1-19087-4	Yoke Assembly—Sight mount	1
3-13519-5	Sight Assembly—Rear gun	1
3-13519-3	Cable Assembly—Rear gun sight	1
BAC1827-2L	Terminal—Swaged	2
1-18296-3	Fitting—Rear gun sight	1
1-18302	Bead—Rear gun sight	1
1-22607	Sight—Gun ring	1
1-26403-1	Quadrant—Rear gun sight	1
BAC274-62	Bushing—Outer diameter bearing	1
1-18263	Bracket Assembly—Control pulley	1
1-18252	Bracket—Control pulley	2
1-18253	Bracket—Control pulley	1
1-18264	Bracket Assembly—Control pulley	1
1-18265	Bracket—Control pulley	1
1-18265-1	Bracket—Control pulley	1
1-18319	Spacer—Micarta	1
41-5951-44-13	Washer—.063 steel (corrosive resistant)	2
15-7516-3	Spacer—Rear gun sight	1
BAC324-63CS	Bushing—Bearing	1
BAC1804-16-6R	Cable Assembly—1/16-7 x 7 control	2
BAC1827-2R	Swaged Terminal—Class "D"	2
BAC1828-23	Swaged Terminal—Dead end cable	2
15-7360-7	Strip—Packing rear gun mount (Everseal Prod. Co., 3822 Hazelwood Ave., Detroit, Mich.)	1
15-7360-8	Strip—Packing rear gun mount (Everseal Prod. Co., 3822 Hazelwood Ave., Detroit, Mich.)	1
15-7360-11	Strip—Packing rear gun mount (Rubbercraft Corp. of California, 110 East 17th St., Los Angeles)	1
15-7360-44	Plate Assembly—Rear gun mount	2
15-7518	Mount Installation—Rear gun	1
15-7518-1	Mount Assembly—Rear gun	1
15-7518-4	Pulley—Rear gun mount	1
1-18300	Clip—Attaching	2
1-18304	Pulley—Sight control	1
BAC1804-21-3R	Cable Assembly—1/16-7 x 7 control	1
BAC1827-2R	Swaged Terminal—Class "D"	1
BAC1828-23	Terminal—Dead end cable	1
BAC1804-16-6R	Cable Assembly—1/16-7 x 7 control	1
BAC1827-2R	Swaged Terminal—Class "D"	1
BAC1828-23	Terminal—Dead end cable	
1-18256	Terminal—Rear gun support	1
1-18262	Terminal—Rear gun support	1
1-19658	Bracket—Rear gun sight	1
1-19661	Crank Assembly—Rear gun sight	1
6-9280	Support—Gun mount	1
3-13527	Yoke Assembly—Rear gun mount	2

AVIALOGS.COM

FUSELAGE ASSEMBLY—REAR SECTION

Enclosure Assembly—Rear Gun

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 240)	
1-18316	Stud—Rear gun mount	4
3-13531	Tube Assembly—Rear gun support	1
1-18381	Clamp—Cable	1
1-18255	Segment—Sight control	2
1-19058	Guide—Rear gun sight	1
BAC750-9-94-5	Disc—Reinforcing	2
15-7518-3	Filler—Rear gun mount	2
NAS55-S25.5A	Bolt—Close tolerance	2
3-13507	Support Assembly—Rear gun mount	2
6-9235	Support—Rear gun	1
1-18258	Bushing—Rear gun support	1
1-18259	Washer—Bearing	1
3-13514	Support Assembly—Rear gun mount	1
6-9235-2	Support—Rear gun	1
15-7572	Panel—Pick-up window	1
15-7572-1	Panel—Pick-up window	1
41-7170-13-56	Washer—3/32 neoprene	8
1-18524	Channel—Protect glass mounting	1
1-20006	Bracket Assembly—Yoke attaching	1
1-20006-1	Bracket Assembly—Yoke attaching	1
15-8778	Window Installation—Rear gunner	1
15-8774	Channel Assembly—Head fairing	1
6-10724-1	Angle—Window track	1
6-10725-1	Angle—Window track	1
15-8775	Former Assembly—Station 11A head fairing	1
6-10724	Angle—Window track	1
6-10725	Angle—Window track	1
15-8779	Panel Assembly—Pick-up window	1
15-8779-4	Window Assembly—Pick-up panel	1
15-8779-3	Packing—Pick-up window panel (Everseal Prod. Co., 3822 Hazelwood Ave., Detroit, Mich)	1
9-3771	Panel—Pick-up window	1
1-20362	Angle Assembly—Window roller	1
1-20362-1	Angle Assembly—Window roller	1
1-20364	Angle—Window roller	1
1-20364-1	Angle—Window roller	1
1-20365	Stud—10-32 special	4
1-20367	Spacer—No. 6 special	2
3-14987	Handle Assembly—Pick-up window	1
1-20366	Tee—Roller support	2
9-3771	Panel—Pick-up window	1
9-3773	Frame—Fixed window	1
BAC-1601-8	Spacer—No. 6 machine screw	2
1603-24	Spacer—No. 10 bolt	2
M-361	Bearing—Rear gunner window (Torrington Co., Torrington, Conn.)	4
M-361-4	Packing—Rear gunner window (Everseal Prod. Co., 3822 Hazelwood Ave., Detroit, Mich.)	1
	(Parts List No. 241)	
15-8778-5	Seal—Rubber—rear gunner window (Goodrich No. 31099)	1
15-7360-2	Shell Assembly—Lower rear gun enclosure	1
6-9306	Bulkhead Assembly—Station 11J + .72	1

Enclosure Assembly—Rear Gun

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-12998	Support—Signal lamp	2
6-9269	Bulkhead—Tail signal	1
15-7510	Bulkhead Assembly—Station 11G—lower	1
1-18583	Channel—Bulkhead reinforcing	2
15-7663	Bulkhead Assembly—Station 11C—lower	1
1-19037	Support—Ammunition track	1
1-19037-1	Support—Ammunition track	1
1-18664	Reinforcement—Bulkhead stiffener	2
15-7678	Bulkhead Assembly—Station 11A—lower	1
1-18664	Reinforcement—Bulkhead stiffener	2
1-18890-1	Angle—Tube support	1
15-7610	Support Assembly—Knee pad LH	1
15-7610-1	Support Assembly—Knee pad RH	1
3-13521	Bracket—Knee support	1
3-13521-1	Bracket—Knee support	1
9-3680	Support Installation—Rear gun stowage	1
9-3680-2	Spacer—Rear gunner stowage support	2
6-9446	Brace Assembly—Rear gun stowage	1
6-9271	Support Assembly—Gun bearing bracket	1
6-9272	Panel Assembly—Rear gun floor	1
6-9272-2	Matting — Rubber — rear gun floor panel (Goodrich)	1
6-9273	Bracket Assembly—Horizontal ammunition box support	1
6-9273-1	Bracket Assembly—Horizontal ammunition box support	1
6-9273-2	Bracket—Rear gun floor panel LH	1
6-9273-3	Bracket—Rear gun floor panel RH	1
1-18887	Snap Assembly—Stowage brace	1
1-18885	Spring—Stowage brace snap	1
1-18108	Channel—Seat top	1
1-18348	Angle—Tie	2
1-19067	Angle—Gun ring support	1
1-19067-1	Angle—Gun ring support	
3-13602	Support—Station 11E ammunition track	1
3-13602-1	Support—Station 11E ammunition track	1
6-9267	Bracket—Armor plate support	1
6-9267-1	Bracket—Armor plate support	1
6-9327-2	Support—Ammunition apron	1
6-9327-3	Support—Ammunition apron	1
6-9349-2	Support—Gun ring lower	1
6-9349-3	Support—Gun ring lower	1
15-7597	Channel—Rear gun stowage	1
1-19829	Channel—Reinforcement	2
3-13924	Support—Gun ring lower	1
	(Parts List No. 242)	
1-17557	Angle—Tabulated stiffener tie	2
1-17557-1	Angle—Tabulated stiffener tie	2
BAC1304-40	Plug—Fastener socket	12
9-3741	Bracket Installation—Over run control	1
14-2871	Patch Installation—Armor support	1
1-21944	Bracket—Interphone support	1
15-7630-46	Angle Assembly—Rear gun enclosure	1
1-18434	Support Assembly—Microphone	1
41-158	Retainer—Interphone jack	1
41-159	Stop—Interphone jack	1
3-16126-7	Decalcomania—Phone call	1

FINAL ASSEMBLY

Tail Gear Installation

	(Parts List No. 243)	
5-7470	Tail Gear Installation—(15-7368 CL diagram tail wheel)	1

Dash number parts, shown on 55-7470 drawing are represented by dash numbers of 15-7470 and 55-7470.

Tail Gear Installation

55-7470-403	Treadle Assembly—Tail gear	1
55-7470-404	Conduit Assembly—Flexible tail gear	1
AN3050-4	Ferrule—Conduit, flexible	2
AN3054-4	Nut—Coupling, conduit	2
55-7470-405	Conduit Assembly—Flexible tail gear	1
AN3050-6	Ferrule—Conduit, flexible	2

AVIALOGS.COM

FINAL ASSEMBLY

Tail Gear Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
AN3054-6	Nut—Coupling, conduit	1
55-7470-408	Brake Assembly—Treadle tail gear	1
6-9356	Switch Installation—Tail wheel center	1
6-9356-1	Spring Assembly—Tail wheel center switch	1
1-18644	Spring—Switch	1
1-18643	Channel—Switch	1
1-18642	Plate—Cover	1
6-9350-2	Switch—Micro tail wheel center	1
6-9281	Brake Assembly—Tail wheel	1
41-3727-3	Brake Disc Assembly—Tail wheel	1
41-3727-1	Disc—Tail wheel brake	1
41-3727-4	Key—Locking—tail wheel brake disc	2
3-12988	Disc Assembly—Tail wheel brake	1
3-12988-5	Plate Assembly—Weld—tail wheel brake disc	1
3-12988-4	Lining—Tail wheel brake disc	2
1-18077	Disc Assembly—Tail wheel brake	1
41-3824-1	Retainer—Tail wheel spring	1
21-8444	Spring—Compression	1
1-18715	Washer—Tail wheel brake compression	1
6-9281-1	Bolt—Tail wheel brake	1
1-18463	Keeper—Brake assembly	1
6-8952	Cover—Tail wheel brake	1
3-10080-2	Lock Assembly—Tail wheel	1
41-9807	Terminal—Tail wheel lock	1
41-3412	Pin—Tail wheel lock	1
21-7829	Spring—Compression	1
41-3413	Sleeve Assembly—Tail	1
81-3414	Nut—Tail wheel lock	1
3-13655	Retainer Assembly—Grease	1
3-13655-1	Ring—Grease retainer	1
3-13655-2	Cap—Grease retainer	1
3-13655-3	Packing—Grease retainer (Booth Felt Co., No. BDF)	1
1-18095	Spacer—Tail wheel spindle	1
1-18097	Guard—Bearing	1
3-13006	Ring—Tail wheel lock	1
6-9355	Switch Installation—Tail wheel lock	1
6-9355-1	Shield Assembly—Tail wheel lock	1
3-13371	Shield Assembly—Bomb rack	1
3-13371-1	Shield—Bomb rack	1
3-13371-2	Cover—Bomb rack shield	1
BAC1247-8D	Angle—Nut plate	2
1-18597	Spring—Locking switch	1

(Parts List No. 243A)

6-9355-3	Switch—Micro tail wheel lock	1
BAC1461	Screw—No. 8—32 non-losable	2
1-18609-1	Plate—Locking switch	1
21-6092-45-31	Bolt—Special No. 10	1
15-7369	Knuckle and Axle Assembly—Tail wheel	1
9-3428	Knuckle Assembly—Tail wheel	1
6-8945	Axle—Tail wheel	1
1-18076	Terminal—Tail wheel axle	1
6-8959	Spindle—Tail wheel	1
NAS60-S44	Bolt—Close tolerance	2
15-7389	Treadle Assembly—Tail gear	1
15-7389-1	Treadle Assembly—Weld tail gear	1
15-7389-17	Housing—Tail gear	1
6-8964	Terminal—Tail gear treadle LH	1
6-8964-1	Terminal—Tail gear treadle RH	1
15-7389-18	Bolt—Tail gear treadle	1
15-7389-15	Timken Bearing Assembly—Tail gear treadle. (cone 34306, cup 34478)	1
15-7389-16	Timken Bearing Assembly—Tail gear treadle (cone 3687, cup 362A)	1
BAC1616-28	Spacer—3/16 rivet	3
15-7389-19	Bushing—Bearing	2
15-7389-20	Bushing—Bearing	2
15-7470-3	Nut—Treadle	1
15-7470-7	Plug—2.50 diameter	1
AN3064-4	Connector—Conduit box	2

Tail Gear Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
AN3064-6	Connector—Conduit box	1
AN3066-4	Nut—Lock, conduit coupling	2
AN3066-6	Nut—Lock, conduit coupling	1
AN7503-2	Washer	1
BAC540-6	Clamp—Loop type	1
BAC540-8	Clamp—Loop type	3
BAC821-118-10	Terminal—Electrical solderless	1
BAC823-18	Connector—Electrical—2 way	2
BAC823-20	Connector—Electrical—2 way	1
BAC1603-16	Spacer—No. 10 bolt	2
15-7389	Treadle Assembly—Tail gear	1
15-7389-1	Treadle Assembly—Weld tail gear	1
15-7389-17	Housing—Tail gear	1
6-8964	Terminal—Tail gear treadle LH	1
6-8964-1	Terminal—Tail gear treadle RH	1
15-7389-18	Bolt—Tail gear treadle	1
15-7389-15	Timken Bearing Assembly—Tail gear treadle (cone 34306, cup 34478)	1
15-7389-16	Timken Bearing Assembly—Tail gear treadle (cone 368, cup 362A)	1
BAC1616-28	Spacer—3/16 rivet	3
15-7389-19	Bushing—Bearing	2
15-7389-20	Bushing—Bearing	2
15-7369	Knuckle and Axle Assembly—Tail wheel	1
9-3428	Knuckle Assembly—Tail wheel	1
6-8945	Axle—Tail wheel	1

(Parts List No. 244)

1-18076	Terminal—Tail wheel axle	1
6-8959	Spindle—Tail wheel	1
NAS60-S44	Bolt—Close tolerance	2
6-9281	Brake Assembly—Tail wheel	1
41-3727-3	Brake Disc Assembly—Tail wheel	1
41-3727-1	Disc—Tail wheel brake	1
41-3727-4	Key—Locking—tail wheel brake disc	2
3-12986	Disc Assembly—Tail wheel brake	1
3-12986-5	Plate Assembly—Weld—tail wheel brake disc	1
3-12988-4	Lining—Tail wheel brake disc	2
1-18077	Disc Assembly—Tail wheel brake	1
41-3824-1	Retainer—Tail wheel spring	1
21-8444	Spring—Compression	1
1-18715	Washer—Tail wheel brake—compression	1
6-9281-1	Bolt—Tail wheel brake	1
6-8952	Cover—Tail wheel brake	6
G-3-168-M	Tail Wheel Assemby—Tail gear (Hayes Industries, Inc., Jackson, Mich.)	1
1-18075	Terminal—Tail wheel axle	1
15-7470-5	Tire—Tail gear	1
15-7470-6	Tube—Tail gear	1
3-10080-2	Lock Assembly—Tail wheel	1
41-9807	Terminal—Tail wheel lock	1
41-3412	Pin—Tail wheel lock	1
21-7829	Spring—Compression	1
41-3413	Sleeve Assembly—Tail wheel lock	1
81-3414	Nut—Tail wheel lock	1
15-7470-7	Plug—Tail gear	1
3-13006	Ring—Tail wheel lock	1
3-13655	Retainer Assembly—Grease	1
3-13655-1	Ring—Grease retainer	1
3-13655-2	Cap—Grease retainer	1
3-13655-3	Packing—Grease retainer (Booth Felt Co., No. BDF)	1
1-18095	Spacer—Tail wheel spindle	1
1-18097	Guard—Bearing	1
1-18463	Keeper—Brake assembly	1
15-7470-2	Washer—Retaining tail gear (AC32A509-2)	1
AN32-62	Bolt—Clevis	1
AN32-40	Bolt	2
AN320-12	Nut	3
AN380-4-5	Cotter	3

AVIALOGS.COM

FINAL ASSEMBLY

Tail Gear Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
55-7470-402	Tube Assembly—Tail gear	1
55-7470-15	Tube—Tail gear	1
21-9751-16	Boot Installation—Universal grease	2
21-9751-16A	Boot—Universal grease	2
21-9751-2	Chord—Universal grease boot	4
BAC1851-16	Universal—Joint	1
365-428	Nut	1
3-14954	Coupling Assembly—Tail gear mechanism	1
BAC1851-16	Universal joint	1
AN3-31A	Bolt	5
	(Parts List No. 245)	
AN4-14	Bolt	1
1-18776	Filler—Tail gear hand retractor	1
3-15190	Bracket—Tail gear retractor	1
15-7378	Yoke—Tail gear	1
AN286-1	Lubricator—Pressures—grip, type PT	1
AN380-4-5	Pin—Cotter	1
AN320-12	Nut—Shear	1
AN32-64	Bolt—Clevis	1
69-1787	Retracting Assembly—Tail gear	1
6-4048	Cover Assembly—Tail wheel retracting gear	1
6-4048-4	Felt—Tail wheel retracting cover	1
6-4048-10	Cover—Tail wheel retracting cover	1
6-4048-13	Cover—Tail wheel retracting cover	1
6-4048-14	Cover—Tail wheel retracting cover	1
6-9343	Terminal Assembly—Tail gear retractor	1
6-9343-1	Terminal—Tail gear retractor (6-9343-2 Forging)	1
6-9343-3	Bushing—Tail gear retractor (make from BAC327-64MB)	1
21-6294	Cap Assembly—Tail wheel retractor gear	1
21-6294-3	Cap—Tail wheel retractor gear	1
21-6294-4	Retainer—Wheel retractor gear	1
21-6294-5	Neoprene—Wheel retractor gear	1
21-6355	Stop Assembly—Tail wheel retractor gear	1
21-6355-1	Stop—Tail wheel retractor gear	1
51-219	Bumper—Tail wheel retractor screw	1
69-1787-1	Plug—Tail gear retractor	1
21-6356	Stop—Tail wheel retractor screw	1
3-14654	Screw—Retractable	1
21-6359	Collar—Tail wheel retractor screw	1
21-6377-6-3	Bolt—¼-28 shoulder	4
21-6306	Gear—Tail wheel retractor	1
21-6305	Gear—Tail wheel retractor	1
3-15117	Nut—Retracting	1
21-6717	Ring—Tail wheel retractor gear	1
21-6420	Bearing—Tail wheel retractor gear	1
21-6718-3	Bearing—Tail wheel retractor gear	2
56-3989	Housing—Tail wheel retractor gear	1
AN25-78	Bolt—Clevis	1
AN320-5	Nut—Shear	1
AN380-2-2	Pin—Cotter	1
AN960-416	Washer	1
365-428	Nut—Self-locking	1
AN3-31A	Bolt—Without, cotter hole	5
365-1032	Nut—Self-locking	5
8-1285	Oleo Assembly—Tail gear	1
8-1285-1	Cylinder Assembly—Weld tail gear oleo	1
3-13536	Cylinder—Tail gear oleo	1
3-13555	Terminal Assembly—Lower tail oleo	1
3-13540	Rod—Oleo orifice	1
3-13538	Terminal Assembly—Tail oleo lower	1
3-13538-1	Terminal—Tail oleo lower	1
BAC335-48MB	Bushing—Bearing	2
	(Parts List No. 246)	
1-18374	Ring—Lower packing	1
1-18373	Ring—Upper packing	1
8-1285-2	Packing—4 sealing rings (Garlock Chevron No. 7815)	1

Tail Gear Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-13537	Nut Assembly—Oleo packing	1
3-13537-1	Nut—Oleo packing	1
1-18372	Bushing—Oleo packing nut	1
3-13577	Ring—Locking	1
6-9283	Piston Assembly—Tail gear oleo	1
1-18375	Piston—Tail gear oleo	1
41-5584	Plate—Oleo orifice	1
6-9284	Rod Assembly—Oleo piston	1
6-9284-1	Rod Assembly—Weld oleo piston	1
3-13535	Rod—Oleo piston	1
3-13539	Terminal—Oleo piston rod	1
BAC335-48MB	Bushing—Bearing	2
37A4724	Body—Shock absorber strut filler plug	1
1-21082	Gasket—Fluid seal metallic	1
8-1285-7	Core—Tail gear	1
3-13554	Plate—Oleo instruction	1
1-20351	Plate—Special fluid	1
40A1252	Cap Assembly—Shock absorber strut filler plug	1
AN32-86	Bolt—Clevis	1
AN320-12	Nut—Shear	1
AN380-4-5	Pin—Cotter	1
3-15190-1	Bracket—Tail gear retractor	1
3-14953	Housing Assembly—Hand retractor mechanism tail gear	1
3-14953-2	Bearing—Hand retractor mechanism—Oilite A-1521	1
3-14956-3	Housing—Hand retractor—Mechanism tail gear	1
G-3-217-A	Tail Assembly—Wheel (Hayes Industries, Inc., Jackson, Mich.)	1
17-277	Tire—Goodyear Tire & Rubber Co., Inc.	1
27-077	Tire—Goodyear Tire & Rubber Co., Inc.	1
AN960-1216	Washer—Plain	4

Landing Gear and Brakes Installation

(Parts List No. 247)

65-4801	Landing Gear and Brakes Installation	1
49-2301	CL Diagram—Landing gear	1
55-5593	Control Installation—Landing gear hand retractor LH (PL 252-253)	1
55-5593-1	Control Installation—Landing gear hand retractor RH (PL 252-253)	1
65-4801-501	Strut Assembly—Landing gear and brakes LH	1
65-4801-502	Strut Assembly—Landing gear and brakes RH	1
55-4803-409	Strut Assembly—Landing gear LH	1
55-4803-410	Strut Assembly—Landing gear RH	1
55-4803-2	Bushing—Landing gear strut	2
55-4803-401	Tube—Landing gear LH	1
55-4803-408	Tube—Landing gear RH	1
55-4803-3	Bushing—Landing gear strut	2
41-2636-14	Screw—⅜-24 flathead	10
41-2636-15	Screw—⅜-24 flathead	8
41-2636-16	Screw—⅜-24 flathead	8
41-2636-17	Screw—⅜-24 flathead	8
41-2636-18	Screw—⅜-24 flathead	6
55-4803-415	Collar Assembly—Landing gear	2
55-4803-412	Bushing—Landing gear collar	4
55-4803-416	Collar—Landing gear collar	2
41-9623-12	Bolt—⅜-24 clevis	6
41-9623-13	Bolt—⅜-24 clevis	4
41-9623-14	Bolt—⅜-24 clevis	4
41-9623-15	Bolt—⅜-24 clevis	4
15-4779	Terminal Assembly—Landing gear strut	2
15-4779-1	Terminal—Landing gear strut	2
15-4779-2	Bushing—Landing gear strut	4
57-1195	Oleo Assembly—Landing gear LH	1
57-1195-1	Oleo Assembly—Landing gear RH	1
3-9164	Cylinder Assembly—Oleo	2
41-2629	Plate—Cylinder	2
46-5857	Piston Assembly—Oleo	2
81-2564	Rod Assembly—Oleo piston	2
41-2562	Terminal—Piston rod	2

AVIALOGS.COM

FINAL ASSEMBLY

Landing Gear and Brakes Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-17232	Plate—Oleo valve	2
21-9083	Plate—Oleo orifice	2
81-2565	Piston—Oleo	2
15-6181	Knuckle—Landing gear LH	1
15-6181-1	Knuckle—Landing gear RH	1
48-735	Axle Assembly—Landing gear	2
48-735-1	Axle—Landing gear	2
48-735-2	Cork—Landing gear axle	2
61-9396-2	Bolt—Jacking cone	2
21-9588-7	Washer—Ball seat	2
41-2569	Rod—Orifice	2
57-1195-3	Washer—Soft copper	2
1-20351-1	Plate—Specification—shock strut fluid	2
41-8199-1	Lug—Towing	2
21-9588-6	Washer—Ball seat	2
	(Parts List No. 248)	
1-17366	Plate—Identification LH	1
1-17366-1	Plate—Identification RH	1
41-5767-1	Plate—Oleo instruction	2
40A1252	Cap Assembly—Shock absorber strut filler plug	2
37A4724	Body—Shock absorber strut filler plug	2
57-1195-401	Core—Schrader No. 1939 landing gear oleo	2
1-21082	Gasket—Fluid seal metallic	2
41-2568	Ring—Lower	2
41-6647	Ring—Bottom adapter	2
57-1195-400	Packing—Landing gear oleo (Garlock Chevron No. 7815)	2
41-6646	Ring—Top adapter	2
41-2567	Ring—Upper	2
21-9084	Nut—Packing lock	2
43-9165	Nut Assembly—Oleo packing	2
43-9165-400	Nut—Oleo packing	2
41-2566	Bushing—Oleo packing nut	2
21-941[illegible]	Nut—Special 1-½-12	4
21-9391	Bolt—Special	2
21-9414	Nut—Special 1-⅜-12	2
AN380-5-10	Cotter—L	6
65-4801-5	Bearing—Landing gear and brakes (Fafnir N-1807)	4
21-9388	Ring—Grease seal	2
21-9389-1	Cap—Grease seal	2
41-671	Washer—Grease retainer	8
21-2366-238-98	Washer—.091 aluminum alloy	8
41-9624-152-98	Washer—.188 aluminum alloy	8
21-6385-152-98	Shim—.032 brass washer	16
AN29-86	Bolt—Clevis	2
AN29-66	Bolt—Clevis	2
AN32-60	Bolt—Clevis	4
AN320-9	Nut	4
AN380-4-4	Cotter	4
3-7833	Bolt—Special 1-½-12	4
9-2312-6	Link Assembly—Torsion	2
9-2312-7	Link Assembly—Torsion	2
9-2312-4	Bearing—Race—torsion link (Timken No. 532A)	8
9-2312-8	Link—Torsion	4
9-2312-9	Link—Torsion	4
9-2312-5	Bearing—Torsion link (Timken cone No. 542)	8
64-1491-501	Drag Strut Assembly—Landing gear	2
64-1491-1	Strut Assembly	2
46-5917	Terminal Assembly	2
46-5917-400	Terminal—(Forging 6-8159)	2
64-1491-4	Bushing	4
43-9175-400	Terminal—Drag strut	4
21-556-1	Guard—Valve dust	2
21-557	Ring—Valve dust guard	2
21-9588-10	Washer—Ball seat	2
21-9588-12	Washer—Ball seat	2
3-10298	Lug—Landing gear towing	2
AN6-17	Bolt	2
AN8-47	Bolt	2
AN310-6	Nut—Castle	2

Landing Gear and Brakes Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 249)	
AN310-8	Nut—Castle	2
AN380-3-3	Cotter	4
64-1498	Mechanism Assembly—Retractor gear LH	1
64-1498-1	Mechanism Assembly—Retractor gear RH	1
9-3082-2	Cover Assembly—Lower retractor screw	2
9-3082-4	Clamp Assembly—Half-weld retractor screw	2
9-3082-7	Clamp Assembly—Half-weld retractor screw	2
9-3082-1	Cover Assembly—Upper retractor screw	2
9-3082-4	Clamp Assembly—Half-weld retractor screw	2
9-3082-7	Clamp Assembly—Half-weld retractor screw	2
46-8053	Housing Assembly—Retractor gear	2
46-8053-400	Housing Assembly—Weld retractor gear	2
46-8053-3	Pins—Retractor gear housing	4
51-289	Bushing—Gear housing	4
3-9288	Gear Set—Retractor gear	2
07100	Cone—Retractor gear mechanism (Timken Roller Bearing Co., Canton, Ohio)	4
07196	Cone—Retractor gear mechanism (Timken Roller Bearing Co., Canton, Ohio)	4
81-2818	Shaft—Retractor gear	2
41-2817	Retainer Assembly—Retractor gear housing	4
41-2817-1	Retainer—Retractor gear housing	4
41-2817-2	Gasket—Retractor gear housing retainer (Booth Felt Co., No. BDF)	4
21-5136	Cap—Retractor gear housing	2
51-264-2	Lock—Cover	2
41-4778	Ring—Lock	4
48-591	Tube Assembly—Retracting nut	2
48-591-401	Tube Assembly—Weld retracting nut	2
43-7810-1	Lug—Retracting gear	4
53-7877	Retainer—Retracting nut	2
51-428	Bushing—Retracting nut	4
3-15124	Nut—Retracting	2
3-15118	Screw—Retracting	2
21-9839	Stop Assembly—Retracting screw—upper	2
21-9839-1	Cap—Retracting screw—upper stop	2
21-9839-2	Bumper—Neoprene—retracting screw upper stop	2
21-9839-3	Felt—Retracting screw upper stop (Booth Felt Co., No. BDF or equivalent)	2
21-9839-4	Washer—Retracting screw upper stop	2
21-9838	Stop—Upper	2
21-9840	Stop Assembly—Retracting screw—lower	2
21-9840-1	Stop—Retracting screw—lower	2
21-9840-2	Collar—Bronze—retracting screw—lower	2
64-1498-502	Bumper—Neoprene—retracting gear mechanism	2
41-1066-164-108	Washer—.031 corrosive resistant steel	4
21-9841	Cap—Lower bumper	2
5208	Bearing Assembly—(Fafnir Britain)	2
1-18740	Angle—Conduit support	4
BAC1603-8	Spacer No. 10 screw	4
	(Parts List No. 250)	
65-4801-13	Shim—Landing gear and brakes	4
46-5903	Link Assembly—Drag strut	2
46-5903-1	Tube—Drag strut link	2
61-7969	Terminal Assembly—Link	2
61-7969-1	Terminal—Link	2
61-7969-2	Bushing—Link terminal	2
3-11757	Terminal Assembly—Link	2
3-11757-1	Terminal—Link	2
BAC294-40ST	Bushing—⅝ press	4
41-9800	Universal Assembly—Drag strut	2
41-9800-1	Universal—Drag strut	2
41-9800-2	Bushing—Drag strut universal	2
3-11760	Universal Assembly—Drag strut	2
3-11760-1	Terminal—Drag strut universal	2
3-11760-2	Bushing—Drag strut universal	2
BAC294-48ST	Bushing—¾ press	2
BAC294-52ST	Bushing—$^{13}/_{16}$ press	2

AVIALOGS.COM

FINAL ASSEMBLY

Landing Gear and Brakes Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
8-588-2	Support—Drag strut	2
65-4801-401	Wheel and Brake Assembly N. D.—Landing gear	2
1-20353	Tire—Main wheel (Goodrich 55 x 19—14 ply)	2
65-4801-403	Tube—Landing gear and brakes (Goodrich 55 x 19)	2
41-2571-1	Ring—Landing gear axle lock	2
AN4-6	Bolt	4
AN10-15	Bolt	24
AN10-13	Bolt	12
3-9864	Spacer—Landing gear wheel	2
AN960-1016	Washer—Plain	12
AN960-1216	Washer	4
AN960-1416	Washer	8
AN310-4	Nut	4
AN310-10	Nut	36
AN320-12	Nut	4
AN380-2-2	Cotter	4
AN380-4-4	Cotter	36
6-8533	Clamp Assembly—Landing gear	2
6-8533-7	Clamp Assembly—Half—landing gear	2
6-8533-2	Clamp—Half—landing gear	2
46-7563	Valve Assembly—Return boost LH	1
46-7563-1	Valve Assembly—Return boost RH	1
46-7563-401	Name Plate—Return boost valve LH	2
43-11072	Cylinder—Large LH	1
43-11072-1	Cylinder—Large RH	1
3-11073-1	Cylinder—Small	2
3-11074	Piston Assembly—Return boost valve	2
3-11074-1	Ball—Return boost valve piston	2

Landing Gear and Brakes Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-11075	Piston Assembly—Return boost valve	2
41-7717	Piston—End	2
41-9016	Piston—Center	2
41-9017	Piston—End	2
1-15573-88-69	Washer—Retaining	2
	(Parts List No. 251)	
51-999	Ring—Sealing	4
41-7710	Ring—Sealing	2
41-7714	Guide—Ball	2
41-7715	Washer—Special	2
41-7716	Spring—Compression	2
41-5459-60-48	Washer—Special	2
41-5762	Spring—Compression	2
41-7719	Guide—Spring	2
BAC1453-2-3	Screw—Round-head heavy gage sheet metal	6
39B846B8	Adapter—Hydraulic hose end (tin threads)	2
1-17249	Gasket—Hydraulic hose	2
39G1030-8-27	Hose Assembly—Brake control (ND)	2
21-7988-8-3	Bolt—¼-28 steel head	8
65-4801-511	Tube—Copper landing gear and brakes LH	1
65-4801-512	Tube—Copper landing gear and brakes RH	1
1-20031	Nut—Hexagon	2
811T8CS	Sleeve—½ tube	2
811FT8	Nipple—½ tube	2
811BT8	Nut—½ tube	4

LANDING GEAR AND BRAKES INSTALLATION

Control Installation—Ldg. Gear Hand Retr.

(Parts List No. 252)

55-5593	Control Installation—Landing gear hand retractor LH	1
55-5593-1	Control Installation—Landing gear hand retractor RH	1
55-5593-405	Gear Box Assembly—Landing gear hand retractor LH	1
55-5593-406	Gear Box Assembly—Landing gear hand retractor RH	1
53-6989	Housing—Landing gear hand retractor LH	1
53-6989-1	Housing—Landing gear hand retractor RH	1
21-6867	Gear—Landing gear hand retractor	2
21-8440	Gear—Landing gear hand retractor	2
55-5593-4	Bearing—Fafnir S10FT hand retractor control	2
55-5593-5	Bearing—Fafnir S12FT hand retractor control	2
21-6948	Retainer Assembly—Hand retractor mechanism	2
21-6948-1	Retainer—Hand retractor mechanism	2
21-6948-2	Felt—Hand retractor mechanism retainer	2
21-6948-3	Retainer Assembly—Hand retractor mechanism	2
21-6948-4	Retainer—Hand retractor mechanism	2
21-6948-5	Felt—Hand retractor mechanism retainer	2
41-43	Insert—Adapter	2
21-9751-20	Boot Installation—Universal grease	2
21-9751-2	Chord—Universal grease boot	4
21-9751-20A	Boot—Universal grease boot	2
41-4220-1	Coupling—Shaft	2
51-498-1	Filler—Hand gear retractor	2
BAC1851-20	Universal joint	2
41-782	Angle—Support	2
3-11370	Cover Assembly—Hand retractor gear RH	1
3-11370-4	Cover Assembly—Hand retractor gear LH	1
NAS54-S34A	Bolt—Close tolerance	6
55-5593-401	Gear Box Assembly—Hand retractor control	1
55-5593-402	Gear Box Assembly—Hand retractor control	1
43-6988	Housing—Landing gear hand retractor LH	1
43-6988-1	Housing—Landing gear hand retractor RH	1

Control Installation—Ldg. Gear Hand Retr.

21-6867	Gear—Landing gear hand retractor	4
55-5593-4	Bearing—(Fafnir S-10 FT) hand retractor control	4
21-6948-3	Retainer Assembly—hand retractor mechanism	4
21-6948-4	Retainer—Hand retractor mechanism	4
21-6948-5	Felt—Hand retractor mechanism retainer	4
51-498-1	Filler—Hand gear retractor	4
41-43	Insert—Adapter	2
41-43-2	Insert—Adapter	2
41-4220-1	Coupling—Shaft	4
21-9751-20	Boot Installation—Universal grease	6
21-9751-2	Chord—Universal grease boot	24
21-9751-20A	Boot—Universal grease boot	12
BAC1851-20	Universal joint	4
NAS54-S41.5A	Bolt—Close tolerance	2
BAC1604-22	Spacer—¼ bolt	4
BAC1604-28	Spacer—¼ bolt	2
BAC1604-172	Spacer—¼ bolt	2
55-5593-407	Tube Assembly—Hand retractor control	2
51-720	Insert—Adapter	2
	(Parts List No. 253)	
41-43	Insert—Adapter	2
55-5593-8	Support Assembly—Hand retractor control	2
55-5593-9	Bearing—SKF No. 1206—hand retractor control support	2
55-5593-10	Wire—Hand retractor control support	2
21-6926	Support—Landing gear hand retractor	2
21-6947-1	Retainer—Landing gear hand retractor	4
41-4220	Coupling—Shaft	2
BAC1851-20	Universal Joint	2
41-4220	Coupling—Shaft	4
BAC1604-42	Spacer—¼ bolt	2
BAC1604-46	Spacer—¼ bolt	2
BAC1604-172	Spacer—¼ bolt	2
55-5593-403	Tube Assembly—Hand retractor control	2

AVIALOGS.COM

LANDING GEAR AND BRAKES INSTALLATION

Control Installation—Ldg. Gear Hand Retr.

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-4220	Coupling—Shaft	2
41-4220-1	Coupling—Shaft	2
41-43	Insert—Adapter	2
41-4220	Coupling—Shaft	2
BAC1851-20	Universal Joint	2
51-498	Filler—Hand gear retractor	2
21-9751-20	Boot Installation—Universal	2
21-9751-2	Chord—Universal boot	4

Control Installation—Ldg. Gear Hand Retr.

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-9751-20A	Boot—Universal	2
NAS54-S35A	Bolt—Close tolerance	2
NAS54-S42A	Bolt—Close tolerance	2
1-23504	Shim—Shaft coupling	2
1-23504-1	Shim—Shaft coupling	2
1-23504-2	Shim—Shaft coupling	2
1-23504-3	Shim—Shaft coupling	2

FINAL ASSEMBLY

Power Plant Installation

(Parts List No. 254)

55-7350	Power Plant Installation	1
	Dash number parts, shown on 55-7350 drawing are represented by dash numbers of 15-7350 and 55-7350.	
55-7359-400	Engine Installation—Engine 1	1
55-7359-401	Engine Installation—Engine 2	1
55-7359-402	Engine Installation—Engine 3	1
55-7359-403	Engine Installation—Engine 4	1
1-18638	Fuel System Installation	1
65-6242	Oil System Installation	1
1-18363	Controls Installation—Engine	1
65-5680-500	Supercharger Installation	1
15-7664-1	Cowling Installation—Inboard engines	1
15-7664	Cowling Installation—Inboard engines	1
15-7667	Cowling Installation—Outboard engines	2
55-6088-414	Oil System Installation—Supercharger lubricating	1
75-6164	Tubing Installation—Supercharger regulator	1
55-7363	Transmitter Installation—Autosyns inboard LH	1
55-7363-1	Transmitter Installation—Autosyns inboard RH	1
	Dash number parts, shown on 55-7363 drawing are represented by dash numbers of 15-7363 and 55-7363.	
55-7363-409	Units Assembly—Forward inboard autosyn transmitter	1
55-7363-412	Fitting Assembly—Forward inboard autosyn transmitter	1
6-10431	Panel Assembly—Forward autosyn transmitter	1
6-10431-1	Panel—Forward autosyn transmitter	1
1-22970-1	Mount—Rubber shock	2
BAC802-2-40	Jumper Assembly—Terminal bonding	1
660-2	Terminal	2
15-7363-13	Fitting Assembly—Inboard autosyn transmitter	1
15-7363-3	Transmitter—Oil pressure inboard autosyn (Government furnished)	1
15-7363-5	Transmitter — Manifold pressure inboard autosyn (Government furnished)	1
55-7363-410	Units Assembly—Inboard autosyn transmitter forward	1
55-7363-413	Fitting Assembly—Inboard autosyn transmitter	1
55-7363-414	Fitting Assembly—Inboard autosyn transmitter	1

(Parts List No. 255)

6-11301	Panel Assembly—Forward autosyn transmitter	1
6-11301-1	Panel—Forward autosyn transmitter	1
100PD1	Mount—Shock (Lord Mfg. Co., Erie, Pa.) (Spec. 1-22970-1)	4
15-7363-3	Transmitter—Oil pressure—inboard autosyn transmitter (Government furnished)	1
15-7363-5	Transmitter — Manifold pressure — inboard autosyn transmitter (Government furnished)	1

Power Plant Installation

55-7363-401	Units Assembly—Aft—inboard autosyn transmitter	2
8-1533	Panel Assembly — Aft — inboard autosyn transmitter	2
8-1533-1	Panel—Aft—inboard autosyn transmitter	2
8-1533-2	Hood—Aft—inboard autosyn transmitter	2
1-18382	Panel—Insulator	2
1-20735-1001	Absorber—Vibration	8
21-2362-64-11	Washer—.051 aluminum alloy	8
21-7401	Bus—Connector panel	2
1-17244	Panel Assembly—Connector	2
1-17244-1	Panel—Connector	2
BAC1602-64	Spacer—No. 8 machine screw	4
39B3480-414	Hose Assembly—Flexible	4
15-7363-2	Transmitter—Oil tempered—inboard autosyn (Government furnished)	2
15-7363-4	Transmitter—Fuel pressure—inboard autosyn (Government furnished)	2
15-7363-6	Transmitter—Tachometer—Inboard autosyn (Government furnished)	2
55-7363-411	Fitting Assembly—Autosyn inboard transmitter	2
15-7363-10	Fitting Assembly—Autosyn inboard transmitter	2
41-4227	Grommet—Shaft	2
41-4228-1	Grommet—Retainer	2
1-22626	Shaft Assembly—Tachometer—drive	2
BAC540-318	Clamp—Cushioned	2
34A1766-1	Washer—Vibration	24R
34A1766-1	Washer—Vibration	18L
55-7363-406	Tube—Fuel pressure—inboard autosyn transmitter	2
BAC535-10	Clamp—Hose	8
BAC548-20	Clamp—Double loop type	2L
BAC548-20	Clamp—Double loop type	1R
BAC802-2-40	Jumper Assembly—Terminal bonding	4
55-7362	Transmitter Installation—Outboard autosyn LH	1
	Dash number parts, shown on 55-7362 drawing are represented by dash numbers of 15-7362 and 55-7362.	
55-7362-1	Transmitter Installation—Outboard autosyn RH	1
55-7362-401	Units Installation—Aft outboard autosyn transmitter	2
8-1533	Panel Assembly—Aft autosyn transmitter	2

(Parts List No. 256)

8-1533-1	Panel—Aft autosyn transmitter	2
8-1533-2	Hood—Aft autosyn transmitter	2
1-18382	Panel—Insulator	2
1-20735-1001	Absorber—Vibration	8
21-2362-64-11	Washer—.051 aluminum alloy	8
21-7401	Bus—Connector panel	2
1-17244	Panel Assembly—Connector	2
1-17244-1	Panel—Connector	2
BAC1002-64	Spacer—No. 8 machine screw	4
15-7362-2	Transmitter—Oil temperature outboard autosyn (Government furnished)	2
15-7362-4	Transmitter—Differential fuel pressure outboard autosyn (Government furnished)	2

AVIALOGS.COM

FINAL ASSEMBLY

Power Plant Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7362-6	Transmitter—Tachometer outboard autosyn transmitter (government furnished)	2
55-7362-402	Units Instrument—Forward outboard autosyn transmitter	2
55-7362-406	Elbow Assembly—90° outboard autosyn transmitter	2
BAC1200-B40	Lockwire	2
15-7362-13	Fitting Assembly—Forward outboard autosyn transmitter	2
6-10431	Panel Assembly—Forward autosyn transmitter	2
6-10431-1	Panel—Forward autosyn transmitter	2
1-22970-1	Mount—Rubber shock	4
BAC802-2-40	Jumper Assembly—Terminal bonding	2
660-2	Terminal	4
15-7362-3	Transmitter—Oil pressure outboard autosyn (government furnished)	2
15-7362-5	Transmitter—Manifold pressure outboard autosyn (government furnished)	2
39B3480-414	Hose Assembly—Flexible instrument	4
55-7362-405	Fitting Assembly—Outboard autosyn transmitter	2
852-4	Elbow—Hose	2
15-7362-10	Fitting Assembly—Outboard autosyn transmitter	2
41-4227	Grommet—Shaft	2
41-4228-1	Grommet—Retainer	2
BAC540-318	Clamp—Loop type cushioned	2
BAC540-4C	Clamp—Loop type cushioned	2
34A1766-1	Washer—Vibration	36
55-7362-400	Tube—Fuel pressure—outboard autosyn transmitter	2
1-22626	Shaft Assembly—Tachometer drive	2
BAC802-2-40	Jumper—Ground	4
BAC540-4C	Clamp—Loop type cushioned	2
BAC540-10	Clamp—Loop type cushioned	4L
BAC540-10	Clamp—Loop type cushioned	2R
BAC535-10	Clamp—Hose	8
15-7355	Control Installation—Starter Nacelle No. 2	1
15-7355-1	Solenoid—Type C-1, 24 volt (government furnished)	1
	(Parts List No. 256A)	
3-11900	Bracket Assembly—Starter control	1
BAC1614-20	Spacer—⅛ rivet	2
3-12788-1	Handle Assembly—Starter control	1
1-17235	Spring—Compression	1
	(Parts List No. 257)	
1-4795	Handle—Starter control	1
51-213	Guide Assembly—Starter control	1
1-17563	Adapter Assembly—Starter control	1
1-18074	Washer—No. 10 plain	2
1-17563-3	Spacer—⅛ rivet	1
BAC1788-40-5	Cable Assembly—1/16-7 x 7 control	1
BAC1826-2	Terminal—Swaged class B	2
15-7356	Control Installation—Starter Nacelle No. 3	1
15-7356-1	Solenoid—24 volt type C-1 (government furnished)	1
15-7356-2	Block—Starter Nacelle No. 3—control	1
1-17563	Adapter Assembly—Starter control	1
1-18074	Washer—No. 10 plain	2
1-17563-3	Spacer—⅛ rivet	1
3-11900-1	Bracket Assembly—Starter control	1
BAC1614-20	Spacer—⅛ rivet	2
3-12788-2	Handle Assembly—Starter control	1
1-17235	Spring—Compression	1
1-4795	Handle—Control	1
51-213-2	Guide Assembly—Starter control	1
BAC1788-39-1	Cable Assembly—1/16-7 x 7 control	1
BAC1826-2	Swaged Terminal—Class B	2

Power Plant Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7354	Control Installation—Starter Nacelle No. 1	1
15-7354-1	Solenoid Type C-1, 24 volt (government furnished)	1
BAC1788-48-5	Cable Assembly—1/16-7 x 7 control	1
BAC1826-2	Swaged Terminal—Class B	2
3-11900	Bracket Assembly—Starter control	1
BAC1614-20	Spacer—⅛ rivet	2
3-12788-3	Handle Assembly—Starter control	1
1-17235	Spring—Compression	1
1-4795	Handle—Starter control	1
51-213-7	Guide Assembly—Starter control	1
1-17563	Adapter Assembly—Starter control	1
1-18074	Washer—No. 10 plain	2
1-17563-3	Spacer—⅛ rivet	1
15-7357	Control Installation—Starter No. 4 Nacelle	1
15-7357-1	Solenoid—Type C-1 24 volts (government furnished)	1
3-11900-1	Bracket Assembly—Starter control	1
BAC1614-20	Spacer—⅛ rivet	1
3-12788-3	Handle Assembly—Starter control	1
1-17235	Spring—Compression	1
	(Parts List No. 258)	
1-4795	Handle—Starter control	1
51-213-7	Guide Assembly—Starter control	1
1-17563	Adapter Assembly—Starter control	1
1-18074	Washer—No. 10 plain	2
1-17563-1	Spacer—⅛ rivet	1
BAC1788-43-4	Cable Assembly—1/16-7 x 7 control	1
BAC1826-2	Swaged Terminal—Class B	2
55-6193	Manifold Assembly—Outboard exhaust (Solar 12-909)	2
15-6193-1	Section Assembly—Outboard exhaust manifold (Solar 12-687-1)	2
1-16597	Gusset—Flange reinforcing (Solar 1-870-4N)	4
1-16598-26	Strip—Plain wear (Solar 1-906-26)	2
1-16599-1	Flange—Exhaust manifold (Solar 1-1276-1)	2
15-6193-2	Section Assembly—Outboard exhaust manifold (Solar 12-687-2)	2
1-16597	Gusset—Flange reinforcing (Solar 1-870-4N)	4
1-16598-26	Strip—Plain wear (Solar 1-906-26)	2
1-16599-1	Flange—Exhaust manifold (Solar 1-1276-1)	2
15-6193-3	Section Assembly—Outboard exhaust manifold (Solar 12-687-3)	2
1-16597	Gusset—Flange reinforcing	4
1-16598-34	Strip—Plain wear (Solar 1-906-34)	2
1-16599-1	Flange—Exhaust manifold	2
1-16601-27	Wearstrip—Beaded wear (Solar 1-1053-27)	2
15-6193-4	Section Assembly—Outboard exhaust manifold (Solar 12-687-4)	2
1-16597	Gusset—Flange reinforcing	4
1-16598-42	Strip—Plain wear (Solar 1-906-42)	2
1-16599-1	Flange—Exhaust manifold	2
1-16601-35	Strip—Beaded wear (Solar 1-1053-35)	2
15-6193-7	Section Assembly—Outboard exhaust manifold (Solar 12-687-7)	2
1-16597	Gusset—Flange reinforcing	4
1-16598-46	Strip—Plain wear (Solar 1-906-46)	2
1-16599-1	Flange—Exhaust manifold	2
1-16601-43	Strip—Beaded wear (Solar 1-1053-43)	2
15-6193-8	Section Assembly—Outboard exhaust manifold (Solar 12-687-8)	2
1-16597	Gusset—Flange reinforcing	4
1-16598-42	Strip—Plain wear (Solar 1-906-42)	2
1-16599-1	Flange—Exhaust manifold	2
1-16601-35	Strip—Beaded wear (Solar 1-1053-35)	2
15-6193-9	Section Assembly—Outboard exhaust manifold (Solar 12-687-9)	2
1-16597	Gusset—Flange reinforcing	4
1-16598-34	Strip—Plain wear (Solar 1-906-34)	2
1-16599-1	Flange—Exhaust manifold	2

AVIALOGS.COM

FINAL ASSEMBLY

Power Plant Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-16601-27	Strip—Beaded wear (Solar 1-1053-27)	2
55-6193-402	Section Assembly—Outlet—outboard exhaust manifold (Solar 12-909-5-6)	2
1-16597	Gusset—Flange reinforcing	16
1-16599-1	Flange—Exhaust manifold	4
1-16601-47	Strip—Beaded wear (Solar 1-1053-47)	2
3-12482-1	Ball—Socket (Solar 3-622-1)	2
1-16601-43	Strip—Beaded wear	2
1-21043	Lug—Clamp stop (Solar 1-2169)	2
55-6193-42	Name Plate—Outboard exhaust manifold (Solar 1-708)	2
3-12481-27	Clamp Assembly—Manifold (Solar 3-610-27S)	4
	(Parts List No. 259)	
3-12481-35	Clamp Assembly—Manifold (Solar 3-610-35S)	4
3-12481-43	Clamp Assembly—Manifold (Solar 3-610-43S)	4
3-13796-47	Clamp Assembly—Manifold (Solar 3-832-47)	2
55-6690-1	Tail Pipe Assembly—Outboard RH	1
55-6690-402	Transition Assembly—Outboard tail pipe (Solar 12-961-6)	1
55-6690-27	Boss Assembly—Outboard tail pipe RH—weld	1
1-19690	Boss—Tail pipe (Solar 1-685-21N)	1
1-16607-6	Strip—Wear (Solar 1-1125-6)	1
1-16608	Flange—Tail pipe (Solar 1-929-N)	1
55-6690-400	Tube Assembly—Outboard tail pipe (Solar 9-214-2)	1
1-16603-5	Strip—Beaded wear (Solar 1-1176-5)	1
1-19967	Sleeve—Exhaust (Solar 9-214-3)	1
1-20563-2	Strip—Wear plain band (Solar 1-2144-2)	1
1-19969	Plate Installation—Instruction (Solar 1-2144-2)	1
1-21472	Plate—Instruction	1
1-19969-1	Tab—Instruction plate (Solar 1-2064) spot weld	4
1-16604	Spring—Compression (Solar 1-877)	3
1-16605	Stud—Spring support (Solar 1-878-S)	3
1-16606	Stud—Spring support (Solar 1-879-S)	3
3-12291	Clamp Assembly—Lower half (Solar 3-473)	1
3-12229-4	Clamp Assembly—Lower half (Station 2) (Solar 3-633-10)	1
3-12485	Ball Assembly—Flexible joint (Solar 3-627-2)	1
3-12487-1	Ball Assembly—Flexible joint (Solar 3-621-2)	1
3-12487-3	Ball—Flexible joint	1
1-16602	Clip Assembly—(Solar 1-1599)	3
3-12486	Socket Assembly—Flexible joint (Solar 12-689-9)	1
1-16603-5	Strip—Beaded wear (Solar 1-1176-5)	1
3-12482	Socket—Ball (Solar 3-622)	1
1-10067	Sleeve—Exhaust	1
3-12487	Ball Assembly—Flexible joint (Solar 3-621-4)	1
3-12487-2	Ball—Flexible joint	1
1-16602	Clip Assembly—Flexible joint (Solar 1-1599)	3
55-6690	Tail Pipe Assembly—Outboard LH (Solar 9-214)	1
55-6690-401	Transition Assembly—Outboard (Solar 12-691-5)	1
55-6690-26	Boss Assembly—Outboard tail pipe LH	1
1-19690	Boss—Tail pipe (Solar 1-685-21N)	1
1-16607-6	Strip—Wear (Solar 1-1175-6)	1
1-16608	Flange—Tail pipe (Solar 1-929-N)	1
55-6690-400	Tube Assembly—Tail pipe (Solar 9-214-2)	1
1-16603-5	Strip—Beaded wear (Solar 1-1176-5)	1
1-19967	Sleeve—Exhaust (Solar 9-214-3)	1
1-20563-2	Band—Plain (Solar 1-2144-2)	1
1-19969	Plate Installation — Instruction (Solar 1-2144-2)	1
1-21472	Plate—Instruction	1

Power Plant Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 260)	
1-19969-1	Tab—Instruction plate (Solar 1-2964 Spot Weld)	4
1-16604	Spring—Compression (Solar 1-877)	3
1-16605	Stud—Spring support (Solar 1-878-S)	3
1-16606	Stud—Spring support (Solar 1-879-S)	3
3-12291	Clamp Assembly—Lower half (Solar 3-473)	1
3-12229-4	Clamp Assembly—Lower half (Station 2) (Solar 3-633-10)	1
3-12485	Ball Assembly—Flexible joint (Solar 3-627-2)	1
3-12487-1	Ball Assembly—Flexible joint (Solar 3-621-2)	1
3-12487-3	Ball—Flexible joint	1
1-16602	Clip Assembly — Flexible joint (Solar 1-1599)	3
3-12486	Socket Assembly—Flexible joint (Solar 12-689-9)	1
1-16603-5	Strip—Beaded wear (Solar 1-1176-5)	1
3-12482	Socket—Ball (Solar 3-622)	1
1-19967	Ring—Reinforcing	1
3-12487	Ball Assembly—Flexible joint (Solar 3-621-4)	1
3-12487-2	Ball—Flexible joint	1
1-16602	Clip Assembly—Flexible joint	3
55-6194	Manifold Assembly—Inboard exhaust LH (Solar 12-910)	1
55-6194-5	Section Assembly—Inboard exhaust manifold (Solar 12-688-5)	1
1-16597	Gusset—Flange reinforcing (Solar 1-870-4N)	2
1-16598-46	Strip—Plain wear (Solar 1-906-46)	1
1-16599-1	Flange—Exhaust manifold (Solar 1-1276-1)	1
1-16601-43	Strip—Beaded wear (Solar 1-1053-43)	1
55-6194-401	Section Assembly—Inboard exhaust manifold (Solar 12-910-6)	1
1-16597	Gusset—Flange reinforcing	2
1-16598-50	Strip—Plain wear (Solar 1-906-50)	1
1-16599-1	Flange—Exhaust manifold	1
1-16601-47	Strip—Beaded wear (Solar 1-1053-47)	1
1-21043	Lug—Clamp stop (Solar 1-2169)	2
55-6194-403	Section Assembly—Inboard exhaust manifold (Solar 12-910-7-8)	1
1-16597	Gusset—Flange reinforcing	8
1-16599-1	Flange—Exhaust manifold	2
1-16601-35	Strip—Beaded wear	1
1-16601-51	Strip—Beaded wear	1
1-21043	Lug—Clamp stop	1
3-12482-1	Socket—Ball	1
15-6193-1	Section Assembly—Manifold (Solar 12-687-1)	1
1-16597	Gusset—Flange reinforcing	2
1-16598-26	Strip—Plain wear (Solar 1-906-26)	1
1-16599-1	Flange—Exhaust manifold	1
15-6193-2	Section Assembly—Manifold (Solar 12-687-2)	1
1-16597	Gusset—Flange reinforcing	2
1-16598-26	Strip—Plain wear	1
1-16599-1	Flange—Exhaust manifold	1
15-6193-3	Section Assembly—Manifold (Solar 12-687-3)	1
1-16597	Gusset—Flange reinforcing	2
1-16598-34	Strip—Plain wear	1
	(Parts List No. 261)	
1-16599-1	Flange—Exhaust manifold	1
1-16601-27	Strip—Beaded wear	1
15-6193-4	Section Assembly—Manifold (Solar 12-687-4)	1
1-16597	Gusset—Flange reinforcing	2
1-16598-42	Strip—Plain wear	1
1-16599-1	Flange—Exhaust manifold	1
1-16601-35	Strip—Beaded wear	1
15-6193-9	Section Assembly—Manifold (Solar 12-687-9)	1
1-16597	Gusset—Flange reinforcing	2
1-16598-34	Strip—Plain wear	1
1-16599-1	Flange—Exhaust manifold	1
1-16601-27	Strip—Beaded wear	1
3-12481-27	Clamp Assembly—Manifold (Solar 3-610-27S)	2

AVIALOGS.COM

FINAL ASSEMBLY

Power Plant Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-12481-35	Clamp Assembly—Manifold (Solar 3-610-35S)	2
3-12481-43	Clamp Assembly—Manifold (Solar 3-610-43S)	1
3-13796-47	Clamp Assembly—Manifold (Solar 3-832-47)	1
3-13796-51	Clamp Assembly—Manifold (Solar 3-832-51)	1
75-6525	Tail Pipe Assembly—Inboard exhaust RH (Solar 12-901)	1
75-6525-605	Section Assembly—Transition—exhaust inboard tail pipe (Solar 12-689-4)	1
75-6525-606	Boss Assembly—Spotweld—exhaust inboard tail pipe (Solar 12-689-5)	1
1-19690	Boss—Weld—exhaust inboard tail pipe (Solar 1-685-21N or Solar 1-685-21S)	1
1-16607-6	Strip—Wear (Solar 1-1175-6)	1
1-16608	Flange—Tail pipe (Solar 1-929-N or Solar 1-929-S)	1
75-6525-16	Section Assembly—Exhaust inboard tail pipe RH (Solar 12-901-1)	1
1-16046	Boss—Boiler mounting (Solar 1-1642)	3
1-16045	Disk—Boiler support (Solar 1-875S)	3
1-16603-5	Strip—Beaded wear (Solar 1-1176-5)	1
1-20563-2	Band—Plain (Solar 1-2144-2)	1
1-16609	Stud—Tail pipe (Solar 1-1643)	1
1-19967	Sleeve—Exhaust (Solar 12-901-4)	1
1-19969	Plate Installation—Instruction (Solar 1-2143)	1
1-19969-1	Tab—Instruction plate (Solar 1-2164)	4
1-21472	Plate—Instruction	1
75-6525-601	Section Assembly—Exhaust inboard tail pipe LH (Solar 12-901-2)	1
1-16603-4	Strip—Beaded wear (Solar 1-1176-4)	1
1-21467	Band—Wear beaded (Solar 1-2145)	1
1-20563-2	Band—Plain (Solar 1-2144-2)	1
1-19967	Sleeve—Exhaust (Solar 12-901-4 or Solar 1-2477-2)	1
75-6525-602	Section Assembly—Exhaust inboard tail pipe LH (Solar 12-901-3)	1
1-16603-4	Strip—Beaded wear (Solar 1-1176-4)	1
1-21467	Band—Wear beaded (Solar 1-2145)	1
1-20563-2	Band—Plain (Solar 1-2144-2)	1
1-19967	Sleeve—Exhaust (Solar 12-901-4)	1
1-21053	Stud—Heater	12
1-16604	Spring—Compression (Solar 1-877)	3
1-16605	Stud—Spring support (Solar 1-878-S)	3
1-16606	Stud—Spring support (Solar 1-879-S)	3

(Parts List No. 262)

1-17355	Cover Assembly—Boiler hole (Solar 1-2077)	1
1-17355-2	Cover Assembly—Weld boiler hole	1
1-16052	Plate—Boiler cover	1
3-12291	Clamp Assembly—Lower half (Solar 3-473)	1
1-16611	Gasket—Copper (Solar 1-1170)	1
3-12229	Clamp Assembly—Lower half (Solar 3-633)	1
1-16616	Washer—Beaded (Solar 1-1662)	1
3-12295	Clamp Assembly—Lower half station 2D inboard (Solar 3-636)	1
3-12312	Clamp Assembly—Lower half station 3 inboard nacelle (Solar 3-636-1)	1
1-16618	Spacer—Clamp (Solar 1-1157)	1
3-12485	Ball Assembly—Flexible joint (Solar 3-627-2)	1
3-12487-1	Ball Assembly—Flexible joint (Solar 3-621-2)	1
3-12487-3	Ball—Flexible joint	1
1-16602	Clip Assembly—Flexible joint (Solar 1-1599)	3
3-12486	Socket Assembly—Flexible joint (Solar 3-914)	1
1-16603-5	Strip—Beaded wear (Solar 1-1176-5)	1
3-12482	Ball—Socket (Solar 3-622)	1
1-19967	Sleeve—Exhaust (Solar 12-901-4)	1
3-12487	Ball Assembly—Flexible joint (Solar 3-621-4)	1
1-16602	Clip Assembly—Flexible joint	3
55-6195	Manifold Assembly—Inboard exhaust RH (Solar 12-908)	1
55-6195-401	Section Assembly—Outlet (Solar 12-686-3-4)	1
55-6195-26	Name Plate—Inboard exhaust manifold	1
1-16597	Gusset—Flange reinforcing (Solar 1-870-4N)	4

Power Plant Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-16599-1	Flange—Exhaust manifold (Solar 1-1276-1)	1
1-16601-27	Strip—Beaded wear (Solar 1-1053-27)	1
1-16601-53	Strip—Beaded wear (Solar 1-1053-53)	1
1-21043	Lug—Clamp stop (Solar 1-2169)	1
3-12482-1	Ball—Socket (Solar 3-622-1)	1
55-6195-402	Section Assembly—Manifold (Solar 12-908-5)	1
1-16597	Gusset—Flange reinforcing	2
1-21043	Lug—Clamp stop (Solar 1-2169)	1
1-16598-52	Strip—Plain wear (Solar 1-906-52)	1
1-16599-1	Flange—Exhaust manifold	1
1-16601-51	Strip—Beaded wear	1
55-6195-403	Section Assembly—Manifold (Solar 12-908-6)	1
1-21043	Lug—Clamp stop (Solar 1-2169)	1
1-16597	Gusset—Flange reinforcing	2
1-16598-50	Strip—Plain wear	1
1-16599-1	Flange—Exhaust manifold	1
1-16601-47	Strip—Beaded wear	1
3-12481-27	Clamp Assembly—Manifold (Solar 3-610-27S)	2
3-12481-35	Clamp Assembly—Manifold (Solar 3-610-35S)	2
3-12481-43	Clamp Assembly—Manifold (Solar 3-610-43S)	1
3-13796-47	Clamp Assembly—Manifold (Solar 3-832-47)	1
3-13796-51	Clamp Assembly—Manifold (Solar 3-832-51)	1
3-13796-53	Clamp Assembly—Manifold (Solar 3-832-53)	1
15-6193-1	Section Assembly—Manifold (Solar 12-687-1)	1
1-16597	Gusset—Flange reinforcing	2
1-16598-26	Strip—Plain wear	1

(Parts List No. 263)

1-16599-1	Flange—Exhaust manifold	1
15-6193-2	Section Assembly—Manifold (Solar 12-687-2)	1
1-16597	Gusset—Flange reinforcing	2
1-16598-26	Strip—Plain wear	1
1-16599-1	Flange—Exhaust manifold	1
15-6193-7	Section Assembly—Manifold (Solar 12-687-7)	1
1-16597	Gusset—Flange reinforcing	2
1-16598-46	Strip—Plain wear	1
1-16599-1	Flange—Exhaust manifold	1
1-16601-43	Strip—Beaded wear	1
15-6193-8	Section Assembly—Manifold (Solar 12-687-8)	1
1-16597	Gusset—Flange reinforcing	2
1-16598-42	Strip—Plain wear	1
1-16599-1	Flange—Exhaust manifold	1
1-16601-35	Strip—Beaded wear	1
15-6193-9	Section Assembly—Manifold (Solar 12-687-9)	1
1-16597	Gusset—Flange reinforcing	2
1-16598-34	Strip—Plain wear	1
1-16599-1	Flange—Exhaust manifold	1
1-16601-27	Strip—Beaded wear	1
65-6525	Tail Pipe Assembly—Inboard exhaust RH (Solar 12-903)	1
65-6525-504	Section Assembly—Inboard exhaust tail pipe (Solar 12-690-4)	1
65-6525-505	Boss Assembly—Inboard exhaust tail pipe (Solar 3-634-1)	1
1-19690	Boss—Inboard exhaust tail pipe (Solar 1-685-21N or Solar 1-685-21S)	1
1-16607-6	Strip—Wear (Solar 1-1175-6)	1
1-16608	Flange—Tail pipe (Solar 1-929-N or Solar 1-929-S)	1
65-6525-501	Section Assembly—Inboard exhaust tail pipe (Solar 12-903-1)	1
1-19967	Sleeve—Exhaust (Solar 12-903-4)	1
1-19969	Plate Installation—Instruction (Solar 1-2143)	1
1-19969-1	Tab—Instruction plate (Solar 1-2064 acceptable)	1
1-21472	Plate—Instruction	1
1-16603-5	Strip—Beaded wear (Solar 1-1176-5)*	1
1-20563-2	Band—Plain (Solar 1-2144-2)	1
1-16609	Stud—Tail pipe (Solar 1-1643)*	1

*Parts indicated by asterisk compose Solar Assembly 1-1805.

AVIALOGS.COM

FINAL ASSEMBLY

Power Plant Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-6525-502	Section Assembly—Exhaust inboard tail pipe LH (Solar 12-903-2)	1
1-21467	Strip—Beaded wear (Solar 1-2145)	1
1-20563-2	Band—Plain (Solar 1-2144-2)	1
1-19967	Sleeve—Exhaust (Solar 9-14-3 or Solar 1-2477-2)	1
65-6525-503	Section Assembly—Exhaust inboard tail pipe (Solar 12-903-3)	1
1-21467	Strip—Beaded wear (Solar 1-2145)	1
1-20563-2	Band—Plain (Solar 1-2144-2)	1
1-19967	Sleeve—Exhaust (Solar 12-903-4)	1
1-16604	Spring—Compression (Solar 1-877)	3
1-16605	Stud—Spring support (Solar 1-878-S)	3
1-16606	Stud—Spring support (Solar 1-879-S)	3
	(Parts List No. 264)	
3-12291	Clamp Assembly—Lower half (Solar 3-473)	1
1-16611	Gasket—Copper (Solar 1-1170)	1
3-12485	Ball Assembly—Flexible joint (Solar 3-627-2)	1
3-12487-1	Ball Assembly—Flexible joint (Solar 3-621-2)	1
3-12487-3	Ball—Flexible joint	1
1-16602	Clip Assembly—Flexible joint (Solar 1-1599)	3
3-12486	Socket Assembly—Flexible joint (Solar 3-914)	1
1-16603-5	Strip—Beaded wear (Solar 1-1176-5)	1
3-12482	Ball—Socket (Solar 3-622)	1
1-19967	Sleeve—Exhaust (Solar 12-901-4)	1
3-12487	Ball Assembly—Flexible joint (Solar 3-621-4)	1
1-16602	Clip Assembly—Flexible joint (Solar 1-1599)	3
3-12229	Clamp Assembly—Lower half (Solar 3-633)	1
1-16616	Washer—Beaded (Solar 1-1662)	1
3-12295	Clamp Assembly—Lower half (Station 2D inboard) (Solar 3-636)	1
3-12312	Clamp Assembly—Lower half (Solar 3-636-1)	1
1-16618	Spacer—Clamp (Solar 1-1157)	1
AN960C516	Washer	144
AN4-7	Bolt	32
AN4-10	Bolt	16
AN310-4	Nut	48
AN380-2-2	Cotter	48
9-3370	Tube Installation—Blast	2
9-3370-3	Tube Assembly—Blast	2
BAC1095-1032	Nut—Self-locking high tempered	6
7-1370	Clamp Installation—Outboard station 2	2
6-8460	Clamp Assembly—Upper half (Solar Drawing 3-632)	2
1-16613	Angle Assembly—Clamp (Solar Drawing 1-1657)	4
1-16615	Angle—Clamp (Solar Drawing 1-1656)	4
1-19051	Retainer—Nut (Solar 1-2015)	8
51-1184	Nut—Square (Solar 1-1283)	8
1-16614	Spacer—Clamp	4
1-19693	Bracket—Exhaust stack support	4
1-19082	Strap—Exhaust support	2
BAC1105-3	Nut—Brass (Castle & Shear)	4
BAC1095-1032	Nut—Self-locking high temperature	8
7-1371	Clamp Installation—Outboard station 2C LH	1
7-1371-1	Clamp Installation—Outboard station 2C RH	1
3-12292	Clamp Assembly—Upper half outboard nacelle (Solar 3-634)	2
1-16617	Angle Assembly—Clamp (Solar 1-1646)	4
1-19051	Retainer—Nut (Solar 1-2015)	8
51-1184	Nut—Square (Solar 1-1283)	8
1-16123-1	Bracket—Clamp support (Solar 1-1638-1)	2
1-16033	Angle—Stack support	2
1-16047-1	Angle—Exhaust stack support	4
BAC1095-1032	Nut—Self-locking high temperature	8
7-1372	Clamp Installation—Inboard station 3C LH	1
7-1372-1	Clamp Installation—Inboard station 3C RH	1

Power Plant Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 265)	
3-12313	Clamp Assembly—Upper half (Solar 3-634-1)	2
1-16617	Angle Assembly—Clamp (Solar 1-1646)	4
1-19051	Retainer—Nut (Solar 1-2015)	4
51-1184	Nut—Square (Solar 1-1283)	8
1-16123	Bracket—Clamp support (Solar 1-1638)	4
1-16055-3	Angle Assembly—Exhaust support	4
1-16054	Angle—Exhaust support	4
BAC1095-1032	Nut—Self-locking high tempered	12
7-1373	Clamp Installation—Inboard station 3 LH	1
7-1373-1	Clamp Installation—Inboard station 3 RH	1
6-8476	Clamp Assembly—Upper half (Solar 3-631)	2
1-16618	Spacer—Clamp (Solar 1-1157)	6
1-16619	Channel Assembly—Upper half clamp LH (Solar 1-1640)	2
1-16619-1	Channel Assembly—Upper half clamp RH (Solar 1-1640-1)	2
1-16620	Channel—Clamp (Solar 1-1647)	2L
1-16620-1	Channel—Clamp (Solar 1-1647-1)	2R
1-19051	Retainer—Nut (Solar 1-2015)	8
51-1184	Nut—Square (Solar 1-1283)	8
BAC1095-1032	Nut—Self-locking high temperature	10
46-8648	Clamp Installation—Inboard station 2D LH	1
46-8648-1	Clamp Installation—Inboard station 2D RH	1
6-8476	Clamp Assembly—Upper half (Solar drawing 3-631)	2
1-16618	Spacer—Clamp (Solar 1-1157)	6
1-16619	Channel Assembly—Upper half clamp LH (Solar 1-1640)	2
1-16619-1	Channel Assembly—Upper half clamp RH (Solar 1-1640-1)	2
1-16620	Channel—Clamp (Solar 1-1647)	2L
1-16620-1	Channel—Clamp (Solar 1-1647)	2R
1-19051	Retainer—Nut (Solar 1-2015)	8
51-1184	Nut—Square	8
1-19068	Strap—Exhaust stack support	2
BAC1095-1032	Nut—Self-locking high temperature	14
46-8649	Clamp Installation—Inboard station 2 LH	1
46-8649-1	Clamp Installation—Inboard station 2 RH	1
1-19082	Strap—Exhaust stack support	2
1-19665-1	Bracket—Exhaust stack support	4
6-8460-1	Clamp Assembly—Upper half station 2 (Solar drawing 3-632-3)	2
1-16613	Angle Assembly—Clamp (Solar drawing 1-1657)	4
1-16615	Angle—Clamp (Solar drawing 1-1656)	4
1-19051	Retainer—Nut (Solar drawing 1-2015)	8
51-1184	Nut—Square (Solar drawing 1-1283)	8
1-16614-1	Spacer—Clamp	4
BAC1095-1032	Nut—Self-locking high temperature	8
9-3186	Seal Installation—Outboard shroud	2
9-3186-1	Gasket Assembly—Outboard shroud seal	2
	(Parts List No. 266)	
9-3186-3	Seal—Asbestos—outboard shroud (Johns Manville or equivalent)	2
6-9519	Plate—Seal—inboard shroud	2
3-14980	Retainer—Seal—Inboard shroud	2
15-7666	Cowl Installation—Fixed outboard LH	1
15-7666-1	Cowl Installation—Fixed outboard RH	1
15-7666-2	Cowl Assembly—Fixed outboard spot weld LH	1
15-7666-3	Cowl Assembly—Fixed outboard spot weld RH	1
15-7666-4	Cowl Assembly—Fixed outboard spot weld LH	1
15-7666-5	Cowl Assembly—Fixed outboard spot weld RH	1
15-7666-6	Segment Assembly—Fixed outboard cowl spot weld LH	2
15-7666-7	Segment Assembly—Fixed outboard cowl spot weld RH	2
15-7666-14	Plate—Reinforcing—fixed outboard cowl	4
15-7666-15	Ring—Fixed outboard cowl LH	2
15-7666-16	Ring—Fixed outboard cowl RH	2

AVIALOGS.COM

FINAL ASSEMBLY

Power Plant Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18250	Spring Instrument—Dzus fastener	48
41-2086	Guide—Cowl fastener	48
41-3637	Spring—Dzus fastener	48
1-18193	Angle Assembly—Cowl ring splice	2
1-18193-1	Angle Assembly—Cowl ring splice	2
BAC1253-10	Nut Plate—High tempered	6
BAC1254-10	Nut Plate—Countersunk high tempered	4
3-13909	Brace—Cowl ring	2
3-13909-1	Brace—Cowl ring	2
15-7669	Nose Assembly—Fixed cowl LH	1
15-7669-1	Nose Assembly—Fixed cowl RH	1
BAC1253-110	Nut Plate—High tempered	16
BAC1095-1032	Nut—Self-locking high tempered	4
15-6624	Shroud Installation—Forward outboard	2
15-6624-1	Shroud Assembly—Spot weld	2
41-2086-1	Guide—Cowl fastener	8
41-3637	Spring—Dzus fastener	8
15-7609	Cover Instrument—Carburetor intake	2
15-7609-4	Cover Assembly—Carburetor intake	2
15-7609-1	Cover Assembly—Spot-weld carburetor intake	2
15-7609-2	Cover—Spot weld carburetor intake	2
1-18250	Spring Instrument—Dzus fastener	8
41-2086	Guide—Cowl fastener	8
41-3637	Spring—Dzus fastener	8
BAC1245-10	Nut—Anchor high tempered	4
BAC1253-10	Nut Plate—High tempered	22
BAC1253-110	Nut Plate—High tempered	12
BAC1254-10	Nut Plate—High tempered	4
1-19076	Support Assembly—Cowl	2
1-19076-1	Support Assembly—Cowl	2
BAC569-20	Clamp Assembly—1″ wide round tube double	4
	(Parts List No. 267)	
BAC1550-11	Sleeve—5/16-.058	8
3-13803-2	Support Assembly—Cowl	2
3-13803-3	Support Assembly—Cowl	2
BAC569-20	Clamp Assembly—1″ wide round tube double	4
BAC1550-11	Sleeve—5/16-.058	8
BAC1095-1032	Nut—Self-locking high tempered	16
15-7668	Cowl Installation—Fixed inboard LH	1
15-7668-1	Cowl Installation—Fixed inboard RH	1
15-7668-2	Cowl Assembly—Fixed inboard	1
15-7668-3	Cowl Assembly—Fixed inboard	1
15-7668-12	Cowl Assembly—Fixed inboard spot weld	1
15-7668-13	Cowl Assembly—Fixed inboard spot weld	1
15-7668-22	Segment Assembly—Fixed inboard cowl	1
15-7668-23	Segment Assembly—Fixed inboard cowl	1
15-7668-28	Ring Assembly—Fixed inboard cowl	1
15-7668-29	Ring Assembly—Fixed inboard cowl	1
1-18250	Spring Installation—Dzus fastener	36
15-7669	Nose Assembly—Fixed cowl LH	2
BAC1253-110	Nut Plate—High tempered	16
3-13909	Brace—Cowl ring	2
3-13909-1	Brace—Cowl ring	2
BAC1095-1032	Nut—Self-locking high tempered	4
15-7668-4	Segment Assembly—Fixed inboard cowl LH	1
15-7668-5	Segment Assembly—Fixed inboard cowl RH	1
15-7668-18	Ring Assembly—Fixed outboard cowl LH	1
15-7668-19	Ring Assembly—Fixed outboard cowl RH	1
1-18250	Spring Installation—Dzus fastener	12
15-6625	Shroud Installation—Forward inboard	1
15-6625-1	Shroud Installation—Forward inboard	1
15-6625-2	Shroud Assembly—Spot weld forward inboard	1
15-6625-3	Shroud Assembly—Spot weld forward inboard	1
41-2086-1	Guide—Cowl fastener	8

Power Plant Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-3637	Spring—Dzus fastener	8
15-7609	Cover Installation—Carburetor intake	2
15-7609-4	Cover Assembly—Carburetor intake	2
15-7609-1	Cover Assembly—Spot weld—carburetor intake	2
1-18250	Spring Installation—Dzus fastener	8
41-2086	Guide—Cowl fastener	8
41-3637	Spring—Dzus fastener	8
1-18193	Angle Assembly—Cowl ring splice	2
1-18193-1	Angle Assembly—Cowl ring splice	2
BAC1253-10	Nut Plate—High tempered	12
BAC1254-10	Nut Plate—Countersunk high tempered	8
BAC1245-10	Nut—Anchor high tempered	4
BAC1253-10	Nut Plate—High tempered	28
BAC1253-110	Nut Plate—High tempered	12
BAC1254-10	Nut Plate—Countersunk high tempered	4
	(Parts List No. 268)	
1-19076	Support Assembly—Engine cowl	1
1-19076-1	Support Assembly—Engine cowl	1
BAC569-20	Clamp Assembly—1″ wide round tube double	2
BAC1550-11	Sleeve—5/16-.058	8
3-13803	Support Assembly—Cowl LH	1
3-13803-1	Support Assembly—Cowl RH	1
BAC569-20	Clamp Assembly—1″ wide round tube double	2
BAC1550-11	Sleeve—5/16-.058	8
3-13802	Support Assembly—Cowl LH	1
3-1380?-1	Support Assembly—Cowl RH	1
BAC569-20	Clamp Assembly—1″ wide round tube double	2
BAC1550-11	Sleeve—5/16-.058	4
BAC1095-1032	Nut—Self-locking high tempered	14
15-7616	Cowl Installation—Anti-drag ring	2
15-7616-1	Cowl Installation—Anti-drag ring	1
15-7616-2	Cowl Installation—Anti-drag ring	1
15-7655	Flap Installation—Engine cowl (used on 15-7616)	2
15-7655-1	Flap Installation—Engine cowl (used on 15-7616-1)	1
15-7655-2	Flap Installation—Engine cowl (used on 15-7616-2)	1
15-7624	Ring Assembly—Cowl flap support	4
15-7624-1	Tube Assembly—Weld cowl flap support	4
15-7624-2	Tube Assembly—Weld cowl flap support	4
15-7624-16	Tube Assembly—Weld cowl flap support	8
15-7624-17	Tube Assembly—Weld cowl flap support	4
41-3637	Spring—Dzus fastener	48
1-20021	Channel—Cowl flap ring splice	20
NAS53-12.5A	Bolt—Close tolerance	80
15-7655-3	Mounting—Cowling flap (Lord Co., No. J-1246-3)	36
15-7662	Flap Assembly—Anti-drag ring (used on 15-7655)	2
21-6082-56	Button—Dzus type FA	12
15-7662-3	Grommet—Dzus—Anti-drag ring flap	12
9-3682	Flap Assembly—Anti-drag ring (used on 15-7655)	2
21-6082-56	Button—Dzus type FA	12
9-3682-3	Grommet—Anti-drag ring flap	12
9-3682	Flap Assembly—Anti-drag ring (used on 15-7655-1 and -2)	4
21-6082-56	Button—Dzus type FA	24
9-3682-3	Grommet—Anti-drag ring flap	24
9-3614	Flap Assembly—Anti-drag ring (used on 15-7655-1 and -2)	2
9-3614-1	Stiffener Assembly—Spot weld anti-drag ring	2
3-14923	Lever Assembly—Cowling flap	2
6-10473	Lever—Cowling flap	2
3-14923-1	Bushing—Cowling flap lever	4
3-14911	Hinge Assembly—Cowling ring	2
1-21949-2	Bushing—Cowling flap	4
1-19062-1	Strip—Cowl flap rubbing plate	2
3-14650	Plate—Cowling flap filler	2

AVIALOGS.COM

FINAL ASSEMBLY

Power Plant Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 268A)	
1-21966	Spacer—Anti-drag ring	2
BAC1470-10-8S	Screw—Button head recessed	16
9-3658	Flap Assembly—Anti-drag ring special	4
9-3658-1	Stiffener Assembly—Anti-drag ring special	4
6-9485	Lever Assembly—Cowling flap filler	4
6-9485-2	Lever—Cowling flap filler	4
6-9485-3	Bushing—Cowling flap filler	8
1-21966	Spacer—Anti-drag ring	4
3-14911	Hinge Assembly—Cowling ring	4
	(Parts List No. 269)	
1-21949	Bushing—Cowling flap	8
3-14650	Plate—Cowling flap filler	4
BAC1470-10-8S	Screw—Button head recessed	32
BAC1252-210S	Plate—Fiber nut	4
BAC1246-110S	Plate—Fiber nut	4
9-3424	Flap Assembly—Anti-drag ring (used on 15-7655-1 and 2)	2
9-3424-1	Stiffener Assembly—Anti-drag ring	2
3-13786-1	Plate—Cowl flap filler	2
1-21064	Plate—Cowl flap rubbing	2
3-14911	Hinge Assembly—Cowling ring	2
1-21949	Bushing—Cowling flap	4
3-14923	Lever Assembly—Cowling flap	2
3-14923-1	Bushing—Cowling flap lever	4
6-10473	Lever—Cowling flap	2
1-21966	Spacer—Anti-drag ring	2
BAC1470-10-8S	Screw—Button head recessed	16
6-10129	Flap Assembly—Anti-drag special	4
15-7971	Flap Assembly—Anti-drag special	4
15-7971-2	Stiffener Assembly—Anti-drag special flap	4
3-14650	Plate—Cowling flap filler	4
3-14923	Lever Assembly—Cowling flap filler	4
6-10473	Lever—Cowling flap filler	4
3-14923-1	Bushing—Cowling flap lever	8
BAC1252-210S	Plate—Fiber nut	8
BAC1470-10-8S	Screw—Button head recessed	32
3-14911	Hinge Assembly—Cowling ring	4
1-21949	Bushing—Cowling flap	8
1-21966	Spacer—Anti-drag ring	4
6-10129-1	Flap Assembly—Anti-drag special	8
15-7971-1	Flap Assembly—Anti-drag special	8
15-7971-3	Stiffener Assembly—Anti-drag special flap	8
1-21064	Plate—Cowling flap rubbing	8
3-14923	Lever Assembly—Cowling flap	8
6-10473	Lever—Cowling flap	8
3-14923-1	Bushing—Cowling flap lever	16
BAC1470-10-8	Screw—Button hand recessed	8
BAC1252-210S	Plate—Fiber nut	32
3-14911	Hinge Assembly—Cowling ring	8
1-21949	Bushing—Flap	16
1-21966	Spacer—Anti-drag ring	8
6-10128	Flap Assembly—Anti-drag ring (for 15-7655)	24
6-10128-1	Flap Assembly—Anti-drag ring (for 15-7655-1 and 2)	20
15-7970	Flap Assembly—Anti-drag ring	44
15-7970-1	Stiffener Assembly—Anti-drag ring flap	44
3-14650	Plate—Cowling flap filler	44
1-21064	Plate—Cowling flap rubbing	44
3-14923	Lever Assembly—Cowling flap	44
3-14923-1	Bushing—Cowling flap lever	88
	(Parts List No. 270)	
6-10473	Lever—Cowling flap	44
BAC1470-10-8S	Screw—Button head recessed	352
3-14911	Hinge Assembly—Cowling flap	44
1-21949	Bushing—Cowling flap	88
1-21966	Spacer—Anti-drag ring	44

Power Plant Installation

Part No.	1 2 3 4 5 6 7	Per Assy
9-3687	Bracket Assembly—Rear ring cowl flap	36
1-21949-1	Bushing—Cowling flap	72
9-3687-2	Bracket—Rear ring cowl flap (casting 9-3687-1)	36
15-7655-5	Lever Assembly—Cowling flap	28
15-7655-8	Lever Assembly—Cowling flap	28
3-13742	Lever Assembly—Emergency cowl flap	56
3-13742-2	Lever—Emergency cowl flap	56
BAC366-21ST	Bushing—Bearing	224
3-13791	Housing Assembly—Cowl flap	56
3-13791-1	Housing—Cowl flap	56
3-14908	Lever Assembly—Cowling flap	56
3-14908-2	Lever—Cowling flap	56
1-21924-3-0218	Bushing—Cowling flap	112
1-18915	Shaft—Cowl flap	56
BAC1095-1032	Nut—Self-locking high tempered	112
41-7085-72-33	Washer	56
15-7655-6	Lever Assembly—Cowling flap LH	4
3-13791	Housing Assembly—Cowl flap	4L
3-13791-1	Housing—Cowl flap	4
3-14908	Lever Assembly—Cowling flap	4L
3-14908-2	Lever—Cowling flap	4
1-21924-3-0218	Bushing—Cowling flap	8
6-9492	Lever Assembly—Cowl flap cylinder	4L
6-9492-2	Lever—Cowl flap cylinder	4
BAC326-18S	Bushing—Bearing	8
BAC366-18S	Bushing—Bearing	8
1-18915	Shaft—Cowl flap	4
BAC1095-1032	Nut—Self-locking high tempered	8
41-7085-72-33	Washer	4
15-7655-7	Lever Assembly—Cowling flap RH	4
3-13750	Lever Assembly—Cowl flap cylinder	4R
3-13750-2	Lever—Cowl flap cylinder	4
BAC326-18S	Bushing—Bearing	8
BAC366-18S	Bushing—Bearing	8
3-14908	Lever Assembly—Cowling flap	4R
3-14908-2	Lever—Cowling flap	4
1-21924-3-0218	Bushing—Cowling flap	8
3-13791	Housing Assembly—Cowl flap	4R
3-13791-1	Housing—Cowl flap	4
1-18915	Shaft—Cowling flap	4R
BAC1095-1032	Nut—Self-locking high tempered	8R
41-7085-72-33	Washer	4
	(Parts List No. 271)	
6-9447	Cylinder Assembly—Cowling flap	4
3-13764	Cylinder—Cowling flap operating	4
3-13765	End—Cowling flap cylinder	4
3-13766	End—Cowling flap cylinder	4
3-13767	End Assembly—Piston rod	8
3-13767-1	Housing—Piston end rod	8
3-13767-2	Bearing—Piston rod end	8
1-18603	Nut—Packing gland	8
1-21393	Nut—Packing gland	4
1-21958	Ring—End packing	4
1-21399	Ring—Cowling flap cylinder	4
41-7710	Ring—Sealing	8
3-13768	Piston Assembly—Cowling flap operating	4
1-18909	Piston—Cowling flap operating	4
3-13769	Rod—Cowling flap operator	4
1-21956	Washer—Cowling flap cylinder	16
1-18604	Spacer—Piston rod	4
AN316-7R	Nut	8
3-14921	Link Assembly—Anti-drag ring support	36
1-17579	Link—Engine cowling flaps	56
3-14912	Bracket Assembly—Anti-drag ring support	36
1-21924-4-0281	Bushing—Cowling flap	72
1-19052-9-5	Rod Assembly—⅜ control	64
1-19052-9-5A	Tube Assembly—⅜ control rod	64
1-19813-2	Rod End—Female	128
1-18487	Rod End—Self-aligning	128
1-19052-15-3	Rod Assembly—⅜ control	4

AVIALOGS.COM

FINAL ASSEMBLY

Power Plant Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-19052-15-3A	Tube Assembly—⅜ control rod	4
1-19813-2	Rod End—Female	8
1-18487	Rod End—Self-aligning	8
41-2486	Washer—Bearing retainer	4
1-20017	Spacer—No. 10 bolt	4
1-21963	Spacer—Anti-drag ring	36
BAC54-S15	Bolt—Close tolerance	112
BAC54-S13.5	Bolt—Close tolerance	8
BAC1095-1032	Nut—Self-locking high tempered	128
15-7962	Segment Assembly—Anti-drag ring—top	4
3-14676	Stiffener—Anti-drag ring	8
BAC802-3-60	Jumper Assembly—Terminal bonding	4
3-14900	Stop Assembly—Anti-drag ring LH	4
3-14900-1	Stop Assembly—Anti-drag ring RH	4
15-7961	Segment Assembly—Anti-drag ring LH	4
3-14000-1	Stop Assembly—Anti-drag ring	8
3-14676	Stiffener—Anti-drag ring	8
1-21395	Bracket—Anti-drag ring forward fastener	4
1-21395-1	Bracket—Anti-drag ring forward fastener	4
1-21396	Bracket—Anti-drag ring forward fastener	4
	(Parts List No. 272)	
1-21396-1	Bracket—Anti-drag ring forward fastener	4
1-21397	Bracket—Anti-drag ring forward fastener	4
1-21397-1	Bracket—Anti-drag ring forward fastener	4
15-7961-27	Grommet—Dzus—Anti-drag ring segment	24
15-7961-28	Fastener—Dzus—Anti-drag ring segment	24
BAC802-3-60	Jumper Assembly—Terminal bonding	8

Power Plant Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7960	Segment Assembly—Anti-drag ring RH	4
3-14900	Stop Assembly—Anti-drag ring	8
3-14676	Stiffener—Anti-drag ring	8
1-21390	Bracket—Anti-drag ring forward fastener	4
1-21390-1	Bracket—Anti-drag ring forward fastener	4
1-21391	Bracket—Anti-drag ring forward fastener	4
1-21391-1	Bracket—Anti-drag ring forward fastener	4
1-21392	Bracket—Anti-drag ring forward fastener	4
1-21392-1	Bracket—Anti-drag ring forward fastener	4
1-21385	Trunnion—Anti-drag ring fastener	24
1-21927	Bolt—Anti-drag ring clamping	12
15-7960-27	Grommet—Dzus—anti-drag ring segment	24
15-7960-28	Fastener—Dzus—anti-drag ring segment	24
3-14676	Stiffener—Anti-drag ring	8
BAC802-3-60	Jumper Assembly—Terminal bonding	4
15-8524	Ring Assembly—Anti-drag front support	4
3-14902	Bracket Assembly—Forward cowling support	36
1-21924-4-0375	Bushing—Cowling flap	72
3-14902-2	Support—Cowling forward (Casting 3-14902-1)	36
3-14921	Link Assembly—Anti-drag ring support	36
3-14912	Bracket Assembly—Anti-drag ring support	36
1-21924-4-0281	Bushing—Cowling flap	72
15-7616-3	Lord Mount—Anti-drag ring cowling (Ford Co., No. J-1246-3)	36
3-14928	Ring—Cowling forward chafing	4
1-21963	Spacer—Anti-drag ring	36
BAC802-6-40	Jumper Assembly—Terminal bonding	16
15-7350-1	Seal—Power plant	2

POWER PLANT INSTALLATION

Engine Installation

(Parts List No. 273)

55-7359-400	Engine Installation—No. 1	1
	Dash number parts, shown on 55-7359 drawings are represented by dash numbers of 15-7359 and 55-7359.	
55-7359-401	Engine Installation—No. 2	1
55-7359-402	Engine Installation—No. 3	1
55-7359-403	Engine Installation—No. 4	1
55-6185	Mount Assembly—Engine	4
15-7683	Bracket Installation—Engine mount ring	4
41-8304	Cone—Jacking	4L
3-11776	Bracket—Engine shock unit	36
3-11776-1	Bracket—Engine shock unit	36
41-6845	Plate—Name	4
AN310-10	Nut—Castle	16
21-2365-64-41	Washer—.094 steel	24
55-7359-404	Tube—Engine	4
55-7359-405	Spacer—Engine	4
15-7359-7	Engine—Wright cyclone (government furnished) W.A.C. drawing	4
15-7359-6	Propeller—(government furnished) Hamilton station propeller	4
15-7359-9	Starter—Engine—type G6 special (government furnished)	4
15-7359-5	Governor—Hamilton standard propeller engine (government furnished)	4
15-7359-11	Generator—Engine Nos. 1, 3, 4	3
AN520-10-8	Screw	12
AN520-10-12	Screw	4
AN520-416-10	Screw	16
365-428	Nut—Self-locking	16
AN960B-416	Washer—Plain	16
15-7359-12	Pump—Vacuum—engine (used on engine No. 2 and No. 3) (government furnished)	2
15-7359-13	Pump—Fuel engine (government furnished)	4
15-7359-14	Tube—Crankcase breather engine	4

Engine Installation

1-13114-46	Clamp—Round tube	4
BAC540-6	Clamp—Loop type cushioned	12
BAC540-16	Clamp—Loop type cushioned	4
745-3A	Clamp—Tube	8
851-16	Elbow—(Furnished by Wright Aero Corp.)	4
882-16-10	Hose—Aircraft	4
AN520-10-10	Screw	4
365-1032	Nut	20
14-1820	Support Installation—Starter crank	4
14-1820-7	Support Assembly—Weld—starter crank	4
14-1820-8	Support Assembly—Starter crank	4
BAC569-20H	Clamp Assembly—1 inch wide round tube double	12
BAC1550-11	Sleeve—5/16-.058	24
15-7681	Tube Installation—Magneto blast LH	4
1-19707-4	Tubing Assembly—Flexible	4
A1512-2	Bushing—Starter crank support oilite bronze (Kingswell Bros., San Francisco)	4
	(Parts List No. 274)	
15-7681-7	Bracket Assembly—Magneto blast RH	4
1-19859-1	Angle—Blast tube support	4
1-19990	Angle—Blast tube support	4
1-19708	Angle—Tube support	4
BAC535-32	Clamp—Hose	16
BAC535-28	Clamp—Hose	4
15-7681-1	Tube Installation—Magneto blast RH (engine Nos. 1 and 4)	2
15-7681-8	Bracket Assembly—Magneto blast RH (engine Nos. 1 and 4)	2
1-19859	Angle—Blast tube support	2
1-19990	Angle—Blast tube support	2
1-19707-4	Tubing Assembly—Flexible	2
1-19708-1	Angle—Tube support	2
BAC535-32	Clamp—Hose	8

AVIALOGS.COM

POWER PLANT INSTALLATION

Engine Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC535-28	Clamp—Hose	2
15-7682	Tube Installation—Magneto blast RH (engine Nos. 2 and 3)	2
15-7682-2	Tube Assembly—Weld—magneto blast RH (engines 2 and 3)	2
15-7682-8	Bracket Assembly—Magneto blast RH (engines 2 and 3)	2
1-19859	Angle—Blast tube support	2
1-19990-1	Angle—Blast tube support	2
1-16665	Angle—Tube support	2
1-19708-1	Angle—Tube support	2
1-19706-3	Tubing—Flexible	2
BAC535-20	Clamp—Hose	3
BAC535-32	Clamp—Hose	6
BAC540-14	Clamp—Loop type cushioned	2
15-6246	Mounting Installation—Engine dynafocal suspension	4
15-6246-1	Bracket Assembly—Engine dynafocal suspension (Lord drawing J-1238-D, Part RL-15-2)	4
15-6246-2	Bracket Assembly—Engine dynafocal suspension (Lord drawing J-1238-E, Part RL-15-3)	12
15-6246-4	End Plate—Engine dynafocal suspension (Lord drawing J-1238-8, Part RL-15-13)	72
15-6246-13	Washer—Rubber snubbing—engine dynafocal suspension (Lord drawing J-1238-11, Part RL-15-22)	72
15-6246-5	Mounting—Rubber—engine dynafocal suspension (Lord drawing J-1205, Part RL-15-1)	36
1-17095	Link Assembly—Dynafocal suspension (Lord drawing J-1238-A)	36
15-6246-9	Bolt—Engine dynafocal suspension (Lord drawing J-1238-9, Part RL-15-14)	36
15-6246-11	Washer—Engine dynafocal suspension (Lord drawing J-1240-16, Part R1-15-16)	36
15-6246-10	Nut—Slotted engine dynafocal suspension (Lord drawing J-1240-7, Part RL-15-15)	36
15-6246-12	Cotter—Engine dynafocal suspension (Lord drawing J-1240-9, Part RL-15-17)	36
15-6246-14	Bolt—Engine dynafocal suspension (Lord drawing J-1240-12, Part RL-15-24)	36
	(Parts List No. 275)	
15-6246-16	Washer—Engine dynafocal suspension (Lord drawing J-1240-16, Part RL-15-20)	36
15-6246-6	Washer—Engine dynafocal suspension (Lord drawing J-1240-10, Part RL-15-12)	36
15-6246-15	Nut—Slotted engine dynafocal suspension (Lord drawing J-1240-7, Part RL-15-19)	36
15-6246-17	Cotter—Engine dynafocal suspension (Lord drawing J-1240-9, Part RL-15-11)	36
15-7653	Plate Assembly—Engine air seal (engine No. 1)	1
15-7653-8	Segment Assembly—Engine air seal plate	1
3-16452	Plate Assembly—Splice	1
BAC1243-410S	Plate	2
1-18923	Channel—Stiffener	1
1-21052	Stiffener—Channel	1
3-13749	Cover—Engine air seal	1
BAC1252-10S	Plate—Fiber nut	2
15-7653-21	Segment Assembly—Engine air seal plate	2
1-19043	Plate Assembly—Splice	2
BAC1246-10S	Plate—Fiber nut	2
BAC1249-210S	Plate—Fiber nut	4
1-21051	Stiffener—Channel	1
1-21052	Stiffener—Channel	1
1-18923	Stiffener—Channel	1
1-18931	Gusset—Flanged	1
3-13753	Plate—Reinforcing	1
BAC1252-10S	Plate—Fiber nut	2
3-13701	Plate—Splice	1
3-13748-2	Channel Assembly—Reinforcing	1
BAC1249-110S	Plate—Fiber nut	2
15-7653-1	Plate Assembly—Engine air seal (engine No. 2)	1

Engine Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7653-8	Segment Assembly—Engine air seal plate	1
3-16452	Plate Assembly—Splice	1
BAC1243-410S	Plate	2
1-18923	Channel—Stiffener	1
1-21052	Stiffener—Channel	1
3-13749	Cover—Engine air seal	1
BAC1252-10S	Plate—Fiber nut	2
15-7653-20	Segment Assembly—Engine air seal plate	1
1-18923	Channel—Stiffener	1
1-19043	Plate Assembly—Splice	1
BAC1246-10S	Plate—Fiber nut	1
BAC1249-210S	Plate—Fiber nut	2
3-13753	Plate—Reinforcing	1
BAC1252-10S	Plate—Fiber nut	2
3-13748-2	Channel Assembly—Reinforcing	1
1-21051	Stiffener—Channel	1
1-21052	Stiffener—Channel	1
BAC1249-110S	Plate—Fiber nut	2
3-13701	Plate—Splice	1
15-7653-22	Plate Assembly—Engine air seal	1
15-7653-2	Segment Assembly—Air seal plate	1
	(Parts List No. 276)	
1-19043	Plate Assembly—Splice	1
BAC1246-10S	Plate—Fiber nut	1
BAC1249-210S	Plate—Fiber nut	2
3-13753	Plate—Reinforcing	1
BAC1252-10S	Plate—Fiber nut	2
1-18923	Channel—Stiffener	1
1-21051	Stiffener—Channel	1
1-21052	Stiffener—Channel	1
15-7653-8	Segment Assembly—Engine air seal	1
1-18923	Channel—Stiffener	1
1-18924	Channel—Splice	1
BAC1243-410S	Plate—Fiber nut	2
3-13749	Cover—Engine air seal	1
1-21052	Stiffener—Channel	1
BAC1252-10S	Plate—Fiber nut	1
3-13701	Plate—Splice	1
3-13748-2	Channel Assembly—Reinforcing	1
BAC1249-110S	Plate—Fiber nut	2
15-7653-23	Plate Assembly—Engine air seal (engine No. 4)	1
15-7653-12	Segment Assembly—Air seal plate	1
1-19043	Plate Assembly—Splice	1
BAC1246-10S	Plate—Fiber nut	1
BAC1249-110S	Plate—Fiber nut	2
3-13753	Plate—Reinforcing	1
1-18931	Gusset—Flanged	1
BAC1252-10S	Plate—Fiber nut	2
1-18923	Channel—Stiffener	1
1-21051	Stiffener—Channel	1
1-21052	Stiffener—Channel	1
15-7653-8	Segment Assembly—Engine air seal	1
1-18923	Channel—Stiffener	1
1-18924	Channel Assembly—Splice	1
BAC1243-410S	Plate—Fiber nut	2
3-13749	Cover—Engine air seal	1
1-21052	Stiffener—Channel	1
BAC1252-10S	Plate—Fiber nut	1
3-13701	Plate—Splice	1
3-13748-2	Channel Assembly—Reinforcing	1
BAC1249-110S	Plate—Fiber nut	2
6-10482-9	Drain Installation—Induction system (engine No. 1)	1
6-10482-10	Drain Installation—Induction system (engine No. 2)	1
6-10482-11	Drain Installation—Induction system (engine No. 3)	1
6-10482-12	Drain Installation—Induction system (engine No. 4)	1
6-10482-1	Drain Tube—Induction system (used on -9)	1
6-10482-5	Drain Tube—Induction system (used on -9)	1

AVIALOGS.COM

POWER PLANT INSTALLATION

Engine Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-10482-2	Drain Tube—Induction system (used on -10)	1
6-10482-6	Drain Tube—Induction system (used on -10)	1
6-10482-3	Drain Tube—Induction system (used on -11)	1
6-10482-7	Drain Tube—Induction system (used on -11)	1
6-10482-4	Drain Tube—Induction system (used on -12)	1
6-10482-8	Drain Tube—Induction system (used on -12)	1
	(Parts List 276A)	
BAC540-6	Clamp—Loop type cushioned (4 on engine Nos. 1 and 2, 6 on engine Nos. 3 and 4)	10
BAC1603-8	Spacer—No. 10 bolt (4 on engine Nos. 1 and 2, 6 on engine Nos. 3 and 4)	10
BAC535-12	Clamp—Hose	16
6-9495	Bracket Installation—Propeller pitch control (engine No. 1)	1
6-9495-1	Bracket Assembly—Propeller pitch control (engine No. 1)	1
	(Parts List No. 277)	
1-19001-99	Fair-lead Assembly—One hole	1
1-19001-98	Fair-lead Assembly—One hole	1
1-19001-100	Fair-lead—Half	1
BAC1603-46	Spacer—No. 10 bolt	1
BAC1603-70	Spacer—No. 10 bolt	1
9-3691	Bracket Installation—Propeller pitch control (engine Nos. 2 and 3)	2
9-3691-1	Bracket Assembly—Propeller pitch control (engine Nos. 2 and 3)	2
9-3691-3	Bracket Assembly—Propeller pitch control (engine Nos. 2 and 3)	2
BAC1614-51	Spacer—⅛ rivet	4
3-13799	Support Assembly—Propeller pitch control	2
BAC1603-8	Spacer—⅛ rivet	2
BAC1603-14	Spacer—⅛ rivet	2
BAC1603-18	Spacer—⅛ rivet	2
BAC1603-24	Spacer—⅛ rivet	2
6-9498	Bracket Installation—Propeller pitch control (engine No. 4)	1
6-9498-1	Bracket Assembly—Propeller pitch control (engine No. 4)	1
BAC1614-56	Spacer—⅛ rivet	1
1-19001-5	Fair-lead Assembly—1 hole	1

Engine Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-19001-6	Fair-lead—Micarta	1
1-19001-7	Fair-lead—Micarta	1
3-13804	Support Assembly—Propeller pitch control	1
BAC1603-8	Spacer—No. 10 bolt	1
BAC1603-29	Spacer—No. 10 bolt	1
1-18313	Pump Assembly—Hydraulic system (engine No. 1)	1
1-21063	Pump Assembly—Glycol (engine No. 2 only)	1
46-9626	Drain Installation—Dual accessory drive (engine 2 only)	2
46-9626-400	Tube—Dual accessory drive drain	2
46-9626-401	Tube—Dual accessory drive drain	2
BAC535-10	Clamp—Hose	8
BAC540-4	Clamp—Loop type cushioned	2
1-21441-90	Jumper Assembly—Terminal bonding	16
1-21441-90A	Braid—Terminal bonding jumper	16
1-21441-4	Terminal—Electrical bonding jumper	16
1-21441-5	Terminal—Electrical bonding jumper	16
1-21902-84	Jumper Assembly—Terminal bonding	4
1-21902-84A	Braid—Terminal bonding jumper	4
1-21902-4	Terminal—Electrical bonding jumper	4
1-21902-5	Terminal—Electrical bonding jumper	4
BAC800-44	Jumper Assembly—Single terminal bonding	4
BAC800-44A	Braid—Copper—single terminal bonding jumper	4
BAC820-6	Terminal — Lock — single terminal bonding jumper	4
BAC802-7-40	Jumper Assembly — Terminal bonding (used on engine No. 1)	1
	(Parts List No. 278)	
BAC802-7-40E	Braid—Copper terminal bonding jumper	1
BAC802-7-40	Jumper Assembly—Terminal bonding (used on engine No. 2, No. 3, and No. 4)	6
BAC802-7-40E	Braid—Copper terminal bonding jumper	6

Fuel System Installation

(Parts List No. 279)

1-18638	Fuel System Installation	1
15-7029	Tank Installation—Wing fuel LH	1
15-7029-1	Tank Installation—Wing fuel RH	1
15-9526	Tank Installation—Bomb bay	1
55-7348	Fuel Tubing Installation	1

FUEL SYSTEM INSTALLATION

Tank Installation—Wing Fuel

(Parts List No. 280)

15-7029	Tank Installation—Wing fuel LH	1
15-7029-1	Tank Installation—Wing fuel RH	1
1-18123	Tank Assembly—Fuel wing transfer LH	1
1-18123-1	Tank Assembly—Fuel wing transfer RH	1
1-18123-2	Fuel Tank—Wing transfer LH	1
1-18123-3	Fuel Tank—Wing transfer RH	1
1-18123-4	Name Plate—Wing trans. fuel tank	2
3-13808-7	Cap Installation—Filler unit	2
3-13613-8	Strainer Assembly—Tank filler unit	2
3-12971	Nut—Filler unit	2
3-13614	Screen Assembly—Tank filler unit	2
3-13613-1	Ring—Split tank filler unit strainer (Pacific Marine Supply, Seattle, Wash. No. 10)	2
3-13613-2	Ring—Split tank filler unit strainer (Pacific Marine Supply, Seattle, Wash. No. 7)	2
3-13613-3	Swivel—Box filler tank unit strainer (Pacific Marine Supply, Seattle, Wash. No. 3/0)	2
3-13613-5	Chain—Filler tank unit strainer	2

Tank Installation—Wing Fuel

3-13806-7	Cap Assembly—Filler unit	2
1-18569-1	Gasket—Filler unit	2
1-19667	Handle—Filler cap	2
1-19668	Fitting—Filler cap	4
41-2558-1	Spring—Filler cap	2
3-16112-2	Cap—Filler unit	2
51-189	Angle—Filler unit	2
1-20016	Gasket—Annular	2
1-18840	Lockpin—Fuel tank liner	4
1-18433	Plug—Autosyn float accessory	2
15-7048	Shell Assembly—Feeder fuel tank LH	1
15-7048-1	Shell Assembly—Feeder fuel tank RH	1
15-7048-2	Container Assembly—Feeder fuel tank shell LH	1
15-7048-3	Container Assembly—Feeder fuel tank shell RH	1
1-21994	Holder—Name plate	2
3-13929	Plate Assembly—Anchor	16
15-7048-8	Cap Assembly—Feeder fuel tank shell LH	1
15-7048-14	Cap Assembly—Fender fuel tank shell RH	1
1-18267	Channel—Tank end reinforcing	4

AVIALOGS.COM

FUEL SYSTEM INSTALLATION

Tank Installation—Wing Fuel

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18541	Clip—Fuel tank	2
3-13560	Plate—Fuel autosyn adapter	2
6-9365-2	Collar Assembly—Autosyn support	2
1-18435-1	Bushing—Drain cock	2
1-19963	Hook Assembly—Lacing	2
1-19963-4	Hook Assembly—Lacing	2
1-19963-2	Hook—Lacing (used on 1-19963)	2
1-19963-5	Hook—Lacing (used on 1-19963-4)	2
3-13940	Stay Installation—Tank liner	14
1-20024	Washer—Special	14
3-13928	Stay Assembly—Fuel tank liner	14
21-6092-32-6	Bolt—Special No. 10-32	14
3-13940-1	Stay Installation—Tank liner	2
	(Parts List No. 281)	
1-20024	Washer—Special	2
3-13928-5	Stay Assembly—Fuel tank liner strap	2
21-6092-32-6	Bolt—Special No. 10-32	2
BAC802-2-60	Jumper Assembly—Terminal bonding	2
660-2	Terminal	4
1-20046	Lockpin—Fuel tank liner	8
1-20046-1	Lockpin—Fuel tank liner	10
1-20046-2	Lockpin—Fuel tank liner	8
1-20046-3	Lockpin—Fuel tank liner	4
1-20046-4	Lockpin—Fuel tank liner	2
1-20046-5	Lockpin—Fuel tank liner	4
BAC535-16	Clamp—Hose	2
1-18124	Tank Assembly—Fuel (engine Nos. 2 and 3) LH	1
1-18124-1	Tank Assembly—Fuel (engine Nos. 2 and 3) RH	1
1-18124-2	Tank—Leakproof fuel (engines 2 and 3) LH	1
1-18124-3	Tank—Leakproof fuel (engines 2 and 3) RH	1
1-18124-4	Name Plate—Leakproof fuel (engines 2 and 3)	2
1-19963	Hook Assembly—Lacing	8
1-19963-1	Hook Assembly—Lacing	2
1-19963-2	Hook—Lacing (used on 1-19963)	8
1-19963-3	Hook—Lacing (used on 1-19963-1)	2
BAC802-2-60	Jumper Assembly—Terminal bonding	2
660-2	Terminal	4
1-19963-4	Hook Assembly—Lacing	2
1-19963-5	Hook—Lacing	2
1-20046	Lockpin—Fuel tank liner	6
1-20046-1	Lockpin—Fuel tank liner	14
1-20046-2	Lockpin—Fuel tank liner	16
1-20046-3	Lockpin—Fuel tank liner	2
3-13808-8	Cap Installation—Filler unit	2
3-13613-9	Strainer Assembly—Tank filler unit	2
3-13614	Screen Assembly—Tank filler unit	2
3-13613-1	Ring—Split filler tank unit strainer (Pacific Marine Supply, Seattle, Wn. No. 10)	2
3-13613-2	Ring—Split filler tank unit strainer (Pacific Marine Supply, Seattle, Wn. No. 7)	2
3-13613-3	Swivel—Box filler tank unit strainer (Pacfiic Marine Supply, Seattle, Wn. No. 3/0)	2
3-13613-5	Chain—Filler tank unit strainer	2
3-12976	Nut—Filler unit	2
3-13806-8	Cap Assembly—Filler unit	2
1-18569-1	Gasket—Filler unit	2
1-19667	Handle—Filler unit	2
1-19668	Fitting—Filler unit	4
41-2558-1	Spring—Filler unit	2
3-16112-3	Cap—Filler unit	2
51-189	Angle—Filler unit	2
1-20016	Gasket—Annular	2
1-18840	Lockpin—Fuel tank liner	4
1-18433	Plug—Autosyn float accessory	2
	(Parts List No. 282)	
15-7349	Shell Assembly—Engines 2 and 3 fuel tank LH	1
15-7349-1	Shell Assembly—Engines 2 and 3 fuel tank RH	1
15-7349-2	Container Assembly—Engines 2 and 3 fuel tank shell LH	1

Tank Installation—Wing Fuel

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7349-3	Container Assembly—Engines 2 and 3 fuel tank shell RH	1
1-21994	Holder—Name plate	2
15-7349-9	Cap Assembly—Weld engines 2 and 3 fuel tank shell LH	1
15-7349-10	Cap Assembly—Weld engines 2 and 3 fuel tank shell RH	1
1-18276	Channel—Tank end reinforcing	4
1-18541	Clip—Fuel tank	2
3-13560	Plate—Fuel autosyn adapter	2
6-69365-3	Collar Assembly—Autosyn support	2
3-9351	Clamp Assembly—Overflow pan adapter	6
BAC1550-8	Sleeve—5/16-.058	4
3-13000-5	Strap Assembly—Fuel tank end brace	2
3-13000-4	Pad—Fuel tank end brace strap	2
1-21018	Fitting—Tank strap	2
1-18199	Fitting—Tank strap	4
1-18309-2	Angle—End strap brace	2
BAC324-9S	Bushing—Bearing	6
3-13451-5	Strap Assembly—Fuel tank end brace	2
3-13451-4	Pad—Fuel tank end brace strap	2
1-21018-3	Fitting—Tank strap	2
1-18199	Fitting—Tank strap	4
1-18309-2	Angle—End strap brace	2
3-13438-1	Pad—Tank strap	2
BAC324-9S	Bushing—Bearing	6
3-13454-5	Strap Assembly—Fuel tank end brace	2
3-13454-4	Pad—Fuel tank end brace strap	2
1-21018	Fitting—Tank strap	2
1-18199	Fitting—Tank strap	4
1-18309-3	Angle—End strap brace	2
BAC324-9S	Bushing—Bearing	6
3-13457-5	Strap Assembly—Fuel tank end brace	2
3-13457-3	Pad—Neoprene fuel tank end brace strap	2
1-18199	Fitting—Tank strap	4
1-18309	Angle—End strap brace	2
3-13438	Pad—Tank strap	2
1-21018-1	Fitting—Tank strap	2
BAC324-9S	Bushing—Bearing	2
3-13464-5	Strap Assembly—Fuel tank end brace	2
3-13464-4	Pad—Fuel tank end brace strap	2
1-21018	Fitting—Tank strap	2
1-18199	Fitting—Tank strap	4
1-18309-2	Angle—End strap brace	2
BAC324-9S	Bushing—Bearing	6
3-13467-5	Strap Assembly—Fuel tank end brace	2
	(Parts List No. 283)	
3-13467-4	Pad—Fuel tank end brace strap	2
1-21018-2	Fitting—Tank strap	4
1-18199	Fitting—Tank strap	4
1-18309-5	Angle—Tank strap	2
BAC324-9S	Bushing—Bearing	6
3-13490-4	Strap Assembly—Fuel tank end brace	2
3-13490-3	Pad—Fuel tank end brace strap	2
1-21018	Fitting—Tank strap	4
1-18309-2	Angle—End strap brace	2
3-13438-2	Pad—Tank strap	2
BAC324-9S	Bushing—Bearing	4
3-13491-4	Strap Assembly—Fuel tank end brace	2
3-13491-3	Pad—Fuel tank end brace strap	2
1-18309-4	Angle—End strap brace	2
3-13438-4	Pad—Tank strap	2
1-21018	Fitting—Tank strap	2
1-21018-2	Fitting—Tank strap	2
BAC324-9S	Bushing—Bearing	4
6-10694-3	Strap Assembly—Fuel tank support	2
6-10694-5	Strap Assembly—Fuel tank support	2
6-10694-7	Strap Assembly—Fuel tank support	2
6-10694-9	Strap Assembly—Fuel tank support	2
6-10694-11	Strap Assembly—Fuel tank support	2

AVIALOGS.COM

FUEL SYSTEM INSTALLATION

Tank Installation—Wing Fuel

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-10694-13	Strap Assembly—Fuel tank support	2
6-10694-15	Strap Assembly—Fuel tank support	2
6-10694-17	Strap Assembly—Fuel tank support	2
6-10694-19	Strap Assembly—Fuel tank support	2
6-10694-21	Strap Assembly—Fuel tank support	2
1-20363-1	Fork—Fuel tank support	20
1-16050-3-0	Cushion—Tank support	20
1-20356	Fitting—Tank strap	80
1-20357	Washer—Ball seat	20
21-9588-1	Washer—Ball seat	20
6-8965-32	Block—Micarta fuel tank support	20
1-20355	Link Assembly—Tank support	20
1-20355-1	Strap—Tank support	20
1-20355-2	Spacer—Tank support	20
BAC326-12S	Bushing—Bearing	20
BAC327-12S	Bushing—Bearing	20
BAC1604-64	Spacer	20
6-10693-1	Strap Assembly—Fuel tank support	2
6-10693-3	Strap Assembly—Fuel tank support	2
6-10693-5	Strap Assembly—Fuel tank support	2
6-10693-7	Strap Assembly—Fuel tank support	2
6-10693-9	Strap Assembly—Fuel tank support	2
6-10693-11	Strap Assembly—Fuel tank support	2
1-16050-5-6	Strip—Tank support	12
1-20355	Link Assembly—Fuel tank support	12
1-20355-1	Strap—Fuel tank support link	12
1-20355-2	Spacer—Fuel tank support link	12
	(Parts List No. 284)	
1-20356	Fitting—Tank strap	48
1-20357	Washer—Ball seat	12
1-20363	Fork—Fuel tank support	12
21-9588-1	Washer—Ball seat	12
BAC326-12S	Bushing—Bearing	12
BAC327-12S	Bushing—Bearing	12
BAC1604-64	Spacer	12
3-13444	Transmitter—Fuel level	2
3-13444-1	Transmitter—Fuel level	2
3-13444-2	Transmitter—Fuel level	2
1-18802	Elbow—¾ hose special 90°	8
56-8969-500	Beam Assembly—Fuel tank support	4
1-17564-1	Channel—Strap attachment	8
1-18888-275	Spacer—Tank stop	8
6-9488	Pan Assembly—Fuel tank overflow LH	1L
6-9488	Pan Assembly—Fuel tank overflow LH	2R
6-9488-1	Pan Assembly—Fuel tank overflow RH	2L
6-9488-1	Pan Assembly—Fuel tank overflow RH	1R
1-19666	Lug Assembly—Fuel tank pan	12
3-9287	Pan Assembly—Fuel tank overflow	6
6-8969-5	Beam Assembly—Fuel tank support	4
1-17564-2	Channel—Strap attachment	8
6-10694-1	Strap Assembly—Fuel tank support	20
1-16050-3-0	Cushion—Tank support	20
1-20363-1	Fork—Fuel tank support	20
1-20355	Link Assembly—Fuel tank support	20
1-20355-1	Strap—Fuel tank support link	20
1-20355-2	Spacer—Fuel tank support link	20
1-20356	Fitting—Tank strap	80
1-20357	Washer—Ball seat	20
21-9588-1	Washer—Ball seat	20
6-8965-31	Block—Micarta fuel tank support	20
BAC327-12S	Bushing—Bearing	20
BAC326-12S	Bushing—Bearing	20
BAC1604-64	Spacer	20
6-9592	Strap Assembly—Fuel tank end brace	2
1-18309-2	Angle—End strap brace	2
1-17570-6	Fitting—Tank strap	2
6-9592-3	Pad—Tank strap	2
1-19833	Fitting—Tank strap	4
3-13438-3	Pad—Tank strap	2
BAC326-12S	Bushing—Bearing	6
6-9593	Strap Assembly—Fuel tank end brace	2

Tank Installation—Wing Fuel

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18309	Angle—End strap brace	2
1-19833	Fitting—Tank strap	4
1-17570-6	Fitting—Tank strap	2
	(Parts List No. 284A)	
6-9593-3	Pad—Tank strap	2
3-13438-5	Pad—Tank strap	2
BAC326-12S	Bushing—Bearing	6
3-13901	Strap Assembly—Fuel tank end brace	2
1-18309-1	Angle—End strap brace	2
1-17570-5	Fitting—Tank strap	2
3-13901-3	Pad—Tank strap	2
1-19833	Fitting—Tank strap	4
BAC326-12S	Bushing—Bearing	6
	(Parts List No. 285)	
3-13902	Strap Assembly—Fuel tank end brace	2
1-18309-1	Angle—End strap brace	2
1-17570-5	Fitting—Tank strap	2
1-13902-3	Pad—Tank strap	2
1-19833	Fitting—Tank strap	4
BAC326-12S	Bushing—Bearing	6
6-9597-3	Beam Assembly—Fuel tank support	2
1-17564-2	Channel—Strap attachment	4
6-8978-3	Beam Assembly—Fuel tank support	6
1-18116-2	Channel—Strap attachment	12
7-1500-42	Beam Assembly—Fuel tank support LH	1
7-1500-43	Beam Assembly—Fuel tank support RH	1
1-17564-2	Channel—Strap attachment	4
1-18317	Strip—Bevel fuel tank support	2
7-1509-4	Beam Assembly—Fuel tank support LH	1
7-1509-5	Beam Assembly—Fuel tank support RH	1
1-18317	Pad—Tank strap	2
1-17564-2	Channel—Strap attachment	4
7-1519-6	Beam Assembly—Fuel tank support LH	1
7-1519-7	Beam Assembly—Fuel tank support RH	1
1-17564-2	Channel—Strap attachment	4
1-18317	Pad—Tank strap	2
1-18888-275	Spacer—Tank stop	4
7-1520-5	Beam Assembly—Fuel tank support LH	1
7-1520-6	Beam Assembly—Fuel tank support RH	1
1-18888-275	Spacer—Tank stop	4
1-18317	Pad—Tank strap	2
1-17564-2	Channel—Strap attachment	4
7-1521-6	Beam Assembly—Fuel tank support LH	1
7-1521-7	Beam Assembly—Fuel tank support RH	1
1-18317	Pad—Tank strap	2
1-17564-2	Channel—Strap attachment	4
21-4844-60	Jumper Assembly—No. 10-10 terminal bonding	8
BAC820-10	Terminal—Electric lock	16
15-7936	Tank Assembly—Fuel engine Nos. 1 and 4 LH	1
15-7936-1	Tank Assembly—Fuel engine Nos. 1 and 4 RH	1
1-20046-3	Lockpin—Fuel tank liner	2
1-20046-4	Lockpin—Fuel tank liner	2
1-18433	Plug—Autosyn float access	2
1-18435-1	Bushing—Drain cock	2
1-18840	Lockpin—Fuel tank liner	10
1-19963-4	Hook Assembly—Lacing	2
1-19963	Hook Assembly—Lacing	4
1-19963-1	Hook Assembly—Lacing	2
	(Parts List No. 286)	
1-19963-2	Hook—Lacing (used on 1-19963)	2
1-19963-3	Hook—Lacing (used on 1-19963-1)	4
1-19963-5	Hook—Lacing (used on 1-19963-4)	2
BAC802-2-60	Jumper Assembly—Terminal bonding	2
660-2	Terminal	4
1-20046	Lockpin—Fuel tank liner	14
1-20046-1	Lockpin—Fuel tank liner	18
1-20046-2	Lockpin—Fuel tank liner	6

AVIALOGS.COM

FUEL SYSTEM INSTALLATION

Tank Installation—Wing Fuel

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-13560-6	Plate—Fuel autosyn adapter	2
BAC535-16	Clamp—Hose	2
3-13808-6	Cap Installation—Filler unit	2
3-13613-7	Strainer Assembly—Tank filler unit	2
3-13613-1	Ring—Split (Pac. Marine Sup., Seattle, Wn. No. 10)	2
3-13613-2	Ring—Split (Pac. Marine Sup., Seattle, Wn. No. 7)	2
3-13613-3	Swivel—Box (Pac. Marine Sup., Seattle, Wn. No. 3/0)	2
3-13613-5	Chain—Filler tank unit	2
3-12970	Nut—Filler unit	2
3-13614	Screen Assembly—Tank filler unit	2
3-13806-6	Cap Assembly—Filler unit	2
1-18569-1	Gasket—Filler unit	2
1-19667	Handle—Filler cap	2
1-19668	Fitting—Filler cap	4
41-2558-1	Spring—Filler cap	2
3-16112-1	Cap—Filler unit	2
51-189	Angle—Filler unit	2
1-20016	Gasket—Annular	2
3-13940	Stay Installation—Tank liner	4
1-20024	Washer—Special	6
3-13928	Stay Assembly—Fuel tank liner	6
21-6092-32-6	Bolt—Special No. 10-32	6
3-13940-1	Stay Installation—Tank liner	2
1-20024	Washer—Special	2
3-13928-5	Stay Assembly—Fuel tank liner	2
21-6092-32-6	Bolt—Special No. 10-32	2
6-9365-4	Collar Assembly—Autosyn support	2
55-7028	Shell Assembly—Engine 1 and 4 fuel tanks LH	1
55-7028-1	Shell Assembly—Engine 1 and 4 fuel tanks RH	1
55-7028-402	Cap Assembly—Engine 1 and 4 fuel tanks LH	1
55-7028-403	Cap Assembly—Engine 1 and 4 fuel tanks RH	1
1-18267	Channel—Tank end reinforcement	2
1-18274	Channel—Tank end reinforcement	2
1-18274-406	Container Assembly—Tank end reinforcement	1
1-18274-407	Container Assembly—Tank end reinforcement	1
1-21994	Holder—Name plate	2
1-18541	Clip—Fuel tank	2
3-13929	Plate Assembly—Anchor	6
1-17550	Name Plate—Fuel tank	2
BAC1603-8	Spacer—No. 10 bolt	2

(Parts List No. 287)

BAC1603-12	Spacer—No. 10 bolt	6
BAC1603-40	Spacer—No. 10 bolt	2
BAC540-22	Clamp—Loop type cushioned	64
BAC802-2-50	Jumper Assembly—Terminal bonding	4
BAC802-2-65	Jumper Assembly—Terminal bonding	2
BAC802-2-100	Jumper Assembly—Terminal bonding	12
BAC535-16	Clamp—Hose	24
BAC535-18	Clamp—Hose	8
BAC535-23	Clamp—Hose	12
BAC540-10	Clamp—Loop type cushioned	24
21-2589-23	Clip—Tab loop type	8
1-20022	Angle—Tube support	24
1-13892-56-12	Clamp—Tabulated square	2
1-13892-38-8	Clamp—Tabulated square	4
41-128-20-12	Washer—.125 steel	30
1-18437-1	Gasket—Fuel autosyn flange	3L
15-7029-2	Hose—Vent wing fuel tank	2
15-7029-3	Hose—Vent wing fuel tank	2
15-7029-4	Hose—Vent wing fuel tank	2
15-7029-13	Hose—Vent wing fuel tank	2
15-7029-14	Hose—Vent wing fuel tank	2
15-7029-8	Tube—Overflow wing fuel tank	2
15-7029-9	Tube—Overflow wing fuel tank	1L
15-7029-15	Tube—Overflow wing fuel tank	1L
15-7029-16	Tube—Overflow wing fuel tank	1R
15-7029-17	Tube—Overflow wing fuel tank	1L
15-7029-18	Tube—Overflow wing fuel tank	1R

Tank Installation—Auxiliary Fuel

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy

(Parts List No. 288)

15-9462	Tank Installation—Auxiliary fuel	1
	Dash number parts, shown on 15-9462 drawing are represented by dash numbers of 15-7336 and 15-9462.	
6-10732	Tank Assembly—Auxiliary fuel tank non-metallic self-sealing LH	1
6-10732-1	Tank Assembly—Auxiliary fuel tank non-metallic self-sealing RH	1
69-2220	Cradle Installation—Auxiliary fuel tank LH	1
69-2220-1	Cradle Installation—Auxiliary fuel tank RH	1
69-2220-605	Cradle Assembly—Auxiliary fuel tank	4
1-16050-6-4	Cushion—Tank support	4
1-16050-6-0	Cushion—Tank support	4
BAC1604-75	Spacer—¼ bolt	24
59-2221-501	Beam Assembly—Inboard RH	1
59-2221-502	Beam Assembly—Inboard LH	1
41-761	Channel—Tank support	2
41-762	Channel—Tank support	2
3-13771-1	Strap Assembly—Tank support	4
1-18914	Fitting—Tank strap	4
3-12062-16	Cushion Assembly—Tank support	4
3-12062-17	Pad—Tank switch support cushion	4
1-16050-15-7	Cushion—Tank support	4
3-8406	Plate—Tank support LH	2
3-8406-1	Plate—Tank support RH	2
3-12994	Fitting Assembly—Auxiliary fuel tank	2
3-12994-1	Fitting Assembly—Auxiliary fuel tank	2
1-18540	Lug—Tank support	4
BAC1603-45	Spacer—¼ bolt	2
BAC1603-54	Spacer—¼ bolt	24
59-2222-501	Beam Assembly—Outboard LH	1
59-2222-502	Beam Assembly—Outboard RH	1
41-761	Channel—Tank support	2
41-762	Channel—Tank support	2
3-13771	Strap Assembly—Tank support	4
1-18914	Fitting—Tank strap	4
3-12062-18	Cushion Assembly—Tank support	4
3-12062-19	Pad—Tank switch support cushion	4
1-16050-19-3	Cushion—Tank support	4
3-8406	Plate—Tank support RH	1
3-8406-1	Plate—Tank support LH	1
1-17577	Angle—Auxiliary fuel tank	2
1-17577-1	Angle—Auxiliary fuel tank	2
59-2222-500	Cushion—Outboard beam (Adolite)	2
1-18540	Lug—Tank support	4
BAC1603-45	Spacer—No. 10 bolt	2
BAC1604-54	Spacer—¼ bolt	26
46-5315	Beam Assembly—Tank	4
46-5315-6	Beam Assembly—Tank	4
41-6796-30-1	Pad Assembly—Tank support	4
3-16114	Gage Assembly—Bomb bay fuel LH	1

(Parts List No. 289)

3-16114-1	Gage Assembly—Bomb bay fuel RH	1
3-8793-3	Shell—Auxiliary fuel gage	2
1-11885-4	Glass—Sight gage	2
1-14068	Cap—Upper shell end	4
41-9863	Gasket—End cap	4
21-3339-22	Clamp—Round loop type	4
3-18291	Marker—Gage orifice restriction	2
3-16134-1	Decalcomania—Bomb bay fuel gage	2
1-17554	Plate—Auxiliary fuel tank	4
1-17552	Stop—Auxiliary fuel tank	4
33D5226	Shackle—(Type B-7) (government furnished)	4
75-7336-600	Tube—Auxiliary fuel tank	2
75-7336-601	Tube—Auxiliary fuel tank LH	1
75-7336-603	Tube—Auxiliary fuel tank RH	1
21-2589-16	Clip—Tab loop type	8
1-18402	Pad Assembly—Auxiliary fuel tank	2
1-18402-1	Channel—Auxiliary fuel tank pad	2

AVIALOGS.COM

FUEL SYSTEM INSTALLATION

Tank Installation—Auxiliary Fuel

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18402-2	Pad—(Adolite) auxiliary fuel tank	2
1-18403	Pad Assembly—Auxiliary fuel tank	6
1-18403-1	Channel—Auxiliary fuel tank pad	6
1-18403-2	Pad—(Adolite) auxiliary fuel tank	6
1-18404	Pad Assembly—Auxiliary fuel tank	2
1-18404-1	Channel—Auxiliary fuel tank pad	2
1-18404-2	Pad—(Adolite) auxiliary fuel tank pad	2
1-18405	Pad Assembly—Auxiliary fuel tank	2
1-18405-1	Channel—Auxiliary fuel tank pad	2
1-18405-2	Pad—(Adolite) auxiliary fuel tank pad	2
1-18406	Pad Assembly—Auxiliary fuel tank	4
1-18406-1	Channel—Auxiliary fuel tank pad	4
1-18406-2	Pad—(Adolite) auxiliary fuel tank pad	4
1-17553	Stop Assembly—Auxiliary fuel tank	4
1-17553-1	Stop—Auxiliary fuel tank	4
1-17553-2	Pad—Auxiliary fuel tank (cement with Goodrich cement)	4
3-9640-14	Strainer Assembly—Auxiliary fuel tank	2
3-9640-4	Chain—Auxiliary fuel tank safety	2
3-9640-5	Ring—Split auxiliary fuel tank (Pac. Marine Supply, Seattle, Wn. No. 7)	2
3-9640-6	Swivel—Auxiliary fuel tank (Pac Marine Supply, Seattle, Wn. No. 3/0)	2
3-9640-9	Ring—Split auxiliary fuel tank (Pac Marine Supply, Seattle, Wn. No. 10)	2
3-9639	Screen Assembly—Tank filler unit	2
3-9639-1	Frame—Tank filler unit screen	2
3-9639-2	Wire—Tank filler unit screen	2
3-9639-3	Screen—Tank filler unit monel metal wire	2
3-13757	Nut Assembly—Tank filler unit	2
3-13757-1	Nut—Tank filler unit	2
1-19081	Lug—Filler unit	8
3-13807-3	Cap Assembly—Auxiliary fuel tank filler unit	2
3-16112	Cap—Filler unit	2

(Parts List No. 290)

3-13807-1	Spacer—Filler unit cap	2
41-2558-1	Spring—Filler cap	2
51-189	Angle—Filler unit	2
1-27615	Handle—Filler cap	2
1-18569-1	Gasket—Filler unit	2
1-27645	Spring	2
6067-8Z	Nut—Speed (Tinnerman)	2
1-18536-8-199	Washer—Serrated	40
1-18380-8-199	Washer—Side window	40
41-G1742	Release—Bomb (government furnish)	2
41-G1742-1	Release—Bomb (type A-2) (furnished for installation check)	2
BAC540-8	Clamp—Cushioned	2
BAC540-10	Clamp—Loop type cushioned	4
BAC540-28	Clamp—Loop type cushioned	4
BAC535-27	Clamp—Hose	8
BAC800-60	Jumper—Single terminal bonding	2
1-20016	Gasket—Annular	2
1-17555	Plate—Auxiliary fuel tank	4
15-7336-10	Hose—Auxiliary fuel tank	2
15-7336-11	Angle—Auxiliary fuel tank	2
75-7336-606	Tube Assembly—Auxiliary fuel tank	2

Fuel Tubing Installation

(Parts List No. 291)

55-7348	Fuel Tubing Installation	1

Dash number parts, shown on 55-7348 drawing are represented by dash numbers of 15-7348 and 75-7348.

1-18860	Plate—Outboard fuel strainer	2
6-8955-2	Pump—Booster	4
6-9352	Strainer Installation—Outboard fuel LH	1
6-9352-1	Strainer Installation—Outboard fuel RH	1
6-9352-2	Strainer Assembly—Outboard fuel LH	1
6-9352-3	Strainer Assembly—Outboard fuel RH	1

Fuel Tubing Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
13961	Strainer—Horizontal or vertical tube (Aero Supply Co., Corry, Pa., No. 139603)	2
1-24222-1	Fitting Assembly—Beaded LH	2
1-24222-4	Fitting Assembly—Beaded RH	2
9-3663	Valve Installation—Fuel transmission selective LH	1
9-3663-1	Valve Installation—Fuel transmission selective RH	1
9-3663-10	Switch Assembly—Fuel transmission valve	2
9-3663-8	Switch—Fuel transmission valve	2
1-24625	Attachment—Actuator	2
9-3663-2	Valve—Fuel transmission selective valve (Aero Supply Co., Corry, Pa., No. 940167)	2
9-3663-8	Switch—Micro—Fuel transmission selective valve	2
1-24625	Actuator—Warning switch	2
1-24222-3	Fitting Assembly—Fuel selective valve	2
1-18764-1	Plate—Micro switch mount	2
1-18865	Adapter—Selective valve controls	2
6-9374-1	Bracket Assembly—Selective valve center support	1R
6-9374-2	Bracket Assembly—Selective valve center support	1L
1-18751	Angle—Support	8
1-18756-1	Handle Assembly—Selective valve control	1
1-18861-1	Dial Assembly—Fuel transmission selective valve	1
1-18866	Screw—Headless drive	1
1-18756-2	Handle Assembly—Selective valve control	1
1-18861-2	Dial Assembly—Fuel transmission selective valve	1
1-18866	Screw—Headless drive	1
3-16129-2	Plate—Name	1R
3-16129-1	Plate—Name	1L
3-13663	Bracket—Selective valve control support	2
066650	Driver—Fuel cock control yoke	2
9-3663-7	Elbow—Hose—90° fuel transmission selective valve	2
9-3668	Pump Installation—Fuel transfer	1
9-3668-7	Unit Assembly—Pump	1
RG4430-2	Fuel Pump—RG-4430-2 or RG-4430A pump—Fuel Transfer Romec Pump Co., Elyria, Ohio, per Boeing Specification drawing 1-18708 (interchangeable with Pump Engineering Service Corporation, Cleveland, Ohio, drawing No. 542N per Boeing Specification drawing 1-187 08)	1
1-24222-3	Fitting Assembly—Fuel transmission pump	2
41-9106-1	Fair-lead—2 tube—¼ diameter	2

(Parts List No. 292)

41-9761	Primer Assembly—Parker 4 engine (Parker Appliance, Cleveland, No. 4050 PN)	1
51-1086	Fair-lead—Tube	2
6-9588	Strainer Installation—Inboard fuel LH	1
6-9588-1	Strainer Installation—Inboard fuel RH	1
6-9588-2	Strainer Assembly—Inboard fuel	1
6-9588-3	Strainer Assembly—Inboard fuel	1
1-19817-2	Cup—Fuel strainer LH	1
1-19817-3	Cup—Fuel strainer RH	1
51-121	Strainer Assembly—Horizontal or vertical tube (Aero Supply Co., Corry, Pa., No. 13960-3)	2
1-24222-4	Fitting Assembly—Beaded LH	1
1-24222-6	Fitting Assembly—Beaded	3
1-18619	Extension—Tank drain	2
1-20248	Plate—Clamp support	4
41-9007-1	Angle—Tube support	1
1-20071-1	Elbow—1 inch hose special 90°	2
1-20072-2	Elbow—1¼ inch hose special 30°	2
1-20075	Elbow—1 inch hose special 60°	2
1-20022	Angle—Tube support	17
1-20022-1	Angle—Tube support	2
3-14207	Angle Installation—Fuel hose support	6

AVIALOGS.COM

FUEL SYSTEM INSTALLATION

Fuel Tubing Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-14207-2	Angle—Fuel hose support	6
BAC540-4	Clamp—Loop type cushioned	99
BAC540-16	Clamp—Loop type cushioned	1
BAC540-18	Clamp—Loop type cushioned	4
BAC540-26	Clamp—Loop type cushioned	115
BAC540-10	Clamp—Loop type cushioned	8
BAC540-8	Clamp—Loop type cushioned	2
BAC540-30	Clamp—Loop type cushioned	10
BAC540-14	Clamp—Loop type cushioned	14
BAC1603-16	Spacer—No. 10 bolt	4
BAC1603-22	Spacer—No. 10 bolt	2
BAC1603-64	Spacer—No. 10 bolt	4
BAC1603-80	Spacer—No. 10 bolt	2
BAC802-2-150	Jumper Assembly—Terminal bonding	4
660-2	Terminal	8
55-7348-410	Fitting Assembly—Fuel tubing	2
15-7348-113	Hose—Tee—Fuel tubing	2
BAC1200-B64	Wire—For locking	2
55-7348-400	Hose—Tee self-sealing—Fuel tubing	2
55-7348-401	Hose—Tee self-sealing—Fuel tubing	2
55-7348-402	Hose—Tee self-sealing—Fuel tubing	2
55-7348-403	Hose—Tee self-sealing—Fuel tubing	2
15-7348-1	Hose—Tee self-sealing—Fuel tubing	2
15-7348-3	Hose—Tee self-sealing—Fuel tubing	2
15-7348-4	Hose—Tee self-sealing—Fuel tubing	1
15-7348-5	Hose—Tee self-sealing—Fuel tubing	1
15-7348-10	Hose—Tee self-sealing—Fuel tubing	1
15-7348-11	Hose—Tee self-sealing—Fuel tubing	1
15-7348-12	Hose—Tee self-sealing—Fuel tubing	1
	(Parts List No. 293)	
15-7348-13	Hose—Tee self-sealing—Fuel tubing	1
15-7348-14	Hose—Tee self-sealing—Fuel tubing	4
15-7348-115	Hose—Tee self-sealing—Fuel tubing	2
15-7348-122	Hose—Tee self-sealing—Fuel tubing	2
1-13114-46	Clamp—Tee	2
21-2589-31	Clip—Tab loop type	4
21-2589-39	Clip—Tab loop type	4
21-4585-140-32	Clamp—Tee	1
21-4585-168-48	Clamp—Tee	2
BAC535-22	Clamp—Hose	4
55-7348-409	Gasket—Fuel tubing	4
15-7348-126	Angle—Fuel tubing	2
15-7348-129	Strip—Lacing—Fuel tubing	1
BAC1603-48	Spacer—No. 10 bolt	1
1-24222-2	Fitting Assembly—Beaded	4
1-24222-4	Fitting Assembly—Beaded	2
1-24222-5	Fitting Assembly—Beaded	4
1-24222-6	Fitting Assembly—Beaded	2
21-4848-80	Jumper Assembly—No. 10 terminal bonding	2
BAC820-10	Terminal—Electrical lock	2
21-4844-80	Jumper Assembly—No. 10-10 terminal bonding	2
21-4844-100	Jumper Assembly—No. 10-10 terminal bonding	4
21-4844-60	Jumper Assembly—No. 10-10 terminal bonding	2
BAC820-10	Terminal—Electrical lock	16
15-9486	Pump Installation—Emergency fuel	1
15-9486-1	Pump Assembly	1
15-9486-2	Padding	1
15-9486-3	Pump—Type D15 (Government furnished)	1
15-9486-6	Bolt—Special	4
15-9486-7	Bracket Assembly—Emergency fuel pump	1
1-24958	Slide	2
1-24960	Strip	2
1-24965	Plate	1
1-24968	Block	1
1-24222-3	Elbow—Hose 90°	1
1-24222-15	Nipple—Hose	1
1-23557	Fitting—Pipe reducer	1
1-24952	Tab	2
1-25516	Strap Assembly—Handle stowage	1
1-25516-1	Strap Assembly—Handle stowage	1

• Fuel Tubing Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-16927-1	Decalcomania	1
41-468-70-16	Clamp—Square tube	1
BAC535-27	Clamp—Hose	2
BAC540-26	Clamp—Loop type cushioned	5
BAC1603-16	Spacer—No. 10 bolt	1
6-10131	Valve Installation—Fuel shut-off inboard LH	1
6-10131-1	Valve Installation—Fuel shut-off inboard RH	1
6-10131-2	Unit Assembly—Valve	1
6-10131-3	Unit Assembly—Valve	1
	(Parts List No. 294)	
3-14653	Valve Assembly—Fuel shut-off	2
3-14653-1	Washer	2
1-24222-1	Fitting Assembly—Beaded	2
1-24222-4	Fitting Assembly—Beaded	2
6-10132	Valve Installation—Fuel shut-off outboard LH	1
6-10132-1	Valve Installation—Fuel shut-off outboard RH	1
6-10132-2	Units Assembly—Valve	1
6-10132-3	Units Assembly—Valve	1
1-24222-1	Fitting Assembly—Beaded	2
1-24222-6	Fitting Assembly—Beaded	2
2660	Valve Assembly—Fuel shut-off (BAC3-14653 Electrimatic Corp., Chicago, Ill.)	2
15-7348-124	Tube—Self-sealing fuel	2
15-7348-125	Tube—Self-sealing fuel	2
15-7348-18	Tube—Self-sealing fuel	1
15-7348-38	Tube—Self-sealing fuel	1
15-7348-47	Tube—Self-sealing fuel	1
15-7348-60	Tube—Self-sealing fuel	1
15-7348-63	Tube—Self-sealing fuel	1
15-7348-67	Tube—Self-sealing fuel	1
15-7348-68	Tube—Self-sealing fuel	1
15-7348-72	Tube—Self-sealing fuel	1
15-7348-73	Tube—Self-sealing fuel	1
15-7348-77	Tube—Self-sealing fuel	1
15-7348-78	Tube—Self-sealing fuel	1
15-7348-83	Tube—Self-sealing fuel	1
15-7348-84	Tube—Self-sealing fuel	4
15-7348-85	Tube—Self-sealing fuel	4
15-7348-89	Tube—Self-sealing fuel	2
15-7348-90	Tube—Self-sealing fuel	2
15-7348-91	Tube—Self-sealing fuel	1
15-7348-92	Tube—Self-sealing fuel	1
15-7348-93	Tube—Self-sealing fuel	1
15-7348-116	Tube—Self-sealing fuel	1
15-7348-118	Tube—Self-sealing fuel	1
15-7348-15	Tube Assembly—Self-sealing fuel	1
15-7348-16	Tube Assembly—Self-sealing fuel	1
15-7348-17	Tube Assembly—Self-sealing fuel	1
15-7348-18	Tube Assembly—Self-sealing fuel	1
15-7348-20	Tube Assembly—Self-sealing fuel	1
15-7348-21	Tube Assembly—Self-sealing fuel	1
15-7348-22	Tube Assembly—Self-sealing fuel	1
15-7348-23	Tube Assembly—Self-sealing fuel	1
15-7348-24	Tube Assembly—Self-sealing fuel	1
15-7348-25	Tube Assembly—Self-sealing fuel	1
15-7348-26	Tube Assembly—Self-sealing fuel	1
15-7348-27	Tube Assembly—Self-sealing fuel	1
15-7348-30	Tube Assembly—Self-sealing fuel	1
15-7348-31	Tube Assembly—Self-sealing fuel	1
15-7348-32	Tube Assembly—Self-sealing fuel	1
15-7348-33	Tube Assembly—Self-sealing fuel	1
	(Parts List No. 295)	
15-7348-34	Tube Assembly—Self-sealing fuel	1
15-7348-35	Tube Assembly—Self-sealing fuel	1
15-7348-36	Tube Assembly—Self-sealing fuel	1
15-7348-39	Tube Assembly—Self-sealing fuel	2
15-7348-40	Tube Assembly—Self-sealing fuel	1
15-7843-42	Tube Assembly—Self-sealing fuel	1

AVIALOGS.COM

FUEL SYSTEM INSTALLATION

Fuel Tubing Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7348-43	Tube Assembly—Self-sealing fuel	1
15-7348-44	Tube Assembly—Self-sealing fuel	1
15-7348-45	Tube Assembly—Self-sealing fuel	1
15-7348-49	Tube Assembly—Self-sealing fuel	1
15-7348-51	Tube Assembly—Self-sealing fuel	1
15-7348-52	Tube Assembly—Self-sealing fuel	1
15-7348-53	Tube Assembly—Self-sealing fuel	1
15-7348-54	Tube Assembly—Self-sealing fuel	1
15-7348-55	Tube Assembly—Self-sealing fuel	1
15-7348-56	Tube Assembly—Self-sealing fuel	1
15-7348-57	Tube Assembly—Self-sealing fuel	1
15-7348-58	Tube Assembly—Self-sealing fuel	1
15-7348-59	Tube Assembly—Self-sealing fuel	1
15-7348-64	Tube Assembly—Self-sealing fuel	1
15-7348-65	Tube Assembly—Self-sealing fuel	1
15-7348-66	Tube Assembly—Self-sealing fuel	1
15-7348-69	Tube Assembly—Self-sealing fuel	1
15-7348-71	Tube Assembly—Self-sealing fuel	1
15-7348-74	Tube Assembly—Self-sealing fuel	1
15-7348-76	Tube Assembly—Self-sealing fuel	1
15-7348-79	Tube Assembly—Self-sealing fuel	1
15-7348-80	Tube Assembly—Self-sealing fuel	1
15-7348-82	Tube Assembly—Self-sealing fuel	1
15-7348-102	Tube Assembly—Self-sealing fuel	1
15-7348-104	Tube Assembly—Self-sealing fuel	1
15-7348-105	Tube Assembly—Self-sealing fuel	1

Fuel Tubing Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7348-106	Tube Assembly—Self-sealing fuel	1
15-7348-112	Tube Assembly—Self-sealing fuel	1
15-7348-114	Tube Assembly—Self-sealing fuel	2
15-7348-117	Tube Assembly—Self-sealing fuel	1
15-7348-119	Tube Assembly—Self-sealing fuel	1
55-7348-405	Tube Assembly—Self-sealing fuel	1
55-7348-407	Tube Assembly—Self-sealing fuel	1
55-7348-408	Tube Assembly—Self-sealing fuel	1
9-3746	Plug Installation—Auxiliary tank port	1
9-3746-1	Plug Installation Auxiliary tank port	1
9-3746-2	Plug Assembly—Auxiliary tank port	2
9-3746-3	Hose—Auxiliary tank port plug	2
9-3746-4	Plug—Auxiliary tank port plug	2
BAC535-27	Clamp—Hose	2
BAC535-27	Clamp—Hose	2
BAC535-10	Clamp—Hose	86
BAC535-23	Clamp—Hose	8
BAC535-24	Clamp—Hose	4
BAC535-27	Clamp—Hose	40
BAC535-30	Clamp—Hose	2
	(Parts List No. 295-A)	
BAC535-31	Clamp—Hose	6
TFD8100	Pump—Booster	4

POWER PLANT INSTALLATION

Oil System Installation

(Parts List No. 296)

65-6242	Oil System Installation	1
15-8522	Tank Installation—Inboard oil LH	1
15-8522-1	Tank Installation—Inboard oil RH	1
	Dash number parts, shown on 65-6242 drawing are represented by dash numbers of 65-6242 and 55-6242.	
15-8541	Tank Installation—Outboard oil LH (PL 301)	1
15-8541-1	Tank Installation—Outboard oil RH (PL 301)	1
15-7772	Regulator Installation—Oil temperature outboard LH	1
15-7772-1	Regulator Installation—Oil temperature outboard RH	1
15-7773	Regulator Installation—Oil temperature inboard LH	1
15-7773-1	Regulator Installation—Oil temperature inboard RH	1
15-7773-2	Cushion—Neoprene—Oil temperature inboard regulator LH	4
15-7773-4	Cushion—Neoprene—Oil temperature inboard regulator	8
1-18826	Strap—Oil cooler	4
1-18895	Filler—Strap end	8
3-13725	Strap Assembly—Oil cooler	8
1-19845	Hook—Strap end	8
15-7310	Intake Assembly—Oil temperature outboard regulator LH	1
15-7944	Intake Assembly—Oil temperature outboard regulator RH	1
15-7647	Intake Assembly—Oil temperature inboard regulator LH	1
15-7647-1	Intake Assembly—Oil temperature inboard regulator RH	1
2E-3078	Regulator—Oil temperature (Airesearch Mfg. Co., Los Angeles, California)	4
51-10-26	Eyebolt—No. ¼-28 (on 15-7772 and -1 only)	4
BAC1901	Washer—Flat head screw	100
BAC802-3-100	Jumper Assembly—Terminal bonding	4

Oil System Installation

51-10-34	Eyebolt—No. ¼-28 (on 15-7773 and -1 only)	4
43-11714	Valve Installation—Inboard oil dilution	2
1-17363	Valve Assembly—Oil dilution solenoid	2
41-9468	Clamp Assembly—2 inch diameter	2
51-163	Support—Valve	2
53-11715	Valve Installation—Outboard oil dilution	2
1-17363	Valve Assembly—Oil dilution solenoid	2
41-9468	Clamp Assembly—2 inch diameter	2
51-163	Support—Valve	2
55-6242-510	Solder Assembly—Oil system	4
65-6242-623	Tube Assembly—Weld—Oil system	1
65-6242-600	Tube Assembly—Oil system	1
37A4041-2	Nut—Thermometer bulb well	1
65-6242-624	Tube Assembly—Weld—Oil system	1
65-6242-601	Tube Assembly—Oil system	1
37A4041-2	Nut—Thermometer bulb well	1
65-6242-625	Tube Assembly—Weld—Oil system	1
65-6242-602	Tube Assembly—Oil system	1
37A4041-2	Nut—Thermometer bulb well	1
	(Parts List No. 297)	
65-6242-626	Tube Assembly—Oil system	1
65-6242-603	Tube Assembly—Oil system	1
37A4041-2	Nut—Thermometer bulb well	1
41-8812-5	Fair-lead Assembly—Oil system	1
41-8812-7	Fair-lead Assembly—Oil system	1
41-9007	Angle Installation—Tube support	9
1-27925	Angle—Tube support	4
1-16351	Angle—Tube support	4
1-27924	Bracket—Tube support	4
37A3528	Fitting—Twin restricted tube	4
37D6114-5	Cock Assembly—"Y" oil drain	4
39G1030-12W-24	Hose—Flexible	1
39G1030-12W-27	Hose—Flexible	1
39G1030-12W-30	Hose—Flexible	2
1-20022	Angle—Tube support	38

AVIALOGS.COM

POWER PLANT INSTALLATION

Oil System Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-14241-6	Tube Assembly—Propeller feather "Y"	2
3-14242	Tube Assembly—Propeller feather "Y"	1
3-14914	Tube Assembly—Propeller feather "Y"	1
BAC1603-20	Spacer—No. 10 bolt	1
BAC1603-8	Spacer—No. 10 bolt	5
BAC1603-32	Spacer—No. 10 bolt	2
BAC1603-40	Spacer—No. 10 bolt	3
BAC535-28	Clamp—Hose	2
BAC540-4C	Clamp—Loop type cushioned	24
BAC540-12C	Clamp—Loop type cushioned	4
BAC540-8	Clamp—Loop type cushioned	11
BAC540-10	Clamp—Loop type cushioned	2
BAC540-20	Clamp—Loop type cushioned	53
BAC543-22-12	Clamp—Round tube strap	4
BAC542-22SF	Channel—Strap clamp	4
65-6242-631	Elbow Assembly—Oil system	2
1-23565	Elbow Assembly—Oil system—Weld	2
BAC535-10	Clamp—Hose	44
BAC535-14	Clamp—Hose	56
BAC535-28	Clamp—Hose	124
BAC535-18	Clamp—Hose	16
BAC535-22	Clamp—Hose	22
55-6242-65	Capacitator—Oil system	4
55-6242-126	Elbow—90° street—Oil system	2
55-6242-400	Nipple—Oil system	1
55-6242-401	Nipple—Oil system	4
55-6242-403	Elbow—45°—Oil system	1
55-6242-404	Elbow—45°—Oil system	3
55-6242-452	Pump—Motor—Oil system (government furnished)	4
55-6242-547	Fitting Assembly—Oil system	13
55-6242-548	Fitting Assembly—Oil system	3
55-6242-549	Fitting Assembly—Oil system	2
	(Parts List No. 297-A)	
55-6242-550	Fitting Assembly—Oil system	2
55-6242-523	Fitting Assembly—Oil system	14
55-6242-524	Fitting Assembly—Oil system	4
	(Parts List No. 298)	
BAC1200-B64	Wire—For locking (used on 55-6242-523 and 524)	2
55-6242-525	Fitting Assembly—Oil system	12
55-6242-527	Fitting Assembly—Oil system	1
55-6242-528	Fitting Assembly—Oil system	2
55-6242-529	Fitting Assembly—Oil system	2
55-6242-533	Fitting Assembly—Oil system	1
65-6242-604	Tube—Oil system	1
65-6242-607	Tube—Oil system	1
65-6242-608	Tube—Oil system	2
65-6242-609	Tube—Oil system	1
65-6242-610	Tube—Oil system	1
65-6242-612	Tube—Oil system	1
65-6242-613	Tube—Oil system	1
65-6242-615	Tube—Oil system	1
65-6242-617	Tube—Oil system	1
65-6242-618	Tube—Oil system	1
65-6242-620	Tube—Oil system	1
65-6242-621	Tube—Oil system	2
65-6242-622	Tube—Oil system	1
65-6242-627	Tube—Oil system	1
65-6242-628	Tube—Oil system	1
65-6242-646	Tube—Oil system	1
65-6242-647	Tube—Oil system	1

Oil System Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-6242-648	Tube—Oil system	1
65-6242-649	Tube—Oil system	1
55-6242-41	Tube—Oil system	1
55-6242-46	Tube—Oil system	1
55-6242-79	Tube—Oil system	1
55-6242-84	Tube—Oil system	1
55-6242-89	Tube—Oil system	1
55-6242-454	Tube—Oil system	1
55-6242-456	Tube—Oil system	1
55-6242-457	Tube—Oil system	1
55-6242-458	Tube—Oil system	1
55-6242-459	Tube—Oil system	1
55-6242-466	Tube—Oil system	1
55-6242-467	Tube—Oil system	1
55-6242-468	Tube—Oil system	1
55-6242-469	Tube—Oil system	1
55-6242-470	Tube—Oil system	1
55-6242-471	Tube—Oil system	1
55-6242-475	Tube—Oil system	1
55-6242-476	Tube—Oil system	1
55-6242-477	Tube—Oil system	1
55-6242-480	Tube—Oil system	1
55-6242-481	Tube—Oil system	1
55-6242-484	Tube—Oil system	1
55-6242-485	Tube—Oil system	1
55-6242-487	Tube—Oil system	1
55-6242-499	Tube—Oil system	2
55-6242-500	Tube—Oil system	1
55-6242-502	Tube—Oil system	1
55-6242-503	Tube—Oil system	1
	(Parts List No. 299)	
55-6242-504	Tube—Oil system	1
55-6242-507	Tube—Oil system	1
55-6242-509	Tube—Oil system	1
55-6242-511	Tube—Oil system	1
55-6242-513	Tube—Oil system	1
55-6242-514	Tube—Oil system	1
55-6242-516	Tube—Oil system	1
55-6242-521	Tube—Oil system	1
55-6242-535	Tube—Oil system	1
55-6242-536	Tube—Oil system	1
55-6242-544	Tube—Oil system	1
55-6242-486	Tube—Oil system	1
55-6242-515	Tube Assembly—Oil system	1
55-6242-537	Tube Assembly—Oil system	1
55-6242-512	Tube Assembly—Oil system	1
55-6242-93	Tube Assembly—Oil system	1
55-6242-92	Tube Assembly—Oil system	1
55-6242-91	Tube Assembly—Oil system	1
55-6242-90	Tube Assembly—Oil system	1
55-6242-50	Tube Assembly—Oil system	1
55-6242-49	Tube Assembly—Oil system	1
55-6242-42	Tube Assembly—Oil system	1
65-6242-637	Tube Assembly—Oil system	1
65-6242-636	Tube Assembly—Oil system	2
65-6242-635	Tube Assembly—Oil system	4
65-6242-634	Tube Assembly—Oil system	2
65-6242-633	Tube Assembly—Oil system	1
65-6242-632	Tube Assembly—Oil system	1
65-6242-616	Tube Assembly—Oil system	2
65-6242-606	Tube Assembly—Oil system	1
65-6242-605	Tube Assembly—Oil system	1

AVIALOGS.COM

OIL SYSTEM INSTALLATION

Tank Installation—Inboard Oil

(Parts List No. 300)

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-8522	Tank Installation—Inboard oil LH	1
15-8522-1	Tank Installation—Inboard oil RH	1
6-10672-1	Tank Assembly—Self-seal oil LH	1
6-10672-2	Tank Assembly—Self-seal oil RH	1
3-14985	Strap Assembly—Oil tank	6
1-20560	Plate—Strap end	12
1-21050	Fitting—Strap end	6
BAC327-15S	Bushing—Bearing	6
1-16056-9-6	Cushion—Tank support	6
1-16056-19-6	Cushion—Tank support	6
3-14933	Strap Assembly—Oil tank	6
1-20560	Plate—Strap end	12
1-21050	Fitting—Strap end	6
BAC327-155	Bushing—Bearing	6
BAC802-3-54	Jumper Assembly—Terminal bonding	2
BAC802-3-64	Jumper Assembly—Terminal bonding	2
1-21424	Washer—Filler unit	2
41-5949-272-164	Washer—.040 aluminum alloy alc	4
15-8522-2	Filler Assembly—Inboard oil tank	2
1-17097-7	Cap Assembly—Tank filler	2
1-23594	Plate—Name	2
41-9241-1	Plate—Name	2
39B4232	Cap	2
1-12965	Nut—Tank filler unit	2

Tank Installation—Outboard Oil

(Parts List No. 301)

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-8541	Tank Installation—Outboard oil LH	1
15-8541-1	Tank Installation—Outboard oil RH	1
6-10672	Tank Assembly—Self-seal oil LH	1
6-10672-3	Tank Assembly—Self-seal oil RH	1
3-14985	Strap Assembly—Oil tank	6
1-20560	Plate—Strap end	12
1-21050	Fitting—Strap end	6
BAC327-155	Bushing—Bearing	6
3-14933	Strap Assembly—Oil tank	6
1-20560	Plate—Strap end	12
1-21050	Fitting—Strap end	6
BAC327-155	Bushing—Bearing	6
1-16056-9-6	Cushion—Tank support	6
1-16056-19-6	Cushion—Tank support	6
BAC-802-3-54	Jumper Assembly—Terminal bonding	2
BAC802-3-130	Jumper Assembly—Terminal bonding	2
1-21424	Washer—Filler unit	2
41-5949-272-164	Washer—.040 aluminum alloy alc	4
15-8541-2	Filler Assembly—Outboard oil tank	2
1-22655	Cap Assembly—Tank filler	2
1-22656	Plate—Name	2
1-22804	Cap Assembly—Tank filler	2
1-12965	Nut—Tank filler unit	2

POWER PLANT INSTALLATION

Conrtols Installation—Engine

(Parts List No. 302)

1-18363	Controls Installation—Engine	1
15-7035	Controls Installation—Throttle (PL 303-317)	1
15-7036	Control Installation—Mixture (PL 318-319)	1
15-7037	Control Installation—Supercharger (PL 320-322)	1
15-7038	Control Installation—Intercooler (PL 323-326)	1
15-7040	Control Installation—Propeller pitch	1
BAC1770-167-4	Cable Assembly—3/32—7 x 7 control	2
BAC1770-167-7	Cable Assembly—3/32—7 x 7 control	2
BAC1770-199-2	Cable Assembly—3/32—7 x 7 control	1
BAC1770-201-2	Cable Assembly—3/32—7 x 7 control	1
BAC1770-253-0	Cable Assembly—3/32—7 x 7 control	1
BAC1770-257-0	Cable Assembly—3/32—7 x 7 control	1
BAC1770-285-2	Cable Assembly—3/32—7 x 7 control	1
BAC1770-294-7	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	18
BAC1808-73	Cable Assembly—3/32—7 x 7 control	2
BAC1808-74	Cable Assembly—3/32—7 x 7 control	2
BAC1825-3	Swaged Terminal—Class "C"	8
BAC1780-26-4R	Cable Assembly—3/32—7 x 7 control	2
BAC1780-43-6R	Cable Assembly—3/32—7 x 7 control	1

Conrtols Installation—Engine

BAC1780-44-2R	Cable Assembly—3/32—7 x 7 control	1
BAC1780-44-5R	Cable Assembly—3/32—7 x 7 control	1
BAC1780-45-2R	Cable Assembly—3/32—7 x 7 control	1
BAC1780-55-7R	Cable Assembly—3/32—7 x 7 control	2
BAC1826-3	Swaged Terminal—Class "B"	8
BAC1827-23R	Swaged Terminal—Class "C"	8
6-9484	Bracket Installation—Propeller pitch	2
6-9484-1	Bracket Assembly—Propeller pitch	2
BAC1614-27	Spacer—1/8 rivet	2
1-19001-19	Fair-lead Assembly—1 hole	2
1-19001-20	Fair-lead—Half micarta	4
6-9493	Bracket Installation—Propeller pitch	1
6-9493-1	Bracket Assembly—Propeller pitch	1
BAC1614-27	Spacer—1/8 rivet	1
1-19001-19	Fair-lead Assembly—1 hole	1
1-19001-20	Fair-lead—Half micarta	2
6-9496	Bracket Installation—Propeller pitch	1
6-9496-1	Bracket Assembly—Propeller pitch	1
BAC1614-27	Spacer—1/8 rivet	1
1-19001-19	Fair-lead Assembly—1 hole	1
1-19001-20	Fair-lead—Half micarta	2
41-5437-1	Link—Adjusting control cable	16

CONTROLS INSTALLATION—ENGINE

Controls Installation—Throttle

(Parts List No. 303)

15-7035	Controls Installation—Throttle	1
15-9275	Stand Installation—Control (PL 305-317)	1
1-18098-9-5	Rod Assembly—Engine control	1
1-18098-9-5A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-18098-10-0	Rod Assembly—Engine control	1

Controls Installation—Throttle

1-18098-10-0A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-18098-12-4	Rod Assembly—Engine control	1
1-18098-12-4A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-18098-13-6	Rod Assembly—Engine control	2
1-18098-13-6A	Tube Assembly—Weld engine control rod	2

AVIALOGS.COM

CONTROLS INSTALLATION—ENGINE

Controls Installation—Throttle

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-19813-3	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
1-18098-13-0	Rod Assembly—Engine control	2
1-18098-13-0A	Tube Assembly—Weld engine control rod	2
1-19813-3	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
1-18098-17-9	Rod Assembly—Engine control	2
1-18098-17-9A	Tube Assembly—Weld engine control rod	2
1-19813-3	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
1-18098-28-9	Rod Assembly—Engine control	1
1-18098-28-9A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-18098-32-6	Rod Assembly—Engine control	1
1-18098-32-6A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-19052-7-2	Rod Assembly—Control 3/8	1
1-19052-7-2A	Tube Assembly—Weld 3/8 control rod	1
1-19813-2	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-19052-9-7	Rod assembly—Control 3/8	1
1-19052-9-7A	Tube Assembly—Weld 3/8 control rod	1
1-19813-2	Rod End—Female	2
1-18487	Rod End—Self-aligning	2

(Parts List No. 304)

1-18979-4-7	Rod Assembly—Engine control	1
1-18979-4-7A	Rod—Engine control	1
1-18487	Rod End—Self-aligning	2
1-18979-5-5	Rod Assembly—Engine control	2
1-18979-5-5A	Rod—Engine control	2
1-18487	Rod End—Self-aligning	4
6-9480	Spring Installation—Throttle control	1
1-18977	Spring—Throttle control	1
1-20078	Link—Throttle spring	1
6-9490	Spring Installation—Throttle control	1
1-19070	Spring—Throttle control	1
1-20078	Link—Throttle spring	1
6-9494	Spring Installation—Throttle control	1
1-18977	Spring—Throttle control	1
1-20078	Link—Throttle spring	1
6-9502	Spring Installation—Throttle control	1
1-18977	Spring—Throttle control	1
1-20078	Link—Throttle spring	1
BAC1770-132-5	Cable Assembly—3/32—7 x 7 control	1
BAC1770-133-3	Cable Assembly—3/32—7 x 7 control	1
BAC1770-136-2	Cable Assembly—3/32—7 x 7 control	2
BAC1770-228-4	Cable Assembly—3/32—7 x 7 control	2
BAC1770-230-3	Cable Assembly—3/32—7 x 7 control	2
BAC1826-3	Swaged Terminal—Class "B"	16
BAC1770-32-2R	Cable Assembly—3/32—7 x 7 control	2
BAC1770-44-7R	Cable Assembly—3/32—7 x 7 control	2
BAC1770-48-0R	Cable Assembly—3/32—7 x 7 control	2
BAC1770-62-3R	Cable Assembly—3/32—7 x 7 control	2
BAC1826-3	Swaged Terminal—Class "B"	8
BAC1827-23R	Swaged Terminal—Class "D"	8
41-5195	Washer—Serrated	8
41-672-4	Fair-lead—Engine control rod	4
41-2488	Washer—Bearing retainer	8
41-4198	Link—Control cable	16
41-5437-1	Link—Adjusting control cable	16
BAC1603-6	Spacer—No. 10 bolt	4

Stand Installation—Engine Control

(Parts List No. 305)

15-9275	Stand Installation—Engine control	1
15-9275-1	Stand Assembly—Engine control	1

Stand Installation—Engine Control

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-5689	Frame Assembly—Engine control stand	1
	Dash number parts, shown on 65-5689 drawing are represented by dash numbers of 55-5689 and 65-5689.	
65-5689-500	Base Assembly—Engine control stand frame	1
65-5689-508	Plate—Rear engine control stand frame	1
55-5689-33	Plate—Front engine control stand frame	1
55-5689-29	Channel Assembly—Engine control stand frame	1
55-5689-35	Channel Assembly—Engine control stand frame	1
41-8328	Angle Assembly—Cable guard	2
55-5689-38	Channel Assembly—Engine control stand frame	1
55-5689-43	Channel Assembly—Engine control stand frame	1
51-108	Bracket Assembly—Pulley	1
BAC1614-32	Spacer—1/8 rivet	1
55-5689-60	Angle Assembly—Cable cover engine control stand frame	4
55-5689-55	Stop Assembly—Engine control stand frame	1
55-5689-26	Plate—Engine control stand frame	1
55-5689-56	Stop Assembly—Engine control stand frame	1
BAC1249-110S	Plate—Fiber nut	7
55-5689-413	Stop—Engine control stand frame	1
6-7370	Cover—Control stand	1
3-10812	Cover—Control stand	2
3-10813-1	Cover—Plate control stand	1
3-10814	Cover—Plate control stand	1
55-5689-23	Cover—Plate engine control stand frame	1
55-5689-22	Cover—Plate engine control stand frame	1
BAC450-4	Bearing—Ball control	4
21-9531-1	Housing Assembly—Bearing	2
55-5689-5	Bearing—Engine control stand frame	1
55-5689-6	Bearing—Engine control stand frame	2
55-5689-72	Bearing—Engine control stand frame	1
55-5689-414	Bearing—Engine control stand frame	2
65-5689-502	Plate—Engine control stand frame LH	1
65-5689-503	Plate—Engine control stand frame RH	1
41-4293	Shaft—Throttle lock	1
41-9728	Collar—Shaft support	1
41-9728-1	Collar—Shaft support	1
51-474	Spring—Compression	1
51-329	Spring—Compression	1

(Parts List No. 306)

14-3002	Control Installation—Modified A.F.C.E.	1
14-3002-1	Control Assembly—Modified A.F.C.E.	1
1-23545	Control Box Modified A.F.C.E. (government furnished)	1
6-10780	Plate—Cover control stand	1
3-11146-7	Pulley Assembly—Propeller pitch handle	1
3-11146-2	Pulley Assembly—Propeller pitch handle	1
3-11146-3	Pulley—Propeller pitch handle	1
41-7846-1	Knob Assembly—Propeller pitch	1
41-7846-5	Knob—Black propeller pitch	1
41-7846-6	Armature—Propeller pitch knob	1
BAC1807-120-2L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-118-5L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Terminal—Swaged class "D"	2
BAC1828-34	Terminal—Dead end cable	2
3-11146-8	Pulley Assembly—Propeller pitch handle	1
3-11146-4	Pulley Assembly—Propeller pitch handle	1
3-11146-3	Pulley—Propeller pitch handle	1
41-7846-4	Knob Assembly—Propeller pitch	1
41-7846-5	Knob—Propeller pitch	1
41-7846-9	Armature—Propeller pitch knob	1
BAC1807-120-7L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-119-5L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Terminal—Swaged class "D"	2

AVIALOGS.COM

CONTROLS INSTALLATION—ENGINE

Stand Installation—Engine Control

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1828-34	Terminal—Dead end cable	2
3-11147-7	Pulley Assembly—Propeller pitch handle	1
3-11147-2	Pulley Assembly—Propeller pitch handle	1
3-11146-3	Pulley—Propeller pitch handle	1
41-7846-2	Knob Assembly—Propeller pitch	1
41-7846-5	Knob—Black propeller pitch	1
41-7846-7	Armature—Propeller pitch knob	1
BAC1807-109-0L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-131-4L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Terminal—Swaged class "D"	2
BAC1828-34	Terminal—Dead end cable	2
3-11147-8	Pulley Assembly—Propeller pitch handle	1
3-11147-4	Pulley Assembly—Propeller pitch handle	1
3-11146-3	Pulley—Propeller pitch handle	1
41-7846-3	Knob Assembly—Propeller pitch	1
41-7846-5	Knob—Black propeller pitch	1
41-7846-8	Armature—Propeller pitch knob	1
BAC1807-110-0L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-132-1L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Terminal—Swaged class "D"	2
BAC1828-34	Terminal—Dead end cable	2
41-5501	Plate—Warning	1
41-8700-3	Washer—Friction	8
41-8700-4	Washer—Friction	6
41-4284	Spacer—Throttle lock	1
41-4284-1	Spacer—Throttle lock	2
	(Parts List No. 307)	
41-9732-14	Spacer—Engine control	1
41-9732-16	Spacer—Engine control	3
41-9732-30	Spacer—Engine control	1
51-495	Spacer—Engine control	1
41-8126	Lever Assembly—Throttle lock	1
41-4292-2	Lever Assembly—Control lock	1
41-7808-2	Knob Assembly—Lock lever	1
41-7808-4	Arm—Lock lever	1
41-7808-7	Knob—Lock lever	1
41-2399	Spring—Compression	1
41-7917	Tube—Lock lever	1
41-7916	Plug—Lock lever	2
41-7940	Plug—Lock lever	1
41-4556	Armature Assembly—Throttle lock	1
41-4298	Stud—Throttle lock	1
41-7919-1	Tube—Lock lever	1
41-8126-1	Pin—Throttle lock	1
41-7941	Spacer—Special	1
BAC1001-29	Key—1/8 square	2
41-7953	Handle Assembly—Engine control lock	1
41-4292	Lever Assembly—Engine control lock	1
41-7808	Knob Assembly—Lock lever	1
41-7808-4	Arm—Lock lever	1
41-7808-7	Knob—Lock lever	1
41-7917	Tube—Lock lever	1
41-2399	Spring—Compression	1
41-9616	Plug—Lock lever	2
41-7940	Plug—Lock lever	1
41-7908	Cam Assembly—Engine control lock	1
41-7908-3	Spacer—Engine control lock cam	1
41-7908-4	Spacer—Engine control lock cam	1
41-7906-3	Cam—Engine control lock	1
41-7919	Tube—Lock lever	1
41-7941	Spacer—Special	1
41-8067	Spacer—Lever	2
41-4286	Shaft—Throttle support	1
21-9574	Washer—Special	4
1-16285	Guide—Shaft support	2
1-16285-1	Guide—Shaft support	1
41-9735	Cam Assembly—Engine control lock	1
41-9706-1	Cam—Engine control lock	1
41-9730	Cam—Throttle lock	1
41-9730-1	Cam—Throttle lock	1
41-9730-2	Cam—Throttle lock	1

Stand Installation—Engine Control

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-9730-3	Cam—Throttle lock	1
41-9731	Cam—Throttle lock	1
41-9731-1	Cam—Throttle lock	1
41-9731-2	Cam—Throttle lock	1
41-9731-3	Cam—Throttle lock	1
	(Parts List No. 308)	
3-15520-2	Rod Assembly—3/8 control	4
3-15520-102	Tube Assembly—Weld 3/8 control	4
1-19813-2	Rod End—Female	8
1-18487	Rod End—Self-aligning	8
6-11058-30	Rod Assembly—Engine control	2
6-11058-28	Tube Assembly—Weld engine control	2
1-19813-3	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
41-7654-2	Drum Assembly—Elevator tab control	1
3-11894	Drum—Elevator tab control	1
BAC1807-512-0L	Cable Assembly—Elevator tab control	1
BAC1827-23L	Terminal—Tab control cable	1
BAC1828-34	Terminal—Tab control cable	1
BAC1807-438-4L	Cable Assembly—Elevator tab control	1
BAC1827-23L	Terminal—Tab control cable	1
BAC1828-34	Terminal—Tab control cable	1
1-18089	Rod Assembly—Engine control	2
1-18089-1	Tube Assembly—Weld engine control rod	2
1-19813-3	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
6-7595	Lever Assembly—Throttle control LH	1
6-7595-1	Lever Assembly—Throttle control RH	1
6-7595-3	Bushing—Bronze throttle control lever	2
6-7595-4	Lever—Throttle control	1L
6-7595-2	Lever—Throttle control	1R
6-7593	Lever Assembly—Throttle control	1
6-7593-1	Lever Assembly—Throttle control	1
6-7593-2	Lever—Throttle control	1L
6-7593-3	Lever—Throttle control	1R
6-7593-4	Bushing—Throttle control lever	2
51-196	Shaft—Engine control stand	1
51-195-38	Spacer—1/4 shaft	1
51-195-40	Spacer—1/4 shaft	2
51-195-48	Spacer—1/4 shaft	4
51-195-93	Spacer—1/4 shaft	1
51-195-148	Spacer—1/4 shaft	1
41-8129-3	Support Assembly—Lock quadrant	1
41-6818	Quadrant—Propeller pitch lock	1
BAC1603-19	Spacer—No. 10 bolt	2
51-200	Shaft—Engine control stand	1
51-79	Shaft—Engine control stand	1
51-249	Plug Assembly—Engine control stand	2
51-249-1	Plug—Engine control stand	2
	(Parts List No. 309)	
3-11810	Lever Assembly—Engine control LH	1
3-11810-1	Lever Assembly—Engine control RH	1
3-11810-2	Handle Assembly—Engine control lever LH	1
3-11810-5	Handle Assembly—Engine control lever RH	1
3-11810-3	Handle—Engine control lever	2
3-11810-4	Knob—Engine control lever	2
41-9608	Lever—Engine controls	2
41-2488	Washer—Bearing retainer	2
3-11811	Lever Assembly—Engine controls LH	1
3-11811-2	Handle Assembly—Engine control lever	1
3-11811-4	Knob—Engine control lever	1
3-11811-5	Handle—Engine control lever	1
3-11811-1	Lever Assembly—Engine controls RH	1
3-11811-3	Handle Assembly—Engine control lever	1
3-11811-4	Knob—Engine control lever	1
3-11811-6	Handle—Engine control lever	1
41-9608-1	Lever—Engine control	2
3-11812	Lever Assembly—Engine controls LH	1

AVIALOGS.COM

CONTROLS INSTALLATION—ENGINE

Stand Installation—Engine Control

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-11812-2	Handle Assembly—Engine control lever	1
3-11812-4	Knob—Engine control lever	1
3-11812-5	Handle—Engine control lever	1
3-11812-1	Lever Assembly—Engine controls RH	1
3-11812-3	Handle Assembly—Engine control lever	1
3-11812-4	Knob—Engine control lever	1
3-11812-6	Handle—Engine control lever	1
41-9608	Lever—Engine controls	2
3-11813	Lever Assembly—Engine controls LH	1
3-11813-2	Handle Assembly—Engine controls lever	1
3-11813-4	Knob—Engine controls lever	1
3-11813-5	Handle—Engine controls lever	1
3-11813-1	Lever Assembly—Engine controls RH	1
3-11813-3	Handle Assembly—Engine controls lever	1
3-11813-4	Knob—Engine controls lever	1
3-11813-6	Handle—Engine controls lever	1
41-9608-1	Lever—Engine control	2
6-11058-33	Rod Assembly—Engine control	2
6-11058-31	Tube Assembly—Weld engine control rod	1
6-11058-32	Tube—Engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
51-196	Shaft—Engine control stand	1
51-195-174	Spacer—¼ shaft	1
51-195-55	Spacer—¼ shaft	2
51-195-64	Spacer—¼ shaft	2
51-195-77	Spacer—¼ shaft	2
41-7953-1	Handle Assembly—Engine control lock	1
41-7908-1	Cam Assembly—Engine control lock	1
	(Parts List No. 310)	
41-7908-3	Spacer—Engine control lock cam	2
41-7908-4	Spacer—Engine control lock cam	2
41-7906-2	Cam—Engine control lock	1
41-7906-3	Cam—Engine control lock	1
41-4292-1	Lever Assembly—Engine control lock	1
41-7808-1	Knob Assembly—Lock lever	1
41-7808-5	Arm—Lock lever knob	1
41-7808-7	Knob—Lock lever	1
41-2399	Spring—Compression	1
41-7917	Tube—Lock lever	1
41-7916	Plug—Lock lever	2
41-7940	Plug—Lock lever	1
41-7919	Tube—Lock lever	1
41-7941	Spacer—Special	1
41-8067	Spacer—Lever	2
41-9736	Cam Assembly—Engine control lock LH	1
41-7906	Cam—Engine control lock	1
41-9736-1	Cam Assembly—Engine control lock RH	1
41-7906-1	Cam—Engine control lock	1
41-9831-43	Spacer—Engine control lever	2
41-9831-46	Spacer—Engine control lever	2
41-9831-53	Spacer—Engine control lever	2
41-9831-55	Spacer—Engine control lever	2
41-9732-4	Spacer—Engine control lever	2
1-24238-1	Shim—.032 brass washer	2
1-24234-2	Stud—Engine control	2
3-11002-6	Pulley Assembly—Engine control	8
3-11002-7	Pulley—Engine control	8
51-197-10	Spacer—½ shaft	1
51-197-18	Spacer—½ shaft	2
51-197-20	Spacer—½ shaft	3
51-197-60	Spacer—½ shaft	2
51-197-109	Spacer—½ shaft	1
51-197-175	Spacer—½ shaft	1
51-197-189	Spacer—½ shaft	1
51-197-255	Spacer—½ shaft	1
1-24234-2	Stud—Engine control	1
3-11624-8	Pulley Assembly—Engine controls LH	1
3-11624-2	Pulley Assembly—Engine controls	1
3-11624-4	Pulley—Engine controls	1
21-2364-71-48	Washer—.064 aluminum alloy	1

Stand Installation—Engine Control

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1807-97-1L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-106-2L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	2
BAC1828-34	Swaged Terminal—Dead end cable	2
3-11624-9	Pulley Assembly—Engine controls RH	1
3-11624-3	Pulley Assembly—Engine controls	1
3-11624-5	Pulley—Engine controls	1
	(Parts List No. 311)	
21-2364-71-48	Washer—.064 aluminum alloy	1
BAC1807-106-1L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-96-0L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	2
BAC1828-34	Swaged Terminal—Dead end cable	2
3-11130-11	Pulley Assembly—Engine controls LH	1
3-11130-4	Pulley Assembly—Engine controls	1
3-11130-6	Pulley—Engine controls	1
21-2364-71-48	Washer—.064 aluminum alloy	1
BAC1807-117-3L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-128-3L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	2
BAC1828-34	Terminal—Dead end cable	2
3-11130-12	Pulley Assembly—Engine controls	1
3-11130-7	Pulley Assembly—Engine controls	1
3-11130-8	Pulley—Engine controls	1
21-2364-71-48	Washer—.064 aluminum alloy	1
BAC1807-117-6L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-127-3L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	2
BAC1828-34	Terminal—Dead end cable	2
51-197-42	Spacer—½ shaft	2
51-197-284	Spacer—½ shaft	1
51-197-12	Spacer—½ shaft	2
21-8038-18	Screw—No. 10-32 flathead	4
41-2488	Washer—Bearing retainer	2
41-8074	Shaft—Elevator tab control	1
3-11002	Pulley Assembly—Engine control	2
3-11002-2	Pulley Assembly—Engine control	2
3-11002-1	Pulley—Engine control	2
3-11002-3	Pulley—Engine control	2
46-4913	Wheel Assembly—Elevator tab control	2
46-4913-403	Wheel Assembly—Elevator tab control	2
46-4913-400	Wheel—Elevator tab control	2
46-4913-401	Rim—Elevator tab control wheel	2
21-9530	Hub—Tab control wheel	2
BAC1001-6	Key—⅛ square	1
BAC1001-12	Key—⅛ square	1
51-202	Tube—Fiber guard	1
21-9533	Gear—Tab control	1
51-197-8	Spacer—½ shaft	2
51-197-6	Spacer—½ shaft	2
51-197-16	Spacer—½ shaft	1
51-197-40	Spacer—½ shaft	1
51-201	Spacer—½ shaft	1
41-7915-3	Bolt Assembly—Engine control	1
41-7915-1	Shank—Engine control bolt	1
	(Parts List No. 312)	
41-7915-2	Pin—Engine control bolt	1
41-9822	Screw—Special	1
3-11133-18	Pulley Assembly—Engine controls LH	1
3-11133-6	Pulley Assembly—Engine controls	1
3-11133-23	Pulley—Engine controls	1
21-2364-71-48	Washer—.064 aluminum alloy	1
BAC1807-101-7L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-123-1L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	2
BAC1828-34	Terminal—Dead end cable	2
3-11133-19	Pulley Assembly—Engine control RH	1
3-11133-10	Pulley Assembly—Engine controls	1
3-11133-24	Pulley—Engine controls	1

AVIALOGS.COM

CONTROLS INSTALLATION—ENGINE

Stand Installation—Engine Control

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-2364-71-48	Washer—.064 aluminum alloy	1
BAC1807-107-5L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-99-0L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	2
BAC1828-34	Terminal—Dead end cable	2
41-2488	Washer—Bearing retainer	2
3-11002-4	Pulley Assembly—Engine controls	3
3-11002-8	Pulley Assembly—Engine controls	3
3-11002-5	Pulley—Engine controls	3
3-11002-9	Pulley—Engine controls	3
51-197-5	Spacer—1/2 shaft	2
51-197-47	Spacer—1/2 shaft	2
51-197-152	Spacer—1/2 shaft	1
1-24235-1	Washer—1/16 brass	2
1-24234-1	Stud—Engine control	1
3-11138-8	Pulley Assembly—Engine controls	1
3-11138-2	Pulley Assembly—Engine controls	1
3-11138-4	Pulley—Engine controls	1
21-2364-71-48	Washer—.064 aluminum alloy	1
BAC1807-114-4L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-122-6L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminals—Class "D"	2
BAC1828-34	Terminals—Dead end cable	2
3-11138-9	Pulley Assembly—Engine controls	1
3-11138-3	Pulley Assembly—Engine controls	1
3-11138-5	Pulley Assembly—Engine controls	1
21-2364-71-48	Washer—.064 aluminum alloy	1
BAC1807-107-3L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-114-5L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminals—Class "D"	2
BAC1828-34	Terminals—Dead end cable	2
3-11133-20	Pulley Assembly—Engine controls RH	1
3-11133-8	Pulley Assembly—Engine controls	1
3-11133-26	Pulley—Engine controls	1

(Parts List No. 313)

21-2364-71-48	Washer—.064 aluminum alloy	1
BAC1807-91-1L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-98-7L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	2
BAC1828-34	Terminal—Dead end cable	2
3-11133-21	Pulley Assembly—Engine control LH	1
3-11133-12	Pulley Assembly—Engine control	1
3-11133-27	Pulley—Engine control	1
21-2364-71-48	Washer—.064 aluminum alloy	1
BAC1807-94-1L	Cable Assembly—3/32—7 x 7 control	1
BAC1807-116-3L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	2
BAC1828-34	Terminal—Dead end cable	2
41-2488	Washer—Bearing retainer	4
51-197-10	Spacer—1/2 shaft	2
51-197-22	Spacer—1/2 shaft	4
51-197-88	Spacer—1/2 shaft	1
3-11003-6	Pulley Assembly—Engine control	1
3-11003-7	Pulley—Engine control	1
51-199-12	Spacer—3/8 shaft	1
3-11003-8	Pulley Assembly—Engine control	1
3-11003-9	Pulley—Engine control	1
51-199-8	Spacer—3/8 shaft	2
51-199-76	Spacer—3/8 shaft	1
3-11003-2	Pulley Assembly—Engine control	1
3-11003-3	Pulley—Engine control	1
3-11003-6	Pulley Assembly—Engine control	1
3-11003-7	Pulley—Engine control	1
BAC1603-88	Spacer—No. 10 bolt	2
BAC1603-48	Spacer—No. 10 bolt	1
BAC1603-36	Spacer—No. 10 bolt	3
BAC1603-56	Spacer—No. 10 bolt	2
21-8487-28	Spacer—No. 10 flathead screw	2
51-199-28	Spacer—3/8 shaft	1
3-11003-8	Pulley Assembly—Engine control	1
3-11003-9	Pulley—Engine control	1

Stand Installation—Engine Control

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
51-199-8	Spacer—3/8 shaft	1
3-11003-6	Pulley Assembly—Engine control	2
3-11003-7	Pulley—Engine control	2
51-199-44	Spacer—3/8 shaft	1
3-11003-2	Pulley Assembly—Engine control	1
3-11003-3	Pulley—Engine control	1
51-199-10	Spacer—3/8 shaft	1
51-199-8	Spacer—3/8 shaft	1

(Parts List No. 314)

BAC1603-80	Spacer—No. 10 bolt	2
BAC1603-28	Spacer—No. 10 bolt	2
21-8457-52	Spacer—No. 10 flathead screw	2
41-8511	Spacer—No. 10-32 screw	1
21-8487-32	Spacer—No. 10 flathead screw	1
BAC1603-62	Spacer—No. 10 bolt	2
3-11003-8	Pulley Assembly—Engine control	2
3-11003-9	Pulley—Engine control	2
51-199-128	Spacer—3/8 shaft	1
51-199-6	Spacer—3/8 shaft	1
51-199-28	Spacer—3/8 shaft	1
3-11003-8	Pulley Assembly—Engine control	2
3-11003-9	Pulley—Engine control	2
3-11003-6	Pulley Assembly—Engine control	2
3-11003-7	Pulley—Engine control	2
51-199-28	Spacer—3/8 shaft	1
51-199-34	Spacer—3/8 shaft	1
51-199-28	Spacer—3/8 shaft	2
3-11003-4	Pulley Assembly—Engine control	2
3-11003-5	Pulley—Engine control	2
3-11003	Pulley Assembly—Engine control	2
3-11003-1	Pulley—Engine control	2
51-199-34	Spacer—3/8 shaft	1
BAC1603-102	Spacer—No. 10 bolt	1
41-5603-76	Spacer—No. 10 flathead screw	1
BAC1603-28	Spacer—No. 10 bolt	2
21-8487-50	Spacer—No. 10 flathead screw	3
21-8487-55	Spacer—No. 10 flathead screw	4
41-8511-1	Spacer—No. 10-32 screw	1
51-198	Spacer—Engine control stand	1
BAC1603-178	Spacer—No. 10 bolt	1
21-8487-26	Spacer—No. 10 flathead screw	2
BAC1603-42	Spacer—No. 10 bolt	2
BAC1603-6	Spacer—No. 10 bolt	1
55-6057	Switch Installation—Throttle warning LH	1
55-6057-1	Switch Installation—Throttle warning RH	1
3-12571	Switch Assembly—Throttle warning LH	1
3-12571-1	Switch Assembly—Throttle warning RH	1
3-12571-2	Switch—Throttle warning (micro blue top regulator)	4
3-12571-3	Switch—Throttle warning (micro green top regulator)	4
43-11518	Shield Assembly—Warning switch LH	1
43-11518-1	Shield Assembly—Warning switch RH	1
43-11518-400	Shield Assembly—Warning switch	1
43-11518-401	Shield Assembly—Warning switch	1

(Parts List No. 315)

BAC1247-8S	Angle—Nut plate	14
43-11518-404	Cover—Warning switch shield LH	1
43-11518-405	Cover—Warning switch shield RH	1
36A4486-832	Screw—Round head necked	14
1-16653	Bracket Assembly—Throttle warning LH	2
1-16653-1	Bracket Assembly—Throttle warning RH	2
1-16654	Bracket—Throttle warning	2
1-16654-1	Bracket—Throttle warning	2
41-9179-2	Spring Assembly—Warning switch	4
41-9179-1	Spring—Warning switch	4
BAC1614-6	Spacer—1/8 rivet	4
41-9254	Panel Assembly—Connector	2

AVIALOGS.COM

CONTROLS INSTALLATION—ENGINE

Stand Installation—Engine Control

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-9254-1	Panel—Micarta connector	2
1-16546	Tag Installation—Electric wire identification (ND)	14
41-9255	Insulator—Connector panel	2
BAC821-18-10	Terminal—Electrical solderless	8
BAC1603-17	Spacer—No. 10 bolt	8
3-11517	Rod Assembly—Throttle warning switch	2
3-11517-1	Terminal—Throttle warning switch	2
3-11517-2	Tube—Throttle warning switch	2
3-11517-3	Terminal—Throttle warning switch	2
BAC364-6S	Bushing—9/16 outside dimension bearing	4
41-1464-32-13	Washer—.025 aluminum alloy	2
41-8822	Cam Assembly—Throttle warning switch	4
1-21024	Cam Assembly—Throttle warning switch	4
41-8821-2	Cam—Throttle warning switch	4
41-8821-1	Cam—Throttle warning switch	4
41-8920	Quadrant—Warning switch cam	4
41-9869	Link—Throttle warning switch	2
BAC364-6S	Bushing—9/16 outside dimension bearing	2
41-9177-1	Crank—Throttle warning switch	4
55-6057-6	Tube—Throttle warning switch	2
55-6057-400	Shaft—Throttle warning switch	2
55-6057-401	Shaft—Throttle warning switch	2
55-6057-402	Shaft—Throttle warning switch	4
41-9012-1	Washer—No. 8 flathead screw	2
41-1464-40-25	Washer—.025 aluminum alloy	2
59-1791-401	Cover Assembly—Control stand	1
59-1791-403	Plate—Control stand	1
21-9531-1	Housing Assembly—Bearing	1
41-9774	Bearing—Control	1
41-9774-2	Bearing—Control	1
21-5943	Shaft Assembly—Tab control	1
21-5943-1	Gear—Spiral tab control	1
21-5932	Shaft—Tab control	1
	(Parts List No. 316)	
41-9514	Pointer—Tab control	1
21-6277	Plate—Elevator tab control	1
3-19013	Plate Assembly—Control stand cover	1
3-16927	Decalcomania—Miscellaneous	1
9-4592-11	Decalcomania	1
3-16948	Stop Assembly—Supercharger control	1
3-16948-1	Angle Assembly—Supercharger control	1
9-4642-30	Decalcomania—Miscellaneous	1
3-16948-2	Stop Assembly—Supercharger control	4
AN8005	Stop	4
BAC1603-37	Spacer—No. 10 bolt	2
41-6818	Quadrant—Propeller switch watch	1
21-8487-26	Spacer—No. 10 flathead screw	2
3-11753	Plate—Control stand cover	1
41-7964	Sector—Lock lever	1
43-11471	Plate—Control stand cover	1
43-11472	Plate—Control stand cover	1
41-8510-1	Guard—Pulley	1
1-22959-2	Washer—Retaining	2
1-24236-1	Washer—.040 aluminum alloy alc	10
1-24287-1	Washer—Cable guard support	2
1-22928-5	Washer	2
1-24237-2	Washer—Laminated phenolic	2
1-24239-3	Washer—Friction	12
1-24239-1	Washer—Friction	3
1-24239-2	Washer—Friction	3
3-13001	Rod Assembly—Control	2
3-13001-1	Tube Assembly—Control rod	2
1-19813-3	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
3-15199	Turn Control Installation—Modified A.F.C.E. (government furnished)	1
1-24192	Turn Control Assembly—Modified A.F.C.E. (government furnished)	1

(Automatic Flight Control Equipment, Minneapolis Honeywell Regulator Co.)

Stand Installation—Engine Control

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-11003-4	Pulley Assembly—Engine control	2
3-11003-5	Pulley—Engine control	2
51-199-104	Spacer—3/8 shaft	2
51-199-96	Spacer—3/8 shaft	2
3-11003-6	Pulley Assembly—Engine control	2
3-11003-7	Pulley—Engine control	2
51-199-8	Spacer—3/8 shaft	2
3-11003-4	Pulley Assembly—Engine control	2
3-11003-5	Pulley—Engine control	2
51-199-40	Spacer—3/8 shaft	2
3-11003	Pulley Assembly—Engine control	2
3-11003-1	Pulley—Engine control	2
	(Parts List No. 317)	
3-11003-4	Pulley Assembly—Engine control	2
3-11003-5	Pulley—Engine control	2
51-199-18	Spacer—3/8 shaft	2
3-11003-6	Pulley Assembly—Engine control	2
3-11003-7	Pulley—Engine control	2
51-199-64	Spacer—3/8 shaft	2
41-2488	Washer—Bearing retainer	2
1-24236-1	Washer—.040 aluminum alloy alc	2

Control Installation—Mixture

(Parts List No. 318)

15-7036	Control Installation—Mixture	1
1-18098-9-6	Rod Assembly—Engine control	1
1-18098-9-6A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-18098-10-0	Rod Assembly—Engine control	1
1-18098-10-0A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-18098-12-6	Rod Assembly—Engine control	2
1-18098-12-6A	Tube Assembly—Weld engine control rod	2
1-19813-3	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
1-18098-14-8	Rod Assembly—Engine control	1
1-18098-14-8A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-18098-15-0	Rod Assembly—Engine control	1
1-18098-15-0A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-18098-17-9	Rod Assembly—Engine control	2
1-18098-17-9A	Tube Assembly—Weld engine control rod	2
1-19813-3	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
1-18098-29-1	Rod Assembly—Engine control	1
1-18098-29-1A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-18098-31-5	Rod Assembly—Engine control	1
1-18098-31-5A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-19052-7-3	Rod Assembly—Control 3/8	1
1-19052-7-3A	Tube Assembly—Weld 3/8 control rod	1
1-19813-2	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-19052-7-5	Rod Assembly—Control 3/8	2
1-19052-7-5A	Tube Assembly—Weld control 3/8 rod	2
1-19813-2	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
1-19052-7-8	Rod Assembly—Control 3/8	2
1-19052-7-8A	Tube Assembly—Weld 3/8 control rod	2

AVIALOGS.COM

CONTROLS INSTALLATION—ENGINE

Control Installation—Mixture

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 319)	
1-19813-2	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
1-19052-8-3	Rod Assembly—Control ⅜	1
1-19052-8-3A	Tube Assembly—Weld ⅜ control rod	1
1-19813-2	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
BAC1770-134-2	Cable Assembly—3/32—7 x 7 control	2
BAC1770-139-4	Cable Assembly—3/32—7 x 7 control	2
BAC1770-225-5	Cable Assembly—3/32—7 x 7 control	1
BAC1770-231-3	Cable Assembly—3/32—7 x 7 control	1
BAC1770-234-0	Cable Assembly—3/32—7 x 7 control	1
BAC1770-237-6	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	16
BAC1780-29-4R	Cable Assembly—3/32—7 x 7 control	2
BAC1780-43-3R	Cable Assembly—3/32—7 x 7 control	2
BAC1780-44-3R	Cable Assembly—3/32—7 x 7 control	2
BAC1780-60-1R	Cable Assembly—3/32—7 x 7 control	2
BAC1826-3	Swaged Terminal—Class "B"	8
BAC1827-23R	Swaged Terminal—Class "D"	8
41-5195	Washer—Serrated	8
41-672-4	Fair-lead—Engine control	4
41-2488	Washer—Bearing retainer	8
21-3147-1	Washer—.019 (Corrosion Resistant)	24
41-4198	Link—Control cable	16
41-5437-1	Link—Adjusting control cable	16
41-9178	Fairlead—Supercharger and mixture control	1
BAC1603-6	Spacer—No. 10 bolt	4

Control Installation—Supercharger

	(Parts List No. 320)	
15-7037	Control Installation—Supercharger	1
6-8055	Regulator Installation—Inboard nacelle supercharger	2
6-8055-2	Regulator Assembly—Supercharger	2
6-8055-1	Supercharger Regulator—Eclipse type A-7 (drawing F71523) (government furnished)	2
6-8055-3	Bushing—Inboard nacelle supercharger regulator	2
9-3040	Regulator Installation—Supercharger control LH	1
9-3040-1	Regulator Installation—Supercharger control RH	1
9-3040-3	Regulator Assembly—Supercharger control	2
9-3040-2	Regulator—Supercharger Eclipse type A-7 (drawing F71523) (government furnished)	2
41-9256	Plate—Supercharger regulator	2
41-445-0-16	Spacer—No. 10 bolt	2
41-445-0-24	Spacer—No. 10 bolt	2
41-445-0-20	Spacer—No. 10 bolt	2
9-3583	Unit Installation—Supercharger control LH	1
9-3583-1	Unit Installation—Supercharger control RH	1
3-13506-2	Cartridge Assembly—Supercharger control	2
1-18127	Screw—.25 pin end	4
1-18241	Collar—Spring cylinder rod	2
1-18282	Tube—Spring cylinder rod	2
1-18283	Bushing—Spring cylinder rod	2
1-18283-1	Bushing—Spring cylinder rod	2
1-18795	Spring—Supercharger chart	2
1-18281-2	Rod—Spring cylinder	2
21-2363-68-21	Washer—.063 steel	4
1-18487	Rod End—Supercharger control	2
BAC1603-12	Spacer—No. 10 bolt	1L
41-2488	Washer—Bearing retainer	2
BAC1603-8	Spacer—No. 10 bolt	2
1-18979-8-2	Rod Assembly—Engine control	1
1-18487	Rod End—Self-aligning	2
1-18979-5-7	Rod Assembly—Engine control	1
1-18487	Rod End—Self-aligning	2
1-18098-14-9	Rod Assembly—Engine control	1
1-18098-14-9A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2

Control Installation—Supercharger

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18487	Rod End—Self-aligning	2
1-18098-17-7	Rod Assembly—Engine control	1
1-18098-17-7A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-18947-19-7	Rod Assembly—Engine control	1
1-18947-19-7A	Tube Assembly—Engine control	1
1-19813-3	Rod End—Female	2
	(Parts List No. 321)	
1-18487	Rod End—Self-aligning	1
1-19033	Clevis—Rod end Male thread	1
1-18947-20-0	Rod Assembly—Engine control	1
1-18947-20-0A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	1
1-19033	Clevis—Rod end Male thread	1
1-18947-14-7	Rod Assembly—Engine control	1
1-18947-14-7A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	1
1-19033	Clevis—Rod end—Male thread	1
1-18947-11-5	Rod Assembly—Engine control	1
1-18947-11-5A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	1
1-19033	Clevis—Rod end—Male thread	1
1-18941-12-6	Rod Assembly—Waste gate	1
1-18941-12-6A	Tube Assembly—Weld waste gate	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	1
1-18936	Rod End—Waste gate	1
1-18941-9-5	Rod Assembly—Waste gate	1
1-18941-9-5A	Tube Assembly—Weld waste gate	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	1
1-18936	Rod End—Waste gate	1
1-18941-7-5	Rod Assembly—Waste gate	1
1-18941-7-5A	Tube Assembly—Weld waste gate	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	1
1-18936	Rod End—Waste gate	1
1-18941-13-1	Rod Assembly—Waste gate	1
1-18941-13-1A	Tube Assembly—Weld waste gate	1
1-19813-3	Rod End—Female	2
1-18487	Rod End—Self-aligning	1
1-18936	Rod End—Waste gate	1
1-18984	Bushing—Rod end	4
41-1066-32-13	Washer—.031 corrosive resistant steel	4
9-3684	Cartridge Installation—Supercharger LH	1
9-3684-1	Cartridge Installation—Supercharger RH	1
9-3684-2	Cartridge Assembly—Supercharger LH	1
9-3684-3	Cartridge Assembly—Supercharger RH	1
1-18117	Fitting—Tube support	2
	(Parts List No. 322)	
1-18127	Screw—.25 pin end	4
1-18241	Collar—Spring cylinder rod	2
1-18282	Tube—Spring cylinder rod	2
1-18283	Bushing—Spring cylinder rod	2
1-18283-2	Bushing—Spring cylinder rod	2
1-18795	Spring—Supercharger chart	2
1-18971	Rod—Spring cylinder	2
21-2363-68-20	Washer—.063 steel	4
1-18487	Rod End—Self-aligning	2
1-18098-9-0A	Tube Assembly—Weld (used on 9-3684-2)	1
1-19813-3	Rod End—Female	2
1-18098-9-5A	Tube Assembly—Weld (used on 9-3684-3)	1
1-19813-3	Rod End—Female	2
41-2488	Washer—Bearing retainer	2

AVIALOGS.COM

CONTROLS INSTALLATION—ENGINE

Control Installation—Supercharger

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1770-106-0	Cable Assembly—3/32—7 x 7 control	1
BAC1770-107-0	Cable Assembly—3/32—7 x 7 control	1
BAC1770-116-5	Cable Assembly—3/32—7 x 7 control	1
BAC1770-118-4	Cable Assembly—3/32—7 x 7 control	1
BAC1770-187-6	Cable Assembly—3/32—7 x 7 control	1
BAC1770-188-0	Cable Assembly—3/32—7 x 7 control	1
BAC1770-195-5	Cable Assembly—3/32—7 x 7 control	1
BAC1770-197-6	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	16
BAC1780-35-4R	Cable Assembly—3/32—7 x 7 control	1
BAC1780-37-3R	Cable Assembly—3/32—7 x 7 control	1
BAC1780-42-7R	Cable Assembly—3/32—7 x 7 control	2
BAC1780-62-5R	Cable Assembly—3/32—7 x 7 control	1
BAC1780-64-3R	Cable Assembly—3/32—7 x 7 control	1
BAC1780-70-1R	Cable Assembly—3/32—7 x 7 control	2
BAC1826-3	Swaged Terminal—Class "B"	8
BAC1827-23R	Swaged Terminal—Class "D"	8
41-5195	Washer—Serrated	4
41-7085-64-25	Washer—.078 steel	4
41-2488	Washer—Bearing retainer	8
41-4198	Link—Control cable	16
41-5437-1	Link—Adjustment control cable	16
41-9324	Lever—Engine control	2
41-9324-1	Lever—Engine control	2
41-9178	Fair-lead—Supercharger and mixture control	1
1-16752-34	Bushing—3/16 bolt	4

Control Installation—Intercooler Temperature

(Parts List No. 323)

15-7038	Control Installation—Intercooler temperature	1
55-6070	Stand. Installation—Carburetor air (PL 325-326).	1
3-13502	Spring Installation—Intercooler	1
1-18106	Spring—Intercooler shutter	1
3-13594	Spring Installation—Inboard intercooler control LH	1
3-13594-1	Spring Installation—Inboard intercooler control RH	1
1-17568	Spring—Intercooler shutter	2
6-9228	Spring Installation—Intercooler	1
1-18208	Spring—Intercooler shutter	1
1-18098-12-0	Rod Assembly—Engine control	1
1-18098-12-0A	Tube Assembly—Weld engine control rod	1
1-19813-3	Rod End—Female	2
37A6545	Rod End—Self-aligning	2
1-19052-8-0	Rod Assembly—Control 3/8	2
1-19052-8-0A	Tube Assembly—Weld 3/8 control rod	2
1-19813-2	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
1-19052-8-2	Rod Assembly—Control 3/8	1
1-19052-8-2A	Tube Assembly—Weld 3/8 control rod	1
1-19813-2	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
1-18098-17-0	Rod Assembly—Engine control	2
1-18098-17-0A	Tube Assembly—Weld	2
1-19813-3	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
BAC1770-194-5	Cable Assembly—3/32—7 x 7 control	1
BAC1770-195-0	Cable Assembly—3/32—7 x 7 control	1
BAC1770-261-0	Cable Assembly—3/32—7 x 7 control	2
BAC1770-59-7	Cable Assembly—3/32—7 x 7 control	1
BAC1770-60-6	Cable Assembly—3/32—7 x 7 cnotrol	1
BAC1770-124-7	Cable Assembly—3/32—7 x 7 control	1
BAC1770-125-6	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal Class "B"	16
BAC1780-34-5R	Cable Assembly—3/32—7 x 7 control	1
BAC1780-39-7R	Cable Assembly—3/32—7 x 7 control	1
BAC1780-40-0R	Cable Assembly—3/32—7 x 7 control	1
BAC1780-40-2R	Cable Assembly—3/32—7 x 7 control	1

Control Installation—Intercooler Temperature

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1780-68-5R	Cable Assembly—3/32—7 x 7 control	2
BAC1780-74-5R	Cable Assembly—3/32—7 x 7 control	2
BAC1826-3	Swaged Terminal—Class "B"	8
BAC1827-23R	Swaged Terminal—Class "C"	8
41-5437-1	Link—Adjusting control cable	16
41-5195	Washer—Serrated	4

(Parts List No. 324)

41-2488	Washer—Bearing retainer	6
21-3147-1	Washer—.019 corrosive resistant steel	6

Stand Installation—Carburetor Air

(Parts List No. 325)

55-6070	Stand Installation—Carburetor air	1
55-6070-400	Stand Assembly—Carburetor air	1
55-6070-2	Frame Assembly—Stand intercooler temperature	1
15-6146	Track Assembly—Carburetor air stand	1
15-6146-1	Track Assembly—Carburetor air stand	1
3-11957	Rack—Carburetor air control	4
41-5495-36	Washer—No. 10 square	4
BAC1603-34	Spacer—No. 10 bolt	14
BAC1603-31	Spacer—No. 10 bolt	2
BAC1603-26	Spacer—No. 10 bolt	14
BAC1603-23	Spacer—No. 10 bolt	2
6-8006	Bracket Installation—Carburetor air	1
6-8006-1	Bracket Assembly—Carburetor Air	1
BAC1614-69	Spacer—1/8 rivet	2
BAC1603-22	Spacer—No. 10 bolt	1
6-7988	Bracket Installation—Carburetor air	1
6-7988-2	Plate Assembly—Carburetor air bracket	1
BAC1603-141	Spacer—No. 10 bolt	2
21-9373-41-36	Bolt—10-32 drilled head	1
BAC1603-77	Spacer—No. 10 bolt	1
BAC1603-16	Spacer—No. 10 bolt	1
BAC1603-10	Spacer—No. 10 bolt	1
21-9373-81-75	Bolt—10-32 drilled head	1
BAC1603-292	Spacer—No. 10 bolt	2
BAC1603-19	Spacer—No. 10 bolt	2
BAC1603-53	Spacer—No. 10 bolt	2
BAC1603-34	Spacer—No. 10 bolt	1
BAC1603-30	Spacer—No. 10 bolt	1
BAC1247-10S	Angle—Nut plate	2
BAC1246-10	Fiber nut plate	1
BAC1470-10-8S	Screw—Washer head	9
55-6070-401	Cover Assembly—Intercooler temperature stand	1
55-6070-15	Plate—Cover Intercooler temperature stand.	1
9-5204-20	Decalcomania	1
55-6070-5	Cover Assembly—Strip Intercooler temperature stand	1
9-5204-21	Decalcomania	1
BAC1249-110S	Plate—Fiber nut	2
55-6070-4	Cover Assembly—Strip intercooler temperature stand	2
9-5204-22	Decalcomania	2
BAC1249-110S	Plate—Fiber nut	4
3-11579	Control Assembly—Carburetor air	1
3-11579-1	Control Assembly—Carburetor air	1
3-11579-2	Control Assembly—Carburetor air	1
3-11579-3	Control Assembly—Carburetor air	1
41-9055	Plate—Carburetor air control	4
41-9117	Plate—Carburetor air control (for use on -1, -3)	2
41-9117-1	Plate—Carburetor air control (for use on -0, -2)	2

AVIALOGS.COM

CONTROLS INSTALLATION—ENGINE

Stand Installation—Carburetor Air

(Parts List No. 326)

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-9048	Knob Assembly—Carburetor air control (for use on -0)	1
41-9048-1	Knob Assembly—Carburetor air control (for use on -1)	1
41-9048-2	Knob Assembly—Carburetor air control (for use on -2)	1
41-9048-3	Knob Assembly—Carburetor air control (for use on -3)	1
41-9048-7	Arm Assembly—Carburetor air control knob	4
41-9051	Pin—Control handle	8
3-11579-5	Plunger Assembly—Carburetor air control	4
41-9111	Plate Assembly—Carburetor air control	4
41-9113	Bearing Assembly—Carburetor air control	8
1-16135-1	Roller—Carburetor air control	8
1-16135-2	Roller—Carburetor air control	8

Stand Installation—Carburetor Air

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-11579-4	Plate—Carburetor air control	4
41-9114	Plunger—Carburetor air control	4
41-9115	Bushing—Carburetor air control	8
41-8453	Spring—Compression	4
BAC1780-53-2L	Cable Assembly—3/32—7 x 7 control	1
BAC1780-71-7L	Cable Assembly—3/32—7 x 7 control	1
BAC1780-82-1L	Cable Assembly—3/32—7 x 7 control	1
BAC1780-94-L	Cable Assembly—3/32—7 x 7 control	1
BAC1780-129-7L	Cable Assembly—3/32—7 x 7 control	1
BAC1780-133-7L	Cable Assembly—3/32—7 x 7 control	1
BAC1780-135-L	Cable Assembly—3/32—7 x 7 control	1
BAC1780-138-7L	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	8
BAC1827-23L	Swaged Terminal—Class "D"	8
BAC1603-40	Spacer—No. 10 bolt	3

POWER PLANT INSTALLATION

Supercharger Installation

(Parts List No. 327)

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-5680-500	Supercharger Installation	1
1-16666	Diagram—Supercharger openings nacelle No. 1 and No. 4	
1-16667	Diagram—Supercharger openings nacelle No. 2 and No. 4	
55-5910-409	Duct Installation—Air inboard LH (PL 330-333)	1
55-5910-410	Duct Installation—Air inboard RH (PL 330-333)	1
65-5911	Duct Installation—Air outboard LH (PL 334-337)	1
65-5911-1	Duct Installation—Air outboard RH (PL 334-337)	1
65-5680-1	Supercharger Assembly—No. 1 nacelle (type B2) (government furnished)	1
21-6862-60-26	Washer—.125 aluminum alloy	6
41-1066-48-22	Washer—.031 corrosive resistant steel	8
41-5951-48-22	Washer—.063 corrosive resistant steel	4
65-5680-1	Supercharger Assembly—No. 4 nacelle (type B2) (government furnished)	1
21-6862-60-26	Washer—.125 aluminum alloy	6
41-1066-48-22	Washer—.031 aluminum alloy	8
41-5951-48-22	Washer—.063 aluminum alloy	4
65-5680-2	Supercharger Assembly—No. 2 nacelle (government furnished) (type B2)	1
6-7907	Seal Installation—Inboard supercharger LH	1
65-5680-4	Screw—Flathead special	1
51-76	Seal—Supercharger pressure duct	1
41-9500	Plate—Cover	1
65-5680-5	Washer—Special	1
65-5680-2	Supercharger Assembly—No. 3 nacelle (type B2) (government furnished)	1
6-7907-2	Seal Installation—Inboard supercharger RH	1
65-5680-4	Screw—Supercharger	1
51-76	Seal—Supercharger pressure duct	1
41-9500	Plate—Cover	1
65-5680-5	Washer—Special	1
58-1077	Intercooler Installation—Inboard supercharger LH	1
58-1077-1	Intercooler Installation—Inboard supercharger RH	1
1E-757	Unit—Intercooler (Airsearch Mfg. Co., Glendale, Calif.)	2
6-7733	Header Assembly—Intercooler LH	2
6-7733-1	Header Assembly—Intercooler RH	2
41-9282-1	Flange—Duct	4
41-8265	Gasket—Intercooler	4
21-4844-70	Jumper Assembly—No. 10-10 terminal bonding	4
BAC820-10	Terminal—Electrical lock	8
58-1077-501	Channel Assembly—Inboard supercharger intercooler	4

Supercharger Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
58-1077-502	Channel Assembly—Inboard supercharger intercooler	4
41-9508	Ring—Washer retainer	4
58-1077-402	Angle—Inboard supercharger intercooler	4
58-1077-8	Tube—Inboard supercharger intercooler	8
41-9501-32-8	Washer—1/8 neoprene	32
21-2364-56-17	Washer—.064 aluminum alloy	16
BAC1603-90	Washer—No. 10 bolt	32

(Parts List No. 328)

15-7654	Intercooler Installation—Outboard vacuum LH	1
15-7654-1	Intercooler Installation—Outboard vacuum RH	1
1E-757	Unit—Intercooler (Airsearch Mfg. Co., Glendale, Calif.)	2
6-7798	Header Assembly—Pressure duct LH	1
6-7798-1	Header Assembly—Pressure duct RH	1
9-2944	Elbow Assembly—Header LH	1
9-2944-1	Elbow Assembly—Header RH	1
9-2944-6	Vane Assembly—Header elbow LH	1
9-2944-7	Vane Assembly—Header elbow RH	1
41-9282	Flange—Duct	2
41-8553	Beam—Air duct	4
41-9509	Bracket—Intercooler support	8
41-9508	Ring—Washer retainer	8
41-8265	Gasket—Intercooler	4
56-7789	Elbow Assembly—Pressure duct LH	1
56-7789-1	Elbow Assembly—Pressure duct RH	1
41-9282-1	Flange—Duct	2
41-9161	Flange—1/8 P.T. welding	2
41-9501-32-8	Washer—1/8 neoprene	32
21-2364-56-17	Washer—.064 aluminum alloy	16
15-7654-2	Spacer—Outboard vacuum intercooler	8
21-4841-40	Jumper Assembly—No. 8-8 terminal bonding	2
BAC820-8	Terminal—Electrical lock	4
21-4844-80	Jumper Assembly—No. 10-10 terminal bonding	2
BAC820-10	Terminal—Electrical lock	4
55-5976	Duct Installation—Pressure outboard LH	1
55-5976-1	Duct Installation—Pressure outboard RH	1
41-8448	Duct Assembly—Carburetor pressure	2
6-8463	Elbow Assembly—Pressure duct LH	1
6-8463-1	Elbow Assembly—Pressure duct RH	1
41-8321	Frame—Half—pressure duct	2
41-8321-1	Frame—Half—pressure duct	2
9-3080-10	Elbow Assembly—Carburetor pressure duct	2

AVIALOGS.COM

POWER PLANT INSTALLATION

Supercharger Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
9-3080-4	Vane Assembly—Rivet—carburetor pressure duct	2
41-9161	Flange—⅛ P.T. welding	2
3-11717	Ring—Hose	12
6-8072	Hose—Corrugated—air	4
6-8072-2	Hose—Corrugated—air	2
41-8374	Ring Assembly—Air duct	24
BAC1095-428	Nut—Self-locking high temperature	26
65-5975	Duct Installation—Pressure inboard LH	1
65-5975-1	Duct Installation—Pressure inboard RH	1
65-5975-511	Duct Assembly—Weld—pressure inboard LH	1
65-5975-512	Duct Assembly—Weld—pressure inboard RH	1
3-11332	Adapter Assembly—Pressure duct LH	1
3-11332-1	Adapter Assembly—Pressure duct RH	1
1-19998	Angle—Pressure duct	2
41-8321	Frame Half—Pressure duct	2
41-8321-1	Frame Half—Pressure duct	2
	(Parts List No. 329)	
3-16455	Pad—Rubbing	2
41-8374	Ring Assembly—Air duct	40
3-11717	Ring—Hose	20
6-8072	Hose—Corrugated air	8
6-8072-2	Hose—Corrugated air	2
6-7741	Connector Assembly—Pressure duct LH	1
6-7741-1	Connector Assembly—Pressure duct RH	1
6-7741-2	Connector Assembly—Weld-pressure duct LH	1
6-7741-5	Connector Assembly—Weld-pressure duct RH	1
3-11350-3	Flange—Pressure duct conn	2
41-8357	Gasket—Pressure duct	4
65-5975-504	Duct Assembly—Weld—pressure inboard LH	1
65-5975-505	Duct Assembly—Weld—pressure inboard RH	1
3-11350	Connector Assembly—pressure duct	2
65-5975-410	Duct Assembly—Weld—pressure inboard LH	1
65-5975-411	Duct Assembly—Weld—pressure inboard RH	1
41-9161	Flange—⅛ P.T.	2
9-3080	Elbow Assembly—Carburetor pressure duct	2
9-3080-4	Vane Assembly—Rivet—Carburetor pressure duct	2

Supercharger Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-11166	Collar Assembly—Air duct	4
41-8461	Collar Assembly—Duct support	4
41-8435	Clamp Assembly—Air duct	4
41-8435-1	Strip—Neoprene—air duct clamp	4
41-8435-2	Clamp—Air duct	4
6-9596	Bracket Assembly—Pressure duct	2
41-8435	Clamp Assembly—Airduct	2
41-8435-1	Strip—Neoprene—air duct clamp	4
41-8435-2	Clamp—Air duct	4
3-13913	Duct—Pressure	2
3-13914	Channel—Pressure duct	2
BAC1603-24	Spacer—No. 10 bolt	8
49-3056-408	Seat Installation—Outboard nacelle station 2C	2
49-3056-400	Frame Assembly—Outboard nacelle station 2C	2
49-3056-4	Seal—Outboard nacelle station 2C seat (Johns-Manville)	2
49-3056-405	Frame Assembly—Outboard nacelle station 2C	2
49-3056-8	Seal—Outboard nacelle station 2C seat (Johns-Manville)	2
15-6531	Scoop Installation—Supercharger cooling—outboard LH	2
15-6531-1	Scoop Installation—Supercharger cooling—outboard RH	2
15-6531-2	Scoop Assembly—Supercharger cooling—outboard LH	2
15-6531-3	Scoop Assembly—Supercharger cooling—outboard RH	2
15-6531-29	Scoop Assembly—Spotweld supercharger cooling—outboard LH	2
15-6531-30	Scoop Assembly—Spotweld supercharger cooling—outboard RH	2
15-6531-4	Scoop Assembly—Weld—supercharger cooling—outboard LH	2
15-6531-5	Scoop Assembly—Weld—supercharger cooling—outboard RH	2
15-6531-27	Baffle Assembly—Spotweld—supercharger cooling—outboard LH	2
15-6531-28	Baffle Assembly—Spotweld—supercharger cooling—outboard RH	2
BAC1095-1032	Nut Plate	8

SUPERCHARGER INSTALLATION

Duct Installation—Air Inboard

(Parts List No. 330)

55-5910-409	Duct Installation—Air inboard LH	1
55-5910-410	Duct Installation—Air inboard RH	1
55-6700	Duct Assembly—Carburetor and cabin air LH	1
55-6700-1	Section—Side duct	1
55-6700-2	Section—Side duct	1
55-6700-3	Plate—Bottom duct	1
55-6700-4	Plate—Bottom duct	1
55-6700-400	Collar—Duct	1
6-7919-7	Duct Assembly—Carburetor and cabin air RH	1
6-7919-1	Duct—Half—inboard air duct	1
6-7919-4	Collar—Air duct	1
6-7919-5	Duct—Half—outboard air duct	1
41-8600	Flange—Duct assembly	1
15-6701	Duct Assembly—Carburetor and cabin air LH	1
15-6701-1	Duct Assembly—Carburetor and cabin air RH	1
15-6701-3	Duct—Top carburetor and cabin air	1
15-6701-4	Duct—Bottom carburetor and cabin air	1
15-6701-5	Duct—Side carburetor and cabin air	1
15-6701-6	Duct—Side carburetor and cabin air	1
15-6701-9	Bracket—Carburetor and cabin air	1
51-786-1	Flange Assembly—Air duct RH	1
15-6701-2	Duct Assembly—Carburetor and cabin air	1
15-6701-10	Duct—Carburetor and cabin air	1

Duct Installation—Air Inboard

15-6701-11	Duct—Carburetor and cabin air	1
15-6701-12	Duct—Carburetor and cabin air	1
15-6701-13	Duct—Carburetor and cabin air	1
1-16661	Flange—Air duct	1
81-8634-402	Flange—Assembly—drain	1
9-3681	Duct Assembly—Air intake	1R
41-8600-1	Flange—Duct assembly	1
51-786	Flange Assembly—Air duct LH	1
81-8634-402	Flange Assembly—Drain	1
41-8746	Gasket—Air duct	1
41-8809	Clamp Assembly—Duct support	2
41-8809-2	Clamp Assembly—Duct support	2
21-6087-3-3	Clamp—Barrel type	2
41-8811-4	Channel—Cold air duct LH	1
41-8811-5	Channel—Cold air duct RH	1
41-8810-2	Channel—Support LH	1
41-8810-3	Channel—Support RH	1
65-6093	Elbow Assembly—Air intake LH	1
65-6093-1	Elbow Assembly—Air intake RH	1
65-6093-513	Duct Assembly—Air intake elbow	2
41-8350-1	Collar—Cold air duct	2

AVIALOGS.COM

SUPERCHARGER INSTALLATION

Duct Installation—Air Inboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-6093-12	Vane Assembly—Air intake elbow	2
6-7927	Housing Assembly—Relief valve—inboard	2
6-7927-1	Box—Relief valve inboard housing	2
	(Parts List No. 331)	
15-6079-4	Channel—Relief valve outboard housing	2
15-6079-5	Seal—Relief valve outboard housing	2
15-6079-6	Plate—Relief valve outboard housing	2
15-6079-7	Channel—Relief valve outboard housing	2
15-6079-8	Seal—Relief valve outboard housing	2
15-6079-9	Plate—Relief valve outboard housing	2
15-6079-10	Angle—Relief valve outboard housing	4
41-8756	Bushing Assembly—Relief valve	4
41-8755	Support—Bushing	4
41-8756-1	Bushing—Relief valve	4
9-2988-4	Spacer—Relief outboard valve	4
41-8752	Shaft Assembly—Relief valve	2
41-8745	Plate—Shaft attaching	2
41-8805	Shaft Assembly—Relief valve	2
41-8745	Plate—Shaft attaching	2
41-8826	Flap Assembly—Relief valve	2
41-8806	Spring—Relief valve	2
51-339	Channel—Brace—cold air duct station 4 LH	1
51-339-1	Channel—Brace—cold air duct station 4 RH	1
9-3123	Duct Assembly—Intake air LH inboard supercharger	1
9-3123-1	Duct Assembly—Intake air RH inboard supercharger	1
7-1643	Duct Assembly—Intake air LH	1
7-1643-1	Duct Assembly—Intake air RH	1
51-676	Flange Assembly—Drain	2
3-16492	Gasket—Corner	8
51-603	Ring—Air duct	2
21-6671-14H3	Bolt—5/16—24 special (drilled head)	8
41-7574-88-25	Clamp Assembly—Tabulated—square	1L
41-468-88-25	Clamp—Square loop tube	1
41-7574-88-25	Clamp Assembly—Tabulated—square	2R
41-468-88-25	Clamp—Square loop type	2
41-8261	Lug—Mixing box	8
49-3022	Header Assembly—Cooling air duct LH	1
49-3022-1	Header Assembly—Cooling air duct RH	1
41-9044	Flange—Header duct	1L
41-9044-1	Flange—Header duct	1R
41-9009	Gasket—Duct	2
41-8958	Channel—Cooling air duct	4
41-8958-1	Channel—Cooling air duct	4
1-16664	Bracket Assembly—Duct support LH	1
41-9088-86-24	Clamp—Square	2
79-3021	Elbow Assembly—Cooling air duct LH	1
79-3021-1	Elbow Assembly—Cooling air duct RH	1
79-3021-710	Duct Assembly—Cooling air elbow LH	1
79-3021-716	Duct Assembly—Cooling air elbow RH	1
79-3021-6	Vane Assembly—Cooling air duct elbow LH	1
	(Parts List No. 332)	
79-3021-7	Vane Assembly—Cooling air duct elbow RH	1
79-3021-11	Vane Assembly—Cooling air duct elbow	2
81-8634-400	Flange Assembly—Drain	2
79-3021-20	Vane Assembly—Cooling air duct	1L
79-3021-21	Vane Assembly—Cooling air duct	1R
3-12104	Flange Assembly—Air duct	2
41-9044	Flange—Header duct	1L
41-9044-1	Flange—Header duct	1R
3-12572	Flange Assembly—Air duct	1L
3-16494	Gasket—Corner	2
1-17595	Plate—Duct support	1
1-17595-1	Plate—Duct support	1
1-17596	Plate—Duct Support	1
1-17596-1	Plate—Duct support	1
BAC540-6	Clamp—Loop type cushioned	4
BAC540-14	Clamp—Loop type cushioned	4
BAC1603-6	Spacer—No. 10 bolt	4

Duct Installation—Air Inboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
55-6339	Duct Assembly—Cooling air LH	1
55-6339-1	Duct Assembly—Cooling air RH	1
41-7763	Housing Assembly—Bearing	4
41-7763-1	Housing—Bearing	4
3-12080	Vane Assembly—Cooling air valve	2
3-12104	Flange Assembly—Air duct	2
3-12105	Flange Assembly—Air duct	2
51-605-2	Shaft—Cooling air valve	2
3-16491	Gasket—Corner	2
21-3894-64-41	Washer—Retaining	4
1-17588-3	Lever—Engine control	4
43-12031	Support Installation—Cooling air duct LH	1
43-12031-1	Support Installation—Cooling air duct RH	1
55-6089	Expander Assembly—Cooling air duct LH	1
55-6089-1	Expander Assembly—Cooling air Duct RH	1
55-6089-400	Frame Assembly—Upper cooling air duct	1
55-6089-401	Frame Assembly—Upper cooling air duct	1
47-1341-12	Plate—Flexible Connector	4
51-781	Gusset—Air Duct	2
51-781-1	Gusset—Air Duct	2
6-11964	Gasket	2
3-12105	Flange Assembly—Air duct	2
59-2990	Connector Assembly—Flexible LH	1
59-2990-1	Connector Assembly—Flexible RH	1
57-1341-500	Frame Assembly—Flexible connector	2
3-18281	Gasket—Connector	4
41-9475	Filler—Corner	8
59-2990-401	Angle Assembly—Flexible connector LH	1
59-2990-402	Angle Assembly—Flexible connector RH	1
59-2990-8	Sleeve Assembly—Flexible connector LH	1
59-2990-14	Sleeve Assembly—Flexible connector RH	1
	(Parts List No. 333)	
59-2990-21	Frame Assembly—Segment—flexible connector LH	1
59-2990-25	Frame Assembly—Segment—flexible connector RH	1
41-9475	Filler—Corner	2
57-1341-12	Plate—Flexible connector	2
59-2990-26	Frame Assembly—Segment—flexible connector LH	1
59-2990-19	Frame Assembly—Segment—flexible connector RH	1
41-9475	Filler—Corner	2
57-1341-12	Plate—Flexible connector	2
41-7574-30-9	Clamp Assembly—Tabulated square	4
41-468-30-9	Clamp—Square loop type	4
6-8372	Support Installation—Cooling air duct LH	1
6-8372-1	Support Installation—Cooling air duct RH	1
41-7574-88-25	Clamp Assembly—Tab square	2
41-468-88-25	Clamp—Square loop type	2
55-5910-415	Bonding—Intake duct	2
55-5910-403	Tube—Intake duct	1R
55-5910-404	Tube—Intake duct	2
55-5910-405	Tube—Intake duct	1L
55-5910-406	Tube—Intake duct	1R
55-5910-408	Tube—Intake duct	1L
BAC535-12	Clamp—Hose	8
BAC1200-B40	Wire—For locking	2
3-16455-1	Pad—Rubbing	2
3-16455-2	Pad—Rubbing	2
3-16455-3	Pad—Rubbing	2
	(Parts List No. 334)	
65-5911	Duct Installation—Air outboard LH	1
65-5911-1	Duct Installation—Air outboard RH	1
6-7998-8	Duct Assembly—Cold air intake LH	1
6-7998-9	Duct Assembly—Cold air intake RH	1
41-9014	Collar—Air duct	2
81-8634-402	Flange Assembly—Drain	2
41-8748	Collar—Air duct	2
6-7841	Bracket Installation—Air duct LH	1
6-7841-1	Bracket Installation—Air duct RH	1

AVIALOGS.COM

SUPERCHARGER INSTALLATION

Duct Installation—Air Outboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-7841-2	Bracket Assembly—Air duct LH	1
6-7841-3	Bracket Assembly—Air duct RH	1
6-7841-4	Strip—Air duct bracket	2
6-7841-5	Clamp Assembly—Air duct LH	1
6-7841-6	Clamp Assembly—Air duct RH	1
41-7636-6	Clamp Assembly—Barrel	4
21-6441-6	Clamp Assembly—¾ wide barrel	4
21-6087-6-3	Clamp—Barrel type	4
41-8753	Clamp Assembly—Air duct	2
41-8753-2	Clamp—Air duct	2
41-9013	Clamp Assembly—Duct—half-weld	4
6-7999	Duct Assembly—Air intake RH	1
6-7999-1	Duct Assembly—Air intake LH	1
41-9014	Collar—Air duct	4
6-9310	Bracket—Air duct support LH	1
6-9310-1	Bracket—Air duct support RH	1
6-7893	Support—Air duct—station 14	1L
6-7893-1	Support—Air duct—station 14	1R
6-7794	Support—Air duct—station 14	1L
6-7794-1	Support—Air duct—station 14	1R
1-9601-2	Clip—Tabulated—square tube	12
41-9013	Clamp Assembly—Duct—half—weld	4
BAC540-6	Clamp—Loop type cushioned	2
BAC540-12	Clamp—Loop type cushioned	4
6-7993	Duct Assembly—Air intake LH	1
6-7993-1	Duct Assembly—Air intake RH	1
41-9014	Collar—Air duct	4
41-7636-5	Clamp Assembly—Barrel	2
21-6441-5	Clamp Assembly—¾ wide barrel	2
21-6087-5-3	Clamp—Barrel type	2
41-7636-6	Clamp Assembly—Barrel	2
21-6441-6	Clamp Assembly—¾ wide barrel	2
21-6087-6-3	Clamp—Barrel type	2
BAC1603-10	Spacer—No. 10 bolt	4
41-9013	Clamp Assembly—Duct—half—weld	4

Duct Installation—Air Outboard

(Parts List No. 335)

9-2988	Valve Assembly—Relief outboard LH	2
15-6079	Housing Assembly—Relief valve outboard	2
15-6079-1	Box Assembly—Weld relief valve outboard	2
41-9014	Collar—Air duct	4
41-8756	Bushing Assembly—Relief valve	4
41-8755	Support—Bushing	4
41-8756-1	Bushing—Relief valve (Olite) (Tingwell Brs. Ltd., No. A-507-4)	4
41-8752	Shaft Assembly—Relief valve	2
41-8752-1	Tube—Relief valve shaft	2
41-8745	Plate—Shaft attachment	2
41-8805	Shaft Assembly—Relief valve	2
41-8805-1	Tube—Relief valve shaft	2
41-8745	Plate—Shaft attachment	2
9-2988-4	Spacer—Relief outboard valve	4
41-8806	Spring—Relief valve	2
41-8826	Flap Assembly—Relief valve	2
41-9013	Clamp Assembly—Air duct half	4
47-1343-23	Duct Assembly—Intercooler (outboard) LH	1
47-1343-24	Duct Assembly—Intercooler (outboard) RH	1
3-12100	Flange Assembly—Duct end LH	1
3-12100-1	Flange Assembly—Duct end RH	1
49-3029	Duct Assembly—Intercooler air LH	1
49-3029-1	Duct Assembly—Intercooler air RH	1
3-12100	Flange Assembly—Duct end LH	1
3-12100-1	Flange Assembly—Duct end RH	1
81-8634-402	Flange Assembly—Drain	2
3-16495	Gasket	2
3-16495-1	Gasket	2
9-3124-33	Duct Assembly—Cooling air LH	1
9-3124-34	Duct Assembly—Cooling air RH	1
3-12084	Vane Assembly—Cooling air valve	2
41-7763	Housing Assembly—Bearing	4

Duct Installation—Air Outboard

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-7763-1	Housing—Bearing	4
9-3124-28	Tube—Cooling air duct	2
1-17588-3	Lever—Engine control	2
51-605-1	Shaft—Cooling air valve	2
21-3894-64-41	Washer—Retaining	4
57-1341	Connector Assembly—Flexible	2
57-1341-500	Frame Assembly—Flexible connector	2
3-18281	Gasket—Connector	4
41-9475	Filler—Corner	8
57-1341-7	Frame Assembly—Flexible connector	2
3-18280	Gasket—Connector	2
41-9475	Filler—Corner	8
3-11584	Support Installation—Air duct LH	1
3-11584-1	Support Installation—Air duct RH	1
3-11584-2	Support Assembly—Air duct LH	1

(Parts List No. 336)

3-11584-3	Support Assembly—Air duct RH	1
BAC1603-8	Spacer—No. 10 bolt	4
3-11585	Support Installation—Air duct LH	1
3-11585-1	Support Installation—Air duct RH	1
41-5362-24	Washer—No. 10 square	6
65-5911-400	Tube—Outboard supercharger intake duct	2
41-3034	Angle—Tubing support	2
65-5911-68	Hose—Outboard supercharger intake duct	2
49-3030	Elbow Assembly—Intercooler duct (outboard) LH	1
49-3030-1	Elbow Assembly—Intercooler duct (outboard) RH	1
21-2165-1	Spring—Feed chute	6
49-3030-14	Vane Assembly—Intercooler duct (outboard) LH	1
49-3030-15	Vane Assembly—Intercooler duct (outboard) RH	1
49-3030-11	Vane Assembly—Intercooler duct (outboard) RH	1
49-3030-20	Vane Assembly—Intercooler duct (outboard) LH	1
3-11657	Support Installation—Cooling duct (outboard) LH	1
3-11657-1	Support Installation—Cooling duct (outboard) RH	1
3-11657-2	Channel—Cooling duct support LH	1
3-11657-3	Channel—Cooling duct support RH	1
6-8101	Support Installation—Cooling air duct (outboard) LH	1
6-8101-1	Support Installation—Cooling air duct (outboard) RH	1
6-8101-5	Support Assembly—Cooling air duct	1L
6-8101-6	Support Assembly—Cooling air duct	1R
6-8101-10	Plate—Flanged	1L
6-8101-11	Plate—Flanged	1R
41-8261	Lug—Mixing box	8
21-6671-14H-3	Bolt—5/16-24 special (drilled head)	8
41-9013	Camp Assembly—Duct half	4
65-5911-69	Hose—Drain outboard supercharger intake duct	2
9-3701-1	Duct Assembly—Outboard supercharger	2
9-3701-2	Duct—Outboard supercharger	2
41-9014	Collar—Air duct	4
9-3701-6	Duct Assembly—Outboard supercharger	2
9-3701-5	Duct—Outboard supercharger	2
41-9014	Collar—Air duct	2
51-603	Ring—Air duct	2
BAC1200B-40	Wire—For locking	2

(Parts List No. 337)

BAC535-12	Hose—Clamp	4
65-5911-50	Strip—Neoprene outboard supercharger intake duct	4
65-5911-66	Sheet—Neoprene outboard supercharger intake duct	2
65-5911-600	Neoprene—Outboard supercharger intake duct	2
65-5911-601	Bonding—Outboard supercharger intake duct	2
3-16455-2	Pad—Rubbing	4
3-16455-3	Pad—Rubbing	2

AVIALOGS.COM

POWER PLANT INSTALLATION

Cowling Installation—Inboard Engines

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 338)	
15-7664	Cowling Installation—Inboard engine	1L
15-7664-1	Cowling Installation—Inboard engine	1R
15-7674	Segment Assembly—Rear Inboard engine cowling	1L
15-7674-2	Segment Assembly—Inboard engine cowling	1
3-13778	Stiffener—Cowling	3
3-13783	Stiffener—Cowling	1
51-664-50	Button Installation—Dzus	5
41-3853-1	Plate—Cowl fastener	5
41-3888-50	Button—Dzus type F	5
51-664-60	Button Installaton—Dzus	1
41-3853-1	Plate—Cowl fastener	1
41-3888-60	Button—Dzus type F	1
15-7674-4	Segment Assembly—Cowling forward	1L
15-7674-6	Segment Assembly—Inner cowling forward	1
1-18365	Channel—Cowling stiffener	1
1-18365-1	Channel—Cowling stiffener	1
1-19038	Stiffener Assembly—Cowling	3L
BAC1253-110	Nut Plate—High tempered	3
1-19039	Stiffener Assembly—Cowling	1L
BAC1253-110	Nut Plate—High tempered	1
BAC1254-110	Nut Plate—Countersunk high tempered	1
1-19040	Stiffener Assembly—Cowling	1L
BAC1253-110	Nut Plate—High tempered	1
1-19669-2	Angle—Engine cowling	3
1-18081-2	Channel Assembly—Dzus button	4
41-3888-50	Button—Dzus type F	4
1-18286-2	Channel Assembly—Dzus button	1
41-3888-50	Button—Dzus type F	1
3-13772	Door Assembly—Fastener access	5
1-18928	Spring—Fastener access door	5
15-7674-1	Segment Assembly—Cowling	1R
15-7674-3	Segment Assembly—Rear cowling	1R
3-13778-1	Stiffener—Cowling	3
3-13783-1	Stiffener—Cowling	1
51-664-50	Button Installation—Dzus	5
41-3853-1	Plate—Cowl fastener	5
41-3888-50	Button—Dzus type F	5
51-664-60	Button Installation—Dzus	1
41-3853-1	Plate—Cowl fastener	1
41-3888-60	Button—Dzus type F	1
15-7674-5	Segment Assembly—Cowling forward	1R
15-7674-7	Segment Assembly—Cowling inner	1R
1-18365	Channel—Cowling stiffener	1
1-18365-1	Channel—Cowling stiffener	1
1-19038-1	Stiffener Assembly—Cowling	3R
BAC1253-110	Nut Plate—High tempered	3
1-19039-1	Stiffener Assembly—Cowling	1R
BAC1253-110	Nut Plate—High temperature	1
BAC1254-110	Nut Plate—Countersunk high temperature	1
1-19040-1	Stiffener Assembly—Cowling	1R
	(Parts List No. 339)	
BAC1253-110	Nut Plate—High temperature	1
1-19669	Angle—Engine cowling	3
1-19669-2	Angle—Engine cowling	3
1-18081-2	Channel Assembly—Dzus button	4
41-3888-50	Button—Dzus type F	4
1-18286-2	Channel Assembly—Dzus fastener	1
41-3888-50	Button—Dzus type F	1
3-13772	Door Assembly—Fastener accessory	5
3-13772-1	Hinge—Fastener accessory door	5
3-13772-2	Flap—Fastener accessory door	5
3-13772-3	Pin—Fastener accessory door	5
1-18928	Spring—Fastener accessory door	5
15-7675	Segment Assembly—Inboard cowling	1L
15-7675-2	Segment Assembly—Rear inboard cowling	1L
3-13778-1	Stiffener—Cowling	2
3-13783-1	Stiffener—Cowling	1
51-664-50	Button Installation—Dzus	5

Cowling Installation—Inboard Engines

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-3853-1	Plate—Cowl fastener	5
41-3888-50	Button—Dzus type F	5
51-664-60	Button Installation—Dzus	1
41-3853-1	Plate—Cowl fastener	1
41-3888-60	Button—Dzus type F	1
15-7675-4	Segment Assembly—Cowling forward	1L
15-7675-6	Segment Assembly—Cowling inner forward	1L
1-18365	Channel—Cowling stiffener	1
1-18365-1	Channel—Cowling stiffener	1
1-19038-1	Stiffener Assembly—Cowling	3L
BAC1253-110	Nut Plate—High temperature	3
1-19040-1	Stiffener Assembly—Cowling	1L
BAC1253-110	Nut Plate—High temperature	1
1-19669-2	Angle—Engine cowling	3
1-18081-2	Channel Assembly—Dzus button	4
41-3888-50	Button—Dzus type F	4
1-18286-2	Channel Assembly—Dzus fastener	1
41-3888-50	Button—Dzus type F	1
3-13772	Door Assembly—Fastener accessory	5
3-13772-1	Hinge—Fastener accessory door	5
3-13772-2	Flap—Fastener accessory door	5
3-13772-3	Pin—Fastener accessory door	5
1-18928	Spring—Fastener accessory door	5
15-7675-1	Segment Assembly—Inboard cowling	1R
15-7675-3	Segment Assembly—Rear inboard cowling	1R
3-13778	Stiffener—Cowling	2
3-13783	Stiffener—Cowling	1
51-664-50	Button Installation—Dzus	5
41-3853-1	Plate—Cowl fastener	5
41-3888-50	Button—Dzus type F	5
51-664-60	Button Installation—Dzus	1
41-3852-1	Plate—Cowl fastener	1

Cowling Installation—Inboard Engines

	(Parts List No. 340)	
41-3888-60	Plate—Cowl fastener	1
15-7675-5	Segment Assembly—Cowling forward	1R
15-7675-7	Segment Assembly—Cowling inner forward	1R
1-18365	Channel—Cowling stiffener	1
1-18365-1	Channel—Cowling stiffener	1
1-19038	Stiffener Assembly—Cowling	3L
BAC1253-110	Nut Plate—High temperature	3
1-19040	Stiffener Assembly—Cowling	1L
BAC1253-110	Nut Plate—High temperature	1
1-19669-2	Angle—Engine cowling	3
1-18081-2	Channel Assembly—Dzus button	4
41-3888-50	Button—Dzus type F	4
1-18286-2	Channel Assembly—Dzus fastener	1
41-3888-50	Button—Dzus type F	1
3-13772	Door Assembly—Fastener accessory	5
3-13772-1	Hinge—Fastener accessory door	5
3-13772-2	Flap—Fastener accessory door	5
3-13772-3	Pin—Fastener accessory door	5
1-18928	Spring—Fastener accessory door	5
55-7672	Segment Assembly—Cowling	2L-3R
55-7672-1	Segment Assembly—Rear cowling	5
3-13778	Stiffener—Cowling	5L
3-13778-1	Stiffener—Cowling	5R
3-13783	Stiffener—Cowling	5L
3-13783-1	Stiffener—Cowling	5R
51-664-50	Button Installation—Dzus	20
41-3853-1	Plate—Cowl fastener	20
41-3888-50	Button—Dzus type F	20
55-7672-400	Segment Assembly—Front cowling	5
55-7672-401	Segment Assembly—Lower cowling	5
1-18365	Channel—Cowling stiffener	5L
1-18365-1	Channel—Cowling stiffener	5R
1-19038	Stiffener Assembly—Cowling LH	10
BAC1253-110	Nut Plate—High tempered	10

AVIALOGS.COM

POWER PLANT INSTALLATION

Cowling Installation—Inboard Engines

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-19038-1	Stiffener Assembly—Cowling RH	10
BAC1253-110	Nut Plate—High tempered	10
1-19040	Stiffener Assembly—Cowling LH	5
BAC1253-110	Nut Plate—High tempered	5
1-19040-1	Stiffener Assembly—Cowling RH	5
BAC1253-110	Nut Plate—High tempered	5
1-19669	Angle—Engine cowling	20
1-18081-2	Channel Assembly—Dzus fastener	20
41-3888-50	Button—Dzus type F	20
1-18286-2	Channel Assembly—Dzus fastener	10
41-3888-50	Button—Dzus type F	10
3-13772	Door Assembly—Fastener accessory	30
3-13772-1	Hinge—Fastener accessory door	30
3-13772-2	Flap—Fastener accessory door	30
3-13772-3	Pin—Fastener accessory door	30
1-18928	Spring—Fastener accessory door	30

(Parts List No. 341)

65-7672	Segment Assembly—Cowling	1L
65-7672-500	Segment Assembly—Rear cowling	1
3-13778	Stiffener—Cowling	1L
3-13778-1	Stiffener—Cowling	1R
3-13783	Stiffener—Cowling	1L
3-13783-1	Stiffener—Cowling	1R
51-664-50	Button Installation—Dzus	4
41-3853-1	Plate—Cowl fastener	4
41-3888-50	Button—Dzus type F	4
65-7672-503	Segment Assembly—Front cowling	1
65-7672-401	Segment Assembly—Lower cowling	1
1-18365	Channel—Cowling stiffener	1L
1-18365-1	Channel—Cowling stiffener	1R
1-19038	Stiffener Assembly—Cowling LH	2
BAC1253-110	Nut Plate—High tempered	2
1-19038-1	Stiffener Assembly—Cowling RH	2
BAC1253-110	Nut Plate—High tempered	2
1-19040	Stiffener Assembly—Cowling LH	1
BAC1253-110	Nut Plate—High tempered	1
1-19040-1	Stiffener Assembly—Cowling RH	1
BAC1253-110	Nut Plate—High tempered	1
1-19669-2	Angle—Engine cowling	4
1-18081-2	Channel Assembly—Dzus button	4
41-3888-50	Button—Dzus type F	4
1-18286-2	Channel Assembly—Dzus fastener	2
41-3888-50	Button—Dzus type F	2
3-13772	Door Assistant—Fastener accessory	6
3-13772-1	Hinge—Fastener accessory door	6
3-13772-2	Flap—Fastener accessory door	6
3-13772-3	Pin—Fastener accessory door	6
1-18928	Spring—Fastener accessory door	6

Cowling Installation—Outboard Engines

(Parts List No. 342)

15-7667	Cowling Installation—Outboard	2
15-7672	Segment Assembly—Cowling	6
15-7672-1	Segment Assembly—Rear cowling	6
3-13783	Stiffener—Cowling	6L
3-13783-1	Stiffener—Cowling	6R
3-13778	Stiffener—Cowling	6L
3-13778-1	Stiffener—Cowling	6R
51-664-50	Button Installation—Dzus	24
41-3888-50	Fastener—Dzus type F	24
41-3853-1	Plate—Spot weld cowl fastener	24
15-7672-5	Segment Assembly—Front cowling	6
15-7672-6	Segment Assembly—Lower cowling	6
1-19811	Stiffener—Cowling	12
1-19811-1	Stiffener—Cowling	6R
1-10669-2	Angle—Engine cowling	12
1-19810	Stiffener—Cowling	12L
1-19810-1	Stiffener—Cowling	12R

Cowling Installation—Outboard Engines

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18365	Channel—Cowling stiffener	6L
1-18365-1	Channel—Cowling stiffener	6R
3-13772	Door Assembly—Fastener accessory	36
3-13772-1	Hinge—Fastener accessory door	36
3-13772-2	Flap—Fastener accessory door	36
3-13772-3	Pin—Fastener accessory door	36
1-18928	Spring—Fastener accessory door	36
1-18081-2	Channel Assembly—Dzus button	24
41-3888-50	Button—Dzus type F	24
1-18286-2	Channel Assembly—Dzus button	12
41-3888-50	Button—Dzus type F	12
BAC1095-1032	Nut—Self-locking high tempered	36
15-7673	Segment Assembly—Cowling outboard	2
15-7673-1	Segment Assembly—Cowling outboard	2
15-7673-2	Segment Assembly—Rear cowling outboard	2L
15-7673-3	Segment Assembly—Rear cowling outboard	2R
3-13778	Stiffener—Cowling	6
3-13778-1	Stiffener—Cowling	6
3-13783	Stiffener—Cowling	2
3-13783-1	Stiffener—Cowling	2
51-664-50	Button Installation—Dzus	20
41-3888-50	Button—Dzus type F	20
41-3853-1	Plate—Spot weld cowl fastener	20
51-664-60	Button Installation—Dzus	4
41-3888-60	Button—Dzus type F	4
41-3853-1	Plate—Spot weld cowl fastener	4
15-7673-4	Segment Assembly—Forward cowling outboard	2L
15-7673-5	Segment Assembly—Forward cowling outboard	2R
15-7673-6	Segment Assembly—Inner cowling outboard	2
15-7673-7	Segment Assembly—Inner cowling outboard	2
1-18365	Channel—Cowling stiffener	4

(Parts List No. 343)

1-18365-1	Channel—Cowling stiffener	4
1-18577	Stiffener Assembly—Cowling	2L
1-18577-1	Stiffener Assembly—Cowling	2R
BAC1253-110	Nut Plate—High tempered	4
BAC1254-110	Nut Plate—Countersunk high tempered	4
1-19669-2	Angle—Engine cowling	12
1-19810	Stiffener—Cowling	6L
1-19810-1	Stiffener—Cowling	6R
1-19811	Stiffener—Cowling	2L
1-19811-1	Stiffener—Cowling	2R
BAC1095-1032	Nut—Self-locking high tempered	16
1-18081-2	Channel Assembly—Dzus button	16
41-3888-50	Button—Dzus type F	16
1-18286-2	Channel Assembly—Dzus fastener	4
41-3888-50	Button—Dzus type F	4
3-13772	Door Assembly—Fastener accessory	20
3-13772-1	Hinge—Fastener accessory door	20
3-13772-2	Flap—Fastener accessory door	20
3-13772-3	Pin—Fastener accessory door	20
1-18928	Spring—Fastener accessory door	20

Oil System Installation—Supercharger Lubrication

(Parts List No. 344)

55-6088-414	Oil System Installation—Supercharger lubrication	1
55-6088-411	Tank Assembly—No. 2 and No. 4 nacelle—supercharger oil lubrication system	2
55-6088-412	Tank Assembly—No. 1 nacelle—supercharger oil lubrication system	1
55-6088-413	Tank Assembly—No. 3 nacelle—supercharger oil lubrication system	1
49-3047	Tank Assembly—Supercharger lubricating oil	2
49-3047-1	Tank Assembly—Supercharger lubricating oil	2
49-3047-400	Tank Assembly—Supercharger lubricating oil	2
49-3047-401	Tank Assembly—Supercharger lubricating oil	2
21-6996	Flange—½ pipe thread	4
41-9528	Flange—Tank filler	4
21-2089	Flange—⅜ pipe thread	12

AVIALOGS.COM

POWER PLANT INSTALLATION

Oil System Installation—Supercharger Lubrication

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
49-3047-9	Name Plate—Supercharger lubricating oil tank	4
49-3047-4	Shell—Supercharger lubricating oil tank	4
49-3047-6	End—Supercharger lubricating oil tank	4
49-3047-7	End—Supercharger lubricating oil tank	4
49-3047-402	Filler Assembly—Supercharger lubricating oil tank	4
1-12965	Nut—Tank filler unit	4
1-17097-8	Cap Assembly—Tank filler	4
39B4232	Adapter Assembly—Fuel tank cap	4
41-9241-1	Name Plate—Tank cap	4
1-23594-1	Name Plate—Tank cap	4
55-6088-9	Tube—Supercharger lubricating oil system	1
55-6088-34	Tube—Supercharger lubricating oil system	1
55-6088-42	Tube—Supercharger lubricating oil system	1
55-6088-47	Tube—Supercharger lubricating oil system	1
55-6088-48	Tube—Supercharger lubricating oil system	1
55-6088-53	Tube—Drain—upper—supercharger lubricating oil system	1
55-6088-54	Tube—Drain—lower—supercharger lubricating oil system	1
55-6088-60	Tube—Vent—lower—supercharger lubricating oil system	1
55-6088-61	Tube—Vent—upper—supercharger lubricating oil system	1
55-6088-62	Tube—Vent—upper—supercharger lubricating oil system	1
55-6088-71	Tube—Drain—lower—supercharger lubricating oil system	1
55-6088-72	Tube—Drain—upper—supercharger lubricating oil system	1
55-6088-73	Tube—Vent—lower—supercharger lubricating oil system	1
55-6088-82	Tube—Supercharger lubricating oil system	1
55-6088-83	Tube—Supercharger lubricating oil system	1
55-6088-88	Tube—Supercharger lubricating oil system	1
55-6088-89	Tube—Supercharger lubricating oil system	1
55-6088-92	Tube—Supercharger lubricating oil system	1
55-6088-93	Tube—Supercharger lubricating oil system	1
55-6088-401	Tube—Return—supercharger lubricating oil system	1
55-6088-402	Tube—Inlet—supercharger lubricating oil system	2
55-6088-404	Tube—Inlet—supercharger lubricating oil system	2
55-6088-405	Tube—Supercharger lubricating oil system	4
55-6088-406	Tube—Return—supercharger lubricating oil system	2
55-6088-407	Tube—Return—supercharger lubricating oil system	1
55-6088-408	Tube—Supercharger lubricating oil system	1
55-6088-409	Tube—Supercharger lubricating oil system	1
55-6088-410	Tube—Supercharger lubricating oil system	1
55-6088-415	Tube—Drain—supercharger lubricating oil system	1
55-6088-416	Tube—Drain—supercharger lubricating oil system	1
55-6088-417	Tube—Vent—No. 3 tank—supercharger lubricating oil system	1
	(Parts List No. 345)	
55-6088-418	Tube—Vent—No. 2 tank—supercharger lubricating oil system	1
55-6088-419	Tube—Drain—supercharger lubricating oil system	1
55-6088-420	Tube—Drain—supercharger lubricating oil system	1
55-6088-421	Tube—Vent—No. 2 tank—supercharger lubricating oil system	1
55-6088-422	Tube—Vent—No. 2 tank—supercharger lubricating oil system	1
21-2589-7	Clip—Tab loop type	8
21-2589-16	Clip—Tab loop type	6
21-4585-42-12	Clamp—Tab square tube	8
21-4655	Clamp—Bonding	4
41-1065-5	Clamp Assembly—¾ wide barrel	1
41-1063-5-3	Clamp—Barrel type	1

Oil System Installation—Supercharger Lubrication

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-1065-21	Strap—Clamp—¾ wide barrel	1
41-1065-4	Clamp Assembly—¾ wide barrel	1
41-1063-4-3	Clamp—Barrel type	1
41-1065-22	Strap—Clamp—¾ wide barrel	1
41-468-70-16	Clamp—Square loop type	4
41-468-28-8	Clamp—Square loop type	4
21-6975-51	Angle—⅞ x ⅞ aluminum alloy	2
41-3034	Angle—Tubing support	6
41-9007	Angle Installation—Tube support	6
41-9007-1	Angle—Tube support	6
41-9100	Angle Installation—Tube support	1
41-9100-1	Angle—Tube support	1
21-7837-1	Washer—Square	1
21-4839-70	Jumper Assembly—No. 6-10 terminal bonding	2
21-4839-70A	Braid—Copper No. 6-10 terminal bonding jumper	2
BAC820-6	Terminal—Electrical lock	2
BAC820-10	Terminal—Electrical lock	2
21-4839-90	Jumper Assembly—No. 6-10 terminal bonding	2
21-4839-90A	Braid—Copper—No. 6-10 terminal bonding	2
BAC820-6	Terminal—Electrical lock	2
BAC820-10	Terminal—Electrical lock	2
BAC535-14	Clamp—Hose	52
BAC535-16	Clamp—Hose	10
BAC540-4	Clamp—Loop type cushioned	2
BAC540-8	Clamp—Loop type cushioned	39
BAC540-10	Clamp—Loop type cushioned	11
BAC1603-16	Spacer—No. 10 bolt	1
BAC1603-24	Spacer—No. 10 bolt	1
BAC1603-32	Spacer—No. 10 bolt	1
BAC1603-40	Spacer—No. 10 bolt	3
BAC1603-44	Spacer—No. 10 bolt	1
BAC1603-48	Spacer—No. 10 bolt	4

Tubing Installation—Supercharger Regulator

(Parts List No. 346)

75-6164	Tubing Installation—Supercharger regulator	1
75-6164-633	Insulator—Supercharger regulator tubing	1
75-6164-634	Insulator—Supercharger regulator tubing	1
65-6164-83	Insulator—Supercharger regulator tubing	4
65-6164-84	Lock Wire—Supercharger regulator tubing	4
41-1065-4	Clamp—¾ wide barrel	4
1-21087	Tee Assembly—Orifice	4
1-21087-1	Tee—Orifice	4
1-21087-2	Plug—Orifice tee	4
75-6164-635	Fitting Assembly—Supercharger regulator tubing.	6
75-6164-636	Fitting Assembly—Supercharger regulator tubing.	5
75-6164-637	Fitting Assembly—Supercharger regulator tubing.	4
1-21361	Hose—Elbow special	4
75-6164-638	Fitting Assembly—Supercharger regulator tubing.	1
1-23501	Clamp Assembly—Supercharger regulator tubing.	40
1-17019	Plate—Insulator tube reinforcing	80
1-23501-1	Clamp Assembly—Supercharger regulator tubing.	5
1-17019	Plate	10
1-23501-2	Clamp Assembly—Supercharger regulator tubing.	5
1-17019	Plate	10
BAC1247-10	Angle—Nut plate	2
BAC535-14	Clamp—Hose	32
BAC540-4	Clamp—Loop type cushioned	4
BAC540-8	Clamp—Loop type cushioned	4
75-6164-600	Tube—Supercharger regulator	1
75-6164-601	Tube—Supercharger regulator	1
75-6164-606	Tube—Supercharger regulator	1
75-6164-616	Tube—Supercharger regulator	1
75-6164-617	Tube—Supercharger regulator	1
75-6164-626	Tube—Supercharger regulator	1
75-6164-627	Tube—Supercharger regulator	1
75-6164-639	Tube—Supercharger regulator	1
75-6164-602	Tube Assembly—Supercharger regulator	1

AVIALOGS.COM

POWER PLANT INSTALLATION

Tubing Installation—Supercharger Regulator

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
75-6164-603	Tube Assembly—Supercharger regulator	1
75-6164-604	Tube Assembly—Supercharger regulator	1
75-6164-605	Tube Assembly—Supercharger regulator	1
75-6164-608	Tube Assembly—Supercharger regulator	1
75-6164-609	Tube Assembly—Supercharger regulator	1
75-6164-612	Tube Assembly—Supercharger regulator	4
75-6164-614	Tube Assembly—Supercharger regulator	1
75-6164-615	Tube Assembly—Supercharger regulator	1
75-6164-618	Tube Assembly—Supercharger regulator	1
75-6164-619	Tube Assembly—Supercharger regulator	1
75-6164-622	Tube Assembly—Supercharger regulator	1
75-6164-623	Tube Assembly—Supercharger regulator	1
75-6164-624	Tube Assembly—Supercharger regulator	2
75-6164-625	Tube Assembly—Supercharger regulator	2
75-6164-628	Tube Assembly—Supercharger regulator	1

Tubing Installation—Supercharger Regulator

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
75-6164-629	Tube Assembly—Supercharger regulator	1
75-6164-630	Tube Assembly—Supercharger regulator	1
65-6164-77	Tube Assembly—Supercharger regulator	1
65-6164-79	Tube Assembly—Supercharger regulator	1
65-6164-430	Tube Assembly—Supercharger regulator	1
	(Parts List No. 347)	
65-6164-431	Tube Assembly—Supercharger regulator	1
65-6164-515	Tube Assembly—Supercharger regulator	1
65-6164-516	Tube Assembly—Supercharger regulator	1
65-6164-517	Tube Assembly—Supercharger regulator	1
65-6164-518	Tube Assembly—Supercharger regulator	1
41-468-28-8	Clamp—Square loop type	2
41-468-70-16	Clamp—Square loop type	4

FINAL ASSEMBLY

Equipment Installation

(Parts List No. 348)

15-7311	Equipment Installation	1
55-7380	Board Installation—Pilot's and co-pilot's instruments (PL 373-375)	1
47-1501	Seat Installation—Pilot LH (PL 376-377)	1
47-1501-1	Seat Installation—Co-pilot RH (PL 376-377)	1
7-1502	Seat Installation—Bomber's (PL 378-379)	1
15-7386	Heating and Ventilating Installation (PL 380-389)	1
65-5715	Control Installation—Fire extinguisher system (PL 390)	1
65-5679	Fire Extinguisher Installation—Engine (PL 391-392)	1
65-5594	Tubing Installation—Vacuum system (PL 393-396)	1
15-7600	De-icer Installation—Wing and tail (PL 397-401)	1
75-5821	Hydraulic System Installation (PL 402-409)	1
65-5660	Anti-icer Installation—Propeller (PL 410-411)	1
64-1698	Raft Installation—Auto ejector (PL 412)	1
15-7365	Tubing Installation—Oxygen (PL 413-417)	1
6-9319	Lining Installation—Soundproof (PL 418-422)	1
74-1611	Panel Installation—Bomber's instrument	1
74-1611-500	Panel Assembly—Bomber's instrument	1
74-1611-502	Indicator—Air speed type D-7 (Government furnished)	1
74-1611-503	Altimeter—Bomber's instrument panel (Government furnished)	1
74-1611-504	Clock—Bomber's instrument panel (Government furnished)	1
74-1611-505	Indicator—Air temperature bomber's instrument panel (Government furnished)	1
74-1611-407	Lamp—Bomber's instrument panel (Government furnished)	1
66-7194	Panel Assembly—Bomber's instrument	1
66-7194-501	Bumper Assembly—Bomber's instrument panel	1
66-7194-503	Rubber—Bomber's instrument panel	1
21-9694	Name Plate—Bomb door indicator	1
41-5760-1	Name Plate—Bomb door indicator	1
074837	Holder—Correction card	1
36A2212-1	Nut—Flexible conduit ferrule coupling	1
39B2823-2	Lamp Assembly—Single contact signal	1
1-21494	Lamp Assembly—Single contact signal	1
39A3906-2	Lamp—Warning signal (Government furnished)	1
39B3334-1	Nut—Conduit coupling	1
64-1611-1	Rod—Bomber's instrument panel	1
34A1766-D2	Washer—Vibration absorber stop	8
33B5452-6	Absorber—Vibration	5
BAC1099-4B	Nut—Cap	1

Equipment Installation

(Parts List No. 349)

3-10565	Bracket—Bomber's instrument panel	2
3-10565-1	Bracket—Bomber's instrument panel	2
41-6810	Support—Shock mount	2
41-6809	Support—Shock mount	2
41-6813	Bolt—Eye ¼-28	1
3-10561	Bracket Assembly—Bomber's instrument board	2
40A6364	Card—50,000 foot altimeter scale (Government furnished)	1
BAC801-40	Jumper Assembly—Double terminal bonding	1
BAC820-6	Terminal—Electrical lock	2
59-1847	Panel Installation—Auxiliary control board	1
59-1847-501	Panel Assembly—Side auxiliary control board	1
56-4252	Plate Assembly—Auxiliary control board	1
56-4252-404	Door Assembly—Auxiliary control board plate	1
56-4252-402	Door—Auxiliary control board plate	1
56-4252-406	Door—Auxiliary control board plate	1
56-4252-500	Frame Assembly—Auxiliary control board plate	1
BAC1246-8S	Plate—Fiber nut	1
074837	Holder Assembly—Compass correction card	1
41-8363-1	Bus—Connector	1
21-7606	Guard—Switch toggle	2
59-1847-504	Panel Assembly—Rear auxiliary control board	1
59-1847-503	Panel Assembly—Auxiliary control board (Government furnished)	1
56-4251	Panel Assembly—Auxiliary control board	1
56-4251-500	Panel—Auxiliary control board	1
9-4645-29	Decalcomania—Engines 1, 2, 3 and 4	1
9-4645-30	Decalcomania—Push to dilute oil	1
21-7205	Guide—Control handle	1
21-2364-76-34	Washer—.064 aluminum alloy	1
BAC1249-108S	Plate—Fiber nut	1
41-6300	Plate—Starter switch	1
46-4253	Shield Assembly—Starter switch	1
46-4253-400	Shield Assembly—Starter switch	1
3-10390	Angle—Auxiliary panel support	1
74-1174	Panel Installation—Pilot's compass	1
74-1174-600	Panel Assembly—Pilot's compass	1
41-4283	Bracket—Compass board	1
074-837	Holder—card	1
74-1174-405	Lartex—Rubber pilot's compass panel	2
74-1174-7	Bracket Assembly—Pilot's compass	2
1-21964	Indicator—Thermometer (type C-11) (Government furnished)	1
1-23737	Compass—Pilot's type B-16 (use optional to 1-21911) (Government furnished)	1
1-21911	Compass—Pilot's type B-17 (use optional to 1-23737) (Government furnished)	1

AVIALOGS.COM

FINAL ASSEMBLY

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-21965	Clock—(Type A-9) (Government furnished)	1
21-9499	Support Assembly—Compass board	2
46-6538	Pan Assembly—Compass board	1
21-3894-56-11	Washer—Retaining	8
41-4192	Channel—Shock mount	1
	(Parts List No. 350)	
33B5452-1	Absorber—Vibration	4
33B5452-2	Absorber—Vibration	4
BAC801-26	Jumper Assembly—Double terminal bonding	1
BAC820-6	Terminal—Electrical lock	2
1-20321	Angle Assembly—Compass board	1
1-20321-1	Angle Assembly—Compass board	1
3-16443	Plate Installation—Ball turret	1
3-16443-1	Plate—Instruction ball turret (Government furnished)	1
BAC1447-4-6	Screw—Round head recessed—sheet metal	4
6-11986-5	Chart Installation—G. G. computing	1
1-26275	Placard—C. G. computing	1
9-5316	Chart—C. G. computing	1
55-7590	Tubing Installation—Pilot's instruments	1
	Dash number parts, shown on 55-7590 drawing are represented by dash numbers of 15-7590.	
15-7590-6	Manifold Assembly—Pilot's instruments tubing	1
3-13662	Fitting—Manifold	1
38A6133	Valve Assembly—Installation vacuum control	1
39G1030-414	Hose Assembly—Instrument flexible	1
39B3481-414	Hose Assembly—Instrument flexible	4
39B3481-1016	Hose Assembly—Instrument flexible	1
40B887-014C022-16	Gasket—Fluid seal metalic	1
39B846B4	Adapter—Hydraulic hose end	1
41-9773	Switch Assembly—Vacuum warning unit	1
15-7590-1	Tube—Pilot's instruments	1
15-7590-10	Tube—Pilot's instruments	1
15-7590-4	Tube—Pilot's instruments	1
15-7590-5	Tube—Pilot's instruments	1
15-7590-7	Tube—Pilot's instruments	1
15-7590-8	Tube—Pilot's instruments	1
15-7590-9	Tube—Pilot's instruments	1
55-7590-400	Tube—Pilot's instruments	1
55-7590-401	Tube—Pilot's instruments	1
BAC540-4	Clamp—Loop type cushioned	5
7-1503	Seat Installation—Radio operator	1
75-4133	Seat Assembly—Radio operator	1
75-4133-404	Tube—Radio operator's seat	2
75-4133-500	Bracket—Radio operator's seat	1
75-4133-505	Tube—Radio operator's seat	1
65-5280-506	Seat Assembly—Crew	1
1-21440	Angle—Seat reinforcing	1
3-14212	Angle—Seat reinforcing	1
BAC1603-35	Spacer—No. 10 bolt	4
56-5141	Shaft Assembly—Radio operator's seat	1
41-9961	Cap Assembly—Seat shaft	1
41-9961-1	Cap—Seat shaft	1
61-9846	Plunger—Seat adjustment	1
41-293	Spring—Compression	1
41-5899	Bell Crank—Crew seat	1
81-4547	Handle—Seat adjustment—casting 81-4547-1	1
BAC1608-10	Spacer—½ bolt	1
1-18050-12	Spacer—Wing and tail rib	2
	(Parts List No. 351)	
51-457	Guide—Control tube	2
3-8010-12	Post Assembly—Radio operator's seat	1
1-18399	Cap—Crew seat post	1
41-9963-1	Washer—Concave	1
21-9759	Collar—Radio operator's seat	1
34-G1646	Belt Assembly—(Type B-11) (Government furnished)	1
BAC54-S26A	Bolt—Close tolerance	1

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
074272	Cushion—Life preserver aircraft (type A-1)	1
AN7501	Cushion	1
7-1504	Seat Installation—Radio compartment auxiliary	1
75-4133-504	Seat Assembly—Radio operator's	1
75-4133-404	Tube—Radio operator's seat	2
75-4133-500	Bracket—Radio operator's seat	1
75-4133-505	Tube—Radio operator's seat	1
65-5280-506	Seat Assembly—Crew	1
1-21440	Angle—Seat reinforcing	1
3-14212	Angle—Seat reinforcing	1
BAC1603-35	Spacer—No. 10 bolt	4
56-5141-503	Shaft Assembly—Radio operator's seat	1
41-9961	Cap Assembly—Seat shaft	1
41-9961-1	Cap—Seat shaft (casting 3-11850)	1
61-9846	Plunger—Seat adjustment	1
41-293	Spring—Compression	1
41-5899	Bell Crank—Crew seat	1
81-4547	Handle—Seat adjustment (casting 81-4547-1)	1
BAC1608-10	Spacer—½ bolt	1
1-18050-12	Spacer—Wing and tail	2
51-457	Guide—Control tube	2
3-8010-13	Post Assembly—Radio operator's seat	1
1-18399	Cap—Crew seat post	1
41-9963-1	Washer—Concave	1
21-9759	Collar—Radio operator's seat	1
51-647	Stop Assembly—Seat	1
34G1646	Belt Assembly—(Type B-11) (Government furnished)	1
074272	Cushion—Life preserver aircraft(type A-1)	1
AN7501	Cushion	1
BAC54-S30A	Bolt—Close tolerance	1
7-1505	Seat Installation—Radio compartment auxiliary	1
75-4133-504	Seat Assembly—Radio operator's	1
75-4133-500	Bracket—Radio operator's seat	1
75-4133-404	Tube—Radio operator's seat	2
75-4133-505	Tube—Radio operator's seat	1
65-5280-506	Seat Assembly—Crew	1
1-21440	Angle—Seat reinforcing	1
3-14212	Angle—Seat reinforcing	1
BAC1603-35	Spacer—No. 10 bolt	4
56-5141-503	Shaft Assembly—Radio operator's seat	1
41-9961	Cap Assembly—Seat shaft	1
41-9961-1	Cap—Seat shaft	1
61-9846	Plunger—Seat adjusting	1
41-293	Spring—Compression	1
	(Parts List No. 351A)	
41-5899	Bell Crank—Crew seat	1
81-4547	Handle—Seat adjustment	1
BAC1608-10	Spacer—½ bolt	1
1-18050-12	Spacer—Wing and tail rib	2
	(Parts List No. 352)	
51-457	Guide—Control tube	2
3-8010-12	Post Assembly—Radio operator's seat	1
1-18399	Cap—Crew seat post	1
41-9963-1	Washer—Concave	1
51-847	Stop Assembly—Seat	1
21-9759	Collar—Radio operator's seat	1
34G1646	Belt Assembly—Type B-11 (Government furnished)	1
BAC114A41S	Bolt—Bearing	1
074272	Cushion—Life preserver aircraft type A-1	1
AN7501	Cushion	1
15-7337	Seat Installation—Rear gunner's	1
15-7337-1	Seat Assembly—Rear gunner's	1
15-7337-2	Seat—Plywood rear gunner's	1
15-7337-5	Channel Assembly—Rear gunner's seat	1
15-7337-17	Hinge—Rear gunner's seat	1
15-7337-8	Support Assembly—Rear gunner's seat	1

AVIALOGS.COM

FINAL ASSEMBLY

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7337-18	Hinge—Rear gunner's seat	1
15-7337-12	Channel Assembly—Rear gunner's seat	1
1-18784	Channel—Spring retainer	1
1-18787	Channel—Support	2
BAC1614-23	Spacer—⅛ rivet	1
1-18778	Strap Assembly—Rear gunner's seat	2
3-12984	Rod Assembly—Locking	1
3-12984-1	Rod—Locking	1
41-6756	Handle—Accessory door	1
1-18070	Rod Assembly—Locking	1
1-18070-1	Rod—Locking	1
41-6756	Handle—Accessory door	1
34G1646	Belt Assembly—Type B-11 (Government furnished)	1
1-18073	Spring—Compression	3
1-18981	Plate—Tail gunner's seat	1
1-18836	Rod—Locking	1
BAC1603-76	Spacer—No. 10 bolt	2
3-13733	Track Assembly—Rear gunner's seat	1
1-18071	Plate—Micarta	1
3-13733-1	Track Assembly—Rear gunner's seat	1
1-18071	Plate—Micarta	1
15-7337-14	Stop—Rear gunner's seat	2
15-6092	Cover Installation—Control cables	1
9-3622	Chair Installation—Navigator's	1
1-18332	Chair—Navigator's	1
1-18410	Rod—Anchor	1
1-18411	Strap Assembly—Navigator's	1
1-18411-1	Strap—Navigator's chair (Air Associates No. M-264)	1
1-18411-2	Tuck—Navigator's chair (Rusco No. D-611)	1
1-18411-3	Tip—Navigator's chair (Rusco No. SB-142)	1
1-18411-4	Buckle—Navigator's chair (Rusco No. 8464)	1
	(Parts List No. 353)	
15-7311-2	Board—Clip	1
1-21474	Hook	2
15-7334	Equipment Installation—Lavatory	1
15-7334-1	Toilet—Lavatory equipment (Imperial Brass Mfg. Co., No. M-1019)	1
15-7334-2	Holder—Lavatory equipment (Dayton Mfg. Co., No. 2)	1
15-7334-3	Cone—Lavatory equipment (Imperial Brass Mfg. Co., No. 43070-9)	12
15-7334-4	Bag—Lavatory equipment (Imperial Brass Mfg. Co., No. 43070-10)	12
65-5697	Table Installation—Navigator	1
65-5697-500	Frame Assembly—Navigator table	1
41-7587	Support—Shield	1
BAC1603-36	Spacer—No. 10 bolt	12
BAC1614-36	Spacer—⅛ rivet	4
65-5697-401	Bracket—Navigator's table	4
65-5697-501	Filler—Navigator's table	2
65-5697-506	Leg Assembly—Navigator's table	1
46-8521	Support Installation—Radio compartment indicator	1
6-8520	Door Assembly—Radio compartment indicator	1
6-8520-2	Door—Radio compartment indicator	1
6-8520-4	Hinge—Radio compartment indicator door	1
6-11308-2	Decalcomania—Indicator radio compass	1
43-12315	Support Assembly—Radio compass indicator	1
1-16127	Spring—Door	1
59-2719	Top Assembly—Navigator's table	1
33B5452-42	Absorber—Vibration	4
33B5452-43	Absorber—Vibration	4
34A1766-3	Washer—Vibration absorber stop	4
BAC1447-10-16	Screw—Round head recessed sheet metal	16
BAC1603-12	Spacer—No. 10 bolt	4
65-5697-19	Bracket—Navigator's table	1
65-5697-20	Filler—Navigator's table	1

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
55-3518	Table Installation—Radio	1
55-3518-409	Table Assembly—Radio	1
55-3518-410	Table Assembly—Glue—radio	1
6-5199	Drawer Installation—Radio table	1
6-5199-10	Frame Assembly—Radio table drawer	1
6-5199-11	Frame Assembly—Radio table drawer	1
6-5199-12	Drawer Assembly—Radio table	1
6-5199-5	End Assembly—Front radio table drawer	1
55-3518-405	Channel Assembly—Radio table	2
55-3518-407	Channel Assembly—Radio table	1
BAC1448-6-8	Screw—Oval head recessed sheet metal	19
55-3518-49	Fastener Assembly—Radio table	1
21-6744	Fastener—Inspection door	1
55-3518-35	Plate—Radio table	1
	(Parts List No. 354)	
55-3518-401	Linoleum—(Armstrong) radio table	1
BAC1603-28	Spacer—No. 10 bolt	4
BAC1603-44	Spacer—No. 10 bolt	2
55-3518-16	Channel Assembly—Radio table	2
BAC1613-33	Spacer—⅛ rivet	2
BAC1603-36	Spacer—No. 10 bolt	4
15-3518-19	Bracket Assembly—Radio table	1
BAC1614-45	Spacer—⅛ rivet	1
BAC1603-52	Spacer—No. 10 bolt	4
BAC1603-40	Spacer—No. 10 bolt	6
3-11163	Support Installation—Radio table	1
3-11163-3	Support Assembly—Radio table	3
3-11163-1	Bracket—Radio table support	1
1-16459-2	Fair-lead—Command antenna	1
1-17109	Plate Assembly—Insulator support	1
41-5746-2	Stud—Plate	1
BAC1447-8-10	Screw—Round head recessed sheet metal	2
BAC1447-8-16	Screw—Round head recessed sheet metal	2
55-3518-22	Tube—Radio table	1
49-2718-400	Platform Installation—Nacelle	2
55-5590	Platform Assembly—Nacelle	2
55-5590-34	Side Assembly—Nacelle platform LH	2
55-5590-35	Side Assembly—Nacelle platform RH	2
41-5988	Terminal—Nacelle platform	4
41-7970	Terminal—Nacelle platform	4
41-5987	Angle—Nacelle platform	4
41-4858	Washer—No. 10 flathead screw	40
1-21470	Loop—Footman	2
55-5590-5	Rubber—Nacelle platform	2
55-5590-407	Floor—Nacelle platform	2
55-5591	Brace Assembly—Nacelle platform	2
55-5591-400	Lock Assembly—Weld nacelle platform brace	2
55-5591-23	Plate—Nacelle platform brace	2
41-7776-5	Tube Assembly—Nacelle platform	2
41-7776-3	Pin—Nacelle platform tube	2
41-7776-4	Plug—Nacelle platform tube	2
41-7776-6	Tube—Nacelle platform tube	2
3-11909	Fitting—Nacelle platform	2
3-11909-1	Fitting—Nacelle platform	2
41-8181	Terminal—Platform brace	8
15-6252-24	Hanger Assembly—Nacelle platform	2
15-6252-3	Washer—Nacelle platform hanger	2
15-6252-12	Tube—Nacelle platform hanger	2
41-6068	Hook Assembly—Nacelle platform	2
41-6068-1	Hook	2
41-6068-2	Handle	2
3-6738-9	Bolt Assembly—Self-locking	2
3-6738-11	Bolt Assembly—Self-locking	8
3-6738-3	Spring—Self-locking bolt	10
3-6738-10	Bolt—Self-locking (used on -9)	2
	(Parts List No. 355)	
3-6738-12	Bolt—Self-locking (used on -11)	8
3-6738-17	Ring—Self-locking bolt (Pacific Marine Apex No. 9)	10

AVIALOGS.COM

FINAL ASSEMBLY

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-8156	Terminal—Nacelle hangar	4
51-179	Hook—Nacelle hangar	2
BAC1603-40	Spacer—No. 10 bolt	2
41-8603	Spring—Torsion	2
BAC1614-40	Spacer—⅛ rivet	8
55-5932	Ladder Assembly—Nacelle and front entrance	1
55-5932-402	Frame Assembly—Nacelle and front entrance ladder	1
55-5932-405	Leg Assembly—Nacelle and front entrance ladder LH	1
55-5932-403	Tube—Nacelle and front entrance ladder	1
55-5932-5	Block—Nacelle and front entrance ladder	1
41-8193	Plate—Ladder hinge	2
55-5932-406	Leg Assembly—Nacelle and front entrance ladder RH	1
55-5932-404	Tube—Nacelle and front entrance ladder	1
55-5932-5	Block—Nacelle and front entrance ladder	1
41-8193	Plate—Ladder hinge	2
55-5932-401	Step Assembly—Nacelle and front entrance ladder	5
41-9654	Angle—Step support	20
55-5932-400	Tube—Nacelle and front entrance ladder	5
55-5932-8	Tread—Nacelle and front entrance ladder tube (Goodrich)	5
55-5932-10	Leg Assembly—Nacelle and front entrance ladder LH	1
55-5932-11	Leg Assembly—Nacelle and front entrance ladder RH	1
55-5932-12	Tube—Nacelle and front entrance ladder	2
55-5932-22	Eyebolt—Special nacelle and front entrance ladder	2
55-5932-23	Eyebolt—Special nacelle and front entrance ladder	4
81-7969	Terminal—Nacelle ladder	2
81-8194	Fitting—Ladder hinge	2
BAC1603-41	Spacer—No. 10 bolt	4
37B3822-6B	Rivnut—Threaded	4
81-7968	Link—Nacelle ladder	2
55-5932-14	Strut Assembly—Nacelle and front entrance ladder	1
55-5932-15	Tube—Nacelle and front entrance ladder	1
55-5932-16	Plug—Nacelle and front entrance ladder	1
55-5932-17	Plug—Nacelle and front entrance ladder	1
55-5932-18	Strut Assembly—Nacelle and front entrance ladder	1
55-5932-16	Plug—Nacelle and front entrance ladder	1
55-5932-19	Tube—Nacelle and front entrance ladder	1
55-5932-13	Block—Nacelle and front entrance ladder tube	1
BAC1603-38	Spacer—No. 10 bolt	3
BAC1808-53-0	Cable Assembly—3/32-7 x 7 control	2
BAC1808-56-2	Cable Assembly—5/32-7 x 7 control	2
BAC1825-3	Swaged Terminal—Class "C"	8
1-22707-12	Strap Assembly—Buckle ¾" wide (Sturges Mfg Co.) No. 1275	2
BAC1603-41	Spacer—No. 10 bolt	2

(Parts List No. 356)

51-800	Plug—Ladder	4
55-5932-22	Eyebolt—Special nacelle and front entrance ladder	2
15-7545	Locker Installation—Bombsight and navigation instrument	1
15-7545-1	Locker Assembly—Bombsight and navigation instrument	1
15-7545-18	Leg Assembly—Bombsight and navigation instrument	1
15-7545-21	Leg Assembly—Bombsight and navigation instrument	1
1-18072	Angle—Attachment	2
41-9739	Cap—Locker	1
BAC1447-6-6	Screw—Round-head recessed sheet metal	8

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1447-6-10	Screw—Round-head recessed sheet metal	2
BAC1447-8-10	Screw—Round-head recessed sheet metal	3
BAC1449-6-4	Screw—Flathead recessed sheet metal	2
BAC1449-6-6	Screw—Flathead recessed sheet metal	8
15-7545-2	Plywood—Spruce bomb sight and navigation instrument locker	1
15-7545-3	Tri-Cleats—Bomb sight and navigation instrument locker	1
15-7545-4	Blocks—Bomb sight and navigation instrument locker	1
15-7545-5	Blocks—Bomb sight and navigation instrument locker	1
15-7545-6	Blocks—Bomb sight and navigation instrument locker	1
15-7545-7	Blocks—Bomb sight and navigation instrument locker	1
15-7545-9	Blocks—Bomb sight and navigation instrument locker	1
15-7545-10	Blocks—Bomb sight and navigation instrument locker	3
15-7545-11	Pad—Felt bomb sight and navigation instrument locker (booth No. 61)	1
15-7545-12	Latch—Bomb sight and navigation instrument locker (Dayton Mfg. Co. No. 44)	1
15-7545-13	Strike—Bomb sight and navigation instrument locker (Dayton Mfg. Co. No. 44)	1
15-7545-14	Hasp—Bomb sight and navigation instrument locker (Seattle Hardware Co. No. B830)	1
15-7545-15	Pad—Bomb sight and navigation instrument locker (booth No. 61)	1
15-7545-16	Pad—Bomb sight and navigation instrument locker (booth No. 61)	1
15-7545-17	Kapok—Bomb sight and navigation instrument locker (Kapok Felters Co.)	1
15-7545-24	Padlock—Bomb sight and navigation instrument locker (Yale Lock Co.)	1
15-7545-26	Block—Bomb sight and navigation instrument locker	1
15-7545-27	Block—Bomb sight and navigation instrument locker	1
15-7545-28	Block—Bomb sight and navigation instrument locker	1
BAC1603-8	Spacer—No. 10 bolt	4
BAC1449-6-10	Screw—Flathead recessed sheet metal	4
15-7545-25	Key—Bomb sight and navigation instrument locker (Yale Lock Co.)	2
BAC1449-6-10	Screw—Flathead recessed sheet metal	4
9-3756	Guard Installation—Heating duct	1
9-3756-2	Guard Assembly—Heating duct	1
3-14073	Cover—Bomber's instrument board	1
6-8988	Support Installation—Starter extension	1
6-8988-1	Bracket Assembly—Starter extension	1
41-7942	Cover—Crank extension tube	1
41-7943	Tube Assembly—Crank extension	1

(Parts List No. 357)

1-3302-28	Clamp—Round tube deep	2
41-7944	Spring—Compression	1
41-7946	Disk—Crank extension	1
1-18342	Plate—Name	1
BAC1601-16	Spacer—No. 6 machine screw	4
3-12408	Extension Assembly—Starter crank	1
1-16423	Sleeve—Crank extension	1
36A6215-1	Sleeve—Starter crank extension shaft	1
41-7945	Cup Assembly—Crank extension	1
41-7945-4	Felt—Crank extension cup	1
41-7945-5	Felt—Crank extension cup	1
BAC1602-18	Spacer—No. 8 machine screw	1
BAC1603-18	Spacer—No. 10 bolt	6
43-9073	Support Installation—Ash tray	1

AVIALOGS.COM

FINAL ASSEMBLY

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
43-9073-400	Box Assembly—Ash tray support	1
43-9073-2	Box—Ash tray support—weld	1
43-9073-4	Ash Tray—Support (Ford Model 1936)	1
BAC1603-46	Spacer—No. 10 bolt	2
BAC1603-48	Spacer—No. 10 bolt	2
14-1692-9	Support Installation—Handcrank and extension	1
14-1692-1	Clip Assembly—Handcrank and extension support	2
BAC1603-12	Spacer—No. 10 bolt	8
14-1692-4	Clip Assembly—Hand crank and extension support	2
21-9586	Extension—Crank	1
41-7945	Cup Assembly—Crank extension	1
41-7945-4	Felt—Crank extension cup	1
41-7945-5	Felt—Crank extension cup	1
41-7943-4	Tube Assembly—Crank extension cup	1
1-13302-28	Clamp—Round tube deep	2
41-7946	Disk—Crank extension	1
41-7944	Spring—Compression	1
41-7942	Cover—Crank extension tube	1
14-1692-7	Block—Micarta	1
14-1692-8	Block—Micarta	1
BAC1603-16	Spacer—No. 10 bolt	8
BAC1601-16	Spacer—No. 6 machine screw	8
1-18119	Plate—Name	1
41-7948	Plate—Name	1
BAC1603-18	Spacer—No. 10 bolt	8
BAC1602-18	Spacer—No. 8 machine screw	4
6-5493-26	Frame Assembly—Diagram	1
6-5493-4	Cardboard—Diagram frame	1
6-5493-22	Frame—Diagram	1
6-5493-23	Plastacelle—Diagram frame	1
6-5493-25	Photo—Diagram Frame	1
6-8943	Cushion Assembly—Rear gunner	1
6-8943-1	Cover—Rear gunner cushion	1
6-8943-2	Cover—Rear gunner cushion	1
6-8943-3	Cushion—Rear gunner	1
	(Parts List No. 358)	
6-8943-4	Tab—Rear gunner cushion	2
6-8943-5	Tab—Rear gunner cushion	1
6-8943-6	Tab—Rear gunner cushion	1
6-9210	Pad Assembly—Rear gun	1
6-9210-2	Cushion—Rear gunner's pad	3
6-9210-3	Tab—Rear gunner pad	6
6-9210-4	Cover—Rear gunne pad	1
6-9210-5	Cover—Rear gunner pad	1
6-9483	Cable Assembly—Tail hoist	1
11-BS-12	Cable—(American Chain & Cable Co., Adrian, Mich.)	2
46-5302	Container Installation—First aid kit	1
46-5302-1	Container—First aid kit	1
6-9236	Strap Installation—Shutter coil	1
6-9236-1	Strap Assembly—Shutter coil	2
6-9236-5	Strap—Shutter coil (Russel Mfg. Co., Middleton, Conn.)	2
6407	Loop—Footman	2
6-9236-3	Strap Assembly—Shutter coil	2
6-9236-4	Strap—Shutter coil (Russel Mfg. Co., No. 8464)	2
365	Buckle—Shutter coil (North & Judd Mfg. Co., New Britian, Conn.)	2
6407	Loop—Footman	2
3-7194-7	Rope Assembly—Guard rail	2
3-7194-6	Harness—Guard rail rope (No. 50, Seattle Hardware)	4
3-7194-9	Rope—Guard rail	2
3-7194-11	Cover—Guard rail rope	4
3-7194-10	Rope Assembly—Guard rail	2
3-7194-8	Rope—Guard rail	2

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-7194-6	Harness—Guard rail rope (No. 50, Seattle Hardware)	4
3-7194-11	Cover—Guard rail rope	4
43-11383	Ash Tray Installation—Navigator's	1
68-701600A	Tray—Ash navigator's (Ford Model 1936, Ford Motor Car Co., Detroit, Mich., replaces -2)	1
43-11383-400	Cover Assembly—Navigator's ash tray	1
3-11260	Cover—Ash tray	1
BAC1601-36	Spacer—No. 6 machine screw	2
3-11389	Ash Tray Installation—Bombers	1
3-11389-1	Tray—Ash bombers (Ford Model 1936)	1
6-8821	Cover Assembly—Walkway LH	1
6-8821-1	Cover Assembly—Walkway RH	1
6-8821-2	Cover—Walkway LH	1
6-8821-3	Cover—Walkway RH	1
6-8821-4	Strap—Walkway cover	4
6-8821-5	Cord—Walkway cover	4
1-17101	Hook—Walkway attachment	4
	(Parts List No. 359)	
1-17104	Hook Assembly—Walkway attachment rear	2
1-17104-1	Hook Assembly—Walkway attachment rear	2
55-5970	Cover Installation—Flight control	1
55-5970-1	Cover Assembly—Flight control	1
55-5970-24	Fastener—Talon	1
55-5970-25	Padlock—Talon fastener (Corbin No. 0900-½)	1
55-5970-404	Cover Assembly—Talon fastener	1
55-5970-405	Cover Assembly—Talon fastener	1
55-5970-406	Cover Assembly—Talon fastener	1
55-5970-16	Support Assembly—Talon fastener	1
BAC1249-110S	Plate—Fiber nut	1
14-1683	Door Installation—Bomb control	1
14-1683-1	Door Assembly—Bomb control	1
14-1683-16	Panel Assembly—Bomb control	1
1-7987	Knob—Hand wheel	2
41-353-15-21	Pin—Door catch	2
BAC1614-26	Spacer—⅛ rivet	2
41-3232	Spring—Snap fastener	2
9-4901	Cover Installation—Tail turret	1
9-4901-1	Cover Assembly—Tail turret	1
BAC1303	Washer—Cinch fastener	12
BAC1305	Fastener—Cinch	12
15-9009	Cover Installation—Spherical turret	1
15-9009-1	Cover Assembly—Spherical turret	1
15-9009-2	Cover—Spherical turret	3
15-9009-3	Cover—Spherical turret	1
15-9009-4	Collar—Spherical turret cover	1
15-9009-5	Sleeve—Spherical turret cover	1
15-9009-6	Sleeve—Spherical turret cover	1
15-9009-7	Collar—Spherical turret cover	2
15-9009-8	Cover—Spherical turret cover	1
BAC1303	Washer—Cinch fastener	18
BAC1305	Fastener—Fabric cinch	18
15-9268	Cover Installation—Pilot's enclosure	1
15-9268-1	Cover Assembly—Pilot's enclosure	1
15-9268-2	Segment—Pilot's enclosure cover	1
15-9268-3	Segment—Pilot's enclosure cover	1
15-9268-4	Segment—Pilot's enclosure cover	1
15-9268-5	Segment—Pilot's enclosure cover	1
15-9268-6	Segment—Pilot's enclosure cover	1
15-9268-7	Segment—Pilot's enclosure cover	1
15-9268-8	Segment—Pilot's enclosure cover	1
15-9268-9	Segment—Pilot's enclosure cover	1
15-9268-10	Segment—Pilot's enclosure cover	1
15-9268-11	Segment—Pilot's enclosure cover	1
15-9268-12	Band—Pilot's enclosure cover	1
15-9268-13	Segment—Pilot's enclosure cover	1
	(Parts List No. 360)	
3-16145	Strap Assembly—Cover	2
1-24929	Hook—Strap	1

AVIALOGS.COM

FINAL ASSEMBLY

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-16145-1	Webbing—Strap (Russel Mfg. Co., Middletown, Conn., Catalogue No. 1400 or equivalent)	1
3-16145-2	Webbing—Strap (Russel Mfg. Co., Middletown, Conn., Catalogue No. 1400 or equivalent)	1
3-16145-3	Buckle—Strap (North & Judd Mfg. Co., New Britain, Conn., Catalogue No. 89, Item No. 635)	1
15-6092	Cover Instrument—Control cable	1
15-6092-1	Angle Assembly—Control cable cover	1
21-7838	Washer—No. 10 square	1
15-6092-4	Angle Assembly—Control cable cover	1
15-6092-9	Cover Assembly—Control cable	1
15-6092-13	Cover Assembly—Control cable	1
15-6092-17	Cover Assembly—Control cable	1
15-6092-21	Cover Assembly—Control cable	1
15-6092-27	Cover Assembly—Control cable	1
15-6092-25	Angle Assembly—Control cable cover	1
51-627-40-24	Strip—1/16 fiber	1
15-7628	Cover Instrument—Bomb control	1
15-7628-1	Cover Assembly—Bomb control	1
6-10683	Bracket—Driftmeter valve	1
15-7628-5	Channel Assembly—Bomb control	1
15-7628-13	Channel Assembly—Bomb control cover	1
15-5923-22	Cover Instrument—Bomb controls	1
15-5923-10	Cover—Bomb controls	1
15-5923-28	Plate Assembly—Bomb controls cover	1
15-5923-8	Channel Assembly—Bomb controls cover	1
15-5923-20	Cover Assembly—Bomb controls	1
BAC1249-110S	Plate—Fiber nut	3
15-5923-11	Angle Assembly—Bomb controls cover	1
15-5923-13	Angle Assembly—Bomb controls cover	1
BAC1246-10S	Plate—Fiber nut	1
15-5923-15	Channel Assembly—Bomb controls cover	1
15-5923-17	Cover Assembly—Bomb controls	1
BAC1249-110S	Plate—Fiber nut	1
	(Parts List No. 361)	
15-5923-26	Panel Assembly—Bomb controls cover	1
41-7591-4	Angle Assembly—Navigator's floor	4
21-3147-1	Washer—.019 steel (corrosive resistant)	10
1-17500-67	Angle—Support	9
3-12910	Bracket—Cover support	2
3-12910-1	Bracket—Cover support	1
3-12910-2	Bracket—Cover support	1
3-12910-3	Bracket—Cover support	1
BAC1246-10S	Plate—Fiber nut	1
15-5937-16	Cover Installation—Bomb control	1
15-5937-1	Cover Assembly—Bomb control	1
15-5937-19	Fair-lead—Bomb control cover	1
15-5937-2	Angle Assembly—Bomb control cover	1
15-5937-10	Angle Assembly—Bomb control cover	1
15-5937-14	Angle Assembly—Bomb control cover	1
15-5937-20	Angle Assembly—Bomb control cover	1
9-3187	Cover Installation—Bomb control	1
9-3187-1	Cover Assembly—Bomb control	1
41-8757	Plate—Instruction	1
9-3187-4	Cover Assembly—Bomb control	1
9-3187-3	Cover—Bomb control	1
14-1681	Boot Installation—Control column LH	1
14-1681-1	Boot Installation—Control column RH	1
14-1681-2	Boot Assembly—Control column LH	1
14-1681-3	Boot Assembly—Control column RH	1
14-1681-4	Leather—Control column boot LH	1
14-1681-5	Leather—Control column boot RH	1
41-7198	Clamp—Control column boot LH	1
41-1351	Clamp—Control column boot RH	1
9-2941	Box Installation—Bomb data card	1
9-2941-13	Box Assembly—Bomb data card	1

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
9-2941-5	Window—Bomb data card box	1
9-2941-6	Bracket—Bomb data card box	2
5-2941-7	Bracket—Bomb data card box	1
5-2941-8	Bracket—Bomb data card box	1
41-8479	Spring—Catch	2
BAC1447-4-4	Screw—Roundhead recessed sheet metal	12
6-9399	Chart Installation—Bomb	1
6-9399-2	Plate Assembly—Bomb chart	1
6-9399-10	Chart—Bomb	1
46-6502	Box Assembly—Map case (bomber's)	1
46-6502-5	Pocket Assembly—Map case (bomber's)	1
46-6502-401	Box Assembly—Weld map case (bomber's)	1
46-6502-402	Hinge—Continuous	2
46-6502-403	Hinge—Continuous	2
41-6060-8	Catch—Friction spring	1
	(Parts List No. 362)	
6-7722-9	Case Assembly—Navigator's map	1
6-7722-2	Door—Navigator's map case	1
6-7722-3	Door—Navigator's map case	1
41-158	Retainer—Interphone jack	2
41-159	Stop—Interphone jack	1
41-6060-8	Catch—Friction spring	2
46-5305	Rack Installation—Radio table	1
	Dash number parts, shown on 46-5305 drawing are represented by dash numbers of 6-5305.	
46-6502-3	Door—Bomber's map case box	1
6-5305-9	Rack Assembly—Radio table	1
1-20055	Plate—Radio call	1
BAC-1603-40	Spacer—No. 10 bolt	4
3-14947	Dispenser Installation—Paper drinking cup	1
39D3339	Dispenser—Paper drinking cup	1
BAC1447-8-14	Screw—Roundhead recessed sheet metal	2
3-13949	Dispenser Installation—Paper drinking cup	1
39D3339	Dispenser—Paper drinking cup	1
15-7583	Mast Installation—Pitot static	1
15-7583-1	Mast Assembly—Pitot static	2
15-7583-2	Block—Pitot static mast	2
15-7583-3	Mast—Pitot static	2
15-7583-4	Head—Pitot static mast (Government furnished)	2
15-7583-5	Tube—Pitot static mast	2
15-7583-6	Tube—Pitot static mast	2
15-7583-7	Hose—Pitot static mast	4
6-9364	Drift Meter and Compass Installation	1
6-9364-1	Drift Meter—Compass (Government furnished)	1
6-9364-2	Compass—Drift meter (Government furnished)	1
1-18166	Plug Assembly—Electrical connection	1
37A5158	Plug—Housing connection	1
37A5159	Cap—Connection plug	1
37A5160	Pin—Connection plug	1
37A5161	Washer—Connection plug	1
37A5162	Spacer—Connection plug	1
15-7627	Support Assembly—Drift meter and compass	1
15-7627-1	Bracket Assembly—Drift meter and compass	1
1-18727	Angle—Lining support	4
15-7627-3	Cylinder and Brace Assembly—Drift meter and compass support	1
15-7627-12	Cylinder Assembly—Drift meter and compass support	1
15-7627-7	Cylinder—Drift meter and compass support	1
074837	Holder Assembly—Compass correction card (type A-1)	1
15-7627-11	Mount Assembly—Drift meter and compass support	1
81-7801	Fitting—Drift meter	4
21-4844-30	Jumper Assembly—No. 10-10 terminal bonding	1
BAC820-10	Terminal—Electrical lock	2

AVIALOGS.COM

FINAL ASSEMBLY

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 363)	
33B5452-8	Absorber—Vibration	8
34A1766-D2	Washer—Vibration absorber	8
53-12153-500	Chart Instrument—Fuse location	1
53-12153-2	Plastacelle—Fuse location chart	1
53-12153-3	Cardboard—Fuse location chart	1
53-12153-4	Plate—Fuse location chart	1
53-12153-502	Photo—Fuse location chart	1
41-9399-2	Frame—License	1
6-10662	Chart Instrument—Loading	1
6-10662-1	Chart—Loading	1
46-8116	Tube Instrument—Emergency relief	1
33A4739	Horn—Pilot's relief tube	1
46-8116-3	Tube—Emergency relief	1
51-642	Bracket—Urinal support	1
46-8116-400	Tube—Emergency relief	1
46-8116-401	Tube—Emergency relief	1
21-2589-23	Clip—Tab loop type	6
31-1177-3	Nut—Conduit clamp	2
33A2431-3	Union—Conduit	1
9-3276	Pump Assembly—Refueling	1
9-3276-1	Bracket—Refueling pump	1
9-3276-2	Block—Micarta refueling pump	1
9-3276-3	Clamp Assembly—Refueling pump	1
9-3276-5	Clamp Assembly—Refueling pump	1
38G3046	Pump—Fuel transmission (Type D-7) (Government furnished)	1
BAC1605-20	Spacer—$^{5}/_{16}$ bolt	4
46-9242	Stowage Instrument—Oil gage	1
1-18613	Fastener—Oil gage	2
6-9242-2	Pad—Oil gage stowage	1
9-5204-16	Decalcomania	1
1-18139	Knob Assembly—Oil lock	1
1-18139-1	Rod—Oil lock knob	1
1-18139-2	Knob—Oil lock knob	1
69-2423	Heater Assembly—Glycol system	1
69-2423-605	Cylinder—Glycol heater	1
69-2423-601	Spindle—Glycol heater (Casting 1-20045)	1
69-2423-602	Pin—Glycol heater	1
69-2423-603	Cap—Glycol heater	1
69-2423-604	Washer—Glycol heater	1
6-7924-17	Jack Assembly—Outboard motor	2
6-7924-19	Spacer—Outboard motor jack	4
6-7924-1	Tube Assembly—Outboard motor jack	2
6-7924-2	Tube—Outboard motor jack	2
6-7924-18	Clamp—Outboard motor jack	2
6-7924-21	Pin Assembly—Outboard motor jack	2
6-7924-3	Chain—Outboard motor jack	2
	(Parts List No. 364)	
6-7924-4	Pin—Outboard motor jack	2
6-7924-20	Rod—Outboard motor jack	2
6-7924-5	Tube Assembly—Outboard motor jack	2
6-7924-9	Tube—Outboard motor jack	2
6-7924-6	Bolt Assembly—Outboard motor jack	2
6-7924-7	Bolt—Outboard motor jack	2
6-7924-8	Washer—Outboard motor jack	2
6-7924-10	Tube Assembly—Outboard motor jack	2
6-7924-11	Tube—Outboard motor jack	2
6-7924-12	Plug—Outboard motor jack	2
335-16	Nut	2
6-7924-14	Shoe Assembly—Outboard motor jack	2
6-7924-15	Shoe—Outboard motor jack (Mine Safety Appliance Co., Pittsburg, Pa.)	2
6-7924-16	Plate—Outboard motor jack	4
6-7924-25	Base Assembly—Outboard motor jack	2
6-7924-14	Shoe Assembly—Weld	2
6-7924-15	Shoe—Outboard motor jack (Mine Safety Appliance Co., Pittsburg, Pa.)	2
6-7924-16	Plate—Outboard motor jack	4

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-16938	Base	2
BAC1447-10-10	Screw—R. H. recessed sheet metal	4
41-8816-1	Socket—Motor jack	2
14-1686	Cover Assembly—Engine	4
14-1686-1	Cover—Engine	4
14-1686-2	Cord—Engine cover	16
14-1686-3	Cord—Engine cover	8
0153316-10	Plate—Name and data	1
0161366	Holder—Airplane flight report (Type A-2)	1
30-1334	Belt Assembly—Safety (Type A-31) (Government furnished)	1
31-1310	Mount Assembly—Camera (Type A-8) (Government furnished)	1
34B2278	Camera Assembly—(Type K-3B) (Government furnished)	1
34B3842	Filter Unit—Lens (Type A-2A) (Government furnished)	1
39D3922	Holder Assembly—Check list (Government furnished)	1
41G8920	Holder Assembly—Pyrot pistol (Type A-1) (Government furnished)	1
41G9233	Container Assembly—Signal flare (Type A-1) (Government furnished)	1
073392	Finder Assembly—Vert view (Type A-2) (Government furnished)	1
51-1197	Spring—Clipboard support	2
BAC1447-6-12	Screw—RH recessed sheet metal	16
BAC1447-6-24	Screw—RH recessed sheet metal	4
BAC1447-6-10	Screw—RH recessed sheet metal	8
BAC1601-16	Spacer—No. 6 machine screw	4
BAC1601-40	Spacer—No. 6 machine screw	4
48-1190	Bar Assembly—Tail wheel towing (Quantity—1 for each 5 planes)	
48-1190-404	Tube Assembly—Tail wheel towing	1 for 5
48-1190-410	Tube Assembly—Tail wheel towing	1 for 5
48-1190-411	Tube Assembly—Tail wheel towing bar	1 for 5
15-7311-17	Tool Assembly—Special equipment	1
15-7311-1	Wrench—Equipment (Cleveland Pneumatic Tool Co. No. EQ634A)	1
	(Parts List No. 364A)	
15-7311-25	Kit—Equipment (Government furnished)	4
1-21923	Wrench Assembly—Accumulator (Vickers Incorporated, Detroit, Mich., No. 63273)	1
1-21923-1	Wrench Assembly—Accumulator (Vickers Incorporated, Detroit, Mich., No. 63272)	1
3-13680	Wrench Assembly—Retract gear housing cap	1
3-13680-1	Spanner—Retract gear housing cap wrench	1
	(Parts List No. 365)	
3-13680-3	Pin—Retractor gear housing cap wrench	2
3-13734	Wrench—Filler neck	1
41-1243-3	Wrench Assembly—Wheel hub nut	1
41-1243-1	Wrench—Wheel hub nut	1
41-1243-2	Pin—Wheel hub nut	1
41-9207	Wrench Assembly—Regular packing holder	1
41-9207-1	Tube—Regular packing holder wrench	1
41-9207-2	Handle—Regular packing holder wrench	1
41-1254	Wrench—Landing gear oleo	1
3-13709	Wrench Assembly—Tail wheel oleo	1
3-13709-1	Pin—Tail wheel oleo wrench	1
3-13709-2	Hook—Tail wheel oleo wrench	1
3-13709-3	Handle—Tail wheel oleo wrench	1
41-1501	Kit Assembly—Special tool	1
1-16750	Bleeder Assembly—Hydromatic accumulator	1
1-16750-1	Pin—Hydromatic accumulator bleeder	1
1-16750-2	Washer—Hydromatic accumulator bleeder	1
1-16750-3	Tube Assembly—Hydromatic accumulator bleeder	1
1-21026	Wrench—Generator	1

AVIALOGS.COM

FINAL ASSEMBLY

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-19825	Wrench—Wing joint	2
15-7311-3	Flight Report—Equipment form No. 1 (Government furnished)	1
15-7311-5	Case Assembly—Equipment navigator's type A-4 (Government furnished)	1
15-7311-6	Computer—Equipment (Government furnished)	1
15-7311-22	Kit—Equipment	2
15-7311-23	Key—Equipment	2 for each 13 planes
15-7311-24	Key—Equipment	2
15-7311-27	Handbook—Equipment	1
15-7311-28	Signal—Equipment (Government furnished)	1
15-7311-29	Signal—Equipment	9
15-7311-31	List—Check—equipment	2
55-5835	Support Installation—Bomb control and computer	1
55-5835-400	Support Assembly—Bomb control and computer	1
3-10995	Channel Assembly—Shock support	2
41-6746	Terminal—Leg	1
41-7580	Angle—Flanged	1
41-7588	Channel—Shock support	1
41-7844	Angle—Support	4
41-7844-1	Angle—Support	4
54-1688	Crank Installation—Bomb controls	1
54-1688-400	Crank Assembly—Bomb controls	1
54-1688-401	Bracket Assembly—Bomb control crank	1
BAC1603-42	Spacer—No. 10 bolt	2
3-12090-1	Crank Assembly—Control	1
3-12089-40-40	Crank—Control	1
BAC450-4	Bearing—Ball control	1
BAC1604-25	Spacer—¼ bolt	1
BAC1604-77	Spacer—¼ bolt	1
BAC1603-33	Spacer—No. 10 bolt	2
BAC1603-33	Spacer—No. 10 bolt	4
BAC1614-35	Spacer—⅛ rivet	2
BAC1615-31	Spacer—5/32 rivet	2
BAC1615-33	Spacer—5/32 rivet	4
	(Parts List No. 366)	
BAC1615-36	Spacer—5/32 rivet	1
BAC1615-35	Spacer—5/32 rivet	4
9-2869	Box Assembly—Computer	1
41-7712	Channel—Shock mount	1
41-7509	Channel—Support	1
46-7682	Support Installation—Leg	1
46-7682-400	Tube Assembly—Leg. support	1
BAC1249-110S	Plate—Fiber nut	2
BAC1614-30	Spacer—⅛ rivet	2
BAC1603-31	Spacer—No. 10 bolt	1
BAC1603-36	Spacer—No. 10 bolt	1
BAC1603-40	Spacer—No. 10 bolt	1
33B5452-6	Absorber—Vibration	4
33B5452-9	Absorber—Vibration	2
34A1766-2	Washer—Vibration absorber stop	6
BAC1603-8	Spacer—No. 10 bolt	4
BAC1614-31	Spacer—⅛ rivet	11
BAC1615-35	Spacer—5/32 rivet	4
BAC1614-35	Spacer—⅛ rivet	8
55-5835-16	Spacer—Bomb control and computer support	1
55-5835-17	Bracket—Bomb control and computer support	1
15-7311-8	Bottle—Thermos Stanley (No. 71085)	2
15-7311-9	Crank Assembly—Hand (Government furnished)	2
15-7311-10	Camera Assembly—(5 lens) (Government furnished)	1
15-7311-16	Camera Assembly—Type K-7C (Government furnished)	1
15-7311-11	Mount—Camera (Government furnished)	1
15-7311-13	Intervalometer—(Government furnished)	1
15-7311-14	Coil—Shutter induction (Government furnished)	1
15-7311-15	Magazine—Extra type A-1A (Government furnished)	1
9-3656	Extinguisher Installation—Fire	1

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-15126	Extinguisher—Fire (type A-17) (Government furnished)	1
49-3654	Extinguisher Installation—Fire bulkhead—No. 5	1
Spec. 40304	Extinguisher—Fire CO_2 (type A-17) (Government furnished) replaces 3-15126	1
BAC1603-40	Spacer—No. 10 bolt	3
6-9207	Extinguisher Installation—Fire bulkhead No. 7	1
1-21497	Extinguisher—Fire (type A-2) (Government furnished)	1
15-8786	Extinguisher Installation—Fire	1
15-8786-1	Channel Assembly—Fire extinguisher	1
15-8786-4	Channel Assembly—Fire extinguisher	1
3-15126	Extinguisher and Bracket—CO_2 type A-17 (Government furnished)	1
1-21497	Extinguisher—Fire (type A-2) (Government furnished)	1
15-7311-18	Filter—Equipment type A-4 (Government furnished)	1
15-7311-19	Filter—Equipment type A-3 (Government furnished)	5
15-7311-20	Cable—Equipment electric connecting type T-3A (Government furnished)	2
15-7311-21	Cable—Equipment electric connecting type T-3A (Government furnished)	3
6-9402	Thermometer Installation—Outside air LH	1
6-9402-1	Thermometer Installation—Outside air RH	1
1-13322-13	Clamp—Landing gear fairing	2
1-21970	Bulb—Resistance type C-11 Therman	2
	(Parts List No. 367)	
6-9205	Control Installation—Instrument vacuum	1
6-9336	Control Installation—Instrument vacuum	1
6-9336-1	Handle Assembly—Instrument vacuum	1
1-18845-5-90	Shaft—½ O.D.	1
066654	Handle—Fuel cock control	1
1-18246	Drum—Valve control	1
BAC1608-44	Spacer—½ bolt	1
BAC1608-135	Spacer—½ bolt	1
6-9205-2	Bumper—Instrument vacuum control	1
BAC1780-24-0R	Cable Assembly—3/32—7 x 7 control	2
BAC1780-50-5L	Cable Assembly—3/32—7 x 7 control	1
BAC1780-55-4L	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	3
BAC1826-23R	Swaged Terminal—Class "B"	3
15-7575	Tubing Installation—Navigation instrument	1
15-7575-18	Unit Assembly—Navigation instrument tubing	1
1-19032	Valve—Vacuum shut-off	1
1-18983	Orifice Assembly—Elbow	1
39B3480-414	Hose Assembly—Instrument flexible	1
39B3481-414	Hose Assembly—Instrument flexible	1
41-1178-2	Clamp—Double loop	15
21-9646	Spacer—Self-locking nut	6
41-9725-88	Hose—Vacuum	1
BAC540-12	Clamp—Loop type cushioned	1
BAC540-4	Clamp—Loop type cushioned	25
BAC540-8	Clamp—Loop type cushioned	1
BAC540-10	Clamp—Loop type cushioned	7
BAC540-6	Clamp	7
BAC540-14	Clamp	1
BAC540-16	Clamp	1
BAC1603-24	Spacer	1
BAC1603-32	Spacer—No. 10 bolt	1
BAC1603-48	Spacer—No. 10 bolt	1
15-7575-1	Tube—Navigation instruments	1
15-7575-2	Tube—Navigation instruments	1
15-7575-5	Tube—Navigation instruments	1
15-7575-20	Tube—Navigation instruments	1
15-7575-22	Tube—Navigation instruments	1
15-7575-23	Tube—Navigation instruments	1
15-7575-24	Tube—Navigation instruments	1
15-7575-25	Tube—Navigation instruments	1

AVIALOGS.COM

FINAL ASSEMBLY

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7575-26	Tube—Navigation instruments	1
15-7575-27	Tube—Navigation instruments	1
15-7575-28	Tube—Navigation instruments	1
15-7575-29	Tube—Navigation instruments	1
15-7575-30	Tube—Navigation instruments	1
15-7575-31	Tube—Navigation instruments	1
15-7575-32	Tube—Navigation instruments	1
15-7575-33	Tube—Navigation instruments	1
15-7575-34	Tube—Navigation instruments	1
15-7575-35	Tube—Navigation instruments	1
15-7575-36	Tube—Navigation instruments	1
	(Parts List No. 368)	
15-7575-37	Tube	1
15-7575-38	Tube	1
15-7575-39	Tube	1
15-7575-40	Tube	1
15-7575-41	Tube	1
15-7575-42	Tube	1
15-7575-43	Tube	1
57-1527	Box Installation—Wiring diagram	1
57-1527-1	Box Assembly—Wiring diagram	1
41-9281-1	Plate—Name	1
57-1527-504	Blueprint—Master electrical wiring diagram box—75-7333 sheet 1	1
57-1527-505	Blueprint—Master electrical wiring diagram box—75-7333 sheet 2	1
57-1527-506	Blueprint—Master electrical wiring diagram box—75-7333 sheet 3	1
57-1527-507	Blueprint—Master electrical wiring diagram box—75-7333 sheet 4	1
57-1527-508	Blueprint—Master electrical wiring diagram box—75-7333 sheet 5	1
57-1527-509	Blueprint—Modified A.F.C.E. wiring diagram box—15-9271	1
57-1527-10	Blueprint—Starter and propeller feather diagram box—15-7535	1
57-1527-11	Blueprint—Retractor motor wiring diagram box—14-2060	1
57-1527-13	Blueprint—Direct current wiring diagram box—15-7519	1
57-1527-14	Blueprint—Ignition wiring diagram box—8-1287	1
57-1527-15	Blueprint—De-Icer and motor wiring diagram box—15-7542	1
57-1527-16	Blueprint—Bomb control wiring diagram box—15-7526	1
57-1527-18	Blueprint—Lighting wiring diagram box—15-7586	1
57-1527-19	Blueprint—Warning lamp wiring diagram box—15-7587	1
57-1527-405	Blueprint—Radio compass and marker beacon wiring diagram box—9-3711	1
57-1527-500	Blueprint—Command and Liaison radio diagram box—9-3764	1
57-1527-503	Blueprint—Interphone wiring diagram box—14-2351	1
57-1527-501	Blueprint—Master radio wiring diagram box—15-7932 sheet 1	1
57-1527-401	Blueprint—Liaison radio wiring diagram box—14-2350	1
57-1527-502	Blueprint—Master radio wiring diagram box—15-7932 sheet 2	1
57-1527-406	Blueprint—Instrument wiring diagram box—65-7585	1
BAC1603-27	Spacer—No. 10 bolt	1
54-1685	Curtain Installation—Pilot's cockpit	1
	(Parts List No. 369)	
54-1685-414	Curtain Assembly—Pilot's cockpit LH	1
54-1685-415	Curtain Assembly—Pilot's cockpit RH	1

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
54-1685-411	Fabric—Curtain pilot's cockpit LH (G. Royle & Co.)	1
54-1685-413	Fabric—Tab pilot's cockpit	1
54-1685-412	Fabric—Curtain pilot's cockpit RH (G. Royle & Co.)	1
54-1685-417	Curtain Assembly—Pilot's cockpit	1
14-1685-416	Fabric—Curtain pilot's cockpit (G. Royle & Co.)	1
54-1685-409	Curtain Assembly—Pilot's cockpit	1
14-1685-410	Fabric—Curtain pilot's cockpit (G. Royle & Co.)	1
37B3822-6B	Rivnut—Threaded	1
15-7611	Curtain Installation—Pilot's compartment LH	1
15-7611-1	Curtain Installation—Pilot's compartment RH	1
15-7611-11	Curtain Assembly—Pilot's compartment LH	1
15-7611-12	Curtain Assembly—Pilot's compartment RH	1
15-7611-15	Fabric—Pilot's compartment curtain (G. Royle & Co., No. 7311)	2
41-6881	Ring—Curtain	44
15-7611-13	Rod—Pilot's compartment curtain	2
15-7611-16	Rod—Pilot's compartment curtain	2
2980-3	Clamp—Loop type	2
2980-9	Clamp—Loop type	8
BAC1601-8	Spacer—No. 6 machine screw	2
BAC1603-8	Spacer—No. 10 bolt	6
15-9287	Curtain Installation—Navigator's compartment	1
15-9287-3	Curtain Assembly—Navigator's compartment	5
15-9287-1	Strap Assembly—Navigator's compartment curtain	5
15-9287-2	Strap—Navigator's compartment curtain (Sun Cook Mills, 40 Worth St., New York)	5
15-9287-4	Curtain—Navigator's compartment (G. Wood & Sons Co., 514 Walnut, Philadelphia, Pa.)	5
15-9287-11	Curtain Assembly—Navigator's compartment	2
15-9287-1	Strap Assembly—Navigator's compartment curtain	4
15-9287-2	Strap—Navigator's compartment curtain (Sun Cook Mills)	4
15-9287-12	Curtain—Navigator's compartment (G. Wood & Sons Co.)	2
15-9287-13	Curtain Assembly—Navigator's compartment	4
15-9287-1	Strap Assembly—Navigator's compartment curtain	4
15-9287-2	Strap—Navigator's compartment curtain (Sun Cook Mills)	2
15-9287-14	Curtain—Navigator's compartment (G. Wood & Sons Co.)	4
15-9287-20	Curtain Assembly—Nose navigator's compartment	1
15-9287-21	Curtain—Navigator's compartment (G. Wood & Sons Co.)	1
15-9287-22	Curtain—Navigator's compartment (G. Wood & Sons Co.)	1
15-9287-23	Curtain Assembly—Navigator's compartment	1
15-9287-24	Curtain—Navigator's compartment (G. Wood & Sons Co.)	1
15-9287-25	Curtain—Navigator's compartment (G. Wood & Sons Co.)	1
	(Parts List No. 370)	
15-9287-15	Rod—Navigator's compartment curtain	2
15-9287-16	Rod—Navigator's compartment curtain	2
15-9287-17	Rod—Navigator's compartment curtain	2
15-9287-19	Rod—Navigator's compartment curtain	4
15-9475-8	Rod—Slide	2
15-9475-10	Rod—Slide	3
BAC1601-24	Spacer—No. 6 machine screw	5
BAC1602-24	Spacer—No. 8 machine screw	29

AVIALOGS.COM

FINAL ASSEMBLY

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-9286	Curtain Installation—Top gun window	1
15-9286-4	Curtain Assembly—Top gun window	1
15-9286-1	Curtain—top gun window (G. Wood & Sons 514 Walnut, Philadelphia, Pa.)	1
15-9286-3	Patch—Reinforcement—top gun window (Seattle Tent & Awning)	4
1-24213	Clip—Top gun window—curtain	4
15-9286-5	Curtain Assembly—Top gun window	1
15-9286-2	Curtain—Top gun window (G. Wood & Sons)	1
9-5033	Curtain Installation—Station 5C LH	1
9-5033-2	Curtain Assembly—Station 5C	1
9-5033-3	Curtain—Station 5C (G. Wood & Sons Co.)	1
9-5033-4	Strap—Station 5C curtain (Sun Cook Mills)	2
9-5033-5	Slide—Station 5C curtain	2
BAC1602-22	Spacer—No. 8 machine screw	4
BAC1449-6-12	Screw—Flathead recessed sheet metal	2
9-5033-1	Curtain Installation—Station 5C RH	1
9-5033-2	Curtain Assembly—Station 5C	1
9-5033-3	Curtain—Station 5C (G. Wood & Sons Co.)	1
9-5033-4	Strap—Station 5C (Sun Cook Mills)	1
9-5033-5	Slide—Station 5C curtain	2
BAC1602-22	Spacer—No. 8 machine screw	4
3-6104-55	Frame Assembly—Data card	3
3-6104-3	Cardboard—Data card frame	3
3-6104-5	Sheet—Data card frame	3
3-6104-47	Photo—Data card frame	3
3-6104-60	Frame—Data card	3
3-6104-57	Frame Assembly—Data card	1
3-6104-3	Cardboard—Data card frame	1
3-6104-5	Sheet—Data card frame	1
3-6104-27	Photo—Data card frame	1
3-6104-60	Frame—Data card	1
3-6104-61	Frame Assembly—Data card	2
3-6104-3	Cardboard—Data card frame	2
3-6104-5	Sheet—Data card frame	2
3-6104-60	Frame—Data card	2
3-6104-62	Card—Data frame	2
3-6104-69	Frame Assembly—Data card	1
3-6104-3	Cardboard—Data card frame	1
3-6104-5	Sheet—Data card frame	1
3-6104-60	Frame—Data card	1
	(Parts List No. 371)	
3-6104-70	Photo—Data card frame	1
6-9463	Card Instrument—Data	1
3-6104-26	Frame Assembly—Data card	1
3-6104-1	Plate—Data card frame	1
3-6104-3	Cardboard—Data card frame	1
3-6104-5	Sheet—Data card frame	1
3-6104-27	Photo—Data card frame	1
3-6104-59	Frame—Data card	1
15-7935	Bracket Instrument—Thermos bottles	1
15-7935-1	Bracket Assembly—Thermos bottles	1
15-7935-2	Base—Thermos bottles bracket	1
15-7935-3	Bracket—Thermos bottles	1
15-7935-4	Bracket—Thermos bottles	1
15-7935-5	Pad—Thermos bottles bracket (Latigo leather—special 9-24) (use Goodrich running board cement)	2
1-16128	Clip Assembly—Thermos bottle	2
1-16128-1	Clip—Thermos bottle	2
1-16128-2	Pad—Thermos bottle	2
3-12317	Clamp Assembly—Thermos bottle	2
3-12317-1	Clamp—Thermos bottle	2
3-12317-2	Lining—Thermos bottle clamp	4
BAC1603-40	Spacer—No. 10 bolt	6

Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
9-3710	Dehydrator Assembly—Window	1 for each 50 planes
9-3710-13	Dehydrator Assembly—Window	1 for each 50 planes
9-3710-1	Dehydrator—Window (Miller Brass Co. No. A13676)	1 for each 50 planes
9-3710-2	Screen—Window dehydrator	1 for each 50 planes
9-3710-14	Reducer Assembly—Window Dehydrator	1 for each 50 planes
9-3710-5	Screen—Window dehydrator	1 for each 50 planes
895-82	Bushing—Reducing	1 for each 50 planes
1-20231	Nipple Assembly—Dehydrator	2 for each 50 planes
1-20231-1	Cap—Dehydrator nipple	2 for each 50 planes
1-20231-2	Rivnut—Dehydrator nipple (Goodrich Type 6-240)	2 for each 50 planes
1-20237	Nipple—Dehydrator	1 for each 50 planes
BAC538-8	Clamp—Loop type cushioned	2 for each 50 planes
BAC542-32S	Channel—Strap clamp	4 for each 50 planes
BAC1447-10-8	Screw—RH recessed sheet metal	2 for each 50 planes
9-3710-3	Panel—Window dehydrator	1 for each 50 planes
9-3710-4	Spacer—Window dehydrator	2 for each 50 planes
9-3710-6	Gage—Window dehydrator (Ashcroft American Type 1000)	1 for each 50 planes
9-3710-7	Valve—Window dehydrator (Crane Co., No. 88)	1 for each 50 planes
9-3710-8	Tube—Window dehydrator (U. S. Rubber Co., No. 871)	1 for each 50 planes
9-3710-9	Tube—Window dehydrator (U. S. Rubber Co., No. 871)	1 for each 50 planes
9-3710-10	Tube—Window dehydrator (U. S. Rubber Co., No. 871)	1 for each 50 planes
	(Parts List No. 372)	
9-3710-11	Tube—Window dehydrator (U. S. Rubber Co., No. 871)	1 for each 50 planes
9-3710-12	Silica Gelatin—Window dehydrator (Davison Chemical Co., No. 6956-160T, 6-16 Mesh)	1 for each 50 planes
3-12986	Strap Installation—Brace stowage	1
3-12986-1	Bracket Assembly—Brace stowage	1
3-12986-3	Strap—Brace stowage (Western Auto Supply Co , No. C-492)	1
3-12986-4	Pad—Brace stowage strap	1
6-9338	Shoulder Pad Installation—Rear gun compartment	1
6-9338-1	Pad Assembly—Rear gun compartment shoulder	2
7-1539	Pad Installation—Rear gunner	1
6-10685	Pad Installation—Bulkhead station 10	1
6-10685-1	Pad Assembly—Bulkhead station 10	1
6-10685-2	Cover—Bulkhead station 10 pad	1
6-10685-3	Cover—Bulkhead station 10 pad	1
6-10685-4	Filler—Bulkhead station 10 pad	1
1-18933	Hook Installation—Coat	1
8831	Hook—Coat (Pacific Marine Supply Co., Seattle, Washington)	1
36G4465	Case—Airplane Mooring (Type D-1) (government furnished)	4
1-20381	Container Installation—Key	1
1-20381-1	Container Assembly—Key	1
BAC1330-1	Rivnut	2
9-4612	Accelerometer Installation—Pilots	1
1-23510	Accelerometer—(Type B-3) (government furnished)	1
6-11305	Bracket—Accelerometer	1
1-20320	Placard—Cowl flap instruction	1
1-20330	Wrench Assembly—Bomb sight mount	1
1-20330-1	Handle—Bomb sight mount wrench	1
1-20330-2	Pins—Bomb sight mount wrench	2

AVIALOGS.COM

EQUIPMENT INSTALLATION

Board Installation—Pilot's and Co-Pilot's Instrument

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 373)	
55-7380	Board Installation—Pilot's and co-pilot's instrument	1
55-7380-400	Board Assembly—Pilot's and co-pilot's instrument	1
15-7379	Frame Assembly—Pilot's instrument board support	1
15-7379-37	Panel Assembly—Base pilot's instrument	1
15-7379-25	Bumper Assembly—Pilot's instrument panel	2
15-7379-22	Bumper—Pilot's instrument board support	2
15-7379-35	Pad—Pilot's instrument board support	2
15-7379-38	Panel Assembly—Front pilot's instrument	1
15-7379-39	Panel Assembly—Rear pilot's instrument	1
3-13542	Bracket—Shock mount	1
3-13700	Bracket—Shock mount	1
46-9293	Panel Assembly—Pilot's instrument	1
46-9293-400	Panel—Pilot's instrument	1
1-18396	Name Plate—Oil pressure	1
1-18507	Plate—Warning	1
41-4299	Plate—Name—flying fortress	1
41-5153	Plate—Name	1
41-5760-1	Decalcomania—Name plate	1
41-8347-1	Plate—Name—vacuum	1
1-21012	Plate—Name	1
074837	Holder Assembly—Compass correction card	1
BAC1447-6-4	Screw—Round head recessed sheet metal	4
46-9294	Panel Assembly—Flight instrument	1
46-9294-401	Panel—Flight instrument	1
1-18398	Plate—Name	1
41-5760-2	Plate—Name	1
41-7813-2	Plate—Name	1
41-7813-3	Plate—Name	1
1-20055	Plate—Radio control	1
6-9295	Panel Assembly—Co-pilot's instrument	1
6-9295-1	Panel—Co-pilot's instrument	1
41-6462	Name Plate—Engine No. 1	1
41-6462-1	Name Plate—Engine No. 2	1
41-6462-2	Name Plate—Engine No. 3	1
41-6462-3	Name Plate—Engine No. 4	1
3-16900-4	Decalcomania	1
3-15191	Panel Assembly—Instrument resistor	1
3-15191-1	Panel—Instrument resistor	1
1-18706	Clip—Instrument resistor	18
1-18707-1	Bus—Resistor panel	1
55-7380-1	Cage—Suction—(government furnished) pilot's and co-pilot's instrument	1
55-7380-8	Indicator—Rate of climb—pilot's and co-pilot's instrument (government furnished)	1
55-7380-7	Indicator—Turn and bank—pilot's and co-pilot's instrument (government furnished)	1
55-7380-4	Indicator—Flight—pilot's and co-pilot's instrument (government furnished)	1
55-7380-3	Indicator—Turn—pilot's and co-pilot's instrument (government furnished)	1
	(Parts List No. 374)	
15-7380-22	Indicator—Pilot's director—pilot's and co'pilot's instrument (government furnished)	1
15-7380-2	Lamp—24 volt—pilot's and co-pilot's instrument (government furnished)	5
55-7380-5	Altimeter—Pilot's and co-pilot's instrument (government furnished)	1
55-7380-6	Indicator—Air speed—pilot's and co-pilot's instrument (government furnished)	1
55-7380-21	Indicator—Thermocouple—pilot's and co-pilot's instrument (government furnished)	2
55-7380-20	Gage—De-icer pressure—pilot's and co-pilot's instrument (government furnished)	1
55-7380-24	Rheostat—Ohmite—model H, catalog No. 0150—pilot's and co-pilot's instrument	1

Board Installation—Pilot's and Co-Pilot's Instrument

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18368	Gage—Hydraulic oil pressure	1
3-13442	Indicator—Flap position	1
3-13443	Indicator—Fuel quantity	1
3-13443-1	Indicator—Fuel quantity	1
3-13443-2	Indicator—Fuel quantity	1
55-7380-18	Indicator—Oil temperature—pilot's and co-pilot's instrument board (government furnished)	1
55-7380-16	Gage—Oil pressure—pilot's and co-pilot's instrument board (government furnished)	1
55-7380-14	Gage—Fuel pressure—pilot's and co-pilot's instrument board (government furnished)	1
55-7380-9	Gage—Manifold pressure—pilot's and co-pilot's instrument board (government furnished)	2
55-7380-10	Indicator—Tachometer—pilot's and co-pilot's instrument board (government furnished)	2
55-7380-11	Switch—Propeller feather—pilot's and co-pilot's instrument board (government furnished)	4
55-7380-23	Insulator—Pilot's and co-pilot's instrument board	1
55-7380-401	Chart Instruction—Pilot's and co-pilot's instrument board (government furnished)	1
1-18509-3	Guard Assembly—Propeller feather switch	1
1-24992-1	Decalcomania—"Push"—propeller feather switch guard	1
37A5222-9	Resistor—Ohmite	9
1-21494	Signal Lamp Assembly—Single contact (AC drawing 40A7419)	2
1-21494-1	Signal Lamp Assembly—Single contact (AC drawing 40A7419)	6
39B2822-2	Signal Lamp Assembly—Single contact	3
39B2822-3	Signal Lamp Assembly—Single contact	1
39B2822-4	Signal Lamp Assembly—Single contact	1
39A3906-2	Lamp—Amber (government furnished)	8
1-21342	Diagram—Selector plate	5
1-21342-1	Diagram—Selector plate	5
1-21041-1	Bus—Connector	1
40A6364	Card—Altimeter scale error (government furnished)	1
39B3334-1	Nut—Conduit	8
41D7019	Indicator—Radio compass (government furnished)	1
1-21041	Connector—Bus	1
1-21382	Valve Assembly—Static pressure (Weatherhead Co., Cleveland, Ohio, No. 275230)	1
1-24193	Switch Assembly—Modified A.F.C.E. (P.R. Mallory and Co., No. 3263J)	1
3-16141-7	Plate—Name	1
	(Parts List No. 375)	
6-10104	Panel Installation—Instrument board	1
1-21001	Insulator—Connector panel	1
3-14228	Panel Assembly—Connector	1
3-14228-1	Panel—Connector	1
1-21000	Bus—Connector panel	1
21-7401-5	Bus—Connector panel	1
21-4841-20	Jumper Assembly—No. 8-10 terminal bonding	4
BAC820-8	Terminal—Electrical lock	8
BAC820-10	Lock—Terminal	1
3-13460	Snubber Assembly—Pilot's instrument board	4
3-13460-1	Bracket—Pilot's instrument board snubber	4
3-13460-2	Bumper—Pilot's instrument board snubber	8
3-13461	Bracket Assembly—Shock mount	4
41-5652-5	Rod Assembly—Shock mount	2
41-2668-4	Rod End—Ball bearing	2
41-5650	Terminal—Threaded	2
33B5452-42	Absorber—Vibration	4
33B5452-43	Absorber—Vibration	3
33B5452-44	Absorber—Vibration	1
33B5452-45	Absorber—Vibration	2
41-128-40-25	Washer—.125 steel	2
34A1766-D3	Washer—Vibration—absorber stop	16

AVIALOGS.COM

EQUIPMENT INSTALLATION

Board Installation—Pilot's and Co-Pilot's Instrument

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
55-7380-27	Voltmeter—Autosyn	1
6-11443-1	Decalcomania—Instrument cover	1
6-11443-2	Decalcomania—Instrument cover..1 for every 175 planes	
6-11443-3	Decalcomania—Instrument cover..1 for every 200 planes	
6-11443-4	Decalcomania—Instrument cover	2

Board Installation—Pilot's and Co-Pilot's Instrument

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-11443-5	Decalcomania—Instrument cover	2
6-11443-6	Decalcomania—Instrument cover	2
6-11443-7	Decalcomania—Instrument cover	2
6-11443-8	Decalcomania—Instrument cover	2
6-11443-9	Decalcomania—Instrument cover	2

EQUIPMENT AND FURNISHINGS INSTALLATION

Seat Installation—Pilot's and Co-Pilot's

(Parts List No. 376)

47-1501	Seat Installation—Pilot LH	1
47-1501-1	Seat Installation—Co-pilot RH	1
	Dash number parts, shown on 47-1501 drawing, are represented by dash numbers of 47-1501 and 7-1501.	
47-1501-402	Seat Assembly—Pilot	1
47-1501-403	Seat Assembly—Co-pilot	1
75-3448	Seat Assembly—Pilot's	2
55-5272-407	Support Assembly—Pilot's seat LH	1
55-5272-408	Support Assembly—Pilot's seat RH	1
55-5272-17	Strap Assembly—Pilot's seat support	4
21-9107	Angle—Pilot's seat support	4
51-957	Angle—Pilot's seat adjustment	2
51-957-1	Angle—Pilot's seat adjustment	2
51-956	Angle Assembly—Pilot's seat adjustment	2
51-956-1	Angle Assembly—Pilot's seat adjustment	2
BAC344-4-128	Bushing—Staked	4
21-5960	Plunger—Pilot's seat adjustment	4
21-5963	Spring—Compression	4
BAC1603-35	Spacer—No. 10 bolt	4
BAC1603-43	Spacer—No. 10 bolt	4
BAC1603-62	Spacer—No. 10 bolt	4
51-19	Arm—Pilot's seat adjustment	4
21-5641	Plunger Assembly—Pilot's seat adjustment	4
41-778	Spring—Compression	4
21-3894-26-13	Washer—Retaining	4
41-9902	Fitting—Pilot's seat	2
41-9902-1	Fitting—Pilot's seat	2
61-5642	Arm—Seat adjustment plunger	2
61-5642-1	Arm—Seat adjustment plunger	2
81-4547	Handle—Seat adjustment (casting 81-4547-1)	2
51-1178-1	Fair-lead—Pilot's seat plunger	4
51-1178-2	Fair-lead—Pilot's seat plunger	4
21-9109	Plate—Pilot's seat adjustment	8
41-5646	Gusset—Pilot's seat support	8
BAC1615-35	Spacer—5/32 rivet	16
55-5272-11	Spacer—Pilot's seat support	8
55-5272-16	Tube—Pilot's seat support	2
55-5272-19	Spacer—Pilot's seat support	8
55-5272-406	Spacer—Pilot's seat support	4
55-5272-20	Tube Assembly—Pilot's seat support	4
75-4093-609	Mount Assembly—Pilot's seat support LH	1
75-4093-1	Mount Assembly—Pilot's seat support RH	1
	Dash number parts, shown on 75-4093 drawing, are represented by dash numbers of 75-4093 and 65-4093.	
75-4093-600	Tube—Pilot's seat support mount	2
75-4093-601	Tube—Pilot's seat support mount	2
75-4093-602	Tube—Pilot's seat support mount	2
75-4093-603	Tube—Pilot's seat support mount	2
75-4093-605	Tube—Pilot's seat support mount	2
75-4093-606	Tube—Pilot's seat support mount	2

(Parts List No. 377)

65-4093-4	Tube—Pilot's seat support mount	2
65-4093-503	Tube—Pilot's seat support mount	2
65-4093-505	Tube—Pilot's seat support mount	2
65-4093-506	Tube—Pilot's seat support mount	2

Seat Installation—Pilot's and Co-Pilot's

65-4093-507	Tube—Pilot's seat support mount	2
BAC1604-33	Spacer—1/4 bolt	16
BAC1604-31	Spacer—1/4 bolt	16
75-4093-607	Lug—Pilot's seat support mount	16
BAC1615-31	Spacer—5/32 rivet	38
BAC1615-33	Spacer—5/32 rivet	8
BAC1615-35	Spacer—5/32 rivet	20
55-7733	Support Installation—Pilot and co-pilot armor LH	1
55-7733-1	Support Installation—Pilot and co-pilot armor RH	1
55-7733-412	Support Assembly—Pilot and co-pilot armor LH	1
55-7733-413	Support Assembly—Pilot and co-pilot armor RH	1
55-7733-416	Channel Assembly—Pilot and co-pilot armor	2
1-20526	Angle—Clip	4
1-20526-1	Angle—Clip	4
55-7733-421	Channel Assembly—Pilot's and co-pilot's armor LH	1
55-7733-422	Channel Assembly—Pilot's and co-pilot's armor RH	1
1-20526	Angle—Clip	1L-2R
1-20526-1	Angle—Clip	2L-1R
BAC1603-36	Spacer—No. 10 bolt	12
BAC1603-39	Spacer—No. 10 bolt	16
9-3767	Support Installation—Fire extinguisher	1R
9-3767-3	Support Assembly—Fire extinguisher	1
BAC1603-36	Spacer—No. 10 bolt	2
BAC1603-37	Spacer—No. 10 bolt	1
BAC1603-39	Spacer—No. 10 bolt	1
1-20039	Support—Installation—Ash tray LH	1
1-20039-4	Plate—Ash tray support	2
1-20039-5	Plate—Ash tray support	2
1-20039-2	Ash Tray—Support (Ford model 1936)	2
1-20345	Plate—Horn support	1L
1-20346	Plate—Horn support	1L
21-9370	Shock Cord Assembly—Pilot's seat	2
21-9370-1	Shock Cord—Pilot's seat	2
21-9370-2	Leather Reinforcement—Pilot's seat	2
41-828	Thimble—Shock cord	4
41-5647	Spring—Horizontal seat adjusting	4
61-7431	Stop—Pilot's seat adjusting	4
61-7431-1	Stop—Rear pilot's seat adjusting	4
21-9352	Fitting—Pilot's seat support	2
41-1242	Channel—Pilot's seat support	2
3-13598	Bracket—Pilot's seat	1R
BAC1602-36	Spacer—No. 8 machine screw	4
34G1346	Belt Assembly—Safety (government furnished)	2
074272	Cushion—Life preserver	2
AN7501	Cushion	2

Seat Installation—Bombers

(Parts List No. 378)

7-1502	Seat Installation—Bombers	1
7-1502-1	Seat Assembly—Bombers	1
75-5580	Seat Assembly—Bomber	1

AVIALOGS.COM

SEAT INSTALLATION—BOMBERS

Seat Installation—Bombers

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
75-5580-607	Base Assembly—Bomber	1
41-6305-1	Bearing—Tube support	1
41-6153	Bracket Assembly—Crew seat	1
BAC1613-56	Spacer—3/32 rivet	1
41-6154	Lever Assembly—Crew seat	1
BAC1550-14	Sleeve—5/16—.058	1
41-5899	Bell Crank—Crew seat	1
41-6155	Link Assembly—Crew seat	1
41-6156	Pin—Crew seat lock	1
41-6814	Spring—Compression	1
51-355-3	Washer—Flanged	1
BAC1246-10S	Plate—Fiber nut	2
75-5580-600	Seat Assembly—Bomber	1
65-5280	Seat Assembly—Crew	1
81-4547	Handle—Seat adjusting	1
BAC1608-10	Spacer—1/2 bolt	1
BAC1603-56	Spacer—No. 10 bolt	1
9-2711-33	Cone Assembly—Bomber's seat	1
9-2711-6	Retainer Assembly—Bomber's seat	1
41-6600-2	Zee—Bearing support	1
41-6600-3	Zee—Bearing support	1
BAC1603-72	Spacer—No. 10 bolt	1
9-2711-22	Channel Assembly—Bomber's seat cone	1
BAC343-2-85	Bushing—5/16 staked	2
9-2711-23	Lever Assembly—Bomber's seat cone	1
9-2711-10	Lever—Bomber's seat cone	1
21-8894	Spring—Pilot's seat slide adjusting	1
BAC605-25	Spacer—5/16 bolt	1
BAC343-2-84	Bushing—3/16 staked	2
BAC343-2-526	Bushing—3/16 staked	1
21-8880-1	Plunger—Pilot's seat slide adjusting	1
21-8663	Spring—Compression	1
BAC1603-6	Spacer—No. 10 bolt	2
BAC703	Washer—Cup—cowl fastener	1
41-6601	Zee—Bearing support	2
41-6601-1	Zee—Bearing support	2
9-2711-24	Bolt—Bomber's seat cone	2
BAC1603-8	Spacer—No. 10 bolt	4
BAC324-17S	Bushing—9/32 OD bearing	4
41-6655	Spring—Bomber's seat	2
9-2711-21	Bolt—Eye bomber's seat cone	1
41-7085-72-13	Washer—.078 steel	1
41-6315	Flange—Tube support	1
9-2711-34	Bearing—Bomber's seat cone	1
41-6312	Post Assembly—Seat support	1
	(Parts List No. 379)	
41-6308	Terminal—Seat support	1
41-6309	Stop—Seat post	1
41-6468	Spring—Compression	1
21-2363-80-28	Washer—.063 steel	1
43-10811-1	Stop—Bomber's seat LH	1
43-10811-2	Stop—Bomber's seat RH	1
34G1646	Belt Assembly—Type B-11 (government furnished)	1
074272	Cushion	1
AN7501	Cushion	1

Heating and Ventilating Installation

(Parts List No. 380)

15-7386	Heating and Ventilating Installation	1
3-12018	Duct Installation—Heat and vent	1
3-12018-1	Duct Assembly—Heat and vent	1
41-8031	Bracket Assembly—Pilot's air duct	2
6-7799	Duct Installation—Heat and vent	1
3-11388	Duct Assembly—Heat and vent	1
3-12776-2	Vane—Turning	1
3-11388-5	Duct Assembly—Heat and vent	1
3-11410	Duct Assembly—Heat and vent	1
3-12776-2	Vane—Turning	1
6-7887	Duct Installation—Heat and vent	1
3-11477	Duct Assembly—Heat and vent	1

Seat Installation—Bombers

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-8623	Angle—Air duct	1
41-8638	Angle—Air duct	1
14-2056	Duct Installation—Heating	1
14-2056-14	Duct Assembly—Heating	1
14-2056-20	Elbow Assembly—Heating duct	1
14-2056-1	Elbow Assembly—Heating duct	1
3-13571	Vane—Air outlet	1
3-13571-1	Vane—Air outlet	1
14-2056-21	Elbow Assembly—Heating duct	1
14-2056-17	Elbow Assembly—Heating duct	1
1-18244	Cover—Grille	1
1-18245	Grille—Air outlet	1
14-2078	Duct Installation—Heating	1
14-2078-17	Duct Assembly—Heating	1
14-2078-1	Duct Assembly—Heating	1
14-2078-19	Elbow Assembly—Heating duct	1
14-2078-18	Duct Assembly—Heating	1
6-9400	Elbow Assembly—Air duct	1
15-7384	Duct Installation—Heating	1
15-7384-1	Elbow Assembly—Heating	1
41-6063-90-32-3	Angle—3/16 x 3/4 aluminum alloy	2
15-7384-8	Elbow Assembly—Heating duct	1
15-7384-13	Duct Assembly—Heating	1
15-7384-20	Duct Assembly—Heating	1
3-11425	Duct Assembly—Heating and ventilating	1
3-11426	Duct Assembly—Heating and ventilating	1
55-7599	Duct Installation—Heating	1
55-7599-1	Duct Assembly—Heating	1
55-7599-6	Elbow Assembly—Heating duct	1
55-7599-400	Elbow Assembly—Heating duct	1
55-7599-10	Elbow Assembly—Heating duct	1
1-18584	Bracket—Duct support	2
55-7599-401	Duct Assembly—Heating	1
55-7599-1	Duct Assembly—Heating	1
1-18584-1	Bracket—Duct support	2
	(Parts List No. 381)	
55-7599-402	Elbow Assembly—Heating duct	1
55-7599-14	Elbow Assembly—Heating duct	1
1-18584	Bracket—Duct support	2
3-11330	Duct Assembly—Gunner's air	1
9-3688	Elbow Assembly—Air duct	1
9-3688-1	Elbow Assembly—Air duct	1
9-3688-6	Transition Assembly—Air duct elbow	1
1-18584	Bracket—Duct support	2
3-13627	Duct Installation—Bomber	1
3-13627-1	Duct Assembly—Bomber	1
9-2951	Duct Installation—Bomber	1
9-2951-7	Duct Assembly—Bomber	1
9-2951-12	Duct Assembly—Bomber	1
3-12776-3	Vane—Turning	1
BAC1602-12	Spacer—No. 8 machine screw	1
BAC1602-20	Spacer—No. 8 machine screw	1
43-11338	Duct Installation—Bomber	1
43-11338-400	Duct Assembly—Bomber	1
3-12776	Vane—Turning	1
43-11466	Duct Installation—Bomber	1
43-11466-400	Duct Assembly—Bomber	1
41-7952-9	Duct—Heating and ventilating	1
BAC1603-24	Spacer—No. 10 bolt	2
46-7745	Duct Installation—Bomber	1
46-7745-400	Duct Assembly—Bomber	1
47-1337	Duct Installation—Bomber	1
3-11358	Grille Assembly—Bomber's air inlet	1
41-8444	Spring—Defroster control	1
41-8462	Plate—Name	1
6-8530	Duct Assembly—Hot air	1
43-11353	Duct Assembly—Bomber's	1
41-8443	Collar—Bomber's air inlet	1
81-8507	Valve Assembly—Defroster	1
41-8445	Knob—Defroster control	1
3-11359-1	Rod—Defroster control	1

AVIALOGS.COM

EQUIPMENT AND FURNISHINGS INSTALLATION

Heating and Ventilating Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
9-3084	Duct Installation—Pilot's air vent	1
6-8152	Transition Assembly—Pilot's air vent	1
6-8152-6	Felt—Strip (booth No. 61)	1
6-8152-7	Lining—Pilot's air vent transition—kapok (Felters Co.)	1
51-149	Collar Assembly—Air duct	1
BAC1246-10	Nut Plate	4
3-11413	Duct Assembly—Air vent	1
3-11413-2	Lining—Air vent duct kapok (Felters Co.)	1
	(Parts List No. 382)	
3-11412	Collar Assembly—Air vent	1
51-150	Grille—Pilot's air vent	1
55-5924	Duct Installation—Pilot's air	1
41-7952-1	Duct—Heating and ventilation	1
46-7622	Elbow Assembly—Pilot's air duct	1
46-7622-1	Elbow Assembly—Pilot's air duct	1
46-7622-2	Duct Assembly—Pilot's air	1
46-7622-3	Duct Assembly—Pilot's air	1
41-7982	Shutter Assembly—Pilot's air duct	2
1-18371	Rod—Shutter control	2
41-7983	Grille—Pilot's air duct	2
41-7981	Cover—Pilot's air duct	2
41-8031	Bracket Assembly—Pilot's air duct	2
41-8031-4	Bracket Assembly—Pilot's air duct	2
46-7624	Elbow Assembly—Air duct	1
46-7624-1	Duct Assembly—Air—elbow	1
46-7624-404	Duct Assembly—Spot-weld	1
41-8031	Bracket Assembly—Pilot's air duct	2
41-7979	Shutter Assembly	1
41-7979-1	Shutter	1
41-7979-2	Clip	1
41-7979-3	Hinge	1
1-19701	Rod—Pilot's heat control	1
1-19701-1	Rod—Pilot's heat control	1
21-2364-48-11	Washer—.064 aluminum alloy	4
21-2364-64-11	Washer—.064 aluminum alloy	3
1-18579	Knob—Plastic	2
9-3714	Duct Installation—Defroster air	1
41-8454	Clamp Assembly—Defroster duct	4
41-8454-2	Pad—Defroster duct clamp (booth No. 61)	4
41-8385	Elbow Assembly—Defroster duct	2
41-8395	Elbow Assembly—Defroster duct	1
41-7952-7	Duct—Heating and ventilating	1
3-11424	Duct Assembly—Heating and ventilating	1
3-12776-4	Vane—Turning	1
3-12776-5	Vane—Turning	1
15-6702	Duct Assembly—Cold air	1
15-6702-6	Gasket—Cold air duct	4
15-6702-10	Duct Assembly—Cold air	1
15-6702-11	Connection Assembly—Flexible	1
3-12572	Flange Assembly—Air duct	2
51-675-6	Gasket—Corner	8
9-3661	Elbow Installation—Air outlet	1
9-3661-1	Elbow Assembly—Air outlet	1
9-3661-11	Duct Assembly—Air outlet elbow	1
3-13934	Damper Assembly—Air duct	1
	(Parts List No. 383)	
1-19055	Grille—Air outlet	1
1-19054	Cover—Grille	1
1-20040	Knob—Plastic	1
1-20036	Spring—Air control	1
1-20037	Plate—Air control	1
1-20038	Rod—Air control	1
9-3661-12	Felt—(Booth SAE-F7)	1
51-255	Elbow Assembly—Air duct	1
3-12776-1	Vane—Turning	1
3-14208	Elbow Assembly—Air duct	1
54-1753	Outlet Installation—Navigator's air	1
54-1753-400	Outlet Assembly—Navigator's air	1

Heating and Ventilating Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
54-1753-407	Outlet Assembly—Spot-weld	1
41-7774	Clamp Assembly—Air splitter	1
41-7774-4	Clamp—Air splitter	1
81-8632	Shutter Assembly—Navigator's air outlet	1
41-8631	Cover—Navigator's air outlet	1
41-8629	Grille—Navigator's air outlet	1
41-8630-1	Rod—Shutter control	1
41-6063-90-32-2	Angle—9/16 x 3/4 aluminum alloy	4
1804-M-1	Nut—Speed (J Type) (Tinnerman)	2
BAC1602-20	Spacer—No. 8 machine screw	2
BAC1602-30	Spacer—No. 8 machine screw	2
14-1747-12	Ventilation Installation—Bomber's compartment	1
14-1747-1	Duct Assembly—Bomber's compartment	1
14-1747-13	Duct Assembly—Bottom half	1
14-1747-6	Plate Assembly—Bottom half duct	1
BAC1249-2080	Plate—Fiber nut	4
41-8744	Drain Assembly—Air ventilation	1
14-1747-14	Duct Assembly—Top half	1
41-6063-77-32-3	Angle—9/16 x 3/4 aluminum alloy	2
41-6063-77-32-4	Angle—9/16 x 3/4 aluminum alloy	2
3-11419	Flange Assembly—Air vent	1
3-11419-1	Flange Assembly—Weld air venltiiaton	1
BAC1249-210D	Plate—Fiber nut	4
3-13792	Plate—Air vent	1
41-8554	Grille—Air vent	1
BAC1602-8	Spacer—No. 8 machine screw	8
BAC1460-8-85	Screw—Recessed head	8
3-11961	Tube Installation—Drain	1
3-11961-1	Rubber—Drain tube	1
3-11961-2	Tube—Drain	1
14-1747-9	Tube—Bomber's compartment vent	1
7-1641	Defroster Installation—Bomber's window	1
7-1641-1	Duct Assembly—Bomber's window	1
7-1641-8	Felt—Bomber's window defroster (Booth Felt Co.)	1
9-3705	Control Installation—Cabin air	1
3-13910	Plate—Name	1
	(Parts List No. 384)	
1-18844	Shaft—1/2 OD	1
3-13923	Drum—3/32 cable	1
41-8065	Handle Assembly—Damper control	1
41-7919	Tube—Lock lever	1
41-8068	Terminal—Lever	1
41-8067	Spacer—Lever	2
41-8066	Lever Assembly—Damper controls	1
41-8069	Knob Assembly—Control	1
41-7916	Plug—Lock lever	2
41-7917-2	Tube—Lock lever	1
41-7940	Plug—Lock lever	1
41-2399	Spring—Compression	1
41-7941	Spacer—Special	1
41-8064	Sector—Control lever	1
BAC1603-30	Spacer—No. 10 bolt	2
BAC1603-36	Spacer—No. 10 bolt	8
BAC1608-57	Spacer—1/2 bolt	1
BAC1608-119	Spacer—1/2 bolt	1
6-9454	Defroster Installation—Pilot's	1
6-9454-1	Duct Assembly—Pilot's defroster	1
6-10120	Outlet—Pilot's defroster	1
6-9481	Elbow Assembly—Defroster duct	1
6-9481-9	Elbow Assembly—Defroster duct	1
6-9481-1	Bottom Assembly—Defroster duct	1
1-18455	Hinge Assembly—Defroster control	1
1-20553	Angle—Attaching	2
1-17572	Spring—Defroster control	1
1-18376	Plate—Defroster control	1
1-18579	Knob—Plastic	1
1-19655	Rod—Defroster control	1
BAC1244-108	Nut Plate—Speed	2
9-3667	Guard Installation—Air duct	1
9-3667-1	Guard Assembly—Air duct	1

AVIALOGS.COM

EQUIPMENT AND FURNISHINGS INSTALLATION

Heating and Ventilating Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
75-6691	Glycol System Installation	1
	Dash number parts, shown on 75-6691 drawing are represented by dash numbers of 65-6691 and 75-6691.	
65-6691-32	Tank Assembly—Glycol system	1
9-3268	Tank Assembly—Insulated	1
6-8647	Tank Assembly—Glycol	1
1-16660	Filler—Glycol tank	1
9-3268-1	Insulation—Tank	1
9-3268-3	Cover—Insulated tank	1
9-3268-4	Cover—Insulated tank	1
9-3268-7	Cover—Insulated tank	1
1-16658	Gage Assembly—Glycol tank	1
21-2363-128-86	Washer—.063 steel	1
39B1024-16	Nut—Hydraulic hose check	1
65-6691-6	Gasket—Glycol system	2
	(Parts List No. 385)	
75-6691-607	Filter Assembly—Glycol system	1
1-16962	Filter Assembly—Glycol or hydraulic fluid (Cuno Eng. Corp., Meriden, Conn., No. 11238)	1
1-21021	Angle—Support	1
51-388-8	Clamp Assembly—Filter	1
51-388-9	Clamp—Filter	1
51-388-13	Tape—Asbestos—Filter clamp	1
1-16757	Valve Assembly—Pressure relief N.D. (Parker 1040-15)	1
69-2423	Heater Assembly—Glycol system	2
69-2423-600	Cylinder—Glycol system heater	2
69-2423-601	Spindle—Glycol system heater	2
69-2423-602	Pin—Glycol system heater	2
69-2423-603	Cap—Glycol system heater	2
69-2423-604	Washer—Glycol system heater	2
65-6691-2	Tube—Glycol system	1
65-6691-3	Tube—Glycol system	1
65-6691-4	Tube—Glycol system	1
65-6691-5	Tube—Glycol system	1
65-6691-7	Tube—Glycol system	1
65-6691-9	Tube—Glycol system	1
65-6691-10	Tube—Glycol system	1
65-6691-14	Tube—Glycol system	1
65-6691-15	Tube Assembly—Glycol system	1
65-6691-16	Tube—Glycol system	1
65-6691-17	Tube—Glycol system	1
65-6691-18	Tube—Glycol system	1
65-6691-19	Tube—Glycol system	1
65-6691-20	Tube—Glycol system	1
65-6691-21	Tube—Glycol system	1
65-6691-22	Tube—Glycol system	1
65-6691-503	Tube Assembly—Glycol system	1
65-6691-12	Tube—Glycol system	1
65-6691-504	Tube—Glycol system	1
75-6691-600	Tube—Glycol system	1
75-6691-601	Tube—Glycol system	1
75-6691-602	Tube—Glycol system	1
75-6691-604	Tube—Glycol system	1
75-6691-605	Tube—Glycol system	1
75-6691-606	Tube—Glycol system	1
75-6691-609	Tube—Glycol system	1
41-3034	Angle—Tubing support	1
41-9007-1	Angle—Tubing support	1
41-9007-24	Boot—Tubing support	2
41-9007-25	Plate—Tubing support	2
41-9007-29	Wrapping—Tubing support	1
75-6691-428	Covering—Pipe—Glycol system	1
1-23501	Clamp Assembly	10
1-17019	Plate—Insulator tube reinforcing	30
1-23501-1	Clamp Assembly	3
1-17019	Plate	6
1-23501-2	Clamp Assembly	2

Heating and Ventilating Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 386)	
1-17019	Plate	4
39B1024-8	Nut—Hydraulic hose check	1
BAC802-2-100	Jumper Assembly—Terminal bonding	1
BAC1602-16	Spacer—No. 8 machine screw	1
21-2589-16	Clip—Tab loop type	6
41-8580-16	Clamp—Loop type	2
BAC540-4	Clamp—Loop type	8
39G1030-8-16	Hose—Hydraulic	1
1-13892-56-12	Clamp—Tabulated square	1
41-468-86-24	Clamp—Square loop type	1
BAC540-8	Clamp	1
BAC540-10	Clamp—Loop type cushioned	3
BAC540-12	Clamp—Loop type cushioned	3
BAC540-14	Clamp—Loop type cushioned	2
BAC540-16	Clamp—Loop type cushioned	2
BAC1603-8	Spacer—No. 10 bolt	6
BAC1603-12	Spacer—No. 10 bolt	1
BAC1603-24	Spacer—No. 10 bolt	1
BAC1603-32	Spacer—No. 10 bolt	2
BAC1603-40	Spacer—No. 10 bolt	2
BAC1603-64	Spacer—No. 10 bolt	1
65-6705	Units and Cables Installation—Cabin heating system	1
	Dash number parts, shown on 65-6705 drawing are represented by dash numbers of 55-6704 and 15-6704.	
55-6704	Units Assembly—Cabin air units	1
55-6704-402	Control Assembly—Cabin air units	1
1-16656	Housing Assembly—Bearing	6
1-16656-1	Housing—Bearing	6
1-16669	Collar—Vane shaft	2
1-16668-6-29	Shaft—½ OD aluminum alloy	2
1-16668-7-24	Shaft—½ OD aluminum alloy	1
3-12574	Vane Assembly—Cabin air control	2
6-8655	Link Assembly—Control arm	1
BAC1613-20	Spacer—⅛ rivet	2
3-13932	Drum—⅛ cable	1
41-4069	Arm Assembly—Damper valve control	2
41-4069-1	Arm—Damper valve control	2
1-16754-3	Gasket—Air duct	1
1-16754-4	Gasket—Air duct	1
7-1655	Vane Assembly—Cabin air control	1
7-1655-6	Pad—Cabin air control valve (Booth No. 61)	1
7-1655-7	Pad—Cabin air control valve (Booth No. 61)	2
7-1655-8	Pad—Cabin air control valve (Booth No. 61)	1
1-21954	Tube—Brake	1
1-21953	Block—Laminated phenolic	2
1-21955	Spring—Laminated phenolic block	1
1-22651	Lever—Damper valve control	2
BAC1613-26	Spacer—⅛ rivet	4
41-4931	Spring—Tension	1
41-6063-90-64	Angle—9/16 x ¾ aluminum alloy	1
BAC1603-10	Spacer—No. 10 bolt	2
	(Parts List No. 386A)	
BAC1608-21	Spacer—No. ½ bolt	2
	(Parts List No. 387)	
21-3894-24-13	Washer—Retaining	4
BAC1246-8S	Plate—Fiber nut	2
15-6704-12	Channel Assembly—Cabin air control unit.	1
15-6704-18	Channel Assembly—Cabin air control unit.	1
15-6704-20	Strip—Cabin air control unit (Booth No. 61)	1

AVIALOGS.COM

EQUIPMENT AND FURNISHINGS INSTALLATION

Heating and Ventilating Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-6704-21	Strip—Cabin air control unit (Booth No. 61	1
15-6704-29	Channel Assembly—Cabin air control unit	1
15-6704-46	Gasket—Cabin air control unit	1
15-6704-51	Gasket—Cabin air control unit	1
15-6704-61	Gasket—Cabin air control unit	1
55-6704-400	Duct Assembly—Cabin air control	1
55-6704-36	Gasket—Cabin air control unit	1
55-6704-57	Gasket—Cabin air control unit	1
55-6704-81	Gasket—Cabin air control unit	1
1-16761	Brace—Heat exchange tie	1
55-6705-9	Filler—Units and cables	1
55-6705-16	Filler—Units and cables	1
6-8656	Radiator Assembly—Heating system	1
6-8656-1	Support Assembly—Heating system radiator LH	1
6-8656-6	Support Assembly—Heating system radiator RH	1
6-8656-12	Paper—Heating system radiator asbestos (Johns Manville Co.)	2
6-8824	Radiator—Heating system	1
6-8829	Insulation Installation—Radiator cabin air	1
6-8829-1	Stonefelt—Radiator cabin air insulation	1
6-8829-5	Skyfelt—Radiator cabin air insulation (Seaman Paper Co.)	1
6-8829-6	Skyfelt—Radiator cabin air insulation (Seaman Paper Co.)	1
6-8829-7	Skyfelt—Radiator cabin air insulation (Seaman Paper Co.)	1
6-8829-8	Skyfelt—Radiator cabin air insulation (Seaman Paper Co.)	1
6-8829-9	Skyfelt—Radiator cabin air insulation (Seaman Paper Co.)	1
6-8829-10	Skyfelt—Radiator cabin air insulation (Seaman Paper Co.)	1
55-6705-5	Gasket—Cabin heat units and cables	4
55-6705-6	Gasket—Cabin heat units and cables	4
9-3270	Bracket Assembly—Cabin air control	1
9-3270-1	Bracket Assembly—Cabin air control	1
BAC1614-52	Spacer—⅛ rivet	2
BAC1603-29	Spacer—No. 10 bolt	2
BAC1603-52	Spacer—No. 10 bolt	1
BAC1603-12	Spacer—No. 10 bolt	2
6-8658	Duct Assembly—Heat and ventilation	1
41-6063-90-32-3	Angle—9/16 x ¾ aluminum alloy	4
3-12578	Valve Assembly—Heating duct	1
3-12578-10	Valve Assembly—Heating	1
BAC1603-24	Spacer—No. 10 bolt	1
6-8659	Duct Assembly—Heat and ventilation	1
	(Parts List No. 388)	
41-6063-90-32-3	Angle—9/16 x ¾ aluminum alloy	2
1-20337	Angle	2
3-12579-7	Valve Assembly—Heating duct	1
3-12578-9	Valve Assembly—Heating	1
41-468-56-12	Clamp—Square loop type	1
BAC1603-24	Spacer—No. 10 bolt	2
BAC1603-80	Spacer—No. 10 bolt	1
15-6703	Duct Assembly—Cold air	1
15-6703-1	Duct Assembly—Cold air	1
15-6703-10	Duct Assembly—Cold air	1
15-6703-25	Duct Assembly—Spot-weld (used on -1)	1
15-6703-26	Duct Assembly—Spot-weld (used on -10)	1
3-12572	Flange Assembly—Air duct (used on -10)	1
41-468-56-12	Clamp—Square loop type	1
BAC1603-8	Spacer—No. 10 bolt	1

Heating and Ventilating Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1603-12	Spacer—No. 10 bolt	1
9-3269	Duct Assembly—Cabin air	1
9-3269-13	Duct Assembly—Spot-weld	1
3-12577	Elbow Assembly—Heating	1
41-6063-90-32-3	Angle—9/16 x ¾ aluminum alloy	2
1-16751	Angle—Duct support	1
9-3267	Elbow Assembly—Cabin air duct	1
9-3267-6	Gasket—Cabin air duct elbow	1
9-3267-8	Gasket—Cabin air duct elbow	4
9-3267-9	Duct Assembly—Cabin air	1
1-16661	Flange—Air duct	1
3-12575	Flange Assembly—Air duct	1
51-675-7	Gasket—Corner	2
51-675-8	Gasket—Corner	4
55-6705-7	Brace—Cabin heating units and cables	1
41-468-56-12	Clamp—Square loop type	1
BAC1603-24	Spacer—No. 10 bolt	1
6-8657	Elbow Assembly—Cabin air duct	1
6-8657-6	Flange Assembly—Cabin air duct elbow	1
6-8657-9	Duct Assembly—Spot-weld	1
6-8657-5	Gasket—Cabin air duct elbow	1
6-8657-7	Gasket—Cabin air duct elbow	2
6-8657-8	Gasket—Cabin air duct elbow	3
3-12575	Flange Assembly—Air duct	1
51-675-8	Gasket—Corner	2
1-16762	Clamp—Square loop type	2
3-12576	Transmission Assembly—Heating	1
41-6063-90-32-3	Angle—9/16 x ¾ aluminum alloy	2
1-20337	Angle	1
55-6705-400	Control Assembly—Cabin heating unit and cable	1
BAC1807-108-0L	Cable Assembly—Control	1
BAC1827-23L	Swaged Terminal—Class "D"	1
BAC1828-34	Terminal—Dead end cable	1
AN8004	Cap	2
AN8005	Stop	2
BAC1602-6	Spacer—No. 8 machine screw	2
	(Parts List No. 389)	
55-6705-401	Tube—Cabin heating unit and cables	1
55-6705-402	Casing—Cabin heating unit and cables (Bowdenite No. 13)	1
55-6705-403	Control Assembly—Cabin heating unit and cables	1
BAC1807-120-0L	Cable Assembly—Control	1
BAC1827-23L	Swaged Terminal—Class "D"	1
BAC1828-34	Terminal—Dead end cable	1
AN8004	Cap	2
AN8005	Stop	2
BAC1602-6	Spacer—No. 8 machine screw	2
55-6705-401	Tube—Cabin heating units and cables	1
55-6705-402	Casing—Cabin heating units and cables (Bowdenite No. 13)	1
41-9163	Post—3/32 flex cable casing	4
65-6705-405	Lacing—Cabin heating units and cables	1
BAC1602-48	Spacer—No. 8 machine screw	2
BAC1602-116	Spacer—No. 8 machine screw	1
BAC1807-49-3R	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23R	Swaged Terminal—Class "D"	1
BAC1828-34	Terminal—Dead end cable	1
BAC1807-58-0R	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23R	Swaged Terminal—Class "D"	1
BAC1828-34	Terminal—Dead end cable	1
15-7386-1	Insulation—Heat and ventilation (Seamans Paper Co.)	1
15-7386-2	Insulation—Heat and ventilation (Seamans Paper Co.)	1

AVIALOGS.COM

EQUIPMENT INSTALLATION

Control Installation—Fire Extinguisher System

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 390)	
65-5715	Control Installation—Fire extinguishing system	1
65-5715-501	Control Assembly—Fire extinguishing system LH	1
65-5715-502	Control Assembly—Fire extinguishing system RH	1
65-5715-500	Handle Assembly—Fire extinguisher control (government furnished)	2
BAC1805-115-5	Cable Assembly—3/32—7 x 7 control	1
BAC1805-121-0	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	2
BAC1828-34	Terminal—Dead end cable	1L
41-4198	Link—Control cable	4
21-5180	Spring—Tension	2
BAC1603-18	Spacer—No. 10 bolt	2
41-5949-40-13	Washer—.040 aluminum alloy alclad	2
3-12035	Fair-lead Installation—Fire extinguisher	1
3-12035-3	Fair-lead Assembly—Fire extinguisher	1
3-12035-1	Fair-lead—Half—fire extinguisher	1
3-12035-2	Fair-lead—Half—fire extinguisher	1
3-10758	Support Assembly—CO_2 bottle control	2
3-10758-1	Bracket Assembly—Weld—normalize	2
41-9163	Post—3/32 flexible cable casing	2

Control Installation—Fire Extinguisher System

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1604-8	Spacer—¼ bolt	2
41-5949-40-17	Washer—.040 aluminum alloy alclad	2
BAC1826-3	Swaged Terminal—Class "B"	2
1-13898-7D	Clip—Tube connection	2
BAC1602-16	Spacer—No. 8 machine screw	5
21-9221	Spacer—Nut plate	2
41-5743	Fairlead—Fire extinguisher	2
1-19002-15	Fair-lead Assembly—2 hole	1
1-19002-16	Fairlead—2 holes	1
1-19002-17	Fair-lead—2 holes	1
1-19001-97	Fair-lead Assembly—1 hole	1
1-19001-94	Fair-lead—Half—1 hole	1
1-19001-96	Fair-lead—Half—1 hole	1
AN8004	Cap	4
AN8005	Stop	4
65-5715-9	Casing—Handle—fire extinguisher control LH	1
65-5715-10	Casing—Handle—fire extinguisher control RH	1
65-5715-11	Tube—Handle—fire extinguisher control LH	1
65-5715-12	Tube—Handle—fire extinguisher control RH	1
65-5715-16	Tube—Handle—fire extinguisher control LH	1
65-5715-17	Tube—Handle—fire extinguisher control RH	1

EQUIPMENT AND FURNISHINGS INSTALLATION

Fire Extinguisher Installation—Engine

	(Parts List No. 391)	
65-5679	Fire Extinguisher Installation—Engine	1
65-5679-467	Cylinder Assembly—CO_2 engine fire	2
65-5679-407	Valve Assembly—CO_2 engine fire (government furnished)	1
1-17350	Channel—Tube support	2
21-4585-96-20	Clamp—Tab square tube	1
41-9007-1	Angle—Tube support	5
41-1065-3	Clamp—¾ wide barrel	4
41-1065-6	Clamp—¾ wide barrel	4
51-638-1	Fair-lead—Tube support	6
41-9007	Angle Installation—Tube support	8
37A5430	Plug—CO^2 discharge (government furnished)	8
BAC540-4	Clamp—Loop type cushioned	8
BAC540-16	Clamp—Loop type cushioned	1
BAC540-8	Clamp—Loop type cushioned	121
BAC1603-24	Spacer—No. 10 bolt	3
BAC1603-8	Spacer—No. 10 bolt	2
BAC1603-80	Spacer—No. 10 bolt	1
65-5679-522	Tube—Engine fire extinguisher	1
65-5679-523	Tube—Engine fire extinguisher	1
65-5679-524	Tube—Engine fire extinguisher	1
65-5679-525	Tube—Engine fire extinguisher	1
65-5679-526	Tube—Engine fire extinguisher	1
65-5679-529	Tube—Engine fire extinguisher	1
65-5679-530	Tube—Engine fire extinguisher	1
65-5679-535	Tube—Engine fire extinguisher	1
65-5679-536	Tube—Engine fire extinguisher	1
65-5679-537	Tube—Engine fire extinguisher	1
65-5679-538	Tube—Engine fire extinguisher	1
65-5679-539	Tube—Engine fire extinguisher	1
65-5679-540	Tube—Engine fire extinguisher	1
65-5679-541	Lacing—Engine fire extinguisher	1
65-5679-400	Tube—Engine fire extinguisher	1
65-5679-401	Tube—Engine fire extinguisher	1
65-5679-402	Tube—Engine fire extinguisher	1
65-5679-408	Tube—Engine fire extinguisher	1
65-5679-411	Tube—Engine fire extinguisher	1
65-5679-421	Tube—Engine fire extinguisher (government furnished)	2
65-5679-422	Tube—Engine fire extinguisher (government furnished)	2

Fire Extinguisher Installation—Engine

65-5679-424	Tube—Engine fire extinguisher	1
65-5679-425	Tube—Engine fire extinguisher	1
65-5679-426	Tube—Engine fire extinguisher	1
65-5679-431	Tube—Engine fire extinguisher	1
65-5679-432	Tube—Engine fire extinguisher	1
65-5679-439	Tube—Engine fire extinguisher	1
65-5679-440	Tube—Eng ne fire extinguisher	1
65-5679-441	Tube—Engine fire extinguisher	1
65-5679-448	Tube—Engine fire extinguisher	1
65-5679-450	Tube—Engine fire extinguisher	1
65-5679-451	Tube—Engine fire extinguisher	1
65-5679-460	Tube—Engine fire extinguisher	1
65-5679-461	Tube—Engine fire extinguisher	1
65-5679-462	Tube—Engine fire extinguisher	1
	(Parts List No. 392)	
65-5679-468	Tube—Engine fire extinguisher (government furnished)	1
65-5679-469	Tube—Engine fire extinguisher (government furnished)	1
65-5679-470	Tube—Engine fire extinguisher (government furnished)	1
65-5679-471	Tube—Engine fire extinguisher (government furnished)	1
65-5679-500	Tube—Engine fire extinguisher	1
65-5679-501	Tube—Engine fire extinguisher	1
65-5679-502	Tube—Engine fire extinguisher	1
65-5679-503	Tube—Engine fire extinguisher	1
65-5679-504	Tube—Engine fire extinguisher	1
65-5679-505	Tube—Engine fire extinguisher	1
65-5679-506	Tube—Engine fire extinguisher	1
65-5679-507	Tube—Engine fire extinguisher	1
65-5679-508	Tube—Engine fire extinguisher	1
65-5679-509	Tube—Engine fire extignuisher	1
65-5679-510	Tube—Engine fire extinguisher	1
65-5679-511	Tube—Engine fire extinguisher	1
65-5679-512	Tube—Engine fire extinguisher	1
65-5679-513	Tube—Engine fire extinguisher	1
65-5679-514	Tube—Engine fire extinguisher	1
65-5679-515	Tube—Engine fire extinguisher	1
65-5679-516	Tube—Engine fire extinguisher	1
65-5679-517	Tube—Engine fire extinguisher	1

AVIALOGS.COM

EQUIPMENT AND FURNISHINGS INSTALLATION

Fire Extinguisher Installation—Engine

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-5679-518	Tube—Engine fire extinguisher	1
65-5679-519	Tube—Engine fire extinguisher	1
65-5679-520	Tube—Engine fire extinguisher	1
65-5679-521	Tube—Engine fire extinguisher	1

Tubing Installation—Vacuum System

(Parts List No. 393)

65-5594	Tubing Installation—Vacuum system	1
15-7515	Valve Installation—De-icer and vacuum	1
15-7515-20	Manifold Assembly—De-icer and vacuum valve	1
15-7515-21	Tube—De-icer and vacuum valve	1
15-7515-26	Tube—De-icer and vacuum valve	1
1-18891	Boss—Vacuum tubing ⅜ P.T.	1
6-9392	Manifold Assembly—Vacuum system	1
6-9392-5	Tube Assembly—Weld—Vacuum system	1
6-9392-6	Tube—Vacuum system manifold	1
6-9392-7	Tube—Vacuum system manifold	1
41-5708-10	Boss—Pressure test	1
D-73914	Valve Assembly—De-icer (Eclipse Aviation Corp., Bendix, New Jersey)	1
15-7579	Support Installation—Vacuum selector valve	1
15-7579-1	Support Assembly—Vacuum selector valve	1
12PVMO	Valve—¾ P.T. figd. cross plug selector replaces BAC1-18461 (Parker Appliance Co.)	1
1-18246	Drum—Valve control	1
41-4023-3-4	Shaft—Control lever	1
41-4231	Yoke—Fuel valve coupling	1
41-4234	Driver—Coupling yoke	1
41-4231-3	Yoke—Fuel valve coupling	1
BAC1603-34	Spacer—No. 10 bolt	4
BAC1608-10	Spacer—½ bolt	1
BAC1608-27	Spacer—½ bolt	1
15-7579-13	Bracket Assembly—Vacuum selector valve support	1
15-7579-3	Plate Assembly—Vacuum selector valve support	1
15-7579-4	Plate Assembly—Vacuum selector valve support	1
1-16656	Housing Assembly—Bearing	2
BAC1603-91	Spacer—No. 10 bolt	2
15-7579-5	Support Assembly—Vacuum selector valve	1
41-7804-1	Fair-lead—Valve shaft	1
1-27613	Fair-lead—Vacuum and de-icer	2
51-938	Fair-lead—Vacuum and de-icer	4
1-19001-13	Fair-lead Assembly—One hole	1
1-19001-12	Fair-lead—One hole	2
41-8959-1	Shaft—De-icer control	1
51-205-1	Shaft—De-icer control	1
51-205-2	Shaft—De-icer control	1
21-4585-96-20	Clamp—Tab square tube	8
BAC540-4	Clamp—Loop type cushioned	4
BAC540-16	Clamp—Loop type cushioned	15
BAC540-20	Clamp—Loop type cushioned	6
BAC535-16	Clamp—Hose	4
BAC535-22	Clamp—Hose	26
BAC535-28	Clamp—Hose	6
BAC540-10	Clamp—Loop type cushioned	1
BAC1603-8	Spacer—No. 10 bolt	12
BAC1603-20	Spacer—No. 10 bolt	1
BAC1603-56	Spacer—No. 10 bolt	1

(Parts List No. 394)

BAC1608-8	Spacer—½ bolt	1
066654	Handle—Fuel cock control	1
15-7515-7	Tube Assembly—De-Icer and vacuum valve	1
15-7515-9	Tube Assembly—De-Icer and vacuum valve	1
15-7515-12	Tube Assembly—De-Icer and vacuum valve	1
15-7515-13	Tube Assembly—De-Icer and vacuum valve	1

Tubing Installation—Vacuum System

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7515-15	Tube Assembly—De-icer and vacuum valve	1
15-7515-16	Tube Assembly—De-icer and vacuum valve	1
15-7515-17	Tube Assembly—De-icer and vacuum valve	1
15-7515-1	Tube—De-icer and vacuum valve	1
15-7515-2	Tube—De-icer and vacuum valve	1
15-7515-3	Tube—De-icer and vacuum valve	1
15-7515-4	Tube—De-icer and vacuum valve	1
15-7515-5	Tube—De-icer and vacuum valve	1
15-7515-6	Tube—De-icer and vacuum valve	1
15-7515-11	Tube—De-icer and vacuum valve	1
15-7515-14	Tube—De-icer and vacuum valve	1
15-7515-18	Tube—De-icer and vacuum valve	1
15-7515-19	Tube—De-icer and vacuum valve	1
15-7515-24	Tube—De-icer and vacuum valve	1
15-7515-25	Tube—De-icer and vacuum valve	1
217-HA	Valve Assembly—Pressure relief—1 inch nose drive (Pump Engine Service Corp.)	2
557-5	Valve—Vacuum check (Eclipse Aviation) (replaces 41-9744) (Bendix Aviation Corp.)	4
41-9007	Angle Instrument—Tube support	17
41-3034	Angle—Tubing support	2
1-17350	Channel—Tube support	1
Spec. 95-28368	Valve—Relief vacuum system tubing (Government furnished)	6
46-6684-405	Separated Assembly—Oil	1
46-6684-8	Washer—Oil separator	1
46-6684-406	Casing Assembly—Weld oil separator	1
46-6684-407	Tube Assembly—Weld	1
46-6684-400	Tube—Oil separator	1
46-6684-404	Name Plate—Oil separator	1
46-6684-401	Spiral—Oil separator	1
41-9791-1	Casing—Oil separator	1
41-9962	Valve—Oil separator	1
41-4972	Cap—Oil separator	1
41-4971	Spring—Compression	1
41-1464-30-16	Washer—.025 aluminum alloy	4
41-9290-3	Fair-lead—Tube support	4
21-4585-42-12	Clamp—Tab—square tube	1
41-468-56-12	Clamp—Square loop type	1
41-9290-4	Fair-lead—Tube support	4
BAC540-8	Clamp—Loop type cushioned	33
BAC540-14	Clamp—Loop type cushioned	2
BAC540-16	Clamp—Loop type cushioned	42
BAC540-20	Clamp—Loop type cushioned	2
BAC1603-8	Spacer—No. 10 bolt	2
BAC1603-16	Spacer—No. 10 bolt	1
BAC1603-24	Spacer—No. 10 bolt	6
BAC1603-28	Spacer—No. 10 bolt	1

(Parts List No. 395)

BAC1603-32	Spacer—No. 10 bolt	2
BAC1603-64	Spacer—No. 10 bolt	5
BAC535-14	Clamp—Hose	40
BAC535-22	Clamp—Hose	110
65-5594-427	Tube—Vacuum system	1
65-5594-500	Tube—Vacuum system	1
65-5594-501	Tube—Vacuum system	1
65-5594-502	Tube—Vacuum system	1
65-5594-503	Tube—Vacuum system	1
65-5594-504	Tube—Vacuum system	1
65-5594-505	Tube—Vacuum system	1
65-5594-509	Spacer—Vacuum system	1
65-5594-510	Spacer—Vacuum system	1
65-5594-511	Spacer—Vacuum system	1
65-5594-512	Spacer—Vacuum system	1
65-5594-513	Spacer—Vacuum system	1
65-5594-514	Tube—Vacuum system	1
65-5594-515	Tube—Vacuum system	1
65-5594-516	Tube—Vacuum system	1
65-5594-517	Tube—Vacuum system	1
65-5594-518	Tube—Vacuum system	1
65-5594-519	Tube—Vacuum system	1

AVIALOGS.COM

EQUIPMENT AND FURNISHINGS INSTALLATION

Tubing Installation—Vacuum System

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-5594-520	Tube—Vacuum system	1
65-5594-521	Tube—Vacuum system	1
65-5594-522	Tube—Vacuum system	1
65-5594-523	Tube—Vacuum system	1
65-5594-524	Tube—Vacuum system	1
65-5594-525	Tube—Vacuum system	1
65-5594-526	Tube—Vacuum system	1
65-5594-527	Tube—Vacuum system	1
65-5594-528	Tube—Vacuum system	1
65-5594-529	Tube—Vacuum system	1
65-5594-530	Tube—Vacuum system	1
65-5594-531	Tube—Vacuum system	1
65-5594-533	Tube—Vacuum system	1
65-5594-534	Tube—Vacuum system	1
65-5594-535	Tube—Vacuum system	1
65-5594-536	Tube—Vacuum system	1
65-5594-537	Tube—Vacuum system	1
65-5594-538	Tube—Vacuum system	1

Tubing Installation—Vacuum System

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-5594-539	Tube—Vacuum system	1
65-5594-540	Tube—Vacuum system	1
65-5594-541	Tube—Vacuum system	1
65-5594-542	Tube—Vacuum system	1
65-5594-543	Tube—Vacuum system	1
65-5594-544	Tube—Vacuum system	1
65-5594-545	Tube—Vacuum system	1
65-5594-547	Tube—Vacuum system	1
65-5594-548	Tube—Vacuum system	1
65-5594-549	Tube—Vacuum system	1
65-5594-550	Tube—Vacuum system	1
65-5594-551	Tube—Vacuum system	1
65-5594-552	Tube—Vacuum system	1
	(Parts List No. 396)	
65-5594-553	Tube—Vacuum system	1

EQUIPMENT INSTALLATION

De-Icer Installation—Wing and Tail

(Parts List No. 397)

15-7600	De-icer Installation—Wing and tail	1
6-9359	Diagram—De-icer tubing—wing and tail	
49-3133	Valve Installation—De-icer distributor	1
49-3133-400	Unit Assembly—De-icer distributor valve	1
1-17360	Valve Assembly—Rotary distributor n. d. (Eclipse aviation type 574, model 2, drawing D-69450)	1
49-3133-405	Manifold Assembly—De-icer distributor valve	1
49-3133-410	Manifold Assembly—De-icer distributor valve	1
557-5	Valve Assembly—1 inch vacuum check nose drive,(Eclipse Aviation Corp., Bendix, New Jersey, special drawing No. 41-9744)	1
41-9007-1	Angle—Tube support	1
BAC1604-84	Spacer—¼ bolt	4
BAC540-10	Clamp—Loop type cushioned	4
BAC540-16	Clamp—Loop type cushioned	8
BAC535-18	Clamp—Hose	8
BAC535-22	Clamp—Hose	2
BAC1603-16	Spacer—No. 10 bolt	1
BAC1603-32	Spacer—No. 10 bolt	1
BAC1603-40	Spacer—No. 10 bolt	2
BAC1603-44	Spacer—No. 10 bolt	1
BAC1603-72	Spacer—No. 10 bolt	1
41-9007-1	Angle—Tube support	8
51-1094	Fair-lead—2 tubes—⅝ diameter	4
51-1095-1	Fair-lead—2 tubes—⅝ diameter	1
51-1095-2	Fair-lead—2 tubes—⅝ diameter	1
51-1096-1	Fair-lead—3 tubes—⅝ diameter	1
51-1096-2	Fair-lead—3 tubes—⅝ diameter	1
41-8565-1	Fair-lead—2 tubes—⅝ diameter	2
51-1092	Screw—Recessed head	1244
51-1092-1	Screw—Recessed head	14
41-9772	Grommet—⅝ de-icer hose	14
15-7600-30	Manifold Assembly—Wing and tail de-icer	2
15-7600-31	Hose—Wing and tail de-icer manifold (B. F. Goodrich)	2
15-7600-32	Hose—Wing and tail de-icer manifold (B. F. Goodrich)	2
15-7600-33	Hose—Wing and tail de-icer manifold (B. F. Goodrich)	2
46-6318	Manifold Assembly—De-icer	2
46-6318-3	Tube—De-icer manifold	6
46-6318-400	Tube—De-icer manifold de-icer	2
15-7600-35	Manifold Assembly—Wing and tail de-icer	2

De-Icer Installation—Wing and Tail

15-7600-36	Hose—Wing and tail de-icer manifold (B. F. Goodrich)	2
15-7600-37	Hose—Wing and tail de-icer manifold (B. F. Goodrich)	2
15-7600-38	Hose—Wing and tail de-icer manifold (B. F. Goodrich)	2
46-6318-402	Manifold Assembly—De-icer	2
46-6318-5	Tube—De-icer manifold	4
46-6318-401	Tube—De-icer manifold	2
15-7600-34	Manifold Assembly—Wing and tail de-icer	2
15-7600-46	Hose—Wing and tail de-icer (B. F. Goodrich)	2
41-688-3	Manifold—De-icer	2
	(Parts List No. 398)	
15-7600-39	Manifold Assembly—Wing and tail de-icer	2
15-7600-40	Hose—Wing and tail de-icer (B. F. Goodrich)	2
15-7600-41	Hose—Wing and tail de-icer (B. F. Goodrich)	2
46-6318-402	Manifold Assembly—Wing and tail de-icer	2
46-6318-5	Tube—Wing and tail de-icer	4
46-6318-401	Tube—Wing and tail de-icer	2
15-7600-45	Manifold Assembly—Wing and tail de-icer	1
15-7600-44	Hose—Wing and tail de-icer (B. F. Goodrich)	1
15-7600-47	Hose—Wing and tail de-icer (B. F. Goodrich)	1
41-688-3	Manifold—De-icer	1
15-7600-113	Manifold Assembly—Wing and tail de-icer	2
15-7600-114	Hose—Wing and tail de-icer (B. F. Goodrich)	2
15-7600-115	Hose—Wing and tail de-icer (B. F. Goodrich)	2
15-7600-116	Hose—Wing and tail de-icer (B. F. Goodrich)	2
3-10475-3	Manifold Assembly—De-icer	2
3-10475-1	Tube—De-icer manifold	2
3-10475-2	Tube—De-icer manifold	6
15-7600-117	Manifold Assembly—Wing and tail de-icer	2
15-7600-118	Hose—Wing and tail de-icer (B. F. Goodrich)	2
15-7600-119	Hose—Wing and tail de-icer (B. F. Goodrich)	2
15-7600-120	Hose—Wing and tail de-icer (B. F. Goodrich)	2
15-7600-121	Hose—Wing and tail de-icer (B. F. Goodrich)	2
15-7600-122	Hose—Wing and tail de-icer (B. F. Goodrich)	2
15-7600-123	Hose—Wing and tail de-icer (B. F. Goodrich)	2
3-10519-3	Manifold Assembly—De-icer	6
3-10519-1	Tube—De-icer manifold	6
3-10519-2	Tube—De-icer manifold	12
3-11257	Manifold Assembly—De-icer	1
3-11257-1	Tube—De-icer manifold	1
3-11257-2	Tube—De-icer manifold	2
3-11257-3	Tube—De-icer manifold	1
1-21400	Angle Assembly—Support	2

AVIALOGS.COM

EQUIPMENT INSTALLATION

De-Icer Installation—Wing and Tail

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7600-62	Tube Assembly—Wing and tail de-icer	1
15-7600-89	Tube Assembly—Wing and tail de-icer	1
15-7600-131	Tube Assembly—Wing and tail de-icer	1
21-2589-19	Clip—Tab loop type	6
21-2589-23	Clip—Tab loop type	2
41-468-16-3	Clamp—Square loop type	3
41-468-21-6	Clamp—Square loop type	7
41-468-28-8	Clamp—Square loop type	6
41-468-56-12	Clamp—Square loop type	2
41-468-86-24	Clamp—Square loop type	4
41-1065-3	Clamp Assembly—¾ wide barrel	3
41-1734-2	Plug—De-icer term	3
1-18828	Tee Assembly—45° branch	4
1-18828-1	Tube—45° branch tee	4
1-18828-3	Tube—45° Branch tee	4
1-19826	Angle—Tube support	5
	(Parts List No. 399)	
1-19826-1	Angle—Tube support	5
BAC540-8	Clamp—Loop type cushioned	1
BAC540-10	Clamp—Loop type cushioned	53
BAC540-12	Clamp—Loop type cushioned	17
BAC504-16	Clamp—Loop type cushioned	74
BAC1603-24	Spacer—No. 10 bolt	4
BAC1603-32	Spacer—No. 10 bolt	2
BAC1603-64	Spacer—No. 10 bolt	2
BAC1446	Screw—Headlines plug 6-32 rivets	1578
BAC540-16	Clamp—Loop type cushioned	4
BAC1603-64	Spacer—No. 10 bolt	4
BAC535-16	Clamp—Hose	52
BAC535-18	Clamp—Hose	40
BAC535-22	Clamp—Hose	90
FC-163-4-1	Boot—Outboard wing tail de-icer LH (same as C-163-4-1 on Goodrich drawing C-163-4G except edges as per Goodrich drawing B-155-C)	1
FC-163-4-2	Boot—Outboard wing tail de-icer RH (same as C-163-4-2 on Goodrich drawing C-163-4G except edges as per Goodrich drawing B-155-C)	1
FC-163-8-1	Boot—Stabilizer wing and tail de-icer (same as Goodrich C-163-8-1 except edges as per Goodrich drawing B-155-0)	2
FC-163-9-1	Boot—Fin wing and tail de-icer (same as Goodrich C-163-9-C except edges as per Goodrich drawing B-155-C)	1
FC-163-10-1	Boot—Inboard wing tail de-icer LH (Goodrich part PC-163-10. See drawing C-163-10)	1
FC-163-10-2	Boot—Inboard wing tail de-icer RH (Goodrich part PC-163-10-2. See drawing C-163-10)	1
15-7600-9	Fairing—Wing and tail de-icer	2
15-7600-10	Fairing—Wing and tail de-icer	2
15-7600-11	Fairing—Wing and tail de-icer	2
15-7600-12	Fairing—Wing and tail de-icer	2
15-7600-13	Fairing—Wing and tail de-icer	2
15-7600-14	Fairing—Wing and tail de-icer	2
15-7600-15	Fairing—Wing and tail de-icer	2
15-7600-16	Fairing—Wing and tail de-icer	2
15-7600-17	Fairing—Wing and tail de-icer	2
15-7600-18	Fairing—Wing and tail de-icer	1
15-7600-19	Fairing—Wing and tail de-icer	1
15-7600-20	Fairing—Wing and tail de-icer	1
15-7600-21	Fairing—Wing and tail de-icer	1
15-7600-22	Fairing—Wing and tail de-icer	1
15-7600-23	Fairing—Wing and tail de-icer	1
15-7600-24	Fairing—Wing and tail de-icer	1
15-7600-25	Fairing—Wing and tail de-icer	1
15-7600-26	Fairing—Wing and tail de-icer	1
15-7600-27	Strap—Wing and tail de-icer	2
15-7600-28	Strap—Wing and tail de-icer	1
15-7600-48	Tape—Wing and tail de-icer (Bauer & Black)	1
15-7600-49	Plug—Wing and tail de-icer (B. F. Goodrich)	30
15-7600-105	Fairing—Wing and tail de-icer	1

De-Icer Installation—Wing and Tail

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 400)	
15-7600-106	Fairing—Wing and tail de-icer	1
15-7600-107	Fairing—Wing and tail de-icer	1
15-7600-108	Fairing—Wing and tail de-icer	1
15-7600-109	Fairing—Wing and tail de-icer	1
15-7600-110	Fairing—Wing and tail de-icer	1
15-7600-111	Fairing—Wing and tail de-icer	1
15-7600-112	Fairing—Wing and tail de-icer	1
15-7600-105	Fairing—Wing and tail de-icer	1
15-7600-106	Fairing—Wing and tail de-icer	1
15-7600-107	Fairing—Wing and tail de-icer	1
15-7600-108	Fairing—Wing and tail de-icer	1
15-7600-109	Strap—Wing and tail de-icer	1
15-7600-110	Strap—Wing and tail de-icer	1
15-7600-111	Strap—Wing and tail de-icer	1
15-7600-112	Strap—Wing and tail de-icer	1
15-7600-159	Fairing—Wing and tail de-icer	2
15-7600-160	Fairing—Wing and tail de-icer	2
15-7600-161	Fairing—Wing and tail de-icer	2
15-7600-162	Fairing—Wing and tail de-icer	2
15-7600-180	Strap—Wing and tail de-icer	2
15-7600-184	Splice—Wing and tail de-icer	2
15-7600-185	Splice—Wing and tail de-icer	2
15-7600-56	Tube—Wing and tail de-icer	1
15-7600-57	Tube—Wing and tail de-icer	1
15-7600-58	Tube—Wing and tail de-icer	1
15-7600-59	Tube—Wing and tail de-icer	1
15-7600-60	Tube—Wing and tail de-icer	1
15-7600-61	Tube—Wing and tail de-icer	1
15-7600-69	Tube—Wing and tail de-icer	1
15-7600-70	Tube—Wing and tail de-icer	1
15-7600-71	Tube—Wing and tail de-icer	1
15-7600-72	Tube—Wing and tail de-icer	1
15-7600-73	Tube—Wing and tail de-icer	1
15-7600-74	Tube—Wing and tail de-icer	1
15-7600-75	Tube—Wing and tail de-icer	1
15-7600-79	Tube—Wing and tail de-icer	1
15-7600-80	Tube—Wing and tail de-icer	1
15-7600-81	Tube—Wing and tail de-icer	1
15-7600-82	Tube—Wing and tail de-icer	1
15-7600-86	Tube—Wing and tail de-icer	1
15-7600-87	Tube—Wing and tail de-icer	1
15-7600-88	Tube—Wing and tail de-icer	1
15-7600-90	Tube—Wing and tail de-icer	1
15-7600-91	Tube—Wing and tail de-icer	1
15-7600-92	Tube—Wing and tail de-icer	1
15-7600-93	Tube—Wing and tail de-icer	1
15-7600-94	Tube—Wing and tail de-icer	1
15-7600-95	Tube—Wing and tail de-icer	1
15-7600-96	Tube—Wing and tail de-icer	1
15-7600-97	Tube—Wing and tail de-icer	1
15-7600-98	Tube—Wing and tail de-icer	1
15-7600-124	Tube—Wing and tail de-icer	1
15-7600-125	Tube—Wing and tail de-icer	1
	(Parts List No. 401)	
15-7600-126	Tube—Wing and tail de-icer	1
15-7600-127	Tube—Wing and tail de-icer	1
15-7600-128	Tube—Wing and tail de-icer	1
15-7600-129	Tube—Wing and tail de-icer	1
15-7600-130	Tube—Wing and tail de-icer	1
15-7600-132	Tube—Wing and tail de-icer	1
15-7600-133	Tube—Wing and tail de-icer	1
15-7600-134	Tube—Wing and tail de-icer	1
15-7600-135	Tube—Wing and tail de-icer	1
15-7600-136	Tube—Wing and tail de-icer	1
15-7600-137	Tube—Wing and tail de-icer	1
15-7600-138	Tube—Wing and tail de-icer	1
15-7600-139	Tube—Wing and tail de-icer	1
15-7600-140	Tube—Wing and tail de-icer	1
15-7600-141	Tube—Wing and tail de-icer	1

AVIALOGS.COM

EQUIPMENT INSTALLATION

De-Icer Installation—Wing and Tail

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7600-142	Tube—Wing and tail de-icer	1
15-7600-143	Tube—Wing and tail de-icer	1
15-7600-144	Tube—Wing and tail de-icer	1
15-7600-145	Tube—Wing and tail de-icer	1
15-7600-146	Tube—Wing and tail de-icer	1
15-7600-149	Tube—Wing and tail de-icer	2
15-7600-150	Tube—Wing and tail de-icer	1
15-7600-151	Tube—Wing and tail de-icer	1
15-7600-152	Tube—Wing and tail de-icer	1
15-7600-157	Tube—Wing and tail de-icer	1
15-7600-158	Tube—Wing and tail de-icer	1
15-7600-29	Tube—Wing and tail de-icer	1
15-7600-197	Tube—Wing and tail de-icer	1
15-7600-198	Tube—Wing and tail de-icer	1

De-Icer Installation—Wing and Tail

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7600-199	Tube—Wing and tail de-icer	1
15-7600-200	Tube—Wing and tail de-icer	1
15-7600-201	Tube—Wing and tail de-icer	1
15-7600-202	Tube—Wing and tail de-icer	1
15-7600-203	Tube—Wing and tail de-icer	1
15-7600-204	Tube—Wing and tail de-icer	1
15-7600-205	Tube—Wing and tail de-icer	1
15-7600-206	Tube—Wing and tail de-icer	1
15-7600-207	Tube—Wing and tail de-icer	1
15-7600-208	Tube—Wing and tail de-icer	1
15-7600-209	Tube—Wing and tail de-icer	1
15-7600-210	Tube—Wing and tail de-icer	1
15-7600-211	Tube—Wing and tail de-icer	1
15-7600-212	Tube—Wing and tail de-icer	1

EQUIPMENT AND FURNISHINGS INSTALLATION

Hydraulic System Installation

(Parts List No. 402)

75-5821	Hydraulic system installation	1
	Dash number parts, shown on 75-5821 drawing are represented by dash numbers of 65-5821.	
6-8273	Diagram—Hydraulic system	
65-6055-415	Units Installation—Hydraulic system (PL 408-409)	1
49-2776	Bracket Installation—Hydraulic tank	1
49-2776-406	Bracket Assembly—Hydraulic tank	1
51-242	Fair-lead—Cable support	2
49-2776-407	Strap Assembly—Hydraulic tank bracket	4
49-2776-404	Cushion—Hydraulic tank bracket (adelite No. 50)	4
41-7771	Strap Assembly—Hydraulic tank support	4
41-7771-1	Strap—Hydraulic tank support	4
75-5821-705	Reservoir Assembly—Hydraulic system	1
9-3609-8	Tank Assembly—Hydraulic system	1
9-3609-1	Tank Assembly—Weld—hydraulic system	1
21-2089	Flange—⅜ pipe thread	2
41-8819	Flange—½ P.T. tank	2
41-4558	Clip—Fuel tank	1
41-9526	Flange—¾ pipe thread	1
41-3796	Plate—Sight cage flange	1
1-21079	Plate—Indicator—hydraulic tank capacity	1
41-5248	Plate—Plexiglas	1
41-3797	Gasket—Sight gage	2
1-20350	Tag—Special hydraulic fluid	1
65-5821-601	Valve Assembly—Check hydraulic system	1
41-7060-1	Valve Assembly—Nipple—800# square inch—check (Aircraft Accessories Corp., Glendale, Cal., No. 34010)	1
41-9007	Angle Installation—Tube support	6
41-3034	Angle—Tube support	1
BAC540-8	Clamp—Loop type cushioned	69
51-235	Valve Assembly—⅝ automatic shut-off—(Aero Supply Co., Corry, Pa., No. 53972)	1
51-674	Valve Assembly—Double ball check ½ p. t. ND (Aircraft Accessories Corp., Glendale, Cal., No. 34017B)	1
1-20327	Bracket—Tube support	1
65-5821-558	Accumulator Assembly—Hydraulic system (Vickers, Inc., Detroit, Mich., No. E58278)	1
43-11574	Pump Assembly—Auxiliary hydraulic hand	1
41-9818	Plate—Name	1
41-9819	Pump Assembly—Auxiliary hydraulic hand ND (Pump Engine Service Corp. Cleveland, Ohio, No. 260)	1
BAC1447-6-6	Screw—Round-head recessed sheet metal	4

Hydraulic System Installation

(Parts List No. 403)

51-636	Fair-lead—Tube support	2
41-9007	Angle Installation—Tube support	2
21-4844-60	Jumper Assembly—No. 10-10 terminal bonding	1
BAC820-10	Terminal—Lock	2
41-468-86-24	Clamp—Square loop type	2
41-3034	Angle—Tubing support	3
41-9007	Angle Installation—Tube support	17
39B846B10	Adapter—Hydraulic hose	2
41-9290-3	Fair-lead—Tube support	4
1-13892-70-16	Clamp—Tabulated square	2
39G1030-8-21	Hose Assembly—Hydraulic	2
39G1030-10W16	Hose Assembly—Hydraulic	1
39G1030-10W18	Hose Assembly—Hydraulic	1
39B1024-10	Nut—Hydraulic hose check	1
40A4334-8	Adapter—Union filling	2
40A4335-8	Nut—Union filling adapter	2
40A4336-8	Gasket—Union filling adapter	2
3-14999	Bracket—Test connector support	1
1-17249-1	Gasket—Hydraulic hose	1
15-7689	Tubing Installation—Cowl flaps	1
15-7689-164	Lacing—Cowl flap tubing	1
15-7689-166	Valve Assembly—Cowl flap tubing	1
15-7689-172	Valve—Needle—cowl flaps tubing	1
39G1030-6W-33	Hose—Hydraulic	8
BAC540-6	Clamp—Loop type cushioned	174
BAC540-14	Clamp—Loop type cushioned	8
1-19005-1	Fair-lead Assembly—5 holes	1
1-19005-2	Fair-lead—5 holes	2
1-19004-13	Fair-lead Assembly—4 holes	1
1-19004-14	Fair-lead—4 holes	2
21-2589-19	Clip—Tab loop type	1
41-3034	Angle—Tubing support	1
1-20022	Angle—Tube support	2
39B1024-6	Nut—Hydraulic hose check	8
15-7689-1	Tube Assembly—Cowl flaps	1
15-7689-2	Tube Assembly—Cowl flaps	1
15-7689-4	Tube Assembly—Cowl flaps	1
15-7689-5	Tube Assembly—Cowl flaps	1
15-7689-6	Tube Assembly—Cowl flaps	1
15-7689-8	Tube Assembly—Cowl flaps	1
15-7689-10	Tube Assembly—Cowl flaps	1
15-7689-12	Tube Assembly—Cowl flaps	1
15-7689-14	Tube Assembly—Cowl flaps	1
15-7689-15	Tube Assembly—Cowl flaps	1
15-7689-17	Tube Assembly—Cowl flaps	1
15-7689-20	Tube Assembly—Cowl flaps	1
15-7689-24	Tube Assembly—Cowl flaps	1
15-7689-25	Tube Assembly—Cowl flaps	1
15-7689-27	Tube Assembly—Cowl flaps	1

AVIALOGS.COM

EQUIPMENT AND FURNISHINGS INSTALLATION

Hydraulic System Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7689-28	Tube Assembly—Cowl flaps	1
15-7689-29	Tube Assembly—Cowl flaps	1
15-7689-32	Tube Assembly—Cowl flaps	1
	(Parts List No. 404)	
15-7689-34	Tube Assembly—Cowl flaps	1
15-7689-36	Tube Assembly—Cowl flaps	1
15-7689-37	Tube Assembly—Cowl flaps	1
15-7689-39	Tube Assembly—Cowl flaps	1
15-7689-40	Tube Assembly—Cowl flaps	1
15-7689-44	Tube Assembly—Cowl flaps	1
15-7689-48	Tube Assembly—Cowl flaps	1
15-7689-49	Tube Assembly—Cowl flaps	1
15-7689-50	Tube Assembly—Cowl flaps	1
15-7689-51	Tube Assembly—Cowl flaps	1
15-7689-52	Tube Assembly—Cowl flaps	1
15-7689-53	Tube Assembly—Cowl flaps	1
15-7689-54	Tube Assembly—Cowl flaps	1
15-7689-56	Tube Assembly—Cowl flaps	1
15-7689-58	Tube Assembly—Cowl flaps	1
15-7689-60	Tube Assembly—Cowl flaps	1
15-7689-62	Tube Assembly—Cowl flaps	1
15-7689-63	Tube Assembly—Cowl flaps	1
15-7689-65	Tube Assembly—Cowl flaps	1
15-7689-68	Tube Assembly—Cowl flaps	1
15-7689-69	Tube Assembly—Cowl flaps	1
15-7689-70	Tube Assembly—Cowl flaps	1
15-7689-72	Tube Assembly—Cowl flaps	1
15-7689-73	Tube Assembly—Cowl flaps	1
15-7689-74	Tube Assembly—Cowl flaps	1
15-7689-77	Tube Assembly—Cowl flaps	1
15-7689-79	Tube Assembly—Cowl flaps	1
15-7689-81	Tube Assembly—Cowl flaps	1
15-7689-82	Tube Assembly—Cowl flaps	1
15-7689-84	Tube Assembly—Cowl flaps	1
15-7689-85	Tube Assembly—Cowl flaps	1
15-7689-89	Tube Assembly—Cowl flaps	1
15-7689-90	Tube Assembly—Cowl flaps	1
15-7689-91	Tube Assembly—Cowl flaps	1
15-7689-92	Tube Assembly—Cowl flaps	1
15-7689-93	Tube Assembly—Cowl flaps	1
15-7689-94	Tube Assembly—Cowl flaps	1
15-7689-95	Tube Assembly—Cowl flaps	1
15-7689-96	Tube Assembly—Cowl flaps	1
15-7689-98	Tube Assembly—Cowl flaps	1
15-7689-100	Tube Assembly—Cowl flaps	1
15-7689-104	Tube Assembly—Cowl flaps	1
15-7689-106	Tube Assembly—Cowl flaps	1
15-7689-107	Tube Assembly—Cowl flaps	1
15-7689-108	Tube Assembly—Cowl flaps	1
15-7689-109	Tube Assembly—Cowl flaps	1
15-7689-110	Tube Assembly—Cowl flaps	1
15-7689-111	Tube Assembly—Cowl flaps	1
15-7689-114	Tube Assembly—Cowl flaps	1
15-7689-116	Tube Assembly—Cowl flaps	1
15-7689-118	Tube Assembly—Cowl flaps	1
15-7689-119	Tube Assembly—Cowl flaps	1
15-7689-122	Tube Assembly—Cowl flaps	1
	(Parts List No. 405)	
15-7689-123	Tube Assembly—Cowl flaps	1
15-7689-124	Tube Assembly—Cowl flaps	1
15-7689-126	Tube Assembly—Cowl flaps	1
15-7689-127	Tube Assembly—Cowl flaps	1
15-7689-128	Tube Assembly—Cowl flaps	1
15-7689-130	Tube Assembly—Cowl flaps	1
15-7689-132	Tube Assembly—Cowl flaps	1
15-7689-136	Tube Assembly—Cowl flaps	1
15-7689-137	Tube Assembly—Cowl flaps	1
15-7689-138	Tube Assembly—Cowl flaps	1
15-7689-139	Tube Assembly—Cowl flaps	1

Hydraulic System Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7689-140	Tube Assembly—Cowl flaps	1
15-7689-143	Tube Assembly—Cowl flaps	1
15-7689-145	Tube Assembly—Cowl flaps	1
15-7689-148	Tube Assembly—Cowl flaps	1
15-7689-151	Tube Assembly—Cowl flaps	1
15-7689-165	Tube Assembly—Cowl flaps	1
15-7689-167	Tube Assembly—Cowl flaps	1
15-7689-168	Tube Assembly—Cowl flaps	1
15-7689-169	Tube Assembly—Cowl flaps	1
15-7689-170	Tube Assembly—Cowl flaps	1
15-7689-171	Tube Assembly—Cowl flaps	1
15-7689-173	Tube Assembly—Cowl flaps	1
BAC540-10	Clamp—Loop type cushioned	52
BAC540-4	Clamp—Loop type cushioned	3
BAC540-14	Clamp—Loop type cushioned	1
BAC540-16	Clamp—Loop type cushioned	26
BAC1602-32	Spacer—No. 8 machine screw	1
BAC1603-8	Spacer—No. 10 bolt	2
BAC1603-16	Spacer—No. 10 bolt	6
BAC1603-20	Spacer—No. 10 bolt	3
BAC1603-24	Spacer—No. 10 bolt	1
BAC1603-32	Spacer—No. 10 bolt	13
BAC1603-40	Spacer—No. 10 bolt	2
BAC1603-64	Spacer—No. 10 bolt	2
BAC1603-96	Spacer—No. 10 bolt	1
6-9595	Valve Installation—Hydraulic shut-off	1
3-13927	Valve Assembly—Hydraulic shut-off (Adel Precision Corp., 231 S. Olive Ave., Burbank, Cal., No. D-9647-1)	1
1-19835	Handle—Hydraulic shut-off valve	1
1-20000	Bracket—Hydraulic shut-off valve	1
1-20208	Dial—Specification check valve	1
BAC1603-12	Spacer—No. 10 bolt	3
1-18660	Switch—Pressure warning	1
41-9007-1	Angle—Support	8
41-9290-4	Fair-lead—Tube support	2
75-5821-700	Tube—Hydraulic system	1
75-5821-704	Tube—Hydraulic system	1
75-5821-706	Tube—Hydraulic system	1
65-5821-602	Test Connecting Assembly—Hydraulic system	1
1-20328	Cap Assembly—Hydraulic test connecting	1
1-20328-1	Tube—Hydraulic test connecting cap	1
	(Parts List No. 406)	
51-235	Valve Assembly—⅝ automatic shut-off (Aero Supply Co., Corry, Pa., No. 53972)	1
65-5821-604	Tee Assembly—Hydraulic system	1
41-7060-1	Valve Assembly (Aircraft Accessory Corp., Glendale, Cal., No. 34010)	1
65-5821-605	Fitting Assembly—Hydraulic system	1
65-5821-606	Fitting Assembly—Hydraulic system	1
21-2545-1	Nipple—Restriction	1
65-5821-607	Fitting Assembly—Hydraulic system	1
65-5821-2	Tube—Hydraulic system	1
65-5821-18	Tube—Hydraulic system	1
65-5821-32	Tube—Hydraulic system	1
65-5821-34	Tube—Hydraulic system	1
65-5821-40	Tube—Hydraulic system	1
65-5821-44	Tube—Hydraulic system	1
65-5821-118	Tube—Hydraulic system	1
65-5821-408	Tube—Hydraulic system	1
65-5821-429	Tube—Hydraulic system	1
65-5821-431	Tube—Hydraulic system	1
65-5821-437	Tube—Hydraulic system	1
65-5821-443	Tube—Hydraulic system	1
65-5821-444	Tube—Hydraulic system	1
65-5821-448	Tube—Hydraulic system	1
65-5821-501	Tube—Hydraulic system	1
65-5821-503	Tube—Hydraulic system	1
65-5821-504	Tube—Hydraulic system	1
65-5821-507	Tube—Hydraulic system	1
65-5821-508	Tube—Hydraulic system	1

AVIALOGS.COM

EQUIPMENT AND FURNISHINGS INSTALLATION

Hydraulic System Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-5821-509	Tube—Hydraulic system	1
65-5821-510	Tube—Hydraulic system	1
65-5821-511	Tube—Hydraulic system	1
65-5821-514	Tube—Hydraulic system	1
65-5821-505	Tube—Hydraulic system	1
65-5821-506	Tube—Hydraulic system	1
65-5821-525	Tube—Hydraulic system	1
65-5821-526	Tube—Hydraulic system	1
65-5821-527	Tube—Hydraulic system	1
65-5821-530	Tube—Hydraulic system	1
65-5821-531	Tube—Hydraulic system	1
65-5821-535	Tube—Hydraulic system	1
65-5821-536	Tube—Hydraulic system	1
65-5821-540	Tube—Hydraulic system	1
65-5821-541	Tube—Hydraulic system	1
65-5821-543	Tube—Hydraulic system	1
65-5821-544	Tube—Hydraulic system	1
65-5821-545	Tube—Hydraulic system	1
65-5821-547	Tube—Hydraulic system	1
65-5821-548	Tube—Hydraulic system	1
65-5821-549	Tbue—Hydraulic system	1
65-5821-551	Tube—Hydraulic system	1
65-5821-552	Tube—Hydraulic system	1
65-5821-553	Tube—Hydraulic system	1
65-5821-554	Tube—Hydraulic system	1
	(Parts List No. 407)	
65-5821-555	Tube—Hydraulic system	1
65-5821-556	Tube—Hydraulic system	1

Hydraulic System Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-5821-557	Tube—Hydraulic system	1
65-5821-562	Tube—Hydraulic system	1
65-5821-563	Tube—Hydraulic system	1
65-5821-564	Tube—Hydraulic system	1
65-5821-565	Tube—Hydraulic system	1
65-5821-569	Tube—Hydraulic system	1
65-5821-584	Tube—Hydraulic system	1
65-5821-583	Tube—Hydraulic system	1
65-5821-581	Tube—Hydraulic system	1
65-5821-578	Tube—Hydraulic system	1
65-5821-582	Tube—Hydraulic system	1
65-5821-577	Tube—Hydraulic system	1
65-5821-576	Tube—Hydraulic system	1
65-5821-579	Tube—Hydraulic system	1
65-5821-586	Tube—Hydraulic system	1
65-5821-595	Tube—Hydraulic system	1
65-5821-594	Tube—Hydraulic system	1
65-5821-588	Tube—Hydraulic system	1
65-5821-587	Tube—Hydraulic system	1
65-5821-574	Tube—Hydraulic system	1
65-5821-592	Tube—Hydraulic system	1
65-5821-593	Tube—Hydraulic system	1
65-5821-589	Tube—Hydraulic system	1
65-5821-590	Tube—Hydraulic system	1
65-5821-591	Tube—Hydraulic system	1
65-5821-596	Tube—Hydraulic system	1
65-5821-598	Tube—Hydraulic system	1
65-5821-599	Tube—Hydraulic system	1
65-5821-600	Tube—Hydraulic system	1
65-5821-603	Tube—Hydraulic system	1

HYDRAULIC SYSTEM INSTALLATION

Units Installation—Hydraulic System

(Parts List No. 408)

65-6055-415	Units Installation—Hydraulic system	1
	Dash number parts, shown on 65-6055 drawing are represented by dash numbers of 55-6055.	
65-6055-500	Cap—Hydraulic system units	1
55-6055-411	Units Assembly—Regulator valve	1
55-6055-13	Tube	1
6-6244	Valve Assembly—Hydraulic regulator	1
3-9466	Housing—Hydraulic regulator valve	1
41-3427	Piston and Rod Assembly—Regulator valve	1
41-3427-1	Piston—Regulator valve	1
41-8878	Rod—Regulator valve piston	1
41-3430	Piston Guide—Regulator valve	1
21-3894-56-26	Washer—Retaining	4
41-3433	Packing—Rings—regulator valve	1
41-3433-1	Packing—Rings—regulator valve	1
6-6244-1	Packing—Chevron hydraulic regulator valve	2
6-6244-3	Guide Assembly—Ball hydraulic regulator valve	1
6-6244-2	Ball—Hydraulic regulator valve	1
41-3424	Ball—Guide—regulator valve	1
41-6196-1	Washer—Copper	1
41-6277	Ball Seat Assembly—Regulator valve	1
41-6277-1	Housing—Ball seat	1
41-3426	Ball—Seat—regulator valve	1
41-3429	Packing—Holder—regulator valve	1
41-6200	Spring—Compression	1
41-3428	Spring—Compression	1
41-6184	Spring—Guide—regulator valve	1
41-6196	Washer—Copper	1
41-7060-1	Valve—800 lb. sq. in check (Aircraft Accessory Corp., Glendale, Cal., No. 34010)	1

Units Installation—Hydraulic System

55-6055-412	Unit Assembly—Relief valve	1
41-9795	Valve Assembly—Hydraulic relief N.D. (Aircraft Accessory Corp., Glendale, Cal., No. 31000)	1
1-16962	Filter Assembly—Hydraulic or glycol fluid (Cuno. Eng. Corp., Meriden, Conn., No. 11238)	1
51-388-14	Clamp Assembly—Filter	1
41-468-70-16	Clamp—Square loop type	1
BAC1603-64	Spacer—No. 10 bolt	1
3-14698	Plate Assembly—Accumulator instructions	1
41-9088-70-16	Clamp—Square	2
55-6055-4	Tube—Hydraulic system units	1
55-6055-418	Tube—Hydraulic system units	1
55-6055-417	Tube—Hydraulic system units	1
55-6055-421	Tube—Hydraulic system units	1
55-6055-15	Tube—Hydraulic system units	1
55-6055-408	Tube—Hydraulic system units	1
55-6055-416	Tube—Hydraulic system units	1
55-6055-414	Tube—Hydraulic system units	1
41-3034	Angle—Tubing support	2
BAC540-8	Clamp—Loop type cushioned	3
BAC540-10	Clamp—Loop type cushioned	6
	(Parts List No. 409)	
BAC1603-16	Spacer—No. 10 bolt	1
BAC1603-32	Spacer—No. 10 bolt	1
1-19003-3	Fair-lead Assembly—3 hole	1
1-19003-4	Fair-lead—Miscellaneous	1
BAC1603-96	Spacer—No. 10 bolt	1
BAC1603-28	Spacer—No. 10 bolt	1

AVIALOGS.COM

EQUIPMENT AND FURNISHINGS INSTALLATION

Anti-Icer Installation—Propeller

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 410)	
65-5660	Anti-icer Installation—Propeller	1
64-1332-504	Tank Assembly—Propeller anti-icing	1
1-17097-9	Cap Assembly—Tank filler	1
39B4232	Cap—Fuel tank—adapter assembly	1
1-23594-2	Name Plate—Tank cap	1
1-17100	Name Plate—Propeller anti-icing	1
64-1332-509	Clip—Fuel tank	2
1-28064	Decalcomania—De-icer tank	1
21-4844-50	Jumper Assembly—No. 10-10 terminal bonding	1
BAC820-10	Terminal—Electrical lock	2
3-11143	Support Installation—Anti-icer tank gage	1
41-7848	Holder—Tank gage	2
BAC1602-38	Spacer—No. 8 machine screw	2
BAC1602-40	Spacer—No. 8 machine screw	2
3-12099	Gage Assembly—Propeller de-icer tank	1
51-947	Valve Assembly—Anti-icer pressure relief (No. 6-1439-34, Parker Appliance Co., Cleveland, Ohio)	4
774-6	Pump and Rheostat—Propeller anti-icer (Eclipse Aviation Corp., Bendix, N. J.)	2
51-1085-1	Fair-lead—Tube support	2
51-1085-2	Fair-lead—Tube support	2
1-17492	Fair-lead—Tubing	8
65-5660-3	Tube Assembly—Anti-icer	4
65-5660-5	Tube Assembly—Anti-icer	1
65-5660-6	Tube Assembly—Anti-icer	2
65-5660-17	Tube Assembly—Propeller anti-icer	1
65-5660-29	Tube Assembly—Propeller anti-icer	1
65-5660-34	Tube Assembly—Propeller anti-icer	1
65-5660-40	Tube Assembly—Propeller anti-icer	1
65-5660-49	Tube Assembly—Propeller anti-icer	2
65-5660-51	Tube Assembly—Propeller anti-icer	2
65-5660-54	Tube Assembly—Propeller anti-icer	1
65-5660-409	Tube Assembly—Propeller anti-icer	1
65-5660-414	Tube Assembly—Propeller anti-icer	1
65-5660-501	Tube Assembly—Propeller anti-icer	1
65-5660-502	Tube Assembly—Propeller anti-icer	1
65-5660-503	Tube Assembly—Propeller anti-icer	1
65-5660-504	Tube Assembly—Propeller anti-icer	1
65-5660-505	Tube Assembly—Propeller anti-icer	2
65-5660-506	Tube Assembly—Propeller anti-icer	2
65-5660-507	Tube Assembly—Propeller anti-icer	2
65-5660-508	Tube Assembly—Propeller anti-icer	2
65-5660-509	Tube Assembly—Propeller anti-icer	2

Anti-Icer Installation—Propeller

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
65-5660-510	Tube Assembly—Propeller anti-icer	2
65-5660-517	Tube Assembly—Propeller anti-icer	1
65-5660-518	Tube Assembly—Propeller anti-icer	1
65-5660-519	Tube Assembly—Propeller anti-icer	1
65-5660-520	Tube Assembly—Propeller anti-icer	1
65-5660-521	Tube Assembly—Propeller anti-icer	1
65-5660-522	Tube Assembly—Propeller anti-icer	1
65-5660-523	Tube—Propeller anti-icer	1
65-5660-524	Tube Assembly—Propeller anti-icer	1
	(Parts List No. 411)	
65-5660-525	Tube—Propeller anti-icer	1
65-5660-526	Tube Assembly—Propeller anti-icer	1
65-5660-528	Tube—Propeller anti-icer	1
65-5660-529	Tube Assembly—Propeller anti-icer	1
65-5660-530	Tube Assembly—Propeller anti-icer	1
65-5660-531	Tube Assembly—Propeller anti-icer	1
65-5660-532	Tube Assembly—Propeller anti-icer	1
65-5660-533	Tube Assembly—Propeller anti-icer	1
65-5660-534	Tube Assembly—Propeller anti-icer	1
65-5660-535	Tube Assembly—Propeller anti-icer	1
65-5660-536	Tube Assembly—Propeller anti-icer	1
65-5660-537	Tube Assembly—Propeller anti-icer	1
65-5660-538	Tube Assembly—Propeller anti-icer	4
65-5660-539	Tube—Propeller anti-icer	1
41-9007-1	Angle—Tube support	4
1-13892-21-6	Clamp—Tabulated square	6
1-13892-56-12	Clamp—Tabulated square	6
41-468-70-16	Clamp—Square loop type	4
41-96	Clamp—1 x 1¾ rectifier tube	2
41-1065-4	Clamp Assembly—¾ wide barrel	2
41-1063-4-3	Clamp—Barrel type	2
41-1065-6	Clamp Assembly—¾ wide barrel	2
41-1063-6-3	Clamp—Barrel type	2
BAC540-6	Clamp—Loop type cushioned	107
BAC540-12	Clamp—Loop type cushioned	2
BAC540-16	Clamp—Loop type cushioned	4
BAC1603-8	Spacer—No. 10 bolt	2
BAC1603-32	Spacer—No. 10 bolt	2
BAC540-9	Clamp—Loop type cushioned	16
21-4844-100	Jumper Assembly—No. 10-10 terminal bonding	1
BAC820-10	Terminal—Electrical lock	2
21-9486	Angle—Tube support	2
1-17359-2	Filter—Propeller anti-icer pump and rheostat	2
BAC535-12	Clamp—Hose	17

EQUIPMENT INSTALLATION

Life Raft Installation—Auto Ejector

	(Parts List No. 412)	
64-1698	Life Raft Installation—Auto ejector	1
64-1698-7	Raft—Auto ejector—life (type A-2) (Government furnished)	2
3-16128	Guide Assembly—Auto ejector—life raft	2
3-16128-4	Strap Assembly—Auto ejector—life raft	2
3-16128-5	Strap—Auto ejector—life raft	2
3-16979	Guide Assembly—Cable	2
3-16979-1	Conduit	2
3-16979-2	Strap Assembly—Cable	2
BAC1602-8	Spacer—No. 8 machine screw	10
41-9046-1	Fair-lead—Life raft control	2
64-1698-500	Cable Assembly—Auto ejector life raft LH	1
64-1698-501	Cable Assembly—Auto ejector life raft RH	1
64-1698-502	Cable—Auto ejector life raft LH	1
64-1698-503	Cable—Auto ejector life raft RH	1
21-8777-1	Shackle—3/16 pin safety	2
BAC1828-23	Terminal—Dead end cable	2

Life Raft Installation—Auto Ejector

1-24228	Cable Assembly—Life raft	2
1-24228-1	Cable—Life raft	2
1-24228-14S	Connector—Life raft (Pacific Marine Supply)	2
1-26276	Ferrule—Rigid conduit	2
41-8180	Spring—Latch LH	1
41-8180-1	Spring—Latch RH	1
64-1698-6	Lanyard—Silk type—auto ejector life raft	2
070618	Snap—Flare rack cable	2
41-7703	Handle—"T" pull—life raft	2
8805	Mounting—Socket assembly—auto ejector life raft (Walt Kidde & Co., N. J.)	2
64-1698-14	Web Assembly—Auto ejector life raft	6
038244	Post—Control cable flexible casing stop threaded ¼	2
1-18566	Bracket—Bowdenite support	1
BAC540-4	Clamp—Loop type cushioned	4
BAC540-7	Clamp—Loop type cushioned	4
BAC1603-8	Spacer—No. 10 bolt	2
BAC1603-28	Spacer—No. 10 bolt	1

AVIALOGS.COM

EQUIPMENT INSTALLATION

Life Raft Installation—Auto Ejector

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1603-40	Spacer—No. 10 bolt	1
BAC1603-76	Spacer—No. 10 bolt	1
BAC1603-84	Spacer—No. 10 bolt	1
BAC1603-92	Spacer—No. 10 bolt	1
64-1698-504	Tube—Auto ejector life raft	1
64-1698-505	Tube—Auto ejector life raft	1
64-1698-506	Casing—Control cable (No. 13 Bowdenite) special 93-24519	1

Tubing Installation—Oxygen

(Parts List No. 413)

15-7365	Tubing Installation—Oxygen	1
9-3441	Cradle Installation—Oxygen cylinder	2
9-3441-1	Cradle Assembly—Oxygen cylinder	4
1-18114-9-8	Strap Assembly—Clamp	16
1-17559	Hook—Strap end	16
1-18782	Spacer—Elevator hinge bracket	16
1-18759	Angle—Hinge	8
1-17573-7-199	Spacer—Clamp	8
15-7533-1	Cradle Installation—Oxygen cylinder LH	1
15-7533-2	Cradle Installation—Oxygen cylinder RH	1
15-7533-8	Cradle Assembly—Oxygen cylinder	4
15-7533-11	Cradle—Oxygen cylinder	4
1-18114-5-5	Strap Assembly—Clamp	12
1-18114-12-3	Strap Assembly—Clamp	8
1-18114-19-4	Strap Assembly—Clamp	4
1-17559	Hook—Strap end	24
1-18782	Loop—Strap hinge	24
1-17573-7-199	Spacer—Clamp	24
BAC1603-40	Spacer—No. 10 bolt	16
15-7533-3	Cradle Installation—Oxygen cylinder LH	1
15-7533-6	Cradle Assembly—Oxygen cylinder LH	2
15-7533-7	Cradle—Oxygen cylinder	1
1-18114-3-7	Strap Assembly—Clamp	4
1-18114-15-4	Strap Assembly—Clamp	2
1-18114-18-5	Strap Assembly—Clamp	2
1-17559	Hook—Strap end	8
1-18782	Loop—Strap hinge	8
1-17573-7-199	Spacer—Clamp	8
BAC1603-35	Spacer—No. 10 bolt	2
BAC1603-40	Spacer—No. 10 bolt	4
15-7522	Bottle Installation—Oxygen	1
15-7522-1	Cylinder—Oxygen (government furnished)	18
3-14230	Hose Assembly—Flexible metal (Chicago Metal Hose Corp., Maywood, Ill.)	2
41-6844-20-48	Clamp—Rectifier tube	3
21-9646	Spacer—Self-locking nut	11
15-7365-5	Tube Assembly—Oxygen	1
15-7365-7	Tube Assembly—Oxygen	1
15-7365-8	Tube Assembly—Oxygen	1
15-7365-9	Tube Assembly—Oxygen	1
15-7365-10	Tube Assembly—Oxygen	1
15-7365-11	Tube Assembly—Oxygen	1
15-7365-12	Tube Assembly—Oxygen	1
15-7365-13	Tube Assembly—Oxygen	1
15-7365-14	Tube Assembly—Oxygen	1
15-7365-15	Tube Assembly—Oxygen	1
15-7365-16	Tube Assembly—Oxygen	1

(Parts List No. 414)

15-7365-17	Tube Assembly—Oxygen	1
15-7365-18	Tube Assembly—Oxygen	1
15-7365-19	Tube Assembly—Oxygen	1
15-7365-20	Tube Assembly—Oxygen	1
15-7365-21	Tube Assembly—Oxygen	1
15-7365-22	Tube Assembly—Oxygen	1
15-7365-23	Tube Assembly—Oxygen	1
15-7365-24	Tube Assembly—Oxygen	1
15-7365-25	Tube Assembly—Oxygen	1
15-7365-26	Tube Assembly—Oxygen	1

Tubing Installation—Oxygen

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7365-27	Tube Assembly—Oxygen	1
15-7365-28	Tube Assembly—Oxygen	1
15-7365-29	Tube Assembly—Oxygen	1
15-7365-30	Tube Assembly—Oxygen	1
15-7365-31	Tube Assembly—Oxygen	1
15-7365-32	Tube Assembly—Oxygen	1
15-7365-33	Tube Assembly—Oxygen	1
15-7365-34	Tube Assembly—Oxygen	1
15-7365-35	Tube Assembly—Oxygen	1
15-7365-36	Tube Assembly—Oxygen	1
15-7365-37	Tube Assembly—Oxygen	1
15-7365-38	Tube Assembly—Oxygen	1
15-7365-39	Tube Assembly—Oxygen	1
15-7365-40	Tube Assembly—Oxygen	1
15-7365-41	Tube Assembly—Oxygen	1
15-7365-42	Tube Assembly—Oxygen	1
15-7365-43	Tube Assembly—Oxygen	1
15-7365-44	Tube Assembly—Oxygen	1
15-7365-45	Tube Assembly—Oxygen	1
15-7365-46	Tube Assembly—Oxygen	1
15-7365-47	Tube Assembly—Oxygen	1
15-7365-48	Tube Assembly—Oxygen	1
15-7365-50	Tube Assembly—Oxygen	1
15-7365-51	Tube Assembly—Oxygen	1
15-7365-52	Tube Assembly—Oxygen	1
15-7365-53	Tube Assembly—Oxygen	1
15-7365-54	Tube Assembly—Oxygen	1
15-7365-55	Tube Assembly—Oxygen	1
15-7365-56	Tube Assembly—Oxygen	1
15-7365-57	Tube Assembly—Oxygen	1
15-7365-58	Tube Assembly—Oxygen	1
15-7365-59	Tube Assembly—Oxygen	1
15-7365-60	Tube Assembly—Oxygen	1
15-7365-61	Tube Assembly—Oxygen	1
15-7365-62	Tube Assembly—Oxygen	1
15-7365-65	Tube Assembly—Oxygen	1
15-7365-66	Tube Assembly—Oxygen	1
15-7365-67	Tube Assembly—Oxygen	1
15-7365 68	Tube Assembly—Oxygen	1
15-7365-71	Tube Assembly—Oxygen	1
15-7365-72	Tube Assembly—Oxygen	1
15-7365-73	Tube Assembly—Oxygen	1
15-7365-74	Tube Assembly—Oxygen	1

(Parts List No. 415)

15-7365-76	Tube Assembly—Oxygen	1
15-7365-79	Tube Assembly—Oxygen	1
15-7365-81	Tube Assembly—Oxygen	1
15-7365-82	Tube Assembly—Oxygen	1
15-7365-83	Tube Assembly—Oxygen	1
15-7365-84	Tube Assembly—Oxygen	1
15-7365-85	Tube Assembly—Oxygen	1
15-7365-86	Tube Assembly—Oxygen	1
15-7365-87	Tube Assembly—Oxygen	1
15-7365-88	Tube Assembly—Oxygen	1
15-7365-89	Tube Assembly—Oxygen	1
15-7365-90	Tube Assembly—Oxygen	1
15-7365-91	Tube Assembly—Oxygen	1
15-7365-94	Tube Assembly—Oxygen	1
15-7365-95	Tube Assembly—Oxygen	1
15-7365-96	Tube Assembly—Oxygen	1
15-7365-98	Tube Assembly—Oxygen	1
15-7365-99	Tube Assembly—Oxygen	1
15-7365-100	Tube Assembly—Oxygen	1
15-7365-101	Tube Assembly—Oxygen	1
15-7365-102	Tube Assembly—Oxygen	1
15-7365-109	Tube Assembly—Oxygen	1
15-7365-126	Tube Assembly—Oxygen	1
15-7365-125	Tube Assembly—Oxygen	1
15-7365-110	Tube Assembly—Oxygen	1
1-20523	Nipple—Oxygen connection	1
15-7365-111	Tube Assembly—Oxygen	1

AVIALOGS.COM

EQUIPMENT INSTALLATION

Tubing Installation—Oxygen

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-20523	Nipple—Oxygen connection	1
15-7365-112	Tube Assembly—Oxygen	1
1-20523	Nipple—Oxygen connection	1
15-7365-113	Tube Assembly—Oxygen	1
1-20523	Nipple—Oxygen connection	1
15-7365-115	Tube Assembly—Oxygen	1
1-20523	Nipple—Oxygen connection	1
15-7365-116	Tube Assembly—Oxygen	1
1-20523	Nipple—Oxygen connection	1
15-7365-117	Tube Assembly—Oxygen	1
1-20523	Nipple—Oxygen connection	1
15-7365-120	Tube Assembly—Oxygen	1
1-20523	Nipple—Oxygen connection	1
1-20523-128	Tube Assembly—Oxygen	1
1-20523-129	Tube Assembly—Oxygen	1
1-20523-130	Tube Assembly—Oxygen	1
1-20523-131	Tube Assembly—Oxygen	1
1-20523-132	Tube Assembly—Oxygen	1
	(Parts List No. 416)	
15-7365-133	Tube Assembly—Oxygen	1
15-7365-134	Tube Assembly—Oxygen	1
15-7365-135	Tube Assembly—Oxygen	1
15-7365-136	Tube Assembly—Oxygen	1
15-7365-137	Tube Assembly—Oxygen	1
15-7365-138	Tube Assembly—Oxygen	1
15-7365-139	Tube Assembly—Oxygen	1
15-7365-140	Tube Assembly—Oxygen	1
15-7365-141	Tube Assembly—Oxygen	1
1-20523	Nipple—Oxygen connection	1
15-7365-143	Tube Assembly—Oxygen	1
1-20523	Nipple—Oxygen connection	1
15-7365-145	Tube Assembly—Oxygen	1
15-7365-146	Tube Assembly—Oxygen	1
15-7365-147	Tube Assembly—Oxygen	1
1-20523	Nipple	1
15-7365-148	Tube Assembly—Oxygen	1
1-20523	Nipple	1
15-7365-149	Tube Assembly—Oxygen	1
1-20523	Nipple—Oxygen connection	1
15-7365-150	Tube Assembly—Oxygen	1
15-7365-151	Tube Assembly—Oxygen	1
3-13529	Bracket Installation—Oxygen regulator (radio operator)	1
3-13529-1	Bracket—Oxygen regulator (radio operator)	1
3-13543	Bracket Installation—Oxygen regulator	1

Tubing Installation—Oxygen

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-13543-1	Bracket—Oxygen regulator	1
BAC1603-36	Spacer—No. 10 bolt	4
6-5182	Bracket Installation—Oxygen regulator LH	1
6-5182-1	Bracket Installation—Oxygen regulator RH	1
6-5182-2	Bracket—Oxygen regulator	1
6-5182-3	Bracket—Oxygen regulator	1
6-8473	Bracket Installation—Oxygen regulator LH	1
6-8473-2	Bracket Installation—Oxygen regulator RH	1
6-8473-1	Bracket—Oxygen regulator	2
6-9363	Bracket Installation—Oxygen regulator station 2A	1
6-9363-1	Bracket—Oxygen regulator	1
BAC1603-8	Spacer—No. 10 bolt	4
3-14072	Bracket Installation—Oxygen regulator (bomber's)	1
3-14072-1	Bracket—Oxygen regulator	1
41-9007	Angle Installation—Tube support	2
3-14230	Hose Assembly—Flex metal (Chicago Metal Hose Corp., Maywood, Ill.)	2
3-16462	Bracket Installation—Oxygen regulator bulkhead 5	1
3-13529-1	Bracket—Oxygen regulator	1
41-468-48-10	Clamp—Square loop type	1
1-22644	Angle—Tube support	1
	(Parts List No. 417)	
41-9624-32-13	Washer—.188 aluminum alloy	1
41-4570-13-6	Pin—Latch	4
BAC540-10	Clamp—Loop type cushioned	6
BAC540-16	Clamp—Loop type cushioned	1
BAC1603-48	Spacer—No. 10 bolt	1
BAC1603-80	Spacer—No. 10 bolt	1
BAC540-5	Clamp—Loop type cushioned	2
15-7365-103	Valve—Relief oxygen tubing (Parker 11-440-7-2)	18
15-7365-104	Valve—Relief oxygen tubing (Parker 11-440-7-4)	18
15-7365-106	Valve—Relief oxygen tubing (Parker 8-1540-1)	1
15-7365-107	Valve—Filler oxygen tubing (Scrader 1660)	1
15-7365-122	Valve—Filler oxygen tubing (Scrader 1660-197)	2
15-7365-121	Bottle—Oxygen tubing (Government furnished)	2
15-7365-4	Regulator—Oxygen tubing (Government furnished)	2
BAC1603-16	Spacer—No. 10 bolt	7
BAC1603-40	Spacer—No. 10 bolt	12
BAC1603-66	Spacer—No. 10 bolt	3
BAC1603-32	Spacer—No. 10 bolt	11
BAC540-5	Clamp—Loop type cushioned	149
BAC540-12	Clamp—Loop type cushioned	1

EQUIPMENT AND FURNISHINGS INSTALLATION

Lining Installation—Soundproofing

	(Parts List No. 418)	
6-9319	Lining Installation—Soundproofing	1
15-7543	Soundproofing Installation—Bulkhead 3	1
15-7543-1	Cover Assembly—Soundproofing bulkhead No. 3	1
15-7543-2	Fabric—Soundproofing bulkhead 3 (G. Royle & Co.)	1
15-7543-3	Felt—Soundproofing bulkhead 3 (Skyfelt)	1
15-7543-4	Fabric—Soundproofing bulkhead 3 (G. Royle & Co.)	1
15-7543-49	Tab—Soundproofing bulkhead 3	1
15-7543-8	Cover Assembly—Soundproofing bulkhead No. 3	1
15-7543-9	Cover Assembly—Soundproofing bulkhead No. 3	1
15-7543-10	Fabric—Soundproofing bulkhead No. 3 (G. Royle)	1

Lining Installation—Soundproofing

15-7543-11	Welt—Soundproofing bulkhead No. 3	1
15-7543-13	Cover Assembly—Soundproofing bulkhead No. 3	1
15-7543-14	Fabric—Soundproofing bulkhead No. 3 (G. Royle)	1
15-7543-15	Felt—Soundproofing bulkhead No. 3 (Skyfelt)	1
15-7543-16	Fabric—Soundproofing bulkhead No. 3 (G. Royle)	1
15-7543-17	Felt—Soundproofing bulkhead No. 3 (Skyfelt)	1
15-7543-49	Tab—Soundproofing bulkhead No. 3	1
15-7543-20	Fastener—Soundproofing bulkhead 3 (talon slide fastener type S-26 No. 5-6)	1
15-7543-23	Cover Assembly—Soundproofing bulkhead No. 3	1
15-7543-24	Fabric—Soundproofing bulkhead No. 3 (G. Royle)	1

AVIALOGS.COM

EQUIPMENT AND FURNISHINGS INSTALLATION

Lining Installation—Soundproofing

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7543-25	Welt—Soundproofing bulkhead No. 3	1
15-7543-27	Cover Assembly—Soundproofing bulkhead No. 3	1
15-7543-28	Fabric—Soundproofing bulkhead No. 3 (G. Royle)	1
15-7543-29	Felt—Soundproofing bulkhead No. 3 (Skyfelt)	1
15-7543-30	Fabric—Soundproofing bulkhead No. 3 (G. Royle)	1
15-7543-31	Stripping—Soundproofing bulkhead No. 3	1
15-7543-49	Tab—Soundproofing bulkhead No. 3	1
15-7543-37	Cover Assembly—Soundproofing bulkhead No. 3	1
15-7543-38	Fabric—Soundproofing bulkhead No. 3 (G. Royle)	1
15-7543-39	Welt—Soundproofing bulkhead No. 3	1
15-7543-40	Felt—Soundproofing bulkhead No. 3 (Skyfelt)	1
15-7543-41	Fabric—Soundproofing bulkhead No. 3 (G. Royle)	1
15-7543-26	Felt—Soundproofing bulkhead No. 3 (Skyfelt)	1
15-7543-49	Tab—Soundproofing bulkhead No. 3	1
15-7543-42	Cover Assembly—Soundproofing bulkhead No. 3	1
15-7543-33	Cover Assembly—Soundproofing bulkhead No. 3	1
15-7543-34	Fabric—Soundproofing bulkhead No. 3 (G. Royle)	1
15-7543-35	Felt—Soundproofing bulkhead No. 3 (Skyfelt)	1
15-7543-36	Fabric—Soundproofing bulkhead No. 3 (G. Royle)	1
15-7543-49	Tab—Soundproofing bulkhead No. 3	1
15-7543-47	Tab Assembly—Soundproofing bulkhead No. 3	1
15-7543-50	Leather—Soundproofing bulkhead No. 3	1
15-7543-43	Cover Assembly—Soundproofing bulkhead No. 3	1
15-7543-44	Fabric—Soundproofing bulkhead No. 3 (G. Royle)	1
	(Parts List No. 419)	
15-7543-45	Felt—Soundproofing bulkhead No. 3 (Skyfelt)	1
15-7543-46	Fabric—Soundproofing bulkhead No. 3 (G. Royle)	1
15-7543-49	Tab—Soundproofing bulkhead No. 3	1
15-7543-6	Stripping—Soundproofing bulkhead No. 3	1
15-7543-7	Stripping—Soundproofing bulkhead No. 3	1
15-7543-12	Felt—(Skyfelt) soundproofing bulkhead No. 3	1
15-7543-18	Stripping—Soundproofing bulkhead No. 3	1
15-7543-19	Stripping—Soundproofing bulkhead No. 3	1
15-7543-21	Strip—Soundproofing bulkhead No. 3	1
15-7543-22	Strip—Soundproofing bulkhead No. 3	1
15-7543-32	Stripping—Soundproofing bulkhead No. 3	1
15-7544	Soundproofing Installation—Bulkhead 4	1
15-7544-13	Cover Assembly—Soundproofing bulkhead No. 4	1
15-7544-8	Trim—Soundproofing bulkhead No. 4	1
15-7544-9	Cover—Fabric (G. Royle, No. 7311) soundproofing bulkhead No. 4	1
15-7544-10	Felt—(Skyfelt) soundproofing bulkhead No. 4	1
15-7544-12	Welt—Soundproofing bulkhead No. 4	1
15-7544-14	Cover Assembly—Soundproofing bulkhead No. 4	1
15-7544-1	Cover—Soundproofing bulkhead No. 4 (G. Royle, No. 7311)	1
15-7544-6	Fastener—Soundproofing bulkhead No. 4 (talon fastener No. 5-6, type S-8)	1
15-7544-7	Patch—Soundproofing bulkhead No. 4	1
15-7544-15	Cover—Soundproofing bulkhead No. 4 (G. Royle, No. 7311)	1
15-7544-16	Welt—Soundproofing bulkhead No. 4	1
15-7544-19	Fastener—Soundproofing bulkhead No. 4 (talon fastener No. 5-6, type S-8)	3

Lining Installation—Soundproofing

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7544-17	Felt Assembly—Soundproofing bulkhead No. 4	1
15-7544-2	Felt—Soundproofing bulkhead No. 4 (Skyfelt)	1
15-7544-11	Welt—Soundproofing bulkhead No. 4	1
15-7544-3	Batt—Soundproofing bulkhead No. 4 (Skyfelt)	1
15-7544-4	Trim—Soundproofing bulkhead No. 4	1
15-7544-18	Felt—Soundproofing bulkhead No. 4 (Skyfelt)	1
15-7544-24	Trim—Soundproofing bulkhead No. 4	1
3-14982	Kickplate—Door bulkhead No. 4	1
BAC1449-6-8	Screw—Flathead recessed sheet metal	1
14-2071	Soundproofing Installation—Bulkhead 5	1
14-2071-2	Cover Assembly—Soundproofing bulkhead No. 5	1
14-2071-4	Cover—Soundproofing bulkhead No. 5 (G. Royle)	1
14-2071-5	Patch—Soundproofing bulkhead No. 5	1
14-2071-6	Patch—Soundproofing bulkhead No. 5	1
14-2071-9	Welt—Soundproofing bulkhead No. 5	1
14-2071-12	Cover—Soundproofing bulkhead No. 5 (G. Royle)	1
14-2071-3	Cover Assembly—Soundproofing bulkhead No. 5	1
14-2071-10	Felt—Soundproofing bulkhead No. 5 (Skyfelt)	1
14-2071-11	Welt—Soundproofing bulkhead No. 5	1
3-14983	Kickplate—Door bulkhead No. 5	1
BAC1601-32	Spacer—No. 6 machine screw	12
14-2071-7	Trim—Soundproofing bulkhead No. 5	1
	(Parts List No. 420)	
14-2071-8	Trim—Soundproofing bulkhead No. 5	1
14-2071-13	Lining—Soundproofing bulkhead No. 5 (Skyfelt)	1
15-7546	Soundproofing Installation—Bulkhead 6	1
15-7546-1	Cover Assembly—Soundproofing bulkhead 6	1
15-7546-6	Welt—Soundproofing bulkhead 6	1
15-7546-7	Fabric—Soundproofing bulkhead 6 (G. Royle, No. 7311)	1
15-7546-2	Lining—Soundproofing bulkhead 6 (Skyfelt)	1
15-7546-3	Trim—Soundproofing bulkhead 6	1
15-7546-4	Trim—Soundproofing bulkhead 6	1
15-7546-5	Trim—Soundproofing bulkhead 6	
15-7547	Soundproofing Installation—Bomber's and navigator's compartment	1
15-7547-1	Cover Assembly—Fabric bomber's and navigator's compartment soundproofing	1
15-7547-2	Fabric—Bomber's and navigator's compartment soundproofing (G. Royle & Co., No. 7311)	1
15-7547-3	Welt—Bomber's and navigator's compartment soundproofing	1
15-7547-4	Tape—Bomber's and navigator's compartment soundproofing (Narrow Fabric Co., No. 203)	1
15-7547-6	Leather—Bomber's and navigator's compartment soundproofing	1
15-7547-8	Cover Assembly—Felt bomber's and navigator's compartment soundproofing	1
15-7547-9	Felt—Bomber's and navigator's compartment soundproofing (Skyfelt)	1
15-7547-10	Welt—Bomber's and navigator's compartment soundproofing	1
56-7986-501	Frame Assembly—Window edging	1
56-7986-502	Frame Assembly—Window edging	1
56-7986-503	Frame Assembly—Window edging	1
56-7986-504	Frame Assembly—Window edging	1
56-7986-505	Frame Assembly—Window edging	1
56-7986-506	Frame Assembly—Window edging	1
56-7986-507	Frame Assembly—Window edging	1

AVIALOGS.COM

EQUIPMENT AND FURNISHINGS INSTALLATION

Lining Installation—Soundproofing

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
56-7986-508	Frame Assembly—Window edging	1
56-7986-509	Frame Assembly—Window edging	1
15-7547-5	Chord—Bomber's and navigator's compartment soundproofing	1
15-7547-14	Trim—Bomber's and navigator's compartment soundproofing LH	1
15-7547-15	Trim—Bomber's and navigator's compartment soundproofing RH	1
15-7547-16	Felt—Bomber's and navigator's compartment soundproofing (Skyfelt)	1
15-7547-17	Felt—Bomber's and navigator's compartment soundproofing (Skyfelt)	1
15-7547-18	Felt—Bomber's and navigator's compartment soundproofing (Skyfelt)	1
15-7547-19	Felt—Bomber's and navigator's compartment soundproofing (Skyfelt)	1
15-7547-20	Felt—Bomber's and navigator's compartment soundproofing (Skyfelt)	1
15-7547-21	Felt—Bomber's and navigator's compartment soundproofing (Skyfelt)	1
15-7547-22	Felt—Bomber's and navigator's compartment soundproofing (Skyfelt)	1
15-7548	Soundproofing Installation—Pilot's compartment.	1
15-7548-1	Cover Assembly—Pilot's compartment soundproofing LH—wall	1
15-7548-2	Fabric—Pilot's compartment soundproofing (G. Royle, No. 7311)	1
15-7548-3	Welt—Pilot's compartment soundproofing	1
15-7548-4	Tape—Pilot's compartment soundproofing (Narrow Fabric Co., No. 203)	1
	(Parts List No. 421)	
15-7548-6	Cover Assembly—Pilot's compartment soundproofing RH wall	1
15-7548-7	Fabric—Pilot's compartment soundproofing (G. Royle, No. 7311)	1
15-7548-8	Welt—Pilot's compartment soundproofing	1
15-7548-9	Tape—Pilot's compartment soundproofing (Narrow Fabric Co., No. 203)	1
15-7548-15	Cover Assembly—Pilot's compartment soundproofing—ceiling	1
15-7548-16	Fabric—Pilot's compartment soundproofing (G. Royle, No. 7311)	1
15-7548-17	Welt—Pilot's compartment soundproofing	1
15-7548-18	Tape—Pilot's compartment soundproofing (Narrow Fabric Co., No. 203)	1
15-7548-20	Leather—Pilot's compartment soundproofing.	1
15-7548-36	Cover Assembly—Pilot's compartment soundproofing—turret	1
15-7548-37	Cover Assembly—Pilot's compartment soundproofing—turret	1
15-7548-38	Fabric—Pilot's compartment soundproofing (G. Royle, No. 7311)	2
15-7548-39	Felt — Pilot's compartment soundproofing (Skyfelt)	2
15-7548-40	Cover Assembly—Pilot's compartment soundproofing—turret bulkhead	1
15-7548-41	Cover Assembly—Pilot's compartment soundproofing—turret bulkhead	1
15-7548-42	Felt — Pilot's compartment soundproofing (Skyfelt)	2
15-7548-43	Fabric—Pilot's compartment soundproofing (G. Royle, No. 7311)	2

Lining Installation—Soundproofing

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7548-44	Cover Assembly—Pilot's compartment soundproofing—turret bulkhead	1
15-7548-45	Felt — Pilot's compartment soundproofing (Skyfelt)	1
15-7548-46	Fabric—Pilot's compartment soundproofing (G. Royle, No. 7311)	1
15-7548-47	Pad Assembly—Pilot's compartment soundproofing—turret	1
15-7548-48	Pad Assembly—Pilot's compartment soundproofing—turret	1
15-7548-49	Felt — Pilot's compartment soundproofing (Skyfelt)	2
15-7548-50	Fabric—Pilot's compartment soundproofing (G. Royle)	2
15-7548-51	Welt—Pilot's compartment soundproofing	2
15-7548-52	Welt—Pilot's compartment soundproofing	2
15-7548-55	Cover Assembly—Pilot's compartment soundproofing	1
15-7548-56	Felt — Pilot's compartment soundproofing (Skyfelt)	1
15-7548-57	Fabric—Pilot's compartment soundproofing (G. Royle, No. 7311)	1
15-7548-5	Chord—Pilot's compartment soundproofing	1
15-7548-10	Chord—Pilot's compartment soundproofing	1
15-7548-11	Felt—Pilot's compartment soundproofing (Skyfelt)	1
15-7548-12	Felt—Pilot's compartment soundproofing (Skyfelt)	1
15-7548-13	Felt—Pilot's compartment soundproofing (Skyfelt)	1
15-7548-14	Battery—Pilot's compartment soundproofing	1
15-7548-19	Chord—Pilot's compartment soundproofing	1
15-7548-29	Trim—Pilot's compartment soundproofing	1
15-7548-30	Trim—Pilot's compartment soundproofing	1
15-7548-31	Trim—Pilot's compartment soundproofing	1
	(Parts List No. 422)	
15-7548-32	Trim—Pilot's compartment soundproofing	1
15-7548-33	Trim—Pilot's compartment soundproofing	1
15-7548-34	Trim—Pilot's compartment soundproofing	1
15-7548-35	Trim—Pilot's compartment soundproofing	1
15-7548-53	Trim—Pilot's compartment soundproofing	1
15-7548-54	Trim—Pilot's compartment soundproofing	1
15-7549	Soundproofing Installation—Radio compartment.	1
15-7549-1	Cover Assembly—Fabric radio compartment soundproofing	1
15-7549-3	Fabric—Radio compartment soundproofing (G. Royle, No. 7311)	1
15-7549-4	Welt—Radio compartment soundproofing	1
15-7549-10	Tape—Radio compartment soundproofing (Narrow Fabric Co., No. 203)	1
15-7549-13	Patch—Radio compartment soundproofing	1
15-7549-2	Cover Assembly—Felt radio compartment soundproofing	1
15-7549-5	Felt—Radio compartment soundproofing	1
15-7549-6	Welt—Radio compartment soundproofing	1
56-7986-510	Frame Assembly—Window edging	2
15-7549-7	Battery—Radio compartment soundproofing (Skyfelt)	1
15-7549-8	Trim—Radio compartment soundproofing	1
15-7549-9	Trim—Radio compartment soundproofing	1
15-7549-11	Trim—Radio compartment soundproofing	1
15-7549-12	Chord—Radio compartment soundproofing	1

AVIALOGS.COM

FINAL ASSEMBLY

Armament Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 423)	
15-6806	Armament Installation	1
15-9255	Control Installation—Bomb racks and doors	1
15-7329-5	Rack Installation—Bomb	1
15-7335-1	Hoist Installation—Internal bomb	1
15-7381	Gun Installation—Nose—.30 caliber	1
H39B5343	Gun—Aircraft machine—flexible—M-2 .30 caliber (furnished for installation check only)	1
38D6273	Sight Assembly—Flexible gun-ring—(type L-2) (furnished for installation check only)	1
40B6227	Sight Assembly—Flexible gun—post—(type A-9) (furnished for installation check only)	1
40D5858	Mount—Ammunition box—(type A-3) (furnished for installation check only)	1
15-7381-2	Adapter Assembly—(Furnished for installation check only) nose .30 caliber gun	1
41A5055	Cap—Gun mount ball and socket (Government furnished)	6
40G7402	Holder Assembly—Ammunition box—(type A-1) (furnished for installation check only)	1
42-D5715	Ball (Government furnished)	6
42-B5717	Ring (Government furnished)	6
42-B5718	Ring (Government furnished)	6
42-B5403	Ring (Government furnished)	6
42-B5461	Skim (Government furnished)	18
3-13458-1	Plate—Gun fire deflector	1
3-13463	Plate—Gun fire deflector	1
15-7381-3	Washer—.30 caliber nose gun	4
3-13468	Gasket—Gun mount	12
15-7999	Camera Installation—Tail gun	1
15-7999-4	Support Assembly—Tail gun camera	1
3-14690	Mount Assembly—N-2—camera	1
1-20735-1001	Mount—Rubber shock	2
1-21061	Angle—Camera mount	1
34A1766-1	Washer—Vibration absorber stop	2
BAC1614-78	Spacer—1/8 rivet	1
BAC1615-32	Spacer—5/32 rivet	1
3-14690-1	Mount Assembly—N-2—camera	1
1-20735-1001	Mount—Rubber shock	2
1-21062	Angle—Camera mount	1
34A1766-1	Washer—Vibration absorber stop	2
BAC1614-78	Spacer—1/8 rivet	1
BAC1615-32	Spacer—5/32 rivet	1
6-10444	Bracket Assembly—N-2—camera	1
1-21362	Snubber Assembly—Camera	1
1-21366	Channel—Reinforcement	1
1-21367	Channel—Reinforcement	1
3-14689	Bracket—N-2—camera	1
	(Parts List No. 424)	
1-21402	Plate—Name	1
1-21402-1	Plate—Name	1
AN3015	Switch Assembly—(Type B5A)	1
AN3017	Switch Assembly—(Type B7A)	1
15-7777	Chute Installation—Tail gun	1
15-7776	Chute Assembly—Tail gun	1
15-7776-1	Weld Assembly—Tail gun chute	1
15-7775	Hopper Assembly—Tail gun	1
1-18308-1	Stiffener—Tail gun skirt	2
1-18308-2	Stiffener—Tail gun skirt	2
1-18308-3	Stiffener—Tail gun skirt	1
1-18308-4	Stiffener—Tail gun skirt	1
1-18308-5	Stiffener—Tail gun skirt	1
3-13926	Cover—Case chute	1
6-9622	Stabilizer Installation—.50 caliber gun	1
3-14078	Stabilizer Assembly—.50 caliber gun LH	1
3-14078-1	Stabilizer Assembly—.50 caliber gun RH	1
1-20065	Bolt—Special—5/16-24	4
9-3610	Gun Installation—Rear—.50 caliber	1
9-3610-1	Adapter—Rear .50 caliber gun (Government furnished)	2

Armament Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
H39B5344	Gun—Machine M-2 .50 caliber (Government furnished)	2
37B2675	Mount—(Type C-2) (Government furnished)	1
37B2675-1	Mount—(Type C-2) (Government furnished)	1
1-22679	Spacer—Rear gun	1
1-22679-1	Spacer—Rear gun	1
15-7686	Chute Assembly—Ammunition LH	1
15-7686-16	Spot Weld Assembly—Ammunition LH	1
3-13661	Holder Assembly—Ammunition box—tail gun	1
3-13661-1	Holder—Ammunition box—tail gun	1
35A5631	Latch Assembly—Ammunition box	1
1-16522	Latch Assembly—Ejector chute	1
1-16522-1	Spring—Ejector chute latch	1
1-16523-1	Stud—Latch spring	2
35A3896	Housing—Ammunition box cover lever	1
35A3897	Lever—Ammunition box cover	1
35A3898	Spring—Ammunition box cover lever	1
35A3899	Pin—Ammunition box cover lever	1
15-7686-1	Chute Assembly—Ammunition RH	1
15-7686-17	Spot Weld Assembly—Ammunition RH	1
3-13661	Holder Assembly—Ammunition box—tail gun	1
3-13661-1	Holder—Ammunition box—tail gun	1
35A5631	Latch Assembly—Ammunition box—tail gun	1
1-16522	Latch Assembly—Ejector chute	1
1-16522-1	Spring—Ejector chute latch	1
1-16523	Stud—Latch spring	2
35A3896	Housing—Ammunition box cover lever	1
35A3897	Lever—Ammunition box cover	1
35A3898	Spring—Ammunition box cover lever	1
35A3899	Pin—Ammunition box cover lever	1
	(Parts List No. 424A)	
3-13532	Support Assembly—Ammunition feed	1
1-18351	Gusset—Ammunition feed support	1
1-18352	Gusset—Ammunition feed support	1
3-13532-1	Support Assembly—Ammunition feed	1
1-18351-1	Gusset—Ammunition feed support	1
1-18352-1	Gusset—Ammunition feed support	1
6-9589	Support Assembly—Rear gun	1
6-9589-1	Weld Assembly—Rear gun support	1
1-19815	Clamp Assembly—3/4 wide round tube	4
1-19815-1	Strap—3/4 wide round tube clamp	4
BAC1550-11	Sleeve—5/16-.058	4
6-9459	Channel Assembly—Rear gun stowage	1
6-9459-1	Channel Assembly—Rear gun stowage	1
1-18912	Spring—Gun stowage lock	1
1-18910	Lever Assembly—Gun stowage lock	1
1-18910-1	Lever—Gun stowage lock	1
1-18911	Bearing—Gun stowage lock	1
3-13556	Channel—Rear gun support	1
1-18407	Spacer—Rear gun	2
1-18169-38	Spacer—5/16 bolt	2
BAC543-12-18	Clamp—Round tube strap	2
BAC543-12-16	Clamp	6
6-11569	Hose Installation—Glide bombing	1
6-11569-1	Hose—Glide bombing	1
6-11569-2	Valve—Selector glide bombing	1
21-9944-3	Spring—Cowl	3
BAC535-10	Clamp—Hose	1
6-11571	Bracket Assembly—Glide bombing	1
3-16126-11	Decalcomania—Miscellaneous	1
3-16451	Bracket—Glide bombing	1
55-7521	Sight Station and Power Turrets Installation	1
	Dash number parts, shown on 55-7521 drawing are represented by dash numbers of 15-7521 and 55-7521.	
15-7521-4	Turret Assembly—Top sighting station and power turrets	1
15-7521-7	Turret Assembly—Sighting station and power upper (Sperry Drawing 645473E) (Government furnished)	1

AVIALOGS.COM

FINAL ASSEMBLY

Armament Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7521-15	Water Seal Assembly	1
15-7521-5	Turret Assembly—Sighting station and power lower spherical (Government furnished)	1
H39B5344	Gun—Machine M-2, .50 caliber (Government furnished)	4
	(Parts List No. 425)	
15-7469	Box Assembly—Side gun ammunition LH	2
15-7469-1	Box Assembly—Side gun ammunition RH	2
15-7469-2	Box Assembly—Side gun ammunition spot-weld LH	2
15-7469-3	Box Assembly—Side gun ammunition spot-weld RH	2
15-7469-8	Cover Assembly—Side gun ammunition	4
15-7469-9	Cover—Side gun ammunition box	4
41-1384	Fastener Installation—Side gun ammunition cover	4
41-1384-2	Snapslide—Side gun ammunition cover	4
41-8016	Washer—Snapslide	8
41-8012-3	Button—Snapslide	8
41-8013-3	Pin—Snapslide guide	4
15-7469-16	Hinge—Side gun ammunition box	4
1-18157	Spring—Ammunition box	4
1-18416	Button—Ammunition box	4
3-13485	Handle—Ammunition box	4
3-13488	Baffle—Ammunition box	4
1-24995	Bolt—¼ stud	4
21-2366-32-16	Washer—.091 aluminum alloy	8
21-2366-96-15	Washer—.091 aluminum alloy	8
M-2005-2D	Roller Assembly—Ammunition box .50 caliber (assembly purchased from Air Associates, Inc., Garden City, N. Y.)	4
3-13675-1	Bearing—Ammunition box .50 caliber roller	4
3-13675-3	Tube—Ammunition box .50 caliber roller	4
3-13675-4	Disc—Ammunition box .50 caliber roller	8
3-15168	Holder Assembly—Ammunition box	4
3-15168-2	Holder—Ammunition box	4
1-16522	Latch Assembly—Ejector chute	4
1-16522-1	Spring—Ejector chute	4
1-16523-1	Stud—Latch spring	8
41-8308-171-4	Stud—Snapslide	4
3-16154-7	Decalcomania—Feed LH	1
3-16154-8	Decalcomania—Feed RH	1
1-22928-5	Washer—.063 steel	2L
9-3686	Cover Assembly—Bomb sight	1
9-3686-7	Chain—Safety bomb sight cover (14") (Seattle Hardware Co.)	1
9-3686-10	Ring—Key (Seattle Hardware Co.)	2
15-7524	Installation—Ammunition box and track LH	1
3-13456	Track Assembly—Ammunition LH	1
6-8950-2	Apron—Ammunition	1
3-13456-2	Track—Ammunition	1
3-13456-3	Strip—Rubbing ammunition track	1
3-13456-4	Plate—Ammunition track	1
3-13456-5	Guard—Ammunition track	1
1-20566	Plate—Ammunition stop	1
15-7486	Box Assembly—.50 caliber ammunition LH	1
15-7486-2	Box Assembly—.50 caliber ammunition LH	1
1-18284	Deflector—Ammunition	1
3-13797	Roller Assembly—Ammunition box .50 caliber (Air Associates, Inc., Garden City, N. Y., No. L20053D)	2
	(Parts List No. 426)	
41-3863	Spring—Dzus fastener	1
1-18687	Pad Assembly—Corner	1
1-18687-2	Pad—Corner	1
15-7486-21	Cover Assembly—.50 caliber ammunition box	1
15-7486-22	Cover—.50 caliber ammunition box	1
41-3862	Grommet—Dzus (type 375)	1

Armament Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-9638-30	Button—Dzus wing type	1
15-7524-1	Installation—Ammunition box and track	1
3-13456-1	Track Assembly—Ammunition	1
6-8950-3	Apron—Ammunition	1
3-13456-3	Strip—Rubbing ammunition track	1
3-13456-4	Plate—Ammunition track	1
3-13456-5	Guard—Ammunition track	1
3-13456-6	Track—Ammunition track	1
1-20566	Plate—Ammunition stop	1
15-7486-1	Box Assembly—.50 caliber ammunition RH	1
15-7486-26	Box Assembly—.50 caliber ammunition RH	1
1-18284	Deflector—Ammunition	1
41-3863	Spring—Dzus fastener	1
3-13797	Roller Assembly—Ammunition box .50 caliber (Air Associates, Inc., Garden City, N. Y., No. L20053D)	
1-18687	Pad Assembly—Corner	1
1-18687-2	Pad—Corner	1
15-7486-21	Cover Assembly—.50 caliber ammunition box	1
15-7486-22	Cover—.50 caliber ammunition box	1
41-3862	Grommet—Dzus (type 375)	1
41-9638-30	Button—Dzus wing type	1
30-616	Ammunition Box—.30 caliber (type L-4) (Government furnished)	5
9-2028	Holder Assembly—Ammunition box (type L-4)	1
9-2028-6	Pin—Ammunition box holder	1
9-2028-7	Box Assembly—Spot-weld	1
9-2028-1	Cover—Box spot-weld	1
3-9772	End—LH Ammunition box holder	1
3-9772-1	End—RH ammunition box holder	1
3-9773	Partition—LH ammunition box holder	1
3-9773-1	Partition—RH ammunition box holder	1
41-40	Spring—Ammunition box holder	2
9-2563	Holder Assembly—Ammunition box (type L-4)	1
9-2563-3	Box Assembly—Spot-weld	1
9-2563-1	Cover—Spot-weld	1
3-9772	End—LH	1
3-9772-1	End—RH	1
3-9773	Partition—LH	2
3-9773-1	Partition—RH	2
9-2563-2	Pin—Ammunition box holder	1
1-18687	Pad Assembly—Corner	1
1-18687-2	Pad Assembly—Corner	1
41-40	Spring—Ammunition box holder	3
	(Parts List No. 427)	
14-3003	Mount Assembly—Anti-vibration	1
1-24212	Strap Assembly—Bomb sight bond	1
6-11451	Trunnion Assembly—Bomb sight mount	1
6-11451-2	Trunnion—Bomb sight mount (casting 6-11451-1)	1
6-11451-3	Sleeve—Bomb sight mount trunnion	2
3-16143	Bracket—Bomb sight mount	1
1-24214	Bolt—Bomb sight support	4
6-11449-1	Plate—Bomb sight mount	1
6-11450-1	Plate—Bomb sight mount	1
33B5452-41	Absorber—Vibration	3
33B5452-46	Absorber—Vibration	1
3-16119	Bracket—Bomb sight mount	1
55-7387	Plate Installation—Armor	1
15-7387-1	Armor Assembly—Plate	1
3-13499	Armor Plate—Top gunner	1
6-9285	Angle Assembly—Armor attachment	1
1-18356	Plate Assembly—Armor attachment	3
1-18357	Spacer—Armor attachment	3
1-18298-1	Buffer—Armor plate	3
1-18299-51-33	Spacer—Armor plate	3
41-5951-56-13	Washer—.063 corrosive resistant steel	3
15-7387-2	Armor Assembly—Plate	1
3-13499-1	Plate—Armor top gunner	1

AVIALOGS.COM

FINAL ASSEMBLY

Armament Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-9285-1	Angle Assembly—Armor attachment	1
1-18356	Plate Assembly—Armor attachment	3
1-18357	Spacer—Armor attachment	3
1-18298-1	Buffer—Armor plate	3
1-18299-51-33	Spacer—Armor plate	3
41-5951-56-13	Washer—.063 corrosive resistant steel	3
3-13545-3	Plate Assembly—Armor rear gunner	1
3-13545-1	Strip—Armor rear gunner plate	1
3-13545-2	Plate—Armor rear gunner	1
3-12914	Armor—Seat—back	1
3-13498	Armor—Plate	1
3-13544	Armor—Plate	1
3-13546	Armor—Plate	1
3-13548	Armor—Plate	1
3-13500	Armor—Plate	1
3-13501	Armor—Plate	1
3-14945	Armor—Seat—back	1
3-14945-1	Armor—Seat—back	1
1-20198	Pin Assembly—Door catch	1
41-353-13-7	Pin—Door catch	1
1-18452	Latch Assembly—Armor plate	2
1-18452-1	Pin—Armor plate latch	2
1-18450	Cylinder Assembly—Armor plate lock	2
1-18450-2	Cylinder—Armor plate lock	2
1-16321-1	Pin—Gun mount lock	2
	(Parts List No. 428)	
1-16322	Knob—Gun mount lock	2
1-16326	Spring—Compression	2
1-18298	Buffer—Armor plate	22
1-18298-1	Buffer—Armor plate	27
1-18298-3	Buffer—Armor plate	12
1-18298-10	Buffer—Armor plate	12
1-18451	Striker—Armor plate lock	2
9-3640	Strap Installation—Armor support	1
9-3640-1	Strap Assembly—Armor support	1
9-3640-2	Strap—Armor support strap (H. G. Sears Co., No. 647)	1
9-3640-3	Tip Armor Support Strap—(North & Judd, No. 1)	1
9-3640-4	Snap—Harness armor support strap (North & Judd, No. 56)	1
9-3640-5	Slide—Malleable armor support strap (North & Judd, No. 30)	1
9-3640-6	Retainer—Strap end armor support	1
1-18519	Hanger—Strap support	1
1-18519	Hanger—Strap support	2
55-7736	Support Installation—Bomber's armor	1
55-7736-1	Frame Assembly—Bomber's armor support	1
6-11309	Support Installation—Dehydrator	1
1-23580-3	Clip—Radio compass loop dehydrator	2
3-15132	Pad Assembly—Armor support	1
3-15132-2	Pad—Armor support	1
55-7736-7	Brace Assembly—Bomber's armor support	1
4-838	Fitting Assembly—Armor support	1
BAC1603-32	Spacer—No. 10 bolt	2
BAC802-3-50	Jumper Assembly—Terminal bonding	3
BAC959-4-18	Hinge—Continuous	1
1-18299-51-33	Spacer—Armor plate	31
1-18299-63-33	Spacer—Armor plate	4
1-18299-60-60	Spacer—Armor plate	18
41-5951-64-17	Washer—.063 corrosive resistant steel	36
41-5651-56-13	Washer—.063 corrosive resistant steel	58
1-22986-1	Washer—1/16 rubber	2
15-9293	Armor Installation—Bulkhead 8	1
1-18298-17	Buffer—Armor plate	6
1-24246	Washer—.063 thick	8
1-24247-1	Spacer—Armor plate	8
6-11311	Armor—Bulkhead 8	1
1-18298-18	Buffer—Armor plate	2
15-8782	Armor Installation—Tail gun	1

Armament Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-22654	Bond Assembly—Armor plate	16
1-24224	Terminal—Bond assembly	16
BAC802-8-35	Jumper Assembly—Terminal bonding	16
	(Parts List No. 428A)	
15-8782-17	Support Assembly—Tail gun armor	1
15-8782-15	Angle Assembly—Armor support	1
1-22661	Angle—Armor support	1
	(Parts List No. 429)	
1-22659	Channel—Armor support	1
15-8782-18	Support Assembly—Tail gun armor	1
15-8782-16	Angle Assembly—Armor support	1
1-22661-1	Angle—Armor support	1
1-22659	Channel—Armor support	1
15-8782-19	Support Assembly—Tail gun armor	1
1-22658	Channel—Armor support	1
1-22658-1	Channel—Armor support	1
1-22660	Channel—Armor support	2
15-8782-2	Buffer—Armor plate	8
1-18298	Buffer—Armor plate	12
1-18298-2	Buffer—Armor plate	6
1-18298-10	Buffer—Armor plate	24
1-18298-12	Buffer—Armor plate	48
1-18298-13	Buffer—Armor plate	48
1-18298-15	Buffer—Armor plate	6
1-18299-63-51	Spacer—Armor plate	18
1-18299-75-27	Spacer—Armor plate	52
1-22605	Plate—Armor tail gunner	1
1-22605-1	Plate—Armor tail gunner	1
1-22606	Plate—Armor tail gunner	1
1-22606-1	Plate—Armor tail gunner	1
6-10727	Armor—Rear gunner	1
6-10727-1	Armor—Rear gunner	1
6-10728	Armor—Rear gunner	1
6-10728-1	Armor—Rear gunner	1
6-10729	Armor—Rear gunner	1
6-10729-1	Armor—Rear gunner	1
6-10730	Armor—Rear gunner	1
6-10730-1	Armor—Rear gunner	1
6-10731	Armor—Rear gunner	1
6-10731-1	Armor—Rear gunner	1
6-10751	Armor—Tail gunner	1
6-10751-1	Armor—Tail gunner	1
41-5951-64-17	Washer—.063 corrosive resistant steel	24
41-5951-64-21	Washer—.063 corrosive resistant steel	52
41-5951-96-17	Washer—.063 corrosive resistant steel	6
41-5951-96-21	Washer—.063 corrosive resistant steel	52
1-22658	Channel—Armor support	1
1-22658-1	Channel—Armor support	1
1-22659	Channel—Armor support	2
1-22660	Channel—Armor support	2
1-22661	Angle—Armor support	1
1-22661-1	Angle—Armor support	1
1-22673	Angle—Armor support	1
1-22673-1	Angle—Armor support	1
1-22674	Angle—Armor support	2
1-18299-63-27	Spacer—Armor plate	6
BAC543-12-20	Clamp—Round tube strap	4
	(Parts List No. 430)	
15-8785	Gun Installation—Side LH	1
15-8785-1	Gun Installation—Side RH	1
1-22614	Clamp—Ammunition box	2
1-22622	Base Assembly—Side gun mount LH	1
1-22622-1	Base Assembly—Side gun mount RH	1
6-10735	Plate Assembly—Ammunition box support	2
6-10735-4	Plate Assembly—Ammunition box support	2
1-22615	Plate—Ammunition box support	2

AVIALOGS.COM

FINAL ASSEMBLY

Armament Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-22616	Pin—Ammunition box support	2
6-10736	Yoke Assembly—Gun mount	2
6-10736-3	Yoke Assembly—Gun mount	2
6-10736-4	Stem Assembly—Gun mount yoke	2
1-22617	Stem—Gun mount	2
1-22621	Bushing—Gun mount	4
6-10737	Post Assembly—Gun mount LH	1
6-10737-1	Post Assembly—Gun mount RH	1
6-10737-2	Post Assembly—Gun mount LH	1
6-10737-3	Post Assembly—Gun mount RH	1
1-22618	Liner—Gun mount	2
1-22619	Tube—Gun mount	2
1-22623	Boss—Gun mount	2
3-15125-10	Bracket—Side gun mount	1L
3-15125-11	Bracket—Side gun mount	1R
1-22609	Spring—Gun mount	2
1-22610	Plunger—Gun mount	2
1-22613	Knob Assembly—Gun mount	2
1-22611	Knob—Gun mount	2
1-22612	Catch—Gun mount	2
15-8789	Support Installation—Ammunition box side gun LH	1
15-8789-1	Support Installation—Ammunition box side gun RH	1
15-8789-2	Bracket Assembly—Ammunition box side gun LH	1
15-8789-3	Bracket Assembly—Ammunition box side gun RH	1
15-8789-10	Angle Assembly—Ammunition box side gun RH	2
1-18612	Plate—Supporting	4

Armament Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-5778-1	Plate—Guide	4
41-9805	Plate—Lock	8
BAC1614-9	Spacer—⅛ rivet	16
1-16283-12	Angle—Stiffener tie	2
1-16283-13	Angle—Stiffener tie	2
6-10750	Bracket Installation—Gun stowage LH	1
6-10750-1	Bracket Installation—Gun stowage RH	1
6-10750-9	Bracket Assembly—Gun stowage LH	1
6-10750-10	Bracket Assembly—Gun stowage RH	1
3-15128	Strap Assembly—Gun stowage	1
3-15128-1	Strap Assembly—Gun stowage	1
3-15128-2	Bracket Assembly—Gun stowage	1
3-15128-3	Bracket Assembly—Gun stowage	1
3-15128-5	Strap (Make from 1-22707-8)	2
	(Parts List No. 431)	
H39B5344	Machine Gun—(M2 .50 caliber) (government furnished)	2
41K3650	Adapter—(Type E8) (government furnished)	2
37A5810	Sight—(Type A5) (government furnished)	2
37A5811	Sight—(Type B11) (government furnished)	2
525-416-9	Screw—Washer head	8
365-428	Nut—Self-locking	8
15-6806-1	Round—Flexible belt, .50 caliber ammunition (government furnished)	3200
15-6806-2	Round—with links, .30 caliber ammunition (government furnished)	500
15-6806-3	Bomb sight—.30 caliber ammunition (government furnished)	1
0903½	Lock—(Corbin Lock Co., New Britain, Conn.)	1

ARMAMENT INSTALLATION

Controls Installation—Bomb Racks and Doors

(Parts List No. 432)

15-9255	Controls Installation—Bomb racks and doors	1
65-4139-500	Control Installation—Bomb doors (PL 436-440)	1
75-4083	Bracket Installation—Main and inboard bomb control (PL 441)	1
3-15520-1	Rod Assembly—Control, ⅜	1
3-15520-101	Tube Assembly—⅜ control rod	1
1-19813-2	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
3-15521-1	Rod Assembly—⅝ inch control	1
3-15521-101	Tube Assembly—⅝ inch control rod	1
1-18109-1	Rod End—Threaded female	2
1-18487	Rod End—Self-aligning	2
3-15521-2	Rod Assembly—⅝ inch control	1
3-15521-102	Tube Assembly—⅝ inch control rod	1
1-18109-1	Rod End—Threaded female	2
1-18487	Rod End—Self-aligning	2
3-15521-3	Rod Assembly—⅝ inch control	1
3-15521-103	Tube Assembly—⅝ inch control rod	1
1-18109-1	Rod End—Threaded female	2
1-18487	Rod End—Self-aligning	2
3-15521-4	Rod Assembly—⅝ inch control	1
3-15521-104	Tube Assembly—⅝ inch control rod	1
1-18109-1	Rod End—Threaded female	2
1-18487	Rod End—Self-aligning	2
3-15521-5	Rod Assembly—⅝ inch control—outboard	2
3-15521-105	Tube Assembly—⅝ inch control rod	2
1-18109-1	Rod End—Threaded female	4
1-18487	Rod End—Self-aligning	4
3-15519-1	Rod Assembly—⅝ inch control	1

Controls Installation—Bomb Racks and Doors

3-15519-101	Tube Assembly—⅝ inch control rod	1
21-6222	Rod End—Adjustment threaded	2
21-5538	Coupling Assembly—Control rod	1
21-5538-1	Coupling—Control rod	1
41-239-11	Rod Assembly—Bomb control	1
41-239-10	Rod—Threaded—bomb control	1
41-239-13	Tube Assembly—Bomb control rod	1
41-236-1	Stop—Bomb control	1
21-6222	Rod End—Adjustment threaded	1
21-5538	Coupling Assembly—Control rod	1
21-5538-1	Coupling—Control rod	1
1-18323	Rod Assembly—Control—½ inch	1
1-18323-1	Tube Assembly—½ inch control rod	1
1-19044	Rod End—Threaded female	2
	(Parts List No. 433)	
1-18487	Rod End—Self-aligning	2
3-15521-6	Rod Assembly—⅝ inch control—inboard	2
3-15521-106	Tube Assembly—⅝ inch control rod	2
1-18109-1	Rod End—Threaded female	4
1-18487	Rod End—Self-aligning	4
3-15521-7	Rod Assembly—⅝ inch control rod	1
3-15521-107	Tube Assembly—⅝ inch control rod	1
1-18109-1	Rod End—Female threaded	2
1-18487	Rod End—Self-aligning	2
3-15522-1	Rod Assembly—⅝ inch control	1
3-15522-101	Tube Assembly—⅝ inch control rod	1
1-19044	Rod End—Threaded female	2
1-18487	Rod End—Self-aligning	2
46-4057	Joint Assembly—Bomb control	1

AVIALOGS.COM

ARMAMENT INSTALLATION

Controls Installation—Bomb Racks and Doors

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
46-4057-400	Rod Assembly—Bomb control joint	1
1-19044	Rod End—Threaded female	1
3-12010	Terminal Assembly—Hinge	1
46-4057-402	Rod Assembly—Bomb control joint	1
1-19044	Rod End—Threaded female	1
3-12010-1	Terminal Assembly—Hinge	1
1-18487	Rod End—Self-aligning	2
21-7270-4	Washer—Bearing retainer	2
21-2361-30-17	Washer—.50 steel	2
3-10948-3	Crank Assembly—Bomb control	1
3-10948-2	Shaft—Bomb control crank	1
1-20056	Arm—Control	1
41-8578	Arm—Control	1
21-3894-108-57	Washer—Retaining	2
BAC450-4	Bearing—Ball control	2
BAC1604-122	Spacer—No. ¼ bolt	1
43-8148	Lock Installation—Bomb control	1
43-8148-400	Lock Assembly—Bomb control	1
43-8148-1	Lock—Bomb control (Best lock No. 4 TOKD)	1
41-9908	Housing—Bomb control	1
21-6966-1	Fair-lead—Bomb control	1
21-9417	Crank Assembly—Bomb control lock	1
21-6974-1	Plate—Fair-lead support	2
21-6979	Fair-lead—Bomb control	1
BAC1603-11	Spacer—No. 10 bolt	2
BAC1603-14	Spacer—No. 10 bolt	2
41-2668-4	Rod End—Ball bearing	2
41-2488	Washer—Bearing retainer	10
1-22987-1	Pin—¼-28 threaded	1
41-8305	Clamp Assembly—Electric lock trigger	1
BAC560-10	Clamp Assembly—½ wide round tube	1
BAC1550-9	Sleeve—5/16—.058	1
	(Parts List No. 434)	
51-900	Arm Assembly—Control swing	2
BAC450-4	Bearing—Ball control	2
46-4212-4	Guard Installation—Emergency bomb release	1
46-4212-3	Cover Assembly—Emergency bomb release guard	1
46-4212-1	Cover—Emergency bomb release guard	1
44-764	Release Installation—Bomb door	1
51-796	Bracket Assembly—Bomb door release	1
BAC1614-19	Spacer—⅛ rivet	3
44-765	Cam Assembly—Door release	1
41-789	Guide—Door release	2
3-12175	Crank Assembly—Emergency bomb release	1
BAC450-4	Bearing—Ball control	1
BAC364-49S	Bushing—9/32 OD bearing	1
6-8993	Handle Installation—Bomb control	1
51-168	Lever Assembly—Bomb door control	1
41-4292-3	Lever Assembly—Engine control lock	1
41-7808-3	Knob Assembly—Lock lever	1
41-7916	Plug—Lock lever	2
41-7917-1	Tube—Lock lever	1
41-7940	Plug—Lock lever	1
41-2399	Spring—Compression	1
51-167	Tube Assembly—Control lever	1
41-7941	Spacer—Special	1

Controls Installation—Bomb Racks and Doors

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-5-4	Clamp Assembly—Switch trigger	1
BAC560-10	Clamp Assembly—½ wide round tube	1
BAC1550-9	Sleeve—5/16—.058	1
51-1193	Quadrant—Door control	1
6-8960	Handle Assembly—Bomb release	1
BAC326-50S	Bushing—Bearing	1
BAC1603-12	Spacer—No. 10 bolt	2
BAC1603-22	Spacer—No. 10 bolt	4
BAC1603-30	Spacer—No. 10 bolt	3
7-1029-11	Slide Installation—Emergency bomb release	1
7-1029-10	Slide Assembly—Emergency bomb release	1
21-6850	Plate—Emergency bomb release	2
21-7064-4	Tube Assembly—Emergency bomb release	1
41-143	Rod Assembly—Emergency bomb release	1
41-143-1	Rod—Emergency bomb release	1
41-143-2	Block—Emergency bomb release rod	1
1-19994	Spring—Compression	1
BAC1603-41	Spacer—No. 10 bolt	2
1-16733-11-7	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	1
46-8989	Fair-lead Installation—Bomb controls	1
46-8989-4	Fair-lead—Bomb controls	1
46-8989-3	Fair-lead—Bomb controls	1
46-8989-400	Fair-lead—Bomb controls	1
	(Parts List No. 435)	
75-5716-500	Cable and Casing Assembly—Bomb rack and door control	1
75-5716-501	Cable Assembly—Emergency release bomb rack and door control	1
0159268	Handle Assembly—(government furnished)	1
AN8004	Cap—Flexible casing	10
AN8005	Stop—Flexible casing	10
75-5716-505	Cable and Casing Assembly—Bomb rack and door control	1
BAC1779-120-6L	Cable Assembly—Swaged terminal	1
BAC1826-3	Swaged Terminal—Class "B"	1
BAC1827-3L	Swaged Terminal—Class "D"	1
AN8004	Cap—Flexible casing	4
AN8005	Stop	4
BAC1603-8	Spacer—No. 10 bolt	2
75-5716-508	Cable and Casing Assembly—Bomb rack and door control	1
BAC1779-95-6L	Cable Assembly—Swaged terminal	1
BAC1826-3	Swaged Terminal—Class "B"	1
BAC1827-3L	Swaged Terminal—Class "D"	1
AN8004	Cap—Flexible casing	4
AN8005	Stop—Flexible casing	4
BAC1603-8	Spacer—No. 10 bolt	2
75-5716-600	Braid Assembly—Bomb rack and door control	6
BAC820-8	Terminal—Electrical lock	12
41-5195	Washer—Serrated	5
0159268	Handle Assembly—(government furnished)	1
1-5745-4	Name Plate—Handle	2
BAC1603-16	Spacer—No. 10 bolt	2
BAC1603-20	Spacer—No. 10 bolt	2

CONTROL INSTALLATION—BOMB RACKS AND DOORS

Control Installation—Bomb Doors

(Parts List No. 436)

65-4139-500	Control Installation—Bomb doors	1
65-4127	Screw Assembly—Bomb door control (PL 439-440)	1
65-4127-1	Screw Assembly—Bomb door control (PL 439-440)	1
65-4127-2	Screw Assembly—Bomb door control (PL 439-440)	1
65-4127-3	Screw Assembly—Bomb door control (PL 439-440)	1

Control Installation—Bomb Doors

59-2018	Gear Installation—Bomb door controls	1
59-2018-500	Gear Assembly—Bomb door controls	1
46-4869	Housing—Bomb door controls	1
51-477	Bearing Assembly—Bomb door control	1
51-477-1	Bearing—Bomb door control (Fafnir S12FT)	1
51-476	Retainer Assembly—Bomb door control	1
51-476-1	Retainer—Bomb door control	1

AVIALOGS.COM

CONTROL INSTALLATION—BOMB RACKS AND DOORS

Control Installation—Bomb Doors

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
51-476-2	Washer Felt—Bomb door control	1
41-8188-1	Spacer—Bearing	1
21-9491	Bearing Assembly—Bomb door control	1
21-9491-1	Retainer—Bomb door control bearing	1
21-9491-3	Bearing—Ball door control bearing	1
21-9491-5	Washer—Bomb door control bearing	1
21-9492	Bearing Assembly—Bomb door control bearing	1
21-9492-1	Retainer—Bomb door control bearing	1
21-9492-3	Bearing—Ball door control bearing	1
21-9492-5	Washer—Bomb door control bearing	1
41-7949	Gear—Bomb door control	1
41-7995	Shaft Assembly—Bomb door control	1
41-7995-1	Shaft—Bomb door controls	1
41-7995-2	Pin—Bomb door controls	2
43-7863-2	Gear—Bomb door controls	1
41-7956	Nut—1-¼-12 special	1
51-778	Screw—Headless—set	3
65-4101-502	Gear Installation—Bomb door control	1
65-4101-504	Gear Assembly—Bomb door control	1
65-4101-503	Gear Assembly—Bomb door control	1
41-8216	Shaft Assembly—Bomb door control	1
43-7853-401	Gear—Bomb door control	1
1-22685	Shaft—Bomb door control	1
43-7853-400	Gear—Bomb door control	1
21-9890	Bearing Assembly—Bomb door control	1
21-9890-1	Bearing—Bomb door control (Fafnir S12FT)	2
21-9490-1	Retainer Assembly—Bomb door controls	1
21-9490-3	Retainer—Bomb door control	1
21-9490-8	Washer—Felt—bomb door control	1
41-7956	Nut—1-¼-12 special	1
21-9457	Collar—Bearing retainer	1
65-4101-400	Plug—Cork	1
51-778	Screw—Headless set	2
51-477	Bearing Assembly—Bomb door control	1
51-477-1	Bearing—Bomb door control (Fafnir S12FT)	2
41-8188-1	Spacer—Bearing	1
51-476	Retainer Assembly—Bomb door controls	1
	(Parts List No. 437)	
51-476-1	Retainer—Bomb door controls	1
51-476-2	Washer—Felt—bomb door controls	1
59-2012	Housing Assembly—Bomb door control	1
59-2012-400	Housing—Bomb door control (casting 49-2011)	1
59-2012-401	Washer—Felt 5	1
41-8217-1	Terminal—Tube end	1
43-7870	Gear Housing—Bomb door controls	1
21-9880	Bearing Assembly—Bomb door controls	1
21-9880-1	Bearing—Bomb door control (Fafnir S10FT)	1
21-9511-1	Retainer Assembly—Bomb door controls	1
21-9491	Bearing Assembly—Bomb door controls	1
21-9492	Bearing Assembly—Bomb door controls	1
43-7863-400	Gear—Bomb door control	1
BAC1002-10	Key—5/32 square	2
21-9881-1	Gear Assembly—Bomb door controls	1
43-7863-1	Gear—Bomb door control	1
21-9879	Bearing Assembly—Bomb door controls	1
21-9879-1	Bearing—Bomb door control (Fafnir S10FT)	1
21-9511	Retainer Assembly—Bomb door controls	1

Control Installation—Bomb Doors

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-8267-1	Nut—Special	1
21-9882	Pin—Crank	1
51-778	Screw—Headless set	4
41-7995	Shaft Assembly—Bomb door control	1
41-7995-1	Shaft—Bomb door control	1
41-7995-2	Pin—Bomb door control shaft	2
43-7863-2	Gear—Bomb door control	1
21-9579	Collar—Bearing retainer	1
21-6385-80-45	Shim—.032 brass washer	2
21-9587-5	Support Assembly—Bomb door crank	1
21-9587-1	Support Assembly—Weld—bomb door crank	1
21-9587-2	Bearing—Oilite—bomb door crank	1
53-7977	Shaft Assembly—Bomb door controls	2
53-7977-1	Shaft Assembly—Bomb door controls	2
41-7811	Bushing—Universal joint adapter	8
53-7977-2	Sleeve—Bomb door controls	2
53-7977-402	Sleeve—Bomb door controls	2
53-7977-400	Tube—Bomb door controls	2
41-6608	Shaft Assembly—Bomb door controls	1
9-3097	Switch Installation—Bomb door limit	1
3-12061	Shield Assembly—Bomb door LH	1
3-12061-1	Shield Assembly—Bomb door RH	1
41-9981-7	Shield Assembly—Junction	2
BAC1247-8D	Plate—Angle nut	4
6-10790-17	Decalcomania—Switch limit bomb door 182	1L
41-9981-2	Cover—Junction shield	2
36A4486-832	Screw—Round head necked	4
39A3756	Switch Assembly—Toggle (Type B-15) ND	2
41-7760-3	Sleeve Assembly—Limit switch	1
	(Parts List No. 438)	
41-94	Guide—Limit switch	1
51-463	Nut—Limit switch	1
51-211	Striker—Limit switch	1
51-211-1	Striker—Limit switch	1
BAC1603-14	Spacer—No. 10 bolt	6
41-9882	Bearing Assembly—Bomb door controls	1
41-9882-1	Retainer—Bomb door control (casting 41-9881)	1
41-9882-2	Bearing—Bomb door control (Fafnir A542)	1
6-8345-13	Check Installation—Bomb door LH	2
6-8345-14	Check Installation—Bomb door RH	2
6-8345-12	Check Assembly—Bomb door	4
6-8345-6	Pin—Bomb door check	4
6-8345-8	Washer—Cup—bomb door check	4
6-8345-9	Spacer—Bomb door check	4
6-8345-10	Packing—Bomb door check	4
6-8345-15	Spring—Expander—bomb door check	4
6-8345-3	Cylinder Assembly—Bomb door check	4
51-872-4	Rod Assembly—Bomb door check	4
51-1107	Clevis—5/16 bolt	4
21-6588-80-21	Washer—.188 steel (1025)	4
51-1108-36-10	Washer—½ neoprene	4
51-873	Nut—Packing	4
41-9868	Seal—Bearing	4
41-7811	Bushing—Universal joint adapter	8
A-4050	Cone—Bomb door control (Timken Bearing Co., Canton, Ohio)	4
21-9751-16	Boot Installation—Universal grease	8
21-9751-16A	Boot—Universal grease	8
21-9751-2	Chord—Universal grease boot	16

CONTROL INSTALLATION—BOMB DOORS

Screw Assembly—Bomb Door Controls

	(Parts List No. 439)	
65-4127	Screw Assembly—Bomb door controls	1
65-4127-1	Screw Assembly—Bomb door controls	1
65-4127-2	Screw Assembly—Bomb door controls	1

Screw Assembly—Bomb Door Controls

65-4127-3	Screw Assembly—Bomb door controls	1
65-4127-7	Cone—Roller bearing (Timken No. 07087)	2
07087	Cone—Roller bearing (used on 65-4127 and -1)	2
21-9682	Catch—Bomb door controls LH (used on 65-4127 and -3)	4

AVIALOGS.COM

CONTROL INSTALLATION—BOMB DOORS

Screw Assembly—Bomb Door Controls

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-9862-1	Catch—Bomb door controls RH (used on 65-4127-1 and -2)	4
21-9886	Spring—Compression	8
41-6825	Nut—⅞-14 special	4
3-9778	Collar Assembly—Bomb door controls LH (used on 65-4127 and -3)	2
3-9778-1	Collar Assembly—Bomb door controls RH (used on 65-4127-1 and -2)	2
41-7584	Stop Assembly—Bomb door controls (used on 65-4127 and -2)	2
41-7584-1	Stop Assembly—Bomb door controls (used on 65-4127-1 and -3)	2
41-7584-2	Neoprene—Bomb door controls stop	4
41-7584-3	Cover—Bomb door control stop	4
6-7198	Fitting—Bomb door control	2
6-7198-1	Fitting—Bomb door control	2
41-6659	Plate—Bomb door controls	8
41-6826	Guide—Bomb door controls	4
21-9860	Guide—Bomb door controls	4
21-9861	Guide—Bomb door controls	4
21-9678	Spring—Compression	4
43-7935-400	Nut Assembly—Bomb door controls (used on 65-4127 and -2)	2
43-7935-401	Nut Assembly—Bomb door controls (used on 65-4127-1 and -3)	2
3-7934-1	Gear—Set—bomb door controls	4
41-9966	Stop—Bomb door controls	2
41-9966-1	Stop—Bomb door controls	2
21-6385-112-88	Shim—.032 brass washer	4
1-21487	Nut—Bomb door controls	2
43-7935-2	Bearing—Ball—bomb door control nut	4
1-21488	Nut—Bomb door controls	2
21-6385-180-160	Shim—.032 brass washer	4
41-9892	Retainer Assembly—Bomb door controls	4
41-9892-1	Retainer—Bomb door controls	4
41-9892-2	Washer—Felt—bomb door controls retainer	4
46-4911	Housing Assembly—Bomb door controls (used on 65-4127 and -3)	2

Screw Assembly—Bomb Door Controls

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
46-4911-1	Housing Assembly—Bomb door controls (used on 65-4127-1 and -2)	2
46-4911-2	Housing—Bomb door controls	2
46-4911-3	Housing—Bomb door controls	2
46-4911-4	Washer—Felt—bomb door controls housing	4
21-9682	Plate—Bomb door controls	4
3-7934-2	Gear Assembly—Set—bomb door controls	4

(Parts List No. 440)

21-9672	Bearing Assembly—Bomb door controls	4
21-9672-3	Bearing—Ball, bomb door controls (Fafnir No. 5205)	4
21-9672-5	Washer—Felt—bomb door controls bearing	4
21-9672-1	Retainer—Bomb door controls bearing	4
41-8267	Nut—Special	4
21-9677	Stop—Bomb door controls (used on 65-4127 and -2)	2
21-9677-1	Stop—Bomb door controls (used on 65-4127-1 and -3)	2
21-9824	Seal Assembly—Bomb door controls	4
21-9824-2	Washer—Bomb door control seal	4
21-9824-4	Ring—Felt—bomb door control seal	4
41-8267	Nut—Special	4
21-9683	Shaft—Bomb door controls	4
6-8130	Terminal Assembly—Bomb door control (used on -0 and -3 only)	2
6-8130-1	Terminal Assembly—Bomb door control (used on -1 and -2 only)	2
6-8130-2	Terminal Assembly—Bomb door controls (used on -0)	2
6-8130-3	Terminal Assembly—Bomb door controls (used on -1)	2
6-8130-7	Rod—Bomb door controls	2
51-778	Screw—Headless set	8
3-15109	Screw—Bomb door controls (used on 65-4127 and -2)	2
3-15109-1	Screw—Bomb door controls (used on 65-4127-1 and -3)	2

CONTROL INSTALLATION—BOMB RACKS AND DOORS

Bracket Installation—Main and Inboard Bomb Control

(Parts List No. 441)

75-4083	Bracket Installation—Main and inboard bomb control	1
3-10300	Bracket Assembly—Main bomb control	1
3-10301	Bracket Assembly—Main bomb control	1
BAC1614-106	Spacer—⅛ rivet	2
41-6077	Bracket Assembly—Main bomb control	1
41-6076	Bracket Assembly—Main bomb control	1
21-9070	Bracket Assembly—Inboard bomb control	1
21-9071	Bracket Assembly—Inboard bomb control	1
3-12987	Bracket Assembly—Inboard bomb control	2
3-6864-119	Crank Assembly—Control	2
51-761-4	Lever—Control	2
51-761-5	Lever—Control	2
BAC450-4	Bearing—Ball control	2
BAC1604-13	Spacer—¼ bolt	1
BAC1604-26	Spacer—¼ bolt	1
BAC1604-40	Spacer—¼ bolt	2
3-7819-4	Bell Crank Assembly—Main bomb control	1

Bracket Installation—Main and Inboard Bomb Control

51-761-4	Lever—Control	2
51-762-1	Lever—Serrated control	1
BAC450-4	Bearing—Ball control	2
BAC1604-63	Spacer—¼ bolt	1
BAC1604-29	Spacer—¼ bolt	1
BAC1604-36	Spacer—¼ bolt	1
3-12090-6	Crank Assembly—Control	1
3-12088-36-42	Crank—Serrated control	1
BAC450-4	Bearing—Ball control	1
3-15520-3	Rod Assembly—Control ⅜	1
3-15520-103	Tube Assembly—Weld control ⅜ rod	1
1-19813-2	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
3-15522-2	Rod Assembly—½ inch control	1
3-15522-102	Tube Assembly—½ inch control rod	1
1-19044	End—Rod—threaded female	1
1-18487	Rod End—Self-aligning	2
1-19001-1	Fair-lead—Miscellaneous	1
BAC1604-32	Spacer—¼ bolt	2

AVIALOGS.COM

ARMAMENT INSTALLATION

Rack Installation—Bomb

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 442)	
15-7329-5	Rack Installation—Bomb	1
14-2048	Cover Installation—Bomb control	1
14-2048-1	Cover Installation—Bomb control	1
1-18064	Angle Assembly—Bomb control cover	16
1-18064-2	Angle Assembly—Bomb control cover	4
14-2048-7	Cover—Bomb control	1L
14-2048-8	Cover—Bomb control	1R
15-6991-12	Rack Assembly—Internal outboard bomb LH	1
15-6991-13	Rack Assembly—Internal outboard bomb RH	1
3-12956	Bracket Assembly—Outboard bomb rack	4
BAC346-8-281	Bushing—Staked	8
15-6809-1	Rail Assembly—Front LH internal inboard bomb rack	1
15-6809-2	Rail Assembly—Front RH internal inboard bomb rack	1
15-6809-3	Rail Assembly—Front LH internal inboard bomb rack	1
15-6809-4	Rail Assembly—Front RH internal inboard bomb rack	1
21-5958-1	Plate—Bomb rack No. tab	3
21-5958-2	Plate—Bomb rack No. tab	3
3-12969	Bar Assembly—Bomb rail spreader LH	1
3-12969-1	Bar Assembly—Bomb rail spreader RH	1
1-17599	Bracket—Bomb control	2
3-13380	Crank Assembly—Bomb control LH	1
3-13380-1	Crank Assembly—Bomb control RH	1
3-13380-2	Crank—Bomb control	2
3-13380-3	Crank—Bomb control	2
3-13380-4	Spacer—Bomb control crank	2
BAC450-4	Bearing—Ball control	2
6-8958-1	Bar Assembly—Bomb rail spreads	2
1-17503	Bracket—Bomb rail spreads	4
1-17505	Tube—Bomb rail spreads	2
1-18088	Filler—Spreader bar	2
BAC1604-21	Spacer—¼ bolt	2
BAC1604-140	Spacer—¼ bolt	2
6-8967	Bar Assembly—Bomb rail spreads	4
41-4180	Pulley Assembly—20 diameter	4
41-4180-1	Pulley—20 diameter	4
1-17503	Bracket—Bomb rail spreader	8
1-17505	Tube—Bomb rail spreader	4
1-20004-1	Washer—Aluminum alloy	4
BAC1604-107	Spacer—No. 10 bolt	4
6-8980	Support Assembly—Bomb release	3
6-8980-1	Support Assembly—Bomb release	3
1-17647	Bearing Assembly—Bomb control	6
1-17569	Retainer—Bomb control bearing	6
1-17566-1	Bell Crank—Bomb control	6
1-17634	Bearing—Bomb control	6
3-13372	Channel—Bomb release	3
3-13372-1	Channel—Bomb release	3
21-8038-16A	Screw—No. 10-32 flathead	12
	(Parts List No. 443)	
6-8980-5	Ring—Clip socket—bomb release support (Simmonds A132) (government furnished)	12
1-18999-12-9	Rod Assembly—Control	4
1-18999-12-9A	Tube—Control rod	4
1-19699-18	End—Rod, LH thread	4
21-5538	Coupling Assembly—Control rod	2
1-19702	Coupling Assembly—Control rod	2
1-19702-1	Coupling—Control rod	2
1-19705-4-8	Rod—Control rod	2
1-19704	Rod End—Control	2
21-9784-10-3A	Eye—Bolt—¼-28	2
41-2668-4	Rod End—Ball bearing	2
33A6182	Latch Assembly—Bomb rack carrying hook	6
33A6182-1	Latch Assembly—Bomb rack carrying hook	6
33A6180	Hook Assembly—Bomb rack carrying hook	6
33A6180-1	Hook Assembly—Bomb rack carrying hook	6

Rack Installation—Bomb

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
33A6186	Spring—Bomb rack carrying hook latch	6
33A6186-1	Spring—Bomb rack carrying hook latch	6
33A6185	Spacer—Bomb rack carrying hook upper front	6
33A6187	Spacer—Bomb rack carrying hook lower front	6
33A6196	Spacer—Bomb rack carrying hook upper rear	6
33A6197	Spacer—Bomb rack carrying hook lower rear	6
41-2488	Washer—Bearing retainer	6
BAC538-10	Clamp—Loop type cushioned	6
BAC539-10	Clamp—Cushioned lug type	2
BAC540-8	Clamp—Loop type cushioned	4
BAC540-6	Clamp—Loop type cushioned	4
15-6991-7	Box—Auxiliary	6
BAC1606-80	Spacer—⅜ bolt	4
BAC1608-90	Spacer—½ bolt	4
BAC540-6	Clamp—Loop type cushioned	2
BAC540-10	Clamp—Loop type cushioned	3
BAC1603-16	Spacer—No. 10 bolt	1
BAC540-12	Clamp—Loop type cushioned	4
15-6992-14	Rack Assembly—Internal inboard bomb LH	1
15-6992-15	Rack Assembly—Internal inboard bomb RH	1
15-6990-1	Channel Assembly—Front—inboard bomb rack rail	1
15-6990-2	Channel Assembly—Front—inboard bomb rack rail	1
21-9852	Plate—Bomb rail reinforcing LH	2
21-9852-1	Plate—Bomb rail reinforcing RH	2
15-6990-3	Channel Assembly—Rear—inboard bomb rack rail	1
15-6990-4	Channel Assembly—Rear—inboard bomb rack rail	1
21-5958-1	Plate—Bomb rack No. tab	14
21-5958-2	Plate—Bomb rack No. tab	8
21-5958-5	Plate—Bomb rack No. tab	2
21-5958-6	Plate—Bomb rack No. tab	8
21-5958-7	Plate—Bomb rack No. tab	4
21-9852	Plate—Bomb rail reinforcing RH	2
	(Parts List No, 444)	
21-9852-1	Plate—Bomb rail reinforcing LH	2
6-8958	Bar Assembly—Bomb rail spreader	2
1-17503	Bracket—Bomb rail spreader	4
1-17505	Tube—Bomb rail spreader	2
1-18088	Filler—Bomb rail spreader	2
6-8957	Bar Assembly—Bomb rail spreader	2
1-17503	Bracket—Bomb rail spreader	4
1-17505	Tube—Bomb rail spreader	2
1-17584-13	Filler—Bomb rail spreader	2
41-4180	Pulley Assembly—20 diameter	2
41-4180-1	Pulley—20 diameter	2
1-20004	Washer—Aluminum alloy	2
46-8974	Bracket Assembly—Inboard bomb rack	1
46-8974-1	Bracket Assembly—Inboard bomb rack	1
3-13903	Crank Assembly—Control RH	1
3-13903-1	Crank Assembly—Control LH	1
3-13903-2	Rub Assembly—Control crank	2
1-19827-144	Hub—Control crank	2
BAC1604-56	Spacer—¼ bolt	2
1-19828-1	Lever—Tab fork	4
BAC1604-35	Spacer—¼ bolt	2
BAC1604-49	Spacer—¼ bolt	2
6-8980	Support Assembly—Bomb release LH	6
6-8980-1	Support Assembly—Bomb release RH	6
6-8980-5	Ring—Clip socket (Simmonds No. A132) (government furnished)	24
1-17634	Bearing—Bomb control	12
3-13372	Channel—Bomb release	6L
3-13372-1	Channel—Bomb release	6R
21-8038-16A	Screw—No. 10-32 flathead	24
1-17566-1	Bell—Crank bomb control	12
1-17647	Bearing Assembly—Bomb control	12
1-17569	Retainer—Bomb control bearing	12

AVIALOGS.COM

ARMAMENT INSTALLATION

Rack Installation—Bomb

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-8980-3	Support Assembly—Bomb release LH	1
6-8980-4	Support Assembly—Bomb release RH	1
1-17566-1	Bell—Crank bomb control	2
1-17634	Bearing—Bomb control	2
1-17647	Bearing Assembly—Bomb control	2
1-17569	Retainer—Bomb control bearing	2
3-13372	Channel—Bomb release	1L
3-13372-1	Channel—Bomb release	1R
21-8038-16A	Screw—10-32 flathead	4
1-18064-2	Angle Assembly—Bomb control cover	4
6-8980-5	Ring—Clip socket (Simmonds No. A132) (government furnished)	4
6-8981	Brace Assembly—Inboard bomb rack LH	1
6-8981-1	Brace Assembly—Inboard bomb rack RH	1
1-19704	Rod End—Ball bearing	2
33A6180	Hook Assembly—Bomb rack carrying	14
	(Parts List No. 445)	
33A6180-1	Hook Assembly—Bomb rack carrying	16
33A6182	Latch Assembly—Bomb rack carrying hook LH	15
33A6182-1	Latch Assembly—Bomb rack carrying hook RH	15
33A6186	Spring—Bomb rack carrying hook latch	15
33A6186-1	Spring—Bomb rack carrying hook latch	15
3-12981	Channel Assembly—Bomb rack reinforcing	1
3-12981-1	Channel Assembly—Bomb rack reinforcing	1
21-5538	Coupling Assembly—Control rod	4
21-5538-1	Coupling—Control rod	4
21-5538-16	Coupling Assembly—Control rod	2
21-5538-17	Coupling—Control rod	2
1-18999-10-0	Rod Assembly—Control	2
1-18999-10-0A	Tube—Control	2
1-19699-18	Rod End—LH thread control	2
1-19702	Coupling Assembly—LH thread control rod	6
1-19702-1	Coupling—RH thread control rod	6
1-19704	Rod End—Ball bearing	2
1-19705-7-8	Rod—¼ RH and LH thread	12
1-19814-8-5	Rod Assembly—Control	2
1-19814-8-5A	Tube Weld Assembly—Control rod	2
1-19813-2	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
1-19814-12-5	Rod Assembly—Control	2
1-19814-12-5A	Tube Assembly—Weld—control	2
1-19813-2	Rod End—Female	4
1-18487	Rod End—Self-aligning	4
1-20004	Washer—Aluminum alloy	2
21-9784-10-4A	Eye—Bolt ¼-28	2
21-8038-52A	Screw—10-32 flathead	50
33A6185	Spacer—Bomb rack carrying hook upper front	16
33A6187	Spacer—Bomb rack carrying hook lower front	16
33A6196	Spacer—Bomb rack carrying hook upper rear	14
33A6197	Spacer—Bomb rack carrying hook lower rear	14
41-2488	Washer—Bearing retaining	14
6-8940	Plate Assembly—Bomb rack shear	1
6-8940-1	Plate Assembly—Bomb rack shear	1
1-18064	Angle Assembly—Bomb control cover	16
3-12090-12	Crank Assembly—Control	2
3-12089-32-32	Crank—Control	2
BAC450-4	Bearing—Ball control	2
6-9223	Crank Assembly—Control	1
6-9223-1	Crank Assembly—Control	1
6-9223-3	Crank—Control	1
6-9223-4	Crank—Control	1
BAC450-4	Bearing—Ball control	2
1-17582-2	Bracket—Crank support	2
3-12989	Channel Assembly—Bomb rail attaching bracket	2
3-12989-1	Channel Assembly—Bomb rail attaching bracket	2
BAC348-4-256	Bushing—½ staked	8
	(Parts List No. 446)	
6-8956	Bar Assembly—Bomb rail spreader	2
1-17503-1	Bracket—Bomb rail spreader	4
1-17504	Tube—Bomb rail spreader	2

Rack Installation—Bomb

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-17584-13	Filler—Bomb rail spreader	2
BAC1604-55	Spacer—¼ bolt	8
41-4180	Pulley Assembly—20 diameter	2
6-8956-1	Bar Assembly—Bomb rail spreader	4
1-17503-1	Bracket—Bomb rail spreader	8
1-17504	Tube—Bomb rail spreader	4
BAC1604-55	Spacer—¼ bolt	16
6-8997	Bar Assembly—Bomb rail spreader	2
6-8997-1	Bar Assembly—Bomb rail spreader	2
1-17503	Bracket—Bomb rail spreader	8
1-17505	Tube—Bomb rail spreader	4
1-18064	Angle Assembly—Bomb control	8
41-4180	Pulley Assembly—20 diameter	2L
41-4180-1	Pulley—20 diameter	2
1-18115	Channel Assembly—Bomb hoist support	2L
1-17584-28	Filler—Bomb rail spreader	2L
1-20004	Washer—Aluminum alloy	2L
BAC1603-14	Spacer—No. 10 bolt	2
BAC1603-18	Spacer—No. 10 bolt	12
BAC1604-25	Spacer—¼ bolt	2
BAC538-10	Clamp—Loop type cushioned	6
BAC539-10	Clamp—Cushioned lug type	2
BAC540-6	Clamp—Loop type cushioned	2
BAC540-8	Clamp—Loop type cushioned	4
BAC540-10	Clamp—Loop type cushioned	4
21-9884	Filler—Bomb rail support	8
BAC1603-8	Spacer—No. 10 bolt	4
BAC1603-32	Spacer—No. 10 bolt	2
BAC1603-64	Spacer—No. 10 bolt	2

Hoist Installation—Internal Bomb

(Parts List No. 447)

15-7335-1	Hoist Installation—Internal bomb	1
15-7781	Adapter Installation—D-6 bomb door shackle LH	1
15-7781-1	Adapter Installation—D-6 bomb door shackle RH	1
15-7781-2	Adapter Assembly—D-6 bomb door shackle LH	1
15-7781-3	Adapter Assembly—D-6 bomb door shackle RH	1
15-7781-4	Tube Assembly—D-6 bomb door shackle adapter LH	1
15-7881-5	Tube Assembly—D-6 bomb door shackle adapter RH	1
1-19995	Bracket Assembly—Shackle adapter	2
21-9212	Bearing Assembly—Control	8
21-9212-1	Bearing—Cup control	8
21-9212-2	Strip—Rubbing control bearing	2
1-19656	Bracket—Shackle adapter	4
1-19847	Bracket—Shackle adapter	4
8-1295	Tube—Shackle adapter LH	1
8-1295-1	Tube—Shackle adapter RH	1
1-19060	Shaft Assembly—Shackle adapter	4
1-19060-1	Shaft—Shackle adapter	4
1-19843	Crank—Shackle adapter	4
1-19069	Lever Assembly—Shackle adapter	4
21-9214-4	Lever—Bomb release	4
1-19857-1	Crank Assembly—Shackle adapter LH	1
1-19857-2	Crank Assembly—Shackle adapter LH	1
1-19843	Crank—Shackle adapter	2
1-19856	Shaft—Shackle adapter	2
41-484-6-1	Rod Assembly—Control	2
41-484-6-6	Rod Assembly—Control	2
41-2668-4	Rod End—Ball bearing	2
1-19857-3	Crank Assembly—Shackle adapter RH	1
1-19857-4	Crank Assembly—Shackle adapter RH	1
1-19843	Crank—Shackle adapter	2
1-19856	Shaft—Shackle adapter	2
51-276	Fitting—Shackle adapter	2
51-274	Fitting—Shackle adapter	2
1-19844	Lever—Flanged	4
41-2668-4	Rod End—Ball bearing	4
3-13937-1	Terminal—Aft—shackle adapter	2
3-13937-2	Terminal—Forward—shackle adapter	2

AVIALOGS.COM

ARMAMENT INSTALLATION

Hoist Installation—Internal Bomb

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-9233	Link—Shackle adapter	2
41-16	Link—Shackle adapter	2
BAC1606-8	Spacer—⅜ bolt	4
BAC1606-38	Spacer—⅜ bolt	4
1-18982	Spacer Assembly—Shackle adapter	4
15-7582	Support Assembly—Bomb hoist	1
3-13533	Support Assembly—Hoist handle stowage	1
3-13533-1	Plate Assembly—Hoist handle stowage	1
3-13533-2	Plate—Hoist handle stowage support	1
3-13533-3	Plug—Hoist handle stowage support	2
41-75-2	Spring—Bomb hoist crank	4
	(Parts List No. 448)	
3-13533-4	Channel Assembly—Hoist handle stowage support	1
3-13558	Support Assembly—Hoist handle stowage	1
3-13558-1	Plate Assembly—Hoist handle stowage support	1
3-13558-4	Plate—Hoist handle stowage support	1
41-75-2	Spring—Bomb hoist crank	4
3-13558-2	Channel Assembly—Hoist handle stowage	1
3-13601	Latch Assembly—Bomb hoist	1
3-13601-1	Housing Assembly—Weld bomb hoist latch	1
41-72	Spring—Compression	1
41-76-1	Knob—Bomb hoist lock	1
41-78	Pin—Bomb hoist lock	1
41-67	Cap—Bomb hoist bearing	4
41-68	Bearing—Bomb hoist	4
1-18311	Plate—Bomb hoist support	2
1-18312	Plate—Bomb	2
9-5204-23	Decalcomania—Doors—open, closed	1
9-5204-28	Decalcomania—Doors—open, closed	1
1-18438	Channel—Bomb hoist	2
1-18292-48-330	Bolt—5/16-24 shoulder	2
21-5584	Bolt—Bearing hinge	4
1-18292-48-222	Bolt—5/16-24 shoulder	2
51-175	Hoist Assembly—Bomb RH	1
51-175-1	Hoist Assembly—Bomb LH	1
1-18165	Cable Assembly—Bomb hoist	2

Hoist Installation—Internal Bomb

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18162	Hook—Bomb hoist	2
BAC1828-67	Terminal—Dead end cable	2
35G3422	Hoist Assembly—Bomb (Type C-3) (government furnished)	2
3-6738	Bolt Assembly—Self-locking	2
3-6738-1	Bolt—Self-locking	2
3-6738-3	Spring—Self-locking	2
3-6738-17	Ring—Self-locking (Pacific Marine Supply, Seattle, Wash.)	2
3-9775	Bolt Assembly—Self-locking	6
3-9775-1	Bolt—Self-locking	6
3-9775-3	Ring—Self-locking (Pacific Marine Supply, Seattle, Wash.)	6
41-4545	Spring—Self-locking bolt	6
3-9777	Guide Assembly—Bomb hoist cable	2
3-9777-1	Guide—Bomb hoist cable	2
41-4180	Pulley Assembly—20 diameter	2
41-4180-1	Pulley—20 diameter	2
41-4180	Pulley Assembly—20 diameter	2
41-4180-1	Pulley—20 diameter	2
41-4181	Pulley Assembly—3½ outside diameter	6
41-4181-1	Pulley—3½ outside diameter	6
33D5226	Shackle Assembly—(Type B-7) (government furnished)	16
33B3441	Handle Assembly—Bomb hoist (government furnished)	2
36C4441	Sling Assembly—Bomb hoist, 300 lb. (government furnished)	1
	(Parts List No. 448A)	
36E4442	Sling Assembly—Bomb hoist, 600 lb. (government furnished)	1
36E4443	Sling Assembly—Bomb 2000 lb.-1100 lb. (government furnished)	1
40G5318	Sling Assembly—Bomb, 2000 lb. (government furnished)	1
41G1742	Bomb Release Assembly (government furnished)	10
41G1742-1	Bomb Release Assembly (government furnished)	10
41E4555	Shackle Assembly—Bomb (Type D-6) (government furnished)	2

FINAL ASSEMBLY

Controls Installation—Flight

(Parts List No. 449)

1-18364	Controls Installation—Flight	1
15-7030	Control Installation—Aileron (PL 450-451)	1
15-9254	Control Installation—Rudder (PL 452-455)	1

Controls Installation—Flight

15-9253	Control Installation—Elevator (PL 456-458)	1
15-7033	Control Installation—Tailwheel and surface lock (PL 459-460)	1
15-7034	Control Installation—Aileron, rudder and elevator trim tabs (PL 461-462)	1

CONTROLS INSTALLATION—FLIGHT

Controls Installation—Aileron

(Parts List No. 450)

15-7030	Control Installation—Aileron	1
1-18205-87-1L	Cable Assembly—⅛—7 x 19 control	1
1-18205-92-5R	Cable Assembly—⅛—7 x 19 control	1
1-20527	Terminal—Swaged class "B" cable, ¼ hole	2
BAC1827-46	Swaged Terminal—Class "D"	2
BAC1775-152-5	Cable Assembly—⅛—7 x 19 control	1
BAC1775-161-5	Cable Assembly—⅛—7 x 19 control	1
BAC1827-4L	Swaged Terminal—Class "D"	2
BAC1827-4R	Swaged Terminal—Class "D"	2

Controls Installation—Aileron

BAC1783-73-4L	Cable Assembly—3/16—7 x 19 control	1
BAC1783-71-7L	Cable Assembly—3/16—7 x 19 control	1
BAC1783-71-2L	Cable Assembly—3/16—7 x 19 control	1
BAC1783-73-2L	Cable Assembly—3/16—7 x 19 control	1
BAC1826-6	Swaged Terminal—Class B	4
BAC1827-6L	Swaged Terminal—Class D	4
BAC1784-94-0L	Cable Assembly—3/16—7 x 19 control	1
BAC1784-100-1R	Cable Assembly—3/16—7 x 19 control	1
BAC1784-111-4R	Cable Assembly—3/16—7 x 19 control	1
BAC1784-159-5L	Cable Assembly—3/16—7 x 19 control	4
BAC1784-246-2L	Cable Assembly—3/16—7 x 19 control	1

AVIALOGS.COM

CONTROLS INSTALLATION—FLIGHT

Controls Installation—Aileron

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1784-253-3L	Cable Assembly—3/16—7 x 19 control	1
BAC1784-265-1L	Cable Assembly—3/16—7 x 19 control	1
BAC1784-273	Cable Assembly—3/16—7 x 19 control	1
BAC1826-6	Swaged Terminal—Class B	11
BAC1827-26L	Swaged Terminal—Class D	11
1-19652	Link—Control cable	8
41-1457-35	Bushing—5/16 OD bearing	2
41-9783	Bracket Assembly—Aileron pulley	2
AN4-42	Bolt—Aircraft, 1/4-28	2
41-4440	Bracket—Pulley	2
AN4-21	Bolt—Aircraft, 1/4-28	2
1-21480	Fair-lead Installation—Aileron control cable	1
41-6641	Brace Assembly—Aileron cable fair-lead	1
1-19004-15	Fair-lead Assembly—Aileron control cable	1
1-19004-16	Fair-lead—Aileron control cable	1
1-19004-17	Fair-lead—Aileron control cable	1
1-19004-18	Fair-lead—Aileron control cable	1
1-19004-19	Fair-lead—Aileron control cable	1
1-19004-20	Fair-lead—Aileron control cable	1
6-7030	Fair-lead Installation—Aileron control cables	1
6-7030-9	Fair-lead Installation—Aileron control cables	1
6-7030-1	Fair-lead—Aileron control cables	1
6-7030-2	Fair-lead—Aileron control cables	1
6-7030-3	Fair-lead—Aileron control cables	1
6-7030-4	Fair-lead—Aileron control cables	1
6-7030-10	Fair-lead Installation—Aileron control cables	1
6-7030-5	Fair-lead—Aileron control cables	1
	(Parts List No. 451)	
6-7030-6	Fair-lead—Aileron control cables	1
6-7030-7	Fair-lead—Aileron control cables	1
6-7030-8	Fair-lead—Aileron control cables	1
41-5132	Fair-lead Installation—Aileron control cables	1
41-6640	Brace Assembly—Aileron cable fair-lead	1
41-5132-5	Fair-lead Assembly—Aileron control cables	1
41-5132-1	Fair-lead Assembly—Aileron control cables	1
41-5132-2	Fair-lead Assembly—Aileron control cables	1
41-5132-3	Fair-lead Assembly—Aileron control cables	1
41-5132-4	Fair-lead Assembly—Aileron control cables	1
1-19001-9	Fair-lead Assembly—1 hole	3
1-19001-8	Fairlead—1 hole	6
1-19001-11	Fair-lead Assembly—1 hole	16
1-19001-10	Fair-lead—1 hole	32
1-19003-1	Fair-lead Assembly—3 holes	2
1-19003-2	Fair-lead—3 holes	4
AN3-14A	Bolt—Aircraft—No. 10-32	2
AN4-11	Bolt—Aircraft—1/4-28	3
AN4-12	Bolt—Aircraft—1/4-28	2
AN4-15	Bolt—Aircraft—1/4-28	2
AN4-21	Bolt—Aircraft—1/4-28	3
AN5-12	Bolt—Aircraft—5/16-24	8
AN155-46L	Barrel—Turnbuckle	16
AN155-46S	Barrel—Turnbuckle	4
AN155-21S	Barrel—Turnbuckle	2
AN165-46L	Eye—Turnbuckle	12
AN165-46S	Eye—Turnbuckle	4
AN161-46RL	Fork—Turnbuckle	2
AN210-3A	Control—Pulley	8
AN310-4	Nut—Castle	12
AN310-5	Nut—Castle	16
365-1032	Nut—Self-locking	16
AN380-2-2	Pin—Cotter	24
AN520-10-16	Screw—Round head—fine thread	2
AN520-10-24	Screw—Round head—fine thread	18
AN960-D10	Washer—Plain	2
AN960-D416	Washer—Plain	14
AN5-6	Bolt—Aircraft—5/16-24	8

Controls Installation—Rudder

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 452)	
15-9254	Controls Installation—Rudder	1
65-3508-502	Rudder Pedals Installation (PL 454-455)	1
54-1600	Control Installation—Brake	1
3-9584-1	Valve Assembly—Wheel brake	2
3-9584-2	Valve Assembly—Wheel brake	2
3-10296	Cylinder—Wheel brake	2
3-10296-1	Cylinder—Wheel brake	2
41-6187-1	Guide Assembly—Wheel brake	4
41-3719	Crosshead—Wheel brake	4
41-3718-1	Guide—Spring—wheel brake	4
41-3722	Spring—Compression	4
41-6190-3	Piston Assembly—Wheel brake	4
41-6190-4	Piston Assembly—Wheel brake	4
41-3715-1	Piston—Wheel brake	4
41-3716-2	Washer—Packing—wheel brake	4
41-3723	Spring—Compression	4
51-419	Adapter—Packing	4
41-6190-5	Packing—Wheel brake piston	8
51-418	Adapter—Packing	4
21-3225	Nut—Clamp	4
41-3758	Ring—Piston—wheel brake	4
41-3712-1	Pintle—Wheel brake	4
41-9384	Spring—Compression	4
41-3713-1	Guide—Pintle—wheel brake	4
41-6189-1	Washer—Wheel brake	4
41-3711	Seat—Ball—wheel brake	4
41-3710	Cap—End wheel brake	4
41-3724	Spring—Compression	4
3-9584-3	Ball—Wheel brake valve	4
51-447-0-39	Spacer—10-32 bolt	12
BAC1603-42	Spacer—No. 10 bolt	4
BAC1603-51	Spacer—No. 10 bolt	8
54-1600-500	Shaft Assembly—Parking brakes control	1
51-704	Tube—Brake control	1
41-9411	Bearing Assembly—Brake control	2
41-9411-1	Housing—Brake control bearing	2
51-446-2-62	Tube—1/8—.058	1
41-4543-5	Arm Assembly—Brake control	2
41-4544	Arm Assembly—Brake control	1
51-784	Shim—Park brake bearing—brass	3
51-784-1	Shim—Park brake bearing—brass	4
41-9411	Bearing Assembly—Brake control	1
41-9411-1	Housing—Brake control bearing	1
21-7196-10	Rod Assembly—Control	1
41-9960	Knob—Parking brake	1
21-7468	Spring—Compression	1
21-2364-48-33	Washer—.064 aluminum alloy	1
3-15184	Unit Installation—Rudder and elevator servo	1
	(Parts List No. 453)	
1-23582	Motor—Elevator servo (government furnished)	1
1-23583	Motor—Rudder servo (government furnished)	1
BAC1603-131	Spacer—1/4 bolt	12
3-10767	Bracket Assembly—Rudder bus cable	2
BAC1614-40	Spacer—1/8 rivet	12
BAC326-17S	Bushing—Bearing	2
41-9782	Bracket Assembly—Control pulley	2
1-18205-9-0R	Cable—1/8—7 x 19 control	2
BAC1772-27-7	Cable Assembly—3/16—7 x 19 control	2
BAC1778-308-1	Cable Assembly—3/16—7 x 19 control	2
BAC1783-86-2L	Cable Assembly—3/16—7 x 19 control	1
BAC1783-89-0L	Cable Assembly—3/16—7 x 19 control	1
BAC1784-116-4L	Cable Assembly—3/16—7 x 19 control	1
BAC1784-118-4L	Cable Assembly—3/16—7 x 19 control	1
BAC1784-268-4L	Cable Assembly—3/16—7 x 19 control	2
BAC1806-82-0	Cable Assembly—3/16—7 x 19 control	2
BAC1818	Cable Assembly—1/8—7 x 19 extra flexible	1
1-18310	Guard—Control mast cable	2
41-1457	Bushing—5/16 OD bearing	2
15-9254-1	Eye—Turnbuckle—rudder control	2

AVIALOGS.COM

CONTROLS INSTALLATION—FLIGHT

Controls Installation—Rudder

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
AN320-4	Nut—Aircraft—shear	2
AN24-17	Bolt—Clevis—14-28	2
365-1032	Nut—Self-locking	4
AN380-2-2	Cotter—Pin	20
AN960-D516	Washer—Plain	12
AN960-D416	Washer—Plain	4
AN960-D10	Washer—Plain	4
AN310-5	Nut—Aircraft—castle	10
AN310-4	Nut—Aircraft—castle	6
AN5-12	Bolt—Aircraft—5/16-24	2
AN5-7	Bolt—Aircraft—5/16-24	8
AN4-42	Bolt—Aircraft—1/4-28	2

Controls Installation—Rudder

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
AN210-4A	Pulley—Control	2
AN3-10A	Bolt—Aircraft—No. 10-32	4
AN165-46S	Eye—Turnbuckle for, pin	2
AN165-46L	Eye—Turnbuckle, for pin	2
AN155-21S	Barrel—Turnbuckle	2
AN155-46S	Barrel—Turnbuckle	2
AN155-46L	Barrel—Turnbuckle	6
AN4-11	Bolt—Aircraft—1/4-28	2
AN320-5	Nut—Shear	2
AN25-14	Bolt—Clevis	2
AN960-516	Washer—Plain	2
AN4-16	Bolt—Aircraft—1/4-28	2

CONTROLS INSTALLATION—RUDDER

Rudder Pedals—Installation

(Parts List No. 454)

65-3508-502	Rudder Pedals Installation	1
65-3508-500	Pedal Assembly—Rudder LH	1
65-3508-503	Pedal Assembly—Rudder RH	1
59-1724	Stirrup Assembly—Rudder pedal	2
59-1724-1	Stirrup Assembly—Rudder pedal	2
43-5340	Arm—Pedal stirrup outer LH	2
43-5340-1	Arm—Pedal stirrup outer RH	2
51-439	Tube—Rudder pedal	4
21-2136	Bushing—Press	4
21-2136-2	Bushing—Press	4
43-5341	Arm—Pedal stirrup—inner LH	2
43-5341-1	Arm—Pedal stirrup—inner RH	2
51-451	Lever—Rudder pedal LH	2
51-451-1	Lever—Rudder pedal RH	2
51-620	Block—Spacer	4
43-7806	Rod Assembly—Pedal adjusting	4
51-427	Pin—Pedal adjusting lock	4
51-421	Rod—Pedal adjusting control	4
21-3754-1	Collar—Pedal adjusting rod	4
51-424	Bushing—Adjusting pin guide	4
3-5369	Lever—Pedal adjusting foot	4
21-3753	Sleeve—Pedal adjusting rod	4
41-8702	Spring—Compression	4
6-8145	Quadrant Assembly—Rudder pedal adjusting LH	2
6-8145-1	Quadrant Assembly—Rudder pedal adjusting RH	2
6-8145-2	Arm—Rudder pedal adjusting (casting 6-8144)	2
6-8145-3	Arm—Rudder pedal adjusting (casting 6-8144-1)	2
21-2098	Quadrant—Rudder pedal adjusting	4
46-7284	Pedal Assembly—Rudder and brake LH	2
46-7284-1	Pedal Assembly—Rudder and brake RH	2
46-7284-400	Pedal—Rudder and brake (casting 46-7283)	2
46-7284-401	Pedal —Rudder and brake (casting 46-7283)	2
41-6558	Arm—Brake pedal LH	2
41-6558-1	Arm—Brake pedal RH	2
51-426	Spool—Adjusting pin guide	4
51-425	Shaft—Rudder pedal	4
51-422	Eye Bolt—3/16 pin—10-32	4
21-2362-72-56	Washer—.050 aluminum alloy	8
21-2364-72-56	Washer—.064 aluminum alloy	4
21-2226-2	Shaft—Rudder pedals	2
51-423-1-0	Spacer—Rudder pedals	4
41-9606	Support—Rudder pedal shaft	2
41-1216	Spring—Stirrup control	4
BAC326-34S	Bushing—3/8 OD bearing	4
BAC324-10S	Bushing—5/8 OD bearing	4

Rudder Pedals—Installation

BAC326-5S	Bushing—3/8 OD bearing	2R
21-5179-2	Link—Rudder cable	8
21-5179	Link—Rudder cable	8
3-9774-7	Lever Assembly—Brake control—weld LH	2
3-9774-8	Lever Assembly—Brake control—weld RH	2
3-14661	Lever—Brake control	4

(Parts List No. 455)

21-2169	Rod Assembly—Control brake	4
41-4691-1	Bolt—Wheel brake	4
21-5179-3	Link—Rudder cable	2R
3-13486	Link Assembly—Brake stop	2R
1-16061	Stop—Brake control LH	2R
1-16061-1	Stop—Brake control RH	2R
1-18421	Link Assembly—Brake stop	2L
AN4-15A	Bolt—Aircraft—1/4-28	2
AN935-10	Washer—Lock	8
365-1032	Nut—Self-locking	4
AN393-9	Pin—Flathead—3/16	4
286-1	Fittings—Lubrication	8
AN393-13	Pin—Flathead—3/16	12
AN320-4	Nut—Aircraft—shear	4
AN960D10	Washer—Plain	8
AN380-2-2	Cotter—Pin	10L
AN380-2-2	Cotter—Pin	12R
501-10-6	Screw—Fillister head—drilled or plain head	8
AN24-18	Bolt—Clevis—1/4-28	2R
AN24-19	Bolt—Clevis—1/4-28	2L
AN960-10	Washer—Plain	4
AN3-10	Bolt—Aircraft—No. 10-32	2R
AN310-3	Nut—Aircraft—castle	2R
AN4-15A	Bolt—(No cotter hole)	4
51-454-7-0	Tube—3/4—.065	1
41-9606	Support—Rudder pedal shaft	4
21-4841-40	Jumper Assembly—No. 8-8 terminal bonding	8
BAC820-8	Terminal—Electrical lock	16
21-4842-40	Jumper Assembly—No. 8-10 terminal bonding	4
BAC820-8	Terminal—Electrical lock	4
BAC820-10	Terminal—Electrical lock	4
21-4585-42-12	Clamp—Tab square tube	2
21-2348-6	Spacer—1/4 bolt	4
21-2363-48-17	Washer—.063 steel	4
365-428	Nut—Self-locking	4
365-832	Nut—Self-locking	16
365-1032	Nut—Self-locking	2
AN4-36A	Bolt—Aircraft—1/4-28	4
AN515-8-7	Screw—Round head (coarse thread)	16
AN520-10-7	Screw—Round head (fine thread)	2
AN960A416L	Washer—Plain	4

AVIALOGS.COM

CONTROLS INSTALLATION—FLIGHT

Controls Installation—Elevator

(Parts List No. 456)

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-9253	Control Installation—Elevator	1
85-3540	Column Installation—Aileron elevator control (PL 457-458)	1
3-11897	Bracket Assembly—Elevator pulley LH	1
3-11897-1	Bracket Assembly—Elevator pulley RH	1
BAC1614-40	Spacer—⅛ rivet	2
AN4-43	Bolt—Aircraft—¼-28	2
41-5053-5	Washer—¼ bevel	4
41-9782	Bracket Assembly—Control pulley	2
AN4-42	Bolt—Aircraft—¼-28	2
1-18310	Guard—Control mast cable	4
AN3-10H	Bolt—(No cotter hole)	8
41-1457-35	Bushing—⅜ OD bearing	2
BAC1603-24	Spacer—No. 10 bolt	4
15-9253-1	Clamp Assembly—Elevator control	2
15-9253-4	Clamp—Segment elevator control	4
BAC1801-35-5L	Cable Assembly—3/16—7 x 19 control	2
BAC1827-26L	Terminal—Swaged class "D"	2
BAC1825-6	Terminal—Swaged class "C"	2
AN510-10-16	Screw—Flathead—fine thread	2
365-1032	Nut—Self-locking	2
15-9253-2	Turnbuckle Eye—Elevator control	2
BAC1772-90-4	Cable Assembly—3/16—7 x 19 control	2
BAC1826-6	Terminal—Swaged Class "C"	4
BAC1778-291-2	Cable Assembly—3/16—7 x 19 control	1
BAC-1778-309-3	Cable Assembly—3/16—7 x 19 control	1
BAC1827-26L	Terminal—Swaged class "D"	2
BAC1827-26R	Terminal—Swaged class "D"	2
BAC1784-255-5R	Cable Assembly—3/16—7 x 19 control	1
BAC1784-350-4L	Cable Assembly—3/16—7 x 19 control	2
BAC1826-6	Terminal—Swaged class "C"	3

Controls Installation—Elevator

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1827-26L	Terminal—Swaged class "D"	3
BAC1784-279-6R	Cable Assembly—3/16—7 x 19 control	1
BAC1826-6	Terminal—Swaged class "C"	1
BAC1827-26L	Terminal—Swaged class "D"	1
BAC1801-29-2L	Cable Assembly—3/16—7 x 19 control	1
BAC1801-43-2R	Cable Assembly—3/16—7 x 19 control	2
BAC1801-45-7R	Cable Assembly—3/16—7 x 19 control	2
BAC1801-281-2L	Cable Assembly—3/16—7 x 19 control	2
BAC1826-6	Terminal—Swaged class "B"	7
BAC1827-26L	Terminal—Swaged class "D"	7
AN5-10	Bolt—Aircraft—5/16-24	4

(Parts List No. 456A)

BAC1818-81-1	Cable Assembly—⅛—7 x 18 extra flexible	1
BAC1827-4L	Terminal—Swaged class "D"	2
AN210-4A	Pulley—Control	4
AN4-12	Bolt—Aircraft—¼-28	4
AN155-21S	Barrel—Turnbuckle	2
AN5-10	Bolt—Aircraft—5/16-24	2
AN4-11	Bolt—Aircraft—¼-28	2
AN5-7A	Bolt—(No cotter hole)	4
AN3-13A	Bolt—(No cotter hole)	2
365-524	Nut—Self-locking	4
AN960-D516	Washer—Plain	10
AN960-D416	Washer—Plain	8
AN960-D10	Washer—Plain	8
AN310-5	Nut—Castle	5
AN310-4	Nut—Castle	10
365-1032	Nut—Self-locking	10
AN380-2-2	Cotter—Pin	12
AN155-46L	Barrel Turnbuckle	8

CONTROLS INSTALLATION—ELEVATOR

Column Installation—Aileron and Elevator Control

(Parts List No. 457)

85-3540	Column Installation—Aileron elevator control	1
85-3540-700	Column Assembly—Aileron elevator control	1
85-3540-701	Tube Assembly—Aileron elevator control LH	1
85-3540-702	Tube Assembly—Aileron elevator control RH	1
63-6685-2	Housing—Control column	2
56-3954-3	Tee Assembly—Control column	1L
56-3954-4	Tee Assembly—Control column	1R
51-500-26-48	Tube—3¾—.065	2
85-3540-601	Tube Assembly—Aileron elevator control column	2
14-2068	Quadrant—Elevator mast	2
85-3540-705	Tube—2—.065	2
1-16755-1	Pin—Taper special	4
41-9808	Washer—Control column	4
85-3540-706	Tube—Aileron elevator control column	1
9-1725-5	Wheel Assembly—Aileron control (co-pilot)	1
9-1725-8	Wheel Assembly—Aileron control (pilot)	1
9-1725-2	Rim—Walnut plywood—aileron control	2
9-1725-3	Plug—Aileron control	28
9-1725-4	Ferrule—Aileron control	4
9-1725-6	Spider—Aileron control	2
9-3587	Button Installation—Pilot—throat microphone	1
9-3587-1	Button Installation—Co-pilot—throat microphone	1
9-3587-9	Button Push—Throat microphone	2
1-19840	Spring—Ground	2
9-3587-3	Shield—Throat microphone button	2
6-8142	End Assembly—Control column	2
3-11875-2	End Assembly—Control column	2
3-11875-3	End—Control column	2
6-8142-1	Bracket—Control column	2

Column Installation—Aileron and Elevator Control

6-8142-2	Bracket—Control column	2
BAC1603-64	Spacer—No. 10 bolt	4
BAC203-5S	Bolt—10-32 drilled head	8
21-3147-2	Washer—.019 steel (corrosive resistant)	4
3-11870	Sleeve—Column support bearing	4
3-11875	End Assembly—Control column	2
3-11875-1	End—Control column	2
BAC203-4S	Bolt—10-32 drilled head	24
3-13435	Guard Installation—Control column	2
41-2834-1	Sprocket—Control column	2
1-23238-2	Shim—.032 brass washer	2
41-9817	Guard—Aileron chain	2
51-499-24-0	Tube—2—.065	1
41-9808	Washer—Control column	4
85-3540-604	Nut—Aileron elevator control column	2
1-17389	Pulley—Roller bearing	4
3-10293	Shaft—Control column	2
51-561-0-20	Tube—1¼—.109	2
41-9338	Shim—Control column support	4

(Parts List No. 458)

51-97	Stop—Control cables 5/16	4
41-9811	Bearing Assembly—Control column	4
41-9811-1	Housing—Control column	4
41-9811-2	Bearing—Fafnir No. A546 control column	4
85-3540-703	Chain Assembly—Aileron elevator control column	2
85-3540-704	Chain—(REX No. 40) aileron elevator control column	4
85-3540-503	Link—Connection—aileron elevator control column	6
21-9360	Bearing Assembly—Control column LH	1

AVIALOGS.COM

CONTROLS INSTALLATION—ELEVATOR

Column Installation—Aileron and Elevator Control

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-9360-1	Bearing Assembly—Control column RH	1
21-9360-2	Bearing—Fafnir No. A546 control column	2
21-9360-3	Housing—Control column	1L
21-9360-4	Housing—Control column	1R
BAC1772-108-1	Cable Assembly—3/16—7 x 19 control	2
BAC1826-6	Swaged Terminal—Class "B"	4

Column Installation—Aileron and Elevator Control

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1784-103-7L	Cable Assembly—3/16—7 x 19 control	2
BAC1826-6	Swaged Terminal—Class "B"	2
BAC1827-26L	Swaged Terminal—Class "D"	2
BAC802-2-70	Jumper Assembly—Terminal bonding	2
BAC538-4	Clamp—Loop type cushioned	3
1-18413-1	Clip—Spring	2

CONTROLS INSTALLATION—FLIGHT

Controls Installation—Tail Wheel and Surface Lock

(Parts List No. 459)

15-7033	Control Installation—Wheel and surface locks	1
7-1537	Lock Installation—Elevator	1
7-1537-1	Plunger Assembly—Elevator lock	1
21-9441-150	Plunger—Control surface lock	1
1-18539	Spring—Compression	1
21-9444	Plunger—Control surface lock	1
7-1528	Arm Assembly—Control surface lock	1
7-1528-1	Arm—Control surface lock plunger (forging 7-1528-2)	1
BAC286-138S	Bushing—3/8 pressure	1
21-9443-8	Link—Control surface lock	1
BAC326-11ST	Spacer—Bushing 3/8 OD bearing	1
BAC326-30ST	Spacer—Bushing 3/8 OD bearing	1
BAC1606-9	Spacer—3/8 bolt	2
21-6928-75	Bolt—1/4-28 filled head	1
21-2363-26-16	Washer—.063 steel	1
41-3560	Spring—Compression	1
BAC326-141ST	Bushing—3/8 OD bearing	1
3-11906	Lever Assembly—Lock	1
3-11905	Arm—Rudder to elevator lock	1
3-11906-1	Lever Assembly—Lock	1
3-11908	Arm—Tail wheel lock	1
51-157	Plunger Assembly—Tail wheel lock	2
21-2361-25-13	Washer—.050 steel	2
51-157-1	Button—Tail wheel lock plunger	2
51-157-2	Rod—Tail wheel lock plunger	2
51-157-3	Spring—Tail wheel lock plunger (Cragin compression No. 6)	2
51-156	Lever—Surface lock	2
41-7081-1	Lever and Catch—Surface lock	2
51-775-0-28	Spacer—1/8 rivet	2
BAC1616-6	Spacer—3/16 rivet	2
BAC1616-13	Spacer—3/16 rivet	2
9-3586	Lock Installation—Rudder	1
9-3586-1	Lock Assembly—Rudder	1
1-18257	Crank Assembly—Rudder lock control	1
1-18257-1	Crank—Rudder tab control shaft	1
BAC330-104S	Bushing—5/8 OD bearing	1
BAC344-4-205	Bushing—1/4 staked	1
BAC350-8-267	Bushing—5/8 staked	1
1-18491	Link Assembly—Rudder lock	1
1-18491-1	Link—Rudder lock	2
BAC1614-16	Spacer—1/8 rivet	2
21-9441-100	Plunger—Control surface lock	1
21-9444	Plunger—Control surface lock	1
41-5699	Spring—Compression	1
BAC1604-16	Spacer—1/4 bolt	1
21-6928-50	Bolt—1/4-28 filled head	1
21-2363-26-16	Washer—.063 steel	1
1-18512	Stop—Eccentric control crank	1
41-3560	Spring—Compression	1

(Parts List No. 460)

1-18512	Stop—Eccentric control crank	1
41-3560	Spring—Compression	1
1-15573-80-61	Washer—Retaining	1

Controls Installation—Tail Wheel and Surface Lock

BAC328-108B	Bushing—1/2 OD bearing	1
1-18327-36-1	Rod Assembly—1/2 inch control	1
1-18327-1A	Tube Assembly—1/2 inch control	1
1-19044	End Rod—Threaded female	1
1-18487	End Rod—Self-aligning	2
1-19052-6-6	Rod Assembly—Control 3/8	1
1-19052-6-6A	Tube Assembly—Control 3/8	1
1-19813-2	Rod End—Female	2
1-18487	Rod End—Self-aligning	2
41-2488	Washer—Bearing retaining	1
BAC1824-308-440	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	1
BAC1827-3L	Swaged Terminal—Class "D"	1
BAC1824-310-3624	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	1
BAC1827-23L	Swaged Terminal—Class "D"	1
BAC1824-310-3625	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	1
BAC1827-23L	Swaged Terminal—Class "D"	1
BAC1824-310-4040	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	1
BAC1827-23L	Swaged Terminal—Class "D"	1
BAC1824-311-2605	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	1
BAC1827-23R	Swaged Terminal—Class "D"	1
BAC1824-316-2993	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	1
BAC1827-23R	Swaged Terminal—Class "D"	1
BAC1824-316-2781	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	1
BAC1827-23R	Swaged Terminal—Class "D"	1
51-5972	Spring—Tension	1
41-5206	Link—Door	1
BAC324-33S	Bushing—9/32 OD bearing	1

Controls Installation—Aileron, Rudder and Elevator Trim Tabs

(Parts List No. 461)

15-7034	Control Installation—Aileron rudder and elevator trim tabs	1
56-4965-504	Control Installation—Aileron tab	1
56-4965-506	Control Assembly—Aileron tab	1
56-4965-502	Housing Assembly—Upper aileron tab control	1
3-12480	Plate Assembly—Aileron tab control	1
3-12480-1	Plate—Aileron tab control	1
51-158	Name Plate—Aileron tab control	1
21-5943	Shaft Assembly—Aileron tab control	1
21-5943-1	Gear—Spiral aileron tab control shaft	1
21-5943-2	Sleeve—Aileron tab control shaft	1
21-5932	Shaft—Aileron tab control shaft	1
21-9531-1	Housing Assembly—Bearing	1
21-9531-4	Housing—Bearing	1
21-9904	Shaft—Aileron tab control	1
21-9533	Gear—Tab control	1
21-9885	Knob—Tab control	1
41-9514	Pointer—Tab control	1

AVIALOGS.COM

CONTROLS INSTALLATION—FLIGHT

Controls Installation—Aileron, Rudder and Elevator Trim Tabs

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-9774-1	Bearing—Control	2
BAC1001-6	Key—⅛ square	1
BAC1608-34	Spacer—⅛ bolt	1
56-4965-505	Housing Assembly—Lower aileron tab control	1
41-9974	Housing Assembly—Bearing	1
41-9974-1	Flange—Bearing housing	1
41-9974-2	Bearing—Housing	1
51-118-2	Drum Assembly—Tab control	1
3-11889	Drum—Control	1
BAC1807-261-7R	Cable Assembly—3/32—7 x 7 control	1
BAC1807-291-7R	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23R	Swaged Terminal—Class "D"	2
BAC1828-34	Terminal—Dead end cable	2
51-126	Shaft—Aileron tab control	1
BAC1001-27	Key—⅛ square	2
21-2364-40-26	Washer—.064 aluminum alloy	2
21-2366-68-26	Washer—.091 aluminum alloy	1
56-4965-500	Tube—Aileron tab control	1
1-19002-3	Fair-lead Assembly—2 holes	3
1-19002-4	Fair-lead—2 holes	6
1-19002-5	Fair-lead Assembly—2 holes	1
1-19002-6	Fair-lead—2 holes	2
56-3922-1	Control Installation—Rudder tab	1
21-5174	Plate—Rudder tab name	1
51-410	Spacer Assembly—Rudder tab control	1
51-410-1	Spacer—Rudder tab control	1
51-410-2	Spacer—Rudder tab control	2
51-410-3	Spacer—Rudder tab control	1
21-5172	Indicator—Tab control	1
6-8429	Wheel Assembly—Rudder tab control	1
6-8429-1	Rim Assembly—Rudder tab control wheel	1
	(Parts List No. 462)	
6-8429-2	Rim—Rudder tab control wheel	1
6-8429-3	Wheel—Rudder tab control	1

Controls Installation—Aileron, Rudder and Elevator Trim Tabs

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
51-127	Driver—Rudder indicator	1
51-118-3	Drum Assembly—Tab control	1
3-11889	Drum—Control	1
BAC1807-589-5L	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	1
BAC1828-34	Terminal—Dead end cable	1
BAC1807-505-41	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	1
BAC1827-34	Swaged Terminal—Class "D"	1
BAC1604-16	Spacer—¼ bolt	1
BAC1604-158	Spacer—¼ bolt	1
BAC1001-18	Key—⅛ square	1
41-6657	Bracket Assembly—Rudder tab cable	2
BAC1613-24	Spacer—5/32 rivet	6
BAC1774-73	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	1
BAC1827-23R	Swaged Terminal—Class "D"	1
BAC1774-82	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "D"	1
BAC1827-23R	Swaged Terminal—Class "D"	1
BAC1780-237-4L	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	1
BAC1827-23L	Swaged Terminal—Class "D"	1
BAC1780-270-2L	Cable Assembly—3/32—7 x 7 control	1
BAC1826-3	Swaged Terminal—Class "B"	1
BAC1827-23L	Swaged Terminal—Class "D"	1
21-7379	Stop—Tab cable	6
41-5437-1	Link—Aileron control cable	4
BAC1774-228-4	Cable Assembly—3/32—7 x 7 control	1
BAC1827-23L	Swaged Terminal—Class "B"	1
BAC1827-23R	Swaged Terminal—Class "D"	1
15-7034-1	Filler—Aileron rudder and elevator trim control	1

FINAL ASSEMBLY

Controls Installation—Wing Flap

(Parts List No. 463)

47-1331	Control Installation—Wing flap	1
46-7378	Unit Assembly—Manual flap control	1
46-7378-3	Coupling Assembly—Manual flap control	2
41-4220-1	Coupling—Shaft	2
BAC1851-16	Joint—Universal (Apex 2700 B-16)	2
46-6603	Housing—Flap control	1
41-4483	Cap Assembly—Flap control	2
41-4483-1	Cap—Flap control	2
41-1436-1	Shaft—Flap control	1
41-1434	Gear—Flap control	1
41-1435	Gear—Flap control	1
BAC1002-8	Key—5/16 square	1
41-2801	Plate—Flap control	2
1-19034	Spacer—Flap control	1
46-7378-2	Sleeve—Manual flap control unit	2
41-1439	Shim—Laminated	2
41-4602-1	Washer—Flap control	2
41-4601	Nut—Flap control	2
41-7297	Terminal Assembly—Crank extrusion	1
41-7297-1	Terminal—Crank extrusion	1
41-7297-2	Pin—Crank extrusion	1
41-5918	Boot Installation—Universal grease	2
41-5918-1	Boot—Universal grease	2
41-5918-2	Cord—Universal grease boot	4
41-5035-35-10	Tube Assembly—Flap torque	2
41-5035-35-10A	Tube—Flap torque	2

Controls Installation—Wing Flap

41-4220	Coupling—Shaft	2
47-1331-3	Tube Assembly—Wing flap control	2
47-1331-4	Tube—Flap torque	2
41-5035-17-2	Tube Assembly—Flap torque	2
41-5035-2A	Tube—Flap torque	2
41-4220	Coupling—Shaft	2
47-1331-7	Ring—Wing flap control	2
47-1331-6	Washer—Wing flap control	2
AN3-5A	Bolt—Aircraft No. 10-32	16
AN310-3	Nut—Aircraft—castle	4
365-832	Nut—Self-locking	8
AN380-2-2	Cotter—Pin	4
386-1-10	Pin—Taper-threaded	4
AN515-8-10	Screw—Round-head (coarse thread)	8
AN960-8	Washer—Plain	8
975-3	Washer—Taper pin	4
365-1032	Nut—Self-locking	12

Electrical Equipment Installation

(Parts List No. 464)

15-7332	Equipment Installation—Electrical	1
15-7983-5	Plant Installation—Auxiliary power	1
15-7983-1	Connector Assembly—Auxiliary power	1
3-15131	Plug Assembly—Electrical connector	1
ANR16	Fitting—Connector (Amer. Phenolic Co., Chicago, Ill.)	1

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
AN3106-28-5S	Plug—Electrical connector	1
15-7983-2	Frame Assembly—Mounting (Government furnished) N.D.	1
8-1532-5	Support Assembly—Auxiliary power plant	1
3-14963	Bracket Assembly—Auxiliary power plant	1
3-14963-1	Bracket Assembly—Auxiliary power plant	1
3-19041	Strap Assembly—Power cable	1
3-14962-1	Bracket—Auxiliary power plant	2
Special 94-32277	Regulator—Voltage (Government furnished)	1
Special 32313	Plant—Auxiliary power (Government furnished)	1
15-7622	Motor Installation—Tail gear retracting	1
1-17361	Motor—Tail wheel	1
BAC1002-20	Key—5/32 square	1
21-7395-48-17	Washer—1/8 fiber	2
3-6672	Bearing Assembly—Tail gear motor bracket	2
3-6672-1	Housing—Tail gear motor bracket	2
21-6955	Bearing—Tail gear retracting	2
41-504	Connector Assembly—Electrical	2
41-504-1	Connector—Electrical	1
15-6345	Motor Installation—Landing gear retracting LH	1
15-6345-1	Motor Installation—Landing gear retracting RH	1
3-12723	Motor—Landing gear retracting RH	1
3-12723-1	Motor—Landing gear retracting LH	1
63-6388	Shield Assembly—Retracting motor	2
63-6388-5	Cover—Retracting motor shield	2
63-6388-4	Box Assembly—Retracting motor shield	2
63-6388-3	Box Assembly—Retracting motor shield	2
63-6388-2	Ring—Retracting motor shield box	2
63-6388-600	Side—Retracting motor shield box	2
63-6388-601	Bottom—Retracting motor shield box	2
BAC1247-8S	Angle—Nut plate	8
BAC1461	Screw—No. 8/32 non-losable	8
41-504	Connector Assembly—Electrical	2
41-504-1	Connector—Electrical	2
41-9505	Insulator—Motor terminals	2
41-7074-1	Bushing—Insulating	4
21-7395-48-17	Washer—1/8 fiber	6
BAC1002-20	Key—5/32 square	2
7-1335-1	Motor Installation—Flap	1
786-1	Motor—Flap (Eclipse Aviation Corp., Bendix, N. J.)	1
53-6388	Shield Assembly—Retracting motor	1
53-6388-8	Cover—Retracting motor shield	1
53-6388-500	Box Assembly—Retracting motor shield	1
53-6388-401	Ring—Retracting motor shield	1
53-6388-402	Ring—Felt retracting motor shield	1
53-6388-501	Box Assembly—Weld retracting motor shield	1
	(Parts List No. 464A)	
21-2364-18-7	Washer—.064 aluminum alloy	8
BAC1247-8D	Angle—Nut plate	4
41-504	Connector Assembly—Electrical	1
41-504-1	Connector—Electrical	1
21-7277-10	Clamp—Exhaust support	1
41-7074-1	Bushing—Insulating	2
41-9505	Insulator—Motor terminal	1
BAC1002-20	Key—5/32 square	1
9-2938-1	Motor Installation—Bomb door	1
63-6388	Shield Assembly—Retracting motor	1
63-6388-5	Cover—Retracting motor shield	1
63-6388-4	Box Assembly—Retracting motor shield	1
63-6388-3	Box Assembly—Retracting motor shield	1
	(Parts List No. 465)	
63-6388-2	Ring—Retracting motor shield box	1
63-6388-600	Side—Retracting motor shield box	1
63-6388-601	Bottom—Retracting motor shield box	1
BAC1247-8D	Angle—Nut plate	4
BAC1461	Screw—No. 8-32 non-losable	4

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1073-1	Motor—Bomb door (Eclipse Aviation Corp., Bendix, N. J.)	1
41-504	Connector Assembly—Electrical	1
41-504-1	Connector—Electrical	1
41-7074-1	Bushing—Insulating	2
21-7395-48-17	Washer—1/8 fiber	3
BAC1002-21	Key—5/32 square	1
6-9214	Indicator Installation—Flap position	1
6-9214-5	Indicator Assembly—Flap position	1
3-13009	Bracket Assembly—Clamp	1
BAC562-28	Clamp Assembly—1 wide round tube	1
BAC1550-15	Sleeve—Weld—5/16-.058	1
41-9268-5-16	Link—Indicator	1
41-9801	Arm—Indicator	1
4550-2	Transmitter — Position (Bendix Aviation Corp., Philadelphia, Pa., BAC Spec. 3-13441)	1
BAC1603-18	Spacer—No. 10 bolt	1
46-9346	Signal Installation—Radio compartment	1
6-9346-2	Lamp Clear Bulb—Radio compartment signal (Government furnished)	1
BAC1601-48	Spacer—No. 6 machine screw	3
1-18758	Plate—Name	1
39B2823-4	Lamp Assembly—Signal—single contact	1
BAC1614-48	Spacer—1/8 rivet	2
3-14686	Bell—Alarm	1
BAC1601-45	Spacer—1/6 machine rivet	1
6-10677	Signal Installation—Landing gear—warning	1
AN-S-8	Signal—Warning (type E-2) (Government furnished) replaces 1-20369	1
14-2072	Shield Installation—Wing junction LH	1
14-2072-1	Shield Installation—Wing junction RH	1
14-2072-3	Shield Assembly—Wing junction LH	1
14-2072-4	Shield Assembly—Wing junction RH	1
9-3600	Panel Assembly—Wing connector LH	1
1-18273	Bus—Connector	1
9-3600-1	Panel—Wing connector LH	1
41-2661-2	Bus—Connector	1
9-3601	Panel Assembly—Wing connector RH	1
9-3601-1	Panel—Wing connector RH	1
3-13696	Insulator—Wing connector	2
Spec. 50131-C	Capacitor—Wing junction shield type B-1	1R
21-2589-23	Clip—Tab loop type	1R
9-4641-4	Decalcomania—Wing junction shield No. 82	1R
6-9325	Shield Assembly—Junction LH	1
	(Parts List No. 465A)	
6-9325-1	Shield Assembly—Junction RH	1
6-9325-2	Box—Junction shield	2
6-9325-3	Cover—Junction shield	2
BAC1247-8S	Angle—Nut plate	16
BAC1461	Screw—No. 8-32 non-losable	16
	(Parts List No. 466)	
BAC1603-8	Spacer—No. 10 bolt	2
15-7047	Shield Installation—Pilot's control panel (AC41-2393 to 2492)	1
15-7047-1	Shield Assembly—Pilot's control panel	1
15-7047-9	Switch Assembly—Pilot's control panel (type C1B) (Navy Drawing 310590)	1
15-7047-7	Lamp—Pilot's control panel (Government furnished) 3 C.P., 28U.S.C.,	2
15-7047-6	Switch Assembly—Pilot's control panel (Cutler—Hammer No. 7131-K2)	1
15-7047-4	Rheostat—Pilot's control panel (Ohmite No. 0317) (50W-350HM)	1
15-7047-3	Voltmeter—Pilot's control panel (type B-1) (Government furnished)	1
15-7047-5	Ammeter—Pilot's control panel (type D-2) (Government furnished)	3
15-7047-2	Shield Assembly—Pilot's control panel	1

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-82	Plate—Tabulated name	1
41-8834-1	Plate—Name	1
14-2040	Shield Assembly—Pilot's control panel	1
14-2040-1	Box—Pilot's control panel shield	1
BAC1247-8	Angle—Nut plate	11
14-2040-3	Cover—Pilot's control panel	1
BAC1461	Screw—No. 8-32 non-losable	9
51-1089-1	Plate—Switch identification	2
AN3017	Switch Assembly—(Type B-7A)	2
AN3015	Switch Assembly—(Type B-5A)	11
3-11263-2	Plate—Name	1
AN3016	Switch Assembly—(Type B-6B)	2
3-11263	Plate—Name	1
3-11263-1	Plate—Name	1
3-6964-1	Plate—Switch identification	1
41-7642-2	Plate—Name	1
21-3703-1	Plate—Switch identification	1
38A1762	Lamp Assembly—Cockpit (type A-6)	2
21-8891-8	Panel Assembly—Connector	1
21-8891-8A	Panel—Micarta connector	1
21-8627-8	Insulator—Junction box	1
21-7401	Bus—Connector panel	2
41-9775	Hook Assembly—Microphone	1
41-1373	Clip—Microphone	1
3-12972	Plate—Name	1
3-12972-1	Plate—Name	1
3-12972-2	Plate—Name	1
1-20239	Plate—Name	1
15-7964	Shield Installation—Pilot's control panel (AC41-9011 to 9245)	1
15-7964-1	Shield Assembly—Pilot's control panel	1
15-7964-3	Voltmeter—Pilot's control panel (type B-1) (Government furnished)	1
15-7964-4	Rheostat—Pilot's control panel—Ohmite (Government furnished)	1
15-7964-5	Ammeter—Pilot's control panel (type F-1) (Government furnished)	4
	(Parts List No. 467)	
15-7964-7	Lamp—Pilot's control panel—S.C. base (3C. P., 28U) (Government furnished)	2
15-7964-6	Switch Assembly—Pilot's control panel	1
15-7964-8	Switch Assembly—Pilot's control panel (type C1B) (Navy Drawing 310590)	1
15-7964-2	Shield Assembly—Pilot's control panel	1
14-2358	Shield Assembly—Pilot's control panel	1
14-2358-4	Cover—Control panel shield	1
14-2358-5	Box—Control panel shield	1
BAC1247-8	Angle—Nut plate	10
BAC1461	Screw—No. 8-32 non-losable	8
41-82	Plate—Tab name	1
1-21048	Plate—Name	1
21-8891-8	Panel Assembly—Connector	1
21-8891-8A	Panel—Micarta connector	1
41-9775	Hook Assembly—Microphone	1
41-1373	Clip—Microphone	1
21-8627-0	Insulator—Junction box	1
21-7401	Bus—Connector panel	2
1-21047	Plate—Name	1
51-1089-1	Plate—Name	2
21-3703-1	Plate—Name	1
3-12972-1	Plate—Switch identification	1
3-12972-2	Plate—Switch identification	1
3-11263	Plate—Switch identification	1
3-11263-1	Plate—Switch identification	1
3-11263-2	Plate—Switch identification	1
41-7642-2	Plate—Switch identification	1
1-20239	Plate—Switch identification	1
3-6964-1	Plate—Switch identification	1
38A1762	Lamp Assembly—Cockpit (type A-6)	2
AN3015	Switch Assembly—Toggle (type B-5A)	11
AN3016	Switch Assembly—Toggle (type B-6B)	2

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
AN3017	Switch Assembly—Toggle (type B-7A)	3
6-9509	Shield Assembly—Generator wing break LH	1
6-9509-1	Shield Assembly—Generator wing break RH	1
6-9509-2	Shield Assembly—Generator wing break LH	1
6-10790-2	Decalcomania—Generator wing break shield No. 138	1
6-9509-3	Shield Assembly—Generator wing break RH	1
6-10790-7	Decalcomania—Generator wing break shield No. 130	1
41-9981-2	Cover—Junction shield	2
BAC1461	Screw—8-32 non-losable	4
6-9507	Shield Installation—Generator connector nacelle No. 3	1
1-19691	Shield Assembly—Junction	1
1-19691-1	Shield Assembly—Junction	1
41-9981-2	Cover—Junction shield	1
BAC1461	Screw—8-32 non-losable	2
6-9508	Shield Installation—Outboard generator connector nacelle No. 1	1
1-19691	Shield Assembly—Junction	1
1-19691-1	Shield Assembly—Junction	1
	(Parts List No. 468)	
41-9981-2	Cover—Junction shield	1
BAC1461	Screw—8-32 non-losable	2
6-9507-1	Shield Installation—Generator connector nacelle No. 2	1
1-20352	Shield Assembly—Junction	1
1-20352-1	Shield Assembly—Junction	1
41-9981-2	Cover—Junction shield	1
BAC1461	Screw—8-32 non-losable	2
6-9508-1	Shield Installation—Outboard center connector nacelle No. 4	1
1-20352	Shield Assembly—Junction	1
1-20352-1	Shield Assembly—Junction	1
41-9981-2	Cover—Junction shield	1
BAC1461	Screw—8-32 non-losable	2
9-4918	Shield Installation—Generator relay	1
9-4918-1	Shield Assembly—Generator relay	1
9-4918-2	Shunt—Generator relay shield (Government furnished)	1
9-4918-3	Bus Assembly—Generator relay shield (Government furnished)	1
21-7401-6	Bus—Connector	1
9-4918-4	Capacitor—Generator relay shield	1
9-4918-8	Relay—Revise current (Government furnished)	1
3-16456	Shield Assembly—Generator relay	1
3-16456-1	Shield—Generator relay	1
3-16456-2	Insulator—Generator relay	1
3-16459	Panel Assembly—Generator relay	1
BAC540-12	Clamp—Loop type cushioned	1
9-4919	Shield Installation—Generator relay	1
9-4919-1	Shield Assembly—Generator relay	1
9-4919-3	Bus Assembly—Generator relay shield	1
21-7401-6	Bus—Connector	1
Spec. 50131C	Capacitor—Generator relay shield	1
94-32278	Relay—Reverse current (Government furnished)	1
3-16456	Shield Assembly—Generator relay	1
3-16456-1	Shield—Generator relay	1
3-16456-2	Insulator—Generator relay	1
BAC540-12	Clamp—Loop type cushioned	1
94-32204	Shunt—Generator relay shield (Government furnished)	1
7-1958	Shield Installation—Generator relay—LH	1
7-1958-2	Shield Assembly—Generator relay	1
7-1958-4	Shunt—Shield (Government furnished)	1
7-1958-5	Bus Assembly—Generator relay	1
21-7401-6	Bus—Connector	1
7-1958-6	Capacitor—Shield	1
7-1958-12	Relay—Shield (Government furnished)	1

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-19950	Channel Installation—Wiring support	1
3-16456	Shield Assembly—Generator relay	1
3-16456-1	Shield—Generator relay	1
3-16456-2	Insulator—Generator relay	1
3-16459	Panel Assembly—Generator relay	1
BAC540-12	Clamp—Loop type cushioned	1
BAC1603-173	Spacer—No. 10 bolt	1
	(Parts List No. 468A)	
BAC1603-47	Spacer—No. 10 bolt	1
BAC1603-52	Spacer—No. 10 bolt	2
9-5038	Ventilating Installation—Generator regulator	1
9-5038-1	Tube—Generator regulator vent	1
9-5038-2	Tube—Generator regulator vent	1
BAC535-22	Clamp—Hose	6
BAC540-16	Clamp—Cushioned	3
BAC1603-32	Spacer—No. 10 bolt	1
BAC537-116	Clamp—Cushioned lug type	1
3-15137	Lamp Installation—Rear gunner dome light	1
3-15137-1	Lamp—Rear gunner dome light	1
37B4983	Lamp Assembly—Cabin type A-5	1
41-7288-2	Spacer—Special	3
59-3659	Shield Installation—Station 6 fuse	1
59-3659-500	Shield Assembly—Station 6 fuse	1
59-3659-501	Shield Assembly—Station 6 fuse	1
7-1535	Shield Assembly—Electrical	1
7-1535-6	Box Assembly—Electrical shield	1
BAC1235	Fastener—Strap	4
BAC775-5	Slip—Electric Fuse	14
57-1534	Panel Assembly—Fuse station No. 6	1
57-1534-500	Panel—Fuse station No. 6	1
1-18567	Bus—Connector	1
21-7401-1	Bus—Connector panel	6
41-277-8	Bus—Connector	1
3-9215-216	Plate—Name	1
3-9215-218	Plate—Name	1
3-9215-219	Plate—Name	1
3-9215-247	Plate—Name	1
3-9215-248	Plate—Name	1
3-9215-305	Plate—Name	1
3-9215-312	Plate—Name	1
3-9215-290	Plate—Name	1
BAC775-5	Clip—Electric fuse	14
1-20240-2	Bus—Electrical	1
41-3996-28-13	Washer—1/8 micarta	13
41-3996-28-17	Washer—1/16 micarta	1
59-3659-3	Fuse—Electric safety	4
59-3659-4	Fuse—Electric safety	2
59-3659-5	Fuse—Electric safety	1
59-3659-6	Fuse—Cartridge	1
3-14216-3	Chart—Fuse identification	1
59-3659-3	Fuse—Electric safety	2
59-3659-4	Fuse—Electric safety	2
59-3659-5	Fuse—Electric safety	1
59-3659-6	Fuse—Cartridge	1
59-3659-7	Insulator—Fuse shield station No. 6	1
	(Parts List No. 469)	
3-14941	Capacitor Installation—Inboard booster pump LH	1
3-14941-1	Capacitor Installation—Inboard booster pump RH	1
3-14941-3	Capacitor Assembly—Inboard booster pump	2
3-14941-2	Plate—Mounting inboard booster pump capacitor	2
1-20336	Clamp Assembly—Booster pump	2
1-20336-1	Base—Booster pump clamp	2
1-20336-2	Clamp—Loop type booster pump	2
Type CB304	Capacitor Assembly—Booster pump BAC special 1-20379 (P. R. Mallory Co., Inc., Ind., Ind.)	2
21-4842-50	Jumper Assembly—No. 8-10 terminal bonding	2

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC820-8	Terminal—Electrical lock	2
BAC820-10	Terminal—Electrical lock	2
BAC1602-24	Spacer—No. 8 machine screw	2
3-14939	Capacitor Installation—Outboard booster pump LH	1
3-14939-1	Capacitor Installation—Outboard booster pump RH	1
3-14939-2	Capacitor Assembly—Outboard booster pump	2
1-20336	Clamp Assembly—Booster pump	2
1-20336-1	Base—Booster pump clamp	2
1-20336-2	Clamp—Loop type booster pump	2
1-20379	Capacitor Assembly—Booster pump (type CB 304) (P. R. Mallory Co., Inc.)	2
21-4842-50	Jumper Assembly—No. 8-10 terminal bonding	2
BAC820-8	Terminal—Electrical lock	2
BAC820-10	Terminal—Electrical lock	2
BAC1602-24	Spacer—No. 8 machine screw	2
1-20528	Terminal Assembly—Electrical	2
21-9753	Tag Installation—Electrical wire identification	1844
21-9753-1	Tape—Scotch cellulose wire identification tag	1844
21-9753-2	Numbers—Electrical wire identification tag	1844
3-11896	Lamp Installation—Cockpit	1
3-11896-1	Lamp Installation—Cockpit	1
3-11896-7	Shield Assembly—Junction cockpit lamp	2
41-158	Retainer—Interphone jack (on -1 only)	1
41-159	Stop—Interphone jack (on -1 only)	1
3-16132-9	Decalcomania—Cockpit	2
AN3017	Switch Assembly—(Type B-7A)	2
38A1762	Lamp Assembly—Cockpit (type A-6)	2
3-11896-6	Lamp—Cockpit (3 CP. 28V., S. C.) (Government furnished)	2
3-11896-3	Cover Assembly—Cockpit lamp	2
41-9981-2	Cover—Junction shield	2
36A4486-832	Screw—Round-head necked	4
46-8338	Lamp Installation—Cockpit	1
46-8338-2	Shield Assembly—Cockpit	1
41-9981-1	Shield Assembly—Junction	1
41-9981-6	Shield—Junction	1
BAC1247-8D	Angle—Nut plate	2
51-1089	Plate—Switch identification	1
AN3017	Switch Assembly—(Type B-7A)	1
	(Parts List No. 470)	
38A1762	Lamp Assembly—(Type A-6)	1
BAC1603-36	Spacer—No. 10 bolt	2
46-8338-9	Lamp—Cockpit (Government furnished)	1
6-8338-7	Cover Assembly—Cockpit lamp	1
36A4486-832	Screw—Round-head necked	2
48-1215-400	Shield Installation—Outboard nacelle LH	1
48-1215-401	Shield Installation—Outboard nacelle RH	1
48-1215-402	Shield Assembly—Outboard nacelle LH	1
48-1215-403	Shield Assembly—Outboard nacelle RH	1
48-1215-404	Shield Assembly—Outboard nacelle LH	1
48-1215-405	Shield Assembly—Outboard nacelle RH	2
6-7538	Shield Assembly—Tail wheel solenoid	2
6-7538-6	Box Assembly—Tail wheel solenoid	2
BAC1235	Fastener—Snap	8
41-8614	Plate—Name	2
41-8614-1	Plate—Name	2
3-13567-1	Card—Fuse—LH	1
3-13567-4	Card—Fuse—RH	1
BAC775-5	Clip—Fuse	4
48-1215-4	Fuse—Spare 40 ampere	2
48-1215-5	Fuse—Outboard nacelle shield (Western Electric No. 66A, 125 ampere Linek type)	4
48-1215-6	Relay—Outboard nacelle shield—24 volt (type B-2)	2
48-1215-7	Switch—Outboard nacelle shield solenoid (eclipse type D-1) (Government furnished)	4

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-16029	Bus—Connector LH	1L
41-6754-1	Bus—Solenoid	2
41-8609	Bus—Connector LH	1L
46-8983-400	Panel Assembly—Junction fuse LH	1
46-8983-401	Panel Assembly—Junction fuse RH	1
46-8983-402	Panel—Junction fuse LH	1
46-8983-403	Panel—Junction fuse RH	1
3-9215-214	Plate—Name	2
3-9215-215	Plate—Name	2
21-7401-1	Bus—Connector panel	2
41-277	Bus—Connector	2
41-8611-5	Bus—Connector	4
BAC775-5	Clip—Fuse	4
51-396-1	Insulator—Fuse panel	2
1-16029-1	Bus—Connector	1R
41-8609-1	Bus—Connector	1R
BAC1604-8	Spacer—¼ bolt	2
48-1215-5	Fuse—Outboard nacelle shield (Western Electric No. 66A, 125 ampere Linek type)	4
48-1215-4	Fuse—Outboard nacelle shield (spare) 40 ampere	2
BAC1603-59	Spacer—No. 10 bolt	4
6-10099	Shield Installation—Lamp and receptacle	1
6-10099-3	Cover Assembly—Lamp and receptacle shield	1
6-10099-4	Cover—Lamp and receptacle shield	1
6-10099-5	Lamp—Lamp and receptacle shield (Govern-furnished)	1
51-1089	Plate—Switch identification	1
	(Parts List No. 471)	
38A1762	Lamp Assembly—Cockpit (type A-6)	1
AN3017	Switch—(Type B-5A)	1
6-10099-1	Box Assembly—Lamp and receptacle shield	1
6-10099-2	Box—Lamp and receptacle shield	1
51-1089-2	Plate—Name	1
AN3015	Switch	1
41-7505	Bracket—Lamp	1
BAC1461	Screw—No. 8-32 non-losable	2
6-8954	Bell Installation—Navigator's compartment	1
6-8954-4	Plate Assembly—Navigator's compartment	1
3-14686	Bell—Alarm	1
BAC802-2-60	Jumper Assembly—Terminal bonding	1
BAC802-2-60	Jumper Assembly—Terminal bonding	1
BAC1447-6-12	Screw—Round-head recessed sheet metal	6
6-8944	Bell Installation—Gunner's	1
3-14686	Bell—Alarm	1
BAC1601-10	Spacer—No. 6 machine screw	4
6-7899-2	Rheostat Installation—De-icer pump	1
567-1	Rheostat—De-icer (Eclipse Aviation Corp., Bendix, N. J.)	2
3-12222	Switch Installation—Bomb door control	1
3-12222-3	Switch Assembly—Bomb door control	1
41-9981-1	Shield Assembly—Junction	10
41-9981-6	Shield—Junction	1
BAC1247-8D	Angle—Nut plate	2
3-12222-1	Cover—Bomb door control switch	1
AN3018	Switch Assembly—Toggle (type B-9A)	1
36A4486-832	Screw—Round-head necked	2
3-12025	Switch Installation—Bomb door lock	1
41-9981-1	Shield Installation—Junction	1
41-9981-6	Shield—Junction	1
BAC1247-8	Angle—Nut plate	2
3-12025-1	Cover—Bomb door lock switch	1
AN3016	Switch Assembly—(Type B-6B)	1
3-8728-6	Spring Assembly—Switch return	1
3-8728-4	Spring—Switch return	1
3-8728-5	Retainer—Switch return spring	1
3-8728-7	Strap—Switch return spring	1
36A4486-832	Screw—Round-head necked	2
3-11871	Switch Installation—Bomb bay lights	1
41-7293-1	Plate—Switch identification	1
1804-M-1	Nut—Speed (Tinnerman, Cleveland, Ohio)	6
41-8825	Bus—Switch connector	1

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
AN3015	Switch—(Type B-5A)	2
AN3014	Switch—(Type B-1B)	1
3-16142-1	Decalcomania	1
	(Parts List No. 472)	
6-9450	Switch Installation—Fuel transmission pump	1
6-9450-1	Guard Assembly—Fuel transmission pump switch	1
6-9450-2	Guard—Fuel transmission pump switch	1
1-18893	Plate—Name	1
1-19951	Guard Assembly—Fuel transmission switch	1
1-19951-1	Guard—Fuel transmission switch	1
1-19951-2	Insulator—Transmission switch guard	1
AN3018	Switch Assembly—Toggle (type B-9A)	1
3-10594	Switch—Double pole toggle (type C-9A)	1
1-18896	Connector—Switch handle	1
BAC1602-10	Spacer—No. 8 machine screw	4
3-12029	Switch Installation—Propeller de-icer	1
3-12029-3	Box Assembly—Propeller de-icer switch	1
41-9981-1	Shield Assembly—Junction	1
41-9981-6	Shield—Junction	1
BAC1247-8	Angle—Nut plate	2
3-12029-2	Cover—Shield propeller de-icer switch	1
41-8563	Plate—Name	1
21-7606	Guard—Switch toggle	1
36A4486-832	Screw—Round-head necked	2
AN3015	Switch Assembly—(Type B-5A)	1
3-11999-2	Switch Installation—Upper limit landing	2
3-11996	Shield Assembly—Junction upper limit landing switch	2
3-11996-3	Shield Assembly—Junction upper limit landing switch	2
BAC1247-8	Angle—Nut plate	4
3-11996-4	Box—Upper limit switch shield	2
41-9981-2	Cover—Junction shield	2
39A3756	Switch Assembly—Toggle (type B-15)	2
36A4486-832	Screw—Round-head necked	4
1-22628	Shim—Upper limit switch	1
3-12000-2	Switch Installation—Lower limit	2
3-11990	Shield Assembly—Lower limit switch	2
3-11990-3	Shield Assembly—Lower limit switch	2
3-11990-4	Box—Lower limit switch shield	2
BAC1247-8S	Angle—Nut plate	4
41-9981-2	Cover—Junction shield	2
36A4486-832	Screw—Round-head necked	4
39A3756	Switch Assembly—Toggle (type B-15)	4
3-11888	Switch Installation—Navigator's dome light	1
41-9981-1	Shield Assembly—Navigator's dome light	1
41-9981-6	Shield—Navigator's dome light	1
BAC1247-8	Angle—Nut plate	2
41-7296-1	Plate—Name	1
AN3014	Switch—(Type B-1B)	1
36A4486-832	Screw—Round-head necked	2
3-11888-1	Cover—Nacelle dome light switch	1
6-9356	Switch Installation—Tail wheel center	1
6-9356-1	Spring Assembly—Tail wheel center switch	1
	(Parts List No. 473)	
1-18644	Spring—Switch	1
1-18643	Channel—Switch	1
Type G-R	Switch—(Micro Corp., Freeport, Ill.)	1
1-18642	Plate—Cover	1
3-13611	Switch Installation—Tail gear unit	1
6-9209	Switch Assembly—Tail gear	1
1-18092	Striker Assembly—Limit switch	1
1-18092-1	Striker—Limit switch	1
1-18093	Roller Assembly—Limit switch	1
1-18204	Roller—Limit switch	1
1-18093-1	Bar—Limit switch roller	1
1-18091	Channel—Limit switch	1
1-18094-1	Stop—Limit switch	1

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18100	Spring—Limit switch	1
39A3756	Switch Assembly—Toggle (type B-15)	1
BAC1603-56	Spacer—No. 10 bolt	2
3-12921	Switch Installation—Bomb release	1
3-12023	Shield Assembly—Bomb release	1
3-12023-1	Shield Assembly—Bomb release	1
41-9981-1	Shield Assembly—Junction	1
41-9981-6	Shield—Junction	1
BAC1247-8	Angle—Nut plate	2
41-5368	Spring—Latch	1
41-5368-1	Spring—Latch	1
1-19823	Switch—Guard	1
BAC1602-6	Spacer—No. 8 machine screw	2
21-2366-32-11	Washer—.091 aluminum alloy	2
41-8712	Bus—Toggle switch	1
AN3019	Switch Assembly—(Type B-11)	1
41-9981-2	Cover—Junction shield	1
9-5204-7	Decalcomania—Doors open-closed	1
36A4486-832	Screw—Round-head necked	2
3-12023-2	Switch — Extension bomb release (Cutler-Hammer, No. 24-1164)	1
3-13374	Switch Installation—Bomb door safety	1
3-13374-1	Switch Assembly—Bomb door safety	1
3-8728-6	Spring Assembly—Switch return	1
3-8728-4	Spring—Switch return	1
3-8728-5	Retainer—Switch return spring	1
3-8728-7	Strap—Switch return spring	1
1-19688-1	Angle—Switch support	1
AN3016	Switch Assembly—Toggle (type B-6B)	1
3-13596	Switch Installation—Dome light	1
3-16132-7	Decalcomania	1
AN3014	Switch Assembly—Toggle (type B-1B)	1
3-13660	Switch Installation—Dome light	1
41-7296-1	Plate—Name	1
AN3014	Switch Assembly—Toggle (type B-1B)	1

(Parts List No. 474)

1804-M-1-025	Nut—Speed (Tinnerman)	2
6-9467	Switch Installation—Tail gear	1
6-9209	Switch Assembly—Tail gear	2
1-18092	Striker Assembly—Limit switch	2
1-18092-1	Striker—Limit switch	2
1-18093	Roller Assembly—Limit switch	2
1-18204	Roller—Limit switch	2
1-18093-1	Bar—Limit switch roller	2
1-18091	Channel—Limit switch	2
1-18094-1	Stop—Limit switch	2
1-18100	Spring—Limit switch	2
39A3756	Switch Assembly—Toggle (type B-15)	2
BAC1603-56	Spacer—No. 10 bolt	4
46-8339	Shield Installation—Inboard starter connector nacelle 2	2
46-8339-9	Shield Assembly—Inboard starter connector nacelle 2	2
41-5124	Insulator—Junction box	2
41-5123	Panel Assembly—Connector	2
41-5123-1	Panel—Connector	2
3-12106	Shield Assembly—Junction	2
3-12106-1	Shield Assembly—Junction	2
BAC1247-8D	Angle—Nut plate	8
3-12106-3	Cover—Junction shield	2
36A4486-832	Screw—Round-head necked	8
46-8335	Shield Installation—Outboard ignition connector nacelle No. 1 and No. 4	2
46-8335-11	Shield Assembly—Outboard ignition connector nacelle No. 1 and No. 4	2
3-12107	Shield Assembly—Junction	2
3-12107-1	Shield Assembly—Junction	2
1-16272	Angle Assembly—Nut plate	2
1-16272-1	Angle Assembly—Nut plate	2
BAC1247-8	Angle—Nut plate	4
3-12107-3	Cover—Junction shield	2

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
36A4486-832	Screw—Round-head necked	8
41-5123	Panel Assembly—Connector	2
41-5123-1	Panel—Connector	2
41-5124	Insulator—Junction box	2
46-8336	Shield Installation—Outboard ignition connector nacelle No. 1 and No. 4	2
46-8336-400	Shield Assembly—Outboard ignition connector nacelle No. 1 and No. 4	2
46-8336-7	Coil—Booster outboard ignition connector nacelle No. 1 and No. 4 shield	2
46-8336-401	Condenser—Outboard ignition connector nacelle No. 1 and No. 4 shield	2
3-12095	Shield Assembly—Junction	2
3-12095-1	Shield Assembly—Junction	2
BAC1247-8S	Angle—Nut plate	8
3-12095-3	Cover—Junction shield	2
36A4486-832	Screw—Round-head necked	8
21-4844-90	Jumper Assembly—No. 10-10 terminal bond	2
BAC820-10	Terminal—Electrical lock	4
21-2589-24	Clip—Tab loop type	2

(Parts List No. 475)

46-8360	Shield Installation—Inboard ignition connection	2
46-8360-400	Shield Assembly—Inboard ignition connection	2
Special 94-32182A	Coil—Booster type C-1 (Government furnished)	2
Special 50131-C	Capacitor—Type B-1	2
3-12106	Shield Assembly—Junction	2
3-12106-1	Shield Assembly—Junction	2
BAC1247-8D	Angle—Nut plate	8
3-12106-3	Cover—Junction shield	2
36A4486-832	Screw—Round-head necked	8
21-4844-90	Jumper Assembly—No. 10-10 term bond	1
BAC820-10	Terminal—Electrical lock	2
21-2589-24	Clip—Tab loop type	2
6-7530-6	Shield Installation—Bomb door solenoid	1
6-7530-3	Shield Assembly—Bomb door solenoid	1
6-7531	Shield Assembly—Solenoid	1
6-7531-6	Box Assembly—Solenoid shield	1
BAC1235	Fastener—Snap	4
41-5760-3	Plate—Name	1
41-5760-4	Plate—Name	1
6-7530-8	Switch—Bomb door solenoid shield	2
BAC1604-8	Spacer—¼ bolt	1
1-13892-70-16	Clamp—Tabulated square	2
21-6862-32-12	Washer—.125 aluminum alloy	2
41-6754	Bus—Solenoid shield	1
41-6754-3	Bus—Solenoid shield	1
1-18058	Bus Assembly—Connection	3
41-162-1	Bus—Connector	3
3-11882	Shield Installation—Dome light switch	1
41-9981	Shield Assembly—Junction	1
41-9981-4	Shield—Junction	1
BAC1247-8D	Angle—Nut plate	2
AN3015	Switch—Single throw (type B-5A)	1
41-7292	Plate—Name	1
3-11882-1	Cover—Dome light switch	1
36A4486-832	Screw—Round-head necked	2
56-8986	Panel Installation—Spare lamps radio compartment	1
56-8986-1	Box Assembly—Spare lamps radio compartment	1
21-7308	Clip—Instrument board lamps	3
21-7307-1	Clip—Instrument board lamps	1
3-13789-1	Plate—Name	1
3-13789-4	Plate—Name	1
3-11953-2	Box Assembly—Spare lamps	1
3-11953-5	Box—Spare lamps weld	1
3-11953-8	Cover—Spare lamps box	1
3-11953-9	Spacer—Micarta spare lamps box	1
3-11953-10	Knob—Black spare lamps box (Northern Radio Co.)	1

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-11953-11	Spacer—Micarta spare lamps box	1
3-11953-14	Hinge—Spare lamps box	1
21-7328	Catch—Spring	1
	(Parts List No. 476)	
21-7329	Catch—Spring	1
3-16142-6	Decalcomania—Spare lamps	1
56-8986-5	Lamp—Spare panel (21C.P., 28V., S.C.) (Government furnished)	2
56-8986-6	Lamp—Spare panel (21C.P., 28V., S.C.) (Government furnished)	1
56-8986-400	Lamp—Spare panel (3C.P., 28V., D.C.) (Government furnished)	1
BAC1603-36	Spacer—No. 10 bolt	3
3-13448	Panel Installation—Camera receptacle	1
39B5786	Panel Assembly—Receptacle (type B-8)	1
15-7351	Panel Installation—Bomber's control	1
7-1525	Panel Assembly—Bomber's control	1
7-1525-1	Rheostat—Bomber's control panel 10 ohms, 50W (type M-1)	2
7-1525-2	Lamp—Extension bomber's control panel (type B-7) (Government furnished)	1
7-1525-3	Switch—Bomber's control panel (type C-1B) (Navy Drawing 310590)	1
6-9307	Plate Assembly—Bomber's control	1
6-9307-3	Plate—Bomber's control	1
41-3862	Grommet—Dzus (type 375)	9
41-3866-30	Button—Dzus (type A)	9
41-6542-2	Plate—Name	1
41-6542-3	Plate—Name extension light	1
41-8749	Plate—Name bomb release	1
38A1762	Lamp Assembly—Cockpit (type A-6)	1
39B2828-4	Lamp Assembly—Signal single contact	1
AN3015	Switch Assembly—(Type B-5A)	2
AN3016	Switch Assembly—(Type B-6B)	1
AN3017	Switch Assembly—(Type B-7A)	1
41-6541	Plate—Switch identification	1
1-18466	Plate—Switch identification	1
1-18639	Plate—Switch identification	1
51-1089	Plate—Switch identification	1
1-21494	Lamp Assembly—Signal amber (A.C. Drawing 40A7419)	1
36A2212-1	Nut—Conduit	1
6-9216	Panel Assembly—Bomb interval switch	1
6-9216-4	Plate—Bomb interval switch panel	1
41D1831	Control—Bomb release (type B-2) (Government furnished)	1
46-7180	Panel Assembly—Bomb load indicator	1
46-7180-3	Holder—Card bomb load indicator panel	1
46-7180-400	Seal—Bomb load indicator panel	1
46-7180-401	Plate Assembly—Bomb load indicator	1
46-7180-402	Plate—Bomb load indicator	1
41-3862	Grommet—Dzus (type 375)	4
41-3866-30	Button—Dzus (type A)	4
41-6479	Plate—Name	1
6-8970	Panel Assembly—Bomb indicator	1
1-18505	Contact Assembly—Spring and terminal	20
3-12982	Plate—Bomb signal lamp	1
BAC1601-34	Spacer—No. 6 machine screw	5
6-8970-1	Panel—Bomb indicator	1
	(Parts List No. 477)	
15-7351-4	Panel Assembly—Terminal bomber's	1
21-8891-12	Panel Assembly—Connector	1
21-8891-12A	Panel—Micarta connection	1
21-7401	Bus—Connector panel	2
21-8627-12	Insulator—Junction box	1
15-7351-1	Lamp—Bomber control panel (2C.P., 28V., S.C.) (Government furnished)	1
15-7351-2	Lamp—Bomber control panel (2C.P., 28V., S.C.) (Government furnished)	1

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7351-3	Lamp—Bomber control panel (2C.P., 28V., D.C.) (Government furnished)	1
39A3906-2	Lamp—Warning signal amber 3 volts (Government furnished)	28
3-13551	Panel Installation—Station 19 wing LH	1
3-13551-1	Panel Installation—Station 19 wing RH	1
41-5123	Panel Assembly—Connector	2
41-5123-1	Panel—Connector	2
41-5124	Insulator—Junction box	2
BAC1468-10-54	Screw—Flathead H. T. 82° countersunk recessed	4
3-13626	Panel Installation—Rear wing junction	1
3-13370	Panel Assembly—Connector	1
3-13370-1	Panel—Connector	1
41-8835	Insulator—Connector panel	1
BAC1603-8	Spacer—No. 10 bolt	1
1-17565	Panel Installation—Station 9	1
1-17244	Panel Assembly—Connector	1
1-17244-1	Panel—Connector	1
1-18382	Panel—Insulator	1
6-10111	Panel Installation—Bomb rack	1
6-10111-2	Shield Assembly—Bomb rack panel	1
3-7139	Shield Assembly—Junction	1
3-7139-3	Cover—Junction shield	1
3-7139-1	Box Assembly—Junction shield	1
BAC1247-8	Angle—Nut plate	4
3-7139-2	Box—Junction shield	1
BAC1461	Screw—No. 8-32 non-losable	4
3-7135-3	Panel Assembly—Connector	1
3-7135-1	Panel—Connector	1
41-580	Insulator—Connector panel	1
6-10653	Panel Installation—Bomb rack	1
6-10653-1	Shield Assembly—Bomb rack panel	1
1-20347	Plate—Name	1
41-580	Insulator—Connector panel	1
1-20340	Switch Assembly—Bomb rack panel	1
1-20340-1	Knob—Bomb rack selective switch	1
3-7135-3	Panel Assembly—Connector	1
3-7135-1	Panel—Micarta connector	1
3-11474	Shield Assembly—Electrical	1
3-11474-1	Cover Assembly—Electrical shield	1
	(Parts List No. 478)	
3-11474-2	Cover—Electrical shield	1
41-3862	Grommet—Dzus (type 375)	6
41-9638-30	Fastener—Dzus wing type	6
3-11474-4	Box Assembly—Electrical shield	1
3-11474-5	Box—Electrical shield—weld	1
41-3864	Spring—Electrical shield	6
46-8987	Panel Installation—Spare lamps	1
46-8987-1	Box Assembly—Spare lamps	1
21-7307-1	Clip—Instrument board lamp	1
21-7308	Clip—Instrument board lamp	5
3-16142-3	Decalcomania—Spare lamps	1
3-16142-5	Decalcomania—Spare lamps	1
3-11953	Box Assembly—Spare lamps	1
3-11953-3	Box—Spare lamps weld	1
3-11953-6	Cover—Spare lamps box	1
3-11953-10	Knob—Black spare lamps box (Northern Radio Co.)	1
3-11953-12	Hinge—Spare lamps box	1
21-7328	Catch—Spring	1
21-7329	Catch—Spring	1
3-16142-6	Decalcomania—Spare lamps	1
46-8987-6	Lamp—Spare—bomber's compartment panel—28V., 3C.P., S.C. (Government furnished)	2
46-8987-7	Lamp—Spare—bomber's compartment panel—28V., 21 C.P., S.C. (Government furnished)	1
46-8987-9	Lamp—Spare—bomber's compartment panel—28V., S.C., (Government furnished)	1
46-8987-400	Lamp—Spare—bomber's compartment panel—28V., 21C.P., D.C. (Government furnished)	1

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
46-8987-401	Lamp—Spare—bomber's compartment panel—28V., 3C.P., D.C. (Government furnished)	1
39A3906-2	Lamp—Spare amber—warning signal—3V (Government furnished)	2
7-1508	Panel Installation—Spare lamps—pilot's compartment	1
7-1508-1	Box Assembly—Spare lamps—panel	1
3-11953-1	Box Assembly—Spare lamps	1
3-11953-4	Box—Spare lamps—weld	1
3-11953-7	Cover—Spare lamp box	1
3-11953-10	Knob—Black—spare lamp box (Northern Radio 8-32 thread)	1
3-11953-13	Hinge—Spare lamps box	1
21-7328	Catch—Spring	1
21-7329	Catch—Spring	1
3-16142-6	Decalcomania—Spare lamps	1
3-13789-1	Plate—Name	1
3-13789-2	Plate—Name	1
21-7308	Clip—Instrument board lamp	4
7-1508-2	Spacer—Spare lamp panel (Government furnished)	3
7-1508-3	Lamp—Spare lamp panel—3C.P., 28V, S. C. (Government furnished)	2
7-1508-4	Lamp—Spare lamp panel—21C.P., 28V, S.C. (Government furnished)	2
48-1194	Panel Installation—Spare lamps	1

(Parts List No. 479)

48-1194-401	Door Assembly—Spare lamp panel	1
21-7308-1	Clip—Instrument board lamp	2
21-7329	Catch—Spring	1
3-16111-12	Decalcomania—Spare lamps	1
48-1194-3	Knob—Panel door spare lamp (Northern Radio Co.)	1
48-1194-403	Panel—Spare lamp (type II)	1
48-1194-406	Door—Panel spare lamp	1
48-1194-407	Hinge—Continuous spare lamp	1
48-1194-400	Door Assembly—Spare lamp panel	1
48-1194-3	Knob—Spare lamp panel door (Northern Radio Co.)	1
48-1194-8	Door—Spare lamp panel door (Northern Radio Co.)	1
48-1194-407	Hinge—Continuous—spare lamp panel	1
3-16111-11	Decalcomania—Fuel cell treated with sloshing compound	1
3-16111-13	Decalcomania—Fuel cell treated with sloshing compound	1
21-7329	Catch—Spring	1
21-7308	Clip—Instrument board lamp	3
21-7307-1	Clip—Instrument board lamp	2
48-1194-4	Lamp—Spare panel 24 volt, 3C.P., S.C. (Government furnished)	2
48-1194-5	Lamp—Spare panel 24 volt, 3C.P., S.C. (Government furnished)	2
48-1194-13	Lamp—Spare panel fluorescent	1
48-1194-404	Felt—Spare panel	1
48-1194-405	Lamp—Spare panel 24 volt, 3C.P., D.C. (Government furnished)	1
39A3906-2	Lamp—Spare panel (Government furnished)	2
15-7538-6	Shield Installation—Station 4 fuse	1
15-7538-1	Fuse—15 ampere station 4 shield	36
15-7538-2	Fuse—20 ampere station 4 shield	8
15-7538-3	Fuse—30 ampere station 4 shield	4
15-7538-4	Fuse—60 ampere station 4 shield	4
15-7538-5	Fuse—70 ampere—cartridge station 4 shield	2
15-7538-7	Fuse—5 ampere—cartridge station 4 shield	18
15-7538-8	Fuse—30 ampere—cartridge station 4 shield	2
14-2079	Shield Assembly—Station 4 fuse	1
14-2079-4	Cover Assembly—Station 4 fuse shield	1

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-9638-30	Button—Dzus oval head	2
1-18254-1	Plate—Name	1
41-3862	Grommet—Dzus fastener	2
BAC775-5	Clip—Electrical fuse	68
14-2079-5	Cover—Fuse shield—station 4	1
14-2079-1	Box Assembly—Fuse shield station 4	1
14-2079-8	Box Assembly—Fuse shield station 4 spot-weld	1
1-18830	Spring—Shield cover	2
41-3864	Spring—Fastener—Dzus	2
BAC1603-40	Spacer—No. 10 bolt	1
55-7635	Panel Assembly—Station 4 fuse	1

Dash number parts, shown on 55-7635 drawing are represented by dash numbers of 15-7635 and 55-7635.

(Parts List No. 480)

55-7635-405	Wire Assembly—Station 4 fuse panel	1
BAC821-12	Terminal—Electric	2
BAC822-12	Sleeve—Insulation	2
55-7635-5	Relay—Station 4 fuse panel	2
55-7635-403	Panel—Station 4 fuse panel	1
55-7635-2	Bus—Station 4 fuse panel	2
55-7635-404	Bus—Station 4 fuse panel	1
41-277-11	Bus—Connector	2
3-9215-125	Plate—Name—radio compass	1
3-9215-220	Plate—Name—propeller pitch	1
3-9215-227	Plate—Name—bomb rack	1
3-9215-228	Plate—Name—bomb door	1
3-9215-233	Plate—Name—ext. lights	1
3-9215-243	Plate—Name—flight control	1
3-9215-251	Plate—Name—bomb sight	1
3-9215-249	Plate—Name—thermometer	1
3-9215-252	Plate—Name—flap and door control	1
3-9215-253	Plate—Name—landing gear control	1
3-9215-254	Plate—Name—int. lights forward	1
3-9215-255	Plate—Name—inverter No. 1	1
3-9215-256	Plate—Name—inverter No. 2	1
3-9215-257	Plate—Name—de-icer oil dilutor	1
3-9215-258	Plate—Name—command radio	1
3-9215-259	Plate—Name—mesh. sol. No. 1	1
3-9215-260	Plate—Name—mesh. sol. No. 2	1
3-9215-261	Plate—Name—mesh. sol. No. 3	1
3-9215-262	Plate—Name—mesh. sol. No. 4	1
3-9215-263	Plate—Name—warning	1
3-9215-274	Plate—Name—fuel boost No. 1	1
3-9215-275	Plate—Name—fuel boost No. 2	1
3-9215-276	Plate—Name—fuel boost No. 3	1
3-9215-277	Plate—Name—fuel boost No. 4	1
3-9215-278	Plate—Name—pitot heat LH	1
3-9215-279	Plate—Name—pitot heat RH	1
3-9215-280	Plate—Name—interphone	1
3-9215-286	Plate—Name—fuel transfer	1
3-9215-300	Plate—Name—engine No. 2 instrument	1
3-9215-301	Plate—Name—engine No. 3 instrument	1
3-9215-302	Plate—Name—engine No. 4 instrument	1
3-9215-303	Plate—Name—fuel and positive indicator	1
3-9215-306	Plate—Name—fuel shut-off No. 1	1
3-9215-307	Plate—Name—fuel shut-off No. 2	1
3-9215-308	Plate—Name—fuel shut-off No. 3	1
3-9215-309	Plate—Name—fuel shut-off No. 4	1
3-9215-299	Plate—Name—engine No. 1 instrument	1
21-7401-1	Bus—Connector	35
BAC775-5	Clip—Fuse	70
3-14216-1	Chart—Fuse	1
3-13716	Insulator—Panel	1
AN3014	Switch—Step lamp (type B-1B)	1
6-8435	Lamp Installation—Pilot's extension	1
6-8435-4	Lamp Assembly—Pilot's extension	1
6-8435-3	Lamp Assembly—Cockpit type B-7 (Government furnished)	1

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 481)	
3-12227-1	Support—Pilot's extension lamp	1
3-12227-2	Support—Pilot's extension lamp	1
BAC1603-8	Spacer—No. 10 bolt	4
6-8435-2	Lamp—Pilot's extension 3C.P., 28V., D.C. (Government furnished)	1
3-12158	Lamp Installation—Flight control units	1
3-12158-1	Sleeve Assembly—Stake	1
36A5457	Sleeve—Stake	1
3-12158-6	Lamp—Flight control unit—21C.P., 28V., S.C. (Government furnished)	1
21-4585-96-20	Clamp—Tab square tube	2
36A2212-3	Nut—Ferrule	1
37A4527	Socket Assembly—Single contact	1
36A5458	Spacer—Lamp socket shielded sleeve	1
6-8425	Lamp Installation—Extension radio compartment	1
6-8425-4	Lamp Assembly—Radio compartment extension	1
6-8425-3	Lamp Assembly—Radio compartment extension (Government furnished)	1
6-8426	Bracket Assembly—Extension lamp radio compartment	1
6-8425-2	Lamp—Extension radio compartment (Government furnished)	1
BAC1603-8	Spacer—No. 10 bolt	6
43-10993	Lamp Installation—Radio compass	1
41-9981-1	Shield Assembly—Junction	1
41-9981-6	Shield—Junction	1
BAC1247-8	Angle—Nut plate	2
38A1762	Lamp Assembly—Cockpit (type A-6)	1
AN3017	Switch Assembly—Toggle (type B-7A)	1
41-7517	Support—Lamp	1
BAC1603-40	Spacer—No. 10 bolt	4
51-1089-1	Plate—Switch identification	1
43-10993-401	Lamp—Radio compass (Government furnished)	1
43-10993-400	Cover—Radio compass lamp	1
36A4486-832	Screw—Round-head necked	2
56-7758	Lamp Installation—Radio compartment	1
56-7758-1	Lamp Installation—Radio compartment	1
6-7734	Lamp Assembly—Shaded	1
6-7734-1	Lamp Assembly—Shaded	1
6-7734-3	Lamp Assembly—Shaded	2
3-10569-10	Shield Assembly—Junction	2
BAC1247-8	Angle—Nut plate	4
6-7734-5	Shade Assembly—Lamp	2
41-1879	Shade—Engineer's lamp	2
41-8355	Ring—Lamp shade	2
32A3376	Sleeve—Lamp socket	2
3-10569-4	Cover—Junction shield	2
BAC1461	Screw—No. 8-32 non-losable	4
AN3015	Switch Assembly—(Type B-5A)	2
3-11351	Bracket Assembly—Radio lamp	2
3-11351-1	Screw Assembly—Weld radio lamp bracket	2
37A4527	Socket Assembly—Single contact	2
41-8428	Knob—¼ threaded	2
	(Parts List No. 482)	
BAC1603-8	Spacer—No. 10 bolt	8
BAC1604-112	Spacer—¼ bolt	2
56-7758-401	Lamp—Radio compartment 21 C.P., 28V., S.C. (Government furnished)	2
6-7759-2	Lamp Installation—Navigator's table	1
6-7759-5	Lamp Assembly—Navigator's table	1
6-7734-6	Lamp Assembly—Shaded	1
6-7734-8	Lamp Assembly—Shaded	1
6-7734-7	Shade Assembly—Shaded	1
41-1879	Shade—Engineer's lamp	1
41-8355	Ring—Lamp shade	1
32A3376	Sleeve—Lamp socket	1
3-10569-10	Shield Assembly—Junction	1
BAC1247-8	Angle—Nut plate	2
AN3015	Switch Assembly—(Type B-5A)	1

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-10569-4	Cover—Junction shield	1
BAC1461	Screw—No. 8-32 non-losable	2
3-11352	Bracket Assembly—Navigator's lamp	1
3-11352-2	Screw Assembly—Navigator's lamp bracket	1
37A4527	Socket Assembly—Single contact	1
41-8428	Knob—¼ threaded	1
BAC1604-112	Spacer—¼ bolt	1
6-7759-4	Lamp—Navigator's table (Government furnished)	1
BAC1603-8	Spacer—No. 10 bolt	4
6-10690	Lamp Installation—Pilot's compartment dome	1
6-10690-1	Switch Assembly—Pilot's compartment dome lamp	1
1-21483	Support—Dome lamp switch	1
AN3015	Switch—(Type B-5A)	1
3-16132-7	Decalcomania	1
6-10690-3	Lamp Assembly—Pilot's compartment dome	1
6-10690-2	Lamp—Pilot's compartment dome (Government furnished)	1
3-12582	Ring—Dome lamp escutcheon	1
41-7288	Spacer—Special	3
37B4983	Lamp Assembly—Cabin (type A-5)	1
BAC1603-12	Spacer—No. 10 bolt	2
3-10826	Lamp Installation—Bomb bay LH	1
3-10826-1	Lamp Installation—Bomb bay RH	1
37B4983	Lamp Assembly—Cabin (type A-5) (Government furnished)	2
41-7288	Spacer—Special	6
3-10826-6	Lamp—Bomb bay (Government furnished)	2
3-10827	Lamp Installation—Dome	1
37B4983	Lamp Assembly—Cabin (type A-5) (Government furnished)	1
41-7288	Spacer—Special	3
3-10827-4	Lamp—Dome (Government furnished)	1
6-10688	Lamp Installation—Dome	1
6-10688-2	Lamp Assembly—Dome	1
6-10688-1	Lamp—Dome (21C.P., 28V., type S8) (Government furnished)	1
6-10687	Support Assembly—Dome light	1
6-10687-1	Support—Dome light	1
1-20333-1	Channel—Dome light support	1
	(Parts List No. 483)	
41-7288	Spacer—Special	3
41-7292	Plate—Name	1
37B4983	Lamp Assembly—Cabin—(type A5)	1
AN3015	Switch—Toggle—(type B-5A)	1
BAC1603-8	Spacer—No. 10 bolt	4
3-12992	Lamp Installation—Dome station 6	1
37B4983	Lamp Assembly—Cabin—(type A-5) (Government furnished)	1
41-7288	Spacer—Special	3
3-12992-1	Lamp—Dome (type S8) (Goverment furnished)	1
3-12995	Lamp Installation—Rear gunner's dome light	1
37B4983	Lamp Assembly—Cabin (type A-5) (Government furnished)	1
AN3015	Switch—Toggle (type B-5A)	1
41-7288	Spacer—Special	3
3-12995-1	Lamp—Rear gunner's dome light (Government furnished)	1
3-10825	Lamp Installation—Step	1
37B4983	Lamp Assembly—Cabin (type A-5) (government furnished)	1
41-7288	Spacer—Special	3
3-10825-4	Lamp—Step (type S8) (Government furnished)	1
3-12999	Lamp Installation—Body position light	7
37B4962-7	Lamp Assembly—Running (type A-8) (Government furnished)	7
3-12999-2	Lamp—Body position light (Government furnished)	7
3-12999-1	Lamp Installation—Body position light	2

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
37B4962-5	Lamp Assembly—Running (type A-8) (Government furnished)	2
3-12999-2	Lamp—Body position light (Government furnished)	2
3-13597	Lamp Installation—Compass fluorescent	1
3-13597-1	Lamp Holder Assembly—Compass fluorescent	1
6-8948	Lamp Installation—Fluorescent—bomber's	1
6-8948-1	Lamp Holder Assembly—Bomber's fluorescent	1
6-9324	Lamp Installation—Fluorescent	1
6-9324-2	Lamp Holder Assembly—Fluorescent (type A-8)	1
21-4838-60	Jumper Assembly—No. 6-8 terminal bonding	1
BAC820-8	Terminal—Electrical lock	1
BAC820-6	Terminal—Electrical lock	1
3-12726	Clamp Assembly—Lamp support	1
BAC1603-16	Spacer—No. 10 bolt	2
6-9344	Lamp Installation—Radio rack	1
6-9344-1	Cover Assembly—Radio rack lamp	1
6-9344-3	Lamp—Radio rack—3C.P., 28V., S.C. (Government furnished)	1
6-9344-2	Terminal—Radio rack lamp	1
38A1762	Lamp Assembly—Cockpit (type A-6)	1
AN3017	Switch Assembly—(Type B-7A)	1
41-9981-2	Cover—Junction shield	1
51-1089	Plate—Switch indentification	1
41-9981-1	Shield Assembly—Junction	1
41-9981-6	Shield—Junction	1

(Parts List No. 484)

BAC1247-8	Angle—Nut plate	2
BAC1603-8	Spacer—No. 10 bolt	2
36A4486-832	Screw—Round-head necked	2
6-9373	Lamp Installation—Bomber's	1
6-9373-1	Lamp—Bomber's —21C.P., 28V., (Government furnished)	1
6-9373-2	Lamp Assembly—Bomber's (drawing G32147-A-6)	1
3-12980	Bracket Assembly—Bomber's lamp	1
6-9411	Lamp Installation—Station 4 fuse panel	1
6-9411-1	Shield Assembly—Station 4 fuse panel lamp	1
6-9411-2	Cover—Station 4 fuse panel lamp	1
41-9981-1	Shield Assembly—Junction	1
41-9981-6	Shield—Junction	1
BAC1247-8D	Angle—Nut plate	2
AN3017	Switch Assembly	1
38A1762	Lamp Assembly—Cockpit (type A-6)	1
3-16132-9	Decalcomania—Shield	1
BAC1461	Screw—No. 8-32 non-losable	2
6-9411-3	Lamp—Station 4 fuse panel (Government furnished)	1
9-3581	Lamp Installation—Bomb release	1
9-3581-1	Lamp—Bomb release—100C.P., 28V., S.C. (Government furnished)	2
37D4865-1	Lamp Assembly—Running (type B-3)	2
3-12996	Retainer—Lamp lens	2
41-8573	Lens—Signal lamp	2
36B3422	Gasket—Running lamp cover glass	3
36B3423	Glass—Running lamp cover glass	1
6-9324-1	Lamp Installation—Fluorescent	1
6-9324-2	Lamp Holder Assembly—Fluorescent (type A-8)	1
21-4838-60	Jumper Assembly—No. 6-8 terminal bonding	1
BAC820-8	Terminal—Electrical lock	1
BAC820-6	Terminal—Electrical lock	1
3-12726	Clamp Assembly—Lamp support	1
BAC1603-16	Spacer—No. 10 bolt	2
7-1526	Lamp Installation—Fluorescent	1
7-1526-5	Lamp—Fluorescent 3C.P., 28V., S.C. (Government furnished)	2
7-1526-1	Lampholder Assembly—Flourescent (type A-8, 4 Watt)	1

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
38A1762	Lamp Assembly—Cockpit (type A-6)	2
1-20077	Angle—Lamp support	1
1-20079	Spring—Tension	1
1-18547	Angle—Lamp mounting	1
6-10437	Lamp Installation—Identification light (upper)	1
AN3097-2	Lamp Assembly—Identification light (upper) (Government furnished)	1
6-10437-2	Lamp—Identification light	1
6-10439	Lamp Installation—Identification light (lower)	1
6-10439-1	Lamp Assembly—Identification light (Government furnished)	1
6-10439-2	Lamp—Identification light 28V., 50C.P., S.C. (Government furnished)	1
1-21086	Gasket—Recognition lamp	1
6-7923-1	Relay Installation—Time delay	1

(Parts List No. 485)

43-11520-402	Relay Assembly—Time delay	1
43-11520-1	Shield Assembly—Time delay relay	1
BAC1247-8	Angle—Nut plate	4
43-11520-405	Shield Assembly—Time delay relay	1
BAC1247-8D	Angle—Nut plate	4
43-11520-401	Cover Assembly—Time delay relay	1
43-11520-4	Cover—Time delay relay	1
3-16111-10	Decalcomania—Fuel call treated with sloshing compound	1
36A4486-832	Screw—Round-head necked	4
43-11520-403	Relay—Time delay	1
41-2531	Bus—Panel	1
3-13579	Receptacle Installation—Bomb sight dummy	1
3-13579-1	Plug—Wall type—bomb sight dummy receptacle	1
9-3440	Solenoid Installation—Flap motor	1
9-3440-1	Panel Assembly—Flap motor solenoid	1
Spec. 94-32181	Solenoid—Flap motor solenoid (Eclipse, type D-1—24 volt)	2
Spec. 50131-C	Capacitor—Flap motor solenoid (type B-1)	2
1-18058	Bus Assembly—Connector	3
41-162-1	Bus—Connector	3
3-16142-7	Decalcomania—Armor side gun	1
3-16142-8	Decalcomania—Armor side gun	1
41-6754-3	Bus—Solenoid	1
1-17244	Panel Assembly—Connector	1
1-17244-1	Panel—Connector	1
9-3608	Panel—Flap solenoid	1
1-18382	Panel Insulator	1
BAC1604-8	Spacer—¼ bolt	1
BAC540-12	Clamp—Loop type cushioned	2
6-9474	Solenoid Installation—Tail wheel	1
6-9474-2	Solenoid Assembly—Tail wheel	1
41-162-1	Bus—Connector	2
41-6754-4	Bus—Solenoid	1
Spec. 32181	Switch—Solenoid type D-1	2
BAC1604-8	Spacer—¼ bolt	1
54-1946	Solenoid Installation—Inboard nacelle LH	1
54-1946-1	Solenoid Installation—Inboard nacelle RH	1
54-1946-7	Fuse—Inboard nacelle solenoid (W.E., No. 66A, Linek)	16
54-1946-400	Shield Assembly—Inboard nacelle solenoid LH	1
54-1946-401	Shield Assembly—Inboard nacelle solenoid RH	1
54-1946-4	Solenoid—Inboard nacelle	4
54-1946-4	Solenoid—Inboard nacelle (Eclipse, type D-1) (Government furnished)	4
54-1946-5	Solenoid—Inboard nacelle (Eclipse, type C-1) (Government furnished)	4
6-9314	Panel Assembly—No. 2 nacelle fuse LH	1
6-9313	Panel Assembly—No. 3 nacelle fuse RH	1
6-9313-1	Panel—Micarta—No. 2 nacelle fuse	2

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 486)	
21-7401-1	Bus—Connector panel	2L-4R
41-8611-5	Bus—Connector	4
BAC775-5	Clip—Electric fuse	2L-4R
49-2940-400	Shield Assembly—Inboard nacelle fuse LH	1
49-2940-401	Shield Assembly—Inboard nacelle fuse RH	1
49-2940-11	Box Assembly—Inboard nacelle fuse shield LH	1
49-2940-2	Box Assembly—Inboard nacelle fuse shield RH	1
49-2940-3	Box—Inboard nacelle fuse shield	1R
49-2940-4	Box—Inboard nacelle fuse shield	1L
41-3863	Spring—Dzus fastener	2
	(Parts List No. 487)	
41-3864	Spring—Dzus fastener	18
49-2940-402	Cover Assembly—Inboard nacelle fuse shield LH	1
49-2940-403	Cover Assembly—Inboard nacelle fuse shield RH	1
49-2940-405	Cover—Inboard nacelle fuse shield	1L
49-2940-406	Cover—Inboard nacelle fuse shield	1R
41-8614	Plate—Name	2
41-8614-1	Plate—Name	2
41-8614-2	Plate—Name	2
41-8614-3	Plate—Name	2
41-9638-30	Button—Dzus wing type	20
41-3862	Grommet—Dzus type 375	20
BAC775-5	Clip—Electric fuse	2L-4R
1-18492	Bus—Solenoid	2
1-18506	Insulator—Fuse panel	2
3-13567-2	Chart—Fuse LH	1
3-13567-3	Chart—Fuse RH	1
41-162-1	Bus—Connector	1L-2R
41-162-2	Bus—Connector	4
41-6754-1	Bus—Connector	2L
41-6754-2	Bus—Connector	2R
51-330	Bus—Solenoid LH	1
51-330-1	Bus—Solenoid RH	1
51-331	Bus—Solenoid LH	1
51-331-1	Bus—Solenoid RH	1
41-6754-5	Bus—Solenoid	1R
BAC1604-8	Spacer—¼ bolt	1L-2R
54-1946-402	Shield Assembly—Inboard nacelle solenoid LH	1
54-1946-403	Shield Assembly—Inboard nacelle solenoid LH	1
BAC1461	Screw—No. 8-32 non-losable	2
41-9981-2	Cover—Junction shield	1
54-1946-404	Shield Assembly—Inboard nacelle solenoid RH	1
54-1946-405	Shield Assembly—Inboard nacelle solenoid RH	1
BAC1461	Screw—No. 8-32 non-losable	2
41-9981-2	Cover—Junction shield	1
BAC1603-18	Spacer—No. 10 bolt	2
BAC1603-28	Spacer—No. 10 bolt	1L-1R
BAC1603-45	Spacer—No. 10 bolt	4
BAC1603-49	Spacer—No. 10 bolt	2
BAC776-5-15	Fuse—Electric safety (2 are spare) (3AG., 15 ampere)	6
6-9291	Leads Installation—Thermocouple	1
6-9291-1	Lead—Thermocouple	2
6-9291-2	Lead—Thermocouple	2
6-9291-3	Lead—Thermocouple	2
6-9291-4	Lead—Thermocouple	2
6-9291-5	Lead—Thermocouple	2
6-9291-9	Lead—Thermocouple	2
6-7889	Box Installation—Ignition LH	1
6-7889-1	Box Installation—Ignition RH	1
21-8364-4	Box Assembly—Electrical junction	2
21-8364-4A	Box Assembly—Electrical junction	2

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 488)	
BAC1247-8	Angle—Nut plate	8
21-8364-4B	Box—Weld—electrical junction	2
21-8364-4C	Cover—Electric junction	2
BAC1461	Screw—No. 8-32 non-losable	8
21-8891-4	Panel Assembly—Connector	2
21-8891-4A	Panel—Micarta—connector	2
9-4641-13	Decalcomania—Heat radiator	1
9-4641-14	Decalcomania—Heat radiator	1
21-8627-4	Insulator—Junction box	2
6-9473	Box Installation—Fluorescent auxiliary	1
6-9473-1	Box—Fluorescent auxiliary	1
6-9475	Box Installation—Auxiliary and relay	1
6-9475-4	Box Assembly—Auxiliary and relay	1
6-9475-5	Box Assembly—Auxiliary and relay	1
6-9475-2	Relay—Auxiliary box (Struthers—Dunn, Inc., type CXA3299)	1
6-9475-1	Box—Auxiliary and relay	1
BAC802-3-65	Jumper Assembly—Terminal bonding	1
14-3005	Box Installation—Junction—modified A.F.C.E	1
14-3005-1	Box Assembly—Junction—modified A.F.C.E.	1
1-24220	Decalcomania—Lamp switch flight control	1
1-24580-1	Box Assembly—Junction—modified A.F.C.E.	1
BAC1603-10	Spacer—No. 10 bolt	4
48-1078	Vent Installation—Flap motor	1
48-1078-400	Vent Assembly—Weld—flap motor	1
41-5717-1	Collar—Alternator blast	1
31-1176-3	Clamp—Conduit	1
31-1177-3	Nut—Conduit clamp	1
48-1078-404	Tube—Flap motor vent	1
31-1176-2	Clamp—Conduit	2
31-1177-2	Nut—Conduit clamp	2
BAC540-16	Clamp—Loop type cushioned	1
BAC1602-12	Spacer—No. 8 machine screw	1
BAC535-10	Clamp Hose	2
BAC535-22	Clamp—Hose	2
3-13503	Wire Installation—Static ground	1
3-13503-4	Wire Assembly—Static ground	1
3-13503-1	Wire—Static ground	1
3-13503-2	Chain—Static ground wire	1
3-13503-3	Wire—Antenna—static ground	1
8-1280	Dynamotor and Inverter Installation—LH	1
8-1280-2	Inverter—Dynamotor 750 volt—ampere (Government furnished)	1
41-6975-24-9	Washer—Rubber	8
1-22928-5	Washer—.063 steel	8
	(Parts List No. 489)	
8-1280-1	Dynamotor and Inverter Installation—RH	1
8-1280-2	Inverter—Dynamotor 750 volt-ampere (Government furnished)	1
41-6975-24-9	Washer—Rubber	8
1-22928-5	Washer—.063 steel	8
14-1945	Battery Installation—LH	1
14-1945-2	Battery — (Type G-1) (drawing S40H5415) (Government furnished)	1
14-1945-25	Jar Assembly—Battery	1
14-1945-13	Gasket—Battery	1
14-1945-27	Jar—Battery—(Ball Mason one pint glass)	1
14-1945-40	Disk—Battery—felt	2
3-12926	Cap Assembly—Battery vent	1
3-12926-2	Cap Assembly—Weld—battery	1
14-1945-34	Tube Assembly—Battery	1
14-1945-8	Tube—Battery	2
14-1945-35	Tube—Battery	1
14-1945-36	Tube Assembly—Battery	1
14-1945-8	Tube—Battery	2
14-1945-37	Tube—Battery	1
14-1945-41	Tube—Battery	1
14-1945-38	Tube Assembly—Battery	1
14-1945-8	Tube—Battery	2

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
14-1945-39	Tube—Battery	1
21-2589-16	Clip—Tab loop type	1
21-4213-6-4	Rod—10-32 control	2
21-7440-3	Bolt—5/16-24 special	2
14-1945-1	Battery Installation—RH	1
14-1945-2	Battery — (Type G-1) (drawing S40H5415) (Government furnished)	2
14-1945-26	Jar Assembly—Battery	1
3-12964	Cap Assembly—Battery vent	1
3-12964-1	Cap Assembly—Battery vent	1
14-1945-13	Gasket—Battery	1
14-1945-27	Jar—Battery (Ball Mason one pint glass)	1
14-1945-40	Disk—Battery felt	2
14-1945-28	Tube Assembly—Battery	1
14-1945-8	Tube—Battery	2
14-1945-29	Tube—Battery	1
14-1945-30	Tube Assembly—Battery	1
14-1945-8	Tube—Battery	2
14-1945-31	Tube—Battery	1
14-1945-41	Tube—Battery	1
14-1945-32	Tube Assembly—Battery	1
14-1945-8	Tube—Battery	2
14-1945-33	Tube—Battery	1
21-4213-6-4	Rod—10-32 control	2
21-2589-1	Clip—Tab	2
21-7440-3	Bolt—5/16-24 special	4
41-9007	Angle Installation—Tube support	12
41-9007-4	Angle Assembly—Tube support	1
3-14080	Capacitor Installation—Fuel transfer	1
	(Parts List No. 490)	
CB304	Capacitor Booster Pump (Mallory & Co., Inc. Indianapolis, Indiana)	1
6-10101	Fuse Installation—Alternating current power	1
6-10101-1	Shield Assembly—Alternating current power	1
1-20556	Plate—Name	1
BAC775-3	Clip—Fuse	4
6-10101-2	Shield—Alternating current power	1
6-10101-3	Fuse—Extractor post—alternating current power (Littel No. 1075A)	2
6-10101-4	Fuse—10 ampere (2 active—2 spare)	4
3-14216-5	Chart—Fuse	1
41-6844-20-48	Clamp—Receptacle tube	2
41-9981-2	Cover—Junction shield	1
BAC1461	Screw—No. 8-32 non-losable	2
6-10098	Receptacle Installation—Extractor power source	1
6-10098-1	Receptacle Assembly—Extractor power source	1
1-21950	Fitting—Power receptacle	1
R-3082	Receptacle Assembly—Extractor power Miles Equipment Co. (airplane battery plug, Miles Equipment Co., St. Louis, Mo.)	1
15-7382	Board Installation—Central control (for airplanes No. AC41-2443 to 41-2669, AC41-9011 to 41-9245)	1
15-7382-2	Box Assembly—Central control board	1
15-7382-3	Box Assembly—Central control board	1
BAC1247-10S	Angle—Nut plate	9
7-1516-3	Panel Assembly—Central control	1
6-9227-1	Panel—Central control	1
9-3693	Valve—Cowl flap control	1
7-1516-2	Panel Assembly—Central control	1
41-4103-2	Link Installation—Ignition switch	1
41-4103-3	Link Assembly—Ignition switch	1
81-4101	Link—Ignition switch	1
81-4102	Clamp—Ignition switch	2
1-21356	Plate—Name	1
1-17248	Bus Assembly—Ignition switch	2
1-17248-1	Bus—Ignition switch	2
21-7606	Guard—Switch toggle	1
21-7859	Guard Assembly—Landing gear switch	1
21-7859-1	Hinge—Landing gear switch	1
21-7859-3	Spring—Landing gear switch	1

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
3-16142-7	Decalcomania—Up	1
9-5204-27	Decalcomania—Gear down	1
1-21030	Plate—Name	1
1-17238-2	Plate—Name	1
1-18254	Plate—Name	1
21-3180-5	Plate—Name	1
21-6118-1	Plate—Name	1
6-9227-2	Panel—Central control	1
41-6812	Switch—Ignition (dual)	1
41-6812-1	Switch—Ignition (dual)	1
AN3014	Switch—(Type B-1B)	1
	(Parts List No. 490A)	
AN3015	Switch—(Type B-5A)	12
AN3017	Switch—(Type B-7A)	1
AN3018	Switch—(Type B-9A)	1
AN3020	Switch Assembly—(Type B-14)	1
	(Parts List No. 491)	
40A5553	Switch	1
41-8825-1	Bus—Switch connection	1
41-8825-4	Bus—Switch connection	2
41-9642	Plate—Flap warning	1
51-1089-1	Plate—Switch identification	1
1-21356	Plate—Name	1
15-7332-115	Receptacle—Bomb sight	1
15-7332-116	Receptacle—Bomb int. release	1
15-7332-117	Receptacle—Pilot director	1
15-7332-1-1	Conduit—Rigid electrical equipment	1
15-7332-1-2	Conduit—Rigid electrical equipment	1
15-7332-1-3	Conduit—Rigid electrical equipment	1
15-7332-1-4	Conduit—Rigid electrical equipment	1
15-7332-1-5	Conduit—Rigid electrical equipment	1
15-7332-2-1	Conduit—Rigid electrical equipment	1
15-7332-2-2	Conduit—Rigid electrical equipment	1
15-7332-3-1	Conduit—Rigid electrical equipment	1
15-7332-3-3	Conduit—Rigid electrical equipment	1
15-7332-3-4	Conduit—Rigid electrical equipment	1
15-7332-4-1	Conduit—Rigid electrical equipment	1
15-7332-4-3	Conduit—Rigid electrical equipment	1
15-7332-4-4	Conduit—Rigid electrical equipment	1
15-7332-5-1	Conduit—Rigid electrical equipment	1
15-7332-5-2	Conduit—Rigid electrical equipment	1
15-7332-6-1	Conduit—Rigid electrical equipment	1
15-7332-6-2	Conduit—Rigid electrical equipment	1
15-7332-15-1	Conduit—Rigid electrical equipment	1
15-7332-15-2	Conduit—Rigid electrical equipment	1
15-7332-15-3	Conduit—Rigid electrical equipment	1
15-7332-15-4	Conduit—Rigid electrical equipment	1
15-7332-16-1	Conduit—Rigid electrical equipment	1
15-7332-16-2	Conduit—Rigid electrical equipment	1
15-7332-16-3	Conduit—Rigid electrical equipment	1
15-7332-16-4	Conduit—Rigid electrical equipment	1
15-7332-118-1	Conduit—Rigid electrical equipment	1
15-7332-118-2	Conduit—Rigid electrical equipment	1
15-7332-118-3	Conduit—Rigid electrical equipment	1
15-7332-118-4	Conduit—Rigid electrical equipment	1
15-7332-119-1	Conduit—Rigid electrical equipment	1
15-7332-119-2	Conduit—Rigid electrical equipment	1
15-7332-120	Conduit—Rigid electrical equipment	1
15-7332-120-2	Conduit—Rigid electrical equipment	1
15-7332-120-3	Conduit—Rigid electrical equipment	1
15-7332-121-2	Conduit—Rigid electrical equipment	1
15-7332-121-4	Conduit—Rigid electrical equipment	1
15-7332-122-2	Conduit—Rigid electrical equipment	1
15-7332-147-2	Conduit—Rigid electrical equipment	1
15-7332-147-3	Conduit—Rigid electrical equipment	1
15-7332-198-1	Conduit—Rigid electrical equipment	1
15-7332-198-2	Conduit—Rigid electrical equipment	1
15-7332-201-1	Conduit—Rigid electrical equipment	1
15-7332-201-2	Conduit—Rigid electrical equipment	1
15-7332-201-3	Conduit—Rigid electrical equipment	1

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 492)	
15-7332-201-4	Conduit—Rigid electrical equipment	1
15-7332-202-1	Conduit—Rigid electrical equipment	1
15-7332-202-2	Conduit—Rigid electrical equipment	1
15-7332-203-1	Conduit—Rigid electrical equipment	1
15-7332-203-2	Conduit—Rigid electrical equipment	1
15-7332-204-1	Conduit—Rigid electrical equipment	1
15-7332-204-2	Conduit—Rigid electrical equipment	1
15-7332-204-3	Conduit—Rigid electrical equipment	1
15-7332-204-4	Conduit—Rigid electrical equipment	1
15-7332-171	Clamp—Wire electrical equipment	2
15-7332-174	Clamp—Wire electrical equipment	10
15-7332-175	Clamp—Wire electrical equipment	26
15-7332-176	Clamp—Wire electrical equipment	5
15-7332-177	Clamp—Wire electrical equipment	3
15-7332-175	Clamp—Wire electrical equipment (Government furnished)	2
15-7332-176	Clamp—Wire electrical equipment (Government furnished)	5
15-7332-177	Clamp—Wire electrical equipment	4
15-7332-140	Tubing—Electrical equipment	1
15-7332-141	Tubing—Electrical equipment	1
15-7332-142	Tubing—Electrical equipment	1
15-7332-143	Tubing—Electrical equipment	1
15-7332-144	Tubing—Electrical equipment	1
15-7332-145	Tubing—Electrical equipment	1
15-7332-146	Tubing—Electrical equipment	1
15-7332-159	Tubing—Control column electrical equipment	2
15-7332-160	Tubing—De-icer valve electrical equipment	1
15-7332-163	Tubing—Bomb sight electrical equipment	1
15-7332-165	Tubing—Bomb interval release electrical equipment	1
15-7332-166	Tubing—Splices electrical equipment	1
15-7332-168	Tubing—Fuel booster pump inboard electrical equipment	2
15-7332-172	Tubing—Fuel trans. pump to fuel trans. switch electrical equipment	1
15-7332-173	Tubing—Fuel trans. switch to microphone switch electrical equipment	1
15-7332-181	Tubing—Landing gear electrical equipment	2
15-7332-182	Tubing—Bomb door safety switch electrical equipment	2
15-7332-189	Tubing—Throttle warning electrical equipment LH	1
15-7332-190	Tubing—Throttle warning electrical equipment RH	1
15-7332-217	Tubing—Main tank gage electrical equipment	1
15-7332-204	Tubing—Pilot mast electrical equipment	2
15-7332-205	Tubing—Electrical equipment	2
15-7332-244	Tubing—Electrical equipment	1
15-7332-245	Tubing—Lower turret sight trans. electrical equipment	2
15-7332-246	Tubing—Lower turret sight trans. electrical equipment	2
15-7332-247	Tubing—Lower turret sight trans. electrical equipment	2
15-7332-250	Tubing—Electrical equipment	1
15-7332-251	Tubing—Electrical equipment	1
15-7332-252	Tubing—Electrical equipment	1
15-7332-253	Tubing—Electrical equipment	2
15-7332-254	Tubing—Electrical equipment	1
15-7332-255	Tubing—Electrical equipment	1
15-7332-256	Tubing—Electrical equipment	1
15-7332-257	Tubing—Electrical equipment	2
	(Parts List No. 493)	
15-7332-258	Tubing—Electrical equipment	2
15-7332-259	Tubing—Electrical equipment	4
15-7332-260	Tubing—Electrical equipment	1
15-7332-261	Tubing—Electrical equipment	6
15-7332-262	Tubing—Electrical equipment	1

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7332-263	Tubing—Electrical equipment	1
15-7332-264	Tubing—Electrical equipment	1
15-7332-265	Tubing—Electrical equipment	1
15-7332-266	Tubing—Electrical equipment	1
15-7332-193	Plug—Drift meter electrical equipment	1
15-7332-3-2	Conduit Assembly—Flexible electrical equipment	1
36A2214-4	Ferrule—Flexible conduit end plain	2
15-7332-4-2	Conduit Assembly—Flexible electrical equipment	1
36A2214-4	Ferrule—Flexible conduit end plain	2
15-7332-7	Conduit Assembly—Flexible electrical equipment	1
41-1464-70-38	Washer—.025 aluminum alloy	1
AN3050-6	Ferrule	1
AN3054-12	Nut	1
BAC764-3B	Ferrule—Flexible conduit	1
15-7332-9	Conduit Assembly—Flexible electrical equipment	1
BAC764-3B	Ferrule—Flexible conduit	2
15-7332-10	Conduit Assembly—Flexible electrical equipment	1
BAC764-3B	Ferrule—Flexible conduit	2
15-7332-13	Conduit Assembly—Flexible electrical equipment	1
BAC761-3	Coupling Nut—Junction box	1
BAC764-3B	Ferrule—Flexible conduit	1
AN3106-18-8P	Plug	1
AN3054-10	Nut—Conduit coupling	1
AN3052-6	Ferrule	1
15-7332-14	Conduit Assembly—Flexible electrical equipment	1
AN3106-18-8P	Plug	1
BAC761-3	Coupling Nut—Junction box	1
AN3054-10	Nut	1
AN3052-6	Ferrule	1
BAC764-3B	Ferrule—Flexible conduit	1
15-7332-19	Conduit Assembly—Flexible electrical equipment	1
BAC764-3B	Ferrule—Flexible conduit	2
15-7332-20	Conduit Assembly—Flexible electrical equipment	1
BAC764-3B	Ferrule—Flexible conduit	2
15-7332-21	Conduit Assembly—Flexible electrical equipment	1
15-7332-83	Braid—Electrical equipment	1
15-7332-77	Sleeve—Electrical equipment	1
BAC764-2B	Ferrule—Flexible conduit	1
	(Parts List No. 494)	
15-7332-22	Conduit Assembly—Flexible electrical equipment	1
15-7332-77	Sleeve—Electrical equipment	1
15-7332-84	Braid—Electrical equipment	1
BAC764-2B	Ferrule—Flexible conduit	1
15-7332-23	Conduit Assembly—Flexible electrical equipment	1
AN3106-18-8P	Plug	1
BAC761-3	Coupling Nut—Junction box	1
AN3054-10	Nut	1
AN3052-6	Ferrule	1
BAC764-3B	Ferrule—Flexible conduit	1
15-7332-24	Conduit Assembly—Flexible electrical equipment	1
AN3106-18-8P	Plug	1
AN3054-10	Nut	1
BAC761-3	Coupling Nut—Junction box	1
AN3052-6	Ferrule	1
BAC764-3B	Ferrule—Flexible conduit	1
15-7332-31	Conduit Assembly—Flexible electrical equipment	1
AN3050-4	Ferrule	2
AN3054-4	Nut	2
15-7332-32	Conduit Assembly—Flexible electrical equipment	1
AN3050-4	Ferrule	2
AN3054-4	Nut	2
15-7332-33	Conduit Assembly—Flexible electrical equipment	1
36A2214-5	Ferrule—Flexible conduit end plain	2
15-7332-34	Conduit Assembly—Flexible electrical equipment	1
36A2214-5	Ferrule—Flexible conduit end plain	2
15-7332-35	Conduit Assembly—Flexible electrical equipment	1
AN3050-16	Ferrule	2
AN3054-16	Nut	2
15-7332-36	Conduit Assembly—Flexible electrical equipment	1
AN3050-16	Ferrule	2
AN3054-16	Nut	2

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7332-43	Conduit Assembly—Flexible electrical equipment.	1
AN3054-4	Nut	2
AN3050-4	Ferrule	2
15-7332-44	Conduit Assembly—Flexible electrical equipment.	1
AN3054-4	Nut	2
AN3050-4	Ferrule	2
15-7332-45	Conduit Assembly—Flexible electrical equipment.	1
36A2214-5	Ferrule—Flexible conduit end plain	2
15-7332-46	Conduit Assembly—Flexible electrical equipment.	1
	(Parts List No. 495)	
36A2214-5	Ferrule—Flexible conduit end plain	2
15-7332-51	Conduit Assembly—Flexible electrical equipment.	1
AN3054-16	Nut	2
AN3050-16	Ferrule	2
15-7332-52	Conduit Assembly—Flexible electrical equipment.	1
AN3054-8	Nut	2
AN3050-8	Ferrule	2
15-7332-53	Conduit Assembly—Flexible electrical equipment.	1
AN3054-8	Nut	2
AN3050-8	Ferrule	2
15-7332-54	Conduit Assembly—Flexible electrical equipment.	1
AN3054-6	Nut	2
AN3050-6	Ferrule	2
15-7332-55	Conduit Assembly—Flexible electrical equipment.	1
AN3050-6	Ferrule	2
AN3054-6	Nut	2
15-7332-56	Conduit Assembly—Flexible electrical equipment.	1
AN3050-6	Ferrule	2
AN3054-6	Nut	2
15-7332-57	Conduit Assembly—Electrical equipment	1
AN3050-4	Ferrule	2
AN3054-4	Nut	2
15-7332-124	Conduit Assembly—Flexible electrical equipment.	1
AN3054-10	Nut	1
AN3054-16	Nut	1
AN3052-10	Ferrule	1
AN3050-10	Ferrule	1
15-7332-126	Conduit Assembly—Flexible electrical equipment.	1
AN3054-10	Nut	1
AN3054-16	Nut	1
AN3052-10	Ferrule	1
AN3050-10	Ferrule	1
15-7332-128	Conduit Assembly—Flexible electrical equipment.	1
AN3050-4	Ferrule	1
AN3052-4	Ferrule	1
AN3054-4	Nut	1
AN3054-8	Nut	1
15-7332-130	Conduit Assembly—Flexible electrical equipment.	1
AN3050-4	Ferrule	1
AN3052-4	Ferrule	1
AN3054-4	Nut	1
AN3054-8	Nut	1
	(Parts List No. 496)	
15-7332-132	Conduit Assembly—Flexible electrical equipment.	1
AN3050-10	Ferrule	1
AN3052-10	Ferrule	1
AN3054-10	Nut	1
AN3054-16	Nut	1
15-7332-134	Conduit Assembly —Flexible electrical equipment.	1
AN3050-10	Ferrule	1
AN3052-10	Ferrule	1
AN3054-10	Nut	1
AN3054-16	Nut	1
15-7332-136	Conduit Assembly—Flexible electrical equipment.	1
AN3050-4	Ferrule	1
AN3052-4	Ferrule	1
AN3054-4	Nut	1
AN3054-8	Nut	1

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7332-138	Conduit Assembly—Flexible electrical equipment.	1
AN3050-4	Ferrule	1
AN3052-4	Ferrule	1
AN3054-4	Nut	1
AN3054-8	Nut	1
15-7332-155	Conduit Assembly—Flexible electrical equipment.	1
AN3050-4	Ferrule	1
AN3052-4	Ferrule	1
AN3054-4	Nut	1
AN3054-8	Nut	1
15-7332-156	Conduit Assembly—Flexible electrical equipment.	1
AN3050-4	Ferrule	1
AN3052-4	Ferrule	1
AN3054-4	Nut	1
AN3054-8	Nut	1
15-7332-157	Conduit Assembly—Flexible electrical equipment.	1
AN3050-4	Ferrule	1
AN3052-4	Ferrule	1
AN3054-4	Nut	1
AN3054-8	Nut	1
15-7332-158	Conduit Assembly—Flexible electrical equipment.	1
AN3050-4	Ferrule	1
AN3052-4	Ferrule	1
AN5054-4	Nut	1
AN5054-8	Nut	1
15-7332-196	Conduit Assembly—Flexible electrical equipment.	1
AN3050-16	Ferrule	2
AN3054-16	Connection—Conduit box	2
15-7332-198-3	Conduit Assembly—Flexible electrical equipment.	1
	(Parts List No. 497)	
36A2214-4	Ferrule—Flexible conduit end plain	2
15-7332-208	Conduit Assembly—Flexible electrical equipment.	1
BAC764-3B	Ferrule—Flexible conduit electrical equipment.	2
15-7332-210	Conduit Assembly—Flexible electrical equipment.	1
BAC764-3B	Ferrule—Flexible conduit electrical equipment.	2
15-7332-212	Conduit Assembly—Flexible electrical equipment.	1
BAC764-3B	Ferrule—Flexible conduit electrical equipment.	2
15-7332-214	Conduit Assembly—Flexible electrical equipment.	1
BAC764-3B	Ferrule—Flexible conduit electrical equipment.	2
15-7332-218	Conduit Assembly—Flexible electrical equipment.	1
AN3050-6	Ferrule	2
AN3054-6	Nut	2
15-7332-220	Conduit Assembly—Flexible electrical equipment.	1
AN3050-6	Ferrule	2
AN3054-6	Nut	2
15-7332-222	Conduit Assembly—Flexible electrical equipment.	1
AN3050-6	Ferrule	2
AN3054-6	Nut	2
15-7332-224	Conduit Assembly—Flexible electrical equipment.	1
AN3050-6	Ferrule	2
AN3054-6	Nut	2
15-7332-226	Conduit Assembly—Flexible electrical equipment.	1
AN3050-6	Ferrule	2
AN3054-6	Nut	2
15-7332-228	Conduit Assembly—Flexible electrical equipment.	1
AN3050-6	Ferrule	2
AN3054-6	Nut	2
15-7332-230	Conduit Assembly—Flexible electrical equipment.	1
AN3050-6	Ferrule	2
AN3054-6	Nut	2
15-7332-232	Conduit Assembly—Flexible electrical equipment.	1
AN3050-6	Ferrule	2
AN3054-6	Nut	2
15-7332-234	Conduit Assembly—Flexible electrical equipment.	1
41-1464-70-38	Washer—.025 aluminum alloy	1
AN3050-6	Ferrule	1
BAC764-3B	Ferrule—Flexible conduit electrical equipment.	1
AN3054-12	Nut—Conduit coupling	1
15-7332-235	Conduit Assembly—Flexible electrical equipment.	1

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 498)	
41-1464-70-38	Washer—.025 aluminum alloy	1
AN3050-6	Ferrule	1
BAC764-3B	Ferrule—Flexible conduit electrical equipment	1
AN3054-12	Nut—Conduit coupling	1
15-7332-236	Conduit Assembly—Flexible electrical equipment	1
41-1464-70-38	Washer—.025 aluminum alloy	1
AN3050-6	Ferrule	1
BAC764-3B	Ferrule—Flexible conduit electrical equipment	1
AN3054-12	Nut—Conduit coupling	1
15-7332-267	Conduit Assembly—Flexible electrical equipment (No. 4 generator)	1
15-7332-269	Conduit Assembly—Flexible electrical equipment (No. 3 generator)	1
15-7332-271	Conduit Assembly—Flexible electrical equipment (No. 2 generator)	1
15-7332-11	Conduit Assembly—Braid electrical equipment	1
15-7332-76	Braid—Electrical equipment	1
15-7332-77	Sleeve—Electrical equipment	1
BAC764-2B	Ferrule—Flexible conduit electrical equipment	1
15-7332-12	Conduit Assembly—Braid Electrical equipment	1
15-7332-78	Braid—Electrical equipment	1
15-7332-77	Sleeve—Electrical equipment	1
BAC764-2B	Ferrule—Flexible conduit electrical equipment	1
15-7332-120-1	Conduit Assembly—Flexible electrical equipment	1
36A2214-4	Ferrule—Flexible conduit end plain	2
15-7332-121-3	Conduit Assembly—Flexible electrical equipment	1
36A2214-3	Ferrule—Flexible conduit end plain	2
6-10667	Conduit Installation—Tail gun	1
6-10667-1	Conduit Rigid—Tail gun	1
21-2589-20	Clip—Tab loop type	4
41-9007-1	Angle—Tube support	2
BAC1603-32	Spacer—No. 10 bolt	1
BAC1603-48	Spacer—No. 10 bolt	1
21-4585-42-12	Clamp—Tab square tube	1
21-4585-96-20	Clamp—Tab square tube	16
1-18853-5	Terminal—Electrical	2
21-2589-8	Clip—Tab loop type	3
21-2589-16	Clip—Tab loop type	23
21-2589-19	Clip—Tab loop type	34
21-2589-47	Clip—Tab loop type	2
21-2589-55	Clip—Tab loop type	2
1-18853-6	Terminal—Electrical	13
41-1464-70-38	Washer—.025 aluminum alloy	4
1-13892-38-8	Clamp—Tabulated square	6
41-468-16-3	Clamp—Square loop type	2
41-468-70-16	Clamp—Square loop type	10
	(Parts List No. 499)	
41-468-86-24	Clamp—Square loop type	2
41-468-28-8	Clamp—Square loop type	4
41-1065-3	Clamp—¾ wide barrel	2
41-1065-6	Clamp—¾ wide barrel	3
BAC538-2	Clamp—Loop type cushioned	80
BAC538-3	Clamp—Loop type cushioned	125
BAC538-4	Clamp—Loop type cushioned	64
BAC538-5	Clamp—Loop type cushioned	41
BAC538-6	Clamp—Loop type cushioned	38
BAC538-7	Clamp—Loop type cushioned	84
BAC538-8	Clamp—Loop type cushioned	157
BAC538-9	Clamp—Loop type cushioned	100
BAC538-10	Clamp—Loop type cushioned	134
BAC538-12	Clamp—Loop type cushioned	181
BAC538-14	Clamp—Loop type cushioned	71
BAC538-16	Clamp—Loop type cushioned	10
BAC538-18	Clamp—Loop type cushioned	50
BAC538-20	Clamp—Loop type cushioned	10
BAC538-22	Clamp—Loop type cushioned	20
BAC539-3	Clamp—Cushioned lug type	32
BAC539-4	Clamp—Cushioned lug type	21
BAC539-5	Clamp—Cushioned lug type	16

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC539-6	Clamp—Cushioned lug type	2
BAC539-7	Clamp—Cushioned lug type	45
BAC539-10	Clamp—Cushioned lug type	16
BAC539-11	Clamp—Cushioned lug type	21
BAC539-12	Clamp—Cushioned lug type	42
BAC539-108	Clamp—Cushioned lug type	32
BAC539-109	Clamp—Cushioned lug type	12
BAC539-112	Clamp—Cushioned lug type	8
BAC539-114	Clamp—Cushioned lug type	8
BAC539-116	Clamp—Cushioned lug type	8
BAC539-118	Clamp—Cushioned lug type	6
BAC539-120	Clamp—Cushioned lug type	10
BAC539-122	Clamp—Cushioned lug type	6
BAC539-124	Clamp—Cushioned lug type	3
BAC540-4	Clamp—Loop type cushioned	20
BAC540-6	Clamp—Loop type cushioned	37
BAC540-8	Clamp—Loop type cushioned	24
BAC540-9	Clamp—Loop type cushioned	4
BAC540-14	Clamp—Loop type cushioned	13
BAC540-16	Clamp—Loop type cushioned	6
BAC540-22	Clamp—Loop type cushioned	4
BAC540-44	Clamp—Loop type cushioned	8
BAC821-122-6	Terminal—Electric solderless	10
BAC821-122-8	Terminal—Electric solderless	10
BAC821-122-10	Terminal—Electric solderless	20
BAC821-120-6	Terminal—Electric solderless	25
BAC821-120-8	Terminal—Electric solderless	110
BAC821-120-10	Terminal—Electric solderless	625
BAC821-118-6	Terminal—Electric solderless	40
BAC821-118-8	Terminal—Electric solderless	90
BAC821-118-10	Terminal—Electric solderless	260
	(Parts List No. 499A)	
BAC821-116-6	Terminal—Electric solderless	25
BAC821-116-8	Terminal—Electric solderless	25
BAC821-116-10	Terminal—Electric solderless	200
BAC821-114	Terminal—Electric solderless	100
BAC821-12	Terminal—Electric solderless	75
BAC821-10	Terminal—Electric solderless	25
BAC821-8	Terminal—Electric solderless	20
BAC821-6	Terminal—Electric solderless	5
BAC821-4	Terminal—Electric solderless	25
	(Parts List No. 500)	
BAC822-0	Sleeve Insulation—Electrical terminal	30
BAC822-2	Sleeve Insulation—Electrical terminal	30
BAC822-14	Sleeve Insulation—Electrical terminal	50
BAC822-16	Sleeve Insulation—Electrical terminal	250
BAC822-18	Sleeve Insulation—Electrical terminal	400
BAC822-20	Sleeve Insulation—Electrical terminal	775
BAC822-22	Sleeve Insulation—Electrical terminal	150
BAC823-18	Splice—Electrical solderless	7
BAC823-20	Splice—Electrical solderless	9
BAC1603-8	Spacer—No. 10 bolt	237
BAC1603-16	Spacer—No. 10 bolt	139
BAC1603-24	Spacer—No. 10 bolt	17
BAC1603-32	Spacer—No. 10 bolt	51
BAC1603-40	Spacer—No. 10 bolt	8
BAC1603-48	Spacer—No. 10 bolt	30
BAC1603-64	Spacer—No. 10 bolt	17
BAC1603-112	Spacer—No. 10 bolt	1
31-1176-2	Clamp—Conduit	24
31-1176-3	Clamp—Conduit	10
31-1176-4	Clamp—Conduit	2
31-1176-7	Clamp—Conduit	12
31-1177-2	Nut—Conduit	74
31-1177-3	Nut—Conduit	18
31-1177-4	Nut—Conduit	10
31-1177-7	Nut—Conduit	32
6-9214-4	Strap—Flap position indicator	3
1-17361-1	Brushes—Spare motor tail wheel	1

AVIALOGS.COM

FINAL ASSEMBLY

Electrical Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-18708-1	Brushes—Spare fuel transfer pump	1
3-12723-2	Brushes—Spare landing wheel motor	2
3-12781-1	Brushes—Spare flap motor	1
6-8955-3	Brushes—Spare booster pump	4
AN3064-4	Clamp	4
AN3064-6	Clamp	13
AN3064-8	Clamp	4
AN3064-16	Connector—Conduit box	4
AN3066-4	Nut	4
AN3066-6	Nut	13
AN3066-8	Nut	4
AN3066-16	Nut	10
AN3106-10S-2S	Plug	1
AN3106-12S-3S	Plug	2
AN3106-14S-1S	Plug	3
AN3106-14S-2S	Plug	28
AN3106-16S-1S	Plug	18
AN3106-16S-4P	Plug	4
AN3106-20-6S	Plug	5
AN3106-28-5S	Plug	3
AN3106-22-4S	Plug—Inverter	2
AN3106-20-5P	Plug—Driftmeter	1
AN3106-12S-4S	Plug	4
AN3106-20-1S	Plug	4
AN3106-14S-5S	Plug	1
AN3108-12S-4S	Plug	4

(Parts List No. 501)

AN3108-12-5S	Plug	4
AN3108-24-1P	Plug	4
33A2431-2	Union—Conduit	23
33A2431-3	Union—Conduit	4
33A2431-4	Union—Conduit	3
33A2431-7	Union—Conduit	12
35A4273	Plug—Electrical connection	2
38A1531	Plug—Gun camera	1
1-21959-3	Fitting—Connector (government furnished)	1
3-15155-1	Brush—Spare bomb door motor	1
21-6441-6	Clamp Assembly—¾ wide barrel	2
21-6087-6-3	Clamp—Barrel type	2
36A2212-2	Nut—Knurl	1

Radio Equipment Installation

(Parts List No. 502)

55-7589	Equipment Installation—Radio (AC41-2393 to 41-2542) (150)	1

Radio equipment installation 55-7589 is used on planes 41-2443 to 41-2542 inclusive.

Dash number parts, shown on 55-7589 drawing are represented by dash numbers of 15-7589 and 55-7589.

55-7589	Conduit Assembly—Flexible radio equipment	1
55-7589-401	Conduit—Flexible radio equipment	1
15-7589-34	Plug—Radio equipment (Government furnished)	1
15-7589-35	Plug—Radio equipment (Government furnished)	1
15-7589-5	Cord Assembly—Pilot's radio equipment	1
15-7589-6	Cord—Radio equipment (type C0201) (Government furnished)	1
15-7589-7	Plug—Radio equipment (type PL-124) (Government furnished)	1
15-7589-8	Plug—Radio equipment (type PL-125) (Government furnished)	1
15-7589-10	Cord Assembly—Co-pilot's radio equipment	1
15-7589-11	Cord—Radio equipment (type C0201) (Government furnished)	1
15-7589-7	Plug—Radio equipment (type PL-124) (Government furnished)	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7589-8	Plug—Radio equipment (type PL-125) (Government furnished)	1
15-7589-4	Microphone—Radio equipment (Government furnished)	2
15-7589-45	Microphone—Radio equipment (Government furnished)	2
15-7589-9	Plug—Radio equipment (Government furnished)	2
15-7589-42	Plug—Radio equipment (Government furnished)	2
15-7589-12	Connector Loop—Radio equipment (Government furnished)	1
15-7589-13	Shaft—Tuning radio equipment (Government furnished)	1
15-7589-15	Shaft—Tuning radio equipment (Government furnished)	1
15-7589-16	Shaft—Tuning radio equipment (Government furnished)	1
15-7589-17	Shaft—Tuning radio equipment (Government furnished)	1
15-7589-18	Shaft—Tuning radio equipment (Government furnished)	1
15-7589-19	Shaft—Tuning radio equipment (Government furnished)	1
15-7589-21	Plug—Radio equipment (Government furnished)	1
15-7589-22	Plug—Radio equipment (Government furnished)	1
15-7589-14	Coupling—Radio equipment (Government furnished)	2
55-7534	Antenna Installation—Radio	1

Dash number parts, shown on 55-7534 drawing are represented by dash numbers of 15-7534 and 55-7534.

55-7534-400	Wire—Switch to antenna radio (Government furnished)	1
55-7534-401	Wire—Radio antenna	1
15-7534-28	Wire—Radio antenna (Government furnished)	1
15-7534-1	Wire—Command antenna radio (Government furnished)	1
15-7534-2	Link—Radio antenna	1
15-7534-3	Insulator—Antenna radio (Government furnished)	4
15-7534-4	Wire—Radio antenna (Government furnished)	3
15-7534-5	Wire—Radio antenna (Government furnished)	1
15-7534-6	Wire—Lead-in radio antenna (Government furnished)	1
15-7534-7	Insulator—Bead radio antenna (Government furnished)	364
15-7534-8	Wire—Radio antenna (Government furnished)	1
15-7534-9	Wire—Radio antenna (Government furnished)	1
15-7534-11	Wire—Radio antenna (Government furnished)	1
15-7534-12	Wire—Radio antenna (Government furnished)	1
15-7534-14	Wire—Radio antenna (Government furnished)	1

(Parts List No. 503)

15-7534-15	Wire—Radio antenna	1
1-12946-1	Bushing—Tab cable	1
6-10446	Switch Installation—Antenna radio (square "D" Co. No. 962)	1
1-21915	Switch Assembly—Antenna change over (square "D" Co., L.A. calory drawing B1143-5; catalog No. 962)	1
1-21434	Plate Assembly—Antenna switch	1
1-21434-1	Plate—Antenna switch	1
BAC1603-16	Spacer—No. 10 bolt	4
1-17633	Insulator Installation—Receiver lead-in	1
1-17633-1	Insulator Installation—Receiver lead-in	1
1-17633-2	Insulator Installation—Receiver lead-in	1
1-17633-4	Insulator Installation—Receiver lead-in	1
1-17633-5	Insulator Installation—Receiver lead-in	1
35A2276	Insulator—(Type IN-81) (Government furnished)	5
41-445-0-6	Spacer—No. 10 bolt	5
3-13564	Insulator Installation—Liaison antenna lead-in	1
41-8420-77-57	Trim—Escutcheon	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
35A2282	Insulator—(Type IN-84) (government furnished)	1
1-18465	Insulator—Lead-in	1
1-18718	Washer—Insulator seal	1
1-18720-40-12	Stud—Brass	1
51-315-48-16	Washer—1/16 lead	2
3-13564-2	Link Assembly—Lead-in	1
1-16064	Bushing—Antenna connect	1
1-16071-1	Link—Antenna connect	1
3-13629	Insulator Installation—Command antenna lead-in	1
35A2282	Insulator—(Type IN-84) (government furnished)	1
1-18465	Insulator—Lead-in	1
1-18718	Washer—Insulator seal	1
1-18720-40-12	Stud—Brass	1
51-315-48-16	Washer—1/16 lead	2
41-8542	Insulator Installation—Trail antenna lead-in	1
35A2277	Insulator—(Type IN-82) (government furnished)	1
3-12778	Insulator Installation—Liaison antenna	1
35A2276	Insulator—(Type IN-81) (government furnished)	2
1-21477	Insulator Installation—Receiver lead-in	1
41-445-0-6	Spacer—No. 10 bolt	1
35A2276	Insulator—(Type IN-81) (government furnished)	1
9-3765	Antenna Installation—Marker beacon	1
9-3765-14	Washer—Plain marker beacon (government furnished)	2
9-3765-15	Nut—Plain marker beacon (government furnished)	2
9-3765-1	Wire Assembly—Antenna marker beacon	1
9-3765-2	Wire—Lead-in marker beacon (government furnished)	1
9-3765-3	Wire—Antenna marker beacon (government furnished)	1
9-3765-4	Wire—Splicing marker beacon (government furnished)	1
9-3765-5	Insulator—Marker beacon (government furnished)	2
	(Parts List No. 504)	
9-3765-6	Wire—Double strand marker beacon (government furnished)	2
9-3765-12	Terminal Assembly—Marker beacon (government furnished)	1
9-3765-7	Cable Assembly—Transmission marker beacon	1
9-3765-8	Cable—Transmission line marker beacon (government furnished)	1
9-3765-9	Coupling Assembly—Marker beacon (government furnished)	1
9-3765-10	Cable—Flexible transmission marker beacon (government furnished)	1
9-3765-11	Fitting Assembly—Marker beacon (government furnished)	1
9-3765-13	Terminal—Marker beacon	1
14-2345	Lead Installation—Whip antenna	1
14-2345-1	Conduit Assembly—Whip antenna lead	1
14-2345-4	Conduit—Rigid whip antenna lead-in	1
14-2345-3	Wire—Whip antenna lead-in (government furnished)	1
14-2345-5	Tube—Whip antenna lead-in	1
14-2345-6	Tube—Whip antenna lead-in	1
1-19089	Cap—Insulator antenna lead-in	2
1-19088	Disc—Insulator antenna lead-in	2
1-18069	Bus—Connector	1
14-2345-7	Wire—Lead-in installation whip antenna	1
1-19086	Clamp Assembly—Antenna wire	1
1-19086-1	Bushing—Antenna wire clamp	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-19086-3	Clamp Assembly—Antenna wire	1
1-19086-2	Bushing—Antenna wire clamp	1
BAC1603-32	Spacer—No. 10 bolt	1
BAC1603-56	Spacer—No. 10 bolt	1
1-19001-33	Fair-lead Assembly—1 hole	1
1-19001-32	Fair-lead—1 hole	2
1-16388-192-20	Fair-lead—Antenna	1
1-16071-1	Link—Antenna connector	1
BAC821-116-10	Terminal—Electrical solderless	2
BAC1602-36	Spacer—No. 8 machine screw	4
9-3713	Antenna Installation—Radio compass	1
3-12479	Antenna Whip—Radio compass	1
3-14988	Seal Installation—Whip antenna	1
3-14988-1	Tube—Whip antenna	1
1-20344	Seal—Whip antenna	1
15-7530	Radio Installation—Command	1
15-7530-1	Transmitter—Command radio (type BC-AL-430) (36D3527) (Government furnished)	1
15-7530-2	Receiver—Command radio (type BC-AL-429) (Sc-D-317A) (Government furnished)	1
15-7530-6	Relay—Antenna switch command radio (type BC-AL-408) (36B3528) (Government furnished)	1
15-7530-15	Mounting—Command radio (type FT-99)	1
15-7530-16	Mounting—Command radio (type FT-100)	1
15-7530-17	Mounting—Command radio (type FT-118)	1
15-7530-18	Insulator — Command radio (type IN-82) (35A2277)	2
15-7530-19	Insulator — Command radio (type IN-81) (35A2276)	1
	(Parts List No. 505)	
15-7530-8	Coil Assembly—Command radio	1
15-7530-4	Coil—Set command radio (type C-271) (35A1219) (Government furnished)	6
15-7530-5	Coil—Set command radio (type C-266) (34B5892) (Government furnished)	1
15-7530-9	Case—Command radio (type CS-44) (34B5892) (Government furnished)	1
15-7530-10	Case—Command radio (type CS-47) (35A1219) (Government furnished)	5
15-7530-11	Coil—Set command radio (type C275) (35A1219) (Government furnished)	1
15-7530-12	Coil—Set command radio (type C274) (35A1219) (Government furnished)	1
15-7530-13	Coil—Set command radio (type C273) (35A1219) (Government furnished)	1
15-7530-14	Coil—Set command radio (type C272) (35A1219) (Government furnished)	1
9-3443-1	Support—Sets	1
6-9239	Panel Assembly—Radio command	1
6-9239-4	Cover Assembly—Command radio	1
1-18588	Spring—Cover catch	2
6-9239-8	Cover—Radio command panel	1
6-9694	Cards—Junction identification	1
BAC802-2-45	Jumper Assembly—Terminal bonding	1
6-9239-9	Panel—Radio command	1
6-9239-10	Insulator—Radio command panel	1
6-9239-3	Condenser—Radio command panel	1
6-9239-6	Resistor—Radio command panel	1
6-9239-7	Relay—Command set radio panel	1
21-7401	Bus—Connector panel	1
9-3606	Support Assembly—Command radio	1
9-3444	Shelf—Command radio	2
1-18576	Angle—Longeron tie	2
1-19965-1-45	Jumper Assembly—Terminal bonding	1
1-19965-1-60	Jumper Assembly—Terminal bonding	1
BAC1603-12	Spacer—No. 10 bolt	4
BAC1603-40	Spacer—No. 10 bolt	8

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-21921	Meter Assembly—Frequency (Government furnished)	1
6-8833	Control Installation—Radio compass (navigation)	1
6-8833-1	Box—Control radio compass navigation (Government furnished)	1
6-9331	Control Installation—Radio and compass	1
6-9331-1	Box—Control radio compass (type BC-414-A) (H40D3229) (Government furnished)	1
6-9331-4	Remote Control Unit—Radio and compass (type MC-135) (drawing SC-D-317A) (Government furnished)	1
6-9331-8	Switch Box—Radio and compass navigation (type BC-326) (drawing SC-D02210-E) (Government furnished)	1
6-9331-6	Mounting—Radio and compass navigation (type FT-118) (Government furnished)	1
	(Parts List No. 506)	
6-9331-7	Mounting—Radio and compass navigation (type FT-118) (government furnished)	1
33A1757	Control Assembly—Radio receiver tuning (type MC-125) (government furnished)	1
36B3526	Control Assembly—Radio receiver tuning (type BC-AN-231) (government furnished)	1
36B3529	Control Assembly—Radio transmitter (type BC-AE-232)	1
1-18831	Bracket—Control support	1
7-1649	Unit Installation—Transmitter tuning	1
1-21920	Unit Assembly—Transmitter tuning (drawing 34D5889) (government furnished)	1
1-21920-1	Unit Assembly—Transmitter tuning (drawing 34D5889) (government furnished)	1
1-21920-2	Case—Transmitter tuning (drawing 34D5889) (government furnished)	2
7-1648	Support Installation—Transmitter tuning	1
7-1648-1	Angle Assembly—Transmitter tuning	1
7-1648-3	Plate—Filler transmitter tuning	2
7-1648-4	Channel Assembly—Transmitter tuning	2
BAC1602-12	Spacer—No. 8 machine screw	8
9-3750	Unit Installation—Antenna tuning	1
1-21914	Unit Assembly—Antenna tuning (government furnished)	1
1-21914-1	Mounting—Antenna tuning unit (government furnished)	1
9-3743	Bracket—Tuning unit support	1
1-19965-2-115	Jumper Assembly—Terminal bonding	1
3-14927	Bracket Assembly—Antenna tuning	1
3-14927-2	Bracket—Antenna tuning	1
3-14927-3	Bumper—Antenna tuning bracket	1
6-10471	Control Installation—Liaison receiver	1
6-10471-1	Control Assembly—Liaison receiver (remote control unit type MR-9C, Bendix Radio Corp., Baltimore, Md.) (government furnished)	1
BAC1602-46	Spacer—No. 8 machine screw	4
3-14979	Receptacle—Cannon	1
1-21959-8	Fitting—Connector	1
3-14979-1	Receptacle—Receiver cannon	1
1-21922	Shaft Assembly—Tuning flexible (Bendix No. A15410) (government furnished)	1
1-21974	Clamp Assembly—Plug connector	3
1-20245	Clamp—Support plug connection	3
36A2212-4	Nut—Flexible conduit ferrule coupling	3
36A2213-4	Ferrule—Flexible conduit end shoulders	3
15-7589-41	Tubing—Radio equipment	1
15-7589-44	Wire—Jumper on plugs—radio equipment	1
3-14994	Filter Installation—Radio	1
DL-445	Filter Assembly—Radio (P. R. Mallory & Co. Inc., Indianapolis, Ind.)	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 507)	
9-3188-6	Interphone Installation—Station 5D radio crew	1
41-9775	Hook Assembly—Microphone	1
41-1373	Clip—Microphone	1
35D3887	Microphone—(Type T-17) (government furnished)	1
41-7592	Retainer Assembly—Headset jack	1
41-158	Retainer—Interphone jack	1
41-159	Stop—Interphone jack	1
9-3188-2	Cord Assembly—Connector headset radio crew interphone	1
9-3188-3	Plug—Connector headset radio crew interphone (government furnished)	2
9-3188-4	Jack—Connector headset radio crew interphone (government furnished)	1
9-3188-5	Garage—Connector headset radio crew interphone (government furnished)	1
41-1150	Hanger—Headset cords	1
9-3188-1	Box—Jack radio crew interphone (government furnished)	1
BAC548-8	Clamp—Double loop type	1
BAC1602-8	Spacer—No. 8 machine screw	3
6-9333	Interphone Installation—Gunner's	1
41-9775	Hook Assembly—Microphone	1
41-1373	Clip—Microphone	1
35D3887	Microphone—(Type T-17) (government furnished)	1
41-1150	Hanger—Headset cords	1
6-9333-2	Cord Assembly—Connector headset	1
6-9333-3	Plug—Gunner's interphone (government furnished)	1
6-9333-4	Jack—Gunner's interphone (government furnished)	1
6-9333-5	Cordage—Gunner's interphone (government furnished)	1
6-9333-1	Box—Jack interphone (government furnished)	1
41-158	Retainer—Interphone jack	1
41-159	Stop—Interphone jack	1
BAC548-8	Clamp—Double loop type	6
49-2875	Interphone Installation—Radio operator's	1
41-1150	Hanger—Headset cords	1
41-9775	Hook Assembly—Microphone	1
41-1373	Clip—Microphone	1
49-2875-1	Box—Jack radio operator's interphone (government furnished)	1
BAC1602-8	Spacer—No. 8 machine screw	3
49-2875-400	Cord Assembly—Connector headset radio operator's interphone	1
49-2875-401	Plug—Connector headset radio operator's interphone (government furnished)	1
49-2875-402	Jack—Connector headset radio operator's interphone (government furnished)	1
49-2875-403	Cordage—Connector headset radio operator's interphone (government furnished)	1
35D3887	Microphone—Radio operator's interphone (type T-17) (government furnished)	1
BAC548-8	Clamp—Double loop type	1
	(Parts List No. 508)	
8-1293	Interphone Installation—Rear gunner	1
8-1293-1	Lamp—Rear gunner interphone 28V., S.C. (government furnished)	1
1-20535-42	Cord Assembly—Headphone extension	1
1-20535-1	Plug—Headphone extension (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension (type JK-26) (government furnished)	1
1-20535-42A	Cordage—Headphone extension (type CO-119-A) (government furnished)	1
41-9775	Hook Assembly—Microphone	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-1373	Clip—Microphone	1
39B2823-4	Lamp Assembly—Single contact signal	1
8-1293-9	Box Assembly—Jack, rear gunner's phone	1
8-1293-7	Box Assembly—Jack, rear gunner's phone (type BC-366) (H40D2226) (government furnished)	1
35D3887	Microphone—(type T-17)	1
BAC1602-40	Spacer—No. 8 machine screw	2
6-9217	Interphone Installation—Lower gunner	1
6-9217-1	Lamp—Lower gunner (government furnished)	1
1-20535-60	Cord Assembly—Headphone extension	1
1-20535-1	Plug—Headphone extension (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension (type JK-26) (government furnished)	1
1-20535-60A	Cordage—Headphone extension (government furnished)	1
41-1150	Hanger—Headset cords	1
41-9775	Hook Assembly—Microphone	1
41-1373	Clip—Microphone	1
35D3887	Microphone—(type T-17) (government furnished)	1
39B2823-[illegible]	Lamp Assembly—Amber single contact signal	1
36A2212-[illegible]	Nut—Flexible conduit ferrule coupling	1
6-9217-7	Box Assembly—Jack, lower gunner interphone	1
6-9217-6	Box—Jack, lower gunner interphone (government furnished)	1
BAC820-8	Terminal—Electrical lock	1
49-2902	Interphone Installation—Forward gunner's	1
41-9775	Hook Assembly—Microphone	1

(Parts List No. 509)

41-1373	Clip—Microphone	1
41-1150	Hanger—Headset cords	1
41-7592	Retainer Assembly—Headset jack	1
41-158	Retainer—Interphone jack	1
41-159	Stop—Interphone jack	1
35D3887	Microphone—(type T-17) (government furnished)	1
BAC548-8	Clamp—Double loop type	1
49-2902-400	Jack Box—Forward gunner interphone (drawing H40D2226) (government furnished)	1
49-2902-401	Cord Assembly—Forward gunner interphone	1
49-2902-402	Plug—Forward gunner interphone (type PL-55) (government furnished)	1
49-2902-403	Jack—Forward gunner interphone (type JK-26) (government furnished)	1
49-2902-404	Cordage—Forward gunner interphone (type CO-119) (government furnished)	1
59-2916	Interphone Installation—Co-pilot's	1
41-158-1	Retainer—Interphone jack	2
41-159	Stop—Interphone jack	2
41-1150	Hanger—Seatset cords	1
41-9830	Hook Assembly—Microphone	1
41-1373	Clip—Microphone	1
BAC1603-14	Spacer—No. 10 bolt	2
59-2916-2	Jack Box—Co-pilot's interphone (type BC-366) (drawing H40D2226) (government furnished)	1
59-2916-3	Switch Box—Co-pilot's interphone (type BX-345) (drawing H39B2224) (government furnished)	1
1-20535-42	Cord Assembly—Headphone extension	1
1-20535-1	Plug—Headphone extension (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension (type JK-26) (government furnished)	1
1-20535-42A	Cordage—Headphone extension (type CO-119-A) (government furnished)	1
35D3887	Microphone—(Type T-17) (government furnished)	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1602-32	Spacer—No. 8 machine screw	7
59-2916-1	Filter—Radio co-pilot's interphone (type FL-5-B) (drawing H40D5671) (government furnished)	1
BAC1602-40	Spacer—No. 8 machine screw	1
1-18793	Spacer—Micarta	1
1-18793-1	Spacer—Micarta	1
BAC548-8	Clamp—Double loop type	1
9-3362	Interphone Installation—Navigator's	1
41-1150	Hanger—Headset cords	1
35D3887	Microphone—(Type T-17) (government furnished)	1
9-3362-2	Cord Assembly—Navigator's interphone connector headset	1
9-3362-3	Plug—Navigator's interphone (type PL-55) (government furnished)	1
9-3362-4	Jack—Navigator's interphone (type JK-26) (government furnished)	1

(Parts List No. 510)

9-3362-5	Cordage—Navigator's interphone (type CO-119) (government furnished)	1
9-3362-1	Box Jack—(Type BC-366) (government furnished)	1
BAC548-8	Clamp—Double loop type	1
64-1741-500	Interphone Installation—Pilot's	1
41-158-1	Retainer—Interphone jack	3
41-159	Stop—Interphone jack	3
BAC1601-38	Spacer—No. 6 machine screw	2
41-1150	Hanger—Headset cords	1
64-1741-4	Filter—Interphone radio (government furnished)	1
BAC1602-40	Spacer—No. 8 machine screw	1
35D3887	Microphone—(Type T-17) (government furnished)	1
64-1741-1	Jack Box—Pilot's interphone (type BC-366) (government furnished)	1
64-1741-2	Box Switch—Pilot's interphone (government furnished)	1
1-20535-42	Cord Assembly—Headphone extension cord	1
1-20535-1	Plug—Headphone extension cord (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension cord (type JK-26) (government furnished)	1
1-20535-42A	Cordage—Headphone extension cord (type CO-119-A) (government furnished)	1
BAC1602-32	Spacer—No. 8 machine screw	7
1-18793	Spacer—Micarta	1
1-18793-1	Spacer—Micarta	1
BAC1602-40	Spacer—No. 8 machine screw	1
3-14995	Guard Installation—Turret interphone	1
6-8826	Receiver Installation—Liaison	1
1-19965-1-55	Jumper Assembly—Terminal bonding	1
BAC802-2-50	Jumper Assembly—Terminal bonding	1
660-2	Terminal	2
6-8826-1	Mounting—Liaison receiver (type FT-154-B) (government furnished)	1
6-8826-11	Receiver—Liaison (BC-348-B) (H40D3166) (government furnished)	1
21-2363-48-12	Washer—.063 steel	8
9-3612	Receiver Installation—Marker beacon	1
9-3612-3	Receiver—Marker beacon (type BC-341-A) (government furnished)	1
9-3612-1	Mounting—Marker beacon (type FT-161) (government furnished)	1
BAC802-2-50	Jumper Assembly—No. 8-10 terminal bonding	1
660-2	Terminal	2
6-8828	Loop Installation—Radio compass	1
6-8828-1	Loop—Radio compass (government furnished)	1
1-17358	Gasket—Loop antenna	1
BAC204-4S	Bolt—¼-28 drilled head	4

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 511)	
9-3360	Receiver Installation—Radio compass	1
9-3360-1	Receiver—Radio compass (government furnished)	1
9-3360-4	Mount—Radio compass receiver (government furnished)	1
BAC802-2-40	Jumper Assembly—No. 8-10 terminal bonding	1
15-6800	Support Installation—Radio compass receiver	1
6-8830	Support Installation—Radio compass receiver mount	1
BAC1603-26	Spacer—No. 10 bolt	4
BAC1603-29	Spacer—No. 10 bolt	6
15-6800-10	Bracket Assembly—Radio compass receiver support	1
15-6800-11	Bracket Assembly—Radio compass receiver support	1
41-9007-1	Angle—Tube support	2
BAC1603-16	Spacer—No. 10 bolt	2
6-7193	Unit Installation—Transmitter tuning	1
6-7193-1	Unit—Transmitter tuning (type TU-5-A) (government furnished)	1
6-7193-2	Unit—Transmitter tuning (type TU-6-A) (government furnished)	1
6-7193-3	Unit—Transmitter tuning (type TU-7-A) (government furnished)	1
6-7193-4	Unit—Transmitter tuning (type TU-8-A) (government furnished)	1
6-7193-5	Unit—Transmission tuning (type TU-9-A) (government furnished)	1
6-7193-6	Case—Transmitter tuning unit (government furnished)	5
7-1323	Support Installation—Tuning unit	1
7-1323-1	Support Assembly—Tuning unit	1
BAC1246-10S	Plate—Fiber nut	4
7-1323-3	Support Assembly—Tuning unit	1
BAC1246-10S	Plate—Fiber nut	4
BAC1603-18	Spacer—No. 10 bolt	16
BAC1602-12	Spacer—No. 8 machine screw	1
6-7582	Amplifier Installation—Interphone	1
H40D3165	Amplifier—(Type BC-347) (government furnished)	1
6-9330	Amplifier Installation—Throat microphone	1
6-9330-2	Mounting—Throat microphone amplifier (government furnished)	1
6-9330-3	Cap—Socket throat microphone amplifier	1
BAC1603-27	Spacer—No. 10 bolt	1
BAC1802-2-45	Jumper Assembly—Terminal bonding	1
37D6141	Amplifier—Microphone (government furnished)	1
15-8548	Dynamotor Installation—Liaison	1
15-8548-1	Support Assembly—Liaison dynamotor	1
BAC802-2-40	Jumper Assembly—Terminal bonding	1
36B5856	Dynamotor—(Type PE-73-B) (government furnished)	1
6-8522	Indicator Installation—Radio compass	1
6-8522-1	Shaft—Tuning radio compass indicator (government furnished)	1
1-16122	Support—Radio compass control	1
H40B3224	Unit—Control (government furnished)	1
H40B3225	Indicator—Bearing (government furnished)	1
BAC802-2-40	Jumper Assembly—Terminal bonding	1
6-8832	Relay Installation—Radio compass	1
6-8832-1	Relay—Radio compass (government furnished)	1
6-8832-2	Fuse—Radio compass	2
	(Parts List No. 512)	
3-12785	Shield Assembly—Radio compass relay	1
3-12785-1	Box Assembly—Radio compass relay shield	1
41-3864	Spring—Dzus fastener	8
41-9775	Hook Assembly—Microphone	1
41-1373	Clip—Microphone	1
3-12785-3	Cover Assembly—Radio compass relay shield	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-3862	Grommet—Dzus (type 375)	8
21-6744	Fastener—Inspection door	3
41-9638-30	Button—Dzus wing type	8
3-12785-4	Cover—Radio compass relay shield	1
3-13567-8	Chart—Fuse identification	1
1-21376	Filter Assembly—Radio	1
6-7189-19	Transmitter Installation—Liaison	1
BAC802-3-45	Jumper Assembly—Terminal bonding	4
6-7189-1	Mounting—Liaison transmitter (type FT-151-A) (government furnished)	1
6-7189-2	Unit—Tuning liaison transmitter (government furnished)	1
6-7189-6	Plate—Liaison transmitter (government furnished)	1
36D5854	Transmitter—(government furnished)	1
35A2959	Mounting—(Type FT-115-B) (government furnished)	2
BAC1604-12	Spacer—¼ bolt	2
BAC1604-58	Spacer—¼ bolt	2
1-19965-1-40	Jumper Assembly—Terminal bonding	1
9-2715	Support Installation—Transmitter	1
9-2715-1	Support Assembly—Transmitter	1
41-4701	Gusset—Transmitter support	4
41-5773	Gusset—Transmitter support	2
41-5448	Clip—Transmitter support	1L
41-5448-1	Clip—Transmitter support	1R
41-5746-1	Stud—Plate	1
BAC1614-51	Spacer—⅛ rivet	4
21-2363-36-13	Washer—.063 steel	2
BAC1603-12	Spacer—No. 10 bolt	12
56-7583	Shield Installation—Liaison junction	1
56-7583-500	Shield Assembly—Liaison junction	1
56-7583-501	Switch—Liaison junction shield (type C-1B)	1
6-7625	Shield Assembly—Electrical junction	1
6-7625-1	Shield Assembly—Electrical junction	1
BAC1247-8D	Angle—Nut plate	4
BAC1247-8S	Angle—Nut plate	2
6-7625-3	Cover—Electrical junction shield	1
BAC1461	Screw—No. 8-32 non-losable	6
21-8891-14	Panel Assembly—Connector	1
21-8891-14A	Panel—Connector	1
41-158	Retainer—Interphone jack	1
41-159	Stop—Interphone jack	1
21-7401	Bus—Connector panel	1
1-16369	Plate—Name	1
21-8627-14	Insulator—Junction box	1
6-9694-2	Card—Junction identification	1
	(Parts List No. 513)	
BAC1603-24	Spacer—No. 10 bolt	4
49-3646	Shield Installation—Forward radio junction	1
49-3646-400	Bracket—Forward radio junction shield (government furnished)	2
49-3646-401	Resistor—Forward radio junction shield (government furnished)	1
9-3646-2	Insulator—Forward radio junction shield	1
9-3646-3	Relay—Microphone forward radio junction shield	2
9-2646-4	Resistor—Forward radio junction shield (IRC type AB) (government furnished)	1
6-9341	Panel Assembly—Forward radio junction	1
6-9341-1	Panel—Forward radio junction	1
21-7401	Bus—Connector panel	5
6-9354	Shield Assembly—Forward radio junction	1
6-9354-1	Box Assembly—Forward radio junction	1
41-3864	Spring—Dzus fastener	1
6-9354-2	Box—Forward radio junction shield	1
6-9354-3	Cover Assembly—Forward radio junction shield	1
6-9354-5	Cover—Forward radio junction shield	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-3862	Grommet—Dzus (type 375)	4
41-9638-30	Fastener—Dzus wing type	4
1-18585	Shim—Microphone relay	2
6-9694-1	Card—Junction identification	1
3-12787	Coupling Installation—Radio compass	1
3-12787-1	Coupling—Radio compass (type MC-136) (government furnished)	1
6-9709-1	Plug Assembly—Radio connector	1
6-9709-2	Plug—Radio connector (government furnished)	1
1-20245	Support—Clamp plug connector	1
6-9709-3	Plug Assembly—Radio connector	1
6-9709-4	Plug—Radio connector (government furnished)	1
1-20245	Support—Clamp plug connector	1
6-9709-5	Plug Assembly—Radio connector	1
6-9709-6	Plug—Radio connector (government furnished)	1
1-20245	Support—Clamp plug connector	1
6-9709-7	Plug Assembly—Radio connector	2
6-9709-8	Plug—Radio connector (type PL-Q-61) (government furnished)	2
1-20245	Support—Clamp plug connector	2
6-9709-9	Plug Assembly—Radio connector	2
6-9709-10	Plug—Radio connector (type PL-Q-64) (government furnished)	2
1-20245	Support—Clamp plug connector	2
6-9709-11	Plug Assembly—Radio connector	1
6-9709-12	Plug—Radio connector (government furnished)	1
1-20245	Support—Clamp plug connector	1
6-9709-17	Plug Assembly—Radio connector	1
6-9709-18	Plug—Radio connector (type PL-Q-103) (government furnished)	1
1-20245	Support—Clamp plug connector	1
6-9709-19	Plug Assembly—Radio connector	1
6-9709-20	Plug—Radio connector (type PL-P-61) (government furnished)	1
1-20245	Support—Clamp plug connector	1
59-2712	Antenna Installation—Trailing	1

(Parts List No. 514)

Dash number parts, shown on 59-2712 drawing are represented by dash numbers of 49-2712 and 59-2712.

59-2712-500	Weight—Trailing antenna (government furnished)	1
3-12470	Cover Installation—Fair-lead	1
3-12470-1	Cover Assembly—Fair-lead	1
3-12474	Fair-lead Assembly—Antenna	1
3-12474-1	Fair-lead Assembly—Antenna	1
3-12474-2	Fair-lead—Antenna	1
3-12474-4	Fair-lead—Antenna	1
3-14970	Pulley Assembly—Antenna	1
1-21951	Band—Antenna pulley	1
1-21952	Pulley—Antenna	1
6-7281	Bracket Assembly—Antenna reel support	1
6-7281-1	Bracket—Antenna reel support	1
59-2712-501	Wire—Trailing antenna (government furnished)	1
37G6167	Reel—Antenna (government furnished)	1
49-2712-400	Fair-lead—Trailing antenna upper (government furnished)	1
49-2712-401	Fairlead—Trailing antenna lower (government furnished)	1
BAC1603-8	Spacer—No. 10 bolt	8
1-20536-100	Cord Assembly—Turret plug-in	1
1-20536-1	Plug—Turret cord (type PL-68) (government furnished)	1
1-20536-100A	Cord—Turret plug-in (type CO-122-A) (government furnished)	1
1-20536-160	Cord Assembly—Turret plug-in	1
1-20536-1	Plug—Turret cord (type PL-68) (government furnished)	1
1-20536-160A	Cord—Turret plug-in (type CO-122-A) (government furnished)	1
1-20537-100	Cord Assembly—Turret plug-in	1
1-20537-1	Plug—Turret cord (type PL-55) (government furnished)	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-20537-100A	Cord—Turret plug-in (type CO-119-A) (government furnished)	1
1-20537-160	Cord Assembly—Turret plug-in	1
1-20537-1	Plug—Turret cord (type PL-55) (government furnished)	1
1-20537-160A	Cord—Turret plug-in (type CO-119-A) (government furnished)	1
1-20538-30	Cord Assembly—Turret headset	2
1-20538-1	Jack—Turret headset cord (type JK-46) (government furnished)	2
1-20538-30A	Cord—Turret headset (type CO-119-A) (government furnished)	2
1-20539-30	Cord Assembly—Turret microphone	2
1-20539-30-1	Jack—Turret headset cord (type JK-48) (government furnished)	2
1-20539-30A	Cord—Turret headset (type CO-119-A) (government furnished)	2
41-7511	Key Installation—Liaison	1
41-7511-2	Key Assembly—Liaison (type J-37) (government furnished)	1
21-9753	Tag Installation—Electric wire identification	508
3-14205	Guard Installation—Wire form	1
BAC1603-8	Spacer—No. 10 bolt	5

(Parts List No. 515)

3-14219	Guard Installation—Wire form	1
BAC1603-40	Spacer—No. 10 bolt	4
43-14203	Switch Installation—Liaison transmitter	1

Dash number parts, shown on 43-14203 drawing are represented by dash numbers of 3-14203 and 43-14203.

1-20230	Name Plate—Liaison transmitter	1
AN3015	Switch Assembly—Toggle (type B-5A)	1
1-20247	Support Assembly—Clamp—plug connection	1
1-20245-1	Support—Clamp—plug connection	1
36A2212-6	Nut—Coupling	1
36A2213-6	Ferrule	1
1-23586	Clamp Assembly—Support plug connection	1
1-23587	Support—Plug connection clamp	1
BAC761-5	Coupling Nut—Junction box	1
BAC764-5B	Ferrule—Flexible conduit	1
21-4585-42-12	Clamp—Tab square tube	1
BAC538-4	Clamp—Loop type cushioned	1
BAC538-6	Clamp—Loop type cushioned	9
BAC538-8	Clamp—Loop type cushioned	1
BAC540-5	Clamp—Loop type cushioned	8
BAC540-6	Clamp—Loop type cushioned	1
BAC540-7	Clamp—Loop type cushioned	16
BAC540-10	Clamp—Loop type cushioned	5
BAC538-10	Clamp—Loop type cushioned	1
BAC821-120-8	Terminal—Electrical solderless	20
BAC821-118-8	Terminal—Electrical solderless	10
BAC821-116-8	Terminal—Electrical solderless	10
BAC821-12	Terminal—Electrical solderless	6
BAC821-118-10	Terminal—Electrical solderless	40
BAC821-116-10	Terminal—Electrical solderless	10
BAC821-120	Terminal—Electrical solderless	80
BAC821-114	Terminal—Electrical solderless	6
BAC821-6	Terminal—Electrical solderless	6
BAC823-18	Electrical Connectors—Two-way	2
BAC823-20	Electrical Connectors—Two-way	8
BAC1603-8	Spacer—No. 10 bolt	5
BAC1603-32	Spacer—No. 10 bolt	1
BAC1603-48	Spacer—No. 10 bolt	1

(Parts List No. 516)

15-7931	Equipment Installation—Radio (AC41-2543 to 41-2669) (127)	1

Radio equipment installation 15-7931 is used on airplanes 41-2543 to 41-2669 inclusive.

15-7931-1	Transmitter—Radio equipment (type BC-457-A) (drawing H41G5076) (government furnished)	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7931-2	Transmitter—Radio equipment (type BC-457-A) (drawing H41G5076) (government furnished)	1
15-7931-3	Rack—Radio equipment (type FT-226-A) (drawing H41G5076) (government furnished)	1
15-7931-4	Mounting—Radio equipment (type FT-227-A) (drawing H41G5076) (government furnished)	1
15-7931-16	Loop Connector—Radio equipment (government furnished)	1
15-7931-17	Receiver—Radio equipment (type BC-453-A) (drawing H41G5077) (government furnished)	1
15-7931-18	Receiver—Radio equipment (type BC-454-A) (drawing H41G5077) (government furnished)	1
15-7931-19	Receiver—Radio equipment (type BC-455-A) (drawing H41G5077) (government furnished)	1
15-7931-20	Dynamotor—Command radio equipment (type DM-33-A) (drawing H41G5076) (government furnished)	1
15-7931-21	Rack—Radio equipment (type FT-220-A) (drawing H41G5077) (government furnished)	1
15-7931-22	Mounting—Radio equipment (type FT-229-A) (drawing H41G5076) (government furnished)	1
15-7931-23	Relay—Antenna—radio equipment (type BC-H42A) (drawing H41G5076) (government furnished)	1
15-7931-24	Mounting—Radio equipment (type FT-229-A) (drawing H41G5076) (government furnished)	1
15-7931-25	Modulator—Command—radio equipment (type BC-456-A) (drawing H41G5076) (government furnished)	1
15-7931-26	Dynamotor—Command—radio equipment (type DM-33A) (drawing H41G5076) (government furnished)	1
15-7931-27	Mounting—Radio equipment (type FT-229-A) (drawing H41G5076) (government furnished)	1
15-7931-28	Shaft—Tuning—radio equipment (type MC124) (drawing SC-D-2035) (government furnished)	1
15-7931-29	Shaft—Tuning—radio equipment (type MC124) (drawing SC-D-2035) (government furnished)	1
15-7931-30	Shaft—Tuning—radio equipment (type MC-215) (drawing H41D5075) (government furnished)	1
15-7931-31	Shaft—Tuning—radio equipment (type MC-124) (drawing SC-D-2035) (government furnished)	1
15-7931-39	Plug—Radio equipment (type PL-122) (government furnished)	1
15-7931-40	Plug—Radio equipment (type PL-118) (government furnished)	2
15-7931-41	Plug—Radio equipment (type PL-112) (government furnished)	1
15-7931-42	Plug—Radio equipment (type PL-152) (government furnished)	6
15-7931-43	Plug—Radio equipment (type PL-153) (government furnished)	2
15-7931-44	Plug—Radio equipment (type PL-154) (government furnished)	2
15-7931-45	Plug—Radio equipment (type PL-151) (government furnished)	2
15-7931-46	Plug—Radio equipment (type PL-148) (government furnished)	1
15-7931-47	Plug—Radio equipment (type PL-156) (government furnished)	1
15-7931-48	Plug—Radio equipment (type PL-156) (government furnished)	2
	(Parts List No. 517)	
15-7931-50	Microphone—Throat—radio equipment (government furnished)	9
15-7931-57	Shaft—Tuning—radio equipment (type MC-215) (drawing H41D5075) (government furnished)	1
15-7931-58	Shaft—Tuning—radio equipment (type MC-215) (drawing H41D5075) (government furnished)	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7931-59	Coupling—Right angle—radio equipment (type MC-136) (drawing SC-B-27A) (government furnished)	1
15-7931-60	Plug—Radio equipment (type PL-108) (government furnished)	1
15-7931-36	Wire—Jumper on plugs—radio equipment	1
15-7931-32	Conduit Assembly—Flexible—radio equipment	1
15-7931-33	Conduit—Flexible—radio equipment	1
15-7931-34	Plug—With jacket (type PL-P-59) (government furnished)	1
15-7931-35	Plug—With jacket (type PL-Q-59) (government furnished)	1
15-7934	Antenna Installation—Radio	1
15-7934-2	Link—Radio antenna (NAF-1086-1)	1
15-7934-15	Wire—Radio antenna	1
15-7934-29	Wire—Radio antenna	1
15-7934-3	Insulator—Radio antenna (type IN-88) (government furnished)	4
15-7934-4	Wire—Double strand—radio antenna (government furnished)	2
15-7934-5	Wire—Lead-in—radio antenna (government furnished)	1
15-7934-6	Wire—Lead-in—radio antenna (government furnished)	1
15-7934-7	Insulator—Bead—radio antenna (government furnished)	364
15-7934-8	Wire—To receiver—radio antenna (government furnished)	1
15-7934-9	Wire—To transmitter—radio antenna (government furnished	1
15-7934-10	Wire—Antenna lead—radio antenna (government furnished)	2
15-7934-11	Wire—Liaison antenna—radio (government furnished)	1
15-7934-12	Wire—Lead-in—radio antenna (government furnished)	1
15-7934-14	Wire—To trailing antenna—radio (government furnished)	1
15-7934-27	Wire—Double strand—radio antenna (government furnished)	1
15-7934-28	Wire—Switch to antenna tuner—radio antenna (government furnished)	1
15-7934-31	Wire—Radio antenna (government furnished)	1
15-7934-32	Wire—Radio antenna (government furnished)	1
15-7934-33	Wire—Radio antenna (government furnished)	1
15-7934-34	Wire—Radio antenna (government furnished)	1
1-17633	Insulator Installation—Receiver lead-in	1
1-17633-1	Insulator Installation—Receiver lead-in	1
1-17633-2	Insulator Installation—Receiver lead-in	1
1-17633-4	Insulator Installation—Receiver lead-in	1
1-17633-5	Insulator Installation—Receiver lead-in	1
41-445-0-6	Spacer—No. 10 bolt	5
35A2276	Insulator—(Type IN-81) (government furnished)	5
3-13944	Insulator Installation—Command lead-in	1
3-13944-1	Escutcheon—Command lead-in	1
1-18465	Insulator—Lead-in	1
1-18718	Washer—Insulator seal	1
1-18720-40-12	Stud—Brass	1
41-7171-80-112	Washer—1/16 neoprene	1
51-315-48-16	Washer—1/16 lead	2
35A2282	Insulator—(Type IN-84) (government furnished	1
	(Parts List No. 518)	
1-21477	Insulator Installation—Receiver lead-in	1
35A2276	Insulator—(Type IN-81) (government furnished)	1
41-445-0-6	Spacer—No. 10 bolt	1
1-23553	Insulator Installation—Command transmitter	1
41-445-0-6	Spacer—No. 10 bolt	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
35A2276	Insulator—(Type IN-81) (government furnished)	1
9-3765	Antenna Installation—Marker beacon	1
9-3765-1	Wire Assembly—Marker beacon antenna	1
9-3765-2	Wire—Marker beacon antenna (government furnished)	1
9-3765-3	Wire—Marker beacon antenna (government furnished)	1
9-3765-4	Wire—Marker beacon antenna (government furnished)	1
9-3765-5	Insulator—Marker beacon antenna (government furnished)	2
9-3765-6	Wire—Marker beacon antenna (government furnished)	2
9-3765-12	Terminal Assembly—Marker beacon antenna (government furnished)	1
9-3765-7	Cable Assembly—Marker beacon antenna	1
9-3765-8	Cable—Marker beacon antenna (government furnished)	1
9-3765-9	Coupling Assembly—Marker beacon antenna (government furnished)	1
9-3765-10	Cable—Marker beacon antenna (government furnished)	1
9-3765-11	Fitting Assembly—Marker beacon antenna (government furnished)	1
9-3765-13	Terminal—Marker beacon antenna (government furnished)	1
9-3765-14	Washer—Plain—marker beacon antenna (government furnished)	2
9-3765-15	Nut—Plain—marker beacon antenna (government furnished)	2
3-13564	Insulator Installation—Liaison antenna lead-in	1
41-8420-77-57	Trim—Escutcheon	1
35A2282	Insulator—(Type IN-84) (government furnished)	1
1-18465	Insulator—Lead-in	1
1-18718	Washer—Insulator seal	1
1-18720-40-12	Stud—Brass	1
51-315-48-16	Washer—1/16 lead	2
3-13564-2	Link Assembly—Liaison antenna lead-in	1
1-16064	Bushing—Antenna connection	1
1-16071-1	Link—Antenna connection	1
6-10446	Switch Installation—Antenna	1
1-21915	Switch Assembly—Antenna change-over	1
1-21434	Plate Assembly—Antenna switch	1
1-21434-1	Plate—Antenna switch	1
BAC1603-16	Spacer—No. 10 bolt	4
41-8542	Insulator Installation—Trailing antenna lead-in	1
35A2277	Insulator—(Type IN-82) (government furnished)	1
3-12778	Insulator Installation—Liaison antenna	1
35A2276	Insulator—(Type IN-81) (government furnished)	2

(Parts List No. 519)

14-2345	Lead Installation—Whip antenna	1
14-2345-1	Conduit Assembly—Whip antenna lead	1
14-2345-4	Conduit—Whip antenna lead-in	1
14-2345-3	Wire—Whip antenna lead-in (government furnished)	1
14-2345-5	Tube—Whip antenna lead-in	1
14-2345-6	Tube—Whip antenna lead-in	1
1-19086	Clamp Assembly—Antenna wire	1
1-19086-1	Bushing—Antenna wire clamp	1
1-19086-3	Clamp Assembly—Antenna wire	1
1-19086-2	Bushing—Antenna wire clamp	1
1-19089	Cap—Insulator—Antenna lead-in	2
1-19088	Insulator—Antenna lead-in disc	2
1-18069	Bus—Connector	1
14-2345-7	Wire—Whip antenna lead-in	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-19001-33	Fair-lead Assembly—1 hole	1
1-19001-32	Fair-lead—1 hole	2
BAC1603-32	Spacer—No. 10 bolt	1
BAC1603-56	Spacer—No. 10 bolt	1
9-3713	Whip Installation—Antenna	1
3-12479	Antenna Whip—Radio compass	1
3-14988	Seal Installation—Whip antenna	1
3-14988-1	Tube—Whip antenna	1
1-20344	Seal—Whip antenna	1
49-3188	Interphone Installation—Radio crew—station 5D	1
1-23534	Microphone Assembly—T-30 (drawing H41G-10067) (government furnished)	1
1-21386	Cord Assembly—Throat microphone (government furnished)	1
41-7592	Retainer Assembly—Headset jack	1
41-7592-1	Plate—Headset jack retainer	1
41-158	Retainer—Interphone jack	1
41-159	Stop—Interphone jack	1
1-20535-113	Cord Assembly—Headphone extension (drawing 36B4044)	1
1-20535-1	Plug—Headphone extension cord (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension cord (type JK-26) (government furnished)	1
1-20535-113A	Cord—Headphone extension cord (OC-119-A) (government furnished)	1
41-1150	Hanger—Headset cords	1
41-1150-1	Hanger—Headset cords	1
9-3188-1	Box—Jack radio crew interphone (BC366) (drawing H40D226) (government furnished)	1
BAC548-8	Clamp—Double loop type	1
BAC1602-8	Spacer—No. 8 machine screw	3
46-9333	Interphone Installation—Gunner's	1
1-23534	Microphone Assembly—(T-30) (drawing H41-G10067) (government furnished)	1
BAC548-8	Clamp—Double loop type	6
41-1150	Hanger—headset cords	1
1-21386	Cord Assembly—Throat microphone type CD-318 (drawing H42G2346) (government furnished)	1
1-20535-60	Cord Assembly—Headphone extension (drawing 36B4044)	1

(Parts List No. 520)

1-20535-1	Plug—Headphone extension cord (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension cord (type JK-26) (government furnished)	1
1-20535-60A	Cord—Headphone extension cord (type CO-119-A) (government furnished)	1
46-9333-400	Box Assembly—Jack	1
6-9333-1	Jack Box Assembly—BC366—(government furnished)	1
41-159	Stop—Interphone jack	1
41-158	Retainer—Interphone jack	1
59-2875	Interphone Installation—Radio operator's	1
41-1150	Hanger—Headset cords	1
41-1150-1	Hanger—Headset cords	1
1-21386	Cord Assembly—Throat microphone (No. H42G2346) (government furnished)	1
1-20535-60	Cord Assembly—Headphone extension (drawing 36B4044)	1
1-20535-1	Plug—Headphone extension cord (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension cord (type JK-26) (government furnished)	1
1-20535-60A	Cord—Headphone extension (type CO-119-A) (government furnished)	1
49-2875-1	Box—Jack—interphone (type BC-366) (government furnished)	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1602-8	Spacer—No. 8 machine screw	3
1-23534	Microphone Assembly—T-30 (drawing H41-G10067) (government furnished)	1
BAC548-8	Clamp—Double loop type	1
48-1293	Interphone Installation—Rear gunner's	1
8-1293-1	Lamp—Rear gunner's interphone (282) (government furnished)	1
8-1293-9	Box Assembly—Rear gunner's interphone (type BC-366) (drawing H40D2226)	1
8-1293-7	Box Assembly—Jack—rear gunner's phone (drawing H40D2226) (government furnished)	1
8-1293-8	Angle—Rear gunner's phone	1
1-20535-42	Cord Assembly—Headphone extension (drawing 36B4044)	1
1-20535-1	Plug—Headphone extension cord (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension cord (type JK-26) (government furnished)	1
1-20535-42A	Cordage—Headphone extension cord (type CO-119-A) (government furnished)	1
1-23534	Microphone Assembly—(T-30) (drawing H41-G10067) (government furnished)	1
1-21386	Cord Assembly—Throat microphone (type CD-318) (drawing H42G2346) (government furnished)	1
41-1150-1	Hanger—Headset cords	1
BAC548-8	Clamp—Double loop type	1
BAC1602-40	Spacer—No. 8 machine screw	2
39B2823-4	Lamp Assembly—Signal—single contact	1
46-9217	Interphone Installation—Lower gunner's	1
6-9217-1	Lamp—Lower gunner's interphone (government furnished)	1

(Parts List No. 521)

1-20535-60	Cord Assembly—Headphone extension (drawing 36B4044)	1
1-20535-1	Plug—Headphone extension cord (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension cord (type JK-26) (government furnished)	1
1-20535-60A	Cord—Headphone extension cord (type CO-119-A) (government furnished)	1
41-1150	Hanger—Headset cords	1
41-1150-1	Hanger—Headset cords	1
BAC548-8	Clamp—Double loop type	1
1-21386	Cord Assembly—Throat microphone (drawing H42G2346) (type CD-318) (government furnished)	1
6-9217-7	Box Assembly—Jack	1
6-9217-6	Box—Jack (BC-366) (drawing H40D2226) (government furnished)	1
1-23534	Microphone Assembly—(Type T-30) (drawing H41G10067) (government furnished)	1
39B2823-4	Lamp Assembly—Signal—single contact	1
36A2212-1	Nut—Flexible conduit ferrule coupling	1
59-2902	Interphone Installation—Forward gunner's	1
1-23534	Microphone Assembly—(T-30) (drawing H41-G10067) (government furnished)	1
41-1150	Hanger—Headset cords	1
41-1150-1	Hanger—Headset cords	1
41-7592	Retainer Assembly—Headset jack	1
41-158	Retainer—Interphone jack	1
41-159	Stop—Interphone jack	1
1-21386	Cord Assembly—Throat microphone (H42G2346) (type CD-318) (government furnished)	1
BAC548-8	Clamp—Double loop type	1
49-2902-400	Jack Box—Interphone (type BC-366) (government furnished)	1
59-2916-505	Interphone Installation—Co-pilot's	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-158-1	Retainer—Interphone jack	2
41-159	Stop—Interphone jack	2
41-1150	Hanger—Headset cords	1
59-2916-2	Jack Box—Interphone co-pilot's (type BC-366) (drawing H40D226) (government furnished)	1
59-2916-3	Box—Switch—(type BC-345) drawing 39B22247) (government furnished)	1
1-20535-42	Cord Assembly—Interphone co-pilot's	1
1-20535-1	Plug—Interphone co-pilot's (type PL-55) (government furnished)	1
1-20535-2	Jack—Interphone co-pilot's (type JK-26) (government furnished)	1
1-20535-42A	Cordage—Interphone co-pilot's (type CO-119-A) (government furnished)	1
1-23534	Microphone Assembly—(Drawing H41G10067) (type T-30) (government furnished)	1
59-2916-1	Filter—Interphone co-pilot's (drawing H40-D5671) (type FL-5-B) (government furnished)	1
BAC1602-40	Spacer—No. 8 machine screw	1

(Parts List No. 522)

BAC1602-32	Spacer—No. 8 machine screw	7
1-18793	Spacer—Micarta	1
1-18793-1	Spacer—Micarta	1
BAC548-8	Clamp—Double loop type	1
49-3362	Interphone Installation—Navigator's	1
41-1150	Hanger—Headset cords	1
1-23534	Microphone Assembly—(T-30) (drawing H41-C10067) (government furnished)	1
1-20535-60	Cord Assembly—Headphone extension (drawing 36B4044)	1
1-20535-1	Plug—Headphone extension (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension (type JK-26) (government furnished)	1
1-20535-60A	Cordage—Headphone extension (type CO-119-A) (government furnished)	1
9-3362-1	Box—Jack (type BC-366) (government furnished)	1
1-21386	Cord Assembly—Throat microphone (CD-318) (drawing H42G2346) (government furnished)	1
BAC548-8	Clamp—Double loop type	1
3-14995	Guard Installation—Turret interphone	1
3-14995-1	Channel—Turret interphone guard	1
6-9708	Dynamotor Installation—Interphone	1
6-9708-1	Bracket—Interphone dynamotor	1
6-9708-2	Bracket—Interphone dynamotor	1
6-9708-3	Dynamotor—Interphone dynamotor (type PE-86) (drawing H41D3926) (government furnished)	1
64-1741-506	Interphone Installation—Pilot's	1
41-158-1	Retainer—Interphone jack	2
41-159	Stop—Interphone jack	2
41-1150	Hanger—Headset cords	1
64-1741-4	Filter—Interphone radio (type FL-5-B) (drawing H40D5671) (government furnished)	1
BAC1602-40	Spacer—No. 8 machine screw	1
1-23534	Microphone Assembly—(T-30) (drawing H41-G10067) (government furnished)	1
64-1741-1	Box—Jack—Interphone pilot's (type BC-366) (drawing H40D2226) (government furnished)	1
64-1741-2	Box—Switch—Interphone pilot's (type BC-345) (drawing H39B2224) (government furnished)	1
1-20535-48	Cord Assembly—Headphone extension cord (drawing 36B4044)	1
1-20535-1	Plug—Headphone extension cord (type PL-55) (government furnished)	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-20535-2	Jack—Headphone extension cord (type JK-26) (government furnished)	1
1-20535-48A	Cord—Headphone extension cord (type CO-119-A) (government furnished)	1
BAC1602-32	Spacer—No. 8 machine screw	7
1-18793	Spacer—Micarta	1
1-18793-1	Spacer—Micarta	1
BAC548-8	Clamp—Double loop type	1
	(Parts List No. 523)	
6-9705	Loop Installation—Radio compass	1
6-9705-2	Loop Installation—Radio compass	1
9-3360-3	Receiver Installation—Radio compass	1
9-3360-4	Mount—Radio compass receiver (type 5T-213-A) (government furnished)	1
9-3360-2	Radio Compass Unit—Receiver (BC-433-A) (drawing 41D7017) (government furnished)	1
BAC802-2-55	Jumper Assembly—Terminal bonding	1
15-6800	Support Installation—Radio compass receiver	1
6-8830	Panel Assembly—Radio compass receiver mount	1
6-8830-1	Panel—Radio compass receiver mount	1
6-8830-2	Angle—Radio compass receiver panel	2
BAC1603-28	Spacer—No. 10 bolt	4
BAC1603-29	Spacer—No. 10 bolt	6
15-6800-10	Bracket Assembly—Radio compass receiver support	1
41-9007-1	Angle—Tube support	1
BAC1603-16	Spacer—No. 10 bolt	1
15-6800-11	Bracket Assembly—Radio compass receiver support	1
41-9007-1	Angle—Tube support	1
BAC1603-16	Spacer—No. 10 bolt	1
6-7193	Unit Installation—Transmission tuning	1
6-7193-1	Unit—Tuning transmission (type TU-5-A) (government furnished)	1
6-7193-2	Unit—Tuning transmission (type TU-6-A) (government furnished)	1
6-7193-3	Unit—Tuning transmission (type TU-7-A) (government furnished)	1
6-7193-4	Unit—Tuning transmission (type TU-8-A) (government furnished)	1
6-7193-5	Unit—Tuning transmission (type TU-9-A) (government furnished)	1
6-7193-6	Cass—Tuning transmission (type C5-48) (government furnished)	5
7-1323	Support Installation—Tuning unit	1
7-1323-1	Support Assembly—Tuning unit	1
7-1323-2	Channel—Tuning unit support	1
BAC1246-10S	Plate—Fiber nut	4
7-1323-3	Support Assembly—Tuning unit	1
7-1323-4	Channel—Tuning unit support	1
BAC1246-10S	Plate—Fiber nut	4
BAC1603-18	Spacer—No. 10 bolt	16
BAC1602-12	Spacer—No. 8 machine screw	1
6-7582	Amplifier Installation—Interphone	1
H40D3165	Amplifier—Interphone (type BC-347) (government furnished)	1
15-8548	Dynamotor Installation—Liaison	1
15-8548-1	Support Assembly—Liaison Dynamotor	1
BAC802-2-40	Jumper Assembly—Terminal bonding	1
36B586	Dynamotor—(Type PE-73-B)	1
46-8522	Indicator Installation—Radio compass	1
46-8522-400	Bearing Indicator—Radio compass (drawing H41D7020) (government furnished)	1
BAC802-2-40	Jumper Assembly—Terminal bonding	1
	(Parts List No. 524)	
6-8826	Receiver Installation—Liaison	1
1-19965-1-55	Jumper Assembly—Terminal bonding	1
BAC802-2-50	Jumper Assembly—Terminal bonding	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-8826-1	Mounting—(Type FT-154-B) (government furnished)	1
6-8826-11	Receiver—Liaison (government furnished)	1
21-2363-48-12	Washer—.063 steel	5
9-3612	Receiver Installation—Marker beacon	1
9-3612-3	Receiver—Marker beacon (type BC-341-A) (government furnished)	1
9-3612-1	Mounting—Marker beacon (type FT-161) (government furnished)	1
BAC802-2-50	Jumper Assembly—No. 8-10 bonding terminal	1
46-8832	Relay Installation—Radio compass	1
46-8832-400	Relay—Radio compass (type BK-22-A) (government furnished)	1
1-23528	Instruction Plate—Radio compass (government furnished)	1
BAC776-3-5	Fuse—Radio compass—5 ampere (1 active—1 spare)	2
BAC776-3-2	Fuse—Radio compass relay	2
43-12785	Shield Assembly—Radio compartment relay	1
43-12785-1	Box Assembly—Radio compartment relay shield	1
41-3864	Spring—Dzus fastener	8
43-12785-2	Box—Radio compartment relay shield	1
43-12785-400	Cover Assembly—Radio compartment relay shield	1
41-3862	Grommet—Dzus (type 375)	8
21-6744	Fastener—Inspection door	3
41-9638-30	Button—Dzus wing type (AW-5-30)	8
43-12785-4	Cover—Rod lamp relay shield	1
BAC775-3	Clip—Electrical fuse	4
3-14216-2	Fuse—Chart	1
BAC538-10	Clamp—Loop type cushioned	1
BAC538-10-12	Clamp—Loop type cushioned	1
46-8833	Control Installation—Radio compass	1
46-8833-400	Compass—Radio control box (drawing H40-D3229) (government furnished)	1
1-21921	Meter Assembly—Frequency BC-221-A (drawing H39B4061) (government furnished)	1
1-21922	Shaft Assembly—Tuning flexible (Bendix Radio Corp.) (drawing A15410) (government furnished)	1
6-7189-19	Transmitter Installation—Liaison	1
BAC802-3-45	Jumper Assembly—Terminal bonding	4
6-7189-1	Mounting—Liaison transmitter (type FT-151-A) (government furnished)	1
6-7189-2	Unit—Tuning—liaison transmitter (type TU-10-A) (government furnished)	1
6-7189-6	Plate—Tuning—liaison transmitter (type NC-206) (government furnished)	1
36D5854	Transmitter—(BC-191-A) (government furnished)	1
35A2959	Mounting—Transmitter (Type FT-115) (government furnished)	2
BAC1604-12	Spacer—¼ bolt	2
BAC1604-58	Spacer—¼ bolt	2
	(Parts List No. 525)	
1-19965-1-40	Jumper Assembly—Terminal bonding	1
9-2715	Support Installation—Transmitter	1
9-2715-1	Support Assembly—Transmitter	1
41-4701	Gusset—Transmitter support	4
41-5773	Gusset—Transmitter support	2
41-5448	Clip—Transmitter support	1L
41-5448-1	Clip—Transmitter support	1R
41-5746-1	Stud—Plate	1
BAC1614-51	Spacer—⅛ rivet	4
21-2363-36-13	Washer—.063 steel	2
BAC1603-12	Spacer—No. 10 bolt	12
56-7583	Shield Installation—Liaison junction	1
56-7583-500	Shield Assembly—Liaison junction	1
56-7583-501	Switch—Liaison junction (type C-1B)	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-7625	Shield Assembly—Electrical junction	1
6-7625-1	Shield Assembly—Electrical junction	1
6-7625-2	Box—Weld—electrical junction shield	1
BAC1247-8D	Angle—Nut plate	6
6-7625-3	Cover—Electrical junction shield	1
BAC1461	Screw—8-32 non-losable	6
21-8891-14	Panel Assembly—Connector	1
21-8891-14A	Panel—Connector	1
41-158	Retainer—Interphone jack	1
41-159	Stop—Interphone jack	1
21-7401	Bus—Connector panel	1
1-16369	Plate—Name	1
21-8627-14	Insulator—Junction box	1
BAC1603-24	Spacer—No. 10 bolt	4
6-9696-2	Card—Junction identification	1
9-3646	Shield Installation—Forward radio junction	1
9-3646-2	Insulator—Forward radio junction shield	1
9-3646-3	Relay—Microphone—Forward radio junction shield	2
46-9341	Panel Assembly—Forward radio junction	1
6-9341-1	Panel—Laminated phenolic—forward radio junction	1
21-7401	Bus—Connector panel	2
6-9696-1	Card—Junction identification	1
6-9354	Shield Assembly—Forward radio junction	1
6-9354-1	Box Assembly—Forward radio junction shield	1
41-3864	Spring—Dzus fastener	1
6-9354-2	Box—Forward radio junction shield	1
6-9354-3	Cover Assembly—Forward radio junction shield	1
6-9354-5	Cover—Forward radio junction shield	1
41-3862	Grommet—Dzus (type 375)	4
41-9638-30	Button—Dzus wing type	4
1-18585	Shim—Microphone relay	2
3-12787	Coupling Installation—Radio compass	1
3-12787-1	Coupling—Radio compass (type MC-136) (drawing H40A3230) (government furnished)	1
6-9709-1	Plug Assembly—Radio connector	1
6-9709-2	Plug with Jacket—Radio connector (government furnished)	1
1-20245	Support—Clamp—plug connection	1
	(Parts List No. 526)	
6-9709-9	Plug Assembly—Radio connector	1
6-9709-10	Plug with Jacket—Radio connector (type PL-Q-64) (government furnished)	1
1-20245	Support—Clamp—plug connection	1
6-9709-17	Plug Assembly—Radio connector	1
6-9709-18	Plug with Jacket—Radio connector (type PL-Q-103) (government furnished)	1
1-20245	Support—Clamp—plug connection	1
6-9709-19	Plug Assembly—Radio connector	1
6-9709-20	Plug with Jacket—Radio connector (type PL-P-61) (government furnished)	1
1-20245	Support—Clamp—plug connection	1
59-2712	Antenna Installation—Trailing	1
	Dash number parts, shown on 59-2712 drawing are represented by dash numbers of 59-2712 and 49-2712.	
59-2712-501	Wire—Trailing antenna (government furnished)	1
3-12470	Cover Installation—Fair-lead	1
3-12470-1	Cover Assembly—Fair-lead	1
3-12474	Fair-lead Assembly—Antenna	1
3-12474-1	Fair-lead Assembly—Antenna	1
3-12474-2	Fair-lead—Antenna	1
3-12474-4	Fair-lead—Antenna	1
3-14970	Pulley Assembly—Antenna	1
1-21951	Band—Antenna pulley	1
1-21952	Pulley—Antenna	1
36G6167	Reel—Antenna (government furnished)	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
59-2712-500	Weight—Trailing antenna (government furnished)	1
49-2712-400	Fairlead—Trailing antenna upper (government furnished)	1
49-2712-401	Fair-lead—Trailing antenna lower (government furnished)	1
BAC1603-8	Spacer—No. 10 bolt	8
41-7511	Key Installation—Liaison	1
41-7511-2	Key Assembly—Liaison (type J-37) (government furnished)	1
21-9753	Tag Installation—Electric wire identification	508
BAC802-2-55	Jumper Assembly—Terminal bonding	1
BAC802-2-552	Braid—Copper terminal bonding jumper	1
3-14205	Guard Installation—Wire form	1
BAC1603-8	Spacer—No. 10 bolt	5
3-14219	Guard Installation—Wire form	1
BAC1603-48	Spacer—No. 10 bolt	4
1-21974	Clamp Assembly—Plug connector	5
1-20245	Support—Clamp—plug connector	5
	(Parts List No. 527)	
36A2212-4	Nut—Flexible conduit ferrule coupling	5
36A2213-4	Ferrule—Flexible conduit end shoulders	5
3-14994	Filter Installation—Radio	1
1-21376	Filter Assembly—Radio	1
3-13946	Shield Installation—Command radio	1
3-13946-1	Box Assembly—Command radio shield	1
21-8891-4	Panel Assembly—Connector	1
21-8891-4A	Panel—Micarta	1
21-8627-4	Insulator—Junction box	1
6-9696-3	Card—Junction identification	1
15-7785	Support Assembly—Command receiver	1
15-7785-6	Support Assembly—Command receiver	1
15-7786	Support Assembly—Command transmitter	1
1-19965-1-30	Jumper Assembly—Terminal bonding	2
1-23561	Clamp Assembly—Plug connector	1
1-20245	Support—Clamp—plug connector	1
36A2212-2	Nut—Flexible conduit ferrule coupling	1
36A2213-2	Ferrule—Flexible conduit end shoulders	1
1-19965-1-30	Jumper Assembly—Terminal bonding	4
21-4844-50	Jumper Assembly—No. 10-10 terminal bonding	8
BAC820-10	Terminal—Electrical lock	16
6-10471	Control Installation—Liaison receiver	1
6-10471-1	Control Assembly—Liaison receiver remote control unit (type MR-9C) (Bendix Radio Corp., Baltimore, Md.) (government furnished)	1
BAC1602-46	Spacer—No. 8 machine screw	4
9-3750	Unit Installation—Antenna tuning	1
1-21914-1	Mounting—Antenna tuning (drawing H38-A6526) (government furnished)	1
	(Parts List No. 528)	
1-21914	Unit Assembly—Antenna tuning (drawing H38A6526) (government furnished)	1
3-14927	Bracket Assembly—Antenna tuning	1
3-14927-2	Bracket—Antenna tuning	1
3-14927-3	Bumper—Antenna tuning bracket	1
1-19965-2-115	Jumper Assembly—Terminal bonding	1
9-3743	Bracket—Tuning unit support	1
7-1649	Unit Installation—Transmitter tuning	1
1-21920	Unit Assembly—Transmitter tuning (drawing 34D5889) (government furnished)	1
1-12920-1	Unit Assembly—Transmitter tuning (drawing 34D5889) (government furnished)	1
1-21920-2	Case—Transmitter tuning (drawing 34D5889) (government furnished)	2
7-1648	Support Installation—Transmitter tuning	1
7-1648-1	Angle Assembly—Transmitter tuning support	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
7-1648-3	Filler Plate—Transmitter tuning support	2
7-1648-4	Channel Assembly—Transmitter tuning support	2
BAC1602-12	Spacer—No. 8 machine screw	8
6-9700	Control Installation—Radio and compass	1
6-9700-1	Box—Control radio and compass (drawing H40D3229) (government furnished)	1
6-9700-4	Box—Control transmitter radio and compass H41G5076) (government furnished)	1
6-9700-5	Box—Control receiver radio and compass (drawing H41G5077) (government furnished)	1
6-9700-6	Mounting—Radio and compass control (drawing H41G5076) (government furnished)	1
6-9700-7	Mounting—Radio and compass control (drawing H41G5077)	1
43-14203	Switch Installation—Liaison transmitter	1
43-14203-1	Channel—Liaison transmitter switch	1
1-20230	Name Plate—Liaison transmitter switch	1
AN3015	Switch Assembly—(Type B-5A)	1
1-20538-30	Cord Assembly—Turret headset	2
1-20538-1	Jack—Turret headset cord (type JK-46) (government furnished)	2
1-20538-30A	Cord—Turret headset (type CO-119-A) (government furnished)	2
1-20539-30	Cord Assembly—Turret microphone	2
1-20539-1	Jack—Turret microphone (type JK-48) (government furnished)	2
1-20539-30A	Cord—Turret microphone (type CO-119-A) (government furnished)	2
1-20537-100	Cord Assembly—Turret plug-in (jack box to upper turret)	1
1-20537-1	Plug—Turret plug-in (type PL-55) (government furnished)	1
1-20537-100A	Cord—Turret plug-in (type CO-119-A) (government furnished)	1
1-20537-160	Cord Assembly—Turret plug-in (jack box to lower turret)	1
1-20537-1	Plug—Turret plug-in (type PL-55) (government furnished)	1
1-20537-160A	Cord—Turret plug-in (type CO-119-A) (government furnished)	1
1-20536-100	Cord Assembly—Turret plug-in (jack box to upper turret)	1
	(Parts List No. 529)	
1-20536-1	Plug—Turret plug-in (type PL-68) (government furnished)	1
1-20536-100A	Cord—Turret plug-in (type CO-112-A) (government furnished)	1
1-20536-16	Cord Assembly—Turret plug-in—pilot's and co-pilot's (jack box to splice)	2
1-20536-1	Plug—Turret plug-in (type PL-68) (government furnished)	2
1-20536-16A	Cord—Turret plug-in (type CO-112-A) (government furnished)	2
1-20536-160	Cord Assembly—Turret plug-in (jack box to lower turret)	1
1-20536-1	Plug—Turret plug-in (type PL-68) (government furnished)	1
1-20536-160A	Cord—Turret plug-in (type CO-122-A) (government furnished)	1
1-20539-48	Cord Assembly—Turret microphone (pilot's and co-pilot's microphone to splice)	2
1-20539-1	Jack—Turret microphone (type JK-48) (government furnished)	2
1-20539-48A	Cord—Turret microphone (type CO-219) (government furnished)	2
1-20247	Support Assembly—Clamp—plug connector	1
1-20245-1	Support—Clamp—plug connector	1
36A2212-6	Nut—Flexible conduit ferrule coupling	1
36A2213-6	Ferrule—Flexible conduit end shoulders	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
21-4585-42-12	Clamp—Tab square tube	1
BAC538-8	Clamp—Loop type cushioned	1
BAC538-6	Clamp—Loop type cushioned	3
BAC538-11	Clamp—Loop type cushioned	1
BAC538-5	Clamp—Loop type cushioned	2
BAC538-9	Clamp—Loop type cushioned	28
BAC540-6	Clamp—Loop type cushioned	1
BAC540-7	Clamp—Loop type cushioned	8
BAC540-10	Clamp—Loop type cushioned	5
BAC821-120-8	Terminal—Electrical solderless	20
BAC821-118-8	Terminal—Electrical solderless	10
BAC821-116-8	Termina.—Electrical solderless	10
BAC821-116-12	Terminal—Electrical solderless	6
BAC821-118-10	Terminal—E ectrical solderless	40
BAC821-116-10	Terminal—Electrical solderless	10
BAC821-120-10	Terminal—Electrical solderless	80
BAC821-114	Terminal—Electrical solderless	6
BAC821-6	Terminal—Electrical solderless	6
BAC823-18	Electrical Connection—Two-way	2
BAC823-20	Electrical Connection—Two-way	8
BAC1603-8	Spacer—No. 10 bolt	5
BAC1603-32	Spacer—No. 10 bolt	1
BAC1603-48	Spacer—No. 10 bolt	1
3-14979	Receptacle—Cannon (Cannon Elec. Development Co., Los Angeles, Calif., No. SK-E16-21½ AC) (government furnished)	1
3-14979-1	Receptacle—Cannon (Cannon Elec. Development Co., Los Angeles, Calif., No. NK-C23—23 (government furnished)	1
1-23586	Clamp Support Assembly—Plug connector	1
1-23587	Support—Clamp—Plug connector	1
BAC761-5	Coupling Nut—Junction box	1
	(Parts List No. 530)	
BAC764-5B	Ferrule—Flexible conduit	1
	(Parts List No. 531)	
15-7789	Equipment Installation—Radio (AC41-9011 to 41-9245) (235) (Radio equipment installation 15-7789 is used on planes 41-9011 to 41-9245 inclusive)	1
15-7774	Antenna Installation—Radio	1
6-10446	Switch Installation—Antenna	1
1-21434	Plate Assembly—Antenna switch	1
1-21434-1	Plate—Antenna switch	1
1-21915	Switch Assembly—Antenna change-over N.D.	1
BAC1603-8	Spacer—No. 10 bolt	4
1-17633	Insulator Installation—Receiver lead-in	1
1-17633-1	Insulator Installation—Receiver lead-in	1
1-17633-3	Insulator Installation—Receiver lead-in	1
1-17633-4	Insulator Installation—Receiver lead-in	1
1-17633-5	Insulator Installation—Receiver lead-in	1
35A2276	Insulator—Receiver lead-in (type IN-81) (government furnished)	5
41-445-0-6	Spacer—No. 10 bolt	5
1-21477	Insulator Installation—Receiver lead-in	1
35A2276	Insulator—Receiver lead-in (type IN-81) (government furnished)	1
41-445-0-6	Spacer—No. 10 bolt	1
3-13564	Insulator Installation—Liaison antenna lead-in	1
3-13564-2	Link Assembly—Liaison antenna lead-in insulator	1
1-16064	Bushing—Antenna connection	1
1-16071-1	Link—Antenna connection	1
41-8420-77-57	Trim—Escutcheon (type IN-84)	1
35A2282	Insulator—Liaison antenna lead-in (government furnished)	1
1-18465	Insulator—Lead-in	1
1-18718	Washer—Insulator seal	1
1-18720-40-12	Stud—Brass	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
51-315-48-16	Washer—1/16 lead	2
3-13944	Insulator Installation—Command antenna lead-in	1
35A2282	Insulator—Command antenna lead-in (type IN-84) (government furnished)	1
1-18465	Insulator—Lead-in	1
1-18718	Washer—Insulator seal	1
1-18720-40-12	Stud—Brass	1
41-7171-80-112	Washer—1/16 neoprene	1
51-315-48-16	Washer—1/16 lead	2
3-13944-1	Escutcheon—Command antenna lead-in insulator	1
41-8542	Insulator Installation—Trailing antenna lead-in	1
35A2277	Insulator—Trailing antenna lead-in (type IN-82) (government furnished)	1
3-12778	Insulator Installation—Liaison antenna	1
35A2276	Insulator—Liaison antenna (type IN-81) (government furnished)	2
	(Parts List No. 532)	
6-10781	Insulator Installation—Trailing antenna	1
6-10781-1	Koroseal—Plastic—trailing antenna (Goodrich No. 12100)	3
1-23309	Tubing—Polystyrene	1
35A2277	Insulator—(Type IN-82) (government furnished)	3
3-15165	Insulator Installation—Bulkhead station 6	1
1-22955-1	Washer—1/16 neoprene	1
35A2282	Insulator—(Type IN-84) (government furnished)	1
9-3713	Antenna Installation—Radio compass	1
3-12479	Antenna Whip—Radio compass	1
3-14988	Seal Installation—Whip antenna	1
3-14988-1	Tube—Rubber whip antenna seal	1
1-20344	Seal—Whip antenna	1
9-3765	Antenna Installation—Marker beacon	1
9-3765-1	Antenna Wire Assembly—Marker beacon	1
9-3765-2	Lead-in Wire—Marker beacon (government furnished)	1
9-3765-3	Antenna Wire—Marker beacon (government furnished)	1
9-3765-4	Splicing Wire—Marker beacon (government furnished)	1
9-3765-5	Insulator—Marker beacon (type IN-88) (government furnished)	2
9-3765-6	Double Strand Wire—Marker beacon (TM-187A) (government furnished)	2
9-3765-12	Terminal Assembly—Marker beacon (government furnished)	1
9-3765-7	Cable Assembly—Transmitter—Marker beacon	1
9-3765-8	Cable—Transmission line—Marker beacon (government furnished)	1
9-3765-9	Coupling Assembly—Marker beacon (type MC-192) (government furnished)	1
9-3765-10	Flex Cable—Transmission—Marker beacon (government furnished)	1
9-3765-11	Fitting Assembly—Marker beacon (government furnished)	1
9-3765-13	Terminal—Marker beacon (government furnished)	1
9-3765-14	Washer—Plain (government furnished)	2
9-3765-15	Nut—Plain (government furnished)	2
14-2345	Lead-in Installation—Whip antenna	1
14-2345-1	Conduit Assembly—Whip antenna lead-in	1
1-18069	Bus—Connector	1
1-19088	Disconnector—Insulator—antenna lead-in	2
14-2345-4	Conduit—Rigid—whip antenna lead-in	1
14-2345-3	Wire—Whip antenna lead-in (government furnished)	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
14-2345-5	Tube—Whip antenna lead-in (Irv-o-lite XTE-30)	1
14-2345-6	Tube—Whip antenna lead-in (Irv-o-lite XTE-30)	1
14-2345-7	Wire—Cambric covered	1
1-19089	Cap—Insulator—antenna lead-in	1
1-19086	Clamp Assembly—Antenna wire	1
1-19086-1	Bushing—Antenna wire clamp	1
1-19086-3	Clamp Assembly—Antenna wire	1
1-19086-2	Bushing—Antenna wire clamp	1
1-19001-33	Fair-lead Assembly—1 hole	1
	(Parts List No. 533)	
1-19001-32	Fair-lead—1 hole	2
BAC1603-32	Spacer—No. 10 bolt	1
BAC1603-56	Spacer—No. 10 bolt	1
1-21946-1	Bushing—Swaged special terminal	1
15-7774-4	Wire—Double strand radio antenna	2
15-7774-37	Wire—Double strand (government furnished)	1
15-7774-36	Wire—Command antenna—radio (government furnished)	1
15-7774-5	Wire—Lead-in—radio antenna (government furnished)	1
15-7774-6	Wire—Lead-in—radio antenna (government furnished)	1
15-7774-8	Wire—To receiver—radio antenna (government furnished)	1
15-7774-9	Wire—To transmitter—radio antenna (government furnished)	1
15-7774-10	Wire—Receiver and transmitter—radio antenna	3
15-7774-11	Wire—Liaison antenna—radio (government furnished)	1
15-7774-12	Wire—Lead-in—radio antenna (government furnished)	1
15-7774-15	Wire—Transmitter to receiver—radio antenna	1
15-7774-29	Wire—Switch to antenna tuner—radio antenna (government furnished)	1
15-7774-30	Wire—Receiver to 15-7774-15—radio antenna	1
15-7774-32	Wire—Antenna lead-in—radio antenna	1
15-7774-33	Wire—Antenna Lead-in—radio antenna	1
15-7774-3	Insulator—Antenna radio (type IN-88) (government furnished)	4
15-7774-7	Insulator—Bead (type IN-83) (government furnished)	621
15-7774-2	Link—Antenna	1
49-3188	Interphone Installation—Radio crew (station 5D)	1
1-23534	Microphone Assembly—(T-30) (government furnished) (drawing H41G10067)	1
1-21386	Cord Assembly—Throat microphone (government furnished)	1
41-7592	Retainer Assembly—Headset jack	1
41-7592-1	Plate—Headset jack retainer	1
41-158	Retainer—Interphone jack	1
41-159	Stop—Interphone jack	1
1-20535-113	Cord Assembly—Headphone extension (drawing 36B4044)	1
1-20535-1	Plug—Headphone extension cord (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension cord (type JK-26) (government furnished)	1
1-20535-113A	Cord—Headphone extension cord (type CC-119-A) (government furnished)	1
41-1150	Hanger—Headset cords	1
41-1150-1	Hanger—Headset cords	1
9-3188-1	Box—Jack radio crew interphone (type BC-366) (drawing H40D226) (government furnished)	1
BAC548-8	Clamp—Double loop type	1
BAC1602-8	Spacer—No. 8 machine screw	3
46-9217	Interphone Installation—Lower gunner's	1
1-21386	Cord Assembly—Throat microphone (government furnished)	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-9217-1	Lamp—Lower gunner's—24-28V., S.C. base (government furnished)	1
1-23534	Microphone Assembly—(Type T-30) (government furnished)	1
36A2212-1	Nut—Conduit	1
39B2823-4	Lamp Assembly—Amber (S.C.)	1
41-1150	Hanger—Headset cords	1
41-1150-1	Hanger—Headset cords	1
	(Parts List No. 534)	
1-21535-60	Cord Assembly—Headphone extension	1
1-21535-1	Plug—Cord (type PL-55) (government furnished)	1
1-21535-2	Jack—Cord (type JK-26) (government furnished)	1
1-21535-60A	Cord—(government furnished)	1
6-9217-7	Box Assembly—Lower gunner's interphone	1
6-9217-6	Box—Lower gunner's interphone (type BC-366) (drawing H40D2226) (government furnished)	1
BAC548-8	Clamp—Three tube	1
59-2902	Interphone Installation—Forward gunner's	1
1-23534	Microphone Assembly—(Type T-30) (government furnished)	1
1-21386	Cord Assembly—Throat microphone	1
49-2902-400	Jack Box—Forward gunner's interphone (government furnished)	1
41-1150	Hanger—Headset cords	1
41-1150-1	Hanger—Headset cords	1
41-7592	Retainer—Headset jack	1
BAC548-8	Clamp—Three tube	1
46-9333	Interphone Installation—Gunner's	1
1-23534	Microphone Assembly—(Type T-30) (government furnished) (drawing H41G10067)	1
BAC548-8	Clamp—Double loop type	3
41-1150	Hanger—Headset cords	1
1-21386	Cord Assembly—Throat microphone (CD-318) (drawing H42G2346) (government furnished)	1
1-20535-60	Cord Assembly—Headphone extension (drawing 36B4044)	1
1-20535-1	Plug—Headphone extension cord (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension cord (type JK-26) (government furnished)	1
1-20535-60A	Cord—Headphone extension (type CO-119-A) (government furnished)	1
46-9333-400	Box Assembly—Jack	1
6-9333-1	Box Assembly—Jack (BC-366) (government furnished)	1
41-158	Retainer—Interphone Jack	1
41-159	Stop—Interphone jack	1
59-2875	Interphone Installation—Radio operator's	1
41-1150	Hanger—Headset cords	1
41-1150-1	Hanger—Headset cords	1
1-21386	Cord Assembly—Throat microphone (drawing H42G2346) (government furnished)	1
1-20535-60	Cord Assembly—Headphone extension (drawing 36B4044)	1
1-20535-1	Plug—Headphone extension cord (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension cord (type JK-26) (government furnished)	1
1-20535-60A	Cord—Headphone extension cord (type CO-119-A) (government furnished)	1
49-2875-1	Box—Jack—Interphone (type BC-366) (government furnished)	1
BAC1602-8	Spacer—No. 8 machine screw	3
1-23534	Microphone Assembly—(T-30) (drawing H41-G10067) (government furnished)	1
BAC548-8	Clamp—Double loop type	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 535)	
48-1293	Interphone Installation—Rear gunner's	1
8-1293-1	Lamp—Rear gunner's interphone (28V) (government furnished)	1
8-1293-9	Box Assembly—Rear gunner's interphone (type BC-366) (drawing H40D2226)	1
8-1293-7	Box Assembly—Jack—rear gunner's phone (drawing H40D2226) (government furnished)	1
8-1293-8	Angle—Rear gunner's phone	1
1-20535-42	Cord Assembly—Headphone extension (drawing 36B4044)	1
1-20535-1	Plug—Headphone extension cord (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension cord (type JK-26) (government furnished)	1
1-20535-42A	Cord—Headphone extension (type CO-119-A) (government furnished)	1
1-23534	Microphone Assembly—(Type T-30) (government furnished)	1
41-1150-1	Hanger—Headset cords	1
1-21386	Cord Assembly—Throat microphone (type CO-318) (government furnished)	1
39B2823-4	Lamp Assembly	1
BAC548-8	Clamp—Double loop type	1
BAC1602-40	Spacer—No. 8 machine screw	2
49-3362	Interphone Installation—Navigator's	1
41-1150	Hanger—Headset cords	1
1-23534	Microphone Assembly—(Type T-30) (drawing H41G10067) (government furnished)	1
1-20535-60	Cord Assembly—Headphone extension (drawing 36B4044)	1
1-20535-1	Plug—Headphone extension (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension (type JK-26) (government furnished)	1
1-20535-60A	Cordage—Headphone extension (type CO-119-A) (government furnished)	1
9-3362-1	Box—Jack (type BC-366) (government furnished)	1
1-21386	Cord Assembly—Throat microphone (type CD-318) (drawing H42G2346) (government furnished)	1
BAC548-8	Clamp—Double loop type	1
3-14995	Guard Installation—Turret interphone	1
3-14995-1	Channel—Turret interphone guard	1
6-9708	Dynamotor Installation—Interphone	1
6-9708-1	Bracket—Interphone dynamotor	1
6-9708-2	Bracket—Interphone dynamotor	1
6-9708-3	Dynamotor—Interphone dynamotor (type PE-86) (drawing H41D3926) (government furnished)	1
64-1741-506	Interphone Installation—Pilot's	1
41-158-1	Retainer—Interphone jack	2
41-159	Stop—Interphone jack	2
41-1150	Hanger—Headset cords	1
64-1741-4	Filter—Interphone radio (type FL-5-B) (drawing H40D5671) (government furnished)	1
BAC1602-40	Spacer—No. 8 machine screw	1
1-23534	Microphone Assembly—(Type T-30) (drawing H41G10067) (government furnished)	1
	(Parts List No. 536)	
64-1741-1	Box—Jack—interphone pilot's (type BC-366) (drawing H40D2226) (government furnished)	1
64-1741-2	Box—Switch—interphone pilot's (type BC-345) (drawing H39B2224) (government furnished)	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
1-20535-48	Cord Assembly—Headphone extension cord	1
1-20535-1	Plug—Headphone extension cord (type PL-55) (government furnished)	1
1-20535-2	Jack—Headphone extension cord (type JK-26) (government furnished)	1
1-20535-48A	Cord—Headphone extension cord (type CO-119-A) (government furnished)	1
BAC1602-32	Spacer—No. 8 machine screw	7
1-18793	Spacer—Micarta	1
1-18793-1	Spacer—Micarta	1
BAC548-8	Clamp—Double loop type	1
59-2916-505	Interphone Installation—Co-pilot's	1
59-2916-1	Filter—Radio—co-pilot's (Government furnished)	1
59-2916-2	Jack Box—Co-pilot's interphone (type BC-366) (drawing H40D2226) (Government furnished)	1
59-2916-3	Switch—Co-pilot's interphone (type BC-345) (drawing 39B2247) (Government furnished)	1
1-23534	Microphone Assembly—(Type T-30) (Government furnished)	1
1-18793	Spacer—Micarta	1
1-18793-1	Spacer—Micarta	1
41-158-1	Retainer—Interphone jack	2
41-159	Stop—Interphone jack	2
41-1150	Hanger—Headset cords	1
1-20535-42	Cord Assembly—Headphone extension	1
1-20535-1	Plug—Headphone extension cord (type PL-55) (Government furnished)	1
1-20535-2	Jack—Headphone extension cord (type JK-26) (Government furnished)	1
1-20535-42A	Cord—Headphone extension (type CO-119-A) (Government furnished)	1
BAC548-8	Clamp—Double loop type	1
BAC1602-40	Spacer—No. 8 machine screw	1
BAC1602-32	Spacer—No. 8 machine screw	7
6-8826	Receiver Installation—Liaison	1
1-19965-1-55	Jumper Assembly—Terminal bonding	1
BAC802-2-50	Jumper Assembly—Terminal bonding	2
6-8826-1	Mounting—Liaison receiver (type FT-154-B) (Government furnished)	1
6-8826-11	Receiver—Liaison (Government furnished)	1
21-2363-48-12	Washer—.063 steel	8
9-3612	Receiver Installation—Marker beacon	1
9-3612-3	Receiver—Marker beacon (type BC-357) (drawing H40G3537) (Government furnished)	1
9-3612-1	Mounting—Marker—beacon (type FT-161) (Government furnished)	1
BAC802-2-50	Jumper Assembly—Terminal bonding	1
6-9705	Loop Installation—Radio compass	1
	(Parts List No. 537)	
6-9705-2	Loop—LP—21-A (Government furnished)	1
1-23580	Dehydrator Assembly—Radio compass loop (A. C. No. 57763-1) (Bendix Radio Corp.) (Government furnished)	1
1-23580-1	Dehydrator—Hose—radio compass loop (Government furnished)	1
1-23580-2	Connector—Radio compass loop (Government furnished)	1
9-3360-3	Receiver Installation—Radio compass	1
9-3360-4	Mount—Radio compass receiver (type 5T-213-A) (Government furnished)	1
9-3360-2	Radio Compass Unit—Receiver (BC433-A, drawing 41D7017) (Government furnished)	1
BAC779-10-24	Jumper Assembly—Terminal bonding	1
15-6800	Support Installation—Radio compass receiver	1
6-8830	Panel Assembly—Radio compass receiver mount	1
6-8830-1	Panel—Radio compass receiver mount	1
6-8830-2	Angle—Radio compass receiver panel	2

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC1603-26	Spacer—No. 10 bolt	4
BAC1603-29	Spacer—No. 10 bolt	6
15-6800-1	Tube—Radio compass receiver support	2
15-6800-2	Channel—Radio compass receiver support	2
15-6800-3	Angle—Radio compass receiver support	1
15-6800-4	Bracket—Radio compass receiver support	1
15-6800-7	Bracket—Radio compass receiver support	1
15-6800-10	Bracket—Radio compass receiver support	1
15-6800-8	Bracket—Radio compass receiver support	1
41-9007-1	Angle—Tube support	1
BAC1603-16	Spacer—No. 10 bolt	1
15-6800-11	Bracket Assembly—Radio compass receiver support	1
15-6800-9	Bracket—Radio compass receiver support	1
41-9007-1	Angle—Tube support	1
BAC1603-16	Spacer—No. 10 bolt	1
6-7193	Unit Installation—Transmission tuning	1
6-7193-1	Unit—Tuning transmission (type TU-5-A) (Government furnished)	1
6-7193-2	Unit—Tuning transmission (type TU-6-A) (Government furnished)	1
6-7193-3	Unit—Tuning transmission (type TU-7-A) (Government furnished)	1
6-7193-4	Unit—Tuning transmission (type TU-8-A) (Government furnished)	1
6-7193-5	Unit—Tuning transmission (type TU-9-A) (Government furnished)	1
6-7193-6	Cass—Tuning transmission (type C5-48) (drawing 34D5889) (Government furnished)	5
7-1323	Support Installation—Tuning unit	1
7-1323-1	Support Assembly—Tuning unit	1
7-1323-2	Channel—Tuning unit support	1
BAC1246-10S	Plate—Fiber nut	4
7-1323-3	Support Assembly—Tuning unit	1
7-1323-4	Channel—Tuning unit support	1
BAC1246-10S	Plate—Fiber nut	4
BAC1603-18	Spacer—No. 10 bolt	16
BAC1602-12	Spacer—No. 8 machine screw	1
6-7582	Amplifier—Interphone (type BC-347) (Government furnished)	1
H40D3165	Amplifier—Interphone (type BC-347) (Government furnished)	1
	(Parts List No. 538)	
15-8548	Dynamotor Installation—Liaison	1
15-8548-1	Support Assembly—Liaison dynamotor	1
1-24620	Clamp—Antenna lead-in	2
BAC802-2-40	Jumper Assembly—Terminal bonding	1
36B5856	Dynamotor—(Type PE-73-B)	1
46-8522	Indicator Installation—Radio compass	1
46-8522-400	Bearing Indicator—Radio compass (drawing H41D7020) (Government furnished)	1
BAC802-2-40	Jumper Assembly—Terminal bonding	1
46-8832	Relay Installation—Radio compass	1
46-8832-400	Relay—Radio compass (type BK-22-A) (drawing H41B7016) (Government furnished)	1
1-23528	Instruction Plate—Radio compass (Government furnished)	1
46-8832-401	Fuse—Radio compass—5 ampere (1 active—1 spare)	2
46-8832-402	Fuse—Radio compass relay—2 ampere (1 active —1 spare)	2
43-12785	Shield Assembly—Radio compass relay	1
43-12785-1	Box Assembly—Radio compass relay shield	1
41-3864	Spring—Dzus fastener	8
43-12785-2	Box—Radio compartment relay shield	1
43-12785-400	Cover Assembly—Radio compass relay shield	1
41-3862	Grommet—Dzus (type 375)	8
21-6744	Fastener—Inspection door	3

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
41-9638-30	Button—Dzus wing type (AW-5-30)	8
43-12785-4	Cover—Rod lamp relay shield	1
BAC775-3	Clip—Electrical fuse	4
3-14216-2	Fuse—Chart	1
BAC538-10	Clamp—Loop type cushioned	1
BAC538-12	Clamp—Loop type cushioned	1
46-8833	Control Installation—Radio compass	1
46-8833-400	Radio Compass Control Box (drawing H40D3229) (Government furnished)	1
1-21921	Meter Assembly—Frequency (BC-221-A) (drawing H39B4061) (Government furnished)	1
6-7189-19	Transmitter Installation—Liaison	1
BAC802-3-45	Jumper Assembly—Terminal bonding	4
6-7189-1	Mounting—Liaison transmitter (type FT-151-A) (Government furnished)	1
6-7189-2	Unit—Tuning—Liaison transmitter (type TU-10-A) (Government furnished)	1
6-7189-6	Plate—Tuning liaison transmitter (type MC-206) (Government furnished)	1
36D5854	Transmitter—BC 191A (Government furnished)	1
35A2959	Mounting—Transmitter (type FT-115) (Government furnished)	2
BAC1604-12	Spacer—¼ bolt	2
BAC1604-58	Spacer—¼ bolt	2
1-19965-1-40	Jumper Assembly—Terminal bonding	1
	(Parts List No. 539)	
9-2715	Support Installation—Transmitter	1
9-2715-1	Support Assembly—Transmitter	1
9-2715-2	Slip—Transmitter support	2
9-2715-3	Channel—Transmitter support	2
9-2715-4	Tube—Transmitter support	2
9-2715-5	Angle—Transmitter support	1
9-2715-6	Angle—Transmitter support	2
9-2715-7	Angle—Transmitter support	1
9-2715-8	Angle—Transmitter support	2
41-4701	Gusset—Transmitter support	4
41-5773	Gusset—Transmitter support	2
41-5448	Clip—Transmitter support	1L
41-5448-1	Clip—Transmitter support	1R
41-5746-1	Stud—Plate	1
BAC1614-51	Spacer—⅛ rivet	4
21-2363-36-13	Washer—.063 steel	2
BAC1603-12	Spacer—No. 10 bolt	12
56-7583	Shield Installation—Liaison junction	1
56-7583-500	Shield Assembly—Liaison junction	1
56-7583-501	Switch—Liaison junction (type C-1B)	1
6-7625	Shield Assembly—Electrical junction	1
6-7625-1	Shield Assembly—Electrical junction	1
6-7625-2	Box—Electrical junction shield	1
BAC1247-8D	Angle—Nut plate	6
6-7625-3	Cover—Electrical junction shield	1
BAC1461	Screw—8-32 non-losable	6
21-8891-14	Panel Assembly—Connector	1
21-8891-14A	Panel—Connector	1
41-158	Retainer—Interphone jack	1
41-159	Stop—Interphone jack	1
21-7401	Bus—Connector panel	1
1-16369	Plate—Name	1
21-8627-14	Insulator—Junction box	1
BAC1603-24	Spacer—No. 10 bolt	4
6-9696-2	Card—Junction identification	1
9-3646	Shield Installation—Forward radio junction	1
9-3646-2	Insulator—Forward radio junction shield	1
9-3646-3	Relay—Microphone—Forward radio junction shield	2
46-9341	Panel Assembly—Forward radio junction	1
6-9341-1	Panel—Laminated phenolic—forward radio junction	1
21-7401	Bus—Connector panel	2

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-9696-1	Card—Junction identification	1
6-9354	Shield Assembly—Forward radio junction	1
6-9354-1	Box Assembly—Forward radio junction shield	1
41-3864	Spring—Dzus fastener	4
6-9354-2	Box—Forward box junction shield	1
6-9354-3	Cover Assembly—Forward radio junction shield	1
6-9354-5	Cover—Forward radio junction shield	1
41-3862	Grommet—Dzus (type 375)	4
41-9638-30	Button—Dzus wing type	4
1-18585	Shim—Microphone relay	2
	(Parts List No. 540)	
3-12787	Coupling Installation—Radio compass	1
3-12787-1	Coupling—Radio compass (type MC-203) (drawing H40A3230) (Government furnished)	1
6-9709-7	Plug Assembly—Radio connector	1
6-9709-8	Plug with Jacket—Radio connector (type PL-Q-61) (Government furnished)	1
1-20245	Support—Clamp—plug connector	1
6-9709-9	Plug Assembly—Radio connector	1
6-9709-10	Plug with Jacket—Radio connector (type PL-Q-64) (Government furnished)	1
1-20245	Support—Clamp—plug connector	1
6-9709-17	Plug Assembly—Radio connector	1
6-9709-18	Plug with Jacket—Radio connector (type PL-Q-103) (Government furnished)	1
1-20245	Support—Clamp—plug connector	1
6-9709-19	Plug Assembly—Radio connector	1
6-9709-20	Plug with Jacket—Radio connector (type PL-P-61) (Government furnished)	1
1-20245	Support—Clamp—plug connector	1
15-8529	Antenna Installation—Trailing	1
15-8529-3	Wire—Antenna (type W106) (Government furnished)	1
1-21707	Control Assembly—Antenna reel (Government furnished)	1
15-8529-1	Fair-lead Assembly—Antenna	1
1-22506	Connector—Clamp (MC-163) (drawing H41G4446) (Government furnished)	1
3-14410-1	Fair-lead—(Drawing SC-D-3355) (Government furnished)	1
3-15105	Clamp Assembly—Antenna fair-lead	1
3-15105-1	Plate—Antenna fair-lead clamp	1
3-15105-2	Clamp—Antenna fair-lead top LH	1
3-15105-3	Clamp—Antenna fair-lead top RH	1
3-15105-4	Clamp—Antenna fair-lead	1
3-15105-5	Clamp—Antenna fair-lead	1
3-15106	Fair-lead Assembly—Station 6D	1
3-15106-1	Fair-lead—Laminated phenolic—(type II)	1
1-22624	Plate—Antenna fair-lead	1
BAC1324-104-40	Button—Dzus oval head	2
BAC1324-104-45	Button—Dzus oval head	1
3-14322-7	Shaft Assembly—Tuning (drawing H41D5075) (Government furnished)	1
3-14326	Reel assembly—Trailing antenna (RL42) (drawing H41G4446) (Government furnished)	1
6-9987-8	Weight Assembly—Antenna	1
6-9987-1	Weight—Antenna—cast iron (drawing SC-D-3338-B) (Government furnished)	1
6-9987-2	Spring—Antenna (drawing SC-D-3338-B) (Government furnished)	1
6-9987-3	Seat—Spring antenna (drawing SC-D-3338-B) (Government furnished)	1
6-9987-4	Screw—End antenna (drawing SC-D-3338-B) (Government furnished)	1
6-9987-6	Tube—Antenna (drawing SC-D-3338-B) (Government furnished)	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
	(Parts List No. 541)	
6-9987-10	Cable—Flexible antenna (drawing SC-D-3338-B) (Government furnished)	1
BAC540-5	Clamp—Loop type cushioned	9
BAC1603-8	Spacer—No. 10 bolt	4
BAC1603-40	Spacer—No. 10 bolt	1
41-7511	Key Installation—Liaison	1
41-7511-2	Key Assembly—Liaison (type J-37) (drawing H39B3362) (Government furnished)	1
21-9753	Tag Installation—Electric wire identification	630
3-14205	Guard Installation—Wire form	1
BAC1603-8	Spacer—No. 10 bolt	5
3-14219	Guard Installation—Wire form	1
BAC1603-40	Spacer—No. 10 bolt	4
43-14203	Switch Installation—Liaison transmitter	1
3-14203-1	Channel—Liaison transmitter switch	1
1-20230	Name Plate—Liaison transmitter switch	1
AN3015	Switch Assembly—(Type B-5A)	1
1-20538-30	Cord Assembly—Turret head-set	2
1-20538-1	Jack—Turret head-set cord (type JK-46) (Government furnished)	2
1-20538-30A	Cord—Turret head-set (type CO-119-A) (Government furnished)	2
1-20539-30	Cord Assembly—Turret microphones	2
1-20539-1	Jack—Turret microphones (type PL-55) (Government furnished)	2
1-20539-30A	Cord—Turret microphones (type CO-119-A) (Government furnished)	2
1-20537-100	Cord Assembly—Turret plug-in (jack box to upper turret)	1
1-20537-1	Plug—Turret plug-in (type PL-55) (Government furnished)	1
1-20537-100A	Cord—Turret plug-in (type CO-119-A) (Government furnished)	1
1-20537-160	Cord Assembly—Turret plug-in (jack box to lower turret)	1
1-20537-1	Plug—Turret plug-in (type PL-55) (Government furnished)	1
1-20537-160A	Cord—Turret plug-in (type CO-119-A) (Government furnished)	1
1-20536-100	Cord Assembly—Turret plug-in (jack box to upper turret)	1
1-20536-1	Plug—Turret plug-in (type PL-68) (Government furnished)	1
1-20536-100A	Cord—Turret plug-in (type CO-112-A) (Government furnished)	1
1-20536-16	Cord Assembly—Turret plug-in—pilot's and co-pilot's (jack box to splice)	2
1-20536-1	Plug—Turret plug-in (type PL-68) (Government furnished)	2
1-20536-16A	Cord—Turret plug-in (type CO-112-A) (Government furnished)	2
1-20536-160	Cord Assembly—Turret plug-in (jack box to lower turret)	1
1-20536-1	Plug—Turret plug-in (type PL-68) (Government furnished)	1
1-20536-160A	Cord—Turret plug-in (type CO-122-A) (Government furnished)	1
1-20539-48	Cord Assembly—Turret microphone (pilot's and co-pilot's microphone to splice)	2
1-20539-1	Jack—Turret microphone (type JK-48) (Government furnished)	2
1-20539-48A	Cord—Turret microphone (type CO-219) (Government furnished)	2
1-20247	Support Assembly—Clamp—plug connector	1
1-20245-1	Support—Clamp—plug connector	1
	(Parts List No. 542)	
36A2212-6	Nut—Flexible conduit ferrule coupling	1
36A2213-6	Ferrule—Flexible conduit end shoulders	1
21-4585-42-12	Clamp—Tab square tube	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
BAC538-8	Clamp—Loop type cushioned	1
BAC538-6	Clamp—Loop type cushioned	2
BAC538-11	Clamp—Loop type cushioned	1
BAC538-5	Clamp—Loop type cushioned	2
BAC538-9	Clamp—Loop type cushioned	28
BAC540-7	Clamp—Loop type cushioned	11
BAC540-10	Clamp—Loop type cushioned	5
1-23586	Clamp Support Assembly—Plug connector	1
1-23587	Support—Clamp—plug connector	1
BAC761-5	Coupling Nut—Junction box	1
BAC764-5B	Ferrule—Flexible conduit	1
BAC802-2-55	Jumper Assembly—Terminal bonding	1
BAC821-120-8	Terminal—Electrical solderless	20
BAC821-118-8	Terminal—Electrical solderless	10
BAC821-116-8	Terminal—Electrical solderless	10
BAC821-12	Terminal—Electrical solderless	6
BAC821-118-10	Terminal—Electrical solderless	40
BAC821-116-10	Terminal—Electrical solderless	10
BAC821-120-10	Terminal—Electrical solderless	80
BAC821-114	Terminal—Electrical solderless	6
BAC821-6	Terminal—Electrical solderless	6
BAC823-18	Electrical Connectors—Two-way	5
BAC823-20	Electrical Connectors—Two-way	25
BAC1603-8	Spacer—No. 10 bolt	5
BAC1603-32	Spacer—No. 10 bolt	1
BAC1603-48	Spacer—No. 10 bolt	1
1-21959-8	Fitting—Connector	1
3-14979	Receptacle Cannon—(Cannon Elec. Devel. Co., No. SK-C16-21-½ AC) (Government furnished)	1
3-14979-1	Receptacle Cannon—(Cannon Elec. Devel. Co., No. NK-C23-23-⅝ B) (Government furnished)	1
15-7789-1	Transmission—Radio command equipment (Cannon Elec. Devel. Co.) (type BC457-A) (drawing H4165076) (Government furnished)	1
	(Parts List No. 543)	
15-7789-2	Transmission—Radio command equipment (Cannon Elec. Devel. Co.) (type BC457-A) (Government furnished)	1
15-7789-3	Rack—Radio equipment (type FT226-A) (Cannon Elec. Devel. Co.) (Government furnished)	1
15-7789-21	Rack—Radio equipment (type FT220-A) (Cannon Elec. Devel. Co.) (Government furnished)	1
15-7789-4	Mounting—Radio equipment (type FT227-A) (Cannon Elec. Devel. Co.) (Government furnished)	1
15-7789-22	Mounting—Radio equipment (type FT221-A) (Cannon Elec. Devel. Co.) (Government furnished)	1
15-7789-27	Mounting—Radio equipment (type FT225-A) (Cannon Elec. Devel. Co.) (Government furnished)	1
15-7789-16	Loop Connector—Radio equipment (type CD-365-A) (Cannon Elec. Devel. Co.) (Government furnished)	1
15-7789-17	Radio Receiver—Command—radio equipment (Cannon Elec. Devel. Co.) (type BC-453-A) (Government furnished)	1
15-7789-18	Radio Receiver—Command—radio equipment (Cannon Elec. Devel. Co.) (type BC-454-A) (Government furnished)	1
15-7789-19	Radio Receiver—Command—radio equipment (Cannon Elec. Devel. Co.) (type BC-445-A) (Government furnished)	1
15-7789-20	Dynamotor—Command—radio equipment (Cannon Elec. Devel. Co.) (type DM-32-A) (Government furnished)	3
15-7789-26	Dynamotor—Command—radio equipment (Cannon Elec. Devel. Co.) (type DM-33-A) (Government furnished)	1

AVIALOGS.COM

FINAL ASSEMBLY

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
15-7789-25	Modulator—Command—radio equipment (Cannon Elec. Devel. Co.) (type BC-456-A) (Government furnished)	1
15-7789-28	Tuning Shaft—Radio equipment (Cannon Elec. Devel. Co.) (type MC-124) (Government furnished)	1
15-7789-29	Tuning Shaft—Radio equipment (Cannon Elec. Devel. Co.) (type MC-124) (Government furnished)	1
15-7789-30	Tuning Shaft—Radio equipment (Cannon Elec. Devel. Co.) (type MC-215) (Government furnished)	1
15-7789-31	Tuning Shaft—Radio equipment (Cannon Elec. Devel. Co.) (type MC-124) (Government furnished)	1
15-7789-57	Tuning Shaft—Radio equipment (Cannon Elec. Devel. Co.) (type MC-215) (Government furnished)	1
15-7789-58	Tuning Shaft—Radio equipment (Cannon Elec. Devel. Co.) (type MC-215) (Government furnished)	1
15-7789-32	Plug—Radio equipment (type PL-151) (Cannon Elec. Devel. Co.) (Government furnished)	2
15-7789-33	Plug—Radio equipment (type PL-148) (Cannon Elec. Devel. Co.) (Government furnished)	1
15-7789-34	Plug—Radio equipment (type PL-147) (Cannon Elec. Devel. Co.) (Government furnished)	1
15-7789-35	Plug—Radio equipment (type PL-156) (Cannon Elec. Devel. Co.) (Government furnished)	2
15-7789-39	Plug—Radio equipment (type PL-122) (Cannon Elec. Devel. Co.) (Government furnished)	1
15-7789-40	Plug—Radio equipment (type PL-118) (Cannon Elec. Devel. Co.) (Government furnished)	2
15-7789-41	Plug—Radio equipment (type PL-112) (Cannon Elec. Devel. Co.) (Government furnished)	3
15-7789-42	Plug—Radio equipment (type PL-152) (Cannon Elec. Devel. Co.) (Government furnished)	6
	(Parts List No. 544)	
15-7789-43	Plug—Radio equipment (type PL-158) (Cannon Elec. Devel. Co.) (Government furnished)	2
15-7789-44	Plug—Radio equipment (type PL-144) (Cannon Elec. Devel. Co.) (Government furnished)	2
15-7789-60	Plug—Radio equipment (type PL-108) (Cannon Elec. Devel. Co.) (Government furnished)	2
15-7789-36	Wire—Jumper on plugs—radio equipment (Cannon Elec. Devel. Co.) (Government furnished)	1
15-7789-59	Coupling—Right angle—radio equipment (Cannon Elec. Devel. Co.) (type MC-136) (Government furnished)	1
15-7789-23	Relay Antenna—Radio equipment (Government furnished)	1
15-7789-24	Mounting—Radio equipment (Government furnished)	1
15-7789-46	Conduit Assembly—Flexible radio equipment	1
15-7789-47	Conduit—Flexible radio equipment	1
15-7789-48	Plug with Jacket—Radio equipment (type PL-P-59) (Government furnished)	1
15-7789-49	Plug with Jacket—Radio equipment (type PL-Q-59)	1
1-21974	Clamp Assembly—Plug connector	5
1-20245	Support—Clamp—plug connector	5
36A2212-4	Nut—Flexible conduit ferrule coupling	5
36A2213-4	Ferrule—Flexible conduit end shoulders	5
3-14994	Filter Installation—Radio	1
1-21376	Filter Assembly—Radio	1
3-13946	Shield Installation—Command radio	1
3-13946-1	Box Assembly—Command radio shield	1
21-8891-4	Panel Assembly—Connector	1
21-8891-4A	Panel—Micarta	1
21-8627-4	Insulator—Junction box	1

Radio Equipment Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-9696-3	Card—Junction identification	1
15-7785	Support Assembly—Command receiver	1
1-19965-1-30	Jumper Assembly—Terminal bonding	2
15-7786	Support Assembly—Command transmitter	1
1-19965-1-30	Jumper Assembly—Terminal bonding	2
1-23561	Clamp Assembly—Plug connector	1
1-20245	Support—Clamp—plug connector	1
36A2212-2	Nut—Flexible conduit ferrule coupling	1
36A2213-2	Ferrule—Flexible conduit end shoulders	1
1-19965-1-30	Jumper Assembly—Terminal bonding	4
21-4844-50	Jumper Assembly—No. 10-10 terminal bonding	8
BAC820-10	Terminal—Electrical lock	16
	(Parts List No. 545)	
9-3750	Unit Installation—Antenna tuning	1
1-21914-1	Mounting—Antenna tuning (drawing H38A6526) (Government furnished)	1
1-21914	Unit Assembly—Antenna tuning (drawing H38A6526) (Government furnished)	1
3-14927	Bracket Assembly—Antenna tuning	1
3-14927-2	Bracket—Antenna tuning	1
3-14927-3	Bumper—Antenna tuning bracket	1
1-19965-2-115	Jumper Assembly—Terminal bonding	1
1-19965-2-115C	Braid—Copper—terminal bonding jumper	1
9-3743	Bracket—Tuning unit support	1
7-1963	Unit Installation—Transmitter tuning	1
7-1963-1	Unit Assembly—Transmitter tuning (drawing 34D5889) (Government furnished)	1
7-1963-2	Case—Transmitter tuning (drawing 34D5889) (Government furnished)	2
7-1648	Support Installation—Transmitter tuning	1
7-1648-1	Angle Assembly—Transmitter tuning support	1
7-1648-2	Extruded Angle—Transmitter tuning support	1
7-1648-3	Filler Plate—Transmitter tuning support	2
7-1648-4	Channel Assembly—Transmitter tuning support	2
7-1648-5	Channel—Transmitter tuning support	2
BAC1602-12	Spacer—No. 8 machine screw	8
6-9700	Control Installation—Radio and compass	1
6-9700-1	Box—Control radio and compass (drawing H40D3229) (Government furnished)	1
6-9700-4	Box—Control transmitter radio and compass (drawing H41G5076) (Government furnished)	1
6-9700-5	Box—Control receiver radio and compass (drawing H41G5077) (Government furnished)	1
6-9700-6	Mounting—Radio and compass control (drawing H41G5076) (Government furnished)	1
6-9700-7	Mounting—Radio and compass control (drawing H41G5077) (Government furnished)	1
1-24920	Terminal—Electrical solderless	2

Marking Installation

(Parts List No. 546)

65-5925	Marking Installation	1
1-24194-1	Decalcomania—K-7C camera	1
1-24194-2	Decalcomania—T-3A camera	1
1-24194-3	Decalcomania—K-3B camera 12 in. cone	1
1-24194-4	Decalcomania—K-3B camera 8¼ in. cone	1
5-16111-8	Decalcomania—Fuel cell treated with sloshing compound	6
3-16457-1	Decalcomania—Feeder fuel drain	1
3-16457-2	Decalcomania—Starter pull	1
3-16457-3	Decalcomania—Caution	2
3-16457-4	Decalcomania—Supercharger lubrication tank drain	2
3-16457-5	Decalcomania—Supercharger lubrication tank drain	2
3-16457-1	Decalcomania—Fuel feeder drain	1

AVIALOGS.COM

FINAL ASSEMBLY

Marking Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-10786-1	Decalcomania—Glycol pump drain	1
6-10786-2	Decalcomania—Glycol overflow	1
6-10786-3	Decalcomania—Glycol tank vent	1
6-10786-4	Decalcomania—Oil cooler drain	4
6-10786-5	Decalcomania—Engine No. 3 fuel drain	1
6-10786-6	Decalcomania—Engine No. 4 tank vent	1
6-10786-7	Decalcomania—Engine No. 1 tank vent	1
6-10786-8	Decalcomania—Engine No. 3 tank filler overflow	1
6-10786-9	Decalcomania—Engine No. 2 fuel drain	1
6-10786-10	Decalcomania—Propeller anti-icer tank drain	1
6-10786-11	Decalcomania—Engine No. 2 tank filler overflow	1
6-10786-12	Decalcomania—Engine No. 1 tank filler overflow	1
6-10786-13	Decalcomania—Feeder tank filler overflow	2
6-10786-14	Decalcomania—Outside air temperature	1
6-10786-15	Decalcomania—Relief drain	1
6-10790-1	Decalcomania—Glycol filter	1
6-10790-2	Decalcomania—Generator wing break shield No. 138	1
6-10790-3	Decalcomania—Generator connection shield No. 219	1
6-10790-4	Decalcomania—Generator connection shield No. 132	1
6-10790-5	Decalcomania—Generator connection shield No. 131	1
6-10790-6	Decalcomania—Generator connection shield No. 130	1
6-10790-7	Decalcomania—Generator wing break shield No. 139	1 1
6-10790-8	Decalcomania—Ignition shield No. 74	1
6-10790-9	Decalcomania—Ignition shield No. 73	1
6-10790-10	Decalcomania—External power solenoid No. 156	1
6-10790-11	Decalcomania—External power receptacle No. 140	1
6-10790-12	Decalcomania—Landing gear limit switch shield No. 309	1
6-10790-13	Decalcomania—Landing gear limit switch shield No. 307	1
6-10790-14	Decalcomania—Tail gear warning switch No. 75	1
6-10790-15	Decalcomania—Rear cabin heat shutter valve	1
6-10790-16	Decalcomania—Bomb door limit switch shield No. 182 down	1
6-10790-17	Decalcomania—Bomb door limit switch shield No. 182 up	1
6-10790-18	Decalcomania—Air shutter valve on opposite side of duct	1
6-10790-19	Decalcomania—Oil pressure	4
6-10790-20	Decalcomania—Oil temperature	4
6-10790-21	Decalcomania—Oxygen filler valve	2
6-10790-22	Decalcomania—Hydraulic filter	1
6-10790-23	Decalcomania—Vacuum relief valve	2
6-10790-24	Decalcomania—Pressure relief valve	3
6-10790-25	Decalcomania—Check valve	5
6-10790-26	Decalcomania—Propeller anti-icer pump	1
6-10790-27	Decalcomania—Hydraulic pressure regulator	1
	(Parts List No. 547)	
6-10790-28	Decalcomania—Fuel transfer pump	1
6-10790-29	Decalcomania—Accumulator bleeder valve	1
6-10790-30	Decalcomania—Anti-icer needle valve	4
6-10790-31	Decalcomania—Right magneto	4
6-10790-32	Decalcomania—Left magneto	4
6-10790-33	Decalcomania—Propeller feather to governor	4
6-10790-34	Decalcomania—Oil dilution connection	4
6-10790-35	Decalcomania—Oil out	4
6-10790-36	Decalcomania—Oil in	4
6-10790-37	Decalcomania—Oil separator vent	2
6-10790-38	Decalcomania—Oil tank vent	8
6-10790-39	Decalcomania—Hydraulic cowl flap	8
6-10790-40	Decalcomania—Vapor vent	4
6-10790-41	Decalcomania—Fuel pump balance line	4
6-10790-42	Decalcomania—Oil dilution valve	4
6-10790-43	Decalcomania—Glycol by-pass relief valve	1

Marking Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
6-10790-44	Decalcomania—Tachometer	4
6-10790-45	Decalcomania—Manifold pressure	4
6-10790-46	Decalcomania—Fuel pressure	4
6-11308-3	Decalcomania—U. S. Army—model B-17E Air Corps serial number crew weight 1200 pounds (special adhesive type)	1
9-4640-1	Decalcomania—Jack	7
9-4640-2	Decalcomania—Water drain	6
9-4640-3	Decalcomania—Tank vent	2
9-4640-4	Decalcomania—Oil drain	4
9-4640-5	Decalcomania—Starter pull	3
9-4640-6	Decalcomania—Blower drain	4
9-4640-7	Decalcomania—Engine support	4
9-4640-8	Decalcomania—Aileron trim tab	1
9-4640-9	Decalcomania—Aileron control	3
9-4640-10	Decalcomania—Moor	2
9-4640-11	Decalcomania—Oil separator drain	1
9-4640-12	Decalcomania—Booster pump drain	4
9-4640-13	Decalcomania—Engine No. 4 fuel drain	1
9-4640-14	Decalcomania—Elevator trim tab	4
9-4640-15	Decalcomania—Supercharger lubrication tank vent	2
9-4640-16	Decalcomania—Supercharger lubrication tank vent	2
9-4640-17	Decalcomania—Supercharger lubrication tank vent	2
9-4640-18	Decalcomania—Hydraulic pump drain	2
9-4640-19	Decalcomania—Loop LP-21-A	1
9-4640-20	Decalcomania—Vacuum pump exhaust	1
9-4640-21	Decalcomania—Flap control	10
9-4640-22	Decalcomania—External power plug	1
9-4640-23	Decalcomania—Access case drain	2
9-4640-24	Decalcomania—Fuel pump drain	4
9-4640-25	Decalcomania—Feathering pump drain	4
9-4640-26	Decalcomania—Disconnect bonding before removing ring cowl	4
9-4640-27	Decalcomania—Caution—do not remove door without engine support in place. Do not overtighten screws	4
9-4640-28	Decalcomania—Fuel transfer pump drain	1
9-4640-29	Decalcomania—Feeder tank vent	2
	(Parts List No. 548)	
9-4640-30	Decalcomania—Engine No. 4 tank filler overflow	1
9-4640-31	Decalcomania—Engine No. 1 fuel drain	1
9-4641-1	Decalcomania—Throttle warning shield No. 303	1
9-4641-2	Decalcomania—Station 6 fuse shield No. 305	1
9-4641-3	Decalcomania—Generator voltage regulator shield No. 273	1
9-4641-4	Decalcomania—Wing junction shield No. 82	1
9-4641-5	Decalcomania—Wing junction shield No. 83	1
9-4641-6	Decalcomania—No. 1 nacelle junction shield No. 61	1
9-4641-7	Decalcomania—Bomb door solenoid shield No. 181	1
9-4641-8	Decalcomania—Station 4 fuse shield No. 146	1
9-4641-9	Decalcomania—No. 3 nacelle junction shield No. 79	1
9-4641-10	Decalcomania—No. 2 nacelle junction shield No. 80	1
9-4641-11	Decalcomania—No. 4 nacelle junction shield No. 78	1
9-4641-12	Decalcomania—Starter connection shield No. 534	1
9-4641-13	Decalcomania—Ignition wing shield No. 76	1
9-4641-14	Decalcomania—Ignition wing shield No. 77	1
9-4641-15	Decalcomania—Caution—disconnect all electrical wiring, tubing and control cables before removing wing	2
9-4641-16	Decalcomania—Level	4
9-4641-17	Decalcomania—Outboard ignition shield No. 532	1
9-4641-18	Decalcomania—Throttle warning shield No. 304	1
9-4641-19	Decalcomania—Bomb rack junction shield No. 183	1
9-4641-20	Decalcomania—Generator relay shield No. 214	1
9-4641-21	Decalcomania—Generator relay shield No. 218	1

AVIALOGS.COM

FINAL ASSEMBLY

Marking Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
9-4641-22	Decalcomania—Generator relay shield No. 221	1
9-4641-23	Decalcomania—Generator relay shield No. 222	1
9-4641-24	Decalcomania—Bomb rack junction shield No. 190	1
9-4641-25	Decalcomania—Flap solenoids No. 250	1
9-4641-26	Decalcomania—De-icer distributor valve accessory door	1
9-4641-27	Decalcomania—Outboard ignition shield No. 65	1
9-4641-28	Decalcomania—Inboard ignition shield No. 70	1
9-4641-29	Decalcomania—Starter connection shield No. 71	1
9-4641-30	Decalcomania—Starter connection shield No. 314	1
9-4641-31	Decalcomania—Starter connection shield No. 535	1
9-4641-32	Decalcomania—Inboard ignition shield No. 533	1
9-4641-33	Decalcomania—A.C. power shield No. 128	1
9-4641-34	Decalcomania—Oxygen relief valve	1
9-4641-35	Decalcomania—Vacuum selector valve	1
9-4642-1	Decalcomania—Tail hoist	1
9-4642-2	Decalcomania—59 pounds (special adhesive type)	1
9-4642-3	Decalcomania—Battery	3
9-4642-4	Decalcomania—Engine No. 3 fuel gage	1
9-4642-5	Decalcomania—Feeder fuel	2
9-4642-6	Decalcomania—Feeder fuel gage	2
9-4642-7	Decalcomania—Battery vent	3
9-4642-8	Decalcomania—Hoist airplane	2
9-4642-9	Decalcomania—Life raft control	2
9-4642-10	Decalcomania—Lock wire vacuum valve shut	2
9-4642-11	Decalcomania—Supercharger lubrication tank	2
9-4642-12	Decalcomania—Rudder trim tab	2
9-4642-13	Decalcomania—Sight control access	1
9-4642-14	Decalcomania—Engine oil	4
	(Parts List No. 549)	
9-4642-15	Decalcomania—Engine No. 4 fuel gage	1
9-4642-16	Decalcomania—Map case	2
9-4642-17	Decalcomania—Variable vacuum orifice	1
9-4642-18	Decalcomania—Nacelle platform braces	2
9-4642-19	Decalcomania—Fuel strainer	4
9-4642-20	Decalcomania—Caution—disconnect all electrical wiring and control cables before removing outer wing	2
9-4642-21	Decalcomania—Caution—disconnect all electrical wiring before removing wing tip	2
9-4642-22	Decalcomania—Engine No. 2 fuel gage	1
9-4642-23	Decalcomania—Engine No. 1 fuel gage	1
9-4642-24	Decalcomania—Air valve	3
9-4642-25	Decalcomania—Load points outboard	1
9-4642-26	Decalcomania—Load points outboard	1
9-4642-27	Decalcomania—Open deflector before opening window	2
9-4642-29	Decalcomania—U.S.A. Model B17E AC serial No. —crew weight 1200 pounds	1
9-4645-1	Decalcomania—Forward cabin heat shutter valve	1
9-4645-2	Decalcomania—Anti-creep adjustable screw	1
9-4645-3	Decalcomania—Replace silica gel. when ¼ pink	5
9-4645-4	Decalcomania—Hydraulic accumulator—release hydraulic pressure by opening drain valve on bomb bay truss. Release air pressure by turning air valve before dismantling minute air pressure with accumulator empty should be 350 P.S.I. Check air pressure on hydraulic pressure gage by noting pressure fall-off point.	1
9-4645-5	Decalcomania—Air shutter valve	1
9-4645-6	Decalcomania—Drift meter vacuum valve lock wire when not in use	1
9-4645-7	Decalcomania—Drift signal door	1
9-4645-8	Decalcomania—Supercharger regulator support	4
9-4645-9	Decalcomania—Turbosupercharger regulator lines	4
9-4645-10	Decalcomania—Hydraulic brake line	2
9-4645-11	Decalcomania—Propeller feathering motor	4
9-4645-12	Decalcomania—Supercharger lubrication tank	2
9-4645-13	Decalcomania—Retracting motor shield No. 276	1
9-4645-14	Decalcomania—Vacuum oil separator	3

Marking Installation

Part No.	Nomenclature 1 2 3 4 5 6 7	Units Per Assy
9-4645-15	Decalcomania—Bomb sight stowage	1
9-4645-16	Decalcomania—⅜ screws	2
9-4645-17	Decalcomania—To open window, jerk handle forward	2
9-4645-18	Decalcomania—Warning—release front and rear latches before opening camera door, latch door when closed, and during gunfire	1
9-4645-19	Decalcomania—Fill with anti-icing fluid specification No. 3585. Capacity 20 U.S. gallons	1
9-4645-20	Decalcomania—Life raft	2
9-4645-21	Decalcomania—To fill glycol tank 1. Fluid—per cent by weight 55%	
	(Parts List No. 550)	
	Diethylene glycol 40 per cent ethylene glycol. 2. Fill to "full mark" on gage	1
	NOTE: For drained system fill tank. Operate pump to fill lines and add fluid to "full mark."	
9-4645-22	Decalcomania—Fuel shut-off valve	4
9-4645-23	Decalcomania—Feeder fuel drain	1
9-4645-24	Decalcomania—Open doors before raising wind deflector when top gun window is out to relieve negative pressure in radio compartment	1
9-4645-26	Decalcomania—Forward cabin heat shutter valve located in bottom center of duct. See T. O. No. 01-20EF-2	1
9-4645-27	Decalcomania—Air shutter valve—see T. O. No. 01-20EF-2 for adjustment	1
9-4660-1	Decalcomania—Bulkhead 4	1
9-4660-2	Decalcomania—Bulkhead 5	1
9-4660-3	Decalcomania—Bulkhead 6	1
9-4660-4	Decalcomania—Bulkhead 7	1
9-4660-5	Decalcomania—Bulkhead 8	1
9-4660-6	Decalcomania—Bulkhead 9	1
9-4660-7	Decalcomania—Bulkhead 10	1
9-4660-8	Decalcomania—Bulkhead 11	1
9-4660-9	Decalcomania—De-icer valve control	1
9-4660-10	Decalcomania—Engine No. 2 fuel	1
9-4660-11	Decalcomania—Engine No. 1 fuel	1
9-4660-12	Decalcomania—Engine No. 3 fuel	1
9-4660-13	Decalcomania—Engine No. 4 fuel	1
9-4660-14	Decalcomania—Propeller anti-icer tank vent	1
9-4660-15	Decalcomania—Caution—DO NOT operate engine without accessory cover and all screws tightly in place	2
9-4660-16	Decalcomania—Flap up	1
9-4660-17	Decalcomania—Flap down	1
9-4660-18	Decalcomania—Glycol tank	1
9-4660-19	Decalcomania—Fire extinguisher located inside	2
9-4660-20	Decalcomania—Tail wheel—down—up	1
9-4660-21	Decalcomania—Landing gear—up—down	2
9-4660-22	Decalcomania—CO_2 fire extinguisher	1
9-4660-23	Decalcomania—Airplane flight reports	1
9-4660-24	Decalcomania—Marker beacon	1
9-4660-25	Decalcomania—65 pounds (special adhesive type)	2
9-4660-26	Decalcomania—Hydraulic pressure warning switch	1
9-4660-27	Decalcomania—Hoist outer wing only	4
9-4660-28	Decalcomania—Salvo bomb release	2
9-4660-29	Decalcomania—Hoist wing only without engines	2
9-4660-30	Decalcomania—Caution—disconnect all electrical wiring and tubing before removing fin	2
9-4660-31	Decalcomania—Caution—disconnect all electrical wiring, tubing and control cables before removing stabilizer	2
9-4660-32	Decalcomania—Bomb control accessory	1
	(Parts List No. 551)	
9-4660-33	Decalcomania—Pull in emergency only	2
9-4660-34	Decalcomania—Pull in emergency only	2
9-4660-35	Decalcomania—Remove guard rail when bombs are loaded above this level	2

AVIALOGS.COM

AVIALOGS.COM

Section 3

NUMERICAL PARTS LIST

AVIALOGS.COM

NUMERICAL PARTS LIST

Part No.	Assy. Parts List Nos.
1-4795	257, 258
1-5745-4	435
1-7987	359
1-9601-2	334
1-10067	259
1-10669-2	342
1-11885-4	289
1-12946-1	503
1-12965	300, 301, 344
1-13114-46	273, 293
1-13302-28	357
1-13322-13	366
1-13892-21-6	411
1-13892-38-8	287, 498
*1-13892-56-12	12, 287, 386
1-13892-70-16	403
1-13898-7D	390
1-13902-3	285
1-14068	289
1-15573-80-61	460
1-15573-88-69	250
1-16029	470
1-16029-1	470
1-16031	140
1-16033	264
1-16045	261
1-16046	261
1-16047-1	264
1-16050-3-0	283, 284
1-16050-5-6	283
1-16050-6-0	288
1-16050-6-4	288
1-16050-15-7	288
1-16050-19-3	288
1-16050-31-5	16, 17
1-16050-39-6	16
1-16050-45-4	17
1-16050-48-4	17
1-16050-50-6	17
1-16050-52-6	16
1-16050-55-0	16
1-16052	262
1-16054	265
1-16055-3	265
1-16056-4-3	32
1-16056-5-3	44
1-16056-9-6	300, 301
1-16056-19-6	300, 301
1-16056-28-0	44
1-16056-28-6	32
1-16056-33-0	42, 45
1-16061	455
1-16061-1	455
*1-16064	86, 503, 518
*1-16071-1	503, 504, 518
1-16122	511
1-16123	265
1-16123-1	264
1-16127	353
1-16128	371
1-16128-1	371
1-16128-2	371
1-16134-19-5	188
1-16135-1	326
1-16135-2	326
1-16272	474
*1-16272-1	474
1-16274	76
1-16274-1	76
*1-16283	151, 152, 168
*1-16283-1	151, 152, 168
1-16283-2	143, 202, 204
*1-16283-3	143, 163, 202
1-16283-4	26, 202, 203
1-16283-5	26, 202
*1-16283-6	141, 141A, 142
*1-16283-7	141, 141A, 142
1-16283-8	153
1-16283-12	26, 430
1-16283-13	26, 430
1-16283-18	160
1-16283-19	160, 231
1-16283-20	151
1-16283-21	151
1-16283-22	143
1-16285	307
1-16285-1	307
1-16288-2	200
1-16316	132
1-16321-1	427
1-16322	428
1-16326	428
1-16351	297
1-16369	512, 525, 539
1-16372	200
1-16378	201
1-16378-1	201
1-16378-2	201
1-16379	201
1-16380	201
1-16381	201
1-16388-192-20	504
1-16411	201
1-16411-1	201
1-16414	200A
1-16414-1	200A
1-16415	200A
1-16415-1	200A
1-16416	201
1-16417	201
1-16417-1	201
1-16418	201
1-16418-1	201
1-16419	201
1-16423	357
1-16459-2	354
1-16461	175
1-16464	172
1-16464-1	172
1-16465	162
1-16466	162
1-16511	38
1-16511-1	38
1-16511-2	51
1-16522	424, 425
1-16522-1	424, 425
1-16523	424
1-16523-1	425
1-16546	315
*1-16597	258, 260, 261
*1-16598-26	258, 260, 262
*1-16598-34	258, 260, 261
1-16598-42	258, 261, 263
1-16598-46	258, 260, 263
1-16598-50	260, 262
1-16598-52	262
*1-16599-1	258, 260, 261
*1-16601-27	258, 261, 262
*1-16601-35	258, 260, 261
1-16601-43	258, 260, 263
1-16601-47	258, 260, 262
1-16601-51	260, 262
1-16601-53	262
*1-16602	259, 260, 262
1-16603-4	261
*1-16603-5	259, 260, 261
*1-16604	259, 260, 261
*1-16605	259, 260, 261
*1-16606	259, 260, 261
1-16607-6	259, 261, 263
1-16608	259, 261, 263
1-16609	261, 263
1-16611	262, 264
1-16613	264, 265
1-16614	264
1-16614-1	265
1-16615	264, 265
1-16616	262, 264
1-16617	264, 265
1-16618	262, 264, 265
1-16619	265
1-16619-1	265
1-16620	265
1-16620-1	265
1-16650-43-0	197
1-16650-43-0A	197
1-16650-98-1	197
1-16650-98-1A	197
1-16653	315
1-16653-1	315
1-16654	315
1-16654-1	315
1-16656	386, 393
1-16656-1	386
1-16658	384
1-16660	384
1-16661	330, 388
1-16664	331
1-16665	274
1-16666	327
1-16667	327
1-16668-6-29	386
1-16668-7-24	386
1-16669	386
1-16733-11-7	434
1-16750	365
1-16750-1	365
1-16750-2	365
1-16750-3	365
1-16751	388
1-16752-34	322
1-16754-3	386
1-16754-4	386
1-16755-1	457
1-16756	58
1-16757	385
1-16761	387
1-16762	388
1-16763	11
1-16764	27
1-16962	385, 408
1-16964	214
1-17019	346, 385, 386
1-17095	274
1-17097-8	344
1-17097-9	410
1-17100	410
1-17101	358
1-17103	42
1-17103-1	42, 233
1-17103-2	48
1-17103-3	48
1-17103-4	35
1-17103-5	35
*1-17103-6	28, 31, 35
*1-17103-7	28, 31, 35
1-17103-8	44, 48
1-17103-9	44, 48
1-17104	359
1-17104-1	359
1-17109	354
1-17232	247
1-17235	256A, 257
*1-17237	205, 206, 207
*1-17237-1	206, 207, 208
*1-17237-2	206, 207, 208
*1-17237-3	206, 208, 210
1-17237-4	205, 206
1-17237-5	206
1-17237-6	206
1-17237-7	206, 208
1-17237-8	202
1-17238-2	490
1-17240	176
1-17242	204, 205
1-17242-1	152, 204, 205
*1-17242-4	210, 211, 212
1-17242-5	210, 212
1-17243-3	142
1-17244	255, 256, 477
1-17244-1	255, 256, 477
1-17248	490
1-17248-1	490
1-17249	251
1-17249-1	403
1-17267	119, 120
1-17350	391, 394
1-17351	187
1-17351-1	187
1-17351-2	187
1-17351-3	187
1-17354	56
1-17354-1	56
1-17355	262
1-17355-2	262
1-17357	90
1-17357-1	90
1-17357-2	90
1-17357-3	90
1-17358	510
1-17359-2	411
1-17360	397
1-17361	464
1-17361-1	500
1-17363	296
1-17364	151
1-17364-1	151
1-17364-2	151
1-17364-3	151
1-17364-4	151
1-17364-5	151
1-17364-6	151
1-17364-7	151
1-17365	151
1-17365-1	151
1-17365-2	151
1-17365-3	151
1-17366	248
1-17366-1	248
1-17368	67
1-17369	68
1-17389	457
1-17457	36
1-17458	19
1-17458-1	19
1-17460	66
1-17460-1	66
1-17461	84
1-17468	57
1-17468-1	57
1-17468-2	68
1-17469	75
1-17469-1	75
1-17469-2	75
1-17469-3	75

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
1-17469-5	75
1-17492	410
1-17500-67	361
1-17503	442, 444, 446
1-17503-1	446
1-17504	446
1-17505	442, 444, 446
1-17507	187
1-17550	286
1-17551	237
1-17552	289
1-17553	289
1-17553-1	289
1-17553-2	289
1-17554	289
1-17555	290
*1-17557	219, 220, 223
*1-17557-1	219, 220, 223
1-17557-2	214
1-17557-3	214
1-17557-4	214
1-17557-5	214
1-17557-6	214
1-17557-7	214
1-17557-8	221
1-17557-9	221
1-17557-10	221
1-17557-11	221
1-17557-12	221
1-17557-13	221
1-17557-16	232
1-17557-17	232
1-17557-18	232
1-17557-19	232
1-17557-20	221, 232
1-17557-21	232
*1-17559	161, 162, 187
1-17560	141
1-17560-1	141
1-17561	141
1-17561-1	141
1-17562	141
1-17562-1	141
1-17563	257, 258
1-17563-1	258
1-17563-3	257
1-17564-1	284
1-17564-2	284, 285
1-17565	477
1-17566-1	442, 444
1-17568	323
1-17569	442, 444
1-17570-5	284A, 285
1-17570-6	284
1-17571	220, 230
1-17572	384
1-17573-7-199	161, 162, 413
1-17575	128
1-17575-1	128
1-17577	288
1-17577-1	288
1-17579	271
1-17582-2	445
1-17584-13	444, 446
1-17584-28	446
1-17585	148A
1-17586	148
1-17587	58, 59, 60
1-17587-1	59
1-17588-3	332, 335
1-17588-4	82, 83
1-17588-5	82, 83
1-17589	220
1-17591	155
1-17595	332
1-17595-1	332
1-17596	332
1-17596-1	332
1-17599	442
1-17632	213
1-17632-1	213
1-17632-3	211
1-17632-4	211
1-17632-5	211
1-17633	503, 517, 531
1-17633-1	503, 517, 531
1-17633-2	503, 517
1-17633-3	531
1-17633-4	503, 517, 531
1-17633-5	503, 517, 531
1-17634	442, 444
1-17639	204
1-17640	145
1-17647	442, 444
1-17673-7-199	187
*1-18050	12, 14, 18
1-18050-1	97, 98, 99
1-18050-2	19, 20, 74
1-18050-5	111, 112
1-18050-8	100, 111
1-18050-9	97, 98, 99
1-18050-10	112
1-18050-11	112
1-18050-12	350, 351, 351A
*1-18050-14	18, 20, 21
1-18050-15	74
1-18050-16	21
1-18050-17	97, 111
1-18054	150
1-18055	150
1-18058	475, 485
1-18064	442, 445, 446
1-18064-2	442, 444
1-18066	195
1-18069	504, 519, 532
1-18070	352
1-18070-1	352
1-18071	352
1-18072	356
1-18073	352
1-18074	257, 258
1-18075	244
1-18076	243A, 244
1-18077	243, 244
*1-18081-2	338, 339, 340
1-18084	218
1-18084-1	218
1-18085	197
1-18086	197
1-18088	442, 444
1-18089	308
1-18089-1	308
1-18090	236
1-18090-1	236
1-18090-3	236
1-18091	473, 474
1-18092	473, 474
1-18092-1	473, 474
1-18093	473, 474
1-18093-1	473, 474
1-18094-1	473, 474
1-18095	243, 244
1-18096	120
1-18097	243, 244
1-18098-9-0A	322
1-18098-9-5	303
1-18098-9-5A	303, 322
1-18098-9-6	318
1-18098-9-6A	318
1-18098-10-0	303, 318
1-18098-10-0A	303, 318
1-18098-12-0	323
1-18098-12-0A	323
1-18098-12-4	303
1-18098-12-4A	303
1-18098-12-6	318
1-18098-12-6A	318
1-18098-13-0	303
1-18098-13-0A	303
1-18098-13-6	303
1-18098-13-6A	303
1-18098-14-8	318
1-18098-14-8A	318
1-18098-14-9	320
1-18098-14-9A	320
1-18098-15-0	318
1-18098-15-0A	318
1-18098-17-0	323
1-18098-17-0A	323
1-18098-17-7	320
1-18098-17-7A	320
1-18098-17-9	303, 318
1-18098-17-9A	303, 318
1-18098-28-9	303
1-18098-28-9A	303
1-18098-29-1	318
1-18098-29-1A	318
1-18098-31-5	318
1-18098-31-5A	318
1-18098-32-6	303
1-18098-32-6A	303
1-18100	473, 474
1-18106	323
1-18107	46
1-18108	241
1-18109-1	432, 433
1-18112	96
1-18114-3-7	413
1-18114-5-5	413
1-18114-9-8	187, 413
1-18114-10-5	161, 162
1-18114-12-3	413
1-18114-15-4	413
1-18114-18-5	413
1-18114-19-4	413
1-18115	446
1-18116-2	285
1-18117	321
1-18119	357
1-18123	280
1-18123-1	280
1-18123-2	280
1-18123-3	280
1-18123-4	280
1-18124	281
1-18124-1	281
1-18124-2	281
1-18124-3	281
1-18124-4	281
1-18127	320, 322
1-18128	172, 176
1-18128-1	172, 176
1-18129	133
1-18132-3-4	73
1-18132-3-6	73
1-18133-2-0	73
1-18133-2-2	73
1-18139	363
1-18139-1	363
1-18139-2	363
1-18157	425
1-18162	448
1-18165	448
1-18166	362
1-18169-38	424A
1-18191	118
1-18191-4	120
1-18192	118
1-18192-1	120
1-18193	266, 267
1-18193-1	266, 267
1-18194	172, 176
1-18195	176
1-18198	172, 177
1-18199	282, 283
1-18200	176
1-18204	473, 474
1-18205-9-0R	453
1-18205-87-1L	450
1-18205-92-5R	450
1-18207	46
1-18207-1	46
1-18208	323
1-18209	127
1-18230	122
1-18230-1	122
1-18232	88
1-18233	237
1-18234	172
1-18235	176
1-18236	172, 176
1-18236-1	172, 176
1-18237	172, 176
1-18241	320, 322
1-18244	380
1-18245	380
1-18246	367, 393
1-18247	88
1-18248	88
1-18248-1	88
1-18249	88
1-18249-1	88
1-18249-2	88
1-18249-3	88
1-18250	266, 267
1-18251-1	215
1-18252	239
1-18253	239
1-18254	490
1-18255	240
1-18256	239
1-18257	459
1-18257-1	459
1-18258	240
1-18259	240
1-18260	19
1-18260-1	19
1-18261	218
1-18262	239
1-18263	239
1-18264	239
1-18265	239
1-18265-1	239
1-18266-1	141, 169, 175
1-18266-2	169, 175
1-18266-3	141, 169, 175
1-18267	280, 286
1-18269	238
1-18270	215
1-18271	215
1-18271-1	215
1-18272-1	61
1-18272-2	61
1-18273	465
1-18274	286
1-18274-406	286
1-18274-407	286
1-18275-5	63
1-18275-6	63
1-18276	282
1-18277	144, 201
1-18277-2	221
1-18277-3	221, 224
1-18278	221, 232, 237
1-18279	97
1-18280	239

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
1-18281-2	320
1-18282	320, 322
1-18283	320, 322
1-18283-1	320
1-18283-2	322
1-18284	425, 426
1-18285	25
1-18285-1	25
*1-18286-2	338, 339, 340
1-18288	218
1-18288-1	218
1-18289	121
1-18290	218
1-18292-48-222	448
1-18292-48-330	448
1-18293	218
1-18295	237
1-18296-3	239
1-18298	428, 429
1-18298-1	427, 428
1-18298-2	429
1-18298-3	428
1-18298-10	428, 429
1-18298-12	429
1-18298-13	429
1-18298-15	429
1-18298-17	428
1-18298-18	428
1-18299-51-33	237, 427, 428
1-18299-60-60	428
1-18299-63-27	429
1-18299-63-33	428
1-18299-63-51	429
1-18299-75-27	429
1-18300	239
1-18300-1	239
1-18302	239
1-18303	197
1-18304	239
1-18306	218
1-18306-1	218
1-18308-1	424
1-18308-2	424
1-18308-3	424
1-18308-4	424
1-18308-5	424
1-18309	282, 284
1-18309-1	284A, 285
1-18309-2	282, 283, 284
1-18309-3	282
1-18309-4	283
1-18309-5	283
1-18310	453, 456
1-18311	448
1-18312	448
1-18313	277
1-18316	240
1-18317	285
1-18319	239
1-18322-4	221
1-18322-5	221
1-18322-6	221
1-18322-7	221
1-18323	432
1-18323-1	432
1-18327-36-1	460
1-18327-36-1A	460
1-18328	233
1-18329	233
1-18332	352
1-18342	357
1-18348	162, 241
1-18350	125
1-18350-1	125
1-18351	424A
1-18351-1	424A
1-18352	424A
1-18352-1	424A
1-18353-1	38, 51
*1-18355	23, 24, 88
1-18356	172, 427
1-18357	172, 427
1-18360	172
1-18361	172
1-18362	218
1-18362-1	218
1-18363	254, 302
1-18364	55, 449
*1-18365	338, 339, 340
*1-18365-1	338, 340, 341
1-18367	118
1-18368	374
1-18369	229
*1-18370	119, 120, 126
1-18371	382
1-18372	246
1-18373	246
1-18374	246
1-18375	246
1-18376	384
1-18377	176
1-18379-3	228
1-18380-8-199	290
1-18380-8-250	228
1-18381	240
*1-18382	255, 256, 477
1-18385	228, 229
1-18388	185
1-18389	19
1-18389-1	19
1-18393	228
1-18394	19
1-18394-1	19
1-18395	19
1-18395-1	19
1-18396	373
1-18397	168
1-18398	373
1-18399	351, 352
1-18400-96	96
1-18401	228, 229
1-18402	289
1-18402-1	289
1-18402-2	289
1-18403	289
1-18403-1	289
1-18403-2	289
1-18404	289
1-18404-1	289
1-18404-2	289
1-18405	289
1-18405-1	289
1-18405-2	289
1-18406	289
1-18406-1	289
1-18406-2	289
1-18407	424A
1-18408	237
1-18408-1	237
1-18409	140
1-18409-1	140
1-18410	352
1-18411	352
1-18411-1	352
1-18411-2	352
1-18411-3	352
1-18411-4	352
1-18413-1	137, 194, 458
1-18414-19-11	187
1-18415	187
1-18416	425
1-18421	455
1-18431	172
1-18432	180
1-18432-1	180
1-18433	280, 281, 285
1-18434	242
1-18435	280, 285
1-18437-1	287
1-18438	448
1-18446	118, 121
1-18447	124
1-18448	185
1-18449	143, 151
1-18450	427
1-18450-2	427
1-18451	428
1-18452	427
1-18452-1	427
1-18455	384
1-18456	216
1-18456-1	216
1-18457-1	228
1-18458	217, 236
1-18458-1	217, 236
1-18459	216, 217
1-18459-1	216, 217
1-18462	185
1-18463	243, 244
1-18464	117
1-18464-1	117
*1-18465	503, 517, 518
1-18467	214
1-18467-1	214
1-18468-196	170
*1-18487	271, 303, 304
1-18490	214
1-18490-1	214
1-18491	459
1-18491-1	459
1-18492	487
1-18493	214
1-18493-1	214
1-18494	108, 118, 121
1-18496	238
1-18496-1	238
1-18497	229
1-18498	229
1-18499	228
1-18499-1	228
1-18500	143, 193
1-18503	221, 230
1-18504	221
1-18505	476
1-18506	487
1-18507	373
1-18509-3	374
1-18510	229
1-18511	229
1-18512	460
1-18512-1	217
1-18517	118, 121
1-18518	121
1-18519	428
1-18520	221
1-18520-1	222
1-18520-2	222
1-18520-3	222
1-18521	224
1-18522	222
1-18522-1	222
1-18522-2	222
1-18522-3	222
1-18524	237. 240
1-18525	237
1-18526	237
1-18527	118
1-18528	121
1-18536-8-199	290
1-18537	118, 121
1-18538-2	137
1-18538-3	137
1-18539	459
1-18540	288
1-18541	280, 282, 286
1-18543-84L	77, 80
1-18543-84R	77, 80
1-18543-96L	77, 80
1-18543-96R	77, 80
1-18544	183
1-18545	217
1-18546-2-34	236
1-18546-3-70	217
1-18547	484
1-18550	122
1-18552	224
1-18552-1	224
1-18553	223, 225
1-18553-1	223
1-18554	223
1-18555-1	223, 225
1-18555-2	223, 224
1-18556	145, 223
1-18557-1	223
1-18557-2	145
1-18557-7	145
1-18557-8	145
1-18557-9	145, 222, 223
1-18557-10	222
1-18559	224
1-18559-1	224
1-18560	228
1-18560-1	228
1-18561	237
1-18563	236
1-18566	412
1-18567	468A
1-18568	122, 123
1-18568-1	122, 123
*1-18569-1	280, 281, 286
1-18570	224
1-18571	128, 218
1-18576	505
1-18577	343
1-18577-1	343
1-18578	185
1-18578-1	185
1-18578-2	185
1-18579	382, 384
1-18580	108
1-18581	230
1-18581-1	230
1-18581-2	230
1-18583	241
1-18584	380, 381
1-18584-1	380
1-18585	513, 525, 539
1-18586	217
1-18586-1	217
1-18587-2	229
1-18587-3	229
1-18588	505
1-18589	118, 121
1-18593-2	223
1-18593-3	223
1-18594	137
1-18594-1	137
1-18595	120
1-18596	120
1-18596-1	120
1-18596-2	120
1-18597	243
1-18599	222
1-18600	222

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
1-18600-1	223
1-18600-2	222
1-18601	223
1-18603	271
1-18604	271
1-18605	178
1-18607	117
1-18607-1	117
1-18609-1	243A
1-18612	430
1-18613	363
1-18619	292
1-18630	224
1-18635	5
1-18636	124
1-18637	188
1-18637-1	188
1-18638	254, 279
1-18639	476
1-18641	86
1-18641-1	86, 87
1-18642	473
1-18643	473
1-18644	473
1-18645	129
1-18651	113, 114
1-18652	217
1-18656	117
1-18657	117
1-18657-1	117
1-18657-2	117
1-18657-3	118
1-18657-4	118
1-18660	405
1-18661-3	225
1-18661-4	225
1-18661-5	225
1-18663	223
1-18664	241
1-18665	80
1-18665-1	80
1-18670	137
1-18670-1	137
1-18671	228
1-18671-1	228
1-18674-4	137
1-18674-5	137
1-18678	174A
1-18680-2	137
1-18681	137
1-18681-1	137
1-18682-10-199	217, 231
1-18683	224
1-18683-1	224
1-18684	125
1-18686	222, 225
1-18686-1	224
1-18686-2	224
1-18686-3	225
1-18686-4	224
1-18687	426
1-18687-2	426
1-18689	165
1-18692	230
1-18692-1	230
1-18693	228
1-18693-1	228
1-18694	228
1-18694-1	228
1-18696-2	230
1-18696-3	230
1-18698	230
1-18698-1	230
1-18701	228
1-18701-1	228
1-18702	228
1-18702-1	228
1-18703	133
1-18703-1	133
1-18703-2	133
1-18704-32-11	217
1-18704-32-13	217
1-18705	237
1-18705-1	237
1-18706	373
1-18707-1	373
1-18708-1	500
1-18709	201
1-18710	201
1-18711	201
1-18711-1	201
1-18712	201
1-18713	227
1-18713-1	228
1-18715	243, 244
1-18717	217
*1-18718	503, 517, 518
*1-18720-40-12	503, 517, 518
1-18721	120
1-18721-1	120
1-18723	125
1-18724	117, 122
1-18725	224
1-18725-1	224
1-18726	224
1-18727	362
1-18727-1	194
1-18740	249
1-18750	146
1-18751	291
1-18752	123
1-18753	123
1-18753-1	123
1-18754	122
1-18754-1	122
1-18754-2	123
1-18754-3	123
1-18755	233
1-18756-1	291
1-18756-2	291
1-18757	27
1-18758	465
*1-18759	161, 162, 187
1-18761	214
1-18762	208
1-18762-1	208
1-18764-1	291
1-18765	238
1-18765-1	238
1-18766	238
1-18766-1	238
1-18767	51
1-18767-1	38, 51
1-18768	143
1-18768-1	143
1-18769	193
1-18770	193, 194
1-18771	214, 221
1-18774	236
1-18775	137
1-18776	245
1-18777	237
1-18778	352
1-18779	217
1-18779-1	217
1-18780	167
1-18781	235
*1-18782	161, 162, 187
1-18783	217
1-18784	352
1-18785	237
1-18786	225
1-18787	352
1-18789	225
*1-18793	509, 510, 522
*1-18793-1	509, 510, 522
1-18795	320, 322
1-18796	190, 191
1-18801	190, 191
1-18802	284
1-18809	50
1-18811-7-328	114
1-18813	117, 122
1-18813-1	117, 122
1-18814-1	227
1-18814-2	217
1-18814-3	227
1-18815	237
1-18816	122
1-18821	164
1-18822	224
1-18823	184
1-18823-1	184
1-18824	119
1-18826	296
1-18828	398
1-18828-1	398
1-18828-3	398
1-18830	479
1-18831	506
1-18833	201, 233
1-18836	352
1-18838	124
1-18838-1	124
1-18839	124
1-18839-1	124
1-18840	280, 281, 285
1-18842	222
1-18842-1	222
1-18842-2	222
1-18842-3	222
1-18843	222
1-18843-1	222
1-18844	384
1-18845-5-90	367
1-18846	143
1-18846-1	143
1-18847	143
1-18847-1	143
1-18848	117
1-18849	185
1-18850	143
1-18850-1	144
1-18851	144
1-18851-1	144
1-18853-5	498
1-18853-6	498
1-18854	193, 201
1-18854-1	193, 201
1-18854-2	193
1-18854-3	193
1-18856	222
1-18857	119
1-18858	119
1-18860	291
1-18861-1	291
1-18861-2	291
1-18862	224
1-18863-1	223, 225
1-18864	118
1-18865	291
1-18866	291
1-18870	119
1-18870-1	119
1-18871	127
1-18872	127
1-18872-1	127
1-18873	127
1-18873-1	127
1-18875	222
1-18875-1	222
1-18876	237
1-18876-1	237
1-18877	237
1-18877-1	237
1-18878	237
1-18879	237
1-18880	128
1-18880-1	128
1-18881	188
1-18882	238
1-18882-1	238
1-18883-4	229
1-18883-5	229
1-18883-6	229
1-18883-7	229
1-18884	223
1-18885	241
1-18887	241
1-18888-275	284, 285
1-18889-2	222
1-18889-3	222
*1-18890	141, 165, 168
1-18890-1	178, 241
1-18891	393
1-18892	125
1-18893	472
1-18895	296
1-18896	472
1-18898	133
1-18898-1	133
1-18900	230, 234
1-18901	233
1-18901-1	233
1-18903	143
1-18904	124
1-18904-1	124
1-18906	215, 217
1-18907	193
1-18907-1	193
1-18908	118
1-18909	271
1-18910	424A
1-18910-1	424A
1-18911	424A
1-18912	424A
1-18913-5	230
1-18913-6	230
1-18914	288
1-18915	270
1-18918	129
1-18918-1	129
1-18920	235
1-18920-1	235
1-18921	122
1-18922	122
1-18923	275, 276
1-18924	276
1-18927	168
1-18927-1	168
*1-18928	338, 339, 340
1-18929-2	229
1-18929-3	229
1-18930	230
1-18931	275, 276
1-18933	372
1-18934	113, 115
1-18935	133
1-18936	321
1-18938	164
1-18941-7-5	321
1-18941-7-5A	321
1-18941-9-5	321
1-18941-9-5A	321

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
1-18941-12-6	321
1-18941-12-6A	321
1-18941-13-1	321
1-18941-13-1A	321
1-18942	144
1-18942-1	144
1-18946-1	229
1-18946-2	229
1-18946-4	229
1-18947-11-5	321
1-18947-11-5A	321
1-18947-14-7	321
1-18947-14-7A	321
1-18947-19-7	320
1-18947-19-7A	320
1-18947-20-0	321
1-18947-20-0A	321
1-18971	322
1-18972	228
1-18973	164
1-18977	304
1-18979-4-7	304
1-18979-4-7A	304
1-18979-5-5	304
1-18979-5-5A	304
1-18979-5-7	320
1-18979-8-2	320
1-18980	155
1-18981	352
1-18982	447
1-18983	367
1-18984	321
1-18987	221
1-18987-1	221
1-18988	221
1-18988-1	221
1-18999-10-0	445
1-18999-10-0A	445
1-18999-12-9	443
1-18999-12-9A	443
1-19000-1	214, 236
1-19000-2	214, 236
1-19000-3	214, 235, 236
1-19000-4	214, 235, 236
1-19000-5	164
1-19000-7	177
1-19000-8	177
1-19000-9	177
1-19001-1	441
1-19001-5	277
1-19001-6	277
1-19001-7	277
1-19001-8	451
1-19001-9	451
1-19001-10	451
1-19001-11	451
1-19001-12	393
1-19001-13	393
1-19001-19	302
1-19001-20	302
1-19001-21	52
1-19001-22	52
1-19001-23	52
1-19001-24	52
1-19001-28	178
1-19001-29	178
1-19001-30	178
1-19001-31	235
1-19001-32	504, 519, 533
1-19001-33	504, 519, 532
1-19001-45	161
1-19001-46	161
1-19001-47	161
1-19001-49	145
1-19001-72	216
1-19001-73	216
1-19001-94	390
1-19001-96	390
1-19001-97	390
1-19001-98	277
1-19001-99	277
1-19001-100	277
1-19001-103	66
1-19001-104	66
1-19001-114	161
1-19001-115	161
1-19001-116	161
1-19001-133	78
1-19001-147	235
1-19001-198	174
1-19001-199	174
1-19001-200	174
1-19001-201	174
1-19001-204	174
1-19001-205	174
1-19001-206	174
1-19001-207	174
1-19001-208	174
1-19002-3	461
1-19002-4	461
1-19002-5	461
1-19002-6	461
1-19002-15	390
1-19002-16	390
1-19002-17	390
1-19003-1	451
1-19003-2	451
1-19003-3	409
1-19003-4	409
1-19003-5	172
1-19004-13	403
1-19004-14	403
1-19004-15	450
1-19004-16	450
1-19004-17	450
1-19004-18	450
1-19004-19	450
1-19004-20	450
1-19005-1	403
1-19005-2	403
1-19006-1	177
1-19006-2	177
1-19006-3	177
1-19030	221
1-19030-1	221
1-19031	52
1-19032	367
1-19033	321
1-19034	92, 93, 463
1-19036	218, 221
1-19037	241
1-19037-1	241
1-19038	338, 340, 341
*1-19038-1	338, 339, 340
1-19039	338
1-19039-1	338
1-19040	338, 340, 341
*1-19040-1	338, 339, 340
1-19043	275, 276
*1-19044	432, 433, 441
1-19045	227
1-19046	227
1-19047	227
1-19048	227
1-19049	227
1-19051	264, 265
1-19052-6-6	460
1-19052-6-6A	460
1-19052-7-2	303
1-19052-7-2A	303
1-19052-7-3	318
1-19052-7-3A	318
1-19052-7-5	318
1-19052-7-5A	318
1-19052-7-8	318
1-19052-7-8A	318
1-19052-8-0	323
1-19052-8-0A	323
1-19052-8-2	323
1-19052-8-2A	323
1-19052-8-3	319
1-19052-8-3A	319
1-19052-9-5	271
1-19052-9-5A	271
1-19052-9-7	303
1-19052-9-7A	303
1-19052-15-3	271
1-19052-15-3A	271
1-19053-1	201
1-19054	383
1-19055	383
1-19056-1	223
1-19057	36
1-19058	240
1-19059	237
1-19059-1	237
1-19060	447
1-19060-1	447
1-19062-1	268
1-19066	228
1-19066-1	228
1-19067	241
1-19067-1	241
1-19068	265
1-19069	447
1-19070	304
1-19072	237
1-19076	266, 268
1-19076-1	266, 268
1-19077-4	227
1-19078	237
1-19079	136
1-19080	228
1-19081	289
1-19082	264, 265
1-19083	238
1-19086	504, 519, 532
1-19086-1	504, 519, 532
1-19086-2	504, 519, 532
1-19086-3	504, 519, 532
1-19087-4	239
1-19088	504, 519, 532
1-19089	504, 519, 532
1-19652	450
1-19653	20
1-19653-1	19, 20
1-19654	19
1-19654-1	22, 23
1-19655	384
1-19656	447
1-19658	239
1-19661	239
1-19664	221
1-19664-1	221
1-19665-1	265
1-19666	284
1-19667	280, 281, 286
1-19668	280, 281, 286
1-19669	339, 340
*1-19669-2	338, 339, 340
1-19688-1	473
1-19690	259, 261, 263
1-19691	467
1-19691-1	467
1-19693	264
1-19695	230
1-19696	230
1-19698	168
1-19699-18	443, 445
1-19700	168
1-19701	382
1-19701-1	382
1-19702	445
1-19702-1	445
1-19703	78
1-19704	443, 444, 445
1-19705-4-8	443
1-19705-7-8	445
1-19706-3	274
1-19707-4	273, 274
1-19708	274
1-19708-1	274
1-19709-92-81	150
1-19709-100-81	150
1-19810	342, 343
1-19810-1	342, 343
1-19811	342, 343
1-19811-1	342, 343
1-19812	150
*1-19813-2	271, 303, 308
*1-19813-3	303, 308, 309
1-19814-8-5	445
1-19814-8-5A	445
1-19814-12-5	445
1-19814-12-5A	445
1-19815	424A
1-19815-1	424A
1-19817-2	292
1-19817-3	292
1-19818	143
1-19818-1	143
1-19820	143
1-19820-1	143
1-19820-2	143
1-19821	143
1-19822	143
1-19822-1	143
1-19823	473
1-19825	365
1-19826	398
1-19826-1	399
1-19827-144	444
1-19827-259	147
1-19827-275	64
1-19827-294	155
1-19828	155
1-19828-1	444
1-19828-2	147
1-19828-3	155
1-19829	241
1-19830	134
1-19832	221
1-19832-1	221
1-19833	284, 284A, 285
1-19834	64
1-19835	405
1-19837	180
1-19840	457
1-19843	447
1-19844	447
1-19845	296
1-19847	447
1-19855	231
1-19855-1	231
1-19856	447
1-19857-1	447
1-19857-2	447
1-19857-3	447
1-19857-4	447
1-19859	274
1-19859-1	274
1-19950	468
1-19951	472

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
1-19951-1	472
1-19951-2	472
1-19963	280, 281, 285
1-19963-1	281, 285
1-19963-2	280, 281, 286
1-19963-3	281, 286
1-19963-4	280, 281, 285
1-19963-5	280, 281, 286
1-19965-1-30	527, 544
1-19965-1-40	512, 525, 538
1 19965-1-45	505
1-19965-1-55	510, 523, 536
1-19965-1-60	505
1-19965-2-115	506, 528, 545
1-19965-2-115C	545
*1-19967	259, 260, 261
1-19969	259, 261, 263
*1-19969-1	259, 260, 261
1-19990	274
1-19990-1	274
1-19994	434
1-19995	447
1-19998	328
1-20000	405
1-20003	234
1-20004	444, 445, 446
1-20004-1	442
1-20005	234
1-20006	240
1-20006-1	240
1-20011	234
1-20011-1	234
1-20012-2	234
1-20012-3	234
1-20013	234
*1-20016	280, 281, 286
1-20017	271
1-20021	268
*1-20022	24, 85, 287
1-20022-1	13, 15, 292
1-20024	280, 281, 286
1-20026	26
1-20026-1	26
1-20026-2	26
1-20031	251
1-20035	232
1-20035-1	232
1-20036	383
1-20037	383
1-20038	383
1-20039	377
1-20039-2	377
1-20039-4	377
1-20039-5	377
1-20040	383
1-20041	232
1-20041-1	232
1-20042	232
1-20042-1	232
1-20042-2	232
1-20042-3	232
1-20043-2	232
1-20043-3	232
1-20046	281, 286
1-20046-1	281, 286
1-20046-2	281, 286
1-20046-3	281, 285
1-20046-4	281, 285
1-20046-5	281
1-20047	232
1-20047-1	232
1-20048	232
1-20048-1	232
1-20055	362, 373
1-20056	433
1-20065	424
1-20071-1	292
1-20072-2	292
1-20075	292
1-20076	200
1-20077	484
1-20078	304
1-20079	484
1-20180-2	231
1-20180-3	231
1-20181	231
1-20181-1	231
1-20182	231
1-20182-1	231
1-20183	231
1-20183-1	232
1-20184	232
1-20184-1	232
1-20186	232
1-20186-1	232
1-20188	136
1-20198	427
1-20199	63, 83, 84
1-20200	63, 83, 84
1-20200-1	63, 83
1-20201	63, 83, 84
1-20202	220, 223
1-20203	181
1-20203-1	181
1-20204	181
1-20204-1	181
1-20206	137
1-20207	14
1-20208	405
1-20209	200
1-20230	515, 528, 541
1-20231	136, 194, 371
1-20231-1	194, 371
1-20231-2	194, 371
1-20232	136
1-20235	26
1-20237	371
1-20238	143
1-20239	466, 467
1-20240-2	468A
1-20242	143
1-20244-1	224
*1-20245	506, 513, 525
*1-20245-1	515, 529, 541
1-20247	515, 529, 541
1-20248	292
1-20316	199
1-20316-1	199
1-20320	372
1-20321	350
1-20321-1	350
1-20327	402
1-20328	405
1-20328-1	405
1-20330	372
1-20330-1	372
1-20330-2	372
1-20333-1	482
1-20334	218, 219
1-20335	219
1-20336	469
1-20336-1	469
1-20336-2	469
1-20337	388
1-20340	477
1-20340-1	477
1-20344	504, 519, 532
1-20345	377
1-20346-1	377
1-20347	477
1-20348	147
1-20350	402
1-20351	246
1-20351-1	247
1-20352	468
1-20352-1	468
120353	250
1-20354	194
1-20355	283, 284
1-20355-1	283, 284
1-20355-2	283, 284
1-20356	283, 284
1-20357	283, 284
1-20360	223
1-20361	223
1-20362	240
1-20362-1	240
1-20363	284
1-20363-1	283, 284
1-20364	240
1-20364-1	240
1-20365	240
1-20366	240
1-20367	240
1-20368	31
1-20368-1	31
1-20371	201
1-20371-1	201
1-20373	88
1-20374	32, 42
1-20374-1	45
1-20376	42
1-20379	469
1-20381	372
1-20381-1	372
1-20382	188
1-20382-1	188
1-20383	187
1-20389	227
1-20391	221
1-20520	143
1-20521	145
1-20523	415, 416
1-20524	50
1-20526	377
1-20526-1	377
1-20527	450
1-20528	469
1-20531	237
1-20531-1	237
1-20532	237
1-20532-1	237
*1-20535-1	508, 509, 510
*1-20535-2	508, 509, 510
*1-20535-42	508, 509, 510
*1-20535-42A	508, 509, 510
1-20535-48	522, 536
1-20535-48A	522, 536
*1-20535-60	508, 519, 520
*1-20535-60A	508, 520, 521
1-20535-113	519, 533
1-20535-113A	519, 533
1-20536-1	514, 529, 541
1-20536-16	529, 541
1-20536-16A	529, 541
1-20536-100	514, 528, 541
1-20536-100A	514, 529, 541
1-20536-160	514, 529, 541
1-20536-160A	514, 529, 541
1-20537-1	514, 528, 541
1-20537-100	514, 528, 541
1-20537-100A	514, 528, 541
1-20537-160	514, 528, 541
1-20537-160A	514, 528, 541
1-20538-1	514, 528, 541
1-20538-30	514, 528, 541
1-20538-30A	514, 528, 541
1-20539-1	528, 529, 541
1-20539-30	514, 528, 541
1-20539-30A	514, 528, 541
1-20539-48	529, 541
1-20539-48A	529, 541
1-20544	204
1-20545	204
1-20546	146
1-20553	384
1-20555	141
1-20556	490
1-20558	36, 50
1-20560	300, 301
1-20561	9
1-20561-1	87
1-20562	86
1-20562-1	86
1-20563-2	259, 261, 263
1-20564	9
1-20565	220, 223
1-20566	425, 426
1-20568	37, 52
1-20569	131
1-20569-1	131
1-20569-2	131
1-20569-3	131
*1-20735-1001	36, 39, 50
1-21000	375
1-21001	375
1-21007	106, 109
1-21008	106, 109
1-21012	373
1-21018	282, 283
1-21018-1	282
1-21018-2	283
1-21018-3	282
1-21021	385
1-21024	315
1-21026	365
1-21030	490
1-21041	374
1-21041-1	374
1-21043	258, 260, 262
1-21044	142
1-21047	467
1-21048	467
1-21050	300, 301
1-21051	275, 276
1-21052	275, 276
1-21053	261
1-21055	215
1-21055-1	215
1-21061	423
1-21062	423
1-21063	277
1-21064	269
1-21065	88
1-21066	218A, 219
1-21074	36
1-21075	77
1-21075-1	77
1-21079	402
1-21082	246, 248
1-21086	484
1-21087	346
1-21087-1	346
1-21087-2	346
1-21342	374
1-21342-1	374
1-21351	39, 50
1-21352	237
1-21353	237
1-21354	237
1-21356	490, 491
1-21357	190
1-21361	346
1-21362	423

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
1-21363	137
1-21363-1	138
1-21366	423
1-21367	423
1-21376	512, 527, 544
1-21382	374
1-21385	272
*1-21386	519, 520, 521
1-21389	140
1-21389-1	140
1-21390	272
1-21390-1	272
1-21391	272
1-21391-1	272
1-21392	272
1-21392-1	272
1-21393	271
1-21395	271
1-21395-1	271
1-21396	271
1-21397	272
1-21397-1	272
1-21399	271
1-21400	155, 398
1-21401	228
1-21402	424
1-21402-1	424
1-21424	300, 301
1-21434	503, 518, 531
1-21434-1	503, 518, 531
1-21437	36
1-21440	350, 351
1-21441-4	277
1-21441-5	277
1-21441-90	277
1-21441-90A	277
1-21467	261, 263
1-21470	354
1-21472	259, 261, 263
1-21474	353
1-21477	503, 518, 531
1-21480	450
1-21481	232
1-21481-1	232
1-21483	482
1-21487	439
1-21488	439
1-21494	348, 374, 476
1-21494-1	374
1-21497	366
1-21535-1	534
1-21535-2	534
1-21535-60	534
1-21535-60A	534
1-21707	540
1-21902-4	277
1-21902-5	277
1-21902-84	277
1-21902-84A	277
1-21911	349
1-21914	506, 528, 545
1-21914-1	506, 527, 545
1-21915	503, 518, 531
1-21920	506, 528
1-21920-1	506, 528
1-21920-2	506, 528
1-21921	505, 524, 538
1-21922	506, 524
1-21923	364A
1-21923-1	364A
1-21924-3-0218	270
1-21924-4-0281	271, 272
1-21924-4-0375	272
1-21927	272
1-21943	222
1-21944	242
1-21946	222
1-21946-1	533
1-21949	269, 270
1-21949-1	270
1-21949-2	268
1-21950	490
1-21951	514, 526
1-21952	514, 526
1-21953	386
1-21954	386
1-21955	386
1-21956	271
1-21958	271
1-21959-3	501
1-21959-8	506, 542
1-21963	271, 272
1-21964	349
1-21965	349
1-21966	268A, 269, 270
1-21970	366
1-21974	506, 526, 544
1-21977	230
1-21980	225
1-21989	137, 138
1-21989-1	137, 138
1-21993	88
1-21994	280, 282, 286
1-22104-0-32	193
1-22506	540
1-22602	224
1-22603	224
1-22605	429
1-22605-1	429
1-22606	429
1-22606-1	429
1-22607	239
1-22609	430
1-22610	430
1-22611	430
1-22612	430
1-22613	430
1-22614	430
1-22615	430
1-22616	430
1-22617	430
1-22618	430
1-22619	430
1-22621	430
1-22622	430
1-22622-1	430
1-22623	430
1-22624	540
1-22626	255, 256
1-22628	472
1-22631	156
1-22639	165, 236
1-22644	416
1-22651	386
1-22654	428
1-22655	301
1-22656	301
1-22658	429
1-22658-1	429
1-22659	429
1-22660	429
1-22661	428A, 429
1-22661-1	429
1-22673	429
1-22673-1	429
1-22674	429
1-22679	424
1-22679-1	424
1-22681	230
1-22681-1	230
1-22682	193
1-22684	193
1-22685	436
1-22689	230
1-22707-12	355
1-22707-30	226
1-22804	301
1-22928-5	316, 425, 488
1-22930	212
1-22930-1	211, 212, 213
1-22946-1	7, 8
1-22955-1	532
1-22959-2	316
1-22970-1	39, 254, 256
1-22986-1	428
1-22987-1	433
1-22989-1	149, 150
1-22989-2	149, 150
1-22989-3	149, 150
1-22989-4	150
1-22994-1	150
1-22994-2	150
1-23238-2	457
1-23308	233
1-23309	532
1-23447	78
1-23501	346, 385
1-23501-1	346, 385
1-23501-2	346, 385
1-23504	253
1-23504-1	253
1-23504-2	253
1-23504-3	253
1-23509	26
1-23509-1	26
1-23510	372
1-23528	524, 238
*1-23534	519, 520, 521, 522, 533
1-23535	221, 223, 224
1-23545	306
1-23552	213
1-23553	518, 532
1-23557	293
1-23561	527, 544
1-23565	297
1-23568	149
1-23569	149
1-23580	537
1-23580-1	537
1-23580-2	537
1-23580-3	428
1-23582	453
1-23583	453
1-23584	149
1-23586	515, 529, 542
1-23587	515, 529, 542
1-23591	149
1-23594	300
1-23594-1	344
1-23594-2	410
1-23737	349
1-24192	316
1-24193	374
1-24194-1	546
1-24194-2	546
1-24194-3	546
1-24194-4	546
1-24206	237
1-24212	427
1-24213	370
1-24214	427
1-24220	488
1-24222-1	291, 294
1-24222-2	293
1-24222-3	291, 293
1-24222-4	291, 292, 293
1-24222-5	293
1-24222-6	292, 293, 294
1-24222-15	293
1-24223	10
1-24223-1	10
1-24224	428
1-24228	412
1-24228-1	412
1-24228-14S	412
1-24234-1	312
1-24234-2	310
1-24235-1	312
1-24236-1	316, 317
1-24237-2	316
1-24238-1	310
1-24239-1	316
1-24239-2	316
1-24239-3	316
1-24246	428
1-24247-1	428
1-24287-1	316
1-24580-1	488
1-24581	137
1-24613-1	230
1-24613-2	230
1-24613-4	230
1-24614	230
1-24620	538
1-24623	194
1-24625	291
1-24627	76
1-24907-4	194
1-24920	545
1-24929	360
1-24952	293
1-24958	293
1-24965	293
1-24968	293
1-24975	213
1-24985	30
1-24992-1	374
1-24995	425
1-25507	151
1-25507-1	151
1-25516	293
1-25516-1	293
1-25553	183A
1-25577	141, 184
1-26275	350
1-26276	412
1-26403-1	239
1-26457	141
1-26474	193
1-26475	193
1-26858	197
1-27180	61, 108
1-27613	393
1-27615	290
1-27645	290
1-27924	297
1-27925	297
1-28064	410
3-5369	454
3-6104-1	371
3-6104-3	370, 371
3-6104-5	370, 371
3-6104-26	371
3-6104-27	370, 371
3-6104-47	370
3-6104-55	370
3-6104-57	370
3-6104-59	371
3-6104-60	370
3-6104-61	370
3-6104-62	370
3-6104-69	370
3-6104-70	371
3-6475-2	145

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
3-6475-3	145
3-6475-6	145
3-6475-7	145
3-6481	132
3-6481-1	132
3-6481-2	132
3-6481-3	132
3-6481-4	132
3-6481-5	132
3-6512	148
3-6512-1	148
3-6513	108
3-6513-1	108
3-6520-1	108
3-6520-2	108
3-6521-1	106
3-6521-2	106
3-6523-1	106, 108
3-6531-1	147
3-6532-1	147
3-6533-1	148
3-6534	148
3-6535	148
3-6538	198
3-6539	198
3-6540	198
3-6541	198
3-6542	198
3-6543	198
3-6544	198
3-6544-1	198
3-6552	171, 176
3-6555-2	106
3-6562	167
3-6565	148
3-6567	171
3-6567-1	171
3-6567-2	171
3-6567-3	171
3-6581-7	134
3-6581-13	134
3-6585	108
3-6585-1	108
3-6586	108
3-6586-1	108
3-6587	108
3-6587-1	108
3-6588	108
3-6588-1	108
3-6589	108
3-6589-1	108
3-6658	106
3-6658-1	106
3-6659	106
3-6659-1	106
3-6660	106
3-6660-1	106
3-6661	106
3-6661-1	106
3-6672	464
3-6672-1	464
3-6691	69
3-6691-2	69
3-6692-2	69
3-6705	108
3-6738	448
3-6738-1	448
3-6738-3	186, 354, 448
3-6738-5	186
3-6738-6	186
3-6738-7	186
3-6738-8	186
3-6738-9	354
3-6738-10	354
3-6738-11	354
3-6738-12	355
3-6738-17	186, 355, 448
3-6755	106
3-6864-119	441
3-6964-1	467
3-7000	170
3-7012	186
3-7012-1	186
3-7012-2	187
3-7022	186
3-7022-1	186
3-7060-5	199
3-7060-6	199
3-7060-8	199
3-7135-1	477
3-7135-3	477
3-7139	477
3-7139-1	477
3-7139-2	477
3-7139-3	477
3-7194-6	358
3-7194-7	358
3-7194-8	358
3-7194-9	358
3-7194-10	358
3-7194-11	358
3-7366	169
3-7366-1	169
3-7817	176
3-7817-1	176
3-7819-4	441
3-7820	171
3-7820-1	171
3-7833	248
3-7838	170
3-7838-1	170
3-7838-3	175
3-7838-4	175
3-7838-8	170, 176
3-7838-9	170, 176
3-7854	184
3-7934-1	439
3-7934-2	439
3-7941	195
3-7941-2	195
3-7941-5	195
3-7941-6	195
3-7941-7	195
3-7941-8	195
3-7942	195
3-7942-1	195
3-7942-2	195
3-7942-3	195
3-7942-4	195
3-7942-5	195
3-7942-10	195
3-7942-11	195
3-7943	195
3-7943-1	195
3-7986-1	195
3-7986-2	195
3-7986-3	195
3-7986-4	195
3-7987-1	195
3-7987-2	195
3-7987-3	195
3-7987-4	195
3-8010-12	351, 352
3-8010-13	351
3-8202-90	63
3-8202-91	63
3-8202-99	53
3-8202-100	38, 51
3-8406	288
3-8406-1	288
3-8728-4	471, 473
3-8728-5	471, 473
3-8728-6	471, 473
3-8728-7	471, 473
3-8744-1	106
3-8744-2	106
3-8746-1	106
3-8746-2	106
3-8748-4	70, 108
3-8752-1	92
3-8760	6
3-8761	6
3-8768	69
3-8768-1	69
3-8768-2	69
3-8785	10
3-8785-1	10
3-8786	10
3-8786-1	10
3-8787	10
3-8787-1	10
3-8793-3	289
3-9073-2	357
3-9073-4	357
3-9095	186
3-9164	247
3-9182	12
3-9182-1	12
3-9183	12A
3-9183-1	12A
3-9184	12A
3-9185	12A
3-9186	12A
3-9215-125	480
3-9215-214	470
3-9215-215	470
3-9215-216	468A
3-9215-218	468A
3-9215-219	468A
3-9215-220	480
3-9215-227	480
3-9215-228	480
3-9215-233	480
3-9215-243	480
3-9215-247	468A
3-9215-248	468A
3-9215-249	480
3-9215-251	480
3-9215-252	480
3-9215-253	480
3-9215-254	480
3-9215-255	480
3-9215-256	480
3-9215-257	480
3-9215-258	480
3-9215-259	480
3-9215-260	480
3-9215-261	480
3-9215-262	480
3-9215-263	480
3-9215-274	480
3-9215-275	480
3-9215-276	480
9-9215-277	480
3-9215-278	480
3-9215-279	480
3-9215-280	480
3-9215-286	480
3-9215-290	468A
3-9215-299	480
3-9215-300	480
3-9215-301	480
3-9215-302	480
3-9215-303	480
3-9215-305	468A
3-9215-306	480
3-9215-307	480
3-9215-308	480
3-9215-309	480
3-9215-312	468A
3-9272	15
3-9273	15
3-9277	13
3-9277-1	12
3-9277-2	12A
3-9277-3	13
3-9277-4	12
3-9277-5	12A
3-9286	59, 60
3-9286-1	59, 60
3-9287	284
3-9288	249
3-9351	282
3-9364-1	26
3-9364-2	27
3-9368	18
3-9371	18
3-9372	18
3-9387-2	58
3-9387-3	58
3-9387-4	57
3-9387-5	57
3-9466	408
*3-9582	29, 34, 45
3-9582-1	192
3-9584-1	452
3-9584-2	452
3-9584-3	452
3-9639	289
3-9639-1	289
3-9639-2	289
3-9639-3	289
3-9640-4	289
3-9640-5	289
3-9640-6	289
3-9640-9	289
3-9640-14	289
3-9772	426
3-9772-1	426
3-9773	426
3-9773-1	426
3-9774-7	454
3-9774-8	454
3-9775	448
3-9775-1	448
3-9775-3	448
3-9777	448
3-9777-1	448
3-9778	439
3-9778-1	439
3-9782	10
3-9782-1	10
3-9799-9	186
3-9799-10	186
3-9864	250
3-10080-2	243, 244
3-10293	457
3-10296	452
3-10296-1	452
3-10298	248
3-10300	441
3-10301	441
3-10307	196
3-10307-1	196
3-10309	54
3-10309-1	54
3-10309-2	55
3-10309-3	55
3-10390	349
3-10396	195
3-10396-1	195
3-10407	136
3-10475-1	398

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
3-10475-2	398
3-10475-3	398
3-10519-1	398
3-10519-2	398
3-10519-3	398
3-10561	349
3-10565	349
3-10565-1	349
3-10569-4	481, 482
3-10569-10	481, 482
3-10594	472
3-10750	181
3-10750-1	181
3-10750-10	181
3-10750-11	181
3-10750-14	181
3-10750-15	181
3-10755	178
3-10755-1	178
3-10756-1	165
3-10757	167
3-10758	390
3-10758-1	390
3-10761	167
3-10762	167
3-10764-1	80
3-10767	453
3-10812	305
3-10813-1	305
3-10814	305
3-10815	176
3-10825	483
3-10825-4	483
3-10826	482
3-10826-1	482
3-10826-6	482
3-10827	482
3-10827-4	482
3-10939	163
3-10939-1	163
3-10948-2	433
3-10948-3	433
3-10949	151
3-10949-3	151
3-10995	365
3-11002	311
3-11002-1	311
3-11002-2	311
3-11002-3	311
3-11002-4	312
3-11002-5	312
3-11002-6	310
3-11002-7	310
3-11002-8	312
3-11002-9	312
3-11003	314, 316
3-11003-1	314, 316
3-11003-2	313
3-11003-3	313
3-11003-4	314, 316, 317
3-11003-5	314, 316, 317
3-11003-6	313, 316, 317
3-11003-7	313, 316, 317
3-11003-8	313, 314
3-11003-9	313, 314
3-11073-1	250
3-11074	250
3-11074-1	250
3-11075	250
3-11087	148
3-11130-4	311
3-11130-6	311
3-11130-7	311
3-11130-8	311
3-11130-11	311
3-11130-12	311
3-11133-6	312
3-11133-8	312
3-11133-10	312
3-11133-11	180
3-11133-12	313
3-11133-18	312
3-11133-19	312
3-11133-20	312
3-11133-21	313
3-11133-22	180
3-11133-23	312
3-11133-24	312
3-11133-25	180
3-11133-26	312
3-11133-27	313
3-11138-2	312
3-11138-3	312
3-11138-4	312
3-11138-5	312
3-11138-8	312
3-11138-9	312
3-11143	410
3-11146-2	306
3-11146-3	306
3-11146-4	306
3-11146-7	306
3-11146-8	306
3-11147-2	306
3-11147-4	306
3-11147-7	306
3-11147-8	306
3-11154	85
3-11163	354
3-11163-1	354
3-11163-3	354
3-11166	329
3-11257	398
3-11257-1	398
3-11257-2	398
3-11257-3	398
3-11260	358
3-11263	466, 467
3-11263-1	466, 467
3-11263-2	466, 467
3-11330	381
3-11332	328
3-11332-1	328
3-11350	329
3-11350-3	329
3-11351	481
3-11351-1	481
3-11352	482
3-11352-2	482
3-11358	381
3-11359-1	381
3-11370	252
3-11370-4	252
3-11375	151
3-11375-1	151
3-11385-1	25
3-11388	380
3-11388-5	380
3-11389	358
3-11389-1	358
3-11410	380
3-11412	382
3-11413	381
3-11413-2	381
3-11419	383
3-11419-1	383
3-11424	382
3-11425	380
3-11426	380
3-11464	198
3-11464-1	198
3-11474	477
3-11474-1	477
3-11474-2	478
3-11474-4	478
3-11474-5	478
3-11477	380
3-11517	315
3-11517-1	315
3-11517-2	315
3-11517-3	315
3-11571-1	164
3-11572-1	156
3-11572-3	154
3-11576	207
3-11579	325
3-11579-1	325
3-11579-2	325
3-11579-3	325
3-11579-4	326
3-11579-5	326
3-11582-4	180
3-11582-5	180
3-11582-6	180
3-11582-7	180
3-11582-9	180
3-11584	335
3-11584-1	335
3-11584-2	335
3-11584-3	336
3-11585	336
3-11585-1	336
3-11620	83
3-11620-1	83
3-11620-2	83
3-11624-2	310
3-11624-3	310
3-11624-4	310
3-11624-5	310
3-11624-8	310
3-11624-9	310
3-11657	336
3-11657-1	336
3-11657-2	336
3-11657-3	336
3-11717	328, 329
3-11720	70
3-11720-1	61
3-11721	107
3-11721-1	109
3-11722	199
3-11733	92
3-11738	89
3-11738-1	89
3-11741	137
3-11741-1	137
3-11741-2	137
3-11743	34
3-11743-1	34
3-11743-2	34
3-11743-3	34
3-11745	107
3-11745-1	107
3-11745-2	109
3-11746	106
3-11746-1	107
3-11746-2	109
3-11747	108
3-11747-1	108
3-11749	108
3-11749-1	108
3-11751	61
3-11751-1	61
3-11751-2	70
3-11751-3	67
3-11752	58
3-11752-1	58
3-11752-2	70
3-11752-3	67
3-11752-4	61
3-11752-5	61
3-11752-6	60
3-11752-7	60
3-11753	316
3-11754-1	161
3-11754-4	161
3-11756	69
3-11756-1	69
3-11757	250
3-11757-1	250
3-11758	161
3-11758-1	161
3-11758-3	161
3-11759	34
3-11759-1	34
3-11759-2	34
3-11759-3	34
3-11760	250
3-11760-1	250
3-11760-2	250
3-11762-4	60
3-11762-5	60
3-11768	58
3-11768-1	58
3-11768-2	58
3-11768-3	58
3-11770	195
3-11770-1	195
3-11770-2	195
3-11770-3	195
3-11771	196
3-11771-1	196
3-11771-2	196
3-11771-3	196
3-11774	198
3-11774-1	198
3-11774-11	199
3-11774-12	199
3-11775	67
3-11776	273
3-11776-1	273
3-11779	169
3-11779-1	169
3-11810	309
3-11810-1	309
3-11810-2	309
3-11810-3	309
3-11810-4	309
3-11810-5	309
3-11811	309
3-11811-1	309
3-11811-2	309
3-11811-3	309
3-11811-4	309
3-11811-5	309
3-11811-6	309
3-11812	309
3-11812-1	309
3-11812-2	309
3-11812-3	309
3-11812-4	309
3-11812-5	309
3-11812-6	309
3-11813	309
3-11813-1	309
3-11813-2	309
3-11813-3	309
3-11813-4	309
3-11813-5	309
3-11813-6	309
3-11852	188
3-11852-3	188
3-11852-4	188

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
3-11852-5	188
3-11852-6	188
3-11852-7	188
3-11854	31
3-11857	177
3-11864	172
3-11865	172
3-11866	132
3-11866-1	132
3-11866-2	132
3-11866-3	132
3-11867	177
3-11870	457
3-11871	471
3-11875	457
3-11875-1	457
3-11875-2	457
3-11875-3	457
3-11880	145
3-11880-1	145
3-11882	475
3-11882-1	475
3-11887	163
3-11887-1	163
3-11888	472
3-11888-1	472
3-11889	461, 462
3-11890	15
3-11890-1	15
3-11891	18
3-11891-1	18
3-11891-2	73
3-11894	308
3-11896	469
3-11896-1	469
3-11896-3	469
3-11896-6	469
3-11896-7	469
3-11897	456
3-11897-1	456
3-11900	256A, 257
3-11900-1	257
3-11905	459
3-11906	459
3-11906-1	459
3-11908	459
3-11909	354
3-11909-1	354
3-11953	478
3-11953-1	478
3-11953-2	475
3-11953-3	478
3-11953-4	478
3-11953-5	475
3-11953-6	478
3-11953-7	478
3-11953-8	475
3-11953-9	475
3-11953-10	475, 478
3,11953-11	475
3-11953-12	478
3-11953-13	478
3-11953-14	475
3-11957	325
3-11961	383
3-11961-1	383
3-11961-2	383
3-11968-19	46
3-11990	472
3-11990-3	472
3-11990-4	472
3-11991	188
3-11991-3	188
3-11996	472
3-11996-3	472
3-11996-4	472
3-11997	106
3-11997-1	69
3-11999-2	472
3-12000-2	472
3-12003-1	51
3-12003-2	53
3-12003-4	51
3-12004	53
3-12005	106
3-12009	148
3-12009-1	148
3-12010	433
3-12010-1	433
3-12012	108
3-12018	380
3-12018-1	380
3-12023	473
3-12023-1	473
3-12023-2	473
3-12025	471
3-12025-1	471
3-12029	472
3-12029-2	472
3-12029-3	472
3-12035	164, 390
3-12035-1	164, 390
3-12035-2	164, 390
3-12035-3	164, 390
3-12038-1	181
3-12038-3	181
3-12038-4	181
3-12040-2	9
3-12040-5	87
3-12040-11	87
3-12041-2	9
3-12041-5	87
3-12041-7	9
3-12041-11	87
3-12057	38
3-12057-1	38
3-12061	437
3-12061-1	437
3-12062-16	288
3-12062-17	288
3-12062-18	288
3-12062-19	288
3-12071	53
3-12071-1	52
3-12077	90
3-12077-2	90
3-12077-3	90
3-12077-4	90
3-12077-5	90
3-12077-6	90
3-12077-7	90
3-12078	90
3-12078-1	90
3-12080	332
3-12081	30
3-12081-1	30
3-12083	66
3-12084	335
3-12085	66
3-12085-1	66
3-12085-2	66
3-12087	93
3-12087-1	93
3-12087-2	93
3-12087-3	93
3-12087-4	93
3-12087-5	93
3-12087-6	93
3-12087-7	93
3-12087-8	93
3-12087-9	93
3-12088-36-42	169, 441
3-12088-36-48	46
3-12088-48-48	37, 52, 53
3-12089-32-32	445
3-12089-40-40	38, 53, 365
3-12089-48-48	51
3-12090	51
3-12090-1	38, 53, 365
3-12090-2	37, 52, 53
3-12090-4	46
3-12090-6	169, 441
3-12090-8	63
3-12090-9	63
3-12090-12	445
3-12090-13	38
3-12095	474
3-12095-1	474
3-12095-3	474
3-12096	50
3-12096-1	50
3-12098-3	115
3-12098-4	115
3-12099	410
3-12100	335
3-12100-1	335
3-12101	132
3-12104	332
3-12105	332
3-12106	474, 475
3-12106-1	474, 475
3-12106-3	474, 475
3-12107	474
3-12107-1	474
3-12107-3	474
3-12109	132
3-12109-1	132
3-12109-3	132
3-12109-4	132
3-12158	481
3-12158-1	481
3-12158-6	481
3-12170	46
3-12175	434
3-12176	132
3-12176-1	132
3-12176-2	132
3-12176-3	132
3-12176-4	132
3-12176-5	132
3-12176-6	132
3-12176-7	132
3-12176-8	132
3-12176-9	132
3-12176-10	132
3-12176-11	132
3-12176-12	132
3-12176-13	132
3-12176-14	132
3-12176-15	132
3-12176-16	132
3-12176-17	132
3-12176-18	132
3-12176-19	132
3-12176-20	132
3-12176-21	132
3-12176-22	132
3-12176-23	132
3-12177	132
3-12178	132
3-12179	132
3-12179-1	132
3-12179-2	132
3-12179-3	132
3-12179-4	132
3-12179-5	133
3-12180	133
3-12180-1	133
3-12180-2	133
3-12182	133
3-12183	133
3-12184	133
3-12184-1	133
3-12185	133
3-12185-1	133
3-12186	133
3-12186-1	133
3-12186-2	133
3-12186-3	133
3-12186-4	133
3-12186-5	133
3-12186-6	133
3-12186-7	133
3-12187	133
3-12188	63
3-12188-1	63
3-12210	32
3-12210-1	32
3-12210-2	49
3-12210-3	49
3-12210-4	49
3-12210-5	49
3-12211	144
3-12211-1	144
3-12211-4	144
3-12211-5	144
3-12211-7	144
3-12211-8	144
3-12212	63
3-12212-1	63
3-12213	13
3-12213-1	13
3-12213-2	14
3-12213-3	14
3-12222	471
3-12222-1	471
3-12222-3	471
3-12223	155
3-12226	51
3-12226-1	51
3-12226-2	51
3-12227-1	481
3-12227-2	481
3-12229	262, 264
3-12229-4	259, 260
3-12291	259, 260, 262
3-12292	264
3-12295	262, 264
3-12302	29
3-12303	29
3-12306	51
3-12306-1	51
3-12306-2	51
3-12306-3	51
3-12309	152
3-12309-1	152
3-12309-4	152
3-12311	51
3-12311-1	51
3-12311-2	51
3-12312	262, 264
3-12313	265
3-12317	371
3-12317-1	371
3-12317-2	371
3-12408	357
3-12409	74
3-12409-3	74
3-12470	514, 526
3-12470-1	514, 526
3-12471	147
3-12471-1	147
3-12473	162

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
3-12474	514, 526
3-12474-1	514, 526
3-12474-2	514, 526
3-12474-4	514, 526
3-12479	504, 519, 532
3-12480	461
3-12480-1	461
3-12481-27	258, 261, 262
3-12481-35	259, 261, 262
3-12481-43	259, 261, 262
*3-12482	259, 260, 262
3-12482-1	258, 260, 262
*3-12485	259, 260, 262
*3-12486	259, 260, 262
*3-12487	259, 260, 262
*3-12487-1	259, 260, 262
3-12487-2	259, 260
3-12487-3	259, 260, 262
3-12571	314
3-12571-1	314
3-12571-2	314
3-12571-3	314
3-12572	332, 382, 388
3-12574	386
3-12575	388
3-12576	388
3-12577	388
3-12578	387
3-12578-9	388
3-12578-10	387
3-12579-7	388
3-12580	200
3-12580-1	200
3-12580-2	200
3-12580-4	200
3-12580-5	200
3-12582	483
3-12723	464
3-12723-1	464
3-12723-2	500
3-12726	483, 484
3-12728	57
3-12728-1	57
3-12728-2	57
3-12728-3	58
3-12728-4	68
3-12728-5	68
3-12776	381
3-12776-1	383
3-12776-2	380
3-12776-3	381
3-12776-4	382
3-12776-5	382
3-12778	503, 518, 531
3-12781-1	500
3-12785	512
3-12785-1	512
3-12785-3	512
3-12785-4	512
3-12787	513, 525, 540
3-12787-1	513, 525, 540
3-12788-1	256A
3-12788-2	257
3-12788-3	257
3-12910	361
3-12910-1	361
3-12910-2	361
3-12910-3	361
3-12914	427
3-12920	149
3-12920-1	149
3-12921	473
3-12925	76
3-12925-1	76
3-12925-4	76
3-12926	489
3-12926-2	489
3-12956	442
3-12964	489
3-12964-1	489
3-12966-3	115
3-12966-4	115
3-12969	442
3-12969-1	442
3-12970	286
3-12971	280
3-12972	466
3-12972-1	466, 467
3-12972-2	466, 467
3-12974	214
3-12976	281
3-12978	152
3-12980	484
3-12981	445
3-12981-1	445
3-12982	476
3-12984	352
3-12984-1	352
3-12985	13
3-12985-1	13
3-12985-2	13
3-12985-3	13
3-12986	244, 372
3-12986-1	372
3-12986-3	372
3-12986-4	372
3-12986-5	244
3-12987	441
3-12988	243
3-12988-4	243, 244
3-12988-5	243
3-12989	445
3-12989-1	445
3-12991	220
3-12992	483
3-12992-1	483
3-12994	288
3-12994-1	288
3-12995	483
3-12995-1	483
3-12996	484
3-12998	241
3-12999	483
3-12999-1	483
3-12999-2	483
3-13000-4	282
3-13000-5	282
3-13001	316
3-13001-1	316
3-13002	164
3-13002-1	164
3-13004	236
3-13005	236
3-13006	243, 244
3-13007	236
3-13009	465
3-13370	477
3-13370-1	477
3-13371	243
3-13371-1	243
3-13371-2	243
3-13372	442, 444
3-13372-1	442, 444
3-13374	473
3-13374-1	473
3-13380	442
3-13380-1	442
3-13380-2	442
3-13380-3	442
3-13380-4	442
3-13430	214
3-13432	157
3-13432-1	157
3-13435	457
3-13436	118
3-13438	282
3-13438-1	282
3-13438-2	283
3-13438-3	284
3-13438-4	283
3-13438-5	284A
3-13439-1	219
3-13440	120
3-13442	374
3-13443	374
3-13443-1	374
3-13443-2	374
3-13444	284
3-13444-1	284
3-13444-2	284
3-13447	171
3-13447-1	171
3-13447-2	171
3-13448	476
3-13451-4	282
3-13451-5	282
3-13452	105
3-13452-1	105
3-13454	138
3-13454-1	138
3-13454-4	282
3-13454-5	282
3-13456	425
3-13456-1	426
3-13456-2	425
3-13456-3	425, 426
3-13456-4	425, 426
3-13456-5	425, 426
3-13456-6	426
3-13457-3	282
3-13457-5	282
3-13458-1	423
3-13460	375
3-13460-1	375
3-13460-2	375
3-13461	375
3-13463	423
3-31464-4	282
3-13464-5	282
3-13466	217
3-13466-1	217
3-13467-4	283
3-13467-5	282
3-13468	423
3-13470	164
3-13485	425
3-13486	455
3-13488	425
3-13490-3	283
3-13490-4	283
3-13491-3	283
3-13491-4	283
3-13492	215
3-13493	215
3-13493-1	215
3-13494	215
3-13494-1	215
3-13498	427
3-13499	427
3-13499-1	427
3-13500	427
3-13501	427
3-13502	323
3-13503	488
3-13503-1	488
3-13503-2	488
3-13503-3	488
3-13503-4	488
3-13504-13	38
3-13506-2	320
3-13507	240
3-13509	218
3-13510	218
3-13510-1	218
3-13511	218
3-13512	218
3-13513	120
3-13513-1	120
3-13513-2	121
3-13513-3	121
3-13514	240
3-13516	121
3-13519-3	239
3-13519-5	239
3-13521	241
3-13521-1	241
3-13522	237
3-13525	237
3-13525-1	238
3-13527	239
3-13528	46
3-13529	416
3-13529-1	416
3-13530	51
3-13530-1	51
3-13531	240
3-13532	424A
3-13532-1	424A
3-13533	447
3-13533-1	447
3-13533-2	447
3-13533-3	447
3-13533-4	448
3-13534	238
3-13535	246
3-13536	245
3-13537	246
3-13537-1	246
3-13538	245
3-13538-1	245
3-13539	246
3-13540	245
3-13541	235
3-13542	373
3-13543	416
3-13543-1	416
3-13544	427
3-13545-1	427
3-13545-2	427
3-13545-3	427
3-13546	427
3-13548	427
3-13549	236
3-13551	477
3-13551-1	477
3-13552	235
3-13553	180
3-13554	246
3-13555	245
3-13556	424A
3-13558	448
3-13558-1	448
3-13558-2	448
3-13558-4	448
3-13560	280, 282
3-13560-6	286
3-13562	117
3-13563	214
3-13564	503, 518, 531
3-13564-2	503, 518, 531
3-13565	227
3-13566	218
3-13566-1	218
3-13567-1	470

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
3-13567-2	487
3-13567-3	487
3-13567-4	470
3-13567-8	512
3-13568	236
3-13568-1	236
3-13569	86
3-13569-1	86
3-13570-3	120
3-13570-4	120
3-13571	380
3-13571-1	380
3-13572	121
3-13572-1	121
3-13572-2	121
3-13573	235
3-13574	236
3-13574-1	236
3-13575	236
3-13576	215
3-13577	246
3-13579	485
3-13579-1	485
3-13580	214
3-13580-1	214
3-13581	218, 218A
3-13581-1	218, 219
3-13582	218A
3-13583	238
3-13584	216
3-13587	143
3-13589	229
3-13589-1	229
3-13590	229
3-13590-1	229
3-13591	229
3-13591-1	229
3-13592	228
3-13592-1	229
3-13592-2	229
3-13592-3	229
3-13594	323
3-13594-1	323
3-13596	473
3-13597	483
3-13597-1	483
3-13598	377
3-13599	238
3-13600	238
3-13601	448
3-13601-1	448
3-13602	241
3-13602-1	241
3-13603	221
3-13603-1	222
3-13603-2	222
3-13603-3	222
3-13603-4	222
3-13603-5	222
3-13603-6	222
3-13603-7	222
3-13604	117
3-13607	218
3-13608	124
3-13609	227
3-13609-1	227
3-13610	164
3-13610-4	164
3-13611	473
3-13612	214
3-13613-1	280, 281, 286
3-13613-2	280, 281, 286
3-13613-3	280, 281, 286
3-13613-5	280, 281, 286
3-13613-7	286
3-13613-8	280
3-13613-9	281
3-13614	280, 281, 286
3-13616	222
3-13616-1	222
3-13617	217
3-13618	217
3-13618-1	217
3-13622	80
3-13622-1	80
3-13625	236
3-13625-1	236
3-13626	477
3-13627	381
3-13627-1	381
3-13628	222
3-13629	503
3-13650	152
3-13652	125
3-13652-1	125
3-13653	233
3-13654	117
3-13655	243, 244
3-13655-1	243, 244
3-13655-2	243, 244
3-13655-3	243, 244
3-13656	223
3-13657	238
3-13658	121
3-13659	238
3-13659-1	238
3-13660	473
3-13661	424
3-13661-1	424
3-13662	350
3-13663	291
3-13664	39, 51
3-13665	223
3-13665-1	223
3-13666	223
3-13666-1	223
3-13669	226
3-13670-4	154
3-13670-5	154
3-13675-1	425
3-13675-3	425
3-13675-4	425
3-13680	364
3-13680-1	364
3-13680-3	365
3-13681	25
3-13681-1	25
3-13681-2	25
3-13681-3	25
3-13682	25
3-13682-1	25
3-13682-2	25
3-13683	25
3-13683-1	25
3-13683-2	25
3-13684	25
3-13684-1	25
3-13684-2	25
3-13690	123
3-13691	123
3-13692	122, 123
3-13693	214
3-13695	233
3-13696	465
3-13697	117
3-13699	234
3-13699-1	234
3-13700	373
3-13701	275, 276
3-13704	231
3-13704-1	231
3-13705	125
3-13705-1	125
3-13707	117
3-13708	117
3-13708-1	117
3-13709	365
3-13709-1	365
3-13709-2	365
3-13709-3	365
3-13710	236
3-13711	221
3-13711-1	221
3-13714	225
3-13714-1	225
3-13714-360	225
3-13716	480
3-13718	114
3-13720	114
3-13721	224
3-13722	224
3-13724	124
3-13725	296
3-13727	222
3-13728	235
3-13729	118
3-13730	118
3-13730-1	118
3-13730-2	118
3-13731-3	235
3-13731-4	235
3-13733	352
3-13733-1	352
3-13734	365
3-13735	225
3-13735-1	225
3-13736	126
3-13737-2	224
3-13737-3	224
3-13737-4	224
3-13740-1	185
3-13740-2	188
3-13740-3	185
3-13742	270
3-13742-2	270
3-13743	217
3-13744	217
3-13745	217
3-13745-1	217
3-13746	117
3-13747-1	227
3-13748-2	275, 276
3-13749	275, 276
3-13750	270
3-13750-2	270
3-13752	226
3-13752-1	226
3-13753	275, 276
3-13757	289
3-13757-1	289
3-13758	226
3-13758-1	226
3-13759	226
3-13759-1	226
3-13762	226
3-13763	231
3-13763-1	231
3-13763-2	231
3-13763-3	231
3-13763-4	231
3-13763-5	231
3-13764	271
3-13765	271
3-13766	271
3-13767	271
3-13767-1	271
3-13767-2	271
3-13768	271
3-13769	271
3-13770	121
3-13770-2	121
3-13771	288
3-13771-1	288
*3-13772	338, 339, 340
*3-13772-1	339, 340, 341
*3-13772-2	339, 340, 341
3-13772-3	339, 340, 341
3-13773	121
3-13774	200
3-13774-1	200
*3-13778	338, 339, 340
*3-13778-1	338, 339, 340
3-13782	205
*3-13783	338, 339, 340
*3-13783-1	338, 339, 340
3-13785	14
3-13785-3	14
3-13786-1	269
3-13788	237
3-13789-1	475, 478
3-13789-2	478
3-13789-4	475
3-13791	270
3-13791-1	270
3-13792	383
3-13794-8	24
3-13794-9	24
3-13795	166
3-13796-47	259, 261, 262
3-13796-51	261, 262
3-13796-53	262
3-13797	425, 426
3-13799	277
3-13802	268
3-13802-1	268
3-13803	268
3-13803-1	268
3-13803-2	267
3-13803-3	267
3-13804	277
3-13806-6	286
3-13806-7	280
3-13806-8	281
3-13807-1	290
3-13807-3	289
3-13808-6	286
3-13808-7	280
3-13808-8	281
3-13900	147
3-13900-1	147
3-13901	284
3-13901-3	284A
3-13902	285
3-13903	444
3-13903-1	444
3-13903-2	444
3-13905-1	64
3-13905-2	64
3-13905-3	64
3-13905-5	64
3-13906	155
3-13906-1	155
3-13907-2	172
3-13908	24
3-13909	266, 267
3-13909-1	266, 267
3-13910	383
3-13913	329
3-13914	329
3-13920	234
3-13920-1	234
3-13921	234
3-13921-1	234

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
3-13922	234
3-13922-1	234
3-13923	384
3-13924	241
3-13926	424
3-13927	405
3-13928	280, 286
3-13928-5	281, 286
3-13929	280, 286
3-13930	136, 194
3-13930-1	136, 194
3-13930-2	136, 194
3-13932	386
3-13932-7	193
3-13932-8	193
3-13932-15	193
3-13932-18	193
3-13932-19	193
3-13932-20	193
3-13932-21	193
3-13934	382
3-13935	232
3-13935-1	232
3-13936	232
3-13936-1	232
3-13937-1	447
3-13937-2	447
3-13940	280, 286
3-13940-1	280, 286
3-13943	155
3-13944	517, 531
3-13944-1	517, 531
3-13945	155
3-13946	527, 544
3-13946-1	527, 544
3-13947-2	165
3-13948	165
3-13949	362
3-14000-1	271
3-14072	416
3-14072-1	416
3-14073	356
3-14078	424
3-14078-1	424
3-14080	489
3-14203-1	541
3-14205	514, 526, 541
3-14207	292
3-14207-2	292
3-14208	383
3-14212	350, 351
3-14216-1	480
3-14216-2	524, 538
3-14216-3	468A
3-14216-5	490
3-14219	515, 526, 541
3-14223	146
3-14224	146
3-14226	164
3-14228	375
3-14228-1	375
3-14230	413, 416
3-14239	84
3-14239-1	84
3-14241-6	297
3-14242	297
3-14322-7	540
3-14326	540
3-14410-1	540
3-14650	268, 269
3-14651	84
3-14651-1	84
3-14653	294
3-14653-1	294
3-14654	245
3-14661	454
3-14674	77
3-14674-1	77
3-14675	77
3-14675-1	77
3-14676	271, 272
3-14686	465, 471
3-14689	423
3-14690	423
3-14690-1	423
3-14698	408
3-14900	271, 272
3-14900-1	271
3-14902	272
3-14902-2	272
3-14908	270
3-14908-2	270
3-14911	268, 268A, 269
3-14912	271, 272
3-14914	297
3-14920	141
3-14921	271, 272
3-14923	268, 269
3-14923-1	268, 269
3-14927	506, 528, 545
3-14927-2	506, 528, 545
3-14927-3	506, 528, 545
3-14928	272
3-14933	300, 301
3-14939	469
3-14939-1	469
3-14939-2	469
3-14941	469
3-14941-1	469
3-14941-2	469
3-14941-3	469
3-14945	427
3-14945-1	427
3-14947	362
3-14953	246
3-14953-2	246
3-14953-3	246
3-14954	244
3-14962-1	464
3-14963	464
3-14963-1	464
3-14966	226
3-14966-1	227
3-14970	514, 526
3-14971	184
3-14971-3	184
3-14971-4	184
3-14979	506, 529, 542
3-14979-1	506, 529, 542
3-14980	266
3-14982	419
3-14983	419
3-14985	300, 301
3-14987	240
3-14988	504, 519, 532
3-14988-1	504, 519, 532
3-14994	506, 527, 544
3-14995	510, 522, 535
3-14995-1	522, 535
3-14997	31, 32
3-14997-1	31, 32
3-14998	44
3-14998-1	44
3-14999	403
3-15104	227
3-15105	540
3-15105-1	540
3-15105-2	540
3-15105-3	540
3-15105-4	540
3-15105-5	540
3-15106	540
3-15106-1	540
3-15109	440
3-15109-1	440
3-15110	216, 217
3-15110-1	216, 217
3-15111	175
3-15111-1	175
3-15112	175
3-15112-1	175
3-15113	169
3-15113-1	169
3-15114	169
3-15114-1	169
3-15115	217
3-15115-1	217
3-15115-2	217
3-15117	245
3-15118	249
3-15122	94
3-15123	93
3-15124	249
3-15125-10	430
3-15125-11	430
3-15126	366
3-15128	430
3-15128-1	430
3-15128-2	430
3-15128-3	430
3-15128-5	430
3-15131	464
3-15132	428
3-15132-2	428
3-15134	238
3-15136	184
3-15136-1	184
3-15137	468A
3-15137-1	468A
3-15145	49
3-15145-1	49
3-15145-4	49
3-15145-5	49
3-15153	227
3-15155-1	501
3-15165	532
3-15168	425
3-15168-2	425
3-15184	452
3-15187	38
3-15190	245
3-15190-1	246
3-15191	373
3-15191-1	373
3-15199	316
3-15519-1	432
3-15519-101	432
3-15520-1	432
3-15520-2	308
3-15520-3	441
3-15520-101	432
3-15520-102	308
3-15520-103	441
3-15521-1	432
3-15521-2	432
3-15521-3	432
3-15521-4	432
3-15521-5	432
3-15521-6	433
3-15521-7	433
3-15521-101	432
3-15521-102	432
3-15521-103	432
3-15521-104	432
3-15521-105	432
3-15521-106	433
3-15521-107	433
3-15522-1	433
3-15522-2	441
3-15522-101	433
3-15522-102	441
3-16001-3	159
3-16001-4	159
3-16111-8	546
3-16111-10	485
3-16111-11	479
3-16111-12	479
3-16111-13	479
3-16112	289
3-16112-1	286
3-16112-2	280
3-16112-3	281
3-16114	288
3-16114-1	289
3-16119	427
3-16120	224
3-16126-7	232, 242
3-16126-11	424A
3-16128	412
3-16128-4	412
3-16128-5	412
3-16129-1	291
3-16129-2	291
3-16132-7	473, 482
3-16132-8	146, 222, 223
3-16132-9	469, 484
3-16134-1	289
3-16136	234
3-16136-1	234
3-16141-7	374
3-16142-1	471
3-16142-3	478
3-16142-5	478
3-16142-6	476, 478
3-16142-7	485, 490
3-16142-8	485
3-16143	427
3-16145	360
3-16145-1	360
3-16145-2	360
3-16145-3	360
3-16154-7	425
3-16154-8	425
3-16451	424A
3-16452	275
3-16455	329
3-16455-1	333
3-16455-2	333, 336
3-16455-3	333, 336
3-16456	468
3-16456-1	468
3-16456-2	468
3-16457-1	546
3-16457-2	546
3-16457-3	546
3-16457-4	546
3-16457-5	546
3-16459	468
3-16462	416
3-16467	176
3-16491	332
3-16492	331
3-16494	332
3-16495	335
3-16495-1	335
3-16900-4	373
3-16927	316
3-16927-1	293
3-16938	364
3-16948	316
3-16948-1	316
3-16948-2	316
3-16979	412
3-16979-1	412
3-16979-2	412
3-18280	335

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
3-18281	332, 335
3-18291	289
3-19013	316
3-19041	464
4-805	84
4-838	428
6-3842-1	176
6-3850-6	169
6-3850-7	169
6-3851	169
6-3851-1	169
6-3854	174
6-3854-1	174
6-3856-6	175
6-3856-7	175
6-3857	171
6-3857-1	171
6-4048	245
6-4048-4	245
6-4048-10	245
6-4048-13	245
6-4048-14	245
6-4115	170
6-4116-7	170
6-4283-1	154
6-4283-4	154
6-4829	148
6-4854	170
6-4854-8	170
6-4854-9	170
6-4854-10	170
6-4856	179
6-5182	416
6-5182-1	416
6-5182-2	416
6-5182-3	416
6-5199	353
6-5199-5	353
6-5199-10	353
6-5199-11	353
6-5199-12	353
6-5305-9	362
6-5493-4	357
6-5493-22	357
6-5493-23	357
6-5493-25	357
6-5493-26	357
6-5918	12A
6-6242-2	102
6-6242-3	102
6-6242-4	102
6-6242-7	102
6-6242-8	102
6-6244	408
6-6244-1	408
6-6244-2	408
6-6244-3	408
6-6426	167
6-6426-1	167
6-6509-1	174
6-6509-2	174
6-6509-3	174
6-6533	28
6-6533-1	28
6-6533-2	45
6-6533-3	45
6-6533-4	45
6-6533-5	45
6-6535	156
6-6535-6	156
6-6686	26
6-6918	70
6-6918-1	70
6-6918-2	70
6-6918-11	70
6-6956	29
6-6956-1	29
6-6958	47
6-6958-1	47
6-7030	450
6-7030-1	450
6-7030-2	450
6-7030-3	450
6-7030-4	450
6-7030-5	450
6-7030-6	451
6-7030-7	451
6-7030-8	451
6-7030-9	450
6-7030-10	450
6-7032-1	174
6-7032-3	174
6-7091	161
6-7091-4	161
6-7092	162
6-7092-12	162
6-7128	70
6-7128-1	70
6-7128-2	70
6-7128-3	70
6-7128-4	70
6-7128-5	70
6-7186	81
6-7189-1	512, 524, 538
6-7189-2	512, 524, 538
6-7189-6	512, 524, 538
6-7189-19	512, 524, 538
6-7193	511, 523, 537
6-7193-1	511, 523, 537
6-7193-2	511, 523, 537
6-7193-3	511, 523, 537
6-7193-4	511, 523, 537
6-7193-5	511, 523, 537
6-7193-6	511, 523, 537
6-7198	439
6-7198-1	439
6-7281	514
6-7281-1	514
6-7366	81
6-7366-1	81
6-7366-2	81
6-7369	81
6-7370	305
6-7376	167
6-7379-2	152
6-7529	152
6-7530-3	475
6-7530-6	475
6-7530-8	475
6-7531	475
6-7531-6	475
6-7538	470
6-7538-6	470
6-7582	511, 523, 537
6-7593	308
6-7593-1	308
6-7593-2	308
6-7593-3	308
6-7593-4	308
6-7595	308
6-7595-1	308
6-7595-2	308
6-7595-3	308
6-7595-4	308
6-7625	512, 525, 539
6-7625-1	512, 525, 539
6-7625-2	525, 539
6-7625-3	512, 525, 539
6-7722-2	362
6-7722-3	362
6-7722-9	362
6-7733	327
6-7733-1	327
6-7734	481
6-7734-1	481
6-7734-3	481
6-7734-5	481
6-7734-6	482
6-7734-7	482
6-7734-8	482
6-7738	62
6-7738-1	62
6-7741	329
6-7741-1	329
6-7741-2	329
6-7741-5	329
6-7757	153
6-7757-1	153
6-7757-5	153
6-7757-6	153
6-7759-2	482
6-7759-4	482
6-7759-5	482
6-7791-21	180
6-7791-22	180
6-7794	334
6-7794-1	334
6-7797-1	26
6-7797-4	26
6-7797-7	26
6-7798	328
6-7798-1	328
6-7799	380
6-7841	334
6-7841-1	334
6-7841-2	334
6-7841-3	334
6-7841-4	334
6-7841-5	334
6-7841-6	334
6-7847	156
6-7847-1	156
6-7848	156
6-7848-1	156
6-7849	156
6-7849-1	156
6-7850	157
6-7850-1	157
6-7850-2	157
6-7850-3	157
6-7851	157
6-7851-1	157
6-7851-2	157
6-7851-3	157
6-7852	156
6-7852-1	156
6-7855	182
6-7855-1	182
6-7887	380
6-7889	487
6-7889-1	487
6-7890	153
6-7890-1	153
6-7892	62
6-7892-1	62
6-7892-2	62
6-7892-3	62
6-7893	334
6-7893-1	334
6-7898	62
6-7898-1	62
6-7898-2	62
6-7898-3	62
6-7899-2	471
6-7901	62
6-7901-1	62
6-7901-2	62
6-7901-3	62
6-7907	327
6-7907-2	327
6-7918	153
6-7918-5	153
6-7918-6	153
6-7919-1	330
6-7919-4	330
6-7919-5	330
6-7919-7	330
6-7923-1	484
6-7924-1	363
6-7924-2	363
6-7924-3	363
6-7924-4	364
6-7924-5	364
6-7924-6	364
6-7924-7	364
6-7924-8	364
6-7924-9	364
6-7924-10	364
6-7924-11	364
6-7924-12	364
6-7924-14	364
6-7924-15	364
6-7924-16	364
6-7924-17	363
6-7924-18	363
6-7924-19	363
6-7924-20	364
6-7924-21	363
6-7924-25	364
6-7927	330
6-7927-1	330
6-7935	64
6-7935-1	64
6-7935-2	64
6-7935-3	64
6-7935-16	64
6-7935-17	64
6-7938	65
6-7938-1	65
6-7938-2	65
6-7938-3	65
6-7936-6	65
6-7938-7	65
6-7939	65
6-7939-1	65
6-7980	65
6-7981	65
6-7988	325
6-7988-2	325
6-7993	334
6-7993-1	334
6-7998-8	334
6-7998-9	334
6-7999	334
6-7999-1	334
6-8001	29
6-8001-1	29
6-8006	325
6-8006-1	325
6-8009	13
6-8009-1	13
6-8009-2	13
6-8009-3	13
6-8009-4	13
6-8009-5	13
6-8009-6	13
6-8009-7	13
6-8010	83
6-8010-1	83
6-8010-2	83
6-8049	30
6-8049-1	30

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
6-8049-10	30
6-8049-11	30
6-8049-12	30
6-8055	320
6-8055-1	320
6-8055-2	320
6-8055-3	320
6-8056	48
6-8056-1	48
6-8056-4	48
6-8056-8	48
6-8056-9	48
6-8056-10	48
6-8072	328, 329
6-8072-2	328, 329
6-8101	336
6-8101-1	336
6-8101-5	336
6-8101-6	336
6-8101-10	336
6-8101-11	336
6-8129-2	84
6-8129-3	84
6-8130	440
6-8130-1	440
6-8130-2	440
6-8130-3	440
6-8130-7	440
6-8134	199
6-8136-4	176
6-8142	457
6-8142-1	457
6-8142-2	457
6-8143	188
6-8143-7	188
6-8145	454
6-8145-1	454
6-8145-2	454
6-8145-3	454
6-8152	381
6-8152-6	381
6-8152-7	381
6-8156	355
6-8247	152
6-8247-1	152
6-8249	108
6-8249-1	108
6-8249-2	108
6-8249-3	108
6-8263-1	133
6-8263-2	133
6-8263-3	133
6-8263-4	133
6-8263-5	133
6-8265	37
6-8265-1	37
6-8273	402
6-8311	38
6-8311-1	38
6-8314-1	38
6-8314-18	38
6-8315	38
6-8315-1	38
6-8325	92
6-8325-1	92
6-8325-5	92
6-8325-7	92
6-8325-10	93
6-8325-12	92
6-8328	11
6-8328-1	11
6-8328-2	11
6-8328-3	11
6-8329	13
6-8329-1	13
6-8329-2	13
6-8329-3	13
6-8329-9	13
6-8329-10	13
6-8329-11	13
6-8329-12	13
6-8331-1	36, 50
6-8337	148
6-8337-1	148
6-8337-2	148
6-8337-9	148
6-8337-10	148
6-8338-7	470
6-8344	172, 176
6-8344-1	172, 176
6-8344-2	172, 176
6-8344-3	172, 176
6-8345-3	438
6-8345-6	438
6-8345-8	438
6-8345-9	438
6-8345-10	438
6-8345-12	438
6-8345-13	438
6-8345-14	438
6-8345-15	438
6-8361	196
6-8361-1	196
6-8361-2	196
6-8361-4	196
6-8365	96
6-8365-1	96
6-8372	333
6-8372-1	333
6-8375	63
6-8376	63
6-8379	133
6-8421	151
6-8421-1	151
6-8424	151
6-8424-1	151
6-8425	481
6-8425-2	481
6-8425-3	481
6-8425-4	481
6-8426	481
6-8429	461
6-8429-1	461
6-8429-2	462
6-8429-3	462
6-8434	194
6-8434-1	194
6-8435	480
6-8435-2	481
6-8435-3	480
6-8435-4	480
6-8439	152
6-8439-1	152
6-8460	264
6-8460-1	265
6-8463	328
6-8463-1	328
6-8472	29
6-8472-1	29
6-8473	416
6-8473-1	416
6-8473-2	416
6-8474	33
6-8474-1	33
6-8476	265
6-8520	353
6-8520-2	353
6-8520-4	353
6-8522	511
6-8522-1	511
6-8526	41
6-8526-1	41
6-8526-2	41
6-8526-3	41
6-8527	40
6-8527-1	41
6-8527-2	41
6-8527-12	41
6-8527-13	41
6-8530	381
6-8532	41
6-8532-1	41
6-8532-2	41
6-8532-3	41
6-8532-17	41
6-8532-18	41
6-8533	250
6-8533-2	250
6-8533-7	250
6-8567	162
6-8567-1	162
6-8567-7	162
6-8569	201
6-8647	384
6-8652	28
6-8655	386
6-8656	387
6-8656-1	387
6-8656-6	387
6-8656-12	387
6-8657	388
6-8657-5	388
6-8657-6	388
6-8657-7	388
6-8657-8	388
6-8657-9	388
6-8658	387
6-8659	387
6-8821	358
6-8821-1	358
6-8821-2	358
6-8821-3	358
6-8821-4	358
6-8821-5	358
6-8824	387
6-8826	510, 524, 536
6-8826-1	510, 524, 536
6-8826-11	510, 524, 536
6-8828	510
6-8828-1	510
6-8829	387
6-8829-1	387
6-8829-5	387
6-8829-6	387
6-8829-7	387
6-8829-8	387
6-8829-9	387
6-8829-10	387
6-8830	511, 523, 537
6-8830-1	523, 537
6-8830-2	523, 537
6-8832	511
6-8832-1	511
6-8832-2	511
6-8833	505
6-8833-1	505
6-8940	445
6-8940-1	445
6-8941-15	36
6-8942	148A
6-8943	357
6-8943-1	357
6-8943-2	357
6-8943-3	357
6-8943-4	358
6-8943-5	358
6-8943-6	358
6-8944	471
6-8945	243, 243A
6-8946	102
6-8946-1	102
6-8947	235
6-8947-1	235
6-8947-4	235
6-8948	483
6-8948-1	483
6-8949	233
6-8949-1	233
6-8950-2	425
6-8950-3	426
6-8951	218
6-8951-1	218
6-8952	243, 244
6-8953	233
6-8954	471
6-8954-4	471
6-8955-2	291
6-8955-3	500
6-8956	446
6-8956-1	446
6-8957	444
6-8958	444
6-8958-1	442
6-8959	243, 244
6-8960	434
6-8961-3	219
6-8962-3	219
6-8964	243A
6-8964-1	243A
6-8965-31	284
6-8965-32	283
6-8967	442
6-8969-5	284
6-8970	476
6-8970-1	476
6-8978-3	285
6-8979	238
6-8980	442, 444
6-8980-1	442, 444
6-8980-3	444
6-8980-4	444
6-8980-5	443, 444
6-8981	444
6-8981-1	444
6-8988	356
6-8988-1	356
6-8992-2	115
6-8992-6	115
6-8992-7	115
6-8993	434
6-8997	446
6-8997-1	446
6-9200	238
6-9200-3	238
6-9202	129
6-9202-1	129
6-9202-2	129
6-9203	126
6-9203-1	126
6-9204	217
6-9204-2	215, 216
6-9205	367
6-9205-2	367
6-9206	127
6-9206-1	127
6-9206-2	127
6-9207	366
6-9208	113, 114, 118
6-9209	473, 474
6-9210	358
6-9210-2	358
6-9210-3	358
6-9210-4	358
6-9210-5	358

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
6-9211	235
6-9214	465
6-9214-3	465
6-9214-4	500
6-9214-5	465
6-9215	214
6-9215-1	214
6-9216	476
6-9216-4	476
6-9217	508
6-9217-1	508, 520, 533
6-9217-6	508, 521, 534
6-9217-7	508, 521, 534
6-9219	102
6-9220	88
6-9220-1	88
6-9221	113
6-9222	113
6-9223	445
6-9223-1	445
6-9223-3	445
6-9223-4	445
6-9227-1	490
6-9227-2	490
6-9228	323
6-9230	217
6-9230-1	217
6-9230-2	217
6-9230-3	217
6-9231	215
6-9231-1	215
6-9234-2	239
6-9235	240
6-9235-2	240
6-9236	358
6-9236-1	358
6-9236-3	358
6-9236-4	358
6-9236-5	358
6-9239	505
6-9239-3	505
6-9239-4	505
6-9239-6	505
6-9239-7	505
6-9239-8	505
6-9239-9	505
6-9239-10	505
6-9242-2	363
6-9262	238
6-9262-1	238
6-9263	238
6-9264	237
6-9264-1	237
6-9265	228
6-9265-1	228
6-9265-2	228
6-9265-3	228
6-9266	238
6-9266-1	238
6-9267	241
6-9267-1	241
6-9268-2	238
6-9268-3	238
6-9269	241
6-9270	238
6-9271	241
6-9272	241
6-9272-2	241
6-9273	241
6-9273-1	241
6-9273-2	241
6-9273-3	241
6-9279	90
6-9279-1	90
6-9279-2	90
6-9279-3	90
6-9279-4	90
6-9279-5	90
6-9279-6	90
6-9280	239
6-9281	243, 244
6-9281-1	243, 244
6-9283	246
6-9284	246
6-9284-1	246
6-9285	427
6-9285-1	427
6-9287	214
6-9288	215
6-9290	23, 24
6-9290-1	23, 24
6-9290-5	24
6-9290-6	24
6-9290-7	23, 24
6-9291	487
6-9291-1	487
6-9291-2	487
6-9291-3	487
6-9291-4	487
6-9291-5	487
6-9291-9	487
6-9295	373
6-9295-1	373
6-9296	184
6-9296-1	184
6-9298	215
6-9299	217
6-9300	218
6-9300-6	218
6-9301	235
6-9301-3	235
6-9302	236
6-9304	236
6-9305	215
6-9305-1	215
6-9306	241
6-9307	476
6-9307-3	476
6-9310	334
6-9310-1	334
6-9312	235
6-9313	485
6-9313-1	485
6-9314	485
6-9315	219
6-9316	219
6-9317	219
6-9318	219
6-9319	348, 418
6-9320	118
6-9320-1	118
6-9321	114
6-9321-1	114
6-9323	193
6-9323-1	193A
6-9323-4	193A
6-9324	483
6-9324-1	484
6-9324-2	483, 484
6-9325	465
6-9325-1	465A
6-9325-2	465A
6-9325-3	465A
6-9326	238
6-9327-2	241
6-9327-3	241
6-9330	511
6-9330-2	511
6-9330-3	511
6-9331	505
6-9331-1	505
6-9331-4	505
6-9331-6	505
6-9331-7	506
6-9331-8	505
6-9332	238
6-9333	507
6-9333-1	507, 520, 534
6-9333-2	507
6-9333-3	507
6-9333-4	507
6-9333-5	507
6-9336	367
6-9336-1	367
6-9337	201
6-9337-1	201
6-9338	372
6-9338-1	372
6-9340	230
6-9340-1	230
6-9340-2	230
6-9340-3	230
6-9340-9	230
6-9340-10	230
6-9341	513
6-9341-1	513, 525, 539
6-9343	245
6-9343-1	245
6-9343-3	245
6-9344	483
6-9344-1	483
6-9344-2	483
6-9344-3	483
6-9345	188
6-9345-1	188
6-9345-2	188
6-9345-3	188
6-9346-2	465
6-9349-2	241
6-9349-3	241
6-9350-2	243
6-9352	291
6-9352-1	291
6-9352-2	291
6-9352-3	291
6-9354	513, 525, 539
6-9354-1	513, 525, 539
6-9354-2	513, 525, 539
6-9354-3	513, 525, 539
6-9354-5	513, 525, 539
6-9355	243
6-9355-1	243
6-9355-3	243A
6-9356	243, 472
6-9356-1	243, 472
6-9358	178
6-9359	397
6-9361	152
6-9361-1	152
6-9363	416
6-9363-1	416
6-9364	362
6-9364-1	362
6-9364-2	362
6-9365-2	280
6-9365-3	282
6-9365-4	286
6-9366	152
6-9368	128
6-9369	128
6-9370	128
6-9371	128
6-9372	128
6-9373	484
6-9373-1	484
6-9373-2	484
6-9374-1	291
6-9374-2	291
6-9375	122
6-9376	123
6-9377	123
6-9378	152
6-9379	127
6-9392	393
6-9392-5	393
6-9392-6	393
6-9392-7	393
6-9399	361
6-9399-2	361
6-9399-10	361
6-9400	380
6-9401	123
6-9402	366
6-9402-1	366
6-9403	118
6-9404	235
6-9405	117
6-9406	117
6-9407	235
6-9407-1	235
6-9408-2	118, 121
6-9408-3	118, 121
6-9409	124
6-9410	124
6-9411	484
6-9411-1	484
6-9411-2	484
6-9411-3	484
6-9413	128
6-9413-1	128
6-9414-1	226
6-9414-2	226
6-9414-5	226
6-9414-6	226
6-9415-2	226
6-9415-3	226
6-9415-6	226
6-9416	226
6-9416-1	226
6-9416-2	226
6-9416-3	226
6-9416-7	226
6-9417	226
6-9417-1	226
6-9417-5	226
6-9440	133
6-9442-1	121
6-9442-2	121
6-9443	225
6-9446	241
6-9447	271
6-9449	120
6-9449-1	120
6-9449-3	120
6-9450	472
9-9450-1	472
6-9450-2	472
6-9452	119
6-9452-1	119
6-9452-4	119
6-9453	235
6-9453-1	235
6-9453-6	235
6-9454	384
6-9454-1	384
6-9455	115
6-9455-1	115
6-9455-4	115
6-9455-5	115
6-9455-6	115
6-9458	113
6-9458-2	113
6-9458-4	113

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
6-9459	424A
6-9459-1	424A
6-9460	127
6-9461	218
6-9462	121
6-9463	371
6-9465	238
6-9465-1	238
6-9467	474
6-9468	238
6-9469	214
6-9472	217
6-9473	488
6-9473-1	488
6-9474	485
6-9474-2	485
6-9475	488
6-9475-1	488
6-9475-2	488
6-9475-4	488
6-9475-5	488
6-9476	232
6-9477	119
6-9479	117
6-9479-1	117
6-9480	304
6-9481	384
6-9481-1	384
6-9481-9	384
6-9483	358
6-9484	302
6-9484-1	302
6-9485	268
6-9485-2	268
6-9485-3	268
6-9486	147
6-9488	284
6-9488-1	284
6-9489	234
6-9489-1	234
6-9490	304
6-9491	39
6-9491-7	39
6-9491-11	39
6-9492	270
6-9492-2	270
6-9493	302
6-9493-1	302
6-9494	304
6-9495	276A
6-9495-1	276A
6-9496	302
6-9496-1	302
6-9498	277
6-9498-1	277
6-9499-2	238
6-9499-3	238
6-9502	304
6-9507	467
6-9507-1	468
6-9508	467
6-9508-1	468
6-9509	467
6-9509-1	467
6-9509-2	467
6-9509-3	467
6-9510	155
6-9510-1	155
6-9519	265
6-9580	230
6-9580-1	230
6-9580-2	230
6-9582	144
6-9582-1	144
6-9582-2	144
6-9582-3	144
6-9584	163
6-9584-1	163
6-9585	163
6-9585-1	163
6-9588	292
6-9588-1	292
6-9588-2	292
6-9588-3	292
6-9589	424A
6-9589-1	424A
6-9592	284
6-9592-3	284
6-9593	284
6-9593-3	284A
6-9595	405
6-9596	329
6-9597-3	285
6-9622	424
6-9691	154
6-9691-1	154
6-9694	505
6-9694-1	513
6-9694-2	512
6-9696-1	525, 539
6-9696-2	525, 539
6-9696-3	527, 544
6-9700	528, 545
6-9700-1	528, 545
6-9700-4	528, 545
6-9700-5	528, 545
6-9700-6	528, 545
6-9700-7	528, 545
6-9701	220
6-9701-1	220
6-9702	185
6-9702-1	185
6-9703	232
6-9703-1	232
6-9705	523, 536
6-9705-2	523, 537
6-9708	522, 535
6-9708-1	522, 535
6-9708-2	522, 535
6-9708-3	522, 535
6-9709-1	513, 525
6-9709-2	513, 525
6-9709-3	513
6-9709-4	513
6-9709-5	513
6-9709-6	513
6-9709-7	513, 540
6-9709-8	513, 540
6-9709-9	513, 526, 540
6-9709-10	513, 526, 540
6-9709-11	513
6-9709-12	513
6-9709-17	513, 526, 540
6-9709-18	513, 526, 540
6-9709-19	513, 526, 540
6-9709-20	513, 526, 540
6-9987-1	540
6-9987-2	540
6-9987-3	540
6-9987-4	540
6-9987-6	540
6-9987-8	540
6-9987-10	541
6-10098	490
6-10098-1	490
6-10099	470
6-10099-1	471
6-10099-2	471
6-10099-3	470
6-10099-4	470
6-10099-5	470
6-10101	490
6-10101-1	490
6-10101-2	490
6-10101-3	490
6-10101-4	490
6-10104	375
6-10111	477
6-10111-2	477
6-10115	147
6-10115-1	147
6-10115-2	147
6-10115-3	147
6-10120	384
6-10122	217
6-10122-4	216
6-10122-5	217
6-10123	177
6-10128	269
6-10128-1	269
6-10129	269
6-10129-1	269
6-10131	293
6-10131-1	293
6-10131-2	293
6-10131-3	293
6-10132	294
6-10132-1	294
6-10132-2	294
6-10132-3	294
6-10137	228
6-10137-1	228
6-10137-2	228
6-10137-3	228
6-10137-5	228
6-10138	39, 50
6-10138-1	39, 50
6-10431	254, 256
6-10431-1	254, 256
6-10437	484
6-10437-2	484
6-10439	484
6-10439-1	484
6-10439-2	484
6-10444	423
6-10446	503, 518, 531
6-10470	29
6-10470-1	29
6-10470-4	29
6-10470-10	29
6-10470-11	29
6-10471	506, 527
6-10471-1	506, 527
6-10473	268, 269, 270
6-10482-1	276
6-10482-2	276
6-10482-3	276
6-10482-4	276
6-10482-5	276
6-10482-6	276
6-10482-7	276
6-10482-8	276
6-10482-9	276
6-10482-10	276
6-10482-11	276
6-10482-12	276
6-10653	477
6-10653-1	477
6-10662	363
6-10662-1	363
6-10667	498
6-10667-1	498
6-10669	193
6-10672	301
6-10672-1	300
6-10672-2	300
6-10672-3	301
6-10677	465
6-10683	360
6-10684	168
6-10685	372
6-10685-1	372
6-10685-2	372
6-10685-3	372
6-10685-4	372
6-10687	482
6-10687-1	482
6-10688	482
6-10688-1	482
6-10688-2	482
6-10690	482
6-10690-1	482
6-10690-2	482
6-10690-3	482
6-10693-1	283
6-10693-3	283
6-10693-5	283
6-10693-7	283
6-10693-9	283
6-10693-11	283
6-10694-1	284
6-10694-3	283
6-10694-5	283
6-10694-7	283
6-10694-9	283
6-10694-11	283
6-10694-13	283
6-10694-15	283
6-10694-17	283
6-10694-19	283
6-10694-21	283
6-10696	154
6-10696-1	154
6-10697	38
6-10697-1	38
6-10697-2	38
6-10697-3	39
6-10697-10	39
6-10697-11	39
6-10724	240
6-10724-1	240
6-10725	240
6-10725-1	240
6-10727	429
6-10727-1	429
6-10728	429
6-10728-1	429
6-10729	429
6-10729-1	429
6-10730	429
6-10730-1	429
6-10731	429
6-10731-1	429
6-10732	288
6-10732-1	288
6-10734	236
6-10734-1	236
6-10734-3	236
6-10735	430
6-10735-4	430
6-10736	430
6-10736-3	430
6-10736-4	430
6-10737	430
6-10737-1	430
6-10737-2	430
6-10737-3	430
6-10738	234
6-10738-1	234
6-10739	231
6-10740	231
6-10746	238
6-10750	430

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
6-10750-1	430
6-10750-9	430
6-10750-10	430
6-10751	429
6-10751-1	429
6-10763	184
6-10763-2	184
6-10780	306
6-10781	532
6-10781-1	532
6-10786-1	546
6-10786-2	546
6-10786-3	546
6-10786-4	546
6-10786-5	546
6-10786-6	546
6-10786-7	546
6-10786-8	546
6-10786-9	546
6-10786-10	546
6-10786-11	546
6-10786-12	546
6-10786-13	546
6-10786-14	546
6-10786-15	546
6-10787	26
6-10787-1	26
6-10788	26
6-10788-1	26
6-10790-1	546
6-10790-2	467, 546
6-10790-3	546
6-10790-4	546
6-10790-5	546
6-10790-6	546
6-10790-7	467, 546
6-10790-8	546
6-10790-9	546
6-10790-10	546
6-10790-11	546
6-10790-12	546
6-10790-13	546
6-10790-14	546
6-10790-15	546
6-10790-16	546
6-10790-17	437, 546
6-10790-18	546
6-10790-19	546
6-10790-20	546
6-10790-21	546
6-10790-22	546
6-10790-23	546
6-10790-24	546
6-10790-25	546
6-10790-26	546
6-10790-27	546
6-10790-28	547
6-10790-29	547
6-10790-30	547
6-10790-31	547
6-10790-32	547
6-10790-33	547
6-10790-34	547
6-10790-35	547
6-10790-36	547
6-10790-37	547
6-10790-38	547
6-10790-39	547
6-10790-40	547
6-10790-41	547
6-10790-42	547
6-10790-43	547
6-10790-44	547
6-10790-45	547
6-10790-46	547
6-11058-28	308
6-11058-30	308
6-11058-31	309
6-11058-32	309
6-11058-33	309
6-11300	39
6-11300-1	39
6-11301	255
6-11301-1	255
6-11305	372
6-11307	216
6-11307-1	216
6-11307-2	216
6-11307-3	216
6-11307-4	216
6-11307-5	216
6-11308-2	353
6-11308-3	547
6-11309	428
6-11311	428
6-11443-1	375
6-11443-2	375
6-11443-3	375
6-11443-4	375
6-11443-5	375
6-11443-6	375
6-14443-7	375
6-14443-8	375
6-14443-9	375
6-11449-1	427
6-11450-1	427
6-11451	427
6-11451-2	427
6-11451-3	427
6-11568	10
6-11568-1	10
6-11569	424A
6-11569-1	424A
6-11569-2	424A
6-11571	424A
6-11945	67
6-11945-1	67
6-11946	67
6-11946-1	67
6-11947	67
6-11947-1	67
6-11964	332
6-11986-5	350
6-13161	236
6-13161-1	236
7-1029-10	434
7-1029-11	434
7-1323	511, 523, 537
7-1323-1	511, 523, 537
7-1323-2	523, 537
7-1323-3	511, 523, 537
7-1323-4	523, 537
7-1335-1	464
7-1336	152
7-1345	84
7-1345-1	84
7-1360	47
7-1360-1	47
7-1360-2	47
7-1360-3	47
7-1361	106
7-1361-1	106
7-1361-3	106
7-1361-4	106
7-1363	34
7-1363-1	34
7-1363-2	34
7-1363-3	34
7-1364	130
7-1364-1	130
7-1365	93
7-1365-1	93
7-1365-2	93
7-1365-3	93
7-1365-4	93
7-1365-5	93
7-1365-6	93
7-1365-7	93
7-1365-8	93
7-1365-9	93
7-1365-10	93
7-1367	133
7-1367-1	133
7-1368	133
7-1368-1	133
7-1368-2	133
7-1368-3	133
7-1368-4	134
7-1369	134
7-1369-1	134
7-1369-2	134
7-1369-3	134
7-1369-4	134
7-1369-5	134
7-1369-6	134
7-1369-7	134
7-1369-8	134
7-1369-9	134
7-1369-11	134
7-1369-12	134
7-1369-13	134
7-1369-14	134
7-1369-15	134
7-1369-16	134
7-1369-17	134
7-1369-18	134
7-1369-19	134
7-1369-20	134
7-1369-21	134
7-1369-22	134
7-1369-23	134
7-1369-24	134
7-1370	264
7-1371	264
7-1371-1	264
7-1372	264
7-1372-1	264
7-1373	265
7-1373-1	265
7-1500-42	285
7-1500-43	285
7-1502	378
7-1502-1	378
7-1503	350
7-1504	351
7-1505	351
7-1506	86
7-1506-1	86
7-1506-6	86
7-1507	214
7-1507-1	214
7-1508	478
7-1508-1	478
7-1508-2	478
7-1508-3	478
7-1508-4	478
7-1509-4	285
7-1509-5	285
7-1510	80
7-1510-1	80
7-1511	80
7-1511-1	80
7-1512	80
7-1512-1	80
7-1513	80
7-1514	80
7-1515	118
7-1516-2	490
7-1516-3	490
7-1517	138
7-1517-1	138
7-1518	172
7-1518-11	172
7-1518-12	172
7-1518-13	172
7-1519-6	285
7-1519-7	285
7-1520-5	285
7-1520-6	285
7-1521-6	285
7-1521-7	285
7-1523	178
7-1523-1	178
7-1525	476
7-1525-1	476
7-1525-2	476
7-1525-3	476
7-1526	484
7-1526-1	484
7-1526-5	484
7-1528	459
7-1528-1	459
7-1529	233
7-1529-1	233
7-1531	108
7-1531-5	108
7-1533	179
7-1533-1	179
7-1535	468A
7-1535-6	468A
7-1536	133
7-1536-1	133
7-1536-2	133
7-1536-3	133
7-1536-4	133
7-1536-5	133
7-1537	459
7-1537-1	459
7-1538-1	121
7-1538-2	121
7-1539	372
7-1640	163
7-1640-1	163
7-1640-2	163
7-1640-3	163
7-1641	383
7-1641-1	383
7-1641-8	383
7-1643	331
7-1643-1	331
7-1648	506, 528, 545
7-1648-1	506, 528, 545
7-1648-2	545
7-1648-3	506, 528, 545
7-1648-4	506, 528, 545
7-1648-5	545
7-1649	506, 528
7-1654	193
7-1654-1	193
7-1655	386
7-1655-6	386
7-1655-7	386
7-1655-8	386
7-1958	468
7-1958-2	468
7-1958-4	468
7-1958-5	468
7-1958-6	468
7-1958-12	468
7-1963	545
7-1963-1	545
7-1963-2	545
8-588-2	250
8-596	99

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
8-596-1	99
8-596-2	99
8-596-3	99
8-787-1	134
8-787-6	134
8-819	152
8-819-14	152
8-819-15	152
8-1041	134
8-1041-10	134
8-1041-13	134
8-1041-16	134
8-1041-19	134
8-1041-22	134
8-1041-25	134
8-1041-28	134
8-1041-31	134
8-1062	162
8-1062-4	162
8-1204	99
8-1204-1	99
8-1204-2	99
8-1204-3	99
8-1205	130
8-1205-1	130
8-1205-2	130
8-1205-3	130
8-1205-4	130
8-1205-5	130
8-1205-6	130
8-1205-7	130
8-1205-8	130
8-1205-9	130
8-1205-10	130
8-1205-11	130
8-1205-12	130
8-1205-13	130
8-1205-14	130
8-1205-15	130
8-1261-1	127
8-1261-2	129
8-1261-3	128
8-1262-2	96
8-1262-3	96
8-1262-4	96
8-1262-5	96
8-1263-1	127
8-1263-2	129
8-1263-3	128
8-1264	127
8-1264-1	127
8-1266	125
8-1266-1	125
8-1267	124
8-1267-1	124
8-1268-3	128
8-1268-4	128
8-1269	125
8-1270	124
8-1270-4	124
8-1270-5	124
8-1270-6	124
8-1270-7	124
8-1270-8	124
8-1270-9	124
8-1271	171
8-1271-1	171
8-1271-3	171
8-1271-4	171
8-1271-5	171
8-1273	218
8-1274	178
8-1274-1	178
8-1275	178
8-1275-1	178
8-1275-12	178
8-1277	117
8-1277-1	117
8-1278	120
8-1278-2	120
8-1278-3	120
8-1278-4	120
8-1280	488
8-1280-1	489
8-1280-2	488, 489
8-1281	178
8-1281-13	178
8-1283-2	129
8-1283-3	128
8-1284-1	127
8-1284-2	129
8-1284-3	128
8-1285	245
8-1285-1	245
8-1285-2	246
8-1285-7	246
8-1286-2	129
8-1286-3	128
8-1290	184
8-1290-1	184
8-1290-2	184
8-1290-3	184
8-1292	181
8-1292-1	181
8-1293	508
8-1293-1	508, 520, 535
8-1293-7	508, 520, 535
8-1293-8	520, 535
8-1293-9	508, 520, 535
8-1294	181
8-1294-1	181
8-1295	447
8-1295-1	447
8-1297-1	127
8-1297-2	129
8-1297-3	128
8-1298-1	127
8-1298-2	129
8-1298-3	127
8-1298-4	129
8-1520	120
8-1520-1	120
8-1520-2	120
8-1520-3	120
8-1520-4	120
8-1520-5	120
8-1521	120
8-1521-1	120
8-1521-2	120
8-1521-3	120
8-1521-4	120
8-1522	125
8-1522-1	125
8-1523-1	124
8-1523-2	124
8-1523-5	126
8-1523-7	124
8-1524	119
8-1525	118
8-1525-3	118
8-1526	154
8-1526-7	154
8-1526-8	154
8-1526-12	154
8-1526-13	154
8-1527	234
8-1527-1	234
8-1527-2	234
8-1527-7	234
8-1532-5	464
8-1533	255
8-1533-1	255, 256
8-1533-2	255, 256
8-1537	234
8-1537-1	234
9-1725-2	457
9-1725-3	457
9-1725-4	457
9-1725-5	457
9-1725-6	457
9-1725-8	457
9-2028	426
9-2028-1	426
9-2028-6	426
9-2028-7	426
9-2312-4	248
9-2312-5	248
9-2312-6	248
9-2312-7	248
9-2312-8	248
9-2312-9	248
9-2563	426
9-2563-1	426
9-2563-2	426
9-2563-3	426
9-2696	70
9-2696-1	70
9-2696-2	70
9-2696-3	70
9-2696-4	70
9-2696-5	70
9-2696-7	70
9-2696-10	70
9-2696-13	70
9-2696-25	70
9-2696-26	70
9-2696-27	70
9-2711-6	378
9-2711-10	378
9-2711-21	378
9-2711-22	378
9-2711-23	378
9-2711-24	378
9-2711-33	378
9-2711-34	378
9-2715	512, 525, 539
9-2715-1	512, 525, 539
9-2715-2	539
9-2715-3	539
9-2715-4	539
9-2715-5	539
9-2715-6	539
9-2715-7	539
9-2715-8	539
9-2722	70
9-2722-1	70
9-2762	179
9-2762-1	179
9-2763	179
9-2763-1	179
9-2764-1	179
9-2764-10	179
9-2765-12	179
9-2771	180
9-2771-1	180
9-2771-10	180
9-2771-11	180
9-2869	366
9-2901	42
9-2901-1	42
9-2901-5	42
9-2901-7	42
9-2927	45
9-2927-1	45
9-2928	183A
9-2928-9	183A
9-2938-1	464A
9-2941	361
9-2941-5	361
9-2941-6	361
9-2941-7	361
9-2941-8	361
9-2941-13	361
9-2944	328
9-2944-1	328
9-2944-6	328
9-2944-7	328
9-2946	157
9-2946-1	157
9-2948-1	157
9-2948-2	157
9-2948-7	157
9-2948-12	157
9-2951	381
9-2951-7	381
9-2951-12	381
9-2958	30
9-2958-1	30
9-2958-2	30
9-2958-3	30
9-2958-4	30
9-2958-5	30
9-2958-6	30
9-2958-7	30
9-2958-8	30
9-2958-9	30
9-2958-10	30
9-2958-11	30
9-2958-12	30
9-2958-13	30
9-2984	179
9-2984-1	179
9-2988	335
9-2988-4	331, 335
9-3024-2	24
9-3024-3	24
9-3024-19	24
9-3024-20	24
9-3032	179
9-3032-1	179
9-3032-2	179
9-3032-4	179
9-3038	83
9-3038-1	83
9-3038-8	83
9-3038-9	83
9-3039	71
9-3039-1	71
9-3040	320
9-3040-1	320
9-3040-2	320
9-3040-3	320
9-3044-2	43
9-3044-3	43
9-3045-9	64
9-3045-10	64
9-3048-2	84
9-3048-3	84
9-3054	49
9-3054-1	49
9-3054-2	49
9-3054-3	49
9-3080	329
9-3080-4	328, 329
9-3080-10	328
9-3082-1	249
9-3082-2	249
9-3082-4	249
9-3082-7	249
9-3084	381
9-3087	51
9-3087-1	51

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
9-3090	152
9-3091	152
9-3091-7	152
9-3092	152
9-3092-6	152
9-3092-8	152
9-3093	51
9-3093-37	51
9-3097	437
9-3123	331
9-3123-1	331
9-3124-28	335
9-3124-33	335
9-3124-34	335
9-3126	46
9-3126-1	46
9-3127	46
9-3127-1	46
9-3135	99
9-3135-1	99
9-3135-2	99
9-3136	100
9-3136-1	100
9-3136-2	100
9-3136-3	100
9-3137	109
9-3137-1	109
9-3137-2	109
9-3137-3	109
9-3139	20
9-3139-1	20
9-3139-4	20
9-3186	265
9-3186-1	265
9-3186-3	265
9-3187	361
9-3187-1	361
9-3187-3	361
9-3187-4	361
9-3188-1	507, 519, 533
9-3188-2	507
9-3188-3	507
9-3188-4	507
9-3188-5	507
9-3188-6	507
9-3189-1	153
9-3189-5	153
9-3192-3	154
9-3192-6	154
9-3192-7	154
9-3194	46
9-3194-1	46
9-3194-2	46
9-3194-3	46
9-3194-14	46
9-3194-15	47
9-3195	41
9-3195-1	41
9-3195-2	41
9-3195-3	41
9-3265	29
9-3265-1	29
9-3265-5	29
9-3266	29
9-3266-1	30
9-3266-2	30
9-3266-9	30
9-3266-10	30
9-3266-11	30
9-3266-40	30
9-3267	388
9-3267-6	388
9-3267-8	388
9-3267-9	388
9-3268	384
9-3268-1	384
9-3268-3	384
9-3268-4	384
9-3268-7	384
9-3269	388
9-3269-13	388
9-3270	387
9-3270-1	387
9-3276	363
9-3276-1	363
9-3276-2	363
9-3276-3	363
9-3276-5	363
9-3360	511
9-3360-1	511
9-3360-2	523, 537
9-3360-3	523, 537
9-3360-4	511, 523, 537
9-3362	509
9-3362-1	510, 522,535
9-3362-2	509
9-3362-3	509
9-3362-4	509
9-3362-5	510
9-3370	264
9-3370-3	264
9-3374	29
9-3420-1	219
9-3421-3	219
9-3422-1	219
9-3423	215
9-3423-2	215
9-3424	269
9-3424-1	269
9-3427	219
9-3428	243
9-3435	77
9-3435-1	77
9-3436	77
9-3436-1	77
9-3437	77
9-3437-1	77
9-3438	77
9-3438-1	77
9-3439-2	77
9-3439-3	77
9-3440	485
9-3440-1	485
9-3441	413
9-3441-1	413
9-3442	238
9-3443-1	505
9-3444	505
9-3445	95
9-3446	95
9-3447	95
9-3448	95
9-3449	95
9-3450	95
9-3451	95
9-3452	95
9-3453	95
9-3454	95
9-3455	95
9-3456	95
9-3457	95
9-3458	95
9-3459	95
9-3581	484
9-3581-1	484
9-3582	215
9-3583	320
9-3583-1	320
9-3585	163
9-3585-1	163
9-3586	459
9-3586-1	459
9-3587	457
9-3587-1	457
9-3587-3	457
9-3587-9	457
9-3588	232
9-3588-1	232
9-3588-3	233
9-3588-4	233
9-3589	231
9-3590	113
9-3590-1	113
9-3592-4	232
9-3599	102
9-3599-1	102
9-3600	465
9-3600-1	465
9-3601	465
9-3601-1	465
9-3606	505
9-3607	233
9-3607-1	233
9-3607-3	233
9-3607-4	233
9-3608	485
9-3609-1	402
9-3609-8	402
9-3610	424
9-3610-1	424
9-3612	510, 524, 536
9-3612-1	510, 524, 536
9-3612-3	510, 524, 536
9-3613	114
9-3613-1	114
9-3614	268
9-3614-1	268
9-3615	182
9-3615-1	182
9-3615-2	182
9-3615-3	182
9-3622	352
9-3640	428
9-3640-1	428
9-3640-2	428
9-3640-3	428
9-3640-4	428
9-3640-5	428
9-3640-6	428
9-3642	86
9-3642-1	86
9-3642-2	86
9-3642-3	86
9-3642-4	86
9-3642-5	86
9-3642-12	86
9-3642-13	86
9-3642-16	86
9-3645	80
9-3645-1	80
9-3645-5	80
9-3645-6	80
9-3646	525, 539
9-3646-2	513, 525, 539
9-3646-3	513, 525, 539
9-3646-4	513
9-3648	81
9-3648-1	81
9-3651	128
9-3652	128
9-3653	51
9-3653-1	51
9-3653-2	51
9-3653-3	51
9-3653-6	51
9-3653-7	51
9-3653-10	51
9-3655	154
9-3655-1	154
9-3655-2	154
9-3655-3	154
9-3655-9	154
9-3655-10	154
9-3655-12	154
9-3655-13	154
9-3656	366
9-3657	172
9-3658	268
9-3658-1	268
9-3660	227
9-3660-1	227
9-3660-2	227
9-3660-3	227
9-3661	382
9-3661-1	382
9-3661-11	382
9-3661-12	383
9-3662	214
9-3663	291
9-3663-1	291
9-3663-2	291
9-3663-7	291
9-3663-8	291
9-3663-10	291
9-3664	114
9-3665	151
9-3666	120
9-3666-1	120
9-3667	384
9-3667-1	384
9-3668	291
9-3668-7	291
9-3669	221
9-3669-1	221
9-3670	221
9-3670-1	221
9-3680	241
9-3680-2	241
9-3681	330
9-3682	268
9-3682-3	268
9-3684	321
9-3684-1	321
9-3684-2	321
9-3684-3	321
9-3685-2	230
9-3685-3	230
9-3685-4	230
9-3685-5	230
9-3685-6	230
9-3686	425
9-2686-7	425
9-3686-10	425
9-3687	270
9-3687-2	270
9-3688	381
9-3688-1	381
9-3688-6	381
9-3690	164
9-3690-1	164
9-3691	277
9-3691-1	277
9-3691-3	277

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
9-3692	164
9-3692-1	164
9-3692-2	164
9-3693	490
9-3695	78
9-3695-4	78
9-3696	78
9-3696-1	78
9-3696-6	78
9-3696-7	78
9-3698	78
9-3698-1	78
9-3698-6	78
9-3698-7	78
9-3701-1	336
9-3701-2	336
9-3701-5	336
9-3701-6	336
9-3705	383
9-3709	193
9-3709-1	193
9-3709-4	193
9-3710	371
9-3710-1	371
9-3710-2	371
9-3710-3	371
9-3710-4	371
9-3710-5	371
9-3710-6	371
9-3710-7	371
9-3710-8	371
9-3710-9	371
9-3710-10	371
9-3710-11	372
9-3710-12	372
9-3710-13	371
9-3710-14	371
9-3713	504, 519, 532
9-3714	382
9-3719-3	233
9-3719-5	233
9-3719-7	233
9-3722	219
9-3730	29
9-3741	242
9-3743	506, 528, 545
9-3746	295
9-3746-1	295
9-3746-2	295
9-3746-3	295
9-3746-4	295
9-3750	506, 527, 545
9-3756	356
9-3756-2	356
9-3763	221
9-3763-1	221
9-3765	503, 518, 532
9-3765-1	503, 518, 532
9-3765-2	503, 518, 532
9-3765-3	503, 518, 532
9-3765-4	503, 518, 532
9-3765-5	503, 518, 532
9-3765-6	504, 518, 532
9-3765-7	504, 518, 532
9-3765-8	504, 518, 532
9-3765-9	504, 518, 532
9-3765-10	504, 518, 532
9-3765-11	504, 518, 532
9-3765-12	504, 518, 532
9-3765-13	504, 518, 532
9-3765-14	503, 518, 532
9-3765-15	503, 518, 532
9-3767	377
9-3767-3	377
9-3771	240
9-3773	240
9-4592-11	316
9-4606	194
9-4606-3	194
9-4606-4	194
9-4606-8	194
9-4606-14	194
9-4606-17	194
9-4606-18	194
9-4609	231
9-4609-1	231
9-4610	234
9-4610-1	234
9-4612	372
9-4640-1	547
9-4640-2	547
9-4640-3	547
9-4640-4	547
9-4640-5	547
9-4640-6	547
9-4640-7	547
9-4640-8	547
9-4640-9	547
9-4640-10	547
9-4640-11	547
9-4640-12	547
9-4640-13	547
9-4640-14	547
9-4640-15	547
9-4640-16	547
9-4640-17	547
9-4640-18	547
9-4640-19	547
9-4640-20	547
9-4640-21	547
9-4640-22	547
9-4640-23	547
9-4640-24	547
9-4640-25	547
9-4640-26	547
9-4640-27	547
9-4640-28	547
9-4640-29	547
9-4640-30	548
9-4640-31	548
9-4641-1	548
9-4641-2	548
9-4641-3	548
9-4641-4	465, 548
9-4641-5	548
9-4641-6	548
9-4641-7	548
9-4641-8	548
9-4641-9	548
9-4641-10	548
9-4641-11	548
9-4641-12	548
9-4641-13	548
9-4641-14	548
9-4641-15	548
9-4641-16	548
9-4641-17	548
9-4641-18	548
9-4641-19	548
9-4641-20	548
9-4641-21	548
9-4641-22	548
9-4641-23	548
9-4641-24	548
9-4641-25	548
9-4641-26	548
9-4641-27	548
9-4641-28	548
9-4641-29	548
9-4641-30	548
9-4641-31	548
9-4641-32	548
9-4641-33	548
9-4641-34	548
9-4641-35	548
9-4642-1	548
9-4642-2	548
9-4642-3	548
9-4642-4	548
9-4642-5	548
9-4642-6	548
9-4642-7	548
9-4642-8	548
9-4642-9	548
9-4642-10	548
9-4642-11	548
9-4642-12	548
9-4642-13	548
9-4642-14	548
9-4642-15	549
9-4642-16	549
9-4642-17	549
9-4642-18	549
9-4642-19	549
9-4642-20	549
9-4642-21	549
9-4642-22	549
9-4942-23	549
9-4642-24	549
9-4642-25	549
9-4642-26	549
9-4642-27	549
9-4642-29	549
9-4642-30	316
9-4645-1	549
9-4645-2	549
9-4645-3	549
9-4645-4	549
9-4645-5	549
9-4645-6	549
9-4645-7	549
9-4645-8	549
9-4645-9	549
9-4645-10	549
9-4645-11	549
9-4645-12	549
9-4645-13	549
9-4645-14	549
9-4645-15	549
9-4645-16	549
9-4645-17	549
9-4645-18	549
9-4645-19	549
9-4645-20	549
9-4645-21	549
9-4645-22	550
9-4645-23	550
9-4645-24	550
9-4645-26	550
9-4645-27	550
9-4645-29	349
9-4645-30	349
9-4660-1	550
9-4660-2	550
9-4660-3	550
9-4660-4	550
9-4660-5	550
9-4660-6	550
9-4660-7	550
9-4660-8	550
9-4660-9	550
9-4660-10	550
9-4660-11	550
9-4660-12	550
9-4660-13	550
9-4660-14	550
9-4660-15	550
9-4660-16	550
9-4660-17	550
9-4660-18	550
9-4660-19	550
9-4660-20	550
9-4660-21	550
9-4660-22	550
9-4660-23	550
9-4660-24	550
9-4660-25	550
9-4660-26	550
9-4660-27	550
9-4660-28	550
9-4660-29	550
9-4660-30	550
9-4660-31	550
9-4660-32	550
9-4660-33	551
9-4660-34	551
9-4660-35	551
9-4901	359
9-4901-1	359
9-4907	47
9-4907-1	47
9-4907-8	47
9-4907-9	47
9-4914	227
9-4918	468
9-4918-1	468
9-4918-2	468
9-4918-3	468
9-4918-4	468
9-4918-8	468
9-4919	468
9-4919-1	468
9-4919-3	468
9-5033	370
9-5033-1	370
9-5033-2	370
9-5033-3	370
9-5033-4	370
9-5033-5	370
9-5038	468A
9-5038-1	468A
9-5038-2	468A
9-5042	183A
9-5204-7	473
9-5204-8	182
9-5204-12	182
9-5204-16	363
9-5204-20	325
9-5204-21	325
9-5204-22	325
9-5204-23	448
9-5204-27	490
9-5204-28	448
9-5316	350
14-1337	23
14-1337-1	23
14-1337-4	23
14-1337-8	23
14-1337-9	23
14-1337-10	24
14-1681	361
14-1681-1	361
14-1681-2	361
14-1681-3	361
14-1681-4	361
14-1681-5	361
14-1683	359
14-1683-1	359
14-1683-16	359
14-1685-410	369
14-1685-416	369
14-1686	364
14-1686-1	364

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
14-1686-2	364
14-1686-3	364
14-1692-1	357
14-1692-4	357
14-1692-7	357
14-1692-8	357
14-1692-9	357
14-1695	192
14-1695-1	192
14-1695-2	192
14-1695-4	192
14-1695-5	192
14-1695-6	192
14-1695-8	192
14-1695-36	192
14-1695-37	192
14-1695-38	192
14-1695-39	192
14-1695-40	192
14-1747-1	383
14-1747-6	383
14-1747-9	383
14-1747-12	383
14-1747-13	383
14-1747-14	383
14-1755-13	28
14-1755-14	28
14-1755-17	28
14-1755-18	28
14-1767	162
14-1767-3	162
14-1767-7	162
14-1767-8	162
14-1767-9	162
14-1767-24	162
14-1820	273
14-1820-7	273
14-1820-8	273
14-1821-2	45
14-1821-3	45
14-1821-8	45
14-1821-9	45
14-1823	168
14-1823-1	168
14-1823-6	168
14-1823-9	168
14-1823-10	168
14-1827	198
14-1827-1	198
14-1827-2	198
14-1827-3	198
14-1827-6	198
14-1827-7	198
14-1827-14	198
14-1827-16	198
14-1827-17	198
14-1827-20	198
14-1827-21	198
14-1827-22	198
14-1827-23	198
14-1827-26	198
14-1827-27	198
14-1827-30	198
14-1827-34	198
14-1827-35	198
14-1827-36	198
14-1827-42	198
14-1827-46	198
14-1945	489
14-1945-1	489
14-1945-2	489
14-1945-8	489
14-1945-13	489
14-1945-25	489
14-1945-26	489
14-1945-27	489
14-1945-28	489
14-1945-29	489
14-1945-30	489
14-1945-31	489
14-1945-32	489
14-1945-33	489
14-1945-34	489
14-1945-35	489
14-1945-36	489
14-1945-37	489
14-1945-38	489
14-1945-39	489
14-1945-40	489
14-1945-41	489
14-2040	466
14-2040-1	466
14-2040-3	466
14-2043	117
14-2043-2	118
14-2044	12
14-2044-1	12
14-2044-14	12
14-2044-15	12
14-2044-18	14
14-2044-23	14
14-2044-25	12
14-2044-26	12
14-2045	23
14-2045-1	23
14-2046	9
14-2046-1	9
14-2046-2	11
14-2046-3	11
14-2046-8	11
14-2046-9	11
14-2046-26	11
14-2046-27	11
14-2046-28	11
14-2046-29	11
14-2046-34	12
14-2046-35	12
14-2046-42	10
14-2046-43	10
14-2048	442
14-2048-1	442
14-2048-7	442
14-2048-8	442
14-2049	24
14-2049-1	24
14-2051	125
14-2052	124
14-2053	102
14-2053-1	102
14-2055-1	82
14-2056	380
14-2056-1	380
14-2056-14	380
14-2056-17	380
14-2056-20	380
14-2056-21	380
14-2057-1	125
14-2057-2	125
14-2057-3	126
14-2058	24
14-2058-1	24
14-2059	24
14-2059-1	24
14-2061	221
14-2061-1	221
14-2062	170
14-2063	176
14-2064	141
14-2068	457
14-2069	86
14-2069-1	86
14-2070	155
14-2070-1	155
14-2071	419
14-2071-2	419
14-2071-3	419
14-2071-4	419
14-2071-5	419
14-2071-6	419
14-2071-7	419
14-2071-8	420
14-2071-9	419
14-2071-10	419
14-2071-11	419
14-2071-12	419
14-2071-13	420
14-2072	465
14-2072-1	465
14-2072-3	465
14-2072-4	465
14-2073	120
14-2073-1	120
14-2073-2	120
14-2073-3	120
14-2073-9	120
14-2073-10	120
14-2074	128
14-2075	128
14-2076	128
14-2077	128
14-2078	380
14-2078-1	380
14-2078-17	380
14-2078-18	380
14-2078-19	380
14-2079	479
14-2079-1	479
14-2079-4	479
14-2079-5	479
14-2079-8	479
14-2340	121
14-2341	121
14-2344	52
14-2344-14	52
14-2344-16	52
14-2344-17	52
14-2345	504, 519, 532
14-2345-1	504, 519, 532
14-2345-3	504, 519, 532
14-2345-4	504, 519, 532
14-2345-5	504, 519, 532
14-2345-6	504, 519, 532
14-2345-7	504, 519, 532
14-2346	25
14-2346-1	25
14-2353	154
14-2353-1	154
14-2353-6	154
14-2354	88
14-2358	467
14-2358-4	467
14-2358-5	467
14-2871	242
14-3002	306
14-3002-1	306
14-3003	426
14-3005	488
14-3005-1	488
15-3518-19	354
15-4779	247
15-4779-1	247
15-4779-2	247
15-5665	42
15-5665-1	42
15-5665-2	43
15-5665-3	43
15-5683-1	167
15-5683-14	167
15-5683-15	167
15-5686	163
15-5686-2	163
15-5686-3	163
15-5686-25	163
15-5686-26	162
15-5686-28	162
15-5692-23	149
15-5923-8	360
15-5923-10	360
15-5923-11	360
15-5923-13	360
15-5923-15	360
15-5923-17	360
15-5923-20	360
15-5923-22	360
15-5923-26	361
15-5923-28	360
15-5926	42
15-5926-1	42
15-5930	40
15-5937-1	361
15-5937-2	361
15-5937-10	361
15-5937-14	361
15-5937-16	361
15-5937-19	361
15-5937-20	361
15-5991	158
15-5991-1	158
15-5991-2	158
15-5991-3	158
15-5991-4	158
15-5991-5	158
15-5991-6	158A
15-5991-7	158A
15-5992	158A
15-5992-2	159
15-5992-4	159
15-5992-6	159
15-5993	159
15-5993-1	159
15-5993-2	159
15-5993-3	159
15-5993-4	159
15-5993-5	159
15-5993-6	159
15-5993-7	159
15-5994	159
15-5994-1	159
15-5994-2	159
15-5994-3	160
15-5994-4	160
15-5994-5	160
15-5994-6	160
15-5994-7	160
15-5995	160
15-5995-1	160
15-5995-2	160
15-5995-3	160
15-5995-4	160
15-5995-5	160
15-5995-6	160
15-5995-7	160
15-6012-6	46
15-6012-7	46
15-6012-18	46
15-6012-19	46
15-6012-28	45
15-6012-29	45
15-6012-30	45
15-6012-31	45

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
15-6013	182
15-6013-1	182
15-6013-2	182
15-6013-3	182
15-6013-4	182
15-6014-1	180
15-6014-2	180
15-6014-3	180
15-6014-6	180
15-6014-8	180
15-6014-9	180
15-6014-19	180
15-6014-22	180
15-6014-26	180
15-6045	31
15-6045-1	31
15-6045-2	31
15-6045-3	31
15-6045-20	31
15-6045-21	31
15-6045-28	31
15-6045-29	31
15-6047	157
15-6047-10	157
15-6047-11	157
15-6047-12	157
15-6047-14	157
15-6053	158
15-6053-10	158
15-6053-11	158
15-6053-12	158
15-6053-14	158
15-6053-26	158
15-6063-4	33
15-6063-5	33
15-6063-20	33
15-6063-30	33
15-6063-31	33
15-6063-41	33
15-6063-42	33
15-6063-55	33
15-6063-56	33
15-6063-64	33
15-6063-65	33
15-6063-66	33
15-6063-67	33
15-6067-11	167
15-6079	335
15-6079-1	335
15-6079-4	331
15-6079-5	331
15-6079-7	331
15-6079-8	331
15-6079-9	331
15-6079-10	331
15-6092	352, 360
15-6092-1	360
15-6092-4	360
15-6092-9	360
15-6092-13	360
15-6092-17	360
15-6092-21	360
15-6092-25	360
15-6092-27	360
15-6097	159
15-6097-1	159
15-6097-2	159
15-6097-3	159
15-6097-6	331
15-6143	24
15-6143-1	24
15-6143-2	24
15-6143-3	24
15-6143-8	24
15-6143-9	25
15-6143-10	25
15-6143-11	25
15-6143-12	25
15-6143-13	25
15-6146	325
15-6146-1	325
15-6155	63
15-6155-1	63
15-6155-2	63
15-6155-3	63
15-6155-14	64
15-6155-15	64
15-6155-24	63
15-6155-25	63
15-6155-37	64
15-6155-38	64
15-6181	247
15-6181-1	247
15-6193-1	258, 260, 262
15-6193-2	258, 260, 262
15-6193-3	258, 260
15-6193-4	258, 261
15-6193-7	258, 262
15-6193-8	258, 263
15-6193-9	258, 261, 263
15-6244	163
15-6246	274
15-6246-1	274
15-6246-2	274
15-6246-4	274
15-6246-5	274
15-6246-6	275
15-6246-9	274
15-6246-10	274
15-6246-11	274
15-6246-12	274
15-6246-13	274
15-6246-14	274
15-6246-15	275
15-6246-16	275
15-6246-17	275
15-6249	84
15-6249-1	84
15-6249-2	84
15-6249-3	84
15-6252-3	354
15-6252-12	354
15-6252-24	354
15-6333	26
15-6333-1	26
15-6333-31	26
15-6333-32	26
15-6334	50
15-6334-14	50
15-6334-16	50
15-6334-19	50
15-6334-22	50
15-6342	36
15-6342-1	36
15-6342-6	36
15-6342-12	36
15-6343	65
15-6343-1	65
15-6343-2	65
15-6343-3	66
15-6343-12	66
15-6343-13	66
15-6343-17	66
15-6343-18	66
15-6345	464
15-6345-1	464
15-6518-1	153
15-6518-3	153
15-6518-5	153
15-6518-10	153
15-6518-12	153A
15-6518-13	153A
15-6518-16	154
15-6531	329
15-6531-1	329
15-6531-2	329
15-6531-3	329
15-6531-4	329
15-6531-5	329
15-6531-27	329
15-6531-28	329
15-6531-29	329
15-6531-30	329
15-6534	40
15-6534-1	40
15-6534-2	40
15-6534-3	40
15-6535	41
15-6535-1	41
15-6535-2	41
15-6535-3	41
15-6535-14	41
15-6535-15	41
15-6620-2	200
15-6620-3	200
15-6620-4	200
15-6620-5	200
15-6620-6	200
15-6620-7	200
15-6620-8	200
15-6620-9	200
15-6620-10	200
15-6620-11	200
15-6620-12	200
15-6620-13	200
15-6620-27	200
15-6620-32	200
15-6620-55	200
15-6620-61	200
15-6620-62	200
15-6620-66	200
15-6620-67	200
15-6621	200
15-6621-1	200
15-6621-8	201
15-6623	25
15-6623-1	25
15-6623-6	25
15-6623-7	25
15-6623-14	25
15-6624	266
15-6624-1	266
15-6625	267
15-6625-1	267
15-6625-2	267
15-6625-3	267
15-6701	330
15-6701-1	330
15-6701-2	330
15-6701-3	330
15-6701-4	330
15-6701-5	330
15-6701-6	330
15-6701-9	330
15-6701-10	330
15-6701-11	330
15-6701-12	330
15-6701-13	330
15-6702	382
15-6702-6	382
15-6702-10	382
15-6702-11	382
15-6703	388
15-6703-1	388
15-6703-10	388
15-6703-25	388
15-6703-26	388
15-6704-12	387
15-6704-18	387
15-6704-20	387
15-6704-21	387
15-6704-29	387
15-6704-46	387
15-6704-51	387
15-6704-61	387
15-6800	511, 523, 537
15-6800-1	537
15-6800-2	537
15-6800-3	537
15-6800-4	537
15-6800-7	537
15-6800-8	537
15-6800-9	537
15-6800-10	511, 523, 537
15-6800-11	511, 523, 537
15-6804	75
15-6804-4	75
15-6804-6	75
15-6804-11	75
15-6804-17	75
15-6804-21	75
15-6804-30	75
15-6804-31	75
15-6806	5, 423
15-6806-1	431
15-6806-2	431
15-6806-3	431
15-6809-1	442
15-6809-2	442
15-6809-3	442
15-6809-4	442
15-6990-1	443
15-6990-2	443
15-6990-3	443
15-6990-4	443
15-6991-7	443
15-6991-12	442
15-6991-13	442
15-6992-14	443
15-6992-15	443
15-6994	75
15-6994-1	75
15-6994-5	75
15-6994-9	75
15-6994-20	75
15-6994-30	75
15-6994-31	75
15-7011	218
15-7012	148A
15-7013	143
15-7015	140
15-7015-42	140
15-7015-43	140
15-7015-44	141
15-7015-64	141
15-7016	214
15-7017	214
15-7017-15	215
15-7018	215
15-7018-1	215
15-7018-9	215
15-7019	216
15-7019-22	216
15-7019-24	216
15-7020	218
15-7023	113, 124
15-7023-1	124
15-7023-2	124
15-7023-31	125
15-7023-54	126
15-7024	113, 117
15-7024-11	118

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
15-7025	113, 127
15-7025-1	113, 127
15-7025-2	127
15-7025-4	127
15-7025-6	128
15-7025-12	129
15-7025-35	129
15-7025-118	129
15-7026	113, 120
15-7026-1	113, 120
15-7026-7	122
15-7027	218
15-7027-1	218
15-7027-13	218
15-7029	279, 280
15-7029-1	279, 280
15-7029-2	287
15-7029-3	287
15-7029-4	287
15-7029-8	287
15-7029-9	287
15-7029-13	287
15-7029-14	287
15-7029-15	287
15-7029-16	287
15-7029-17	287
15-7029-18	287
15-7030	95, 449, 450
15-7033	449, 459
15-7034	449, 461
15-7034-1	462
15-7035	302, 303
15-7036	302, 318
15-7037	302, 320
15-7038	302, 323
15-7040	302
15-7042	118
15-7042-1	118
15-7043	121
15-7043-1	121
15-7044	228
15-7044-1	228
15-7044-2	228
15-7044-3	228
15-7044-8	228
15-7044-9	228
15-7044-10	229
15-7044-11	229
15-7044-12	229
15-7045	121
15 7045-1	121
15-7045-2	121
15-7045-6	121
15-7046	121
15-7046-1	121
15-7047	466
15-7047-1	466
15-7047-2	466
15-7047-3	466
15-7047-4	466
15-7047-5	466
15-7047-6	466
15-7047-7	466
15-7047-9	466
15-7048	280
15-7048-1	280
15-7048-2	280
15-7048-3	280
15-7048-8	280
15-7048-14	280
15-7310	296
15-7311	5, 348
15-7311-1	364
15-7311-2	353
15-7311-3	365
15-7311-5	365
15-7311-6	365
15-7311-8	366
15-7311-9	366
15-7311-10	366
15-7311-11	366
15-7311-13	366
15-7311-14	366
15-7311-15	366
15-7311-16	366
15-7311-17	364
15-7311-18	366
15-7311-19	366
15-7311-20	366
15-7311-21	366
15-7311-22	365
15-7311-23	365
15-7311-24	365
15-7311-25	364
15-7311-27	365
15-7311-28	365
15-7311-29	365
15-7311-31	365
15-7312	225
15-7312-1	225
15-7312-12	225
15-7312-13	225
15-7312-21	225
15-7312-26	225
15-7312-27	225
15-7312-28	225
15-7312-32	225
15-7312-33	225
15-7312-50	225
15-7313	140, 205
15-7313-20	205
15-7313-21	205
15-7313-44	205
15-7313-45	205
15-7313-46	205
15-7313-47	205
15-7313-49	205
15-7313-51	205
15-7313-69	206
15-7313-70	206
15-7313-85	206
15-7313-86	206
15-7313-87	206
15-7313-88	206
15-7313-89	206
15-7313-90	206
15-7313-91	206
15-7313-92	206
15-7313-93	206
15-7313-94	207
15-7313-95	207
15-7313-96	207
15-7313-97	207
15-7313-98	207
15-7313-99	207
15-7313-100	207
15-7313-101	207
15-7313-102	207
15-7313-103	207
15-7313-104	207
15-7313-105	208
15-7313-106	208
15-7313-107	208
15-7313-108	208
15-7313-109	208
15-7313-110	208
15-7313-111	208
15-7313-112	208
15-7313-113	208
15-7314	140, 209
15-7314-39	209
15-7314-40	209
15-7314-41	209
15-7314-42	209
15-7314-43	209
15-7314-44	209
15-7314-45	209
15-7314-46	209
15-7314-47	209
15-7314-48	209
15-7314-49	209
15-7314-50	209
15-7314-51	209
15-7314-52	209
15-7314-53	209
15-7314-54	209
15-7314-55	209
15-7314-56	210
15-7314-57	210
15-7314-58	210
15-7314-59	210
15-7314-60	210
15-7314-61	210
15-7314-62	210
15-7316-17	219
15-7316-22	219
15-7316-29	219
15-7316-62	220
15-7316-63	220
15-7316-70	220
15-7316-71	220
15-7316-74	220
15-7316-75	220
15-7316-85	220
15-7317	218
15-7318	218
15-7319	218
15-7320-1	219
15-7321-1	219
15-7322-1	219
15-7323-3	219
15-7324	5, 113
15-7329-5	423, 442
15-7330	136, 140
15-7331	136, 214
15-7332	5, 464
15-7332-1-1	491
15-7332-1-2	491
15-7332-1-3	491
15-7332-1-4	491
15-7332-1-5	491
15-7332-2-1	491
15-7332-2-2	491
15-7332-3-1	491
17-7332-3-2	493
15-7332-3-3	491
15-7332-3-4	491
15-7332-4-1	491
15-7332-4-2	493
15-7332-4-3	491
15-7332-4-4	491
15-7332-5-1	491
15-7332-5-2	491
15-7332-6-1	491
15-7332-6-2	491
15-7332-7	493
15-7332-9	493
15-7332-10	493
15-7332-11	498
15-7332-12	498
15-7332-13	493
15-7332-14	493
15-7332-15-1	491
15-7332-15-2	491
15-7332-15-3	491
15-7332-15-4	491
15-7332-16-1	491
15-7332-16-2	491
15-7332-16-3	491
15-7332-16-4	491
15-7332-19	493
15-7332-20	493
15-7332-21	493
15-7332-22	494
15-7332-23	494
15-7332-24	494
15-7332-31	494
15-7332-32	494
15-7332-33	494
15-7332-34	494
15-7332-35	494
15-7332-36	494
15-7332-43	494
15-7332-44	494
15-7332-45	494
15-7332-46	494
15-7332-51	495
15-7332-52	495
15-7332-53	495
15-7332-54	495
15-7332-55	495
15-7332-56	495
15-7332-57	495
15-7332-76	498
15-7332-77	493, 494, 498
15-7332-78	498
15-7332-83	493
15-7332-84	494
15-7332-115	491
15-7332-116	491
15-7332-117	491
15-7332-118-1	491
15-7332-118-2	491
15-7332-118-3	491
15-7332-118-4	491
15-7332-119-1	491
15-7332-119-2	491
15-7332-120	491
15-7332-120-1	498
15-7332-120-2	491
15-7332-120-3	491
15-7332-121-2	491
15-7332-121-3	498
15-7332-121-4	491
15-7332-122-2	491
15-7332-124	495
15-7332-126	495
15-7332-128	495
15-7332-130	495
15-7332-132	496
15-7332-134	496
15-7332-136	496
15-7332-138	496
15-7332-140	492
15-7332-141	492
15-7332-142	492
15-7332-143	492
15-7332-144	492
15-7332-145	492
15-7332-146	492
15-7332-147-2	491
15-7332-147-3	491
15-7332-155	496
15-7332-156	496
15-7332-157	496
15-7332-158	496
15-7332-159	492
15-7332-160	492
15-7332-163	492
15-7332-165	492
15-7332-166	492
15-7332-168	492

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
15-7332-171	492
15-7332-172	492
15-7332-173	492
15-7332-174	492
15-7332-175	492
15-7332-176	492
15-7332-177	492
15-7332-181	492
15-7332-182	492
15-7332-189	492
15-7332-190	492
15-7332-193	493
15-7332-196	496
15-7332-198-1	491
15-7332-198-2	491
15-7332-198-3	496
15-7332-201-1	491
15-7332-201-2	491
15-7332-201-3	491
15-7332-201-4	492
15-7332-202	493
15-7332-202-1	492
15-7332-202-2	492
15-7332-203-1	492
15-7332-203-2	492
15-7332-204	492
15-7332-204-1	492
15-7332-204-2	492
15-7332-204-3	492
15-7332-204-4	492
15-7332-205	492
15-7332-208	497
15-7332-210	497
15-7332-212	497
15-7332-214	497
15-7332-217	492
15-7332-218	497
15-7332-220	497
15-7332-222	497
15-7332-224	497
15-7332-226	497
15-7332-228	497
15-7332-230	497
15-7332-232	497
15-7332-234	497
15-7332-235	497
15-7332-236	498
15-7332-244	492
15-7332-245	492
15-7332-246	492
15-7332-247	492
15-7332-250	492
15-7332-251	492
15-7332-252	492
15-7332-253	492
15-7332-254	492
15-7332-255	492
15-7332-256	492
15-7332-257	492
15-7332-258	493
15-7332-259	493
15-7332-260	493
15-7332-261	493
15-7332-263	493
15-7332-264	493
15-7332-265	493
15-7332-266	493
15-7332-267	498
15-7332-269	498
15-7332-271	498
15-7334	353
15-7334-1	353
15-7334-2	353
15-7334-3	353
15-7334-4	353
15-7335-1	423, 447
15-7336-10	290
15-7336-11	290
15-7337	352
15-7337-1	352
15-7337-2	352
15-7337-5	352
15-7337-8	352
15-7337-12	352
15-7337-14	352
15-7337-17	352
15-7337-18	352
15-7338-1	124
15-7338-2	125
15-7338-7	126
15-7338-8	126
15-7339-1	125
15-7339-3	126
15-7339-5	124
15-7340-1	125
15-7340-3	126
15-7340-5	124
15-7341-1	125
15-7341-3	126
15-7341-4	126
15-7342-1	125
15-7342-3	126
15-7342-5	124
15-7343-1	125
15-7343-3	126
15-7343-5	124
15-7344-1	125
15-7344-3	126
15-7344-4	126
15-7345-1	125
15-7345-2	125
15-7345-5	126
15-7345-7	124
15-7347	227
15-7347-1	227
15-7347-2	227
15-7347-3	227
15-7347-4	227
15-7347-5	227
15-7348-1	292
15-7348-3	292
15-7348-4	292
15-7348-5	292
15-7348-10	292
15-7348-11	292
15-7348-12	292
15-7348-13	293
15-7348-14	293
15-7348-15	294
15-7348-16	294
15-7348-17	294
15-7348-18	294
15-7348-20	294
15-7348-21	294
15-7348-22	294
15-7348-23	294
15-7348-24	294
15-7348-25	294
15-7348-26	294
15-7348-27	294
15-7348-30	294
15-7348-31	294
15-7348-32	294
15-7348-33	294
15-7348-34	295
15-7348-35	295
15-7348-36	295
15-7348-38	294
15-7348-39	295
15-7348-40	295
15-7348-42	295
15-7348-43	295
15-7348-44	295
15-7348-45	295
15-7348-47	294
15-7348-49	295
15-7348-51	295
15-7348-52	295
15-7348-53	295
15-7348-54	295
15-7348-55	295
15-7348-56	295
15-7348-57	295
15-7348-58	295
15-7348-59	295
15-7348-60	294
15-7348-63	294
15-7348-64	295
15-7348-65	295
15-7348-66	295
15-7348-67	294
15-7348-68	294
15-7348-69	295
15-7348-71	295
15-7348-72	294
15-7348-73	294
15-7348-74	295
15-7348-76	295
15-7348-77	294
15-7348-78	294
15-7348-79	295
15-7348-80	295
15-7348-82	295
15-7348-83	294
15-7348-84	294
15-7348-85	294
15-7348-89	294
15-7348-90	294
15-7348-91	294
15-7348-92	294
15-7348-93	294
15-7348-102	295
15-7348-104	295
15-7348-105	295
15-7348-106	295
15-7348-112	295
15-7348-113	292
15-7348-114	295
15-7348-115	293
15-7348-116	294
15-7348-117	295
15-7348-118	294
15-7348-119	295
15-7348-122	293
15-7348-124	294
15-7348-125	294
15-7348-126	293
15-7348-129	293
15-7349	282
15-7349-1	282
15-7349-2	282
15-7349-3	282
15-7349-9	282
15-7349-10	282
15-7350-1	272
15-7351	476
15-7351-1	477
15-7351-2	477
15-7351-3	477
15-7351-4	477
15-7352	141
15-7352-1	141
15-7354	257
15-7354-1	257
15-7355	256
15-7355-1	256
15-7356	257
15-7356-1	257
15-7356-2	257
15-7357	257
15-7357-1	257
15-7359-5	273
15-7359-6	273
15-7359-7	273
15-7359-9	273
15-7359-11	273
15-7359-12	273
15-7359-13	273
15-7359-14	273
15-7360	136, 237
15-7360-1	237
15-7360-2	241
15-7360-7	239
15-7360-8	239
15-7360-11	239
15-7360-44	239
15-7362-2	256
15-7362-3	256
15-7362-4	256
15-7362-5	256
15-7362-6	256
15-7362-10	256
15-7362-13	256
15-7363-2	255
15-7363-3	254, 255
15-7363-4	255
15-7363-5	254, 255
15-7363-6	255
15-7363-10	255
15-7363-13	254
15-7365	348, 413
15-7365-4	417
15-7365-5	413
15-7365-7	413
15-7365-8	413
15-7365-9	413
15-7365-10	413
15-7365-11	413
15-7365-12	413
15-7365-13	413
15-7365-14	413
15-7365-15	413
15-7365-16	413
15-7365-17	414
15-7365-18	414
15-7365-19	414
15-7365-20	414
15-7365-21	414
15-7365-22	414
15-7365-23	414
15-7365-24	414
15-7365-25	414
15-7365-26	414
15-7365-27	414
15-7365-28	414
15-7365-29	414
15-7365-30	414
15-7365-31	414
15-7365-32	414
15-7365-33	414
15-7365-34	414
15-7365-35	414
15-7365-36	414
15-7365-37	414
15-7365-38	414
15-7365-39	414
15-7365-40	414
15-7365-41	414
15-7365-42	414
15-7365-43	414
15-7365-44	414
15-7365-45	414
15-7365-46	414
15-7365-47	414

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
15-7365-48	414
15-7365-50	414
15-7365-51	414
15-7365-52	414
15-7365-53	414
15-7365-54	414
15-7365-55	414
15-7365-56	414
15-7365-57	414
15-7365-58	414
15-7365-59	414
15-7365-60	414
15-7365-61	414
15-7365-62	414
15-7365-65	414
15-7365-66	414
15-7365-67	414
15-7365-68	414
15-7365-71	414
15-7365-72	414
15-7365-73	414
15-7365-74	414
15-7365-76	415
15-7365-79	415
15-7365-81	415
15-7365-82	415
15-7365-83	415
15-7365-84	415
15-7365-85	415
15-7365-86	415
15-7365-87	415
15-7365-88	415
15-7365-89	415
15-7365-90	415
15-7365-91	415
15-7365-94	415
15-7365-95	415
15-7365-96	415
15-7365-98	415
15-7365-99	415
15-7365-100	415
15-7365-101	415
15-7365-102	415
15-7365-103	417
15-7365-104	417
15-7365-106	417
15-7365-107	417
15-7365-109	415
15-7365-110	415
15-7365-111	415
15-7365-112	415
15-7365-113	415
15-7365-115	415
15-7365-116	415
15-7365-117	415
15-7365-120	415
15-7365-121	417
15-7365-122	417
15-7365-125	415
15-7365-126	415
15-7365-128	415
15-7365-129	415
15-7365-130	415
15-7365-131	415
15-7365-132	415
15-7365-133	416
15-7365-134	416
15-7365-135	416
15-7365-136	416
15-7365-137	416
15-7365-138	416
15-7365-139	416
15-7365-140	416
15-7365-141	416
15-7365-143	416
15-7365-145	416
15-7365-146	416
15-7365-147	416
15-7365-148	416
15-7365-149	416
15-7365-150	416
15-7365-151	416
15-7367	127
15-7367-6	127
15-7369	243A
15-7370	117
15-7371	117
15-7371-1	117
15-7371-5	117
15-7372	169
15-7372-1	175
15-7372-2	141
15-7372-4	169
15-7372-5	175
15-7372-6	141
15-7372-18	175
15-7372-28	141
15-7373	161
15-7373-1	161
15-7373-2	161
15-7374	228
15-7374-1	228
15-7374-2	228
15-7374-3	228
15-7375	219
15-7376	128
15-7377	5, 136
15-7378	245
15-7379	373
15-7379-22	373
15-7379-25	373
15-7379-35	373
15-7379-37	373
15-7379-38	373
15-7379-39	373
15-7380-2	374
15-7380-22	374
15-7381	423
15-7381-2	423
15-7381-3	423
15-7382	490
15-7382-2	490
15-7382-3	490
15-7384	380
15-7384-1	380
15-7384-8	380
15-7384-13	380
15-7384-20	380
15-7385	128
15-7385-1	128
15-7385-2	128
15-7385-3	128
15-7386	348, 380
15-7386-1	389
15-7386-2	389
15-7387-1	427
15-7387-2	427
15-7388	124
15-7388-1	124
15-7388-2	124
15-7388-3	124
15-7389	243A
15-7389-1	243A
15-7389-15	243A
15-7389-16	243A
15-7389-17	243A
15-7389-18	243A
15-7389-19	243A
15-7389-20	243A
15-7469	425
15-7469-1	425
15-7469-2	425
15-7469-3	425
15-7469-8	425
15-7469-9	425
15-7469-16	425
15-7470-2	244
15-7470-3	243A
15-7470-5	244
15-7470-6	244
15-7470-7	243A, 244
15-7471	148
15-7471-1	148
15-7471-2	148
15-7471-3	148
15-7471-4	148
15-7471-5	148, 148A
15-7471-6	148
15-7471-7	148A
15-7471-8	148A
15-7475	95
15-7475-1	95
15-7475-2	95
15-7475-11	95
15-7476	9, 80
15-7476-1	9, 80
15-7476-2	80
15-7476-3	80
15-7476-28	80
15-7476-29	80
15-7476-44	80
15-7476-45	80
15-7476-68	80
15-7477	117
15-7477-1	117
15-7477-3	117
15-7477-5	117
15-7477-7	117
15-7477-9	117
15-7478	113
15-7478-1	113
15-7478-2	113
15-7479	117
15-7479-29	117
15-7480	227
15-7480-1	227
15-7480-2	227
15-7481	117
15-7482	117
15-7483-85	77
15-7483-87	77
15-7483-90	78
15-7483-106	78
15-7483-111	78A
15-7486	425
15-7486-1	426
15-7486-2	425
15-7486-21	426
15-7386-22	426
15-7486-26	426
15-7488	238
15-7489	237
15-7510	241
15-7511	224
15-7513	221
15-7513-1	221
15-7513-33	223
15-7513-34	223
15-7513-35	223
15-7514	223
15-7514-1	223
15-7514-16	223
15-7514-21	223
15-7514-22	223
15-7514-32	223
15-7514-34	223
15-7514-35	223
15-7515	393
15-7515-1	394
15-7515-2	394
15-7515-3	394
15-7515-4	394
15-7515-5	394
15-7515-6	394
15-7515-7	394
15-7515-9	394
15-7515-11	394
15-7515-12	394
15-7515-13	394
15-7515-14	394
15-7515-15	394
15-7515-16	394
15-7515-17	394
15-7515-18	394
15-7515-19	394
15-7517-20	393
15-7515-21	393
15-7515-24	394
15-7515-25	394
15-7515-26	393
15-7516	238
15-7516-1	238
15-7516-3	239
15-7516-4	238
15-7517	125
15-7517-2	125
15-7518	239
15-7518-1	239
15-7518-3	240
15-7518-4	239
15-7520	237
15-7520-13	237
15-7520-14	237
15-7520-15	237
15-7521-4	424A
15-7521-5	424A
15-7521-7	424A
15-7521-15	424A
15-7522	413
15-7522-1	413
15-7523	118
15-7524	425
15-7524-1	426
15-7525-1	128
15-7525-3	128
15-7525-18	129
15-7525-19	129
15-7527	179
15-7530	504
15-7530-1	504
15-7530-2	504
15-7530-4	505
15-7530-5	505
15-7530-6	504
15-7530-8	505
15-7530-9	505
15-7530-10	505
15-7530-11	505
15-7530-12	505
15-7530-13	505
15-7330-14	505
15-7530-15	504
15-7530-16	504
15-7530-17	504
15-7530-18	504
15-7530-19	504
15-7533-1	413
15-7533-2	413
15-7533-3	413
15-7533-6	413
15-7533-7	413
15-7533-8	413

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
15-7533-11	413
15-7534-1	502
15-7534-2	502
15-7534-3	502
15-7534-4	502
15-7534-5	502
15-7534-6	502
15-7534-7	502
15-7534-8	502
15-7534-9	502
15-7534-11	502
15-7534-12	502
15-7534-14	502
15-7534-15	503
15-7534-28	502
15-7536	236
15-7536-1	236
15-7537-1	128
15-7537-2	129
15-7537-3	129
15-7538-1	479
15-7538-2	479
15-7538-3	479
15-7538-4	479
15-7538-5	479
15-7538-6	479
15-7538-7	479
15-7538-8	479
15-7539-1	128
15-7539-2	129
15-7539-3	129
15-7541	231
15-7541-18	231
15-7543	418
15-7543-1	418
15-7548-2	418
15-7543-3	418
15-7543-4	418
15-7543-6	419
15-7543-7	419
15-7543-8	418
15-7543-9	418
15-7543-10	418
15-7543-11	418
15-7543-12	419
15-7543-13	418
15-7543-14	418
15-7543-15	418
15-7543-16	418
15-7543-17	418
15-7543-18	419
15-7543-19	419
15-7543-20	418
15-7543-21	419
15-7543-22	419
15-7543-23	418
15-7543-24	418
15-7543-25	418
15-7543-26	418
15-7543-27	418
15-7543-28	418
15-7543-29	418
15-7543-30	418
15-7543-31	418
15-7543-32	419
15-7543-33	418
15-7543-34	418
15-7543-35	418
15-7543-36	418
15-7543-37	418
15-7543-38	418
15-7543-39	418
15-7543-40	418
15-7543-41	418
15-7543-42	418
15-7543-43	418
15-7543-44	418
15-7543-45	419
15-7543-46	419
15-7543-47	418
15-7543-49	418, 419
15-7543-50	418
15-7544	419
15-7544-1	419
15-7544-2	419
15-7544-3	419
15-7544-4	419
15-7544-6	419
15-7544-7	419
15-7544-8	419
15-7544-9	419
15-7544-10	419
15-7544-11	419
15-7544-12	419
15-7544-13	419
15-7544-14	419
15-7544-15	419
15-7544-16	419
15-7544-17	419
15-7544-18	419
15-7544-19	419
15-7544-24	419
15-7545	356
15-7545-1	356
15-7545-2	356
15-7545-3	356
15-7545-4	356
15-7545-5	356
15-7545-6	356
15-7545-7	356
15-7545-9	356
15-7545-10	356
15-7545-11	356
15-7545-12	356
15-7545-13	356
15-7545-14	356
15-7545-15	356
15-7545-16	356
15-7545-17	356
15-7545-18	356
15-7545-21	356
15-7545-24	356
15-7545-25	356
15-7545-26	356
15-7545-27	356
15-7545-28	356
15-7546	420
15-7546-1	420
15-7546-2	420
15-7546-3	420
15-7546-4	420
15-7546-5	420
15-7546-6	420
15-7546-7	420
15-7547	420
15-7547-1	420
15-7547-2	420
15-7547-3	420
15-7547-4	420
15-7547-5	420
15-7547-6	420
15-7547-8	420
15-7547-9	420
15-7547-10	420
15-7547-14	420
15-7547-15	420
15-7547-16	420
15-7547-17	420
15-7547-18	420
15-7547-19	420
15-7547-20	420
15-7547-21	420
15-7547-22	420
15-7548	420
15-7548-1	420
15-7548-2	420
15-7548-3	420
15-7548-4	420
15-7548-5	421
15-7548-6	421
15-7548-7	421
15-7548-8	421
15-7548-9	421
15-7548-10	421
15-7548-11	421
15-7548-12	421
15-7548-13	421
15-7548-14	421
15-7548-15	421
15-7548-16	421
15-7548-17	421
15-7548-18	421
15-7548-19	421
15-7548-20	421
15-7548-29	421
15-7548-30	421
15-7548-31	421
15-7548-32	422
15-7548-33	422
15-7548-34	422
15-7548-35	422
15-7548-36	421
15-7548-37	421
15-7548-38	421
15-7548-39	421
15-7548-40	421
15-7548-41	421
15-7548-42	421
15-7548-43	421
15-7548-44	421
15-7548-45	421
15-7548-46	421
15-7548-47	421
15-7548-48	421
15-7548-49	421
15-7548-50	421
15-7548-51	421
15-7548-52	421
15-7548-53	422
15-7548-54	422
15-7548-55	421
15-7548-56	421
15-7548-57	421
15-7549	422
15-7549-1	422
15-7549-2	422
15-7549-3	422
15-7549-4	422
15-7549-5	422
15-7549-6	422
15-7549-7	422
15-7549-8	422
15-7549-9	422
15-7549-10	422
15-7549-11	422
15-7549-12	422
15-7549-13	422
15-7571-1	128
15-7571-2	129
15-7571-3	129
15-7572	240
15-7572-1	240
15-7573	229
15-7573-1	229
15-7573-2	229
15-7573-3	229
15-7573-8	229
15-7573-9	229
15-7573-10	229
15-7573-11	229
15-7573-12	229
15-7573-13	229
15-7573-14	229
15-7573-15	229
15-7575	367
15-7575-1	367
15-7575-2	367
15-7575-5	367
15-7575-18	367
15-7575-20	367
15-7575-22	367
15-7575-23	367
15-7575-24	367
15-7575-25	367
15-7575-26	367
15-7575-27	367
15-7575-28	367
15-7575-29	367
15-7575-30	367
15-7575-31	367
15-7575-32	367
15-7575-33	367
15-7575-34	367
15-7575-35	367
15-7575-36	367
15-7575-37	368
15-7575-38	368
15-7575-39	368
15-7575-40	368
15-7575-41	368
15-7575-42	368
15-7575-43	368
15-7577	162
15-7577-1	162
15-7577-2	162
15-7577-3	162
15-7578-1	128
15-7578-2	129
15-7578-3	129
15-7579	393
15-7579-1	393
15-7579-3	393
15-7579-4	393
15-7579-5	393
15-7579-13	393
15-7580	121
15-7580-1	121
15-7581	122
15-7581-1	122
15-7582	447
15-7583	362
15-7583-1	362
15-7583-2	362
15-7583-3	362
15-7583-4	362
15-7583-5	362
15-7583-6	362
15-7583-7	362
15-7588-1	187
15-7588-2	187
15-7588-3	187
15-7589-4	502
15-7598-5	502
15-7589-6	502
15-7589-7	502
15-7589-8	502
15-7589-9	502
15-7589-10	502
15-7589-11	502
15-7589-12	502
15-7589-13	502
15-7589-14	502
15-7589-15	502

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
15-7589-16	502
15 7589-17	502
15-7589-18	502
15-7589-19	502
15-7589-21	502
15-7589-22	502
15-7589-34	502
15-7589-35	502
15-7589-41	506
15-7589-42	502
15-7589-44	506
15-7589-45	502
15-7590-1	350
15-7590-4	350
15-7590-5	350
15-7590-6	350
15-7590-7	350
15-7590-8	350
15-7590-9	350
15-7590-10	350
15-7591	86
15-7591-1	86
15-7591-12	86
15-7591-13	86
15-7592	86
15-7592-1	86
15-7592-10	86
15-7594	122
15-7594-1	122
15-7594-2	122
15-7594-3	122
15-7595	224
15-7595-1	224
15-7595-13	225
15-7595-14	224
15-7596	77
15-7596-1	77
15-7596-2	77
15-7596-3	77
15-7596-4	77
15-7596-5	77
15-7597	241
15-7600	348, 397
15-7600-9	399
15-7600-10	399
15-7600-11	399
15-7600-12	399
15-7600-13	399
15-7600-14	399
15-7600-15	399
15-7600-16	399
15-7600-17	399
15-7600-18	399
15-7600-19	399
15-7600-20	399
15-7600-21	399
15-7600-22	399
15-7600-23	399
15-7600-24	399
15-7600-25	399
15-7600-26	399
15-7600-27	399
15-7600-28	399
15-7600-29	401
15-7600-30	397
15-7600-31	397
15-7600-32	397
15-7600-33	397
15-7600-34	397
15-7600-35	397
15-7600-36	397
15-7600-37	397
15-7600-38	397
15-7600-39	398
15-7600-40	398
15-7600-41	398
15-7600-44	398
15-7600-45	398
15-7600-46	397
15-7600-47	398
15-7600-48	399
15-7600-49	399
15-7600-56	400
15-7600-57	400
15-7600-58	400
15-7600-59	400
15-7600-60	400
15-7600-61	400
15-7600-62	398
15-7600-69	400
15-7600-70	400
15-7600-71	400
15-7600-72	400
15-7600-73	400
15-7600-74	400
15-7600-75	400
15-7600-79	400
15-7600-80	400
15-7600-81	400
15-7600-82	400
15-7600-87	400
15-7600-88	400
15-7600-89	398
15-7600-90	400
15-7600-91	400
15-7600-92	400
15-7600-93	400
15-7600-94	400
15-7600-95	400
15-7600-96	400
15-7600-97	400
15-7600-98	400
15-7600-105	399, 400
15-7600-106	400
15-7600-107	400
15-7600-108	400
15-7600-109	400
15-7600-110	400
15-7600-111	400
15-7600-112	400
15-7600-113	398
15-7600-114	398
15-7600-115	398
15-7600-116	398
15-7600-117	398
15-7600-118	398
15-7600-119	398
15-7600-120	398
15-7600-121	398
15-7600-122	398
15-7600-123	398
15-7600-124	400
15-7600-125	400
15-7600-126	401
15-7600-127	401
15-7600-128	401
15-7600-129	401
15-7600-130	401
15-7600-131	398
15-7600-132	401
15-7600-133	401
15-7600-134	401
15-7600-135	401
15-7600-136	401
15-7600-137	401
15-7600-138	401
15-7600-139	401
15-7600-140	401
15-7600-141	401
15-7600-142	401
15-7600-143	401
15-7600-144	401
15-7600-145	401
15-7600-146	401
15-7600-149	401
15-7600-150	401
15-7600-151	401
15-7600-152	401
15-7600-157	401
15-7600-158	401
15-7600-159	400
15-7600-160	400
15-7600-161	400
15-7600-162	400
15-7600-180	400
15-7600-184	400
15-7600-185	400
15-7600-197	401
15-7600-198	401
15-7600-199	401
15-7600-200	401
15-7600-201	401
15-7600-202	401
15-7600-203	401
15-7600-204	401
15-7600-205	401
15-7600-206	401
15-7600-207	401
15-7600-208	401
15-7600-209	401
15-7600-210	401
15-7600-211	401
15-7600-212	401
15-7602-1	215
15-7602-3	215
15-7602-4	215
15-7603	216
15-7603-1	216
15-7603-5	216
15-7603-6	216
15-7603-13	216
15-7603-14	216
15-7603-16	216
15-7603-17	216
15-7606	224
15-7606-1	224
15-7606-20	224
15-7606-30	224
15-7607	80
15-7607-1	80
15-7607-11	80
15-7607-12	81
15-7609	266, 267
15-7609-1	266, 267
15-7609-2	266
15-7609-4	266, 267
15-7610	241
15-7610-1	241
15-7611	369
15-7611-1	369
15-7611-11	369
15-7611-12	369
15-7611-13	369
15-7611-15	369
15-7611-16	369
15-7613	122
15-7613-1	122
15-7614	122
15-7614-1	122
15-7615	122
15-7615-1	122
15-7616	268
15-7616-1	268
15-7616-2	268
15-7616-3	272
15-7617	114
15-7617-1	114
15-7617-2	114
15-7619-1	127
15-7619-2	127
15-7619-3	127
15-7619-4	127
15-7619-5	127
15-7619-6	127
15-7621	234
15-7621-1	234
15-7621-2	234
15-7621-4	234
15-7621-6	234
15-7621-7	234
15-7622	464
15-7624	268
15-7624-1	268
15-7624-2	268
15-7624-16	268
15-7624-17	268
15-7627	362
15-7627-1	362
15-7627-3	362
15-7627-7	362
15-7627-11	362
15-7627-12	362
15-7628	360
15-7628-1	360
15-7628-5	360
15-7628-13	360
15-7630	114
15-7630-5	114
15-7630-46	242
15-7631	114
15-7631-1	114
15-7631-2	114
15-7632	115
15-7632-1	115
15-7632-6	115
15-7632-7	115
15-7633	230
15-7633-1	230
15-7633-13	231
15-7633-14	231
15-7634	167
15-7636	122
15-7636-1	122
15-7637	123
15-7637-1	123
15-7638	47
15-7638-11	47
15-7639	29
15-7639-1	29
15-7641	235
15-7641-1	235
15-7641-5	235
15-7643	78
15-7643-1	78
15-7643-2	78
15-7643-3	78
15-7643-16	78
15-7643-17	78
15-7647	296
15-7647-1	296
15-7648	77A
15-7648-1	77A
15-7648-2	77A
15-7648-3	77A
15-7648-16	78
15-7648-17	78
15-7652	225
15-7652-1	225
15-7652-2	225
15-7652-3	225
15-7652-15	225

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
15-7652-16	225
15-7653	275
15-7653-1	275
15-7653-2	275
15-7653-8	275, 276
15-7653-12	276
15-7653-20	275
15-7653-21	275
15-7653-22	275
15-7653-23	276
15-7654	328
15-7654-1	328
15-7654-2	328
15-7655	268
15-7655-1	268
15-7655-2	268
15-7655-3	268
15-7655-5	270
15-7655-6	270
15-7655-7	270
15-7655-8	270
15-7661	229
15-7661-1	229
15-7661-2	229
15-7661-3	229
15-7662	268
15-7662-3	268
15-7663	241
15-7664	254, 338
15-7664-1	254, 338
15-7665	231
15-7665-14	231
15-7665-16	231
15-7666	266
15-7666-1	266
15-7666-2	266
15-7666-3	266
15-7666-4	266
15-7666-5	266
15-7666-6	266
15-7666-7	266
15-7666-14	266
15-7666-15	266
15-7666-16	266
15-7667	342
15-7668	267
15-7668-1	267
15-7668-2	267
15-7668-3	267
15-7668-4	267
15-7668-5	267
15-7668-12	267
15-7668-13	267
15-7668-18	267
15-7668-19	267
15-7668-22	267
15-7668-23	267
15-7668-28	267
15-7668-29	267
15-7669	266, 267
15-7669-1	266
15-7670	234
15-7670-1	234
15-7670-6	234
15-7670-7	234
15-7672	342
15-7672-1	342
15-7672-5	342
15-7672-6	342
15-7673	342
15-7673-1	342
15-7673-2	342
15-7673-3	342
15-7673-4	342
15-7673-5	342
15-7673-6	342
15-7673-7	342
15-7674	338
15-7674-1	338
15-7674-2	338
15-7674-3	338
15-7674-4	338
15-7674-5	338
15-7674-6	338
15-7674-7	338
15-7675	339
15-7675-1	339
15-7675-2	339
15-7675-3	339
15-7675-4	339
15-7675-5	340
15-7675-6	339
15-7675-7	340
15-7678	241
15-7681	273
15-7681-1	274
15-7681-7	274
15-7681-8	274
15-7682	274
15-7682-2	274
15-7682-8	274
15-7683	273
15-7686	424
15-7686-1	424
15-7686-16	424
15-7686-17	424
15-7688	52
15-7688-4	52
15-7688-5	52
15-7688-6	52
15-7688-7	52
15-7689	403
15-7689-1	403
15-7689-2	403
15-7689-4	403
15-7689-5	403
15-7689-6	403
15-7689-8	403
15-7689-10	403
15-7689-12	403
15-7689-14	403
15-7689-15	403
15-7689-17	403
15-7689-20	403
15-7689-24	403
15-7689-25	403
15-7689-27	403
15-7689-28	403
15-7689-29	403
15-7689-32	403
15-7689-34	404
15-7689-36	404
15-7689-37	404
15-7689-39	404
15-7689-40	404
15-7689-44	404
15-7689-48	404
15-7689-49	404
15-7689-50	404
15-7689-51	404
15-7689-52	404
15-7689-53	404
15-7689-54	404
15-7689-56	404
15-7689-58	404
15-7689-60	404
15-7689-62	404
15-7689-63	404
15-7689-65	404
15-7689-68	404
15-7689-69	404
15-7689-70	404
15-7689-72	404
15-7689-73	404
15-7689-74	404
15-7689-77	404
15-7689-79	404
15-7689-81	404
15-7689-82	404
15-7689-84	404
15-7689-85	404
15-7689-89	404
15-7689-90	404
15-7689-91	404
15-7689-92	404
15-7689-93	404
15-7689-94	404
15-7689-95	404
15-7689-96	404
15-7689-98	404
15-7689-100	404
15-7689-104	404
15-7689-106	404
15-7689-107	404
15-7689-108	404
15-7689-109	404
15-7689-110	404
15-7689-111	404
15-7689-114	404
15-7689-116	404
15-7689-118	404
15-7689-119	404
15-7689-122	404
15-7689-123	405
15-7689-124	405
15-7689-126	405
15-7689-127	405
15-7689-128	405
15-7689-130	405
15-7689-132	405
15-7689-136	405
15-7689-137	405
15-7689-138	405
15-7689-139	405
15-7689-140	405
15-7689-143	405
15-7689-145	405
15-7689-148	405
15-7689-151	405
15-7689-164	403
15-7689-165	405
15-7689-166	403
15-7689-167	405
15-7689-168	405
15-7689-169	405
15-7689-170	405
15-7689-171	405
15-7689-172	403
15-7689-173	405
15-7772	296
15-7772-1	296
15-7773	296
15-7773-1	296
15-7773-2	296
15-7773-4	296
15-7774	531
15-7744-2	533
15-7774-3	533
15-7774-4	533
15-7774-5	533
15-7774-6	533
15-7774-7	533
15-7774-8	533
15-7774-9	533
15-7774-10	533
15-7774-11	533
15-7774-12	533
15-7774-15	533
15-7774-29	533
15-7774-30	533
15-7774-32	533
15-7774-33	533
15-7774-36	533
15-7774-37	533
15-7775	424
15-7776	424
15-7776-1	424
15-7777	424
15-7780	231, 232
15-7780-1	231
15-7780-80	232
15-7780-81	232
7781	447
15-7781-1	447
15-7781-2	447
15-7781-3	447
15-7781-4	447
15-7781-5	447
15-7784	88
15-7784-1	88
15-7784-2	88
15-7785	527, 544
15-7785-6	527
15-7786	527, 544
15-7789	5, 531
15-7789-1	542
15-7789-2	543
15-7789-3	543
15-7789-4	543
15-7789-16	543
15-7789-17	543
15-7789-18	543
15-7789-19	543
15-7789-20	543
15-7789-21	543
15-7789-22	543
15-7789-23	544
15-7789-24	544
15-7789-25	543
15-7789-26	543
15-7789-27	543
15-7789-28	543
15-7789-29	543
15-7789-30	543
15-7789-31	543
15-7789-32	543
15-7789-33	543
15-7789-34	543
15-7789-35	543
15-7789-36	544
15-7789-39	543
15-7789-40	543
15-7789-41	543
15-7789-42	543
15-7789-43	544
15-7789-44	544
15-7789-46	544
15-7789-47	544
15-7789-48	544
15-7789-49	544
15-7789-57	543
15-7789-58	543
15-7789-59	544
15-7789-60	544
15-7930-1	153
15-7931	5, 516
15-7931-1	516
15-7931-2	516
15-7931-3	516
15-7931-4	516

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
15-7931-16	516
15-7931-17	516
15-7931-18	516
15-7931-19	516
15-7931-20	516
15-7931-21	516
15-7931-22	516
15-7931-23	516
15-7931-24	516
15-7931-25	516
15-7931-26	516
15-7931-27	516
15-7931-28	516
15-7931-29	516
15-7931-30	516
15-7931-31	516
15-7931-32	517
15-7931-33	517
15-7931-34	517
15-7931-35	517
15-7931-36	517
15-7931-39	516
15-7931-40	516
15-7931-41	516
15-7931-42	516
15-7931-43	516
15-7931-44	516
15-7931-45	516
15-7931-46	516
15-7931-47	516
15-7931-48	516
15-7931-50	517
15-7931-57	517
15-7931-58	517
15-7931-59	517
15-7931-60	517
15-7934	517
15-7934-2	517
15-7934-3	517
15-7934-4	517
15-7934-5	517
15-7934-6	517
15-7934-7	517
15-7934-8	517
15-7934-9	517
15-7934-10	517
15-7934-11	517
15-7934-12	517
15-7934-14	517
15-7934-15	517
15-7934-27	517
15-7934-28	517
15-7934-29	517
15-7934-31	517
15-7934-32	517
15-7934-33	517
15-7934-34	517
15-7935	371
15-7935-1	371
15-7935-2	371
15-7935-3	371
15-7935-4	371
15-7935-5	371
15-7936	285
15-7936-1	285
15-7937	136
15-7937-7	136
15-7937-8	136
15-7943	165
15-7943-1	165
15-7943-6	165
15-7943-9	165
15-7943-13	165
15-7943-14	165
15-7943-15	165
15-7943-16	165
15-7944	296
15-7945	78
15-7960	272
15-7960-27	272
15-7960-28	272
15-7961	271
15-7961-27	272
15-7961-28	272
15-7962	271
15-7964	466
15-7964-1	466
15-7964-2	467
15-7964-3	466
15-7964-4	466
15-7964-5	466
15-7964-6	467
15-7964-7	467
15-7964-8	467
15-7970	269
15-7970-1	269
15-7971	269
15-7971-1	269
15-7971-2	269
15-7971-3	269
15-7973	77
15-7973-1	77
15-7973-2	77
15-7973-3	77
15-7983-1	464
15-7983-2	464
15-7983-5	464
15-7984	155
15-7994	43
15-7994-1	43
15-7994-2	43
15-7994-3	43
15-7994-6	43
15-7999	423
15-7999-4	423
15-8520	224
15-8520-1	224
15-8520-4	224
15-8520-10	224
15-8522	296, 300
15-8522-1	296, 300
15-8522-2	300
15-8524	272
15-8529	540
15-8529-1	540
15-8529-3	540
15-8535	42, 50
15-8535-1	42, 50
15-8535-13	50
15-8535-14	50
15-8536	28, 36
15-8536-1	28, 36
15-8536-8	36
15-8536-9	36
15-8537	61
15-8537-1	61
15-8537-5	62
15-8537-6	62
15-8537-12	62
15-8541	296, 301
15-8541-1	296, 301
15-8541-2	301
15-8548	511, 523, 538
15-8548-1	511, 523, 538
15-8757	194
15-8757-1	194
15-8761	193
15-8761-1	193
15-8761-2	193
15-8761-3	193
15-8765-3	194
15-8765-4	194
15-8767	225
15-8767-1	225
15-8767-6	226
15-8767-7	226
15-8767-9	226
15-8767-10	226
15-8767-11	226
15-8767-12	226
15-8767-13	226
15-8774	240
15-8775	240
15-8778	240
15-8778-5	241
15-8779	240
15-8779-3	240
15-8779-4	240
15-8782	428
15-8782-2	429
15-8782-15	428A
15-8782-16	429
15-8782-17	428A
15-8782-18	429
15-8782-19	429
15-8785	430
15-8785-1	430
15-8786	366
15-8786-1	366
15-8786-4	366
15-8788	236
15-8789	430
15-8789-1	430
15-8789-2	430
15-8789-3	430
15-8789-10	430
15-9009	359
15-9009-1	359
15-9009-2	359
15-9009-3	359
15-9009-4	359
15-9009-5	359
15-9009-6	359
15-9009-7	359
15-9009-8	359
15-9252	232
15-9252-1	232
15-9252-2	232
15-9253	449, 456
15-9253-1	456
15-9253-2	456
15-9253-4	456
15-9254	449, 452
15-9254-1	453
15-9255	423, 432
15-9256-1	149
15-9256-2	150
15-9257	149
15-9257-1	149
15-9257-2	150
15-9267	234
15-9267-8	234
15-9267-9	234
15-9268	359
15-9268-1	359
15-9268-2	359
15-9268-3	359
15-9368-4	359
15-9368-5	359
15-9368-6	359
15-9368-7	359
15-9368-8	359
15-9368-9	359
15-9268-10	359
15-9368-11	359
15-9368-12	359
15-9368-13	359
15-9275	303, 305
15-9275-1	305
15-9286	370
15-9286-1	370
15-9286-2	370
15-9286-3	370
15-9286-4	370
15-9286-5	370
15-9287	369
15-9287-1	369
15-9287-2	369
15-9287-3	369
15-9287-4	369
15-9287-11	369
15-9287-12	369
15-9287-13	369
15-9287-14	369
15-9287-15	370
15-9287-16	370
15-9287-17	370
15-9287-19	370
15-9287-20	369
15-9287-21	369
15-9287-22	369
15-9287-23	369
15-9287-24	369
15-9287-25	369
15-9293	428
15-9297	215
15-9297-2	215
15-9297-3	215
15-9298	140, 167
15-9451	149
15-9451-1	149
15-9462	288
15-9475-8	370
15-9475-10	370
15-9486	293
15-9486-1	293
15-9486-2	293
15-9486-3	293
15-9486-6	293
15-9486-7	293
21-264-2	28
21-556-1	248
21-557	248
21-926-1	106
21-1022-8-S	145
21-1063	198
21-1537-4	103
21-1803-1	26
21-2023-1	123, 135
21-2089	344, 402
21-2098	454
21-2136	454
21-2136-2	454
21-2165-1	336
21-2169	455
21-2226-2	454
21-2348-6	455
21-2361-25-13	459
21-2361-30-17	433
21-2362-49-14	182, 184
21-2362-64-11	255, 256
21-2362-72-56	454
21-2363-26-16	459
21-2363-32-13	96
21-2363-36-13	512, 525, 539
21-2363-48-12	510, 524, 536
21-2363-48-17	455
21-2363-68-20	322
21-2363-68-21	320
21-2363-80-28	379
21-2363-128-86	384
21-2364-18-7	464A
21-2364-32-8	158
21-2364-40-26	461

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
21-2364-48-11	382
21-2364-48-13	158
21-2364-48-33	452
21-2364-56-17	327, 328
21-2364-64-11	382
*21-2364-71-48	180, 181, 310
21-2364-72-56	454
21-2364-76-34	349
21-2364-108-57	66
21-2365-64-41	273
21-2366-28-13	159
21-2366-32-11	473
21-2366-32-16	425
21-2366-58-44	133
21-2366-68-26	461
21-2366-96-15	425
21-2366-238-98	248
*21-2367	144, 145, 152
21-2367-1	144, 152
21-2367-2	153, 167
21-2367-3	153, 155,167
21-2367-4	192, 193
21-2367-5	192, 193
21-2367-6	29, 44, 153
21-2367-7	29, 44, 153
21-2367-8	144, 196
21-2367-9	144, 196
21-2521-8	112
21-2545-1	406
21-2589-1	489
21-2589-7	345
21-2589-8	498
*21-2589-16	289, 345, 386
21-2589-19	398, 403, 498
21-2589-20	498
21-2589-23	287, 363, 398
21-2589-24	474, 475
21-2589-27	75
21-2589-31	293
21-2589-39	293
21-2589-47	498
21-2589-55	498
*21-3147-1	8, 41, 103
*21-3147-2	26, 48, 85
21-3180-5	490
21-3225	452
21-3232	146, 222,223
21-3339-22	289
21-3703-1	466, 467
21-3753	454
21-3754-1	454
21-3894-24-13	387
21-3894-26-13	376
21-3894-28-13	161
21-3894-48-17	115
21-3894-48-25	162
21-3894-56-11	349
21-3894-56-26	408
21-3894-64-41	332, 335
21-3894-108-57	433
21-3894-140-6	62
21-4213-6-4	489
*21-4585-42-12	345, 394, 455
*21-4585-96-20	391, 393, 481
21-4585-140-32	293
21-4585-168-48	293
21-4655	345
21-4838-60	115, 484
21-4838-60A	115
21-4839-70	345
21-4839-70A	345
21-4839-90	345
21-4839-90A	345
21-4841-20	375
21-4841-40	328, 455
21-4841-50	113, 114
21-4841-50A	113, 114
21-4841-60	165
21-4841-70	114
21-4841-70A	114
21-4842-40	455
21-4842-50	469
21-4843-50	90
21-4843-50A	90
21-4843-80	91
21-4843-80A	91
21-4844-30	362
21-4844-50	410, 527, 544
21-4844-60	285, 293, 403
21-4844-70	327
21-4844-80	293, 328
21-4844-90	474, 475
21-4844-100	293, 411
21-4848-80	293
21-5136	249
21-5172	461
21-5174	461
21-5179	454
21-5179-2	454
21-5179-3	455
21-5180	390
21-5345	194
21-5473-4	140
21-5473-5	140
21-5474	167
21-5474-1	167
21-5474-5	187, 188
21-5508	176
21-5511	18, 21
21-5511-1	18, 21
21-5511-2	97
21-5511-3	97
21-5512-1	18, 21
21-5515	167, 194
21-5531	99
21-5531-1	99
21-5531-2	98
21-5531-3	98
*21-5534	18, 20, 21
*21-5534-1	21, 22, 23
21-5536	98
21-5536-1	98
21-5537	99
21-5538	432, 443, 445
21-5538-1	432, 445
21-5538-16	445
21-5538-17	445
21-5566	106
21-5566-1	106
21-5581	167
21-5581-1	141
21-5582	141, 167
21-5582-1	141
21-5584	448
21-5591	148
21-5593	148
21-5594	148
21-5601-2	198
21-5601-3	198
21-5604-1	174
21-5604-3	169
21-5604-4	174
21-5604-5	196
21-5604-6	196
21-5604-7	196
21-5604-8	196
21-5608-1	198
21-5609	198
21-5609-1	198
21-5615-1	167
21-5617	168
21-5617-1	168
21-5617-2	168
21-5617-3	168
21-5618-3	193
21-5624	171, 177
21-5624-2	177
21-5625	171
21-5526	171, 177
21-5626-2	171
21-5626-3	171
21-5627	171
21-5627-2	171
21-5633	171
21-5641	376
21-5656-1	177
21-55664-1	171, 176
21-5738	97, 98
21-5738-1	97, 98
21-5739-1	102
21-5739-2	97, 98, 99
21-5739-3	97, 98, 99
21-5741-1	101, 102
21-5741-2	100, 101
21-5741-4	99, 100
21-5742-6	74
21-5742-7	74
21-5742-8	74
21-5743	96
21-5748	106, 108
21-5782-6	72
21-5782-7	72
21-5782-8	72
21-5782-9	72
21-5833	99
21-5833-1	99
21-5834	99
21-5834-1	99
21-5835	101, 102
21-5835-1	101, 102
21-5836	101, 102
21-5836-1	101, 102
21-5841-1	101
21-5887	100, 101
*21-5887-1	18, 19, 20
21-5887-2	21, 99, 100
21-5887-3	14
21-5887-4	14, 21, 22
21-5887-5	100, 101
*21-5887-6	14, 18, 21
21-5913	109
21-5932	315, 461
21-5933	111
21-5938	102
21-5941	167
21-5941-1	167
21-5942	168
21-5943	315, 461
21-5943-1	315, 461
21-5943-2	461
21-5947	130
21-5958-1	442, 443
21-5958-2	150, 442, 443
21-5958-5	150, 443
21-5958-6	443
21-5958-7	443
21-5960	376
21-5963	376
21-5991-1	130
21-5994	130
21-5994-1	130
21-5994-2	130
21-6003	99
21-6018-1	69
21-6021	22, 23
21-6021-1	23
21-6022	171
21-6030	135
21-6030-1	135
21-6030-2	135
21-6031	134
21-6031-1	134
21-6031-2	134
21-6031-3	134
21-6031-4	134
21-6035-1	135
*21-6038	24, 43, 75
21-6041	171
21-6041-1	171
21-6042	171
21-6042-1	171
21-6082-46	43, 77
21-6082-56	74, 75, 268
*21-6083	43, 74, 75
21-6087-3-3	330
21-6087-5-3	334
21-6087-6-3	334, 501
21-6092-12-0	92
21-6092-18-1	31
21-6092-32-6	280, 281, 286
21-6092-45-31	243A
21-6094	108
21-6094-1	108
21-6107	106
21-6107-1	106
21-6107-4	106
21-6107-5	106
21-6108	106
21-6108-1	106
21-6108-4	106
21-6108-5	106
21-6116-32	162
21-6118-1	490
21-6126	69
21-6126-1	69
21-6126-2	69
21-6126-3	69
21-6126-4	69
21-6136	21
21-6136-1	18
21-6146-1	23
21-6169-18	67
21-6169-19	67
21-6177-1	22
21-6222	432
21-6240-1	194
21-6246	150
21-6246-1	150
21-6246-2	150
21-6264-9	131
21-6277	316
21-6294	245
21-6294-3	245
21-6294-4	245
21-6294-5	245
21-6305	245
21-6306	245
21-6326-1	188
21-6327	187
21-6328	188
21-6334	22
21-6349	58
21-6349-1	58
21-6349-2	59
21-6349-3	59
21-6349-4	59
21-6349-5	59
21-6349-6	59
21-6349-7	59
21-6349-10	59
21-6349-11	59
21-6355	245
21-6355-1	245

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
21-6356	245
21-6359	245
21-6377-6-3	245
21-6385-80-45	437
21-6385-112-88	439
21-6385-152-98	248
21-6385-180-160	439
21-6387	135
21-6387-1	135
21-6387-2	135
21-6420	245
21-6429	96
21-6441-5	334
21-6441-6	334, 501
21-6447-4	135
21-6447-5	135
21-6448	135
21-6448-1	135
21-6448-2	135
21-6448-3	135
21-6448-4	135
21-6448-5	135
21-6449	135
21-6469-1	138
21-6492	150
21-6498	150
21-6498-1	150
21-6498-2	150
21-6498-3	150
21-6526-3	103
21-6527	103
21-6542	169
21-6578-0-5	187
21-6578-1	191
21-6584-2	104
21-6584-3	104
21-6588-80-21	438
21-6602-20-1	233
21-6609	134
21-6609-6	134
21-6630	24
21-6630-1	24
21-6630-2	24
21-6671-14H3	331, 336
21-6685-9	163
21-6708-2	91
21-6708-3	91
21-6715	104
21-6715-1	104
21-6716	104
21-6716-1	104
21-6717	245
21-6718-3	245
21-6726-21-7	100, 101
*21-6730-28-7	14, 20, 21
21-6730-28-10	19
21-6730-28-18	182
*21-6744	165, 200, 233
21-6747	104, 105
21-6747-1	104, 105
21-6747-2	104
21-6747-3	104, 105
21-6758	218
21-6847	134
21-6847-1	134
21-6847-2	134
21-6849	99
21-6850	434
21-6854-2	91
21-6861	135
21-6861-1	135
21-6861-2	135
21-6861-4	135
21-6862-32-12	475
21-6862-32-17	10, 11
21-6862-60-26	327
21-6867	252
21-6872	135
21-6893	170
21-6909-0-40	223
21-6926	253
21-6928-50	459
21-6928-75	459
21-6947-1	253
21-6948	252
21-6948-1	252
21-6948-2	252
21-6948-3	252
21-6948-4	252
21-6948-5	252
21-6955	464
21-6966-1	433
21-6974-1	433
21-6975-51	345
21-6979	433
21-6996	344
21-7001	187
21-7007-5	186
21-7007-6	186
21-7008-5	186
21-7009-1	187
21-7010-1	187
21-7013	186
21-7013-1	186
21-7020	186
21-7021	186
21-7022	103
21-7022-1	27
21-7030-1	186
21-7031	61
21-7064-4	434
21-7196-10	452
21-7205	349
21-7221-1-16	64
21-7221-1-28	24
21-7221-16	64
21-7224	153
21-7225	153
21-7270-4	433
21-7277-10	464A
21-7307-1	475, 478, 479
21-7308	475, 478
21-7308-1	479
21-7312-5	133
21-7312-6	133
21-7328	475, 478
21-7329	476, 478
21-7379	462
21-7395-48-17	464, 465
21-7395-104-56	149
*21-7401	255, 256, 466
21-7401-1	468A, 486
21-7401-5	375
21-7401-6	468
21-7440-3	489
21-7452-3-0	21
21-7468	452
21-7484	171, 177
21-7512	177
21-7606	349, 472, 490
21-7758-2-10	109
21-7758-2-12	109
21-7758-2-13	109
21-7829	243, 244
21-7837	162
21-7837-1	345
21-7838	360
21-7859	490
21-7859-1	490
21-7859-3	490
21-7988-8-3	251
21-8038-12	92
21-8038-16A	442, 444
21-8038-18	311
21-8038-52A	445
21-8364-4	487
21-8364-4A	487
21-8364-4B	488
21-8364-4C	488
21-8377-24	126, 129
21-8378-39	163
21-8440	252
21-8444	243, 244
21-8457-52	314
21-8469-48-50	25, 83
21-8469-50-50	82, 83
21-8487-26	314, 316
21-8487-28	313
21-8487-32	314
21-8487-50	314
21-8487-55	314
21-8539-36	65
21-8539-38	69
21-8627	467
21-8627-4	488, 527, 544
21-8627-8	466
21-8627-12	477
21-8627-14	512, 525, 539
21-8645-16-8	84
21-8645-17-9	84
21-8645-18-10	84
21-8645-19-11	84
21-8645-20-10	34
21-8645-20-12	84
21-8663	378
21-8777-1	412
21-8880-1	378
21-8891-4	488, 527, 544
21-8891-4A	488, 527, 544
21-8891-8	466, 467
21-8891-8A	466, 467
21-8891-12	477
21-8891-12A	477
21-8891-14	512, 525, 539
21-8891-14A	512, 525, 539
21-8894	378
21-8962-48-13	227
21-9064	169
21-9064-1	169
21-9070	441
21-9071	441
21-9073	199
21-9073-1	199
21-9073-2	199
21-9073-3	199
21-9073-4	199
21-9073-5	199
21-9073-6	199
21-9073-7	199
21-9073-8	199
21-9073-9	199
21-9078-1	134
21-9078-2	118, 121
21-9078-6	118
21-9083	247
21-9084	248
21-9091	171
21-9092	171
21-9093	171
21-9107	376
21-9109	376
21-9132-1	56
21-9141	168
21-9142-2	167
21-9142-3	167
21-9148	167
21-9212	447
21-9212-1	447
21-9212-2	447
21-9214-4	447
*21-9221	141, 141A, 142
21-9233	447
21-9352	377
21-9360	458
21-9360-1	458
21-9360-2	458
21-9360-3	458
21-9360-4	458
21-9370	377
21-9370-1	377
21-9370-2	377
21-9373-41-36	325
21-9373-81-75	325
21-9379-1	160, 162,179
21-9388	248
21-9389-1	248
21-9391	248
21-9392	96, 97, 99
*21-9392-1	19, 20, 96
21-9401	150
21-9402	150
21-9403	150
21-9403-1	150
21-9404	151
21-9405	150
21-9414	248
21-9415	248
21-9417	433
21-9430-1	27
21-9434-1	181
21-9438-5	181
21-9441-100	459
21-9441-150	459
21-9443-8	459
21-9444	459
21-9454	171
21-9454-1	171
21-9457	436
21-9486	411
21-9490-1	436
21-9490-3	436
21-9490-8	436
21-9491	436, 437
21-9491-1	436
21-9491-3	436
21-9491-5	436
21-9492	436, 437
21-9492-1	436
21-9492-3	436
21-9492-5	436
21-9499	349
21-9511	437
21-9511-1	437
21-9520	171
21-9530	311
21-9531-1	305, 315, 461
21-9531-4	461
21-9533	311, 461
21-9574	307
21-9579	437
21-9586	357
21-9587-1	437
21-9587-2	437
21-9587-5	437
21-9588-1	283, 284
21-9588-4	84
21-9588-6	247
21-9588-7	247
21-9588-8	84
21-9588-9	81
21-9588-10	248
21-9588-11	84
21-9588-12	248
21-9594	181

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
21-9594-1	181
21-9646	367, 413
21-9670	145
21-9672	440
21-9672-1	440
21-9672-3	440
21-9672-5	440
21-9677	440
21-9677-1	440
21-9678	439
21-9682	439
21-9683	440
21-9689	181
21-9694	348
21-9734-64	82, 83
21-9735-64	85
21-9735-188	89
*21-9751-2	118, 252, 253
*21-9751-16	118, 121, 244
*21-9751-16A	118, 121, 244
21-9751-20	252, 253
21-9751-20A	252, 253
*21-9753	469, 514, 526
21-9753-1	469
21-9753-2	469
21-9759	351, 352
21-9784-10-3A	443
21-9784-10-4A	445
21-9824	440
21-9824-2	440
21-9824-4	440
21-9838	249
21-9839	249
21-9839-1	249
21-9839-2	249
21-9839-3	249
21-9839-4	249
21-9840	249
21-9840-1	249
21-9840-2	249
21-9841	249
21-9852	443
21-9852-1	443, 444
21-9860	439
21-9861	439
21-9862	439
21-9862-1	439
21-9879	437
21-9879-1	437
21-9880	437
21-9880-1	437
21-9881-1	437
21-9882	437
21-9884	446
21-9885	461
21-9886	439
21-9890	436
21-9890-1	436
21-9892	171
21-9904	461
21-9905	151, 195, 196
21-9905-1	151, 195, 196
21-9905-2	196
21-9905-3	196
21-9905-4	196
21-9905-5	196
21-9944-3	424A
41-5-4	434
41-16	447
41-40	426
41-43	252, 253
41-43-2	252
41-63	177
41-63-1	177
41-67	448
41-68	448
41-72	448
41-75-2	447, 448
41-76-1	448
41-78	448
41-82	466, 467
41-87	148
41-88	147
41-94	438
41-96	411
41-128-20-12	287
41-128-40-25	375
41-143	434
41-143-1	434
41-143-2	434
*41-158	232, 242, 362
*41-158-1	509, 510, 521
*41-159	232, 362, 469
41-162-1	475, 485, 487
41-162-2	487
41-164	186
41-202-7	137
41-207-16	51-53
41-207-26	51
41-236-1	432
41-239-10	432
41-239-11	432
41-239-13	432
41-277	470
41-277-8	468A
41-277-11	480
41-293	350, 351
41-306	187
41-306-1	187
41-314	152
41-353-13-7	427
41-353-15-7	165
41-353-15-8	175
41-353-15-21	359
41-445-0-4	13
*41-445-0-6	503, 517, 518
41-445-0-9	53
41-445-0-10	62
41-445-0-12	51, 100
41-445-0-14	62
41-445-0-16	38, 51, 320
41-445-0-18	64
41-445-0-20	320
41-445-0-22	64
41-445-0-24	320
41-445-0-28	25
41-445-0-40	76
41-468-16-3	398, 498
41-468-21-6	398
*41-468-28-8	14, 345, 347
41-468-30-9	15, 333
41-468-48-10	416
*41-468-56-12	388, 394, 398
*41-468-70-16	345, 408, 411
*41-468-86-24	386, 398, 403
41-468-88-25	331, 333
41-484-6-1	447
41-484-6-6	447
41-504	464, 464A, 465
41-504-1	464, 464A, 465
41-514	190
41-580	477
41-665-2	37, 52, 53
41-671	248
41-672-4	304, 319
41-688-3	397, 398
41-761	288
41-762	288
41-778	376
41-782	252
41-789	434
41-805	84
41-828	377
41-871-21-11	112
41-871-27-13	82
41-871-28-11	74
41-871-35-15	99, 101, 102
41-871-47-15	21
41-871-49-13	15
41-871-50-13	14, 15
41-871-50-22	14
41-871-51-13	14
41-871-59-12	18
41-1058-XL6	126
41-1058XM6	126, 129
41-1058-XT6	126
41-1063-4-3	345, 411
41-1063-5-3	345
41-1063-6-3	411
41-1065-3	391, 398, 499
41-1065-4	345, 346, 411
41-1065-5	345
41-1065-6	391, 411, 499
41-1065-21	345
41-1065-22	345
41-1065-64-17	63
41-1066-32-13	321
41-1066-32-16	160
41-1066-40-13	188
41-1066-48-22	327
*41-1066-64-17	37, 38, 51
41-1066-164-108	249
*41-1150	507, 508, 509
*41-1150-1	519, 520, 521
41-1156	89
41-1156-1	85
41-1156-2	85
41-1178-2	367
41-1216	454
41-1242	377
41-1243-1	365
41-1243-2	365
41-1243-3	365
41-1254	365
41-1351	361
*41-1373	466, 467, 507
41-1384	425
41-1384-2	425
41-1394-14	135
41-1394-15	135
41-1395-16	118
41-1395-21	94
41-1399-1	81
41-1399-26	81
41-1399-48	81
41-1426	57
41-1433	10
41-1433-1	10
41-1433-2	10
41-1433-3	10
41-1433-4	10
41-1433-5	10
41-1434	93, 463
41-1434-1	92
41-1435	92, 93, 463
41-1436	93
41-1436-1	463
41-1463-2	92
41-1437	93
41-1439	92, 93, 463
41-1457	543
41-1457-35	450, 456
41-1458-1-0	16, 17
41-1464-30-16	394
41-1464-32-13	315
41-1464-40-25	315
41-1464-70-38	493, 497, 498
41-1501	365
41-1606-37-10	99, 101, 102
*41-1606-37-11	18, 20, 21
41-1645-52	144, 194
14-1645-55	32
41-1645-57	62
41-1645-63	168
41-1645-67	188
41-1645-68	76
41-1645-75	232
41-1720	165
41-1725-1	196
41-1725-2	196
41-1725-3	196
41-1734-2	398
41-1766	195
41-1779	194
41-1801	103
41-1801-1	27
*41-1818	160, 168, 183A
41-1831-3	105, 118
41-1879	481, 482
41-2086	266, 267
*41-2086-1	29, 34, 45
*41-2399	186, 307, 310
41-2424-32-17	113, 114
41-2476	154
41-2476-3	154
41-2486	271
*41-2488	304, 309, 311
41-2531	485
41-2536-1-16	214
41-2541	57
41-2541-1	57
*41-2558-1	280, 281, 286
41-2562	247
41-2566	248
41-2567	248
41-2568	248
41-2569	247
41-2571-1	250
41-2574-12	45, 46
41-2574-13	46
41-2574-14	48
41-2574-15	48
41-2574-16	48
41-2574-17	48
41-2629	247
41-2636-14	247
41-2636-15	247
41-2636-16	247
41-2636-17	247
41-2636-18	247
41-2661-2	465
*41-2668-4	375, 433, 443
41-2741-6B	161, 176
41-2787	13
41-2789	84
41-2801	92, 93, 463
41-2817	249
41-2817-1	249
41-2817-2	249
41-2823	69
41-2823-1	73
41-2823-2	73
41-2823-3	73
41-2823-4	73
41-2830	69
41-2830-1	68
41-2834-1	457
41-3002-24-104	109
41-3002-28-56	151
41-3002-30-64	143
41-3002-59-80	187
41-3003-25-64	202
41-3003-25-70	202, 204

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
41-3003-40-144	163
41-3003-56-40	59, 60
41-3003-56-48	73
41-3003-68-48	179
41-3003-69-44	72, 73
41-3003-97-48S	172, 176
41-3005-97-48S	172, 176
41-3018-253-6	90
*41-3034	55, 171, 336
41-3039	72
41-3040	72
41-3041	72
41-3043	72
41-3044	72
41-3045	72
41-3045-1	72
41-3046	72
41-3046-1	72
41-3047	72
41-2047-1	72
41-3048	72
41-3048-1	72
41-3049	72
41-3049-1	72
41-3050	72
41-3050-1	72
41-3054-17	156, 157
41-3054-18	158
41-3055	69
41-3119	146
41-3125	11
41-3125-1	11
41-3125-2	10
41-3125-3	10
41-3140	72
41-3140-1	72
41-3140-2	72
41-3140-3	72
41-3140-4	72
41-3140-5	72
41-3140-6	72
41-3140-7	72
41-3140-8	72
41-3140-9	72
41-3150	58
41-3232	359
41-3316-6	140
41-3316-7	140
41-3316-28	48
41-3316-29	48
41-3316-30	48
41-3316-31	48
41-3383	68
41-3387-16-8	84
41-3387-17-9	84
41-3387-18-10	84
41-3387-19-11	84
41-3387-20-12	84
41-3390	12
41-3390-1	12
41-3412	243, 244
41-3413	243, 244
41-3422	58
41-3424	408
41-3426	408
41-3427	408
41-3427-1	408
41-3428	408
41-3429	408
41-3430	408
41-3433	408
41-3433-1	408
41-3555	91
41-3555-1	91
41-3555-2	91
41-3560	459, 460
41-3572	91
41-3572-1	91
41-3623	34
41-3623-1	34
41-3625	34
41-3625-1	34
41-3627-1	135
41-3627-2	135
*41-3637	29, 34, 45
41-3701	155
41-3702	34
41-3702-1	34
41-3703	34
41-3710	452
41-3711	452
41-3712-1	452
41-3713-1	452
41-3715-1	452
41-3716-2	452
41-3718-1	452
41-3719	452
41-3722	452
41-3723	452
41-3724	452
41-3727-1	243, 244
41-3727-3	243, 244
41-3727-4	243, 244
41-3741	27
41-3741-1	27
41-3758	452
41-3796	402
41-3797	402
41-3824-1	243, 244
41-3826-1	34
41-3826-2	34
41-3827	34, 47
41-3827-1	34, 47
41-3828	34, 48
41-3828-1	34, 48
41-3831	34, 35, 47
41-3834	26, 48
41-3840	34, 47
41-3841	35
41-3841-1	35
41-3842	35
41-3842-1	35
41-3845-1	16
41-3852-1	339
41-3853	192
*41-3853-1	338, 339, 340
*41-3862	36, 50, 82
*41-3863	36, 50, 82
*41-3864	478, 479, 487
41-3866-30	36, 50, 476
41-3866-35	82, 88
41-3866-40	50, 82, 88
*41-3888-50	192, 338, 339
*41-3888-60	338, 339,340
41-3996-28-13	468A
41-3996-28-17	468A
41-4023-3-4	393
41-4023-8-10	83
41-4023-8-22	82
41-4069	386
41-4069-1	386
41-4103-2	490
41-4103-3	490
41-4146-1	36
*41-4180	442, 444, 446
*41-4180-1	442, 444, 446
41-4181	448
41-4181-1	448
41-4188	150
41-4188-1	150
41-4188-2	150
41-4190	150
41-4192	349
41-4196	150
*41-4198	304, 319, 322
41-4220	94, 253, 463
*41-4220-1	92, 93, 252
41-4222-253-3	90
41-4227	255, 256
41-4228-1	255, 256
41-4231	393
41-4231-3	393
41-4234	393
41-4283	349
41-4284	306
41-4284-1	306
41-4286	307
41-4292	307
41-4292-1	310
41-4292-2	307
41-4292-3	434
41-4293	305
41-4298	307
41-4299	373
41-4328-1	146
41-4328-2	141, 170
41-4376	36, 50
41-4407-1	155
41-4429-2	200
41-4440	450
41-4441	71
41-4445	69, 71
41-4447	71
41-4448	69
41-4449	69
41-4452-1	146
41-4483	92, 93, 463
41-4483-1	92, 93, 463
41-4484	93
41-4498	92
41-4541	80
41-4541-1	80
41-4542	80
41-4543-5	452
41-4544	452
41-4545	448
41-4556	307
41-4558	402
41-4570-13-6	417
41-4600	92
41-4600-1	92
41-4600-2	92
41-4601	92, 93, 463
41-4602-1	92, 93, 463
41-4614-29-18	28
41-4633	93
41-4638	93
41-4639-4	133
41-4691-1	455
41-4701	512, 525, 539
41-4764	155, 183, 183A
41-4778	249
*41-4858	138, 141, 185
41-4888-14-4	136
41-4888-14-7	194
41-4912-7	172
41-4931	386
41-4937	92
41-4971	394
41-4972	394
41-4977	21, 22
41-4977-1	21, 22
41-5024	130
41-5024-1	130
41-5024-2	130
41-5024-3	130
41-5024-4	130
41-5024-5	130
41-5024-6	130
41-5024-7	130
41-5035-17-2	463
41-5035-17-2A	463
41-5035-21-15	94
41-5035-24-8	94
41-5035-35-10	463
41-5035-35-10A	463
41-5035-50-31	94
41-5035-51-1	94
41-5035-53-13	94
41-5035-53-17	94
41-5035-55-25	94
41-5035-61-16	94
41-5035-61-19	94
41-5039	29, 47
41-5053-5	456
41-5106	89
41-5123	105, 474, 477
41-5123-1	105, 474, 477
41-5124	474, 477
41-5131	174
41-5132	451
41-5132-1	451
41-5132-2	451
41-5132-3	451
41-5132-4	451
41-5132-5	451
*41-5135	34, 46, 50
*41-5135-1	34, 40, 50
41-5135-2	127, 129
41-5135-3	127
41-5135-4	45, 46, 235
41-5135-5	45, 46, 235
41-5135-6	144
41-5135-7	144
41-5153	373
*41-5195	304, 319, 322
41-5205	92
41-5206	460
41-5248	402
41-5282-8	83
41-5317	150
41-5317-1	150
41-5362-24	336
41-5368	473
41-5368-1	473
*41-5437-1	302, 304, 319
41-5448	512, 525, 539
41-5448-1	512, 525, 539
41-5451	29
41-5451-1	29
41-5451-2	154
41-5451-3	154
41-5456	187
41-5459-60-48	251
41-5495-36	325
41-5495-38	82
41-5501	306
41-5533-0-20	100
41-5533-0-44	99
41-5533-0-56	155
41-5533-1-2	155
41-5533-1-6	155
41-5544	140, 167, 194
41-5580	187
41-5584	246
41-5595	28, 45
41-5603-76	314
41-5613	92
*41-5633-40-20	20, 99,100
41-5646	376
41-5647	377
41-5650	375

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
41-5652-5	375
41-5699	459
41-5708-10	393
41-5717-1	488
41-5741-1	167
41-5741-2	167
41-5743	390
*41-5746-1	211, 213, 512
41-5746-2	233, 354
41-5760-1	348, 373
41-5760-2	373
41-5760-3	475
41-5760-4	475
41-5762	251
41-5767-1	248
41-5773	512, 525, 539
41-5778-1	430
41-5876	92
41-5876-1	92
41-5876-2	92
41-5878-3	127
41-5878-4	29, 33, 151
41-5878-6	45
41-5881	8
41-5881-1	8
41-5888	188
41-5889-6	155
41-5889-8	155
41-5889-10	155
*41-5899	350, 351, 351A
41-5918	94, 463
41-5918-1	94, 463
41-5918-2	94, 463
41-5949-40-13	390
41-5949-40-17	390
41-5949-272-164	300, 301
41-5951-44-13	239
41-5951-48-22	327
41-5951-56-13	427, 428
41-5951-64-17	428, 429
41-5951-64-21	429
41-5951-96-17	429
41-5951-96-21	429
41-5972	460
41-5982	47
41-5982-1	47
41-5983	29, 44, 47
41-5987	354
41-5988	354
41-5996-1	188
41-5997	188
41-5997-1	188
41-5997-2	188
41-6060-8	361, 362
41-6063-77-32-3	383
41-6063-77-32-4	383
41-6063-78-32-2-	126
41-6063-81-40-2	202
41-6063-83-32-2	126
41-6063-90-32-2	383
41-6063-90-32-3	380, 387, 388
41-6063-90-40	187, 210
*41-6063-90-40-1	142, 143, 144
41-6063-90-64	386
41-6063-90-70-1	202
41-6068	354
41-6068-1	354
41-6068-2	354
41-6076	441
41-6077	441
41-6109	130
41-6109-1	130
41-6109-2	130
41-6109-3	130
41-6109-4	130
41-6109-5	130
41-6109-6	130
41-6109-7	130
41-6109-8	130
41-6109-9	130
41-6109-10	130
41-6109-11	130
41-6153	378
41-6154	378
41-6155	378
41-6156	378
41-6158	188
41-6159	188
41-6184	408
41-6187-1	452
41-6189-1	452
41-6190-3	452
41-6190-4	452
41-6190-5	452
41-6196	408
41-6196-1	408
41-6200	408
41-6277	408
41-6277-1	408
41-6300	349
41-6303	153
41-6305-1	378
41-6308	379
41-6309	379
41-6310	174
41-6310-1	174
41-6312	378
41-6315	378
41-6351	36, 50, 54
41-6462	373
41-6462-1	373
41-6462-2	373
41-6462-3	373
41-6468	379
41-6472	148A
41-6472-1	148A
41-6473	149
41-6479	476
41-6492	87
41-6492-1	87
41-6492-2	85
41-6492-3	85
41-6492-4	87
41-6492-5	85
41-6511-400	10
41-6511-401	10
41-6511-402	10
41-6511-403	10
41-6511-404	10
41-6541	476
41-6542-2	476
41-6542-3	476
41-6546	80
41-6546-1	80
41-6546-2	80
41-6546-3	80
41-6558	454
41-6588-1	454
41-6600-2	378
41-6600-3	378
41-6601	378
41-6601-1	378
41-6602-9	142
41-6602-12	140
41-6602-13	140
41-6602-17	142
41-6608	437
41-6615-4	197
41-6615-5	197
41-6616	193
41-6640	451
41-6641	450
41-6642	27
41-6642-1	27
41-6646	248
41-6647	248
41-6655	378
41-6657	462
41-6659	439
41-6746	365
41-6754	475
41-6754-1	470, 487
41-6754-2	487
41-6754-3	475, 485
41-6754-4	485
41-6754-5	487
41-6756	352
41-6796-30-1	288
41-6809	349
41-6810	349
41-6812	490
41-6812-1	490
41-6813	349
41-6814	378
41-6818	308, 316
41-6825	439
41-6826	439
41-6829	142
41-6829-1	142
41-6829-2	142
41-6829-3	142
41-6829-4	142
41-6830	142, 202, 203
41-6844-20-48	413, 490
41-6845	273
41-6881	369
41-6905	92
41-6905-1	92
41-6913	150, 206
41-6969-40-40	64
41-6969-44-48	62
41-6974-3	61
41-6974-4	61
41-6975-24-9	488, 489
41-7024	168, 192
41-7050	78
41-7051	78
41-7052-2	95
41-7052-3	95
41-7060-1	402, 406, 408
41-7074-1	464, 464A, 465
41-7081-1	459
41-7083	181
41-7083-1	181
41-7084	142, 146
41-7084-1	142, 146
41-7085-64-25	322
41-7085-72-13	378
41-7085-72-33	270
41-7101	95
41-7101-1	96
41-7170-13-56	240
41-7170-17-48	233
41-7171-12-32	222
41-7171-80-112	517, 531
41-7183	199
41-7190	172
41-7198	361
41-7280	146
41-7280-1	146
41-7282	146
41-7282-1	146
41-7288	482, 483
41-7288-2	468A
41-7292	475, 483
41-7293-1	471
41-7295	96, 129
41-7296-1	472, 473
41-7297	463
41-7297-1	463
41-7297-2	463
41-7371	21, 22
41-7372-1	21, 22
*41-7473	41, 82, 83
41-7504	142, 215
41-7504-1	142
51-7505	471
41-7509	366
41-7510	203
41-7511	514, 526, 541
41-7511-2	514, 526, 541
41-7517	481
41-7574-30-9	14, 333
41-7574-88-25	331, 333
41-7580	365
41-7581	151
41-7583	14
41-7583-1	14
41-7583-2	14
41-7583-3	14
41-7584	439
41-7584-1	439
41-7584-2	439
41-7584-3	439
41-7587	353
41-7588	365
41-7589-1	147
41-7589-2	147
41-7590-2	202
41-7590-3	202
41-7591	140, 202, 203
41-7591-1	202
41-7591-4	361
*41-7592	507, 509, 519
41-7592-1	519, 533
41-7609-5-24	103
41-7609-5-27	6
41-7609-5-28	27
41-7609-5-29	129
41-7609-5-31	6
41-7609-6-15	27
41-7609-6-18	103
41-7609-8-27	27
41-7609-8-35	27
41-7609-9-35	27
41-7609-9-36	27
41-7609-10-33	27
41-7609-10A-34	27
41-7632	26, 156
41-7636-5	334
41-7636-6	334
41-7642-2	466, 467
41-7647	55
41-7647-1	55
41-7647-2	54
41-7647-3	55
41-7647-4	55
41-7647-5	55
41-7654-2	308
41-7703	412
41-7707	148
41-7708	148
41-7710	251, 271
41-7712	366
41-7714	251
41-7715	251
41-7716	251

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
41-7717	250
41-7719	251
41-7760-3	437
41-7763	332, 335
41-7763-1	332, 335
41-7771	402
41-7771-1	402
41-7774	383
41-7774-4	383
41-7776-3	354
41-7776-4	354
41-7776-5	354
41-7776-6	354
41-7800-2	155
41-7804-1	393
41-7808	307
41-7808-1	310
41-7808-2	307
41-7808-3	186, 434
41-7808-4	307
41-7808-5	310
41-7808-7	307, 310
41-7811	437, 438
41-7813-2	373
41-7813-3	373
41-7814	201
41-7816-1	182
41-7844	365
41-7844-1	365
41-7846-1	306
41-7846-2	306
41-7846-3	306
41-7846-4	306
41-7846-5	306
41-7846-6	306
41-7846-7	306
41-7846-8	306
41-7846-9	306
41-7848	410
41-7853	54
41-7853-1	54
41-7855	31, 32
41-7855-1	31, 32
41-7906	310
41-7906-1	310
41-7906-2	310
41-7906-3	307, 310
41-7908	307
41-7908-1	309
41-7908-3	307, 310
41-7908-4	307, 310
41-7909	186
41-7915-1	311
41-7915-2	312
41-7915-3	311
*41-7916	186, 307, 310
41-7917	307, 310
41-7917-1	434
41-7917-2	384
41-7919	307, 310, 384
41-7919-1	307
*41-7940	307, 310, 384
*41-7941	307, 310, 384
41-7942	356, 357
41-7943	356, 357
41-7944	357
41-7945	357
41-7945-4	357
41-7945-5	357
41-7946	357
41-7948	357
41-7949	436
41-7952-1	382
41-7952-7	382
41-7952-9	381
41-7953	307
41-7953-1	309
41-7956	436
41-7957-8-24	149
41-7957-8-80	149
41-7957-10-34	182
41-7957-10-75	182
41-7964	316
41-7967	50
41-7967-1	50
41-7970	354
41-7979	382
41-7979-1	382
41-7979-2	382
41-7979-3	382
41-7981	382
41-7982	382
41-7983	382
41-7995	436, 437
41-7995-1	436, 437
41-7995-2	436, 437
41-8012-3	425
41-8013-3	425
41-8016	425
41-8031	380, 382
41-8031-2	167
41-8031-4	382
41-8064	384
41-8065	384
41-8066	384
41-8067	307, 310, 384
41-8068	384
41-8069	384
41-8074	311
41-8089	183, 183A
*41-8097	141, 141A, 142
41-8125-2	205
41-8125-3	205
41-8126	307
41-8126-1	307
41-8129-3	308
41-8180	412
41-8180-1	412
41-8181	354
41-8184	191
41-8184-1	191
41-8184-5	191
41-8184-6	191
41-8188-1	436
41-8193	355
41-8199-1	247
41-8202	191
41-8208-1	75
41-8209-35	86, 88
*41-8209-40	23, 24, 30
*41-8210	23, 30, 31
*41-8211	23, 24, 30
41-8216	436
41-8217-1	437
41-8219	54
41-8219-1	54
41-8261	331, 336
41-8264	43
41-8264-1	43
41-8265	327, 328
41-8266	43
41-8266-1	43
41-8267	440
41-8267-1	437
41-8270-7	152
41-8273	185
41-8279	44
41-8279-1	44
41-8279-2	45
41-8279-3	45
41-8279-4	45
41-8279-5	45
41-8300	47
41-8301	44
41-8301-1	44
41-8301-2	44
41-8301-3	44
41-8301-4	44
41-8301-5	44
41-8304	273
41-8305	433
41-8308-171-4	425
41-8321	328
41-8321-1	328
41-8324	42
41-8324-1	42
41-8324-2	42
41-8324-3	42
41-8324-4	42
41-8324-5	42
41-8328	305
41-8343	54
41-8343-1	54
41-8345-3	161
41-8345-4	161
41-8347-1	373
41-8350-1	330
41-8355	481, 482
41-8357	329
41-8360	54
41-8360-1	54
41-8363-1	349
41-8364-2	55
41-8364-3	55
41-8369	198
41-8369-1	198
41-8369-2	198
41-8369-3	198
41-8374	328, 329
41-8378-1	14
41-8379-1	14
*41-8380	25, 43, 50
41-8385	382
41-8388	45
41-8388-1	45
41-8395	382
41-8420-77-57	503, 518, 531
41-8423	42
41-8423-1	42
41-8424	42
41-8424-1	42
41-8427	186
41-8428	481, 482
41-8435	329
41-8435-1	329
41-8435-2	329
41-8443	381
41-8444	381
41-8445	381
41-8448	328
41-8453	326
41-8454	382
41-8454-2	382
41-8461	329
41-8462	381
41-8464	32
41-8464-1	32
41-8467	31, 32
41-8467-1	31, 32
41-8478	42
41-8478-1	42
41-8479	361
41-8487	92
41-8501	159, 160
41-8508-32-6	157
41-8508-32-8	157
41-8510-1	316
41-8511	314
41-8511-1	314
41-8541-39-44	179
41-8542	503, 518, 531
41-8553	328
41-8554	383
41-8557	201
41-8563	472
41-8565-1	397
41-8573	484
41-8578	433
41-8579-2	158
41-8579-3	158
41-8579-4	156
41-8579-5	156
41-8579-6	156
41-8579-7	156
41-8580-16	386
41-8582	180
41-8582-1	180
41-8589	36
41-8594-16-12	147
41-8596	186
41-8597	142
41-8600	330
41-8600-1	330
41-8603	355
41-8604	211, 213
41-8607	52, 53
41-8609	470
41-8609-1	470
41-8611-5	470, 486
41-8614	470, 487
41-8614-1	470, 487
41-8614-2	487
41-8614-3	487
41-8622	48
41-8623	380
41-8629	383
41-8630-1	383
41-8631	383
41-8638	380
41-8639	167
41-8700-3	306
41-8700-4	306
41-8702	454
41-8709	167
41-8712	473
41-8713	35
41-8713-1	35
41-8713-2	35
41-8713-3	35
41-8737-90L-135	125
41-8737-90R-135	125
41-8737-90L-145	125
41-8737-90R-145	125
41-8744	383
41-8745	331, 335
41-8746	330
41-8748	334
41-8749	476
41-8752	331, 335
41-8752-1	335
41-8753	334
41-8753-2	334
41-8755	331, 335
41-8756	331, 335
41-8756-1	331, 335
41-8757	361
41-8759	54
41-8802-56-22	76, 179
41-8802-56-23	179
41-8802-56-24	179
41-8802-56-25	179
*41-8802-56-28	28, 30, 62
41-8802-70-27	37

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
41-8805	331, 335
41-8805-1	335
41-8806	331, 335
41-8809	330
41-8809-2	330
41-8810-2	330
41-8810-3	330
41-8811-4	330
41-8811-5	330
41-8812-5	297
41-8812-7	297
41-8816-1	364
41-8819	402
41-8821-1	315
41-8821-2	315
41-8822	315
41-8825	471
41-8825-1	491
41-8825-4	491
41-8826	331, 335
41-8834-1	466
41-8835	477
41-8868	167
41-8878	408
41-8920	315
41-8924	144
41-8924-1	144
41-8925-13	176
41-8925-17	176
41-8925-19	176, 184
41-8925-23	176
41-8925-28	168
41-8925-36	176
41-8925-47	184
41-8925-49	176
41-8925-50	164
41-8925-51	194
41-8925-69	176
41-8925-83	176
41-8925-98	176
41-8925-111	176
41-8925-118	183A
41-8925-120	167
41-8925-160	183A
41-8925-223	184
41-8925-462	176
41-8925-477	183
41-8925-510	184
41-8941	26
41-8941-1	26
41-8947	26
41-8947-2	26
41-8947-4	48, 50
41-8951	65
41-8951-1	65
41-8952	65
41-8952-1	65
41-8958	331
41-8958-1	331
41-8959-1	393
41-9006-1	194
*41-9007	297, 345, 391
*41-9007-1	35, 154, 292
41-9007-4	489
41-9007-24	385
41-9007-25	385
41-9007-29	385
41-9009	331
41-9012-1	315
41-9013	334, 335, 336
41-9014	334, 335, 336
41-9016	250
41-9017	250
41-9042-2	143
41-9042-3	143
41-9044	331, 332
41-9044-1	331, 332
41-9046-1	412
41-9048	326
41-9048-1	326
41-9048-2	326
41-9048-3	326
41-9048-7	326
41-9051	326
41-9053-2	66
41-9055	325
41-9057	206
41-9088-70-16	408
41-9088-86-24	331
41-9100	345
41-9100-1	345
41-9106-1	291
41-9111	326
41-9113	326
41-9114	326
41-9115	326
41-9117	325
41-9117-1	325
41-9161	328, 329
*41-9163	161, 162, 163
41-9166-1	25
41-9166-2	25
41-9166-3	25
41-9166-4	25
41-9174	65
41-9174-1	65
41-9174-2	65
41-9174-3	65
41-9177-1	315
41-9178	319, 322
41-9179-1	315
41-9179-2	315
41-9207	365
41-9207-1	365
41-9207-2	365
41-9241-1	344
41-9254	315
41-9254-1	315
41-9255	315
41-9256	320
41-9268-5-16	465
41-9281-1	368
41-9282	328
41-9282-1	327, 328
41-9284	82, 83
41-9284-1	82, 83
41-9290-3	394, 403
41-9290-4	394, 405
41-9324	322
41-9324-1	322
41-9338	457
41-9384	452
41-9399-2	363
41-9404-1	84
41-9411	452
41-9411-1	452
41-9417	11
41-9417-1	11
41-9461	107, 108
41-9465	11
41-9466	172, 175
41-9466-2	172, 175
41-9468	296
41-9475	332, 333, 335
41-9477	185
41-9500	327
41-9501-32-8	327, 328
41-9505	464, 464A
41-9507	6
41-9508	46, 327, 328
41-9509	328
41-9514	316, 461
41-9526	402
41-9528	344
41-9541	35
41-9541-1	35
41-9542	47
41-9542-1	34, 47
41-9542-2	34
41-9543-1	115
41-9543-2	115
41-9546	48
41-9576	89
41-9604	27
41-9604-1	27
41-9606	454, 455
41-9608	309
41-9608-1	309
41-9616	307
41-9622-K75	161
41-9623-12	247
41-9623-13	247
41-9623-14	247
41-9623-15	247
41-9624-32-13	417
41-9624-152-98	248
*41-9638-30	148A, 426, 478
41-9642	491
41-9654	355
41-9656	89
41-9663	107
41-9663-1	107
41-9663-2	108
41-9664	107
41-9664-1	107
41-9664-2	108
41-9665	107
41-9665-1	107
41-9665-2	109
41-9665-3	109
41-9666	107
41-9666-1	107
41-9666-2	109
41-9666-3	109
41-9667	108
41-9667-1	108
41-9668	109
41-9668-1	109
41-9669	108
41-9669-1	109
41-9669-2	109
41-9670	108
41-9670-1	109
41-9670-2	109
41-9671	57
41-9671-1	57
41-9671-2	56
41-9672	57
41-9672-1	57
41-9674	56, 61, 66
41-9674-1	56, 61, 66
41-9674-2	67, 69, 70
41-9674-3	60
41-9674-4	60
41-9676	61
41-9676-1	61
41-9676-2	69, 70
41-9676-3	60, 61
41-9676-4	60, 61
41-9677	69, 70
41-9678-1	70
41-9678-2	69
41-9678-3	70
41-9679	70
41-9679-1	70
41-9680	67, 68, 69
41-9680-1	67, 68, 69
41-9680-2	68
41-9681	58, 59, 69
41-9681-2	59
41-9681-3	59
41-9682-1	67
41-9697	61
41-9706-1	307
41-9725-88	367
41-9728	305
41-9728-1	305
41-9730	307
41-9730-1	307
41-9730-2	307
41-9730-3	307
41-9731	307
41-9731-1	307
41-9731-2	307
41-9731-3	307
41-9732-4	310
41-9732-14	307
41-9732-16	307
41-9732-30	307
41-9735	307
41-9736	310
41-9736-1	310
41-9739	356
41-9755	150
41-9755-1	150
41-9756	164, 172
41-9758	137
41-9758-1	137
41-9761	292
41-9763	180, 181
41-9763-1	180
41-9772	397
41-9773	350
41-9774	315
41-9774-1	461
41-9774-2	315
*41-9775	466, 467, 507
41-9778	187
41-9779	186
41-9782	453, 456
41-9783	450
41-9791-1	394
41-9792-1	28
41-9792-2	28
41-9795	408
41-9797	150
41-9797-1	151
41-9798	151
41-9798-1	151
41-9798-2	151
41-9798-3	151
41-9799	147
41-9799-1	147
41-9800	250
41-9800-1	250
41-9800-2	250
41-9801	465
41-9805	430
41-9807	243, 244
41-9808	457
41-9811	458
41-9811-1	458
41-9811-2	458
41-9812	185
41-9817	457
41-9818	402
41-9819	402
41-9821	59
41-9822	312
41-9824	34
41-9824-1	34
41-9830	509
41-9831-43	310

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
41-9831-46	310
41-9831-53	310
41-9831-55	310
41-9833	137
41-9834	31
41-9834-1	31
41-9835	31
41-9835-1	31
41-9863	289
41-9865	171
41-9868	438
41-9869	315
41-9870	10, 11
41-9882	438
41-9882-1	438
41-9882-2	438
41-9892	439
41-9892-1	439
41-9892-2	439
41-9894	99
41-9902	376
41-9902-1	376
41-9908	433
41-9915	57
41-9915-1	57
41-9915-2	58
41-9915-3	58
41-9916	199
41-9960	452
41-9961	350, 351
41-9961-1	350, 351
41-9962	394
41-9963-1	351, 352
41-9966	439
41-9966-1	439
41-9974	461
41-9974-1	461
41-9974-2	461
41-9981	176, 475
*41-9981-1	469, 471, 472
*41-9981-2	176, 437, 467
41-9981-4	475
*41-9981-6	469, 471, 473
41-9981-7	437
41-9992	145
41-9992-1	145
41-9998	196
43-5340	454
43-5340-2	454
43-5341	454
43-5341-1	454
43-6493-400	107
43-6493-401	107
43-6493-402	109
43-6493-403	109
43-6494-400	107
43-6494-401	107
43-6494-402	109
43-6494-403	109
43-6668-400	130
43-6668-401	130
43-6668-404	130
43-6668-405	130
43-6988	252
43-6988-1	252
43-7806	454
43-7810-1	249
43-7853-400	436
43-7853-401	436
43-7863-1	437
43-7863-2	436, 437
43-7863-400	437
43-7870	437
43-7935-2	439
43-7935-400	439
43-7935-401	439
43-8148	433
43-8148-1	433
43-8148-400	433
43-8754	93
43-8754-1	93
43-8754-2	93
43-8756	93
43-8782	56
43-8782-1	56
43-8784	10
43-8788	10
43-8789	10
43-9073-2	357
43-9073-4	357
43-9073-400	357
43-9153	11
43-9165	248
43-9165-400	248
43-9175-400	248
43-9270	15
43-9271-5	15
43-9271-6	15
43-9274	15
43-9274-1	15
43-9284	15
43-9355	60
43-9355-1	60
43-9369	18
43-9369-1	18
43-9370	18
43-9370-1	18
43-9588	34
43-9588-1	34
43-9588-2	34
43-9588-3	34
43-9588-400	34
43-9771	194
43-9803	153
43-9803-1	153
43-10760-7	191
43-10760-9	190
43-10760-10	191
43-10760-400	190
43-10760-401	191
43-10811	146
43-10811-1	379
43-10811-2	379
43-10993	481
43-10993-400	481
43-10993-401	481
43-11072	250
43-11072-1	250
43-11181	192
43-11261-400	185
43-11261-403	185
43-11338	381
43-11338-400	381
43-11344-2	75
43-11344-3	75
43-11344-400	75
43-11353	381
43-11383	358
43-11383-400	358
43-11466	381
43-11466-400	381
43-11471	316
43-11472	316
43-11518	314
43-11518-1	314
43-11518-400	314
43-11518-401	314
43-11518-404	315
43-11518-405	315
43-11520-1	485
43-11520-4	485
43-11520-401	485
43-11520-402	485
43-11520-403	485
43-11520-405	485
43-11574	402
43-11667	26, 44
43-11667-402	26
43-11714	296
43-11993	214
43-11993-1	214
43-12031	332
43-12031-1	332
43-12315	353
43-12785	524, 538
43-12785-1	524, 538
43-12785-2	524, 538
43-12785-4	524, 538
43-12785-400	524, 538
43-13605	193
43-14203	515, 528, 541
43-14203-1	528
44-764	434
44-765	434
46-3851-400	169
46-3851-401	169
46-3852	169
46-3854-400	175
46-3854-401	175
46-3855-400	175
46-3855-401	175
46-4022	106
46-4051	168
46-4051-400	168
46-4051-401	168
46-4057	433
46-4057-400	433
46-4057-402	433
46-4128	188
46-4128-402	188
46-4212-1	434
46-4212-3	434
46-4212-4	434
46-4253	349
46-4253-400	349
46-4254-5	153
46-4869	436
46-4911	439
46-4911-1	439
46-4911-2	439
46-4911-3	439
46-4911-4	439
46-4913	311
46-4913-400	311
46-4913-401	311
46-4913-403	311
46-5302	358
46-5302-1	358
46-5305	362
46-5315	288
46-5315-6	288
46-5541	42
46-5857	247
46-5867	60
46-5867-1	60
46-5870-402	60
46-5870-403	60
46-5871	59
46-5871-1	59
46-5882	68
46-5886	68
46-5886-1	68
46-5888	68
46-5888-1	68
46-5891	57
46-5891-1	57
46-5903	250
46-5903-1	250
46-5917	248
46-5917-400	248
46-6158	28
46-6158-1	28
46-6158-400	28
46-6318	397
46-6318-3	397
46-6318-5	397, 398
46-6318-400	397
46-6318-401	397, 398
46-6318-402	397, 398
46-6502	361
46-6502-3	362
46-6502-5	361
46-6502-401	361
46-6502-402	361
46-6502-403	361
46-6507	174
46-6507-1	174
46-6508	174
46-6508-401	174
46-6512-400	85
46-6512-401	85
46-6512-402	85
46-6512-403	85
46-6513-400	84
46-6513-401	84
46-6513-402	84
46-6513-403	85
46-6520	11
46-6520-1	11
46-6530	28, 47
46-6530-1	28, 47
46-6538	349
46-6603	92, 463
46-6684-8	394
46-6684-400	394
46-6684-401	394
46-6684-404	394
46-6684-405	394
46-6684-406	394
46-6684-407	394
46-6957	29
46-6957-1	29
46-6959	44
46-6959-1	44
46-7095	141
46-7095-1	141
46-7180	476
46-7180-3	476
46-7180-400	476
46-7180-401	476
46-7180-402	476
46-7284	454
46-7284-1	454
46-7284-400	454
46-7284-401	454
46-7372	163
46-7372-1	163
46-7378	463
46-7378-2	463
46-7378-3	463
46-7563	250
46-7563-1	250
46-7563-401	250
46-7580	196
46-7580-1	196
46-7580-20	196
46-7580-21	196
46-7590	52
46-7590-1	52
46-7590-400	52
46-7590-401	52
46-7590-410	52
46-7622	382
46-7622-1	382

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
46-7622-2	382
46-7622-3	382
46-7624	382
46-7624-404	382
46-7631-405	183A
46-7631-406	183
46-7682	366
46-7682-400	366
46-7696	163
46-7696-1	163
46-7696-2	163
46-7696-400	163
46-7745	381
46-7745-400	381
46-7795	33
46-7880	182
46-7880-1	182
46-7880-400	182
46-7880-401	182
46-7880-402	182
46-7880-403	182
46-7921-402	165
46-7921-403	165
46-8013	63
46-8013-400	63
46-8014	63
46-8014-400	63
46-8050	45
46-8050-1	45
46-8053	249
46-8053-3	249
46-8053-400	249
46-8111	197
46-8111-1	197
46-8111-2	197
46-8111-3	197
46-8116	363
46-8116-3	363
46-8116-400	363
46-8116-401	363
46-8335	474
46-8335-11	474
46-8336	474
46-8336-7	474
46-8336-400	474
46-8336-401	474
46-8338	469
46-8338-2	469
46-8338-9	470
46-8339	474
46-8339-9	474
46-8360	475
46-8360-400	475
46-8373	141
46-8373-402	141
46-8521	353
46-8522	523, 538
46-8522-400	523, 538
46-8648	265
46-8648-1	265
46-8649	265
46-8649-1	265
46-8660	29
46-8660-7	29
46-8660-8	29
46-8660-9	29
46-8832	524, 538
46-8832-400	524, 538
46-8832-401	538
46-8832-402	538
46-8833	524, 538
46-8833-400	524, 538
46-8941	36
46-8974	444
46-8974-1	444
46-8975	50
46-8975-1	50
46-8983-400	470
46-8983-401	470
46-8983-402	470
46-8983-403	470
46-8987	478
46-8987-1	478
46-8987-6	478
46-8987-7	478
46-8987-9	478
46-8987-400	478
46-8987-401	478
46-8989	434
46-8989-3	434
46-8989-4	434
46-8989-400	434
46-9217	520, 533
46-9242	363
46-9293	373
46-9293-400	373
46-9294	373
46-9294-401	373
46-9333	519, 534
46-9333-400	520, 534
46-9339	238
46-9341	525, 539
46-9346	465
46-9414	226
46-9414-400	226
46-9414-401	226
46-9415	226
46-9415-1	226
46-9419-400	222
46-9419-401	222
46-9419-402	222
46-9419-403	222
46-9626	277
46-9626-400	277
46-9626-401	277
46-9766	150
46-9766-1	150
47-1141	153
47-1141-1	153
47-1141-402	153
47-1141-403	153
47-1305	34
47-1305-1	45
47-1309	88
47-1309-1	88
47-1331	5, 463
47-1331-3	463
47-1331-4	463
47-1331-6	463
47-1331-7	463
47-1337	381
47-1341-12	332
47-1343-23	335
47-1343-24	335
47-1501	348, 376
47-1501-1	348, 376
47-1501-402	376
47-1501-403	376
48-591	249
48-591-401	249
48-592	23
48-592-1	23
48-592-2	23
48-592-3	23
48-594-420	67
48-594-421	67
48-594-422	67
48-594-423	67
48-597-2	12
48-597-3	12
48-597-10	12
48-597-11	12
48-726	144
48-735	247
48-735-1	247
48-735-2	247
48-785	135
48-785-1	135
48-785-2	135
48-785-3	135
48-785-4	135
48-785-6	135
48-785-7	135
48-785-10	135
48-785-11	135
48-785-400	135
48-785-401	135
48-785-402	135
48-789	104
48-789-419	104
48-790	104
48-790-1	104
48-790-418	104
48-790-419	104
48-791	104
48-791-1	104
48-791-400	104
48-791-402	104
48-791-403	104
48-791-406	104
48-791-407	104
48-792	104
48-792-1	104
48-792-400	104
48-792-402	104
48-792-403	104
48-792-406	104
48-792-407	104
48-793	104
48-793-1	104
48-793-400	104
48-793-402	104
48-793-403	104
48-793-406	104
48-793-407	104
48-794	105
48-794-1	105
48-794-401	105
48-794-402	105
48-794-405	105
48-794-406	105
48-794-409	105
48-1061	102
48-1061-1	102
48-1061-400	103
48-1071	141
48-1073	178
48-1073-412	178
48-1073-413	178
48-1076	28
48-1076-1	28
48-1078	488
48-1078-400	488
48-1078-404	488
48-1190	364
48-1190-404	364
48-1190-410	364
48-1190-411	364
48-1194	478
48-1194-3	479
48-1194-4	479
48-1194-5	479
48-1194-8	479
48-1194-13	479
48-1194-400	479
48-1194-401	479
48-1194-403	479
48-1194-404	479
48-1194-405	479
48-1194-406	479
48-1194-407	479
48-1202	19
48-1202-1	19
48-1202-2	19
48-1202-3	19
48-1203	20
48-1203-1	20
48-1203-2	20
48-1203-3	20
48-1215-4	470
48-1215-5	470
48-1215-6	470
48-1215-7	470
48-1215-400	470
48-1215-401	470
48-1215-402	470
48-1215-403	470
48-1215-404	470
48-1215-405	470
48-1217	18
48-1217-1	18
48-1217-2	18
48-1217-3	18
48-1293	520, 535
49-1777-409	105
49-1777-410	105
49-1777-411	105
49-1777-412	105
49-1777-413	105
49-1777-414	105
49-1777-417	105
49-2002	175
49-2002-1	175
49-2002-401	175
49-2002-410	175
49-2002-411	175
49-2002-412	175
49-2002-413	175
49-2002-414	175
49-2015	179
49-2015-1	179
49-2301	247
49-2314-6	74
49-2314-406	74
49-2314-407	74
49-2405	58
49-2405-1	58
49-2539	30
49-2539-1	30
49-2631	92
49-2631-2	92
49-2631-4	93
49-2698	70
49-2698-1	70
49-2698-400	70
49-2698-401	71
49-2710	196
49-2710-1	196
49-2710-4	196
49-2710-5	196
49-2710-400	196
49-2710-401	196
49-2712-400	514, 526
49-2712-401	514, 526
49-2718-400	354
49-2776	402
49-2776-404	402
49-2776-406	402
49-2776-407	402
49-2875	507
49-2875-1	507, 520, 534
49-2875-400	507
49-2875-401	507
49-2875-402	507

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
49-2875-403	507
49-2876	31
49-2876-1	31
49-2876-400	31
49-2876-401	31
49-2900	155
49-2900-5	155
49-2900-400	155
49-2900-402	155
49-2900-405	155
49-2900-406	155
49-2902	508
49-2902-400	509, 521, 534
49-2902-401	509
49-2902-402	509
49-2902-403	509
49-2902-404	509
49-2914	192
49-2914-400	192
49-2936	37
49-2936-1	37
49-2936-400	37
49-2936-401	37
49-2940-2	486
49-2940-3	486
49-2940-4	486
49-2940-11	486
49-2940-400	486
49-2940-401	486
49-2940-402	487
49-2940-403	487
49-2940-405	487
49-2940-406	487
49-2947	158
49-2947-1	158
49-2947-2	158
49-2947-3	158
49-2952	158
49-2952-402	158
49-2976	92
49-2976-400	92
49-2976-402	92
49-2999	163
49-3022	331
49-3022-1	331
49-3029	335
49-3029-1	335
49-3030	336
49-3030-1	336
49-3030-11	336
49-3030-14	336
49-3030-15	336
49-3030-20	336
49-3037	182
49-3037-400	182
49-3045	64
49-3045-1	64
49-3045-2	64
49-3045-3	64
49-3045-400	64
49-3047	344
49-3047-1	344
49-3047-4	344
49-3047-6	344
49-3047-7	344
49-3047-9	344
49-3047-400	344
49-3047-401	344
49-3047-402	344
49-3056-4	329
49-3056-8	329
49-3056-400	329
49-3056-403	329
49-3056-408	329
49-3088	53
49-3129	46
49-3129-1	46
49-3133	397
49-3133-400	397
49-3133-405	397
49-3133-410	397
49-3188	519, 533
49-3189	153
49-3362	522, 535
49-3439	78
49-3439-1	78
49-3592	232
49-3646	513
49-3646-400	513
49-3646-401	513
49-3654	366
49-3685	229
49-3685-400	230
49-3719	233
49-3719-400	233
49-3719-403	233
51-7	169
51-10-26	296
51-10-34	296
51-15	169, 175, 224
51-16	169, 175
51-16-1	145, 224
51-17	145
51-17-2	224
51-19	376
*51-61-14-6	136, 144, 145
51-61-15-6	81
51-72	165
51-75	81
51-76	327
51-79	308
51-83	30
51-83-1	30
51-83-2	31
51-84	15
51-85	15
51-86	36
51-93	170
51-94	170
51-94-1	170
51-95	170
51-95-1	170
51-97	458
51-101	160
51-101-1	160
51-101-2	160
51-101-3	160
51-105	12
51-105-1	12
51-106	12
51-106-1	12
51-107	12
51-107-1	12
51-108	305
51-118-2	461
51-118-3	462
51-121	292
51-126	461
51-127	462
51-134-10-14	12
51-134-10-16	12
51-134-22-6	75
51-144-1	169, 175
51-149	381
51-150	382
51-156	459
51-157	459
51-157-1	459
51-157-2	459
51-157-3	459
51-158	461
51-163	296
51-167	434
51-168	434
51-172	151
51-174	151
51-175	448
51-175-1	448
51-176	6
51-176-1	6
51-176-2	6
51-176-3	6
51-176-4	6
51-179	355
*51-189	280, 281, 286
51-195-38	308
51-195-40	308
51-195-48	308
51-195-55	309
51-195-64	309
51-195-77	309
51-195-93	308
51-195-148	308
51-195-174	309
51-196	308, 309
51-197-5	312
51-197-6	311
51-197-8	311
51-197-10	310, 313
51-197-12	311
51-197-16	311
51-197-18	310
51-197-20	310
51-197-22	313
51-197-40	311
51-197-42	311
51-197-47	312
51-197-60	310
51-197-88	313
51-197-109	310
51-197-152	312
51-197-175	310
51-197-189	310
51-197-255	310
51-197-284	311
51-198	314
51-199-6	314
51-199-8	313, 316
51-199-10	313
51-199-12	313
51-199-18	317
51-199-28	313, 314
51-199-34	314
51-199-40	316
51-199-44	313
51-199-64	317
51-199-76	313
51-199-96	316
51-199-104	316
51-199-128	314
51-200	308
51-201	311
51-202	311
51-205-1	393
51-205-2	393
51-211	93, 438
51-211-1	438
51-213	257
51-213-2	257
51-213-7	257, 258
51-219	245
51-220	36, 50
51-223	11
51-226-24	188
51-226-32	188
51-235	402, 406
51-236	182
51-242	402
51-247	108
51-247-1	108
51-249	308
51-249-1	308
51-255	383
51-258	136
51-259	136
51-264-2	249
51-274	447
51-276	447
51-281	69, 70, 108
51-281-1	61, 66, 107
51-281-2	61, 66, 107
51-282	19, 20, 100
51-282-1	19, 20, 100
51-285	182
51-286	182
51-289	249
51-291	191
51-293	191
51-295	191
51-297-4	191
51-297-5	192
51-297-6	191
51-297-7	192
51-300	197
51-300-1	197
*51-315-48-16	503, 517, 518
51-329	305
51-330	487
51-330-1	487
51-331	487
51-331-1	487
51-535-48-20	165
51-336	174
51-337	197
51-337-1	197
51-337-2	197
51-339	331
51-339-1	331
51-355-3	378
51-381	197
51-381-1	197
51-382	197
51-382-1	197
51-383	197
51-383-1	197
51-384	183, 183A
51-385	183, 183A
51-388-8	385
51-388-9	*385
51-388-13	385
51-388-14	408
51-395-6	37
51-396-1	470
51-397	37
51-397-1	37
51-409	170
51-409-1	170
51-410	461
51-410-1	461
51-410-2	461
51-410-3	461
51-418	452
51-419	452
51-421	454
51-422	454
51-423-1-0	454
51-424	454
51-425	454
51-426	454
51-427	454
51-428	249
51-439	454

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
51-446-0-8	122
51-446-0-60	122
51-446-2-62	452
51-447-0-39	452
51-451	454
51-451-1	454
51-454-7-0	455
51-457	351, 352
51-463	438
51-468	134
51-471	82
51-471-1	14, 15
51-472	37
51-472-1	37
51-473	37
51-473-1	37
51-474	305
51-476	436
51-476-1	436, 437
51-476-2	436, 437
51-477	436
51-477-1	436
51-482	93
51-487	52
51-488	52
51-494	21
51-495	307
51-497	10, 11, 198
51-498	253
51-498-1	252
51-499-24-0	457
51-500-26-48	457
51-541	149
51-541-1	149
51-560	136
51-561-0-20	457
51-563	53
51-563-1	52
51-565	53
51-566	52
51-566-1	52
51-568	92
51-569	92
51-571	49
51-572	49
51-572-1	49
51-573-0-18	28, 47, 49
51-574-1-16	28, 47, 49
51-603	331, 336
51-604	105
51-605-1	335
51-605-2	332
51-606	27
51-606-1	27
51-606-3	27
51-606-4	27
51-606-6	27
51-606-7	27
51-606-8	27
51-606-9	27
51-610	85, 87
51-610-2	85
51-610-3	27
51-610-4	27
51-615-56-28	53
51-620	454
51-622-44-46	149
51-622-55-62	149
51-622-59-22	149
51-622-64-52	150
51-626	165
51-627-40-24	360
51-636	403
51-638-1	391
51-642	363
51-647	351
*51-664-50	338, 339, 340
51-664-60	338, 339, 342
51-671	37
51-671-1	37
51-674	402
51-675-6	382
51-675-7	388
51-675-8	388
51-676	331
51-704	452
51-713	136
51-713-1	136
51-716-138-15	156
51-720	252
51-761	63
51-761-1	38, 51, 147
51-761-4	63, 441
51-761-5	441
51-761-6	38, 51
51-762-1	441
51-762-4	66
51-764	115
51-764-1	115
51-775-0-28	459
51-776	130
51-776-1	131
51-776-2	131
51-776-3	131
51-776-4	131
51-776-5	131
51-776-6	131
51-776-7	131
51-776-8	131
51-776-9	131
51-776-10	131
51-776-11	131
51-778	436, 437, 440
51-779	196, 197
51-780	197
51-780-1	197
51-780-2	196
51-780-3	196
51-781	332
51-781-1	332
51-783	135
51-783-1	135
51-784	452
51-784-1	452
51-786	330
51-786-1	330
51-790	196, 197
51-791	96
51-793	135
51-794	135
51-794-1	135
51-796	434
51-800	356
51-847	352
51-872-4	438
51-873	438
51-888-2	63
51-888-3	63
51-900	434
51-930	102
51-930-1	101
51-931	66
51-938	393
51-947	410
51-948	36, 50
51-951	110
51-956	376
51-956-1	376
51-957	376
51-957-1	376
51-981	91
51-981-2	91
51-982	91
51-983	91
51-997	146
51-998	146
51-999	251
51-1085-1	410
51-1085-2	410
51-1086	292
51-1087	110
51-1088	71
*51-1089	469, 470, 476
*51-1089-1	466, 467, 481
51-1089-2	471
51-1092	397
51-1092-1	397
51-1094	397
51-1095-1	397
51-1095-2	397
51-1096-1	397
51-1096-2	397
51-1097	109
51-1107	438
51-1108-36-10	438
51-1161	71
51-1178-1	376
51-1178-2	376
51-1184	264, 265
51-1191	45
51-1191-1	45
51-1193	434
51-1197	364
53-6388	464
53-6388-8	464
53-6388-401	464
53-6388-402	464
53-6388-500	464
53-6388-501	464
53-6667	131
53-6667-1	131
53-6667-2	131
53-6667-3	131
53-6667-4	131
53-6667-5	131
53-6667-6	131
53-6667-7	131
53-6667-8	131
53-6667-9	131
53-6667-500	131
53-6667-501	131
53-6989	252
53-6989-1	252
53-7877	249
53-7977	437
53-7977-1	437
53-7977-2	437
53-7977-400	437
53-7977-402	437
53-9181	13
53-9181-1	13
53-9181-502	13
53-9356	58
53-9356-1	58
53-11715	296
53-12106	137
53-12106-1	137
53-12153-2	363
53-12153-3	363
53-12153-4	363
53-12153-500	363
53-12153-502	363
54-1425-423	109
54-1481-2	69
54-1481-3	69
54-1487-409	21
54-1487-410	21
54-1487-411	21
54-1487-412	21
54-1503	22
54-1503-1	22
54-1503-2	22
54-1503-3	22
54-1600	452
54-1600-500	452
54-1618	80
54-1618-1	80
54-1618-410	80
54-1618-411	80
54-1618-418	80
54-1618-419	80
54-1636	26
54-1636-402	26
54-1685	368
54-1685-409	369
54-1685-411	369
54-1685-412	369
54-1685-413	369
54-1685-414	369
54-1685-415	369
54-1685-417	369
54-1688	365
54-1688-400	365
54-1688-401	365
54-1691	82
54-1691-1	82
54-1696	192
54-1696-1	192
54-1753	383
54-1753-400	383
54-1753-407	383
54-1759	30
54-1759-1	30
54-1766	43
54-1766-1	43
54-1766-2	43
54-1766-3	43
54-1766-4	43
54-1766-5	43
54-1821	45
54-1821-1	45
54-1946	485
54-1946-1	485
54-1946-4	485
54-1946-5	485
54-1946-7	485
54-1946-400	485
54-1946-401	485
54-1946-402	487
54-1946-403	487
54-1946-404	487
54-1946-405	487
54-2044-400	14
54-2044-401	14
54-2044-402	14
54-2044-403	14
54-2044-404	14
54-2044-405	14
54-2044-406	14
54-2044-407	14
54-2044-408	14
54-2044-409	14
55-3518	353
55-3518-16	354
55-3518-22	354
55-3518-35	353
55-3518-49	353
55-3518-401	354
55-3518-405	353
55-3518-407	353
55-3518-409	353
55-3518-410	353
55-3652-1	165
55-3652-7	165

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
55-3652-12	165
55-3652-23	165
55-3652-405	165
55-3685	144
55-3685-1	144
55-4100	170
55-4100-1	170
55-4100-425	170
55-4100-426	170
55-4100-427	170
55-4100-428	170
55-4301	199
55-4301-400	199
55-4301-405	199
55-4764	6
55-4764-1	6
55-4766	6
55-4803-2	247
55-4803-3	247
55-4803-401	247
55-4803-408	247
55-4803-409	247
55-4803-410	247
55-4803-412	247
55-4803-415	247
55-4803-416	247
55-4817	16
55-4817-1	16
55-4817-400	16
55-4817-401	16
55-4817-402	16
55-4817-403	16
55-4817-404	16
55-4817-405	16
55-5272-11	376
55-5272-16	376
55-5272-17	376
55-5272-19	376
55-5272-20	376
55-5272-406	376
55-5272-407	376
55-5272-408	376
55-5292	155
55-5442	9, 92
55-5442-1	9, 92
55-5590	354
55-5590-5	354
55-5590-34	354
55-5590-35	354
55-5590-407	354
55-5591	354
55-5591-23	354
55-5591-400	354
55-5593	247, 252
55-5593-1	247, 252
55-5593-4	252
55-5593-5	252
55-5593-8	253
55-5593-9	253
55-5593-10	253
55-5593-401	252
55-5593-403	253
55-5593-405	252
55-5593-406	252
55-5593-407	252
55-5593-422	252
55-5684	137
55-5684-407	137
55-5684-411	137
55-5685	156
55-5685-1	156
55-5685-2	156
55-5685-3	156
55-5685-22	156
55-5685-23	156
55-5685-74	156
55-5685-75	156
55-5685-417	156
55-5685-418	156
55-5685-422	156
55-5685-423	156
55-5689-5	305
55-5689-6	305
55-5689-22	305
55-5689-23	305
55-5689-26	305
55-5689-29	305
55-5689-33	305
55-5689-35	305
55-5689-38	305
55-5689-43	305
55-5689-55	305
55-5689-56	305
55-5689-60	305
55-5689-72	305
55-5689-413	305
55-5689-414	305
55-5693-1	149
55-5693-4	149
55-5693-7	149
55-5693-10	149
55-5693-13	149
55-5693-16	149
55-5693-21	149
55-5693-28	149
55-5693-32	149
55-5785	199
55-5785-404	199
55-5785-405	199
55-5785-406	199
55-5832	182
55-5835	365
55-5835-16	366
55-5835-17	366
55-5835-400	365
55-5839	82
55-5839-1	82
55-5910-403	333
55-5910-404	333
55-5910-405	333
55-5910-406	333
55-5910-408	333
55-5910-409	327, 330
55-5910-410	327, 330
55-5910-415	333
55-5918	82
55-5918-1	82
55-5924	382
55-5929	40
55-5929-1	40
55-5929-84	40
55-5929-85	40
55-5929-400	40
55-5929-401	40
55-5929-406	40
55-5929-415	40
55-5929-416	40
55-5929-417	40
55-5929-418	40
55-5929-432	40
55-5929-433	40
55-5929-443	40
55-5929-444	40
55-5929-445	40
55-5929-446	40
55-5929-447	40
55-5929-448	40
55-5929-449	40
55-5929-450	40
55-5929-451	40
55-5929-452	40
55-5929-461	40
55-5929-462	40
55-5929-463	40
55-5929-464	40
55-5929-473	40
55-5929-474	40
55-5929-482	40
55-5929-512	40
55-5929-513	40
55-5929-514	40
55-5929-515	40
55-5929-542	40
55-5929-543	40
55-5932	355
55-5932-5	355
55-5932-8	355
55-5932-10	355
55-5932-11	355
55-5932-12	355
55-5932-13	355
55-5932-14	355
55-5932-15	355
55-5932-16	355
55-5932-17	355
55-5932-18	355
55-5932-19	355
55-5932-22	355, 356
55-5932-23	355
55-5932-400	355
55-5932-401	355
55-5932-402	355
55-5932-403	355
55-5932-404	355
55-5932-405	355
55-5932-406	355
55-5962	26
55-5962-1	26
55-5962-427	26
55-5962-428	26
55-5970	359
55-5970-1	359
55-5970-16	359
55-5970-24	359
55-5970-25	359
55-5970-404	359
55-5970-405	359
55-5970-406	359
55-5976	328
55-5976-1	328
55-5982-416	44
55-6017	54
55-6017-1	54
55-6017-2	54
55-6017-3	54
55-6017-15	54
55-6017-16	54
55-6017-401	54
55-6017-410	54
55-6017-411	54
55-6017-416	54
55-6017-417	54
55-6017-421	54
55-6017-422	54
55-6017-423	54
55-6017-451	54
55-6017-452	54
55-6017-453	54
55-6017-454	54
55-6055-4	408
55-6055-13	408
55-6055-15	408
55-6055-408	408
55-6055-411	408
55-6055-412	408
55-6055-414	408
55-6055-416	408
55-6055-417	408
55-6055-418	408
55-6055-421	408
55-6057	314
55-6057-1	314
55-6057-6	315
55-6057-400	315
55-6057-401	315
55-6057-402	315
55-6070	323, 325
55-6070-2	325
55-6070-4	325
55-6070-5	325
55-6070-15	325
55-6070-400	325
55-6070-401	325
55-6081	33
55-6081-1	33
55-6083	178
55-6083-405	178
55-6083-406	178
55-6087	64
55-6087-1	64
55-6087-3	64
55-6088-9	344
55-6088-34	344
55-6088-42	344
55-6088-47	344
55-6088-48	344
55-6088-53	344
55-6088-54	344
55-6088-60	344
55-6088-61	344
55-6088-62	344
55-6088-71	344
55-6088-72	344
55-6088-73	344
55-6088-82	344
55-6088-83	344
55-6088-88	344
55-6088-89	344
55-6088-92	344
55-6088-93	344
55-6088-401	344
55-6088-402	344
55-6088-404	344
55-6088-405	344
55-6088-406	344
55-6088-407	344
55-6088-408	344
55-6088-409	344
55-6088-410	344
55-6088-411	344
55-6088-412	344
55-6088-413	344
55-6088-414	344
55-6088-415	344
55-6088-416	344
55-6088-417	344
55-6088-418	345
55-6088-419	345
55-6088-420	345
55-6088-421	345
55-6088-422	345
55-6089	332
55-6089-1	332
55-6089-400	332
55-6089-401	332
55-6142	82
55-6142-1	82
55-6142-2	82
55-6142-5	82
55-6142-405	82
55-6154	83
55-6154-2	83
55-6154-3	83
55-6154-6	83

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
55-6154-403	83
55-6156	78
55-6156-1	78
55-6156-407	78
55-6156-408	78
55-6162	43
55-6162-1	44
55-6162-17	44
55-6162-18	44
55-6162-400	44
55-6162-401	44
55-6162-402	44
55-6185	273
55-6191	48
55-6191-1	49
55-6191-402	49
55-6191-403	49
55-6191-406	49
55-6191-407	49
55-6191-410	49
55-6191-411	49
55-6193	258
55-6193-42	258
55-6193-402	258
55-6194	260
55-6194-5	260
55-6194-401	260
55-6194-403	260
55-6195	262
55-6195-26	262
55-6195-401	262
55-6195-402	262
55-6195-403	262
55-6242-41	298
55-6242-42	299
55-6242-46	298
55-6242-49	299
55-6242-50	299
55-6242-65	297
55-6242-79	298
55-6242-84	298
55-6242-89	298
55-6242-90	299
55-6242-91	299
55-6242-92	299
55-6242-93	299
55-6242-126	297
55-6242-400	297
55-6242-401	297
55-6242-403	297
55-6242-404	297
55-6242-452	297
55-6242-454	298
55-6242-456	298
55-6242-457	298
55-6242-458	298
55-6242-459	298
55-6242-466	298
55-6242-467	298
55-6242-468	298
55-6242-469	298
55-6242-470	298
55-6242-471	298
55-6242-475	298
55-6242-476	298
55-6242-477	298
55-6242-480	298
55-6242-481	298
55-6242-484	298
55-6242-485	298
55-6242-486	299
55-6242-487	298
55-6242-499	298
55-6242-500	298
55-6242-502	298
55-6242-503	298
55-6242-504	299
55-6242-507	299
55-6242-509	299
55-6242-510	296
55-6242-511	299
55-6242-512	299
55-6242-513	299
55-6242-514	299
55-6242-515	299
55-6242-516	299
55-6242-521	299
55-6242-523	297A
55-6242-524	297A
55-6242-525	298
55-6242-527	298
55-6242-528	298
55-6242-529	298
55-6242-533	298
55-6242-535	299
55-6242-536	299
55-6242-537	299
55-6242-544	299
55-6242-547	297
55-6242-548	297
55-6242-549	297
55-6242-550	297A
55-6330	37
55-6330-1	37
55-6330-400	37
55-6331	37
55-6331-1	37
55-6331-400	38
55-6336	53
55-6336-400	53
55-6339	332
55-6339-1	332
55-6341	96
55-6341-1	96
55-6341-400	96
55-6341-401	96
55-6518	153
55-6522	155
55-6522-1	155
55-6539-1	74
55-6539-400	74
55-6539-401	74
55-6539-404	75
55-6612	140, 200
55-6612-69	200
55-6612-90	201
55-6612-91	201
55-6612-122	201
55-6612-465	200
55-6612-499	200
55-6612-500	200
55-6690	259
55-6690-1	259
55-6690-26	259
55-6690-27	259
55-6690-400	259
55-6690-401	259
55-6690-402	259
55-6700	330
55-6700-1	330
55-6700-2	330
55-6700-3	330
55-6700-4	330
55-6700-400	330
55-6704	386
55-6704-36	387
55-6704-57	387
55-6704-81	387
55-6704-400	387
55-6704-402	386
55-6705-5	387
55-6705-6	387
55-6705-7	388
55-6705-9	387
55-6705-16	387
55-6705-400	388
55-6705-401	389
55-6705-402	389
55-6705-403	389
55-7014	221
55-7028	286
55-7028-1	286
55-7028-402	286
55-7028-403	286
55-7315-1	211
55-7315-2	211
55-7315-23	211
55-7315-27	211
55-7315-52	212
55-7315-53	212
55-7315-54	212
55-7315-55	212
55-7315-56	212
55-7315-57	212
55-7315-58	212
55-7315-59	212
55-7315-60	212
55-7315-61	212
55-7315-62	212
55-7315-402	212
55-7315-404	213
55-7315-406	213
55-7315-407	213
55-7315-409	213
55-7315-413	213
55-7315-415	213
55-7315-422	213
55-7315-427	213
55-7315-428	213
55-7316	219
55-7316-400	220
55-7316-402	220
55-7316-404	220
55-7316-406	220
55-7316-408	220
55-7316-410	220
55-7316-414	220
55-7316-415	220
55-7316-416	220
55-7316-417	220
55-7316-418	220
55-7348	279, 291
55-7348-400	292
55-7348-401	292
55-7348-402	292
55-7348-403	292
55-7348-405	295
55-7348-407	295
55-7348-408	295
55-7348-409	293
55-7348-410	292
55-7350	5, 254
55-7359-400	254, 273
55-7359-401	254, 273
55-7359-402	254, 273
55-7359-403	254, 273
55-7359-404	273
55-7359-405	273
55-7362	255
55-7362-1	255
55-7362-400	256
55-7362-401	255
55-7362-402	256
55-7362-405	256
55-7362-406	256
55-7363	254
55-7363-1	254
55-7363-401	255
55-7363-406	255
55-7363-409	254
55-7363-410	254
55-7363-411	255
55-7363-412	254
55-7363-413	254
55-7363-414	254
55-7380	348, 373
55-7380-1	373
55-7380-3	373
55-7380-4	373
55-7380-5	374
55-7380-6	374
55-7380-7	373
55-7380-8	373
55-7380-9	374
55-7380-10	374
55-7380-11	374
55-7380-14	374
55-7380-16	374
55-7380-18	374
55-7380-20	374
55-7380-21	374
55-7380-23	374
55-7380-24	374
55-7380-27	375
55-7380-400	373
55-7380-401	374
55-7387	427
55-7470	5, 243
55-7470-15	244
55-7470-402	244
55-7470-403	243
55-7470-404	243
55-7470-405	243
55-7470-408	243
55-7483	9, 77
55-7483-1	9, 77
55-7483-56	77
55-7483-57	77
55-7483-84	78
55-7483-87	78
55-7483-111	78
55-7483-400	77
55-7483-401	77
55-7483-410	78
55-7521	424A
55-7534	502
55-7534-400	502
55-7534-401	502
55-7589	5, 502
55-7589-400	502
55-7589-401	502
55-7590	350
55-7590-400	350
55-7590-401	350
55-7598	153
55-7599	380
55-7599-1	380
55-7599-6	380
55-7599-10	380
55-7599-14	381
55-7599-400	380
55-7599-401	380
55-7599-402	381
55-7604-401	227
55-7604-402	227
55-7612	236
55-7635	479
55-7635-2	480
55-7635-5	480
55-7635-403	480
55-7635-404	480
55-7635-405	480

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
55-7672	340
55-7672-1	340
55-7672-400	340
55-7672-401	340
55-7679	138
55-7679-406	138
55-7679-417	138
55-7679-434	138
55-7679-443	138
55-7679-444	138
55-7679-445	138
55-7679-446	138
55-7679-448	138
55-7733	377
55-7733-1	377
55-7733-412	377
55-7733-413	377
55-7733-416	377
55-7733-421	377
55-7733-422	377
55-7736	428
55-7736-1	428
55-7736-7	428
55-8765	140, 190
55-8765-400	190
56-3852-500	169
56-3852-501	169
56-3855-500	174A
56-3855-501	175
56-3922-1	461
56-3954-3	457
56-3954-4	457
56-3989	245
56-4251	349
56-4251-500	349
56-4252	349
56-4252-402	349
56-4252-404	349
56-4252-406	349
56-4252-500	349
56-4965-500	461
56-4965-502	461
56-4965-504	461
56-4965-505	461
56-4965-506	461
56-5141	350
56-5141-503	351
56-5530	67
56-5530-1	67
56-5532	57
56-5532-1	57
56-5608	198
56-5608-500	198
56-5608-501	198
56-5866	60
56-5866-1	60
56-5868	60
56-5868-1	60
56-5872	59
56-5872-1	59
56-5874	59
56-5874-1	59
56-5876	59
56-5876-1	59
56-5880	58
56-5880-1	58
56-5883	69
56-5883-1	69
56-5887	68
56-5887-1	68
56-7583	512, 525, 539
56-7583-500	512, 525, 539
56-7583-501	512, 525, 539
56-7758	481
56-7758-1	481
56-7758-401	482
56-7789	328
56-7789-1	328
56-7986-501	420
56-7986-502	420
56-7986-503	420
56-7986-504	420
56-7986-505	420
56-7986-506	420
56-7986-507	420
56-7986-508	420
56-7986-509	420
56-7986-510	422
56-8969-500	284
56-8986	475
56-8986-1	475
56-8986-5	476
56-8986-6	476
56-8986-400	476
57-992	169
57-992-500	169
57-1195	247
57-1195-1	247
57-1195-3	247
57-1195-400	248
57-1195-401	248
57-1341	335
57-1341-7	335
57-1341-12	333
57-1341-500	332, 335
57-1527	368
57-1527-1	368
57-1527-10	368
57-1527-11	368
57-1527-13	368
57-1527-14	368
57-1527-15	368
57-1527-16	368
57-1527-18	368
57-1527-19	368
57-1527-401	368
57-1527-405	368
57-1527-406	368
57-1527-500	368
57-1527-501	368
57-1527-502	368
57-1527-503	368
57-1527-504	368
57-1527-505	368
57-1527-506	368
57-1527-507	368
57-1527-508	368
57-1527-509	368
57-1534	468A
57-1534-500	468A
58-598	12
58-598-1	12
58-598-500	12
58-598-501	12
58-598-507	12
58-598-508	12
58-598-509	12
58-598-510	12
58-713	67
58-777-400	22
58-777-401	22
58-777-402	22
58-777-403	22
58-778-400	23
58-778-401	23
58-778-402	23
58-778-403	23
58-779-400	23
58-779-401	23
58-779-402	23
58-779-403	23
58-784	95, 113, 132
58-784-1	95, 113, 132
58-817	196
58-817-1	196
58-1077	327
58-1077-1	327
58-1077-8	327
58-1077-402	327
58-1077-501	327
58-1077-502	327
59-1712	170
59-1712-1	170
59-1724	454
59-1724-1	454
59-1734-506	74
59-1734-507	74
59-1734-508	74
59-1791-401	315
59-1791-403	315
59-1847	349
59-1847-501	349
59-1847-503	349
59-1847-504	349
59-2012	437
59-2012-400	437
59-2012-401	437
59-2018	436
59-2018-500	436
59-2221-501	288
59-2221-502	288
59-2222-500	288
59-2222-501	288
59-2222-502	288
59-2314	74
59-2314-1	74
59-2314-500	74
59-2314-501	74
59-2406	58
59-2406-1	58
59-2407	58
59-2407-1	58
59-2408	57
59-2408-1	57
59-2409	57
59-2409-1	57
59-2410	15
59-2410-1	15
59-2410-509	15
59-2410-510	15
59-2410-515	15
59-2410-516	15
59-2411	18
59-2411-1	18
59-2411-412	18
59-2411-413	18
59-2712	513, 526
59-2712-500	514, 526
59-2712-501	514, 526
59-2719	353
59-2861	147
59-2875	520, 534
59-2902	521, 534
59-2916	509
59-2916-1	509, 521, 536
59-2916-2	509, 521, 536
59-2916-3	509, 521, 536
59-2916-505	521, 536
59-2923	143
59-2932-400	143
59-2932-402	143
59-2932-500	143
59-2990	332
59-2990-1	332
59-2990-8	332
59-2990-14	332
59-2990-19	333
59-2990-21	333
59-2990-25	333
59-2990-26	333
59-2990-401	332
59-2990-402	332
59-3034	76
59-3034-1	76
59-3034-500	76
59-3034-501	76
59-3034-502	76
59-3035	76
59-3035-1	76
59-3035-10	76
59-3035-11	76
59-3035-400	76
59-3035-401	76
59-3035-500	76
59-3035-501	76
59-3659	468A
59-3659-3	468A
59-3659-4	468A
59-3659-5	468A
59-3659-6	468A
59-3659-7	468A
59-3659-500	468A
59-3659-501	468A
61-5642	376
61-5642-1	376
61-5771	188
61-5837	101
61-5837-1	101
61-6590	104
61-6590-1	104
61-6672	90
61-6672-1	90
61-6674	90
61-6674-1	90
61-6866	90
61-6866-3	90
61-6866-400	90
61-6866-401	90
61-7032	61
61-7431	377
61-7431-1	377
61-7969	250
61-7969-1	250
61-7969-2	250
61-9034	115
61-9396-2	247
61-9846	350, 351
63-6388	464, 464A
63-6388-2	464, 465
63-6388-3	464, 464A
63-6388-4	464, 464A
63-6388-5	464, 464A
63-6388-600	464, 465
63-6388-601	464, 465
63-6685-2	457
64-1031	7
64-1031-1	7
64-1031-6	7
64-1031-7	7
64-1031-32	7
64-1031-33	7
64-1031-400	7
64-1031-401	7
64-1031-408	7
64-1031-409	7
64-1031-410	7
64-1031-411	7
64-1031-418	7
64-1031-419	7
64-1031-425	8
64-1031-426	8
64-1031-431	7
64-1031-432	7
64-1031-458	7

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
64-1031-459	7
64-1031-460	7
64-1031-461	7
64-1031-462	7
64-1031-463	7
64-1031-464	7
64-1031-465	7
64-1031-466	8
64-1031-467	8
64-1031-468	7
64-1031-469	7
64-1031-470	7
64-1031-471	7
64-1031-472	7
64-1031-473	7
64-1031-474	7
64-1031-475	7
64-1031-500	7
64-1031-501	7
64-1031-502	7
64-1031-503	7
64-1080	6
64-1080-1	6
64-1135-515	21
64-1135-516	21
64-1135-517	21
64-1135-518	21
64-1332-504	410
64-1332-509	410
64-1424	95, 106
64-1424-1	95, 106
64-1424-527	106
64-1424-528	106
64-1424-529	106
64-1424-530	106
64-1425	95, 108
64-1425-1	95, 108
64-1425-425	109
64-1425-426	109
64-1425-427	109
64-1425-428	109
64-1430	36
64-1430-1	36
64-1434	70
64-1434-1	70
64-1434-500	70
64-1434-501	70
64-1434-506	69
64-1490	9, 90
64-1490-1	9, 90
64-1490-400	90
64-1490-401	90
64-1491-1	248
64-1491-4	249
64-1491-501	248
64-1494	22
64-1494-1	22
64-1494-2	22
64-1494-12	22
64-1498	249
64-1498-1	249
64-1498-502	249
64-1504	18
64-1504-1	18
64-1504-2	18
64-1504-3	18
64-1504-8	18
64-1504-9	18
64-1504-23	18
64-1504-24	18
64-1505	17
64-1505-1	17
64-1505-10	18
64-1505-11	18
64-1505-20	17
64-1505-21	17
64-1512	14
64-1512-1	14
64-1512-8	14
64-1512-9	14
64-1512-402	14
64-1512-403	14
64-1512-530	14
64-1551	36
64-1551-1	36
64-1607	63
64-1607-1	63
64-1607-416	65
64-1607-417	65
64-1611-1	348
64-1680	75
64-1680-1	75
64-1680-500	75
64-1680-503	76
64-1680-507	76
64-1680-508	76
64-1680-511	76
64-1680-512	76
64-1693	141
64-1693-403	141
64-1693-605	141
64-1694	165
64-1694-1	165
64-1697	193
64-1697-1	193
64-1697-502	193
64-1697-511	193
64-1697-512	193
64-1698	348, 412
64-1698-6	412
64-1698-7	412
64-1698-14	412
64-1698-500	412
64-1698-501	412
64-1698-502	412
64-1698-503	412
64-1698-504	412
64-1698-505	412
64-1608-506	412
64-1741-1	510, 522, 536
64-1741-2	510, 522, 536
64-1741-4	510, 522, 535
64-1741-500	510
64-1741-506	522, 535
64-1831	9, 74
64-1831-1	9, 74
64-1831-418	74
64-1831-419	74
64-2054	82
64-2054-1	82
64-2054-406	82
65-3468	145
65-3468-41	145
65-3468-400	145
65-3468-414	145
65-3469	150
65-3469-421	150
65-3469-422	150
65-3508-500	454
65-3508-502	452, 454
65-3508-503	454
65-3584	96
65-3584-501	96
65-3684-711	138
65-3686-405	187
65-4093-4	377
65-4093-503	377
65-4093-505	377
65-4093-506	377
65-4093-507	377
65-4101-400	436
65-4101-502	436
65-4101-503	436
65-4101-504	436
65-4127	436, 439
65-4127-1	436, 439
65-4127-2	436, 439
65-4127-3	436, 439
65-4127-7	439
65-4139-500	432, 436
65-4774	95, 111
65-4774-1	95, 111
65-4774-500	111
65-4774-501	111
65-4781-13	56
65-4781-14	56
65-4781-500	56
65-4781-501	56
65-4781-502	56
65-4781-503	56
65-4781-504	56
65-4781-510	56
65-4781-516	56, 57
65-4781-517	56, 57
65-4781-521	56
65-4782-6	57
65-4782-7	57
65-4782-505	57
65-4782-510	57
65-4782-511	57
65-4783-6	67
65-4783-7	67
65-4784-502	68
65-4784-503	68
65-4784-508	67
65-4786	95
65-4786-1	95
65-4786-33	95
65-4786-34	95
65-4786-500	95
65-4786-501	95
65-4801	5, 247
65-4801-5	248
65-4801-13	250
65-4801-401	250
65-4801-403	250
65-4801-501	247
65-4801-502	247
65-4801-511	251
65-4801-512	251
65-4818-33	9
65-4818-34	9
65-4818-400	9
65-4818-401	9
65-4818-410	9
65-5025-425	43
65-5025-426	43
65-5034-500	41
65-5034-501	41
65-5034-502	41
65-5034-503	41
65-5034-509	41
65-5034-510	41
65-5034-513	41
65-5034-514	41
65-5280	378
65-5280-506	350, 351
65-5299	30
65-5299-1	30
65-5584	140
65-5584-21	140
65-5584-22	140
65-5584-500	140
65-5584-529	140
65-5589	136
65-5589-3	136
65-5589-7	136
65-5589-8	136
65-5589-9	136
65-5589-11	136
65-5589-12	136
65-5589-16	136
65-5589-17	136
65-5589-18	136
65-5589-19	136
65-5589-88	136
65-5589-401	136
65-5589-445	136
65-5589-500	136
65-5589-501	136
65-5589-502	136
65-5589-503	136
65-5589-508	136
65-5594	348, 393
65-5594-427	395
65-5594-500	395
65-5594-501	395
65-5594-502	395
65-5594-503	395
65-5594-504	395
65-5594-505	395
65-5594-509	395
65-5594-510	395
65-5594-511	395
65-5594-512	395
65-5594-513	395
65-5594-514	395
65-5594-515	395
65-5594-516	395
65-5594-517	395
65-5594-518	395
65-5594-519	395
65-5594-520	395
65-5594-521	395
65-5594-522	395
65-5594-523	395
65-5594-524	395
65-5594-525	395
65-5594-526	395
65-5594-527	395
65-5594-528	395
65-5594-529	395
65-5594-530	395
65-5594-531	395
65-5594-533	395
65-5594-534	395
65-5594-535	395
65-5594-536	395
65-5594-537	395
65-5594-538	395
65-5594-539	395
65-5594-540	395
65-5594-541	395
65-5594-542	395
65-5594-543	395
65-5594-544	395
65-5594-545	395
65-5594-547	395
65-5594-548	395
65-5594-549	395
65-5594-550	395
65-5594-551	395
65-5594-552	395
65-5594-553	396
65-5660	348, 410
65-5660-3	410
65-5660-5	410
65-5660-6	410
65-5660-17	410
65-5660-29	410
65-5660-34	410
65-5660-40	410
65-5660-49	410
65-5660-51	410

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
65-5660-54	410
65-5660-409	410
65-5660-414	410
65-5660-501	410
65-5660-502	410
65-5660-503	410
65-5660-504	410
65-5660-505	410
65-5660-506	410
65-5660-507	410
65-5660-508	410
65-5660-509	410
65-5660-510	410
65-5660-517	410
65-5660-518	410
65-5660-519	410
65-5660-520	410
65-5660-521	410
65-5660-522	410
65-5660-523	410
65-5660-524	410
65-5660-525	411
65-5660-526	411
65-5660-528	411
65-5660-529	411
65-5660-530	411
65-5660-531	411
65-5660-532	411
65-5660-533	411
65-5660-534	411
65-5660-535	411
65-5660-536	411
65-5660-537	411
65-5660-538	411
65-5660-539	411
65-5663	140
65-5667	144
65-5667-2	144
65-5667-3	144
65-5667-4	144
65-5667-8	144
65-5667-9	144
65-5667-11	144
65-5667-13	144
65-5667-14	144
65-5667-16	144
65-5667-17	144
65-5667-22	145
65-5667-23	145
65-5667-25	145
65-5667-26	145
65-5667-28	145
65-5667-29	145
65-5667-403	145
65-5667-405	145
65-5667-500	145
65-5667-501	145
65-5667-502	145
65-5667-503	144
65-5667-504	144
65-5667-505	144
65-5667-506	144
65-5667-507	144
65-5667-508	144
65-5667-509	144
65-5667-510	144
65-5667-511	145
65-5667-512	145
65-5671-21	148A
65-5671-22	148A
65-5671-28	148
65-5671-29	148A
65-5671-411	148A
65-5671-412	148A
65-5671-500	148A
65-5671-511	148A
65-5671-601	148A
65-5671-602	148A
65-5671-603	148A
65-5679	348, 391
65-5679-400	391
65-5679-401	391
65-5679-402	391
65-5679-407	391
65-5679-408	391
65-5679-411	391
65-5679-421	391
65-5679-422	391
65-5679-424	391
65-5679-425	391
65-5679-426	391
65-5679-431	391
65-5679-432	391
65-5679-439	391
65-5679-440	391
65-5679-441	391
65-5679-448	391
65-5679-450	391
65-5679-451	391
65-5679-460	391
65-5679-461	391
65-5679-462	391
65-5679-467	391
65-5679-468	392
65-5679-469	392
65-5679-470	392
65-5679-471	392
65-5679-500	392
65-5679-501	392
65-5679-502	392
65-5679-503	392
65-5679-504	392
65-5679-505	392
65-5679-506	392
65-5679-507	392
65-5679-508	392
65-5679-509	392
65-5679-510	392
65-5679-511	392
65-5679-512	392
65-5679-513	392
65-5679-514	392
65-5679-515	392
65-5679-516	392
65-5679-517	392
65-5679-518	392
65-5679-519	392
65-5697-520	392
65-5679-521	392
65-5679-522	391
65-5679-523	391
65-5679-524	391
65-5679-525	391
65-5679-526	391
65-5679-529	391
65-5679-530	391
65-5679-535	391
65-5679-536	391
65-5679-537	391
65-5679-538	391
65-5679-539	391
65-5679-540	391
65-5679-541	391
65-5680-1	327
65-5680-2	327
65-5680-4	327
65-5680-5	327
65-5680-500	254, 327
65-5689	305
65-5689-500	305
65-5689-502	305
65-5689-503	305
65-5689-508	350
65-5695	160
65-5695-1	160
65-5695-23	160
65-5695-27	160
65-5695-50	160
65-5695-51	160
65-5695-56	160
65-5695-57	160
65-5695-518	160
65-5695-519	160
65-5697	353
65-5697-19	353
65-5697-20	353
65-5697-401	353
65-5697-500	353
65-5697-501	353
65-5697-506	353
65-5715	390
65-5715-9	390
65-5715-10	390
65-5715-11	390
65-5715-12	390
65-5715-16	390
65-5715-17	390
65-5715-500	390
65-5715-501	390
65-5715-502	390
65-5780	146
65-5780-51A	146
65-5780-513	146
65-5780-515	146
65-5780-516	146
65-5780-517	146
65-5780-518	146
65-5780-521	146
65-5780-522	146
65-5780-523	146
65-5780-524	146
65-5780-525	146
65-5780-526	146
65-5780-527	146
65-5781-504	147
65-5781-507	146
65-5781-523	147
65-5781-526	147
65-5783-405	191
65-5783-406	191
65-5783-425	192
65-5783-607	192
65-5783-622	192
65-5783-624	192
65-5783-654	191
65-5783-655	192
65-5787	183
65-5787-500	183
65-5787-503	183
65-5787-505	183
65-5787-507	183
65-5787-508	183
65-5787-524	183
65-5787-525	183
65-5787-526	183
65-5787-527	183
65-5787-528	183
65-5787-529	183
65-5787-533	183
65-5787-535	183
65-5795	140, 202
65-5795-504	202
65-5795-510	202
65-5795-514	202
65-5795-520	202
65-5795-521	202
65-5795-524	202
65-5795-569	203
65-5795-571	202
65-5795-573	202
65-5795-575	203
65-5795-576	203
65-5795-577	203
65-5795-578	203
65-5795-579	203
65-5795-581	203
65-5795-582	203
65-5795-583	203
65-5795-584	203
65-5795-590	203
65-5795-592	203
65-5795-594	203
65-5795-596	204
65-5795-598	204
65-5795-607	202
65-5795-608	202
65-5796	141
65-5796-404	141
65-5796-408	141A
65-5796-500	141A
65-5796-502	142
65-5797	142
65-5797-400	142
65-5797-401	142
65-5797-404	142
65-5797-405	142
65-5797-408	142
65-5797-409	143
65-5797-412	143
65-5797-500	142
65-5821-2	406
65-5821-18	406
65-5821-32	406
65-5821-34	406
65-5821-40	406
65-5821-44	406
65-5821-118	406
65-5821-408	406
65-5821-429	406
65-5821-431	406
65-5821-437	406
65-5821-443	406
65-5821-444	406
65-5821-448	406
65-5821-501	406
65-5821-503	406
65-5821-504	406
65-5821-505	406
65-5821-506	406
65-5821-507	406
65-5821-508	406
65-5821-509	406
65-5821-510	406
65-5821-511	406
65-5821-514	406
65-5821-525	406
65-5821-526	406
65-5821-527	406
65-5821-530	406
65-5821-531	406
65-5821-535	406
65-5821-536	406
65-5821-540	406
65-5821-541	406
65-5821-543	406
65-5821-544	406
65-5821-545	406
65-5821-547	406
65-5821-548	406
65-5821-549	406
65-5821-551	406
65-5821-552	406

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
65-5821-553	406
65-5821-554	406
65-5821-555	407
65-5821-556	407
65-5821-557	407
65-5821-558	402
65-5821-562	407
65-5821-563	407
65-5821-564	407
65-5821-565	407
65-5821-569	407
65-5821-574	407
65-5821-576	407
65-5821-577	407
65-5821-578	407
65-5821-579	407
65-5821-581	407
65-5821-582	407
65-5821-583	407
65-5821-584	407
65-5821-586	407
65-5821-587	407
65-5821-588	407
65-5821-589	407
65-5821-590	407
65-5821-591	407
65-5821-592	407
65-5821-593	407
65-5821-594	407
65-5821-595	407
65-5821-596	407
65-5821-598	407
65-5821-599	407
65-5821-600	407
65-5821-601	402
65-5921-602	405
65-5821-603	407
65-5821-604	406
65-5821-605	406
65-5921-606	406
65-5821-607	406
65-5836	31
65-5836-1	31
65-5911	327, 334
65-5911-1	327, 334
65-5911-50	336
65-5911-66	336
65-5911-68	336
65-5911-69	336
65-5911-400	336
65-5911-600	336
65-5911-601	336
65-5915	31
65-5915-1	31
65-5915-500	31
65-5915-501	31
65-5915-502	32
65-5915-503	32
65-5915-504	32
65-5915-505	32
65-5925	5, 546
65-5931	164
65-5931-1	164
65-5931-20	164
65-5931-400	164
65-5931-500	164
65-5931-501	164
65-5931-504	164
65-5931-507	164
65-5931-508	164
65-5965	42, 54
65-5965-1	42, 54
65-5965-401	54
65-5965-403	54
65-5965-404	54
65-5965-428	55
65-5965-429	55
65-5965-430	55
65-5965-431	55
65-5972-421	54
65-5972-424	54
65-5972-501	54
65-5972-502	54
65-5972-503	54
65-5972-504	54
65-5972-510	54
65-5972-511	54
65-5972-512	54
65-5972-513	54
65-5975	328
65-5975-1	328
65-5975-410	329
65-5975-411	329
65-5975-504	329
65-5975-505	329
65-5975-511	328
65-5975-512	328
65-5977-421	45
65-5977-422	45
65-5977-507	45
65-5977-508	45
65-5982	44
65-5982-1	44
65-5982-500	44
65-5982-501	44
65-5982-502	44
65-5982-503	44
65-5983	44
65-5983-1	44
65-5983-500	44
65-5983-501	44
65-6000	158
65-6000-1	158
65-6000-400	158
65-6000-401	158
65-6000-425	158
65-6000-426	158
65-6000-431	158
65-6000-432	158
65-6002-407	34
65-6002-500	34
65-6002-501	34
65-6007	48
65-6007-1	48
65-6007-445	48
65-6007-446	48
65-6007-490	48
65-6007-491	48
65-6019	33
65-6019-1	33
65-6019-401	33
65-6019-402	33
65-6019-510	33
65-6019-511	33
65-6019-512	33
65-6019-513	33
65-6019-514	33
65-6019-515	33
65-6019-516	33
65-6019-517	33
65-6019-518	33
65-6019-519	33
65-6043	62
65-6043-1	62
65-6043-2	62
65-6043-3	62
65-6044	32
65-6044-1	32
65-6044-514	32
65-6044-515	32
65-6055-415	402, 408
65-6055-500	408
65-6093	330
65-6093-1	330
65-6093-12	330
65-6093-513	330
65-6164-77	346
65-6164-79	346
65-6164-83	346
65-6164-84	346
65-6164-430	346
65-6164-431	347
65-6164-515	347
65-6164-516	347
65-6164-517	347
65-6164-518	347
65-6242	254, 296
65-6242-600	296
65-6242-601	296
65-6242-602	296
65-6242-603	297
65-6242-604	298
65-6242-605	299
65-6242-606	299
65-6242-607	298
65-6242-608	298
65-6242-609	298
65-6242-610	298
65-6242-612	298
65-6242-613	298
65-6242-615	298
65-6242-616	299
65-6242-617	298
65-6242-618	298
65-6242-620	298
65-6242-621	298
65-6242-622	298
65-6242-623	296
65-6242-624	296
65-6242-625	296
65-6242-626	297
65-6242-627	298
65-6242-628	298
65-6242-631	297
65-6242-632	299
65-6242-633	299
65-6242-634	299
65-6242-635	299
65-6242-636	299
65-6242-637	299
65-6242-646	298
65-6242-647	298
65-6242-648	298
65-6242-649	298
65-6525	263
65-6525-501	263
65-6525-502	263
65-6525-503	263
65-6525-504	263
65-6525-505	263
65-6539	75
65-6539-3	75
65-6539-15	75
65-6539-500	75
65-6539-502	75
65-6539-503	75
65-6691-2	385
65-6691-3	385
65-6691-4	385
65-6691-5	385
65-6691-6	384
65-6691-7	385
65-6691-9	385
65-6691-10	385
65-6691-12	385
65-6691-14	385
65-6691-15	385
65-6691-16	385
65-6691-17	385
65-6691-18	385
65-6691-19	385
65-6691-20	385
65-6691-21	385
65-6691-22	385
65-6691-32	384
65-6691-503	385
65-6691-504	385
65-6705	386
65-6705-405	389
65-7604	226
65-7604-501	227
65-7672	341
65-7672-401	341
65-7672-500	341
65-7672-503	341
66-5529	67
66-5529-1	67
66-5531	56
66-5531-1	56
66-5860	61
66-5860-1	61
66-5861	61
66-5861-1	61
66-5862	61
66-5862-1	61
66-5863	60
66-5863-1	60
66-5864	60
66-5864-1	60
66-5865	60
66-5865-1	60
66-5873	59
66-5873-1	59
66-5873-600	59
66-5875	59
66-5875-1	59
66-5877	59
66-5877-1	59
66-5878	59
66-5878-1	59
66-5879	58
66-5879-1	58
66-5881	58
66-5881-1	58
66-7194	348
66-7194-501	348
66-7194-503	348
68-589	15
68-589-1	15
68-590	13
68-590-1	13
68-593-517	56
68-593-518	56
68-593-600	56
68-593-601	56
68-715	16
68-715-1	16
68-715-600	16
68-715-601	16
68-715-614	16
68-715-615	16
68-716	16
68-716-1	16
68-716-600	16
68-716-601	16
68-716-614	16
68-716-615	16
68-718	17
68-718-1	17
68-718-600	17
68-718-601	17

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
68-718-614	17
68-718-615	17
68-719	17
68-719-1	17
68-719-600	17
68-719-601	17
68-719-614	17
68-719-615	17
68-763-407	97
68-763-408	97
68-763-409	97
68-763-410	97
68-763-413	111
68-763-414	111
68-763-415	111
68-763-416	111
68-763-419	100
68-763-420	100
68-763-421	101
68-763-422	101
68-764-14	111
68-764-15	111
68-764-20	101
68-764-21	101
68-764-22	101
68-764-23	101
68-764-408	97
68-764-409	97
68-764-410	97
68-764-411	97
68-765-11	111
68-765-12	111
68-765-17	101
68-765-18	101
68-765-19	101
68-765-20	101
68-765-405	98
68-765-406	98
68-765-407	98
68-765-408	98
68-766-11	111
68-766-12	111
68-766-17	101
68-766-18	101
68-766-19	101
68-766-20	101
68-766-405	98
68-766-406	98
68-766-407	98
68-766-408	98
68-767-10	111
68-767-11	111
68-767-16	101
68-767-17	101
68-767-18	101
68-767-19	101
68-767-401	98
68-767-402	98
68-767-405	98
68-767-406	98
68-768-11	112
68-768-12	112
68-768-17	101
68-768-18	101
68-768-19	101
68-768-20	101
68-768-405	98
68-768-406	98
68-768-407	98
68-768-408	98
68-769-10	112
68-769-11	112
68-769-16	101
68-769-17	101
68-769-18	102
68-769-19	102
68-769-404	98
68-769-405	98
68-769-406	98
68-769-407	98
68-770-10	112
68-770-11	112
68-770-12	112
68-770-13	112
68-770-16	102
68-770-17	102
68-770-18	102
68-770-19	102
68-770-404	98
68-770-405	98
68-770-406	99
68-770-407	99
68-771-10	112
68-771-11	112
68-771-12	112
68-771-13	112
68-771-16	102
68-771-17	102
68-771-18	102
68-771-19	102
68-771-404	99
68-771-405	99
68-771-406	99
68-771-407	99
68-775-400	22
68-775-401	22
68-775-402	22
68-775-403	22
68-780-400	22
68-780-401	22
68-780-402	22
68-780-403	23
69-1734	74
69-1734-1	74
69-1734-600	74
69-1734-601	74
69-1735	74
69-1735-1	74
69-1735-600	74
69-1735-601	74
69-1787	245
69-1787-1	245
69-2220	288
69-2220-1	288
69-2220-605	288
69-2423	363, 385
69-2423-600	385
69-2423-601	363, 385
69-2423-602	363, 385
69-2423-603	363, 385
69-2423-604	363, 385
69-2423-605	363
74-1144-400	21
74-1144-401	21
74-1144-402	21
74-1144-412	21
74-1174	349
74-1174-7	349
74-1174-405	349
74-1174-600	349
74-1429-41	62
74-1433	61
74-1433-1	61
74-1433-2	61
74-1433-3	61
74-1500	9, 72
74-1500-1	9, 72
74-1500-515	73
74-1500-516	73
74-1500-600	72
74-1500-601	72
74-1552	36
74-1552-1	36
74-1611	348
74-1611-407	348
74-1611-500	348
74-1611-502	348
74-1611-503	348
74-1611-504	348
74-1611-505	348
74-1689	147
74-1689-607	147
74-1826	50
74-1826-1	50
75-3423-753	168
75-3423-754	168
75-3423-755	168
75-3424	140, 169
75-3440	174
75-3440-1	174
75-3440-413	174
75-3440-414	174
75-3440-506	174
75-3441	169
75-3441-1	169
75-3444	147
75-3444-423	147
75-3444-602	147
75-3444-612	147
75-3444-615	148
75-3445	140, 198
75-3445-1	140, 198
75-3448	376
75-3471-657	190
75-3471-679	190
75-3471-680	190
75-3471-681	190
75-3471-682	190
75-3471-686	190
75-3471-687	190
75-3471-688	190
75-3471-689	190
75-3471-692	190
75-3471-693	190
75-3471-696	190
75-3471-698	190
75-3471-702	190
75-3471-703	190
75-3471-733	190
75-3471-746	190
75-3471-781	190
75-3513	140, 178
75-3513-65	181
75-3513-132	181
75-3513-504	181
75-3513-531	181
75-3513-532	181
75-3513-600	178
75-3513-601	178
75-3513-602	178
75-3513-607	178
75-3513-619	181
75-3513-620	178
75-3513-622	178
75-3513-626	178
75-3513-628	178
75-3513-629	178
75-3513-633	181
75-3513-639	178
75-3513-642	178
75-3513-648	178
75-3513-649	180
75-3513-655	182
75-3513-657	183
75-3577	140, 185
75-3577-600	185
75-3577-601	186
75-3577-602	185
75-3577-603	185
75-3577-604	185
75-3577-605	186
75-3577-607	186
75-3577-609	186
75-3577-616	186
75-3577-618	185
75-3577-619	186
75-3577-620	185
75-3577-622	185
75-3577-623	185
75-3577-629	185
75-3577-632	185
75-3577-633	185
75-3577-634	185
75-3577-637	185
75-3577-645	186
75-3577-646	186
75-3577-647	185
75-3577-648	185
75-3577-650	185
75-3577-651	185
75-3577-652	189
75-3577-653	185
75-3577-654	186
75-3577-661	185
75-3590-15	105
75-3590-16	105
75-3590-20	105
75-3590-424	105
75-3590-620	95, 104
75-3590-621	95, 104
75-3590-622	105
75-3590-623	105
75-3684-1	137
75-3684-633	137
75-3684-640	138
75-3684-641	138
75-3684-642	138
75-3684-643	138
75-3684-674	137
75-3684-675	137
75-3684-678	137
75-3684-681	138
75-3684-704	137
75-3685-522	187
75-3686	186
75-3686-17	187
75-3686-400	188
75-3688-441	188
75-3686-442	188
75-3686-500	187
75-3686-501	187
75-3686-523	187
75-3686-525	187
75-3686-537	187
75-3686-544	187
75-3686-545	188
75-3686-546	188
75-3686-602	187
75-3686-603	187
75-3686-609	187
75-3686-634	187
75-3686-643	187
75-3686-646	187
75-4083	432, 441
75-4093-1	376
75-4093-600	376
75-4093-601	376
75-4093-602	376
75-4093-603	376

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
75-4093-605	376
75-4093-606	376
75-4093-607	377
75-4093-609	376
75-4122	140, 195
75-4122-1	140, 195
75-4122-642	195
75-4122-643	195
75-4122-647	195
75-4122-648	195
75-4122-654	195
75-4122-655	195
75-4122-657	195
75-4122-658	195
75-4133	350
75-4133-404	350, 351
75-4133-500	350, 351
75-4133-504	351
75-4133-505	350, 351
75-4771-715	27
75-4771-765	27
75-4771-826	6, 9
75-4771-827	6, 9
75-4772	6, 95
75-4772-1	6, 95
75-4772-4	103
75-4772-5	103
75-4772-13	103
75-4772-14	103
75-4772-17	103
75-4772-18	103
75-4772-601	103
75-4772-602	103
75-4772-604	103
75-4772-605	103
75-4772-609	102
75-4772-610	102
75-4781	56
75-4781-1	56
75-4783	67
75-4783-1	67
75-4799	9, 88
75-4799-1	9, 88
75-4799-600	88
75-4799-601	88
75-4799-602	88
75-4799-603	88
75-4799-618	88
75-4799-635	88
75-4799-636	88
75-4799-637	88
75-4799-638	88
75-4799-650	89
75-4799-651	89
75-4799-652	89
75-4805	9, 28
75-4805-1	9, 28
75-4805-105	28
75-4805-468	28
75-4805-469	28
75-4805-551	28
75-4805-600	28
75-4805-601	28
75-4805-633	28
75-4805-634	28
75-4805-769	28
75-4805-770	28
75-4806	9, 42
75-4806-1	9, 42
75-4806-746	42
75-4806-747	42
75-4808-600	82
75-4808-601	82
75-5025	43
75-5025-26	43
75-5025-600	43
75-5025-601	43
75-5127	113, 130
75-5127-1	113, 130
75-5580	378
75-5580-600	378
75-5580-607	378
75-5716-500	435
75-5716-501	435
75-5716-505	435
75-5716-508	435
75-5716-600	435
75-5781	146
75-5781-600	146
75-5783	190
75-5783-668	190
75-5783-669	190
75-5783-670	190
75-5783-671	190
75-5783-672	190
75-5783-673	191
75-5783-691	191
75-5783-692	191
75-5783-710	191
75-5783-711	191
75-5783-712	191
75-5783-713	191
75-5783-714	191
75-5783-715	191
75-5783-721	192
75-5783-722	192
75-5783-723	192
75-5788	183
75-5788-503	183
75-5788-504	183
75-5788-515	183
75-5788-525	183
75-5788-600	183
75-5788-602	183
75-5788-605	183
75-5788-606	183
75-5788-609	183
75-5821	348, 402
75-5821-700	405
75-5821-704	405
75-5821-705	402
75-5821-706	405
75-5985	42
75-5985-1	42
75-5985-600	42
75-5985-601	42
75-6002	33
75-6002-1	33
75-6002-604	33
75-6002-605	33
75-6164	254, 346
75-6164-600	346
75-6164-601	346
75-6164-602	346
75-6164-603	346
75-6164-604	346
75-6164-605	346
75-6164-606	346
75-6164-608	346
75-6164-609	346
75-6164-612	346
75-6164-614	346
75-6164-615	346
75-6164-616	346
75-6164-617	346
75-6164-618	346
75-6164-619	346
75-6164-622	346
75-6164-623	346
75-6164-624	346
75-6164-625	346
75-6164-626	346
75-6164-627	346
75-6164-628	346
75-6164-629	346
75-6164-630	346
75-6164-633	346
75-6164-634	346
75-6164-635	346
75-6164-636	346
75-6164-637	346
75-6164-638	346
75-6164-639	346
75-6344	36
75-6344-1	36
75-6344-600	36
75-6344-601	36
75-6525	261
75-6525-16	261
75-6525-601	261
75-6525-602	261
75-6525-605	261
75-6525-606	261
75-6691	384
75-6691-428	385
75-6691-600	385
75-6691-601	385
75-6691-602	385
75-6691-604	385
75-6691-605	385
75-6691-606	385
75-6691-607	385
75-6691-609	385
75-7315	140, 211
75-7315-600	211
75-7315-601	211
75-7315-602	211
75-7315-603	211
75-7315-604	211
75-7315-605	211
75-7336-600	289
75-7336-601	289
75-7336-603	289
75-7336-606	290
78-581	9, 56
78-581-1	9, 56
78-581-738	56
78-581-739	56
78-581-740	56
78-581-741	56
78-582	9, 67
78-582-1	9, 67
78-582-738	67
78-582-739	67
78-582-740	67
78-582-741	67
78-717	16
78-717-1	16
78-717-700	17
78-717-701	17
78-717-714	17
78-717-715	17
79-3021	331
79-3021-1	331
79-3021-6	331
79-3021-7	332
79-3021-11	332
79-3021-20	332
79-3021-21	332
79-3021-710	331
79-3021-716	331
81-2540	67
81-2564	247
81-2565	247
81-2818	249
81-3414	243, 244
81-3822-400	131
81-3822-401	131
81-4094	131
81-4094-1	131
81-4101	490
81-4102	490
*81-4547	350, 351, 351A
81-7801	362
81-7968	355
81-7969	355
81-8071	73
81-8071-1	73
81-8072	73
81-8072-1	73
81-8194	355
81-8507	381
81-8632	383
81-8634-400	332
81-8634-402	330, 334, 335
84-1123-407	19
84-1123-408	19
84-1123-419	19
84-1123-420	19
84-1123-421	19
84-1123-422	19
84-1123-700	19
84-1123-701	19
84-1124-407	19
84-1124-408	19
84-1124-419	19
84-1124-420	19
84-1124-421	19
84-1124-422	20
84-1124-700	19
84-1124-701	19
84-1127-409	21
84-1127-410	21
84-1127-421	21
84-1127-422	21
84-1127-500	21
84-1127-501	21
84-1130-13	111
84-1130-14	111
84-1130-19	100
84-1130-20	100
84-1130-21	100
84-1130-22	100
84-1130-407	97
84-1130-408	97
84-1130-700	97
84-1130-701	97
84-1580	5, 6
84-1580-1	5, 6
84-1580-8	8
84-1580-9	8
84-1580-10	8
84-1580-11	8
84-1580-14	8
84-1580-15	8
84-1580-16	8
84-1580-17	8
84-1580-700	8
84-1580-701	8
84-1580-702	8
84-1580-703	8
85-3425	140, 174
85-3425-604	174
85-3425-605	174
85-3540	456, 457
85-3540-503	458
85-3540-601	457
85-3540-604	457
85-3540-700	457
85-3540-701	457
85-3540-702	457
85-3540-703	458
85-3540-704	458
85-3540-705	457

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
85-3540-706	457
85-4808	9, 82
85-4808-1	9, 82
85-5005	9, 86
85-5005-1	9, 86
85-5005-700	86
85-5005-701	86
88-761-20	100
88-761-21	100
88-761-22	100
88-761-23	100
88-761-400	97
88-761-401	97
88-761-408	111
88-761-409	111
88-761-802	97
88-761-803	97
88-762-20	100
88-762-21	100
88-762-22	100
88-762-23	100
88-762-400	97
88-762-401	97
88-762-408	111
88-762-409	111
88-762-802	97
88-762-803	97
94-1125-407	20
94-1125-408	20
94-1125-419	20
94-1125-420	20
94-1125-421	20
94-1125-422	20
94-1125-806	20
94-1125-807	20
94-1126-421	20
94-1126-422	20
94-1126-500	20
94-1126-501	20
94-1126-806	20
94-1126-807	20
94-1128-13	111
94-1128-14	111
94-1128-407	96
94-1128-408	96
94-1128-419	99
94-1128-420	99
94-1128-421	99
94-1128-422	99
94-1128-800	111
94-1128-801	111
94-1128-802	96
94-1128-803	96
94-1129-20	100
94-1129-21	100
94-1129-22	100
94-1129-23	100
94-1129-400	96
94-1129-401	96
94-1129-408	111
94-1129-409	111
94-1129-800	111
94-1129-801	111
94-1129-802	96
94-1129-803	96
94-32204	468
94-32278	468
95-3684-800	138
95-3684-801	138
95-3684-802	138
95-3684-803	138

AVIALOGS.COM

AVIALOGS.COM

Section 4

STANDARD PARTS LIST

AVIALOGS.COM

STANDARD PARTS LIST

Part No.	Assy. Parts List Nos.
AN3-5A	463
AN3-6A	113, 114
AN3-10	455
AN3-10A	453
AN3-10H	456
AN3-13A	456A
AN3-14A	451
AN3-21	47
AN3-22	47, 48
AN3-22A	47
AN3-31A	244, 245
AN4-6	250
AN4-7	264
AN4-10	8, 264
*AN4-11	113, 451, 453
AN4-11A	165
AN4-12	116, 451, 456A
AN4-13	114
AN4-14	245
AN4-15	451
AN4-15A	455
*AN4-16	113, 114, 116
AN4-21	450, 451
AN4-24	115
AN4-36A	455
AN4-42	450, 453, 456
AN4-43	456
AN5-6	451
AN5-7	453
AN5-7A	456A
AN5-10	456, 456A
AN5-11A	8
AN5-12	451, 453
AN5-15	115
AN6-12A	8
AN6-17	248
AN-S-8	465
AN8-47	248
AN10-13	250
AN10-15	250
AN10-27	48
AN10-46	47
ANR-16	464
AN24-17	453
AN24-18	455
AN24-19	455
AN25-14	453
AN25-23	115
AN25-25	115
AN25-78	245
AN29-66	248
AN29-86	248
AN32-40	244
AN32-60	248
AN32-62	244
AN32-64	245
AN32-86	246
AN155-21S	451, 453, 456A
AN155-46L	451, 453, 456A
AN155-46S	451, 453
AN161-46RL	451
AN165-46L	451, 453
AN165-46S	451, 453
AN200-K3-1	134
AN210-3A	451
AN210-4A	453, 456A
AN286-1	245
*AN310-3	47, 48, 455
*AN310-4	8, 47, 114
*AN310-5	95, 115, 451
AN310-6	248
AN310-8	249
AN310-10	250, 273
AN316-7R	271
AN320-4	453, 455
AN320-5	115, 245, 453
AN320-9	6, 248
*AN320-12	244, 245, 246
AN320-14	6
*AN380-2-2	7, 8, 48
AN380-3-3	249
AN380-4-4	6, 248, 250
*AN380-4-5	6, 244, 245
AN380-5-10	248
AN393-9	455
AN393-13	455
AN510-10-8	103
AN510-10-9	8
AN510-10-16	456
AN515-6-8	115
AN515-8-7	455
AN515-8-8	113, 114, 115
AN515-8-10	113, 166, 463
AN520-10-7	455
AN520-10-8	273
AN520-10-10	273
AN520-10-12	273
AN520-10-16	451
AN520-10-24	451
AN520-416-10	273
AN525-10-6	138
AN935-10	455
AN960-8	463
*AN960-10	47, 48, 113
*AN960-D10	451, 453, 455
*AN960-416	8, 47, 114
AN960-A-416L	455
AN960-B-416	273
AN960-D-416	451, 453, 456A
*AN960-516	8, 115, 138
AN960-C-516	264
AN960-D-516	453, 456A
AN960-616	8
AN960-1016	250
AN960-1216	246, 250
AN960-1416	250
AN975-7	7
*AN3014	471, 472, 473
*AN3015	424, 466, 467
*AN3016	466, 467, 471
*AN3017	424, 466, 467
AN3018	471, 472, 490A
AN3019	473
AN3020	490A
*AN3050-4	243, 494, 495
*AN3050-6	243, 493, 495
AN3050-8	495
AN3050-10	495, 496
AN3050-16	494, 495, 496
AN3052-4	495, 496
AN3052-6	493, 494
AN3052-10	495, 496
*AN3054-4	243, 494, 495
AN3054-6	243, 495, 497
AN3054-8	495, 496
*AN3054-10	493, 494, 495
AN3054-12	493, 497, 498
AN3054-16	494, 495, 496
AN3064-4	243A, 500
AN3064-6	243A, 500
AN3064-8	500
AN3064-16	500
AN3066-4	243A, 500
AN3066-6	243A, 500
AN3066-8	500
AN3066-16	500
AN3097-2	484
AN3106-10S-2S	500
AN3106-12S-3S	500
AN3106-12S-4S	500
AN3106-14S-1S	500
AN3106-14S-2S	500
AN3106-14S-5S	500
AN3106-16S-1S	500
AN3106-16S-4P	500
AN3106-18-8P	493, 494
AN3106-20-1S	500
AN3106-20-5P	500
AN3106-20-6S	500
AN3106-22-4S	500
AN3106-28-5S	464, 500
AN3108-12-5S	501
AN3108-24-1P	501
*AN7501	351, 352, 377
AN7503-2	243A
*AN8004	388, 390, 435
*AN8005	316, 388, 390

BAC53-S6A	11
BAC53-7S	64
BAC53-S25.5A	11
BAC53-S105A	133
BAC54-S10.5A	90
BAC54-DD11A	90
BAC54-DD11.5A	90
BAC54-DD12.5A	90
BAC54-S12.5A	90
BAC54-S13.5	271
BAC54S15	271
BAC54-S22	73
BAC54-DD24	90
BAC54-S26A	351
BAC54-S30A	351
BAC54-DD30.5	15
BAC54-S33.5A	68
BAC54-DD34A	67
BAC54-DD36A	13
BAC54-S36A	13
BAC54-57A	125
BAC57-DD35A	13
BAC57-DD37.5A	13
BAC113S7	37
BAC113-8S	65
BAC113S10A	10
BAC113-10S	10
BAC113-A11S	45, 117
BAC113-S15A	224
BAC113-A15S	128
BAC113-A17S	127
BAC113-A19S	128, 148
BAC113-S32A	32
BAC113-S33A	31
BAC113-S34A	31
BAC113-S36A	31
BAC113-A37S	11
BAC113-39S	85
BAC113-41S	85
BAC113-42A	10
BAC113-49S	14
BAC113A52S	218
BAC113-A54S	218
BAC113-A55S	64, 218
BAC114-A9DD	137
BAC114-A-10DD	148
BAC114-S11A	107
BAC114-A11DD	137
BAC114-A11S	137
BAC114-S12A	107, 108
BAC114-A12DD	137
BAC114-A17S	128
BAC114-A18S	127
BAC114-A34S	28
BAC114-A35S	67
BAC114-S36	47
BAC114-36DD	10
BAC114-36S	34
BAC114-A37S	28, 34
BAC114-A38DD	18
BAC114-40S	10
BAC114-A41DD	199
BAC114-A41S	352
BAC114-A-42DD	148
BAC114-A43DD	199
BAC114-A43S	198
BAC114-A-44DD	107, 199
BAC114-DD44A	148
BAC114-S-44A	148
BAC114-A-44S	107
BAC114-S45A	107
BAC114-A45DD	148, 199
BAC114-A-46DD	148, 199
BAC114-A-46S	198
BAC114-A-47DD	148
BAC114-A-47S	198
BAC114-A-48DD	148
BAC114-ADD50	172
BAC114-ADD53	172
BAC114-A53DD	67
BAC114-A53S	67
BAC114-A56S	67
BAC114-A57S	64
BAC114-S58A	82, 83
BAC114-61S	24
BAC115-DD-9A	11
BAC115-DD-10A	11, 15
BAC115-DD-11A	11, 15
BAC115-11DD	14
BAC115-DD12A	11, 15
BAC115-12DD	14
BAC115-13DD	14
BAC115-14DD	14
BAC115A14S	137
BAC115-34S	95
BAC115-37S	34
BAC115-DD37A	11
BAC115-38S	34
BAC115A39S	28
BAC115A40S	28, 137
BAC115-DD41A	11
BAC115-DD42A	11
BAC115A-48DD	148
BAC115A-49DD	148
BAC115A50DD	148
BAC115A-51DD	172, 177
BAC115-54DD	14

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
BAC115A54S	172
BAC115ADD54	173
BAC115A-60S	172
BAC116A41S	138
BAC116A44DD	137
BAC116-DD45A	107
BAC116-DD46A	107
BAC116A-47DD	148, 199
BAC116A48DD	199
BAC116A51DD	216, 218
BAC116A53DD	217
BAC116A54DD	216, 217
BAC116A55DD	173
BAC116A55S	218
BAC116-56DD	14
BAC116A61DD	173
BAC116A62S	67
BAC116A64S	67
BAC117A63S	67
BAC117A65S	67
BAC203-4S	457
BAC203-5S	457
BAC203-23S	214
BAC204-4S	510
BAC204-11S	163
BAC204-12S	149
BAC204-61S	155
BAC206-10S	30
BAC206-11S	30
BAC274-62	239
*BAC283-10ST	32, 49, 83
BAC285-32S	214
BAC286-138S	459
BAC294-40ST	250
BAC294-48ST	250
BAC294-52ST	250
BAC324-4-89CS	158
BAC324-9S	282, 283
BAC324-10S	454
BAC324-17S	378
BAC324-33S	460
BAC324-63CS	239
BAC324-167-CS	158
BAC326-5S	454
BAC326-11ST	459
*BAC326-12S	283, 284, 284A
BAC326-17S	230, 453
BAC326-18S	270
BAC326-30ST	459
BAC326-34S	454
BAC326-44CS	238
BAC326-50S	434
BAC326-64S	230
BAC326-141ST	459
BAC327-12S	283, 284
BAC327-15S	300
BAC327-35S	195, 196
BAC327-155	300, 301
BAC328-108B	460
BAC330-104S	459
BAC335-48MB	245, 246
BAC343-2-84	378
BAC343-2-85	378
BAC343-2-123	25
BAC343-4-145	78
BAC343-4-156	78
BAC343-4-220	32, 49
BAC343-526	378
BAC343-4145	78
BAC344-2-148	44
BAC344-2-238	31, 32
BAC344-2-249	45
BAC344-4-96	223
BAC344-4-128	376
BAC344-4-190	225
BAC344-4-205	459
BAC344-4-363	224
BAC344-4-439	145
BAC345-4-194	201
BAC345-4-257	106, 108
BAC346-4-188	168
BAC346-4-194	198
BAC346-8-196	228
BAC346-8-281	442
BAC348-4-225	148
BAC348-4-256	445
BAC350-8-267	459
BAC364-6S	315
BAC364-9S	148
BAC364-17S	201
BAC364-49S	434
BAC366-8S	222
BAC366-18S	270
BAC366-21ST	270
*BAC450-4	32, 37, 38
*BAC535-10	255, 256, 277
*BAC535-12	276A, 333, 337
*BAC535-14	297, 345, 346
*BAC535-16	194, 281, 286
*BAC535-18	287, 297, 397
BAC535-20	274
*BAC535-22	293, 297, 393
BAC535-23	287, 295
BAC535-24	295
BAC535-27	290, 293, 295
BAC535-28	274, 297, 393
BAC535-30	295
BAC535-31	295A
BAC535-32	274
BAC537-2	129
BAC537-116	468A
*BAC538-2	103, 126, 129
BAC538-3	499
*BAC538-4	136, 458, 499
BAC538-5	499, 529, 542
*BAC538-6	499, 515, 529
BAC538-7	12, 499
*BAC538-8	136, 371, 499
BAC538-9	499, 529, 542
*BAC538-10	194, 443, 446
BAC538-11	529, 542
BAC538-12	499, 524, 538
BAC538-14	499
BAC538-16	499
BAC538-18	499
BAC538-20	499
BAC538-22	499
BAC539-2	105
BAC539-3	499
BAC539-4	499
BAC539-5	499
BAC539-6	499
BAC539-7	499
BAC539-10	443, 446, 499
BAC539-11	499
BAC539-12	499
BAC539-108	499
BAC539-109	499
BAC539-112	499
BAC539-114	499
BAC539-116	499
BAC539-118	499
BAC539-120	499
BAC539-122	499
BAC539-124	499
*BAC540-4	277, 292, 345
BAC540-4C	256, 297
BAC540-5	417, 515, 541
*BAC540-6	243A, 273, 276A
*BAC540-7	412, 515, 529
*BAC540-8	243A, 290, 292
BAC540-9	411, 499
*BAC540-10	256, 287, 290
*BAC540-12	334, 367, 386
BAC540-12C	297
*BAC540-14	274, 292, 332
*BAC540-16	273, 292, 367
BAC540-18	292
BAC540-20	297, 393, 394
BAC540-22	287, 499
BAC540-26	292, 293
BAC540-28	290
BAC540-30	292
BAC540-44	499
BAC540-318	255, 256
BAC542-22SF	297
BAC542-32S	371
BAC543-12-16	424A
BAC543-12-18	424A
BAC543-12-20	429
BAC543-22-12	297
*BAC548-8	507, 509, 510
BAC548-20	255
BAC560-10	433, 434
BAC560-36	93
BAC560-36A	93
BAC562-28	465
BAC569-20	266, 267, 268
BAC569-20H	273
BAC703	378
BAC750-9-94-5	240
BAC761-3	493, 494
BAC761-5	515, 529, 542
BAC764-2B	493, 494, 498
*BAC764-3B	493, 494, 497
BAC764-5B	515, 530, 542
BAC775-3	490, 524, 538
*BAC775-5	468A, 470, 479
BAC776-3-2	524
BAC776-3-5	524
BAC776-5-15	487
BAC779-10-24	537
BAC800-44	277
BAC800-44A	277
BAC800-60	290
BAC801-26	350
BAC801-40	349
BAC801-70	113
BAC801-70A	113
*BAC802-2-40	254, 255, 256
BAC802-2-45	505, 511
*BAC802-2-50	287, 510, 524
BAC802-2-55	523, 526, 542
BAC802-2-60	281, 286, 471
BAC802-2-65	287
BAC802-2-70	458
BAC802-2-100	287, 386
BAC802-2-150	292
BAC802-2-552	526
BAC802-3-45	512, 524, 538
BAC802-3-50	428
BAC802-3-54	300, 301
BAC802-3-60	271, 272
BAC802-3-64	300
BAC802-3-65	488
BAC802-3-100	296
BAC802-3-130	301
BAC802-6-40	272
BAC802-7-40	277, 278
BAC802-7-40E	278
BAC802-8-35	428
*BAC820-6	113, 115, 277
*BAC820-8	91, 113, 114
*BAC820-10	285, 293, 327
BAC820-14	91
BAC821-4	499A
*BAC821-6	499A, 515, 529
BAC821-8	499A
BAC821-10	499A
*BAC821-12	480, 499A, 515
BAC821-18-6	105
BAC821-18-10	105, 315
BAC821-20-6	105
*BAC821-114	499A, 515, 529
BAC821-116-6	499A
*BAC821-116-8	499A, 515, 529
*BAC821-116-10	499A, 504, 515
BAC821-116-12	529
BAC821-118-6	499
*BAC821-118-8	499, 515, 529
*BAC821-118-10	103, 243A, 499
BAC821-120	515
BAC821-120-6	499
*BAC821-120-8	499, 515, 529
BAC821-120-10	499, 529, 542
BAC821-122-6	499
BAC821-122-8	499
BAC821-122-10	499
BAC822-0	500
BAC822-2	500
BAC822-12	480
BAC822-14	500
BAC822-16	500
BAC822-18	103, 500
BAC822-20	500
BAC822-22	500
*BAC823-18	243A, 500, 515
*BAC823-20	243A, 500, 515
BAC958-4-8	147
BAC959-4-18	428
BAC1001-6	311, 461
BAC1001-12	311
BAC1001-18	462
BAC1001-27	461
BAC1001-29	307
BAC1002-8	92, 93, 463
BAC1002-10	437
BAC1002-20	464, 464A
BAC1002-21	465
BAC1002-64	256
BAC1094-1032	33
BAC1095-428	328
*BAC1095-1032	33, 41, 54
BAC1097-6-1055	151
BAC1097-10-63	80
BAC1097-10-855	213
BAC1097-10-105	129, 148A
BAC1099-4B	348
BAC1105-3	264
BAC1200B-40	256, 333, 336
BAC1200-B64	292, 298
BAC1235	468A, 470, 475
BAC1238-2	141
BAC1243-410S	275, 276
BAC1244-108	384
BAC1245-10	45, 147, 266
BAC1245-110S	236
BAC1246-6D	183, 267
BAC1246-8S	349, 387
*BAC1246-10	146, 200, 221
BAC1246-10D	164, 177, 194
*BAC1246-10S	71, 78, 86
BAC1246-110S	149, 225, 269
BAC1246-210S	78
*BAC1247-8	165, 203, 204
*BAC1247-8D	92, 176, 193A
BAC1247-8S	315, 464, 465A
*BAC1247-10	148A, 151, 215
*BAC1247-10	215, 148A, 151
*BAC1247-10S	141A, 142, 143
BAC1247-108S	154, 156, 221
*BAC1247-110S	144, 205, 206
BAC1249-108S	349
*BAC1249-110S	27, 42, 48

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
BAC1249-141-6	203
BAC1249-206D	193A
BAC1249-208S	193
BAC1249-210D	383
*BAC1249-210S	54, 55, 62
BAC1249-516S	141
BAC1249-616S	231
BAC1249-2416D	146
BAC1249-2416S	37, 163
BAC1249-2080	383
*BAC1252-10S	115, 117, 120
BAC1252-210S	152, 269
*BAC1253-10	33, 41, 45
*BAC1253-110	40, 41, 50
BAC1253-210	41
*BAC1253-410	33, 40, 41
BAC1254-10	266, 267
BAC1254-110	338, 343
BAC1255-45-101	85
BAC1257-412-122	85
BAC1257-412-123	85
BAC1257-424-105	85
BAC1303	359
BAC1304-40	242
BAC1304-51	232
BAC1305	359
BAC1322-2B	194
BAC1324-5-35	147
BAC1324-104-40	540
BAC1324-104-45	540
BAC1326-5-40	43
BAC1326-65-45	23
BAC1327-4-2	236
BAC1327-4-200	202
BAC1327-5-200	202
BAC1327-5-300	43
BAC1328-5-175	43, 88
BAC1328-5-312	147
BAC1328-6-250	23
BAC1330-1	114, 372
*BAC1330-101	78, 96, 103
*BAC1330-102	79, 96, 105
BAC1330-105	219
*BAC1446	126, 128, 218
BAC1447-4-4	201, 361
BAC1447-4-6	227, 350
BAC1447-6-4	185, 373
BAC1447-6-6	227, 356, 402
BAC1447-6-10	356, 364
BAC1447-6-12	364, 471
BAC1447-6-24	364
BAC1447-8-10	354, 356
BAC1447-8-14	185, 362
BAC1447-8-16	354
BAC1447-10-8	371
BAC1447-10-10	364
BAC1447-10-16	353
BAC1448-6-8	353
BAC1448-8-8	169, 175
BAC1448-10-14	169, 175
BAC1449-6-4	356
BAC1449-6-6	184, 356
BAC1449-6-8	419
BAC1449-6-10	356
BAC1449-6-12	370
BAC1449-8-8	169, 175
BAC1449-8-14	185, 227
BAC1449-8-16	185
BAC1453-2-3	251
BAC1456-10-10	227
BAC1460-8-85	383
*BAC1461	165, 243A, 464
BAC1468-10-22S	155
BAC1468-10-54	477
BAC1468-10-256	155
BAC1470-10-8	269
*BAC1470-10-8S	268A, 269, 270
BAC1550-8	282
BAC1550-9	433, 434
*BAC1550-11	267, 268, 273
BAC1550-14	378
BAC1550-15	465
BAC1550-17	93
BAC1601-8	240, 369
BAC1601-10	471
BAC1601-16	357, 364
BAC1601-24	370
BAC1601-32	419
BAC1601-34	476
BAC1601-36	358
BAC1601-38	510
BAC1601-40	194, 364
BAC1601-45	465
BAC1601-48	465
BAC1602-6	388, 389, 473
*BAC1602-8	383, 412, 507
BAC1602-10	472
*BAC1602-12	381, 488, 506
BAC1602-16	103, 386, 390
BAC1602-18	357
BAC1602-20	96, 381, 383
BAC1602-22	370
BAC1602-24	370, 469
BAC1602-30	383
*BAC1602-32	405, 509, 510
BAC1602-36	377, 504
BAC1602-38	410
*BAC1602-40	410, 508, 509
BAC1602-45	157
BAC1602-46	506, 527
BAC1602-48	389
BAC1602-64	255
BAC1602-116	389
BAC1603-5	62
*BAC1603-6	162, 217, 304
BAC1603-7	37, 162
*BAC1603-8	11, 13, 37
BAC1603-9	163, 187
*BAC1603-10	52, 217, 325
BAC1603-11	62, 433
*BAC1603-12	65, 162, 231
BAC1603-13	52, 227
*BAC1603-14	52, 65, 164
BAC1603-15	25
*BAC1603-16	15, 53, 62
BAC1603-17	159, 315
*BAC1603-18	14, 188, 277
*BAC1603-19	25, 201, 308
*BAC1603-20	76, 196, 297
*BAC1603-21	52, 100, 159
*BAC1603-22	62, 292, 325
BAC1603-23	138, 171, 325
*BAC1603-24	66, 74, 156
BAC1603-25	159, 179
*BAC1603-26	37, 64, 325
*BAC1603-27	52, 182, 368
*BAC1603-28	13, 75, 76
*BAC1603-29	66, 277, 387
BAC1603-30	325, 384, 434
*BAC1603-31	162, 171, 325
*BAC1603-32	26, 52, 160
BAC1603-33	365
*BAC1603-34	62, 138, 182
*BAC1603-35	20, 350, 351
*BAC1603-36	313, 353, 354
*BAC1603-37	13, 99, 177
*BAC1603-38	37, 65, 92
BAC1603-39	65, 149, 377
*BAC1603-40	162, 287, 297
*BAC1603-41	37, 62, 171
*BAC1603-42	174, 179, 314
BAC1603-43	162, 163, 376
*BAC1603-44	82, 159, 222
*BAC1603-45	25, 38, 157
*BAC1603-46	37, 156, 172
BAC1603-47	171, 468A
*BAC1603-48	156, 159, 168
BAC1603-49	66, 487
*BAC1603-50	14, 62, 82
*BAC1603-51	46, 141, 231
*BAC1603-52	82, 157, 159
BAC1603-53	25, 325
BAC1603-54	288
BAC1603-55	65, 147
*BAC1603-56	100, 168, 216
BAC1603-57	13, 37, 168
BAC1603-58	149, 172
BAC1603-59	150, 160, 470
BAC1603-60	65
BAC1603-61	159
*BAC1603-62	159, 188, 314
BAC1603-63	65, 160
*BAC1603-64	149, 150, 154
*BAC1603-65	159, 160, 182
BAC1603-66	171, 417
*BAC1603-68	72, 73, 159
BAC1603-69	73
BAC1603-70	277
BAC1603-71	187
*BAC1603-72	66, 157, 160
BAC1603-73	46
BAC1603-74	39
BAC1603-76	158, 352, 412
BAC1603-77	178, 325
BAC1603-78	39
BAC1603-79	53
*BAC1603-80	13, 55, 146
BAC1603-83	64, 159
*BAC1603-84	13, 37, 179
BAC1603-86	65, 178
*BAC1603-88	159, 160, 179
BAC1603-90	327
*BAC1603-91	28, 31, 32
BAC1603-92	55, 412
BAC1603-95	28
*BAC1603-96	24, 34, 44
BAC1603-100	25
BAC1603-101	13
BAC1603-102	314
BAC1603-104	138
BAC1603-107	172
BAC1603-112	10, 11, 500
BAC1603-123	85
BAC1603-131	453
BAC1603-133	96
BAC1603-134	138
BAC1603-136	96, 158A
BAC1603-137	96
BAC1603-140	15
BAC1603-141	217, 325
BAC1603-142	138
BAC1603-159	171
BAC1603-163	178
BAC1603-164	160
BAC1603-171	25
BAC1603-172	177, 215, 216
BAC1603-173	468
BAC1603-175	216
BAC1603-178	314
BAC1603-256	154
BAC1603-292	325
*BAC1604-6	39, 62, 158
BAC1604-7	46, 216
*BAC1604-8	13, 38, 46
BAC1604-9	65
BAC1604-10	25, 156
*BAC1604-12	13, 65, 158A
BAC1604-13	62, 64, 441
BAC1604-14	25, 52
BAC1604-16	83, 459, 462
BAC1604-18	13, 157
BAC1604-19	53
BAC1604-20	46, 83, 154
BAC1604-21	100, 442
BAC1604-22	252
*BAC1604-23	32, 49, 83
BAC1604-24	24, 52
BAC1604-25	365, 446
BAC1604-26	49, 83, 441
BAC1604-27	90
BAC1604-28	157, 178, 252
*BAC1604-29	46, 53, 222
BAC1604-31	169, 377
BAC1604-32	46, 157, 441
BAC1604-33	158, 377
BAC1604-34	90, 169, 178
BAC1604-35	147, 160, 444
*BAC1604-36	90, 157, 158
BAC1604-37	160
BAC1604-38	49, 155
BAC1604-39	178
*BAC1604-40	39, 49, 158
BAC1604-41	24
BAC1604-42	39, 253
BAC1604-44	53
BAC1604-45	99
BAC1604-46	25, 147, 253
BAC1604-49	49, 444
BAC1604-51	178
BAC1604-53	66
BAC1604-54	288
BAC1604-55	446
BAC1604-56	32, 49, 444
BAC1604-57	174, 174A
*BAC1604-58	64, 512, 524
BAC1604-59	32
BAC1604-60	28
BAC1604-61	24
BAC1604-63	441
BAC1604-64	64, 283, 284
BAC1604-66	25, 49
BAC1604-68	49, 73
BAC1604-69	158A
*BAC1604-75	38, 66, 214
BAC1604-76	38
BAC1604-77	365
BAC1604-78	33, 56, 57
BAC1604-79	20
BAC1604-80	67, 68
BAC1604-83	138
BAC1604-84	151, 397
BAC1604-85	46
BAC1604-88	151
BAC1604-93	158A
BAC1604-98	25
BAC1604-101	158A
BAC1604-104	18
BAC1604-106	18
BAC1604-107	442
BAC1604-108	109
*BAC1604-112	10, 11, 36
BAC1604-116	15
BAC1604-119	155
BAC1604-122	433
BAC1604-127	15
BAC1604-128	15
BAC1604-130	15, 147
*BAC1604-140	15, 16, 64
BAC1604-143	51
BAC1604-146	57
BAC1604-151	38
BAC1604-152	13, 155
BAC1604-158	462

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
BAC1604-159	171
*BAC1604-161	56, 57, 60
BAC1604-162	172
BAC1604-170	66
*BAC1604-172	12A, 13, 14
BAC1604-205	154
BAC1605-7A	138
BAC1605-8	200
BAC1605-10A	138
BAC1605-11	433
BAC-1605-11A	138
BAC1605-14	433
BAC1605-20	363
BAC1605-24	138
BAC1605-25	378
BAC1605-36	35
BAC1605-56	200
BAC1605-58	114
BAC1605-60	34
BAC1605-97	11
BAC1605-106	11
BAC1605-111	12
BAC1605-123	107
BAC1606-8	447
BAC1606-9	459
BAC1606-38	447
BAC1606-80	443
BAC1606-95	85
BAC1606-105	85
BAC1606-136	170
BAC1606-144	174
BAC1606-148	170
BAC1606-161	67
BAC1607-95	85
BAC1607-105	85
BAC1608-8	394
*BAC1608-10	350, 351, 351A
BAC1608-21	386-A
BAC1608-27	393
BAC1608-34	461
BAC1608-41	83
BAC1608-44	367
BAC1608-57	384
BAC1608-90	443
BAC1608-119	384
BAC1608-135	367
BAC1609-96	32
BAC1613-6	153
BAC1613-15	201
BAC1613-20	386
BAC1613-24	462
BAC1613-26	386
BAC1613-33	354
BAC1613-56	378
BAC1613-64	199
BAC1613-78	170
BAC1614-6	315
BAC1614-8	179
BAC1614-9	430
BAC1614-16	459
*BAC1614-19	162, 197, 434
*BAC1614-20	51, 141, 169
BAC1614-22	231
BAC1614-23	352
BAC1614-24	66, 146, 231
BAC1614-26	168, 359
BAC1614-27	230, 302
*BAC1614-28	11, 66, 161
BAC1614-30	179, 366
BAC1614-31	170, 366
*BAC1614-32	109, 146, 160
BAC1614-34	230, 234
BAC1614-35	365, 366
BAC1614-36	11, 353
BAC1614-37	167
*BAC1614-40	100, 157, 163
BAC1614-42	179
*BAC1614-43	52, 53, 215
BAC1614-44	65
BAC1614-45	216, 354
BAC1614-46	62, 167, 182
*BAC1614-48	64, 156, 196
BAC1614-50	62, 156, 167
*BAC1614-51	277, 512, 525
BAC1614-52	157, 387
BAC1614-53	52
BAC1614-56	167, 277
BAC1614-58	216
BAC1614-59	52
BAC1614-60	158
BAC1614-62	65, 158
*BAC1614-64	16, 17, 62
BAC1614-67	159
*BAC1614-68	37, 157, 158
BAC1614-69	325
BAC1614-72	157, 160
BAC1614-74	52
BAC1614-78	52, 423
BAC1614-80	195
BAC1614-94	170
BAC1614-106	441
BAC1615-19	8
BAC1615-21	181
BAC1615-26	50
BAC1615-31	365, 377
BAC1615-32	423
BAC1615-33	365, 377
*BAC1615-35	18, 20, 21
BAC1615-36	366
*BAC1615-42	18, 20, 21
BAC1615-56	98, 99
BAC1616-5	185
BAC1616-6	459
BAC1616-13	459
BAC1616-28	243A
BAC1770-32-2R	304
BAC1770-44-7R	304
BAC1770-48-0R	304
BAC1770-59-7	323
BAC1770-60-6	323
BAC1770-62-3R	304
BAC1770-106-0	322
BAC1770-107-0	322
BAC1770-116-5	322
BAC1770-118-4	322
BAC1770-124-7	323
BAC1770-125-6	323
BAC1770-132-5	304
BAC1770-133-3	304
BAC1770-134-2	319
BAC1770-136-2	304
BAC1770-139-4	319
BAC1770-167-4	302
BAC1770-167-7	302
BAC1770-187-6	322
BAC1770-188-0	322
BAC1770-194-5	323
BAC1770-195-0	323
BAC1770-195-5	322
BAC1770-197-6	322
BAC1770-199-2	302
BAC1770-201-2	302
BAC1770-225-5	319
BAC1770-228-4	304
BAC1770-230-3	304
BAC1770-231-3	319
BAC1770-234-0	319
BAC1770-237-6	319
BAC1770-253-0	302
BAC1770-257-0	302
BAC1770-261-0	323
BAC1770-285-2	302
BAC1770-294-7	302
BAC1772-27-7	453
BAC1772-90-4	456
BAC1772-108-1	458
BAC1774-73	462
BAC1774-82	462
BAC1774-228-4	462
BAC1775-152-5	450
BAC1775-161-5	450
BAC1778-291-2	456
BAC1778-308-1	453
BAC1778-309-3	456
BAC1779-95-6L	435
BAC1779-120-6L	435
BAC1780-24-0R	367
BAC1780-26-4R	302
BAC1780-29-4R	319
BAC1780-34-5R	323
BAC1780-35-4R	322
BAC1780-37-3R	322
BAC1780-39-7R	323
BAC1780-40-0R	323
BAC1780-40-2R	323
BAC1780-42-7R	322
BAC1780-43-3R	319
BAS1780-43-6R	302
BAC1780-44-2R	302
BAC1780-44-3R	319
BAC1780-44-5R	302
BAC1780-45-2R	302
BAC1780-50-5L	367
BAC1780-53-2L	326
BAC1780-55-4L	367
BAC1780-55-7R	302
BAC1780-60-1R	319
BAC1780-62-5R	322
BAC1780-64-3R	322
BAC1780-68-5R	323
BAC1780-70-1R	322
BAC1780-71-7L	326
BAC1780-74-5R	323
BAC1780-82-1L	326
BAC1780-94-L	326
BAC1780-129-7L	326
BAC1780-133-7L	326
BAC1780-135-L	326
BAC1780-138-7L	326
BAC1780-237-4L	462
BAC1780-270-2L	462
BAC1783-71-2L	450
BAC1783-71-7L	450
BAC1783-73-2L	450
BAC1783-73-4L	450
BAC1783-86-2L	453
BAC1783-89-0L	453
BAC1784-94-0L	450
BAC1784-95-4A	96
BAC1784-95-4L	96
BAC1784-100-1R	450
BAC1784-103-7L	458
BAC1784-111-4R	450
BAC1784-116-4L	453
BAC1784-118-4L	453
BAC1784-159-5L	450
BAC1784-246-2L	450
BAC1784-253-3L	450
BAC1784-255-5R	456
BAC1784-265-1L	450
BAC1784-268-4L	453
BAC1784-273	450
BAC1784-279-6R	456
BAC1784-350-4L	456
BAC1788-39-1	257
BAC1788-40-5	257
BAC1788-43-4	258
BAC1788-48-5	257
BAC1801-29-2L	456
BAC1801-35-5L	456
BAC1801-43-2R	456
BAC1801-45-7R	456
BAC1801-89-2A	96
BAC1801-89-2L	96
BAC1801-281-2L	456
BAC1804-5-3L	239
BAC1804-16-6R	239
BAC1804-21-3R	239
BAC1805-61-7	108
BAC1805-61-7A	108
BAC1805-115-5	390
BAC1805-121-0	390
BAC1806-82-0	453
BAC1807-49-3R	389
BAC1807-58-0R	389
BAC1807-68-0A	122
BAC1807-68-0L	122
BAC1807-91-1L	313
BAC1807-92-0L	180
BAC1807-94-1L	313
BAC1807-96-0L	311
BAC1807-97-1L	310
BAC1807-98-7L	313
BAC1807-99-0L	312
BAC1807-101-7L	312
BAC1807-106-1L	311
BAC1807-106-2L	310
BAC1807-107-3L	312
BAC1807-107-5L	312
BAC1807-108-0L	388
BAC1807-109-0L	306
BAC1807-110-0L	306
BAC1807-112-0L	181
BAC1807-112-3L	181
BAC1807-114-4L	312
BAC1807-114-5L	312
BAC1807-116-3L	313
BAC1807-117-3L	311
BAC1807-117-6L	311
BAC1807-117-7L	181
BAC1807-118-5L	306
BAC1807-119-5L	306
BAC1807-120-0L	389
BAC1807-120-2L	306
BAC1807-120-7L	306
BAC1807-122-6L	312
BAC1807-123-1L	312
BAC1807-127-3L	311
BAC1807-128-3L	311
BAC1807-131-1A	122
BAC1807-131-1R	122
BAC1807-131-4L	306
BAC1807-132-1L	306
BAC1807-197-6A	121
BAC1807-197-6R	121
BAC1807-261-7R	461
BAC1807-267-3A	122
BAC1807-267-3R	121
BAC1807-291-7R	461
BAC1807-295-1R	118
BAC1807-438-4L	308
BAC1807-505-41	462
BAC1807-512-0L	308
BAC1807-589-5L	462
BAC1808-53-0	355
BAC1808-56-2	355
BAC1808-73	302
BAC1808-74	302
BAC1818	453
BAC1818-81-1	456A
BAC1824-308-440	460
BAC1824-310-3624	460

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
BAC1824-310-3625	460
BAC1824-310-4040	460
BAC1824-311-2605	460
BAC1824-316-2781	460
BAC1824-316-2993	460
BAC1825-3	302, 355
BAC1825-6	96, 456
BAC1826-2	257, 258
*BAC1826-3	108, 302, 304
*BAC1826-6	96, 450, 456
BAC1826-23R	367
BAC1827-2L	239
BAC1827-2R	239
BAC1827-3L	197, 435, 460
BAC1827-4L	450, 456A
BAC1827-4R	450
BAC1827-6L	450
BAC1827-23A	122
*BAC1827-23L	122, 181, 306
*BAC1827-23R	118, 121, 122
*BAC1827-26L	96, 450, 456
BAC1827-26R	456
BAC1827-34	462
BAC1827-46	450
*BAC1828-23	146, 222, 223
*BAC1828-34	108, 118, 121
BAC1828-67	448
BAC1849-10	96, 133
*BAC1851-16	92, 94, 118
BAC1851-20	252, 253
*BAC1901	8, 76, 78
BAC1906-2	184
BAC1907-3D	185
BAC1907-9D	185
BAC1907-11S	80

NAS53-S4.5A	82
NAS53S5	31
NAS53-S5.5	36
NAS53-S6A	44, 117
NAS53-S11.5A	113, 114
NAS53-12.5A	268
NAS53-A13.5	128
NAS53-S16A	231
NAS53-17.5S	72
NAS53-S20	72, 73
NAS53-S22A	44, 55
NAS53-S22.5	55
NAS53-S23	55
NAS53-S23A	44
NAS53-25.5A	15
NAS53A27	109
NAS53A27.5	109
NAS53-S27.5A	236
NAS53-A30	109
NAS53-S32	62
NAS53-S32A	169
NAS53-S32.5A	231
NAS53-32.5A	169
NAS53A-33	70
NAS53A-33DD	177
NAS53S33.5	62
NAS53-S34	62
NAS53-S34.5A	96, 217
NAS53-S37A	76
NAS53-56	36
NAS53-56.5	36
NAS53-S105A	133
NAS53-531-5A	232
NAS54-S5.5A	30
NAS54-S7A	30
NAS54-DD7.5A	112
NAS54-S10A	30
NAS54-DD10.5A	112
NAS54-S12A	125
NAS54-DD13.5A	112
NAS54-DD17	73
NAS54-S20	73
NAS54-S22.5A	56, 57
NAS54A-23DD	12
NAS54-DD24.5	18
NAS54A25.5DD	199
NAS54A-26	199
NAS54-DD26A	165
NAS54A-26DD	199
NAS54A26.5	109
NAS54-DD26.5A	165
NAS54A26.5DD	109, 199
NAS54A27	109
NAS54A27DD	109, 199
NAS54A27.5	109
NAS54A27.5DD	109, 199
NAS54-S30	73
NAS54-DD31.5	15
NAS54-S31.5	15
NAS54A-32.5	70
NAS54-S32.5	61
NAS54-S32.5A	61, 71
NAS54A32.5DD	177
NAS54DD33A	61, 69
NAS54S33A	68, 174A
NAS54-33DD	70
NAS54A-33.5	59
*NAS54-DD33.5A	56, 57, 58
NAS54-S33.5A	56, 174A
NAS54A33.5DD	177
NAS54A34	70
NAS54-S34	61
*NAS54DD34A	13, 56, 60
NAS54-S34A	56, 57, 252
NAS54-DD34.5A	58, 68, 69
NAS54-S34.5A	58, 68, 69
NAS54A-35	59
*NAS54A-DD35A	56, 57, 60
NAS54A-S35A	60
*NAS54-S35A	56, 57, 60
NAS54-S35.5A	60, 65
NAS54-S36A	68, 69
NAS54-S36.5A	57, 60
NAS54-S37A	57, 58, 69
NAS54-S37.5A	60
NAS54-S41.5A	252
NAS54-S42A	253
NAS55A-5.5DD	15
NAS55A-6DD	15
NAS55A-6.5DD	15
NAS55-S7A	215
NAS55A-7DD	15
NAS55-S10A	30
NAS55-S11A	30
NAS55A-13	113
NAS55-S14A	215
NAS55-S17.5A	215
NAS55-S25.5A	240
NAS55-A-27DD	15
NAS55A-30DD	15
NAS55-DD32.5A	61
NAS55A-32.5DD	70
NAS55-S33A	68
NAS55A33.5	59, 177
NAS55-DD33.5	61
NAS55A33.5DD	177
NAS55A36.5	177
NAS55-S36.5A	56
NAS55-S37A	56
NAS55-S37.5A	68
NAS55-S55A	124
NAS56-S11A	175
NAS56-S13A	174
NAS56-S14.5A	215
NAS56A27.5DD	109
NAS56A30DD	109, 199
NAS56A34.5DD	177
NAS56-DD35A	174
NAS56-DD35.5A	169A
NAS56-S36A	56, 57
NAS56-DD36.5A	174
NAS56-S37A	68
NAS56-S37.5A	57
NAS56A37.5DD	177
NAS56A40DD	177
NAS56-DD40.5A	175
*NAS56-S40-5A	57, 68, 169A
NAS56-S41A	175
NAS56-S41.5A	174, 175
NAS56-DD43A	175
NAS56-S43A	175
NAS56-S44A	169A, 175
NAS56-S45.5A	169A
NAS56-S46.5A	175
NAS56-S50.5A	175
NAS57-S35A	175
NAS57-S35.5A	169A
NAS57-S36.5A	174
NAS57-S37A	169
NAS57-S37.5A	58
NAS57-S-40A	58
NAS57-S41.5A	175
NAS57-S42.5A	169A, 175
NAS57-S43.5A	175
NAS57-S44A	169
NAS57-S45A	169A
NAS57-S45.5A	169A
NAS60S43	57
NAS60-S44	243A, 244
NAS62-S44.5	56

Type GR	473
1E-757	327, 328
2E-3078	296
G3-168-M	244
G-3-217-A	246
11-BS-12	358
12PVMO	393
17-277	246
25-1F	225
27-077	246
30-616	426
30-1334	364
31-1176-2	488, 500
31-1176-3	500
31-1176-4	500
31-1176-7	500
31-1177-2	488, 500
31-1177-3	363, 488, 500
31-1177-4	500
31-1177-7	500
31-1310	364
31-8209-40	42
32A3376	481, 482
33A1757	506
33A2431-2	501
33A2431-3	363, 501
33A2431-4	501
33A2431-7	501
33A4739	363
33D5226	289, 448
33B5452-1	350
33B5452-2	350
33B5452-6	348, 366
33B5452-9	366
33B5452-41	427
33B5452-42	353, 375
33B5452-43	353, 375
33B5452-44	375
33B5452-45	375
33B5452-46	427
33A6180	443, 444
33A6180-1	443, 445
33A6182	443, 445
33A6182-1	443, 445
33A6185	443, 445
33A6186	443, 445
33A6186-1	443, 445
33A6187	443, 445
33A6196	443, 445
33A6197	443, 445
34G1346	351, 352, 379
34A1766-1	255, 256, 423
34A1766-2	366
34A1766-D2	348, 363
34A1766-3	353
34A1766-D3	375
34B2278	364
34B3842	364
35A2276	503, 517, 518
35A2277	231, 503, 518
35A2282	503, 517, 518
35A2959	512, 524, 538
35G3422	448
35B3441	448
35D3887	507, 508, 509
35A3896	424
35A3897	424
35A3898	424
35A3899	424
35A4273	501
35A5631	424
36B586	523
36A2212-1	348, 476, 508
36A2212-2	501, 527, 544
36A2212-3	481
36A2212-4	506, 527, 544
36A2212-6	515, 529, 542
36A2213-2	527, 544
36A2213-4	506, 527, 544
36A2213-6	515, 529, 542

AVIALOGS.COM

Part No.	Assy. Parts List Nos.
36A2214-3	498
36A2214-4	493, 497, 498
36A2214-5	494, 495
36B3422	484
36B3423	484
36D3467	81
36B3526	506
36B3529	506
36C4441	448
36E4442	448A
36E4443	448A
36G4465	372
36A4486-832	93, 315, 437
36B5356	511
36A5457	481
36A5458	481
36D5854	512, 524, 538
36G6167	526
36A6215-1	357
37B2675	424
37B2675-1	424
37A3528	297
37B3822-1	79
37B3822-6B	115, 140, 141A
37B3822-6C	167
37B3822-6D	170
37B3822-6E	176, 183, 194
37B3822-6K	167, 170, 194
37B3822-6X	167
37A4041-2	296, 297
37A4527	481, 482
37A4724	246, 248
37D4865	81
37D4865-1	484
37B-4962-1	105
37B-4962-2	105
37B-4962-3	105
37B-4962-4	105
37B4962-5	483
37B4962-7	483
37B4983	482, 483, 468A
37A5158	362
37A5159	362
37A5160	362
37A5161	362
37A5162	362
37A5222-9	374
37A5430	391
37A5810	431
37A5811	431
37D6114-5	297
37D6141	511
37G6167	514
37A6545	323
38B846B4	350
38A1531	501
38A1762	466, 467, 469
38G3046	363
38A6133	350
38D6273	423
39B846B8	251
39B846B10	403
39B1024-6	403
39B1024-8	386
39B1024-10	403
39B1024-16	384
39G1030-6W-33	403
39G1030-8-16	386
39G1030-8-21	403
39G1030-8-27	251
39G1030-10W16	403
39G1030-10W18	403
39G1030-12W-24	297
39G1030-12W-27	297
39G1030-12W-30	297
39G1030-414	350
39B2822-2	374
39B2822-3	374
39B2822-4	374
39B2823-2	348
39B2823-4	465, 476, 508
39B3334-1	348, 374
39D3339	362
39B3480-414	255, 256, 350
39B3481-414	350, 367
39B3481-1016	350
39A3756	437, 472, 473
39A3906-2	348, 374, 477
39D3922	364
39B4232	410, 344
H39B5343	423
H39B5344	424, 424A, 431
39B5786	476
40B887-014C-022-16	350
40A1252	246, 248
H40D3165	511, 523, 537
H40B3224	511
H40B3225	511
40A4334-8	403
40A4335-8	403
40A4336-8	403
40G5318	448A
40A5553	491
40D5858	423
40B6227	423
40A6364	349, 374
4007402	423
41-G1742	290, 448A
41-G1742-1	290, 448A
41D1831	476
41K3650	431
41E4555	448A
41A5055	423
41D7019	374
41G8920	364
41G9233	364
42-B5403	423
42-B5461	423
42-D5715	423
42-B5717	423
42-B5718	423
53-1C	225
68-701600A	358
Spec No. 94-32181	485
Spec No. 94-32182A	475
Spec No. 94-32277	464
Spec No. 95-28368	394
100PD1	255
FC-163-4-1	399
FC-163-4-2	399
FC-163-8-1	399
FC-163-9-1	399
FC-163-10-1	399
FC-163-10-2	399
217-HA	394
Type CB304	469, 490
M361-4-M361	240
365	358
DL-445	506
C492	235
C492-2	235
C492-4	235
C492-5	235
557-5	394, 397
567-1	471
660-2	510
774-6	410
786-1	464
0903½	431
1073-1	465
1125	185
A1512-2	273
1804-M-1	383, 471
1804-M-1-025	474
1815-M-1	183, 183A
M-2005-2D	425
2660	294
2980-8	369
2980-9	369
R-3082	490
A4050	438
RG4430-2	291
4550-2	465
5208	249
6067-8Z	290
6162-10Z	158
6264-10Z	158, 182
6407	358
07087	439
07100	249
07196	249
TFD8100	295A
8805	412
8831	372
13961	291
Spec No. 32181	485
Spec No. 32313	464
038244	412
Spec No. 40304	366
Spec No. 50131-C	465, 468, 475
066654	367, 394
070618	191, 412
073392	364
073410	187
D73914	393
074272	351, 352, 377
074837	348, 449, 362
0153316-10	364
0159268	435
0161366	364

ADDITIONAL COPIES of this publication may be secured on requisition, AAF Form 102, as prescribed in AAF Regulations 15-102. Submit requisition to: Commanding General, Air Service Command, Patterson Field, Fairfield, Ohio. Also, see T. O. No. 00-25-3 for details on distribution of Technical Orders. (Requests from Naval activities shall be submitted to: Chief of the Bureau of Aeronautics, Navy Department, Washington, D. C.)

AVIALOGS.COM

AVIALOGS.COM